

EM

SECTION

GI

MA

EM

LC

EF &
EC

FE

CONTENTS

<p>PRECAUTIONS2</p> <p style="padding-left: 20px;">Supplemental Restraint System "AIR BAG"2</p> <p style="padding-left: 20px;">Parts Requiring Angular Tightening.....2</p> <p style="padding-left: 20px;">Liquid Gasket Application Procedure2</p> <p>PREPARATION3</p> <p style="padding-left: 20px;">Special Service Tools3</p> <p style="padding-left: 20px;">Commercial Service Tools5</p> <p>OUTER COMPONENT PARTS6</p> <p>COMPRESSION PRESSURE.....9</p> <p style="padding-left: 20px;">Measurement of Compression Pressure.....9</p> <p>OIL PAN10</p> <p style="padding-left: 20px;">Removal.....10</p> <p style="padding-left: 20px;">Installation.....11</p> <p>TIMING BELT.....12</p> <p style="padding-left: 20px;">Removal.....12</p> <p style="padding-left: 20px;">Inspection.....14</p> <p style="padding-left: 20px;">Installation.....15</p> <p>OIL SEAL REPLACEMENT19</p> <p>THROTTLE BODIES21</p> <p style="padding-left: 20px;">Precaution.....21</p> <p style="padding-left: 20px;">Installation.....21</p>	<p>CYLINDER HEAD.....23</p> <p style="padding-left: 20px;">Removal.....24</p> <p style="padding-left: 20px;">Disassembly.....25</p> <p style="padding-left: 20px;">Inspection.....26</p> <p style="padding-left: 20px;">Assembly31</p> <p style="padding-left: 20px;">Installation.....32</p> <p>TURBOCHARGERS34</p> <p style="padding-left: 20px;">Removal.....34</p> <p style="padding-left: 20px;">Inspection.....36</p> <p>CHARGE AIR COOLERS.....39</p> <p style="padding-left: 20px;">Removal.....39</p> <p>ENGINE REMOVAL.....40</p> <p style="padding-left: 20px;">M/T Model.....41</p> <p style="padding-left: 20px;">A/T Model42</p> <p>CYLINDER BLOCK43</p> <p style="padding-left: 20px;">Disassembly.....44</p> <p style="padding-left: 20px;">Inspection.....44</p> <p style="padding-left: 20px;">Assembly51</p> <p>SERVICE DATA AND SPECIFICATIONS (SDS)54</p> <p style="padding-left: 20px;">General Specifications.....54</p> <p style="padding-left: 20px;">Inspection and Adjustment55</p>	<p>CL</p> <p>MT</p> <p>AT</p> <p>PD</p> <p>FA</p> <p>RA</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>EL</p> <p>IDX</p>
--	--	--

PRECAUTIONS

Supplemental Restraint System "AIR BAG"

The Supplemental Restraint System "Air Bag" helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), sensors, a diagnosis unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- All SRS air bag electrical wiring harnesses and connectors are covered with yellow outer insulation. Do not use electrical test equipment on any circuit related to the SRS.

Parts Requiring Angular Tightening


Use an angle wrench for the final tightening of the following engine parts:

- Cylinder head bolts
- Connecting rod cap nuts.

Do not use a torque value for final tightening.


The torque value for these parts are for a preliminary step.

Ensure thread and seat surfaces are clean and coated with engine oil.











Liquid Gasket Application Procedure

- Use a scraper to remove all traces of old liquid gasket from mating surfaces and grooves. Also, completely clean any oil from these areas.
- Apply a continuous bead of liquid gasket to mating surfaces. (Use Genuine Liquid Gasket or equivalent.)
 - Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide (for oil pan).
 - Be sure liquid gasket is 2.0 to 3.0 mm (0.079 to 0.118 in) wide (in areas except oil pan).
- Apply liquid gasket to inner surface around hole perimeter area. (Assembly should be done within 5 minutes after coating.)
- Wait at least 30 minutes before refilling engine oil and engine coolant.



PREPARATION

Special Service Tools

Tool number (Kent-Moore No.) Tool name	Description	
ST0501S000 (—) Engine stand assembly ① ST05011000 (—) Engine stand ② ST05012000 (—) Base	 <p style="text-align: center;">NT042</p>	Disassembling and assembling
KV10106500 (—) Engine stand shaft	 <p style="text-align: center;">NT028</p>	
KV10110001 (—) Engine sub-attachment	 <p style="text-align: center;">NT032</p>	
ST10120000 (J24239-01) Cylinder head bolt wrench	 <p style="text-align: center;">NT583</p>	Loosening and tightening cylinder head bolt
KV10111300 (—) Valve spring compressor	 <p style="text-align: center;">NT017</p>	Disassembling and assembling valve components
① KV10107501 (—) Valve oil seal drift ② KV10111400 (—) Attachment	 <p style="text-align: center;">NT026</p>	Installing valve oil seal
ST27180001 (J25726-A) Steering wheel puller	 <p style="text-align: center;">NT170</p>	Removing crankshaft pulley
KV10114400 (J38365) Heated oxygen sensor wrench	 <p style="text-align: center;">NT636</p>	Loosening or tightening heated oxygen sensor

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT









HA

EL

IDX








PREPARATION

Special Service Tools (Cont'd)



Tool number (Kent-Moore No.) Tool name	Description	
① EG14860000 (J38387) Push-pull gauge ② KV10112000 (—) Hook	 NT039	Adjusting timing belt tension
(J36467) Valve oil seal remover	 NT034	Removing valve oil seals
EM03470000 (J8037) Piston ring compressor	 NT044	Installing piston assembly into cylinder bore
ST16610001 (J23907) Pilot bushing puller	 NT045	Removing crankshaft pilot bushing
KV10111100 (J37228) Seal cutter	 NT046	Removing oil pan
WS39930000 (—) Tube presser	 NT052	Pressing the tube of liquid gasket
ST33200000 (J26082) Drift	 NT613	Installing camshaft oil seal a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia. c: 75 mm (2.95 in)
KV38100300 (J22888) Drift	 NT606	Installing front oil seal a: 32 mm (1.26 in) dia. b: 46 mm (1.81 in) dia. c: 54 mm (2.13 in) dia. d: 15 mm (0.59 in) e: 5 mm (0.20 in) f: 10 mm (0.39 in)
ST15310000 (J25640-B) Drift	 NT607	Installing rear oil seal a: 84 mm (3.31 in) dia. b: 96 mm (3.78 in) dia. c: 8 mm (0.31 in) d: 20 mm (0.79 in)

PREPARATION

Commercial Service Tools

Tool name	Description										
Spark plug wrench	 <p style="text-align: center;">16 mm (0.63 in)</p>	Removing and installing spark plug									
Pulley holder		Holding camshaft pulley while tightening or loosening camshaft bolt									
Valve seat cutter set		Finishing valve seat dimensions									
Piston ring expander		Removing and installing piston ring									
Valve guide drift		Removing and installing valve guide									
Valve guide reamer		Reaming valve guide ① or hole for oversize valve guide ②									
Engine slinger		<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="width: 25%;">Engine</th> <th style="width: 33%;">VG30DE</th> <th style="width: 42%;">VG30DETT</th> </tr> </thead> <tbody> <tr> <td>Front</td> <td>10005-30P10</td> <td>10005-40P10</td> </tr> <tr> <td>Rear</td> <td colspan="2" style="text-align: center;">10006-30P10</td> </tr> </tbody> </table>	Engine	VG30DE	VG30DETT	Front	10005-30P10	10005-40P10	Rear	10006-30P10	
Engine	VG30DE	VG30DETT									
Front	10005-30P10	10005-40P10									
Rear	10006-30P10										

OUTER COMPONENT PARTS




: N·m (kg-m, ft-lb)


OUTER COMPONENT PARTS

Turbocharger model

Right side



Left side



: N·m (kg-m, ft-lb)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT




HA

EL

IDX

SEM488EA

OUTER COMPONENT PARTS



: N·m (kg-m, ft-lb)

Measurement of Compression Pressure

1. Warm up engine.
2. Turn ignition switch off.
3. Release fuel pressure.
Refer to "Releasing Fuel Pressure" in EF & EC section.
4. Remove all spark plugs.
5. Disconnect camshaft position sensor harness connector.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



6. Attach a compression tester to No. 1 cylinder.
7. Depress accelerator pedal fully to keep throttle valve wide open.
8. Crank engine and record highest gauge indication.
9. Repeat the measurement on each cylinder as shown.

Always use a fully-charged battery to obtain specified engine speed.


Compression pressure:

Unit: kPa (kg/cm², psi)/300 rpm

	VG30DE	VG30DETT
Standard	1,285 (13.1, 186)	1,177 (12.0, 171)
Minimum	981 (10.0, 142)	883 (9.0, 128)
Difference limit between cylinders	98 (1.0, 14)	


10. If cylinder compression in one or more cylinders is low, pour a small amount of engine oil into cylinders through the spark plug holes and retest compression.
 - **If adding oil improves cylinder compression, piston rings may be worn or damaged. If so, replace piston rings after checking piston.**
 - **If pressure stays low, a valve may be sticking or seating improperly. Inspect and repair valves and valve seats. Refer to SDS (EM-55). If valves or valve seats are damaged excessively, replace them.**
 - **Compression stays low in two cylinders that are next to each other:
The cylinder head gasket may be leaking, or both cylinders may have valve component damage. Inspect and repair as necessary.**

OIL PAN




Removal


1. Drain engine oil.
2. Remove engine under cover.
3. Remove oil filter and bracket.
4. Remove engine rear gussets from both sides.



5. Disconnect A/C tube clamps as shown.




6. Disconnect steering column lower joint.
7. Remove tension rod fixing bolts from both sides.
8. Loosen transverse link bolts on both sides.



9. Set a suitable transmission jack under the suspension member.
 - At this time, hoist engine with engine slingers.
10. Remove suspension member fixing bolts.
11. Remove engine mounting bolts from both sides and then slowly lower transmission jack.
12. Remove oil pan bolts.

OIL PAN

Removal (Cont'd)




13. Remove oil pan.

(1) Insert Tool between cylinder block and oil pan.


- Do not drive seal cutter into oil pump or rear oil seal retainer portion. Doing so will damage the aluminum mating face.
- Do not insert screwdriver, or oil pan flange may be deformed.

(2) Slide Tool by tapping its side with a hammer, and remove oil pan.




Installation

1. Before installing oil pan, remove all traces of liquid gasket from mating surface using a scraper.
 - Also remove traces of liquid gasket from cylinder block mating surface.




2. Apply sealant to oil pump gasket and rear oil seal retainer gasket.



3. Apply a continuous bead of liquid gasket to oil pan mating surface.

Use Genuine Liquid Gasket or equivalent.

- Be sure liquid gasket is 3.5 to 4.5 mm (0.138 to 0.177 in) wide.
- Attaching should be done within 5 minutes after coating.



4. Install oil pan.

- Install bolts in the reverse order of removal.


- Wait at least 30 minutes before refilling engine oil.

Tightening procedure


① - ⑫ (M8 bolt): 16 - 21 N·m (1.6 - 2.1 kg-m, 12 - 15 ft-lb)

⑬ - ⑱ (M6 bolt): 6.3 - 8.3 N·m (0.64 - 0.85 kg-m, 4.6 - 6.1 ft-lb)

TIMING BELT



SEM619CA








Removal

1. Remove engine under cover.
2. Drain coolant from both cylinder block drain plugs, and radiator drain cock.
3. Remove radiator.
4. Remove drive belts, cooling fan and coupling.

TIMING BELT

Removal (Cont'd)



5. Remove crankshaft pulley bolt.
(At this time, remove starter motor and set a suitable tool to ring gear so that crankshaft cannot rotate.)

6. Remove crankshaft pulley using Tool.
7. Remove water inlet and outlet.
8. Remove front timing belt covers.

9. Install a suitable stopper bolt (M6) into tensioner arm of auto-tensioner so that auto-tensioner pusher does not spread out.

10. Set No. 1 cylinder at TDC on its compression stroke.
11. Remove auto-tensioner and timing belt.

CAUTION:

- a. Do not bend or twist timing belt.
- b. After removing timing belt, do not turn crankshaft and camshaft separately because valves will strike piston heads.
- c. Make sure that timing belt, camshaft sprocket, crankshaft sprocket, idler pulley and auto-tensioner are clean and free of oil and water.

CI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA





EL

IDX

TIMING BELT

Inspection

Visually check the condition of timing belt.
Replace if any abnormality is found.


Item to check	Problem	Cause
Tooth is broken/tooth root is cracked.	 <p style="text-align: right;">SEM394A</p>	<ul style="list-style-type: none"> • Camshaft jamming • Distributor jamming • Damaged camshaft/crankshaft oil seal
Back surface is cracked/worn.	 <p style="text-align: right;">SEM395A</p>	<ul style="list-style-type: none"> • Tensioner jamming • Overheated engine • Interference with belt cover
Side surface is worn.	 <p style="text-align: right;">SEM396A</p> <ul style="list-style-type: none"> • Belt corners are worn and round. • Wicks are frayed and coming out. 	<ul style="list-style-type: none"> • Improper installation of belt • Malfunctioning crankshaft pulley plate/timing belt plate
Teeth are worn.	 <p style="text-align: center;">Rotating direction</p> <p style="text-align: right;">SEM397A</p> <ul style="list-style-type: none"> • Canvas on tooth face is worn down. • Canvas on tooth is fluffy, rubber layer is worn down and faded white, or weft is worn down and invisible. 	<ul style="list-style-type: none"> • Poor belt cover sealing • Coolant leakage at water pump • Camshaft not functioning properly • Distributor not functioning properly • Excessive belt tension
Oil/Coolant or water is stuck to belt.		<ul style="list-style-type: none"> • Poor oil sealing • Coolant leakage at water pump • Poor belt cover sealing

TIMING BELT

Inspection (Cont'd)


AUTO-TENSIONER

Check for oil leaks from pusher rod and diaphragm.



Installation

1. Confirm that No. 1 cylinder is set at TDC on its compression stroke.
2. Align matching marks on camshaft and crankshaft sprockets with aligning marks on rear belt cover and oil pump housing.
3. Remove all spark plugs.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX


TIMING BELT Installation (Cont'd)

4. Set timing belt.
 - a. Ensure timing belt and sprockets are clean and free from oil or water. Do not bend or twist timing belt.
 - b. Align white lines on timing belt with matching mark on camshaft sprocket and crankshaft sprocket.
 - c. Point arrow on timing belt towards the front.



5. Using a suitable vise, adjust tensioner arm to give 4 mm (0.16 in) clearance with pusher of auto-tensioner. Then, insert stopper bolt into tensioner arm so that clearance does not change.


When adjusting clearance, do not push tensioner arm with stopper bolt fitted because it will damage thread portion of stopper bolt.



6. Install auto-tensioner and tighten nut (1) and bolts (2, 3) slightly by hand.


TIMING BELT

Installation (Cont'd)




7. Push auto-tensioner slightly towards timing belt to prevent belt from slipping.
Set tensioner slightly by pushing timing belt. Then, turn crankshaft 10 degrees clockwise and tighten nut (①) and bolts (②, ③) to 16 to 21 N·m (1.6 to 2.1 kg·m, 12 to 15 ft·lb).

At this time, do not push auto-tensioner hard, or belt will be adjusted too tightly.




8. Turn crankshaft 120 degrees counterclockwise.
9. Loosen nut (①) and bolts (②, ③) 1/2 turn to set tensioner body as for back as it will go.
10. Turn crankshaft clockwise and set No. 1 cylinder at TDC on its compression stroke.




11. Push the end of pusher with approx. 58.8 N (6.0 kg, 13.2 lb) force using Tool (push-pull gauge) and tighten nut (①) and bolts (②, ③) to 16 to 21 N·m (1.6 to 2.1 kg·m, 12 to 15 ft·lb).

If deflection of timing belt exceeds specification in procedure 15., change applied pushing force.




12. Turn crankshaft 120 degrees clockwise.
13. Turn crankshaft 120 degrees counterclockwise and set No. 1 cylinder at TDC on its compression stroke.



14. Prepare a suitable steel plate to measure belt deflection as shown.

TIMING BELT

Installation (Cont'd)



15.

- (1) Set plate and push it with 49 N (5 kg, 11 lb) force using Tool (push-pull gauge) at each position of timing belt mid-way between pulleys as shown.
- (2) Measure each deflection.

Deflection:


6 - 7 mm (0.24 - 0.28 in) or the average of each portion

$$\frac{\textcircled{A} + \textcircled{B} + \textcircled{C} + \textcircled{D}}{4}$$

is 6 - 7 mm (0.24 - 0.28 in)


If not within specification, repeat procedure from step 7 through step 15.

16. Confirm auto tensioner fixing nuts and bolts are tightened to 16 to 21 N·m (1.6 to 2.1 kg·m, 12 to 15 ft·lb).




17.

- Remove the auto-tensioner stopper bolt.
- After 5 minutes check the projection of the rod (clearance between tensioner arm and pusher) stays at 3.5 to 5.2 mm (0.138 to 0.205 in).




18. Check the proper installation (no slip or misplacement) of timing belt at each position as shown.



19. Install timing belt covers.

OIL SEAL REPLACEMENT



VALVE OIL SEAL

1. Remove intake manifold collector and valve cover.
2. Remove timing belt, camshaft sprocket and rear belt cover.
3. Remove camshaft brackets, camshaft and valve lifter.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT


HA

EL


IDX




4. Remove valve spring using Tool or a suitable tool.
 - Piston concerned should be set at TDC to prevent valve from falling.
5. Pry out valve oil seal.




6. Apply engine oil to new valve oil seal and install it.
 - Before installing valve oil seal, install inner valve spring seat.



OIL SEAL INSTALLATION DIRECTION



OIL SEAL REPLACEMENT




CAMSHAFT OIL SEAL

1. Remove timing belt and camshaft sprocket.
2. Remove rear belt cover and camshaft oil seal.


Be careful not to scratch camshaft.

3. Apply engine oil to new camshaft oil seal and install it using Tool or a suitable tool.




FRONT OIL SEAL

1. Remove timing belt and crankshaft sprocket.
2. Remove oil pan and oil pump assembly.
3. Remove front oil seal from oil pump body.




4. Apply engine oil to new oil seal and install it using Tool or a suitable tool.



REAR OIL SEAL

1. Remove flywheel or drive plate.
2. Remove rear oil seal from retainer.

Be careful not to scratch crankshaft.



3. Apply engine oil to new oil seal and install it using Tool or a suitable tool.

THROTTLE BODIES

Precaution

A letter, "U" or "L", is stamped on the throttle bodies. When changing throttle body, replace it with new one that has the same mark.

Installation

The intention of this installation and adjustment procedure is to assure accurate synchronization of the throttle body opening points.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST



RS

BT

HA

EL

IDX





- Before installing each throttle body, confirm that stopper wire is installed in hole of rod pin. If not, install suitable wire.
- When tightening bolts, free accel-drum-unit so that drum unit is left under its own weight. Do not apply external force to accel-drum unit.
- When replacing throttle bodies only, you need not perform procedures (3), (4) and (5).

1. Install accel-drum unit and throttle bodies (right side and left side).


Tightening order:

- (1) ① → ② → ③ → ④ :
9 - 11 N·m (0.9 - 1.1 kg-m, 6.5 - 8.0 ft-lb)
- (2) ① → ② → ③ → ④ :
18 - 22 N·m (1.8 - 2.2 kg-m, 13 - 16 ft-lb)
- (3) A → B → C: Tighten by hand
- (4) A → B → C :
5 N·m (0.5 kg-m, 3.6 ft-lb)
- (5) A → B → C :
20 N·m (2.0 kg-m, 14 ft-lb)




THROTTLE BODIES


Installation (Cont'd)




2. Pull out stopper wire of right side throttle body in order to secure right side joint lever.




3. Loosen left side throttle body lock nut and back adjusting screw until clearance is made between the screw and joint lever.



4. Set dial gauge on joint lever and set indicator to zero. Confirm that bottom end of adjusting screw is not in contact with joint lever of accelerator drum unit.



5. Pull out left side throttle body stopper wire from rod pin.



6. Turn adjusting screw until dial gauge indicates within the following range.

Range: 0.07 - 0.13 mm (0.0028 - 0.0051 in)

Then tighten lock nut.

7. Confirm that the dial gauge indicator is still within the above range.

CYLINDER HEAD

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



: Apply liquid gasket.


: N·m (kg·m, ft·lb)

* : After installing gasket, cut off any loose ends.


CYLINDER HEAD

CAUTION:

- When installing sliding parts such as camshaft, camshaft bracket and oil seal, be sure to apply new engine oil on their sliding surfaces.
- When tightening cylinder head bolts, camshaft sprocket bolts and camshaft bracket bolts, lubricate thread portions and seat surfaces of bolts with new engine oil.




- Do not put hydraulic lash adjusters (HLA) upside down, otherwise air will enter HLA, causing it to make a noise.
- Do not disassemble HLA.
- Attach tags to HLA so as not to mix them up.
- HLA should be immersed in engine oil.




Removal

1. Remove intake manifold collector.



2. Remove injector pipe assembly.



3. Remove valve covers.


CYLINDER HEAD

Removal (Cont'd)


4. Remove timing belt.

Refer to "Removal" of TIMING BELT. (EM-13)

5. Remove idler pulley and its stud bolt.




6. Remove intake manifold.



7. Disconnect front exhaust tube from exhaust manifold.

8. Remove cylinder head with exhaust manifold.

Cylinder head bolts should be loosened in two or three steps.




Disassembly

1. Remove exhaust manifold from cylinder head.

2. Remove camshaft sprockets.

3. Remove timing belt rear cover.




4. Remove camshaft brackets.

Bolts should be loosened in two or three steps.

Before removing camshaft, measure camshaft end play.

5. Remove oil seals, camshafts and hydraulic lash adjusters.



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA






EL

IDX

CYLINDER HEAD

Disassembly (Cont'd)

6. Remove valve springs with Tool or a suitable tool.
7. Pull out valve oil seals.



Inspection

CYLINDER HEAD DISTORTION

Head surface flatness:

Less than 0.1 mm (0.004 in)

If beyond the specified limit, resurface it or replace it.

Resurfacing limit:

The resurfacing limit of cylinder head is determined by the relation with the amount of cylinder block resurfacing.

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit is as follows:

$A + B = 0.2 \text{ mm (0.008 in)}$

After resurfacing cylinder head, check to make sure that camshaft rotates freely by hand. If not, cylinder head must be replaced.

Nominal cylinder head height from camshaft center:

Refer to SDS (EM-55).

CAMSHAFT VISUAL CHECK

Check camshaft for scratches, seizure and wear.

CAMSHAFT RUNOUT

1. Measure camshaft runout at the center journal.

Runout (Total indicator reading):

Limit 0.1 mm (0.004 in)

2. If it exceeds the limit, replace camshaft.

CYLINDER HEAD

Inspection (Cont'd)

CAMSHAFT CAM HEIGHT

1. Measure camshaft cam height.


Standard cam height:

Unit: mm (in)

Standard cam height	Non-turbocharger Turbocharger M/T	Turbocharger A/T
Intake	40.405 - 40.595	39.785 - 39.815 (1.5663 - 1.5675)
Exhaust	(1.5907 - 1.5982)	40.405 - 40.595 (1.5907 - 1.5982)

Cam wear limit: 0.15 mm (0.0059 in)

2. If wear is beyond the limit, replace camshaft.




CAMSHAFT JOURNAL CLEARANCE

1. Install camshaft bracket and tighten bolts to the specified torque.
2. Measure inner diameter of camshaft bearing.

Standard inner diameter:

28.000 - 28.021 mm (1.1024 - 1.1032 in)



3. Measure outer diameter of camshaft journal.


Standard outer diameter:

27.935 - 27.955 mm (1.0998 - 1.1006 in)

4. If clearance exceeds the limit, replace camshaft and/or cylinder head.

Camshaft journal clearance limit:

0.15 mm (0.0059 in)




CAMSHAFT END PLAY

1. Install camshaft in cylinder head.
2. Measure camshaft end play.

Camshaft end play:

Standard

0.03 - 0.08 mm (0.0012 - 0.0031 in)




VALVE GUIDE CLEARANCE

1. Push valve stem out so that its end is even with valve guide end. Measure valve runout by moving valve.


Valve deflection limit (Dial gauge reading):

0.20 mm (0.0079 in)




CYLINDER HEAD

Inspection (Cont'd)




2. If it exceeds the limit, check valve stem to valve guide clearance.
 - a. Measure valve stem diameter and valve guide inner diameter.
 - b. Check that clearance is within specification.
Valve stem to valve guide clearance limit:
0.10 mm (0.0039 in)
 - c. If it exceeds the limit, replace valve or valve guide.


VALVE GUIDE REPLACEMENT




1. To remove valve guide, heat cylinder head to 150 to 160°C (302 to 320°F).



2. Drive out valve guide with a press [under a 20 kN (2 ton, 2.2 US ton, 2.0 Imp ton) pressure] or hammer and suitable tool.




3. Ream cylinder head valve guide hole.
Valve guide hole diameter
(for service parts):
Intake and Exhaust
10.175 - 10.196 mm (0.4006 - 0.4014 in)



4. Heat cylinder head to 150 to 160°C (302 to 320°F) and press service valve guide onto cylinder head.
Projection "ℓ":
15.1 - 15.3 mm (0.594 - 0.602 in)

CYLINDER HEAD

Inspection (Cont'd)



5. Ream valve guide.

Finished size:

Intake and Exhaust

6.000 - 6.018 mm (0.2362 - 0.2369 in)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

VALVE SEATS

Check valve seats for evidence of pitting at valve contact surface. Reseat or replace if it is worn excessively.

- **Before repairing valve seats, check valve and valve guide for wear. If they have worn, replace them. Then correct valve seat.**
- **Cut with both hands to assure a uniform surface.**

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX



REPLACING VALVE SEAT FOR SERVICE PARTS

1. Bore out old seat until it collapses. Set machine depth stop so that boring cannot contact bottom face of seat recess in cylinder head.

2. Ream cylinder head recess.


Reaming bore for service valve seat

Oversize [0.5 mm (0.020 in)]:

Intake 36.500 - 36.516 mm (1.4370 - 1.4376 in)


Exhaust 32.000 - 32.016 mm (1.2598 - 1.2605 in)

Reaming should be done to the concentric circles to valve guide center so that valve seat will have the correct fit.



3. Heat cylinder head to 150 to 160°C (302 to 320°F).

4. Press fit valve seat until it seats on the bottom.



5. Cut or grind valve seat using suitable tool at the specified dimensions as shown in SDS (EM-56).

6. After cutting, lap valve seat with abrasive compound.

7. Check valve seat contact condition.

CYLINDER HEAD


Inspection (Cont'd)

VALVE DIMENSIONS

Check dimensions in each valve. For dimensions, refer to SDS (EM-55).

When valve head has been worn down to 0.5 mm (0.020 in) in margin thickness, replace valve.

Grinding allowance for valve stem tip is 0.2 mm (0.008 in) or less.



VALVE SPRING


Squareness

1. Measure "S" dimension.

Out-of-square:

Less than 1.8 mm (0.071 in)

2. If it exceeds the limit, replace spring.



Pressure

Check valve spring pressure.

Pressure: N (kg, lb) at height mm (in)


Standard:

536.4 (54.7, 120.6) at 26.5 (1.043)

Limit:


452.79 (46.17, 101.80) at 26.5 (1.043)

If below the limit, replace spring.



HYDRAULIC LASH ADJUSTER (HLA)


1. Check contact and sliding surfaces for wear or scratches.



2. Check diameter of HLA.

Outer diameter:

30.955 - 30.965 mm (1.2187 - 1.2191 in)



CYLINDER HEAD

Inspection (Cont'd)

3. Check HLA guide inner diameter.

Inner diameter:

31.000 - 31.020 mm (1.2205 - 1.2213 in)

Standard clearance between HLA and HLA guide:

0.035 - 0.065 mm (0.0014 - 0.0026 in)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

Assembly

1. Install valve component parts.

- **Always use new valve oil seal. Refer to OIL SEAL REPLACEMENT (EM-19).**
- **Install valve spring (uneven pitch type) with its narrow pitch side (painted side) toward cylinder head side.**

AT

- To facilitate installation of collet, apply a small amount of grease to a suitable rod and attach collet to it.

PD

FA

RA

BR

ST






RS

BT

HA

EL

IDX




2. Install camshafts as shown.


- Exhaust camshaft (left bank) has spline for camshaft position sensor.

CYLINDER HEAD

Assembly (Cont'd)




- When installing valve timing control solenoid valves, apply liquid gasket to solenoid valve surfaces.



3. Install camshaft brackets.


Tighten camshaft bracket bolts gradually in two or three stages.



When installing front side camshaft brackets, apply liquid gasket as shown.


4. Apply engine oil to camshaft oil seal lip and install it in place. **Always use new camshaft oil seal.**
5. Install rear timing belt cover.
6. Install camshaft sprockets.

When tightening bolts, fix camshaft to prevent it from rotating.



Installation






1. Set No. 1 piston at TDC on its compression stroke as follows:
(1) Align crankshaft sprocket aligning mark with mark on oil pump body.



- (2) Align camshaft sprocket aligning mark with mark on timing belt rear cover.

CYLINDER HEAD

Installation (Cont'd)



2. Install cylinder head with new gasket.
 - Be sure to install washers between bolts and cylinder head.
 - Do not rotate crankshaft and camshaft separately, or valves will hit piston heads.
3. Install cylinder head bolts.
 - Install short bolts (L₂) into the correct holes of cylinders #1 and #6 as shown in figure of step (6).
4. Tighten cylinder head bolts in numerical order.
 - **Tightening procedure**
 - (1) Tighten all bolts to 39 N·m (4.0 kg-m, 29 ft-lb).
 - (2) Tighten all bolts to 123 N·m (12.5 kg-m, 90 ft-lb).
 - (3) Loosen all bolts completely.
 - (4) Tighten all bolts to 34 to 44 N·m (3.5 to 4.5 kg-m, 25 to 33 ft-lb).
 - (5) Tighten all bolts to 123 N·m (12.5 kg-m, 90 ft-lb) or if an angle wrench is available, tighten bolts 70 to 75 degrees (L₁), 65 to 70 degrees (L₂) clockwise.
- (6) Tighten bolts (⊗) as shown to 10 to 12 N·m (1.0 to 1.2 kg-m, 7 to 9 ft-lb).
5. Install valve covers.

When installing exhaust side valve cover, apply liquid gasket as shown.
6. Install remaining parts.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL


IDX




Removal

RIGHT SIDE UNIT


1. Remove right part of cowl top.
2. Remove battery.




3. Remove air inlet hose and pipe.
4. Disconnect lower pipe from turbocharger unit.



5. Remove ASCD bracket with wiper motor and solenoid valves.
6. Disconnect heated oxygen sensor harness connector.




7. Remove turbocharger water hoses, and disconnect turbocharger oil inlet tube.
8. Remove two bolts fastening warm up three-way catalyst to turbocharger unit.




9. Remove the following parts;
 - oil pressure switch
 - oil filter
 - turbocharger oil return tube
 - front exhaust tube
 - warm up three-way catalyst
10. Disconnect oil hose from oil filter bracket, and turbocharger water tubes from turbocharger unit.

TURBOCHARGERS


Removal (Cont'd)



11. Remove rod pin of wastegate valve actuator.
12. Remove oil filter bracket.




13. Unbend locking plates for fastening nuts of turbocharger unit.
14. Remove turbocharger unit.




LEFT SIDE UNIT

1. Remove brake master cylinder and brake booster.
2. Disconnect heated oxygen sensor harness connector.



3. Remove air inlet hose and pipe.
4. Disconnect lower pipe from turbocharger unit.



5. Disconnect water tubes.
6. Remove two bolts fastening warm up three-way catalyst to turbocharger unit.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL


IDX

TURBOCHARGERS


Removal (Cont'd)



7. Remove front exhaust tube and warm up three-way catalyst.
8. Disconnect steering lower joint.




9. Remove turbocharger oil return tube and water tubes.
10. Disconnect EGR tube and actuator bracket of turbocharger wastegate valve.



11. Remove manifold cover and fastening nuts.
12. Remove turbocharger unit with exhaust manifold.



Inspection



TURBOCHARGERS


Inspection (Cont'd) OIL AND WATER TUBES

Check tubes for clogging.




ROTOR SHAFT

1. Check rotor shaft for smooth rotating.




2. Check rotor shaft for carbon deposits.



3. Measure runout of rotor shaft.

Runout (Total indicator reading):
0.056 - 0.127 mm (0.0022 - 0.0050 in)



4. Measure end play of rotor shaft.

End play:
0.013 - 0.096 mm (0.0005 - 0.0038 in)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


TURBOCHARGERS

Inspection (Cont'd)

TURBINE WHEEL

Check turbine wheel for the following:


- Oil
- Carbon deposits
- Deformed fins
- Contact with turbine housing



COMPRESSOR WHEEL

Check compressor wheel for the following:


- Oil
- Deformed fins
- Contact with compressor housing



WASTEGATE VALVE

Remove rod pin and check wastegate valve for cracks, deformation and smooth movement.


Check valve seat surface for smoothness.




WASTEGATE VALVE ACTUATOR

Apply air pressure to wastegate valve actuator and check it for smooth movement.

- Do not keep applying air pressure to the actuator.
- The air pressure should be in the range of 78 to 88 kPa (0.8 to 0.9 kg/cm², 11 to 13 psi).



CHARGE AIR COOLERS



Removal

1. Remove front part of front fender protector.
2. Remove reservoir tank when servicing left side charge air cooler.

GI

MA

EM


LC

EF &
EC


FE

CL

MT



3. Remove front combination lamp.




4. Remove bolts fastening charge air cooler and front inlet cover.

AT

PD

FA

RA



5. Remove inlet and outlet hoses.
6. Remove charge air cooler unit.

BR

ST

RS


BT

HA

EL

IDX





ENGINE REMOVAL



WARNING:

- Situate vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.
- Do not remove engine until exhaust system has completely cooled off. Otherwise, you may burn yourself and/or fire may break out in fuel line.
- Before disconnecting fuel hose, release fuel pressure from fuel line. Refer to "Releasing Fuel Pressure" in EF & EC section.
- Be sure to hoist engine and transmission in a safe manner.
- For engines not equipped with engine slingers, attach and use proper slingers and bolts described in PARTS CATALOG.
- When lifting engine, be careful not to strike adjacent parts, especially accelerator wire casing, brake lines, and brake master cylinder.

ENGINE REMOVAL



M/T Model

1. Remove engine under cover and hood.
2. Drain coolant from both cylinder block drain plugs, and radiator drain cock.
3. Drain engine oil from drain plug of oil pan.
4. Remove vacuum hoses, fuel tubes, wires, harnesses and connectors and so on.
5. Remove front exhaust tubes and propeller shaft.
6. Remove radiator.
7. Remove drive belts, cooling fan and coupling.
8. Remove P/S oil pump, alternator, A/C compressor, starter motor, and clutch operating cylinder.
9. Disconnect A/C tube clamps as shown.

10. Disconnect steering column lower joint.
11. Remove tension rod fixing bolts from both sides.
12. Loosen transverse link bolts on both sides.

13. Set a suitable transmission jack under suspension member.
 - At this time, hoist engine with engine slinger.
14. Remove suspension member fixing bolts.
15. Remove engine mounting bolts from both sides and then slowly lower transmission jack.
16. Remove engine with transmission as shown in following figure.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

ENGINE REMOVAL M/T Model (Cont'd)




A/T Model

1. Perform the same procedures (1 to 8) as for M/T model.
2. Remove transmission from vehicle.


Refer to "REMOVAL AND INSTALLATION" in AT section.

3. Hoist engine with engine slingers and remove engine mounting bolts from both sides.



4. Remove engine from vehicle as shown.

CYLINDER BLOCK




SEM355EA

- CAUTION:**
- When installing sliding parts such as bearings and pistons, be sure to apply engine oil on the sliding surfaces.
 - Place removed parts such as bearings and bearing caps in their proper order and direction.
 - When installing connecting rod nuts, and main bearing cap bolts, apply new engine oil to threads and seating surfaces.

GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


CYLINDER BLOCK




Disassembly

PISTON AND CRANKSHAFT


1. Place engine on a work stand.
2. Remove timing belt.
3. Drain coolant and remove water pump.
4. Drain oil.
5. Remove oil pan, oil pump and rear oil seal retainer.
6. Remove intake manifold collector, intake manifold and cylinder head.



7. Remove pistons.
 - When disassembling piston and connecting rod, remove snap ring first. Then heat piston to 60 to 70°C (140 to 158°F) or use piston pin press stand at room temperature.



8. Remove bearing cap and crankshaft.
 - **Before removing bearing cap, measure crankshaft end play.**
 - **Bolts should be loosened in two or three steps.**



Inspection

PISTON AND PISTON PIN CLEARANCE

1. Measure inner diameter of piston pin hole "dp".
Standard diameter "dp":
21.987 - 21.999 mm (0.8656 - 0.8661 in)
2. Measure outer diameter of piston pin "Dp".
Standard diameter "Dp":
21.989 - 22.001 mm (0.8657 - 0.8662 in)
3. Calculate piston pin clearance.
dp - Dp = -0.004 to 0 mm (-0.0002 to 0 in)

If it exceeds the above value, replace piston assembly with pin.

CYLINDER BLOCK

Inspection (Cont'd)

PISTON RING SIDE CLEARANCE

Side clearance:

Top ring
0.040 - 0.073 mm (0.0016 - 0.0029 in)

2nd ring
0.030 - 0.063 mm (0.0012 - 0.0025 in)

Max. limit of side clearance:
0.1 mm (0.004 in)

O-ring:
0.015 - 0.185 mm (0.0006 - 0.0073 in)

Max. limit of side clearance:
0.2 mm (0.008 in)

If out of specification, replace piston and/or piston ring.

PISTON RING END GAP

End gap:

Top ring
0.21 - 0.40 mm (0.0083 - 0.0157 in)

2nd ring
0.50 - 0.76 mm (0.0197 - 0.0299 in)

Oil ring
0.20 - 0.76 mm (0.0079 - 0.0299 in)

Max. limit of end gap:
1.0 mm (0.039 in)

If out of specification, replace piston ring. If gap still exceeds the limit even with a new ring, rebore cylinder and use oversized piston and piston rings.

Refer to SDS (EM-57).

- When replacing the piston, check the cylinder block surface for scratches or seizure. If scratches or seizure is found, hone or replace the cylinder block.

CONNECTING ROD BEND AND TORSION

Bend:

Limit 0.15 mm (0.0059 in) per 100 mm (3.94 in) length

Torsion:

Limit 0.3 mm (0.012 in) per 100 mm (3.94 in) length

If it exceeds the limit, replace connecting rod assembly.

CYLINDER BLOCK DISTORTION AND WEAR

1. Clean upper face of cylinder block and measure the distortion.

Limit:

0.10 mm (0.0039 in)

2. If out of specification, resurface it.

The resurfacing limit is determined by the relationship with the amount of cylinder head resurfacing.





Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit is as follows:

$A + B = 0.2 \text{ mm (0.008 in)}$

3. If necessary, replace cylinder block.



GI

MA

EM

LC

EF &

EC

FE

CL

WT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

CYLINDER BLOCK

Inspection (Cont'd)

PISTON-TO-BORE CLEARANCE

Method A (Using bore gauge and micrometer)

- Using a bore gauge, measure cylinder bore for wear, out-of-round and taper.

Standard inner diameter:

87.000 - 87.030 mm (3.4252 - 3.4264 in)

Wear limit: 0.20 mm (0.0079 in)





Out-of-round (X - Y) standard: 0.015 mm (0.0006 in)

Taper (A - B - C) standard: 0.015 mm (0.0006 in)

If it exceeds the limit, rebore all cylinders. Replace cylinder block if necessary.

- Check for scratches and seizure. If necessary, hone it.

- If cylinder block or piston is replaced, match piston grade with grade number on cylinder block upper surface.**



- Measure piston skirt diameter.

Piston diameter "A":

Refer to SDS (EM-57).

Measuring point "a" (Distance from the top):

48.0 mm (1.890 in)

- Check that piston-to-bore clearance is within specification.

Piston-to-bore clearance "B":

Non-turbocharger

0.015 - 0.035 mm (0.0006 - 0.0014 in)

Turbocharger

0.025 - 0.045 mm (0.0010 - 0.0018 in)

- Determine piston oversize according to amount of wear.

Oversize pistons are available for service. Refer to SDS (EM-57).

- Cylinder bore size is determined by adding piston-to-bore clearance to piston diameter "A".

Rebored size calculation:

D = A + B - C

D: Bored diameter

A: Piston diameter as measured

B: Piston-to-bore clearance

C: Honing allowance 0.02 mm (0.0008 in)

- Install main bearing caps, and tighten to the specified torque to prevent distortion of cylinder bores in final assembly.

- Rebore cylinders.

- When any cylinder needs boring, all other cylinders must also be bored.**

- Do not bore more than 0.05 mm (0.0020 in) in diameter at a time.**

- Hone cylinders to obtain specified piston-to-bore clearance.

- Measure finished cylinder bore for out-of-round and taper.

- Measurement should be done after cylinder cools down.**

CYLINDER BLOCK

Inspection (Cont'd)

CRANKSHAFT

CAUTION:

Never attempt to disassemble crankshaft counter weight.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST



RS

BT

HA

EL

IDX



1. Check crankshaft main and pin journals for score, wear or cracks.
2. With a micrometer, measure journals for taper and out-of-round.

Out-of-round (X - Y):


Less than 0.005 mm (0.0002 in)

Taper (A - B):

Less than 0.005 mm (0.0002 in)

Limit:


0.02 mm (0.0008 in)



3. Measure crankshaft runout.

Runout (Total indicator reading):

Less than 0.10 mm (0.0039 in)




BEARING CLEARANCE

- Use Method A or Method B. Method A is preferred because it is more accurate.

Method A (Using bore gauge & micrometer)

Main bearing

1. Set main bearings in their proper positions on cylinder block and main bearing cap.




2. Install main bearing cap to cylinder block.

Tighten all bolts in correct order in two or three stages.


3. Measure inner diameter "A" of each main bearing.

CYLINDER BLOCK

Inspection (Cont'd)




4. Measure outer diameter "Dm" of each crankshaft main journal.
Main journal diameter "Dm":
Refer to SDS (EM-59).
5. Calculate main bearing clearance.
Main bearing clearance (A - Dm):
Standard
0.028 - 0.055 mm (0.0011 - 0.0022 in)
Limit
0.090 mm (0.0035 in)
6. If it exceeds the limit, replace bearing.




7. If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing.

CAUTION:

- When grinding crankshaft journal, confirm that "L" dimension in fillet roll is more than the specified limit.
"L": 0.1 mm (0.004 in)
- Refer to SDS (EM-59) for available service parts.



8. If crankshaft, cylinder block or main bearing is reused again, measure main bearing clearance.
If crankshaft, cylinder block and main bearings are replaced with new ones, it is necessary to select thickness of main bearings as follows:
 - a. Grade number of each cylinder block main journal is punched on the respective cylinder block.



- b. Grade number of each crankshaft main journal is punched on the No. 1 counter weight of crankshaft.
- c. Select main bearing with suitable thickness according to the following table.

For example:

$$\begin{aligned}
 &\text{Cylinder block journal grade number: } 1 \\
 &\text{Crankshaft journal grade number: } 2 \\
 &\text{Main bearing grade number} = 1 + 2 \\
 &= 3
 \end{aligned}$$

Main bearing grade number:

		Cylinder block journal grade number		
		0	1 (I)	2 (II)
Crankshaft journal grade number	0	0	1	2
	1 (I)	1	2	3
	2 (II)	2	3	4

Grade numbers are punched in either Arabic or Roman numerals.

CYLINDER BLOCK

Inspection (Cont'd)

Connecting rod bearing (Big end)





1. Install connecting rod bearing to connecting rod and cap.
2. Install connecting rod cap to connecting rod.

Tighten bolts to the specified torque.

3. Measure inner diameter "C" of each bearing.

Big end inner diameter "C":

53.000 - 53.013 mm (2.0866 - 2.0871 in)



4. Measure outer diameter "Dp" of each crankshaft pin journal.

Pin journal diameter "Dp":

Refer to SDS (EM-59).

5. Calculate connecting rod bearing clearance.

Connecting rod bearing clearance (C - Dp):

Standard

0.028 - 0.048 mm (0.0011 - 0.0019 in)

Limit

0.090 mm (0.0035 in)

6. If it exceeds the limit, replace bearing.
7. If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing. Refer to step 7 of "BEARING CLEARANCE — Main bearing" (EM-48).

8. When replacing crankshaft, connecting rods or bearings with new ones, select thickness of connecting rod bearings as follows:

- a. Grade number of each connecting rod big end is punched on the respective connecting rod.

- b. Grade number of each crankshaft pin journal is punched on the No. 5 counter weight of crankshaft.

- c. Select connecting rod bearing with suitable thickness according to the following table.

For example:

Connecting rod big end grade number: 1

Crankshaft pin grade number: 2

Connecting rod bearing grade number = 1 + 2
= 3

Connecting rod bearing grade number:

		Connecting rod big end grade number	
		0	1 (I)
Crankshaft pin grade number	0	0	1
	1 (I)	1	2
	2 (II)	2	3

Grade numbers are punched in either Arabic or Roman numerals.



CYLINDER BLOCK

Inspection (Cont'd)

Method B (Using "plastigage")

CAUTION:


- Do not turn crankshaft or connecting rod while plastigage is being inserted.
- When bearing clearance exceeds the specified limit, ensure that the proper bearing has been installed. If clearance cannot be adjusted using any standard bearing grade, grind crankshaft journal and use undersized bearing.



CONNECTING ROD BUSHING CLEARANCE (Small end)

1. Measure inner diameter "C" of bushing.
Small end bushing inner diameter "C":
22.000 - 22.012 mm (0.8661 - 0.8666 in)
2. Measure outer diameter "Dp" of piston pin.
Piston pin outer diameter "Dp":
21.989 - 22.001 mm (0.8657 - 0.8662 in)
3. Calculate connecting rod bushing clearance.
C - Dp = 0.005 - 0.017 mm (0.0002 - 0.0007 in)
Limit: 0.023 mm (0.0009 in)

If it exceeds the specified value, replace connecting rod bushing and/or piston set with pin.



REPLACEMENT OF CONNECTING ROD BUSHING (Small end)

1. Drive in small end bushing until it is flush with end surface of rod.


Be sure to align the oil holes.

2. After driving in small end bushing, ream the bushing.

Small end bushing inside diameter:

Finished size

22.000 - 22.012 mm (0.8661 - 0.8666 in)



FLYWHEEL/DRIVE PLATE RUNOUT

Runout (Total indicator reading):


Flywheel (M/T model)

Less than 0.15 mm (0.0059 in)

Drive plate (A/T model)

Less than 0.15 mm (0.0059 in)




CYLINDER BLOCK



Assembly


PISTON

1. Install new snap ring on one side of piston pin hole.
2. Heat piston to 60 to 70°C (140 to 158°F) and assemble piston, piston pin, connecting rod and new snap ring.
 - **Align the direction of piston and connecting rod.**
 - **Numbers stamped on connecting rod and cap correspond to each cylinder.**
 - **After assembly, make sure connecting rod swings smoothly.**
3. Set piston rings as shown.



CRANKSHAFT

1. Set main bearings in their proper positions on cylinder block and main bearing cap.
 - **Confirm that correct main bearings are used. Refer to "Inspection" (EM-47).**



2. Install crankshaft and main bearing caps and tighten bolts to the specified torque.
 - **Prior to tightening bearing cap bolts, shift crankshaft back and forth to properly seat the bearing cap.**
 - **Tighten bearing cap bolts gradually in two or three stages. Start with center bearing and move outward sequentially.**
 - **After securing bearing cap bolts, make sure crankshaft turns smoothly by hand.**

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

CYLINDER BLOCK

Assembly (Cont'd)



3. Measure crankshaft end play.

Crankshaft end play:


Standard

0.05 - 0.18 mm (0.0020 - 0.0071 in)

Limit

0.30 mm (0.0118 in)

If beyond the limit, replace bearing with a new one.




4. Install connecting rod bearings in connecting rods and connecting rod caps.

- Confirm that correct bearings are used.

Refer to "Inspection" (EM-47).


- Install bearings so that oil hole in connecting rod aligns with oil hole of bearing.



5. Install pistons with connecting rods.

- a. Install them into corresponding cylinders with Tool.

- Be careful not to scratch cylinder wall by connecting rod.
- Arrange so that front mark on piston head faces toward front of engine.



- b. Install connecting rod bearing caps.

Tighten connecting rod bearing cap nuts to the specified torque.

Connecting rod bearing nut


- (1) Tighten to 14 to 16 N·m

(1.4 to 1.6 kg-m, 10 to 12 ft-lb).

- (2) Tighten to 59 to 65 N·m

(6.0 to 6.6 kg-m, 43 to 48 ft-lb)

or if you have an angle wrench, tighten bolts 60 to 65 degrees clockwise.



6. Measure connecting rod side clearance.

Connecting rod side clearance:

Standard

0.20 - 0.35 mm (0.0079 - 0.0138 in)

Limit

0.40 mm (0.0157 in)


If beyond the limit, replace connecting rod and/or crankshaft.

CYLINDER BLOCK

Assembly (Cont'd)

REPLACING PILOT BUSHING

1. Remove pilot bushing (M/T)/pilot converter (A/T) with suitable tool.
2. Install pilot bushing (M/T)/pilot converter (A/T).



GI

MA

EM

LC

EF &
EC

FE

GL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications


Cylinder arrangement	V-6	
Displacement	cm ³ (cu in)	2,960 (180.62)
Bore and stroke	mm (in)	87 x 83 (3.43 x 3.27)
Valve arrangement	DOHC	
Firing order	1-2-3-4-5-6	
Number of piston rings		
Compression	2	
Oil	1	
Number of main bearings	4	
Compression ratio (Non-turbocharger/Turbocharger)	10.5/8.5	

COMPRESSION PRESSURE

Unit: kPa (kg/cm², psi)/300 rpm

	Non-Turbocharger	Turbocharger
Compression pressure		
Standard	1,285 (13.1, 186)	1,177 (12.0, 171)
Minimum	981 (10.0, 142)	883 (9.0, 128)
Differential limit between cylinders	98 (1.0, 14)	

Cylinder number




SEM713A

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

VALVE SEAT



SEM529C

Unit: mm (in)

		Standard	Service*
Cylinder head seat recess diameter (D_1)	In.	36.000 - 36.016 (1.4173 - 1.4179)	36.500 - 36.516 (1.4370 - 1.4376)
	Ex.	31.500 - 31.516 (1.2402 - 1.2408)	32.000 - 32.016 (1.2598 - 1.2605)
Valve seat interference fit	In.	0.081 - 0.113 (0.0032 - 0.0044)	
	Ex.	0.064 - 0.096 (0.0025 - 0.0038)	
Valve seat outer diameter (D_4)	In.	36.097 - 36.113 (1.4211 - 1.4218)	36.597 - 36.613 (1.4408 - 1.4415)
	Ex.	31.580 - 31.596 (1.2433 - 1.2439)	32.080 - 32.096 (1.2630 - 1.2636)
Valve seat inner diameter (D_2)	In.	29.85 - 30.15 (1.1752 - 1.1870)	
	Ex.	24.35 - 24.65 (0.9587 - 0.9705)	
Height (H)	In.	5.9 - 6.0 (0.232 - 0.236)	5.35 - 5.45 (0.2106 - 0.2146)
	Ex.	5.9 - 6.0 (0.232 - 0.236)	5.9 - 6.0 (0.232 - 0.236)
Face angle (θ)	In.	45°	
	Ex.	45°	
Face inner diameter (D_4)	In.	31.5 (1.240)	*: Valve seat surface must be corrected to specified value.
Face outer diameter (D_3)	In.	33.6 - 33.8 (1.323 - 1.331)	
	Ex.	28.9 - 29.1 (1.138 - 1.146)	


SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

PISTON, PISTON RING AND PISTON PIN

Available piston

Unit: mm (in)



SEM740D

	Non-turbocharger	Turbocharger
Piston skirt diameter "A"		
Standard		
Grade No. 1	86.975 - 86.985 (3.4242 - 3.4246)	86.965 - 86.975 (3.4238 - 3.4242)
Grade No. 2	86.985 - 86.995 (3.4246 - 3.4250)	86.975 - 86.985 (3.4242 - 3.4246)
Grade No. 3	86.995 - 87.005 (3.4250 - 3.4254)	86.985 - 86.995 (3.4246 - 3.4234)
0.25 (0.0098) oversize (Service)	87.225 - 87.275 (3.4340 - 3.4360)	87.215 - 87.265 (3.4337 - 3.4356)
0.50 (0.0197) oversize (Service)	87.475 - 87.525 (3.4439 - 3.4459)	87.465 - 87.515 (3.4435 - 3.4455)
"a" dimension	48.0 (1.890)	
Piston pin hole diameter	21.987 - 21.999 (0.8656 - 0.8661)	
Piston clearance to cylinder block	0.015 - 0.035 (0.0006 - 0.0014)	0.025 - 0.045 (0.0010 - 0.0018)

Piston ring

Unit: mm (in)

	Standard	Limit
Side clearance		
Top	0.040 - 0.073 (0.0016 - 0.0029)	0.1 (0.004)
2nd	0.030 - 0.063 (0.0012 - 0.0025)	
Oil	0.015 - 0.185 (0.0006 - 0.0073)	0.2 (0.008)
End gap		
Top	0.21 - 0.40 (0.0083 - 0.0157)	1.0 (0.039)
2nd	0.50 - 0.76 (0.0197 - 0.0299)	
Oil (rail ring)	0.20 - 0.76 (0.0079 - 0.0299)	

Piston pin

Unit: mm (in)

Piston pin outer diameter "Dp"	21.989 - 22.001 (0.8657 - 0.8662)
Interference fit of piston pin to piston	0 - 0.004 (0 - 0.0002)
Piston pin to connecting rod bushing clearance	0.005 - 0.017 (0.0002 - 0.0007)

* Values measured at ambient temperature of 20°C (68°F)

CONNECTING ROD

Unit: mm (in)

Center distance	154.1 - 154.2 (6.067 - 6.071)
Bend [per 100 (3.94)]	
Limit	0.15 (0.0059)
Torsion [per 100 (3.94)]	
Limit	0.3 (0.012)
Piston pin bushing inner diameter "C"	22.000 - 22.012 (0.8661 - 0.8666)
Connecting rod big end inner diameter "C"	53.000 - 53.013 (2.0866 - 2.0871)
Side clearance	
Standard	0.20 - 0.35 (0.0079 - 0.0138)
Limit	0.40 (0.0157)


* After installing in connecting rod

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)


CAMSHAFT AND CAMSHAFT BEARING

Unit: mm (in)



SEM568A

	Standard	Max. tolerance
Camshaft journal to bearing clearance	0.045 - 0.086 (0.0018 - 0.0034)	0.15 (0.0059)
Inner diameter of camshaft bearing	28.000 - 28.021 (1.1024 - 1.1032)	—
Outer diameter of camshaft journal	27.935 - 27.955 (1.0998 - 1.1006)	—
Camshaft runout [TIR*]	Less than 0.04 (0.0016)	0.1 (0.004)
Camshaft end play	0.03 - 0.08 (0.0012 - 0.0031)	—




EM671

	Non-turbocharger Turbocharger M/T	Turbocharger A/T
Cam height "A"		
Intake	40.405 - 40.595 (1.5907 - 1.5982)	39.785 - 39.815 (1.5663 - 1.5675)
Exhaust		40.405 - 40.595 (1.5907 - 1.5982)
Wear limit of cam height	0.15 (0.0059)	

*Total indicator reading

Valve timing



EM120A
Unit: degree


	a	b	c	d	e	f
Non-turbocharger	248	248	-1	69	9	59
Turbocharger M/T						
Turbocharger A/T	248	240	0	60	9	59

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

CYLINDER BLOCK

Unit: mm (in)




SEM733E

Surface flatness	
Standard	Less than 0.03 (0.0012)
Limit	0.10 (0.0039)
Cylinder bore	
Inner diameter	
Standard	
Grade No. 1	87.000 - 87.010 (3.4252 - 3.4256)
Grade No. 2	87.010 - 87.020 (3.4256 - 3.4260)
Grade No. 3	87.020 - 87.030 (3.4260 - 3.4264)
Wear limit	0.20 (0.0079)
Out-of-round (X - Y)	Less than 0.015 (0.0006)
Taper (A - B - C)	Less than 0.015 (0.0006)
Main journal inner diameter	
Grade No. 0	66.645 - 66.654 (2.6238 - 2.6242)
Grade No. 1	66.654 - 66.663 (2.6242 - 2.6245)
Grade No. 2	66.663 - 66.672 (2.6245 - 2.6249)
Difference in inner diameter between cylinders	
Standard	Less than 0.05 (0.0020)

CRANKSHAFT


Unit: mm (in)

Main journal dia. "Dm"	
Grade No. 0	62.967 - 62.975 (2.4790 - 2.4793)
Grade No. 1	62.959 - 62.967 (2.4787 - 2.4790)
Grade No. 2	62.951 - 62.959 (2.4784 - 2.4787)
Pin journal dia. "Dp"	
Grade No. 0	49.968 - 49.974 (1.9672 - 1.9675)
Grade No. 1	49.962 - 49.968 (1.9670 - 1.9672)
Grade No. 2	49.955 - 49.962 (1.9667 - 1.9670)
Center distance "r"	41.47 - 41.53 (1.6327 - 1.6350)
Out-of-round (X - Y)	
Standard	Less than 0.005 (0.0002)
Limit	0.02 (0.0008)
Taper (A - B)	
Standard	Less than 0.005 (0.0002)
Limit	0.02 (0.0008)
Runout [TIR]	
Standard	Less than 0.10 (0.0039)
Free end play	
Standard	0.05 - 0.18 (0.0020 - 0.0071)
Limit	0.30 (0.0118)



SEM645

Out-of-round (X) - (Y)
Taper (A) - (B)




EM715

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

AVAILABLE MAIN BEARING



SEM327A

No. 1 main bearing

Grade number	Thickness "T" mm (in)	Width "W" mm (in)	Identification color
0	1.817 - 1.821 (0.0715 - 0.0717)		Black
1	1.821 - 1.825 (0.0717 - 0.0719)		Brown
2	1.825 - 1.829 (0.0719 - 0.0720)	22.4 - 22.6 (0.882 - 0.890)	Green
3	1.829 - 1.833 (0.0720 - 0.0722)		Yellow
4	1.833 - 1.837 (0.0722 - 0.0723)		Blue

No. 2 and 3 main bearing

Grade number	Thickness "T" mm (in)	Width "W" mm (in)	Identification color
0	1.817 - 1.821 (0.0715 - 0.0717)		Black
1	1.821 - 1.825 (0.0717 - 0.0719)		Brown
2	1.825 - 1.829 (0.0719 - 0.0720)	18.9 - 19.1 (0.744 - 0.752)	Green
3	1.829 - 1.833 (0.0720 - 0.0722)		Yellow
4	1.833 - 1.837 (0.0722 - 0.0723)		Blue

No. 4 main bearing

Grade number	Thickness "T" mm (in)	Identification color
0	1.817 - 1.821 (0.0715 - 0.0717)	Black
1	1.821 - 1.825 (0.0717 - 0.0719)	Brown
2	1.825 - 1.829 (0.0719 - 0.0720)	Green
3	1.829 - 1.833 (0.0720 - 0.0722)	Yellow
4	1.833 - 1.837 (0.0722 - 0.0723)	Blue

Undersize

Unit: mm (in)

	Thickness	Main journal diameter "Dm"
0.25 (0.0098)	1.948 - 1.956 (0.0767 - 0.0770)	Grind so that bearing clearance is the specified value.

AVAILABLE CONNECTING ROD BEARING

Connecting rod bearing

Grade number	Thickness "T" mm (in)	Identification color
0	1.496 - 1.499 (0.0589 - 0.0590)	No color
1	1.499 - 1.502 (0.0590 - 0.0591)	Brown
2	1.502 - 1.505 (0.0591 - 0.0593)	Green
3	1.505 - 1.508 (0.0593 - 0.0594)	Yellow

Undersize

Unit: mm (in)

	Thickness	Crank pin journal diameter "Dp"
0.08 (0.0031)	1.540 - 1.548 (0.0606 - 0.0609)	Grind so that bearing clearance is the specified value.
0.12 (0.0047)	1.560 - 1.568 (0.0614 - 0.0617)	
0.25 (0.0098)	1.625 - 1.633 (0.0640 - 0.0643)	

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment (Cont'd)

TURBOCHARGER

		Unit: mm (in)
Rotor shaft		
Runout [TIR]*	0.056 - 0.127 (0.0022 - 0.0050)	
End play	0.013 - 0.096 (0.0005 - 0.0038)	

*Total indicator reading

MISCELLANEOUS COMPONENTS

		Unit: mm (in)
Flywheel		
Runout [TIR]*	Less than 0.15 (0.0059)	

*Total indicator reading

Bearing clearance

		Unit: mm (in)
Main bearing clearance		
Standard	0.028 - 0.055 (0.0011 - 0.0022)	
Limit	0.090 (0.0035)	
Connecting rod bearing clearance		
Standard	0.028 - 0.048 (0.0011 - 0.0019)	
Limit	0.090 (0.0035)	

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX