

DRIVER ASSURANCE

Mazda Driver's Assurance Plan
Check out www.mymazda.com, the website dedicated to you. Manage your maintenance records, receive valuable offers, see the latest accessories and much more!

Mazda Roadside Assistance
Exhilaration, liberation and inspiration are great reasons to drive a Mazda car, truck, SUV or minivan. In addition to all the other great standard features, you also get peace of mind, our Emergency Roadside Assistance Plan, it's just a phone call away, 24 hours a day, 365 days a year, call **1-800-866-1998**

Mazda "bumper-to-bumper" Limited Warranty
We design and build every Mazda to give you driving pleasure now and far down the road. We're so confident in our quality that we cover the entire vehicle against defects in materials and workmanship


for 48 months or 50,000 miles, whichever comes first

Mazda Service Transportation Solution

Being without your Mazda may put a crimp in your day

If you do ever have to take your Mazda in for repairs don't worry, you're covered. With the Mazda Transportation Solution, you will be given a loaner car at no charge when your Mazda vehicle is in for warranty repairs.

For all the details, see your Mazda Dealer



This Quick Tips® guide is provided by Mazda North American Operations to make your Mazda ownership experience more convenient. It is not intended to replace your Owner's Manual.

If you have any questions about your vehicle, you are invited to contact your local dealer. Or if you need additional help, feel free to call our

Customer Assistance Center at 1-800-222-5500

Monday through Friday,
8 a.m.-4:45 p.m., Pacific
9 a.m.-5:45 p.m., Eastern/Central



©2005 Calcar, Quick Tips® is a trademark of Calcar, made in USA 5/05 73.238M DOT Mazda North American Operations reserves the right to change product specifications at any time without incurring obligations. 9999-95-078C-06QT 6M81-19G217-AA

2006


MAZDA6

Quick Tips®

Reference
Guide for
Controls and
Functions



DRIVER'S VIEW



Getting Started

Mazda6 Quick Tips® are designed to quickly familiarize you with some important features of your Mazda6

This Driver's View tab is your index to the Quick Tips®, locate the item you would like to learn more about and then turn to the listed tab

Be sure to see the tab called Getting Started, this section contains important operating tips about your Mazda6

Items identified in blue text call out important information


1. **Power window switches**, see Switches
2. **Power door locks**, see Locks
3. **Dual power mirrors**, see Switches
4. **Instrument panel lighting**, see Getting Started
5. **Air vents**
6. **Turn signal/lighting control lever**, see Driver Controls
7. **Traction Control System**, see Driving Tips
8. **Horn/Air bag**
9. **Wiper/washer control lever**, see Driver Controls
10. **Clock setting buttons**, see Getting Started
11. **NAVI Display***, see Owner's Manual
12. **Information display**, see Owner's Manual
13. **AMB**
Ambient temperature display
Push for more than three seconds to change between celsius and fahrenheit
14. **Hazard warning switch**, Press on/off
15. **Audio system**, see Audio Systems
16. **Climate control panel**, see Climate Controls
17. **Passenger air bag off indicator**, see Seats
18. **Accessory socket**
19. **Gearshift lever (A/T)***, see Transmission
20. **Cup holder**
21. **Heated seats***, see Trunk/Console
22. **Console**, see Trunk/Console
23. **Parking brake lever**, see Trunk/Console
24. **NAVI Remote control***
25. **Storage**
26. **Cruise control**, see Getting Started
27. **Tilt/telescopic steering-wheel lever**, see Getting Started
28. **Audio control switches**, see Getting Started
29. **Remote trunk release (Sedan only)**
Push to open trunk
30. **Hood release handle**
31. **Headlight leveling switch***, see Getting Started
32. **Bottle holder**
CAUTION: Use plastic bottles with caps, cups may spill when door is closed
33. **Remote fuel-door release**

*Denotes optional equipment

Always check the Owner's Manual for more operating information and safety features

Driver's
View

GETTING STARTED

**Remote keyless entry system**

Functions only with key removed from ignition switch

To lock doors: Press button (1); press again within 5 seconds, doors relock and horn beeps

To unlock: Press (2) for driver's door; press again within 5 seconds to unlock other doors, press and hold for 3 seconds to lower front windows

To open trunk: Press (4)

Panic alarm: Press (3); horn sounds; to stop, press any button on the transmitter or turn ignition to ON position


Remote window operation

Remote keyless entry: Press unlock button (2) and hold, doors/liftgate unlock and windows fully open

Key: Insert key in driver's door lock; turn toward front/rear of vehicle and hold it, after doors/liftgate are unlocked/locked windows will open/close

**Clock**

To set: With ignition in ACC or ON position, press (A) and hold until beep sounds; 12 hr/24hr will be displayed; press (B) to select; press (A) again while selection is flashing: Hr ADJUST displays; press (B) to select hr; press (A) when done, do the same to set minutes

**Tilt/telescopic steering-wheel lever**

Pull lever (5) down to unlock column, adjust tilt angle and length of steering column

WARNING: Do not adjust steering-wheel while driving


**Instrument panel lighting**

To brighten/dim turn thumbwheel up/down

**HID headlights leveling switch**

Set position at 0 unless vehicle is loaded heavily, leveling switch adjusts

headlight angle to compensate for weight of passengers and cargo, see Owner's Manual

**Cruise control**

Operates above 19 mph

To activate:

Press and release ON/OFF (1)

To set speed: Press and release SET/COAST (3) at desired speed


To accelerate: Press and hold RES/ACCEL (2); incremental acceleration: Press and release (2), each tap = plus 1 mph

To decelerate: Press and hold SET/COAST (3), release at desired speed; or tap brake pedal, press and release (3) at desired speed; incremental deceleration: Press and release (3), each tap = minus 1 mph

To cancel: Tap brake pedal, clutch pedal (manual transaxle) or press CANCEL button (4) or ON/OFF (1)

Return to preset speed after

CANCEL button or braking: Press and release RES/ACCEL button (2)
Tip: Cruise control will not be canceled in Manual Mode during gear changes

**Steering-wheel audio controls***

To increase/decrease volume: Press (5)

Radio: Press / (6) less than one second to select next/previous preset station, press / (6) more than one second until beep sound is heard to seek next/previous station

Cassette/CD: Press (6) to select next selection/track, press (6) to repeat current selection/track

Press (7) to select AM, FM 1, FM 2, Cassette* and CD mode

Press (8) to mute Audio/NAVI system*

*Denotes optional equipment

† See Owner's Manual

**Rear center position seat belt (Sport Wagon only)†**

To pull seat belt from ceiling recess (9): Slide tongues with finger while moving downward

Fastening seat belt: Tongue (10) and anchor (11) must be fastened, then slowly pull out lap/shoulder belt (12) and insert tongue (13) into buckle (14) until click is heard


Unfastening seat belt: Depress buckle button to release

Stowing seat belt: Retract belt, put tongues (10) and (13) together, insert securely into recess (9)

Always check the Owner's Manual for more operating information and safety features

Instrument Cluster

INSTRUMENT CLUSTER



GAUGES

1. **Tachometer**
2. **Speedometer**
3. **Fuel gauge**
4. **Odometer/tripmeter**
5. **Gear indicator***
Displays current gear of Sport AT
6. **Odometer/tripmeter selector**
Press to select among trip A, trip B, and odometer
Press and hold to reset selected trip meter
7. **Engine coolant temperature gauge**
If above normal range, stop vehicle and turn off engine, check coolant level when safe

WARNING LIGHTS

8. CRUISE **Cruise control**, see Getting Started
9. CRUISE MAIN **Cruise Control Main Power On**, see Getting Started
10. **Anti-lock Brake System (ABS)**
ABS malfunction, normal brakes only, dealer inspection required
11. **Turn signals/hazard warning on**
12. **AT Automatic transaxle indicator**
Dealer inspection required if light remains on
13. **High beams on**
14. **Traction Control System**,
Light flashes when in use; dealer inspection required if light remains on
15. **Lights on****
16. TCS OFF **Traction Control System off**,
System turned off manually or malfunctioning; dealer inspection required
17. **Low fuel**
18. **Brake system**
Parking brake on/low fluid level
19. **Check engine**
Dealer inspection required
20. **Charging system warning light**
Dealer inspection required
21. **Engine oil pressure warning light**
22. **Air bag readiness**
Front, side and/or curtain air bag malfunction; warning light constantly flashes or stays on or never comes on with ignition on, dealer inspection required
23. **Door ajar**
24. **Immobilizer system on**, see Locks
25. **Always fasten safety belts**


*Denotes optional equipment
**If equipped with black-out meter

Always check the Owner's Manual for more operating information and safety features

Instrument Cluster

Driver Controls

DRIVER CONTROLS



Turn signal/lighting control lever

OFF = Lights off

○ = Tail, parking and dashboard lights on: Rotate knob (1) to first notch

⊞ = Tail, parking, dashboard and headlights on: Rotate knob (1) to second notch


High beams on/off: Push lever forward/pull back to detent

To flash high beams: Pull lever back slightly and release

Turn signals right/left: Move lever up/down

⊞ = Fog lights* on: Rotate knob (2); functions only with headlight low beams on

Tip: Headlights switch off automatically within 30 seconds if lights are left on and switch is in lock position or key removed



Wiper/washer control lever

Intermittent wiper: One click down

To change interval speed:

Rotate inner ring (3)

Normal wiper speed: Two clicks down

Fast wiper speed: Three clicks down

Single wipe: Push stalk up

Washer: Pull stalk back

Rear window wiper/washer (5-Door/Sport Wagon)


To activate rear interval wiper:

Rotate knob (4) up to INT

To activate rear normal speed wiper: Rotate knob (4) up to ON

To activate rear washer with wipers operating: Rotate knob (4) up to ; hold knob (4) to continue washing; release knob and wipers will continue to operate

To operate stand alone wipe/wash function: Rotate knob (4) down and hold, release to stop




Dual power mirrors

Ignition switch must be in ACC or ON position

Switch is on driver's door

To adjust left/right mirror: Press selector switch (1) left/right, press switch (2) in direction of desired movement

Tip: To lock mirrors in place, move selector switch (1) to center position



Power window switches

Ignition switch must be in ON position

All windows controlled from the driver's armrest; passenger doors have separate switches

Front window switches

One-touch down/up: Press/pull AUTO switch (3) firmly and release, window goes down/up all the way, press/pull briefly to stop, press/pull lightly and hold for normal operation

Tip: During closing window operation, window will stop and open partway if object blocks window operation

If battery power is lost, anti-pinch function is disabled, see Owner's Manual for resetting procedure

Rear window switches

Push switch (4) down and hold to open; pull back and hold to close

Power window lockout switch

Press button (5) down until clicks, only driver's window operates; press again and passenger windows function again


*Denotes optional equipment

Always check the Owner's Manual for more operating information and safety features

Switches

Locks

LOCKS



Key

Operates ignition and all locks

Tip: Use key number plate to purchase a new key; store in safe place separate from vehicle

Retractable key


To fold/unfold press release button (1)

Immobilizer system

Prevents engine from running unless coded key is used; see Owner's Manual




Remote keyless entry system, see Getting Started



Liftgate (Sport Wagon)

Liftgate is locked/unlocked via power door lock switch or keyless entry transmitter; pull up on handle (2) to open liftgate



Power door locks

Master front door lock switches

To lock/unlock all doors and liftgate: Press bottom/top of switch (3)

To lock doors without key: With door open, press bottom of door lock switch, exit car, close doors


To unlock: Use key to unlock driver's front door, rotate key to counter-clockwise position for more than one second to unlock other doors, hold for 3 seconds to lower front windows

Manual door locks Lock button

To lock: Press front of button (4) toward door handle

To unlock: Pull front of button away from door handle

Tip: Doors can be locked with key in ignition (chime sounds to alert you to key in ignition)




Child-safety locks

Located at the edge of rear doors

To activate: Pull tab up; door opens from outside only

To cancel: Push tab down

WARNING: Since children may access either rear door, child-safety locks for both rear doors should be activated



Automatic transmission*

P = Park

To move gearshift from Park: Press firmly on brake pedal

R = Reverse

N = Neutral

No gear engaged

D (Overdrive)

For normal driving: Shifts through all forward gears automatically


M (Sport A/T manual shift mode)

Move shifter from D to M to engage manual shift mode, M will be illuminated for manual mode on shift position indicator located in the instrument panel

Manual shifting of transmission is achieved by moving shifter back to upshift and forward to downshift, move shifter from M to D to engage automatic shift mode

Gear indicator (A/T only)*

Illuminated numeral of gear indicator located in the instrument panel displays current gear in Automatic and Manual shift modes



Manual transmission*

Depress clutch pedal to start engine and change gears

WARNINGS: Do not shift into 1st above 20 mph or clutch failure could occur

Resting your foot on clutch pedal while driving and using the clutch to hold your vehicle at a stand still while waiting on a hill may reduce clutch life

*Denotes optional equipment

Always check the Owner's Manual for more operating information and safety features

Transmission

Seats

SEATS

Shoulder belt height adjustment

To raise: Push adjuster upward
To lower: Pull button (1) and slide downward



WARNING: Make sure adjuster locks in one of its positions

Manual controls

1. Fore-aft adjustment

Lift lever and hold, slide seat, release lever

2. Raise/lower seat


Pull/push lever and release

3. Seatback angle

To adjust: Lift and hold lever, lean forward or backward, release lever

4. Head restraint

To raise/lower: Pull up/push in release button (8) and push down



5. Lumbar adjustment*

Rotate knob to increase/decrease firmness

Power driver's seat*

6. Raise/lower front of seat cushion

Pull/push front of switch vertically

Fore/aft adjustment

Slide switch horizontally

Raise/lower rear of seat cushion

Pull/push rear of switch vertically

Raise/lower seat

Pull/push center of switch vertically

7. Seatback angle

Press front/rear of switch

Tip: Verify side air bags* by locating "SRS AIRBAG" indicator tags on outboard side of front seatbacks

Folding rear seatbacks, see Trunk/Liftgate

WARNINGS: Do not adjust seats while driving
Safety belts must always be worn when vehicle is in motion
Air bags are supplemental and do not replace safety belt usage

Always wear your safety belt and properly secure children 12 and under in the rear seat
Never place rear-facing infant-safety seat in front of any air bag, an infant is in serious danger of being injured or killed

If you must install a forward-facing child-safety seat in the front seating position, move vehicle seat as far back as possible
Use age appropriate child restraints, see Owner's Manual and state or province laws

Child-safety seat

To install in rear outboard seats: Use dual locking mode retractor seat belts; see Owner's Manual for proper installation and child seat tether and LATCH system instructions

Passenger air bag deactivation indicator light

Front air bag deactivation indicator light provides current status of front passenger air bag and pretensioner system

If total seated weight on front passenger seat is less than approximately 66 lb., front passenger air bag deactivation indicator light illuminates, air bag/pretensioner will not deploy/activate in an accident

If the total seated weight is greater than approximately 93 lb., light does not illuminate, and the air bag/pretensioner will deploy/activate in an appropriate accident,

see Owner's Manual for additional information on this feature and the air bag system

Safety belt emergency locking mode

Belts lock only on hard acceleration, braking, cornering or impacts of about 5 mph or more

Automatic locking mode (front passenger and all rear safety belts only)

Must be used when installing child-safety seat

To activate: Pull belt fully out of retractor, allow belt to retract until click is heard; belt will only tighten

To disengage: Unbuckle belt and allow belt to retract fully

Rear center position seat belt

5-Door: Seat belt stowage located behind left side head rest
Sport Wagon: See Getting Started


*Denotes optional equipment

Always check the Owner's Manual for more operating information and safety features


Seats

Climate Controls

CLIMATE CONTROLS



Manual A/C



Automatic A/C*

1. Air flow selections

- = air to dash
- = air to dash and floor
- = air to floor
- = air to floor and windshield
- = air to windshield (defrost) (Manual Climate Control)

5. Air intake control

- = recirculate inside air; use for maximum cooling
- = fresh air

WARNING: Do not use position in cold weather, windows may fog and hamper vision

7. Windshield defroster switch

Press: Fresh air position is automatically selected, A/C automatically turns ON

8. OFF

Control positions for maximum defrost

Fan to maximum, temperature to maximum hot, selected

Tips: To help prevent windshield fogging in humid weather, select

2. Fan control

Rotate knob clockwise/ counterclockwise to increase/ decrease fan speed

3. Temperature control

Cooler/warmer = rotate knob counterclockwise/clockwise

4. A/C = air conditioner

Press to turn on/off

6. Rear window defogger

Press on/off; shuts off with ignition or automatically after 15 minutes of operation; also operates heated side mirrors*


Tip: The word "heated" is imprinted on glass reflector of side mirrors, this indicates they are heated

To prevent fogging, never drive with system off

Objects placed under the front seats may interfere with air flow to the rear

Automatic operation

Press AUTO (9) for automatic operation; rotate outer dial to set temperature, see Owner's Manual



1. Map/reading light switch

Press on/off

2. Interior light switch

DOOR = light on when door open
OFF = light always off

3. Interior map/reading light

4. Sunglass holder

Press concaved lip to open

5. Sunroof tilt switch*

Press rear of switch to tilt rear of sunroof
Press front of switch to close

6. Sunroof slide switch*

Press rear of switch to open sunroof
Press front of switch to close

Illuminated visor mirrors

Mirrors lighted when covers open; off when closed

*Denotes optional equipment

Always check the Owner's Manual for more operating information and safety features

Interior
Lights

AM/FM STEREO/CASSETTE/CD CHANGER

1. Power/Volume

Press to turn on/off; rotate to increase/decrease volume

2. SEEK/TRACK/APC

Radio: Press \wedge / \vee to automatically seek higher/lower frequency


CD: Press \wedge / \vee to select next/previous track

Cassette*: Press \wedge / \vee to automatically advance tape to beginning of next selection/replay selection; to stop this operation, press button again

3. LOAD*

To load multiple discs: Press and hold LOAD (3) until beep sound is heard; insert CD when "In" is displayed

To eject disc: Press Eject (11)



Tips: Always remove antenna before entering a car wash
To remove antenna; rotate counter-clockwise,
to install rotate clockwise

To eject specific disc: Press and hold Eject (11) until beep sound is heard; within five seconds press the desired tray number 1-6 (4)

4. Memory preset buttons

To set: Tune to station, press and hold until beep sound is heard

5. FM1/2

Press to select between FM1/FM2 station preset buttons (4)

6. AM

Press to select AM frequency band

7. SAT†, Satellite ready capability

8. CD slot

9. CD, Press to play CD

10. MEDIA

Press to play cassette tape

11. CD eject button

*Denotes optional equipment

†SAT button is standard but requires SIRIUS subscription/additional hardware

12. Scan/Auto-Memory

Press to briefly sample next listenable selections; functions in all modes

Radio: Press and hold until a beep sound is heard; system automatically scans and temporarily stores six strong stations in each band; press again to cancel

13. Tuning/Audio Control

Tune: Rotate counterclockwise/clockwise for lower frequency/higher frequency

Audio control: Press to select ALC/BASS/TREB/FADE/BAL/BEEP (Automatic level control) can be turned on and off; rotate right/left to adjust selected feature

ALC ON = Audio volume decreases/increases with vehicle speed

ALC OFF = Audio volume does not decrease/increase with changes in vehicle speed

14. Fast forward ►►

Press to fast forward through a track

15. Cassette eject button*

16. Reverse ◀◀

Press to reverse through a track

17. Program Random

Press for random play

18. Cassette door*

19. Repeat

Press to replay current CD/tape selection

20. Dolby® Noise Reduction*

Reduces tape noise and hiss; press to activate/deactivate

21. Disc up ^*


Press to skip forward to beginning of next CD

22. Disc down v*

Press to skip back to beginning of previous CD

Always check the Owner's Manual for more operating information and safety features

HOMELINK®



HomeLink® Wireless Control System*

Located on rear view mirror
HomeLink® provides three
programmable buttons that
will replace three hand-held
device transmitters

Tip: It is recommended to
park outside of garage when
programming HomeLink®

WARNING: When programming
a garage door or gate opener,
disconnect power to these
devices before programming,
continuous operation of these
devices could damage the motor

To program or reprogram:
Press and hold two outer
HomeLink® buttons (1) for 20
seconds and no more than
30 seconds, release only after
indicator light (4) begins to
flash; hold transmitter for the
device to be programmed
between 1-3 inches to
HomeLink®; press transmitter
button and desired HomeLink®
button (1) simultaneously until
HomeLink® indicator light (4)
goes from slow to rapid flashing
Verify device operation by
pressing HomeLink® button (1)
that was just programmed

Tip: You do not need to repeat
the first step to program the
other two hand-held transmitters
for the remaining
HomeLink® buttons

Rolling code synchronization procedure

Refer to your garage door opener or
device instruction manual to confirm
your system is equipped with a
rolling code feature

Tip: This procedure is easier
to perform with the assistance
of another person

To synchronize: Press programming
button on garage door opener
motor; press/hold for 2 seconds
and release the programmed
HomeLink® button 2 times
within 30 seconds of pressing
the garage door opening
motor programming button

Some devices may require you
to press/hold and release a
third time to complete
programming procedure
If indicator light stays on,
programming is complete

For further information, contact
HomeLink® at **1-800-355-3515**,
www.homelink.com or your
authorized Mazda Dealer

To erase all existing programming;
press and hold two outer
HomeLink® buttons (1) on mirror,
continue to hold buttons until
indicator light flashes

Auto-dimming rear view mirror*

Auto-dimming function changes
are based on outside lighting
conditions and if bright headlights
are visible in rear view mirror
Press on (2), off (3)

Gas cap

After filling vehicle with gasoline,
fully reinstall gas cap by turning
clockwise until a clicking sound is
heard, if gas cap is not fully
installed, Check Engine light
may come on

For more information on Check
Engine light, see Owner's Manual

Anti-lock Braking System (ABS)

ABS automatically reduces
hydraulic pressure to any wheel
on the verge of locking up
You may feel a slight pulsing of
the brake pedal and hear a
clicking noise; this tells you the
ABS is functioning properly;
increase pressure on pedal for
maximum braking

Tip: Maintain constant
pressure on the brake pedal
Do not pump the brakes

ABS self test

A self-diagnostic test is performed
when starting; you may feel some
brake pedal pulsation and hear
some noise, this is normal

Traction Control System (TCS)

Enhances traction and safety by
regulating engine torque
When TCS detects drive wheel
slippage it lowers engine torque
to prevent loss of traction


*Denotes optional equipment

Always check the Owner's Manual for more operating information and safety features


Driving
Tips

Trunk/ Liftgate


TRUNK/LIFTGATE



Mazda6 Sedan



Mazda6 5-Door



Mazda6 Sport Wagon

1. Lug wrench

2. Jack

Remove cover panel to access

3. Cargo light

4. Cargo securing loops


5. Rear seatback remote handle levers

6. Seatback release buttons

7. Cargo area cover

Split rear folding seatback (Sedan)

Unfasten the lap portion of the rear center seat belt, pull rear seatback remote handle levers (5) To raise seatback: Push seatback firmly until latched, re-attach center belt



Luggage compartment internal safety release (Sedan)

Allows you to escape should you become locked in trunk
Slide illuminated release lever in direction of arrow; lever will glow if it has been exposed to light
Located on interior trunk lid

8. Sub-compartment cover

Lift carpet, disconnect sub-woofer wire connector, remove cargo sub-compartment cover, remove sub-woofer, remove spare tire (Sedan not equipped with sub-woofer)

9. Temporary spare tire

Stored under panel in trunk

Folding rear seatbacks flat (5-Door/Sport Wagon)

Unfasten rear seat belt, pull handle levers (5) on left/right side or press seatback release buttons (6) support seatback; then fold seatback forward

To raise seatback: Lift seatbacks upward until firmly latched, properly fasten rear seat belts, then check that seat belts are routed properly for passenger use

Tire economy and tips

Check pressure regularly when tires are cold, maintain correct front-end alignment and tire balance; rotate tires every 7,500 miles

Tire pressure

P215/45R18 93W,
P215/50R17 93V,
P205/60R16 91V (Sedan only)


Front/rear: 32psi cold

Tip: Correct tire pressure promotes safe handling and ride comfort

Tire chains†

Tire chains cannot be used on this vehicle, interference with vehicle body and scratching could occur

*Denotes optional equipment
†See Owner's Manual



1. Console

2. Parking-brake lever

To engage: Pull up
To release: Pull up slightly while depressing button at front of lever, lower hand brake lever

3. Cup holder

4. Storage

5. Heated seats*

Press on/off switch; indicator light on when activated


6. Accessory socket

Always check the Owner's Manual for more operating information and safety features

Trunk/ Console

Under Hood

UNDER HOOD



1. Engine oil filler cap

SAE 5W-20

2. Automatic transmission fluid (ATF) dipstick*

See Owner's Manual

3. Brake/Clutch* fluid reservoir

Fill to MAX mark with DOT 3 fluid; check with cap on

4. Battery

5. Fuse block

6. Air filter

7. Hood support rod

8. Hood latch

Push hood latch to the right, open hood

9. Engine coolant reservoir

Level should be between FULL and LOW markings when cold

⚠ WARNING: Never remove coolant reserve tank cap while engine is running or hot; you could get burned

10. Engine oil dipstick

Check with engine off after approximately 5 minutes and at operating temperature; fluid level should be between MAX and MIN markings on dipstick

11. Power steering fluid reservoir

Check with engine off and at normal temperature; fill to MAX mark

12. Windshield washer reservoir

Fill with windshield washer fluid

Break-in period

First 600 miles: Drive at varying road and engine speeds; avoid full throttle, rapid acceleration or kick-down of transmission

Unique driving conditions†

Every 5,000 miles change oil/filter, inspect coolant level, lights, brake/clutch fluid, tire pressure/wear, power steering fluid, locks/hinges and washer fluid

Normal maintenance notes

Rotate tires every 7,500 miles or sooner if needed

Replace cabin air filter every 25,000 miles or 24 months

Inspect exhaust system and heat shields every 45,000 miles

Replace (FL22)* engine coolant every 120,000 miles or 10 years

*Denotes optional equipment

† See Owner's Manual

NORMAL SERVICE INTERVALS

7,500 miles	A
15,000 miles	A B
22,500 miles	A
30,000 miles	A B C
37,500 miles	A D
45,000 miles	A
52,500 miles	A
60,000 miles	A B C E
67,500 miles	A
75,000 miles	A F
82,500 miles	A
90,000 miles	A
105,000 miles	G

A. Change: Engine oil/
replace filter

Lube: Locks and hinges

B. Inspect: Disc brakes

C. Inspect: Drive belts (3.0 liter), fuel lines and hoses, brake lines, hoses and connections, steering operation and linkages, front and rear suspension ball joints, driveshaft dust boots, cooling system

D. Inspect: Drive belts (2.3 liter)
Replace: Air filter

E. Inspect: Hoses and tubes for emission system

F. Replace: Spark plugs
Inspect: Engine valve clearance (2.3 liter), adjust if noisy

G. Replace: Engine coolant (Other than FL22)

Always check the Owner's Manual for more operating information and safety features