





About this manual

This manual contains a description of the equipment supplied with the vehicle at the time this manual was published. Some of the units described herein will not be available until a later date or are only available in certain markets.

Because this is a general manual for the IBIZA range, some of the equipment and functions that are described in this manual are not included in all types or variants of the model: they may vary or be modified depending on the technical requirements and on the market: this is in no way deceptive advertising.

The illustrations are intended as a general guide and may vary from the equipment fitted in your vehicle in some details.

The steering indications (left, right, forward, reverse) appearing in this manual refer to the normal driving movements of the vehicle except when otherwise indicated.

The audiovisual material only is intended to help users to understand certain car functionalities better. It does not replace the instruction manual. Please use the instruction manual to obtain more comprehensive information and indications.

* The equipment marked with an aster-

isk* is fitted as standard only in certain versions, and is only supplied as optional extras for some versions, or are only offered in certain countries.

- R All registered marks are indicated with ®. Although the copyright symbol does not appear, it is a copyrighted mark.
- >> The section is continued on the following page.
- Æ Important warnings on a given page
- Detailed contents on a given page
- General information on a given page
- SOS Emergency information on a given page
- -Audiovisual material on a given page

A WARNING

Texts preceded by this symbol contain information on safety. They warn you about possible dangers of accident or injury.

() CAUTION

Texts with this symbol draw your attention to potential sources of damage to your vehicle.

\Re For the sake of the environment

Texts preceded by this symbol contain relevant information concerning environmental protection.

i Note

Texts preceded by this symbol contain additional information.

This manual is divided into six large parts, which are.

- 1. The essentials
- 2. Safety
- 3. Emergencies
- 4. Operation
- 5. Tips

6. Technical data

At the end of this manual, there is a detailed alphabetical index that will help you quickly find the information you require.

Foreword

This Instruction Manual and its corresponding supplements should be read carefully to familiarise yourself with your vehicle.

Besides the regular care and maintenance of the vehicle, its correct handling will help preserve its value.

For safety reasons, always note the information concerning accessories, modifications and part replacements.

If selling the vehicle, give all of the on-board documentation to the new owner, as it should be kept with the vehicle. You can access the information in this manual using:

- Thematic table of contents that follows the manual's general chapter structure.
- Visual table of contents that uses graphics to indicate the pages containing "essential" information, which is detailed in the corresponding chapters.
- Alphabetical index with many terms and synonyms to help you find information.

∆ WARNING

Read and always observe safety information concerning the passenger's front airbag »» page 72, Important information regarding the front passenger's airbag.

»

Related videos



Table of Contents

Table of Contents

The essentials	5
Exterior view	5
Exterior view	6
Interior view (left-hand drive)	7
Interior view (right-hand drive)	8
How it works	9
Opening and closing	9
Before driving	12
Airbags	14
Child seats	16
Starting the vehicle	21
Lights and visibility	21
Easy Connect	24
Driver information system	25
Journey data	29
Cruise control	34
Warning lamps	35
Gearbox lever	37
Air conditioning	39
Fluid Level control	40
Emergencies	44
Fuses	44
Bulbs	45
Action in the event of a puncture	45
Changing a wheel	47
Snow chains	50
Emergency towing of the vehicle	51
How to jump start	52
Changing the windscreen wiper blades	54
Safety	56
Safe driving	56
Safety first!	56
Advice about driving	56

Pedal area 61 Seat belts 61 Why wear a seat belt? 61 Why wear a seat belt? 61 Belt pretensioners* 65 Airbag system 66 Brief introduction 66 Airbag system 66 Airbag system 66 Airbag setty instructions 69 Deactivating airbags 70 Transporting children safely 72 Safety for children 72 Child seats 73 Emergencies 75 Self-help 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses 80 Fuses 80 Changing the bulbs 83 Single headlight bulb change 84 Double headlight bulb change 84 Double headlight bulbs 87 Changing the fog light bulbs 87 Changing the fog light bulbs 87 Changing the side and interior bulbs 89 Ope	Correct position for passengers	57
Why wear a seat belt? 61 How to properly adjust your seatbelt 64 Belt pretensioners* 65 Airbag system 66 Brief introduction 66 Airbag system 66 Deactivating airbags 70 Transporting children safely 72 Safety for children 72 Child seats 73 Emergencies 75 Self-help 75 Emergency equipment 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Changing the AFS headlight bulbs 87 Changing the AFS headlight bulbs 87 Changing the AFS headlight bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Maring and control lamps 94	Pedal area	61
How to properly adjust your seatbelt 64 Belt pretensioners* 65 Airbag system 66 Airbag system 66 Airbag system 66 Airbag safety instructions 69 Deactivating airbags 70 Transporting children safely 72 Safety for children 72 Child seats 73 Emergencies 75 Self-help 75 Tyre repair 76 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses 80 Changing the AFS headlight bulbs 83 Single headlight bulb change 84 Double headlight bulb change 84 Double headlight bulb change 85 Changing the Kaellight bulbs 87 Changing the kaellight bulbs 87 Changing the side and interior bulbs 89 Operation 93 Controls and displays 93 General instrument panel 92 Instruments	Seat belts	61
Belt pretensioners* 65 Airbag system 66 Brief introduction 66 Brief introduction 66 Airbag safety instructions 69 Deactivating airbags 70 Transporting children safely 72 Safety for children 72 Child seats 73 Emergencies 75 Self-help 75 Emergency equipment 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Fuses and bulbs 83 Single headlight bulb change 84 Changing the KFS headlight bulbs 87 Changing the AFS headlight bulbs 87 Changing the tail light bulbs 88 Changing the side and interior bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Marning and control lamps 94 Instruments 94	Why wear a seat belt?	61
Airbag system 66 Brief introduction 66 Airbag safety instructions 69 Deactivating airbags 70 Transporting children safely 72 Safety for children 72 Child seats 73 Emergencies 75 Self-help 75 Emergency equipment 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Fuses 80 Changing the Airbicker on wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the AFS headlight bulbs 87 Changing the Ail light bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Marning and control lamps 94 Maring and control lamps 94	How to properly adjust your seatbelt	64
Brief introduction 66 Airbag safety instructions 69 Deactivating airbags 70 Transporting children safely 72 Safety for children 72 Child seats 73 Emergencies 75 Self-help 75 Emergency equipment 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Changing bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the AFS headlight bulbs 87 Changing the side and interior bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Marning and control lamps 94 Introduction to the Easy Connect system* 99		65
Airbag safety instructions 69 Deactivating airbags 70 Transporting children safely 72 Safety for children 72 Child seats 73 Emergencies 75 Self-help 75 Emergency equipment 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Changing the kindscreen wiper blades 83 Single headlight bulb change 84 Double headlight bulb change 84 Double headlight bulb change 85 Changing the KFS headlight bulbs 87 Changing the kall light bulbs 88 Changing the side and interior bulbs 89 Operation 93 Controls and displays 93 General instrument panel 92 Instruments 94 Marming and control lamps 94		66
Deactivating airbags 70 Transporting children safely 72 Safety for children 72 Child seats 73 Emergencies 75 Emergency equipment 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Fuses 80 Changing the kindscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Fuses and bulbs 80 Fuses and bulbs 81 Single headlight bulb change 84 Double headlight bulb change 85 Changing the FQ light bulbs 87 Changing the fog light bulbs 88 Changing the side and interior bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Marning and control lamps 94 Instruments 94 Marning and control lamps 98	Brief introduction	66
Transporting children safely 72 Safety for children 72 Safety for children 72 Child seats 73 Emergencies 75 Saferhelp 75 Emergency equipment 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Fuses and bulbs 80 Changing bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the AFS headlight bulbs 87 Changing the AFS headlight bulbs 87 Changing the fog light bulbs 88 Changing the side and interior bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Marning and control lamps 94 Instruments 94 Marning and control lamps 94		69
Safety for children 72 Child seats 73 Emergencies 75 Self-help 75 Emergency equipment 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Changing bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the AfS headlight bulbs 87 Changing the adlight bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Marning and control lamps 94 Marning and control lamps 98		70
Child seats 73 Emergencies 75 Self-help 75 Emergency equipment 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Fuses and bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the fog light bulbs 87 Changing the fog light bulbs 87 Changing the side and interior bulbs 89 Operation 93 Controls and displays 93 General instrument panel 92 Instruments and warning/control lamps 94 Instruments 94 Marting and control lamps 94	Transporting children safely	72
Emergencies 75 Self-help 75 Emergency equipment 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Towing or tow-starting 79 Fuses and bulbs 80 Fuses and bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the fog light bulbs 87 Changing the side and interior bulbs 88 Changing the side and interior bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Marning and control lamps 94 Introduction to the Easy Connect system* 99	Safety for children	72
Self-help 75 Emergency equipment 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Fuses and bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the AFS headlight bulbs 87 Changing the fol light bulbs 87 Changing the side and interior bulbs 89 Operation 93 Controls and displays 93 General instrument panel 92 Instruments 94 Marming and control lamps 94 Marming and control lamps 98	Child seats	73
Emergency equipment 75 Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Fuses 80 Changing bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the fog light bulbs 87 Changing the side and interior bulbs 88 Changing the side and interior bulbs 89 General instrument panel 92 Instruments 94 Marning and control lamps 94 Introduction to the Easy Connect system* 99	Emergencies	75
Tyre repair 76 Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Fuses and bulbs 80 Fuses and bulbs 80 Fuses and bulbs 80 Changing bulbs 83 Single headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the AFS headlight bulbs 87 Changing the Fog light bulbs 87 Changing the side and interior bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Instruments 94 Marning and control lamps 98	Self-help	75
Changing the windscreen wiper blades 78 Towing or tow-starting 79 Fuses and bulbs 80 Fuses and bulbs 80 Changing bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the AFS headlight bulbs 87 Changing the AfS headlight bulbs 87 Changing the side and interior bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Marning and control lamps 94 Introduction to the Easy Connect system* 99	Emergency equipment	75
Towing or tow-starting 79 Fuses and bulbs 80 Fuses and bulbs 80 Fuses and bulbs 80 Changing bulbs 81 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the fog light bulbs 87 Changing the tail light bulbs 87 Changing the side and interior bulbs 89 Operation 93 Controls and displays 93 General instrument panel 92 Instruments 94 Instruments 94 Marning and control lamps 98	Tyre repair	76
Fuses and bulbs 80 Fuses 80 Changing bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the fog light bulbs 87 Changing the fog light bulbs 87 Changing the side and interior bulbs 88 Changing the side and interior bulbs 89 Controls and displays 93 General instrument panel 92 Instruments 94 Marning and control lamps 94 Introduction to the Easy Connect system* 99	Changing the windscreen wiper blades	78
Fuses 80 Changing bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the fog light bulbs 87 Changing the tail light bulbs 87 Changing the side and interior bulbs 88 Controls and displays 93 General instrument panel 92 Instruments 94 Marning and control lamps 94 Introduction to the Easy Connect system* 99		79
Changing bulbs 83 Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the AFS headlight bulbs 87 Changing the fog light bulbs 87 Changing the side and interior bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Instruments 94 Marning and control lamps 98	Fuses and bulbs	80
Single headlight bulb change 84 Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the fog light bulbs 87 Changing the tail light bulbs 88 Changing the side and interior bulbs 88 Controls and displays 93 General instrument panel 92 Instruments 94 Instruments 98 Introduction to the Easy Connect system* 99	Fuses	80
Double headlight bulb change 85 Changing the AFS headlight bulbs 87 Changing the fog light bulbs 87 Changing the tail light bulbs 87 Changing the side and interior bulbs 89 Operation 93 Controls and displays 93 General instrument panel 92 Instruments 94 Instruments 94 Introduction to the Easy Connect system* 99		83
Changing the AFS headlight bulbs 87 Changing the fog light bulbs 87 Changing the tail light bulbs 87 Changing the tail light bulbs 88 Changing the side and interior bulbs 89 Operation 93 General instrument panel 92 Instruments 94 Instruments 94 Marning and control lamps 98	Single headlight bulb change	84
Changing the fog light bulbs 87 Changing the tail light bulbs 88 Changing the side and interior bulbs 89 Operation 93 Controls and displays 93 General instrument panel 92 Instruments and warning/control lamps 94 Instruments 94 Introduction to the Easy Connect system* 99	Double headlight bulb change	85
Changing the tail light bulbs 88 Changing the side and interior bulbs 89 Operation 93 Controls and displays 93 General instrument panel 92 Instruments and warning/control lamps 94 Instruments 94 Instruments 94 Intruduction to the Easy Connect system* 99	Changing the AFS headlight bulbs	87
Changing the side and interior bulbs 89 Operation 93 Controls and displays 93 General instrument panel 92 Instruments and warning/control lamps 94 Instruments 94 Instruments 94 Instruments 94 Instruments 94 Introduction to the Easy Connect system* 99		87
Operation 93 Controls and displays 93 General instrument panel 92 Instruments and warning/control lamps 94 Instruments 94 Marning and control lamps 98 Introduction to the Easy Connect system* 99	Changing the tail light bulbs	88
Controls and displays 93 General instrument panel 92 Instruments and warning/control lamps 94 Instruments 94 Warning and control lamps 98 Introduction to the Easy Connect system* 99	Changing the side and interior bulbs	89
General instrument panel 92 Instruments and warning/control lamps 94 Instruments 94 Warning and control lamps 98 Introduction to the Easy Connect system* 99	Operation	93
Instruments and warning/control lamps 94 Instruments 94 Warning and control lamps 98 Introduction to the Easy Connect system* 99	Controls and displays	93
Instruments 94 Warning and control lamps 98 Introduction to the Easy Connect system* 99	General instrument panel	92
Warning and control lamps 98 Introduction to the Easy Connect system* 99	Instruments and warning/control lamps	94
Introduction to the Easy Connect system* 99	Instruments	94
	Warning and control lamps	98
System settings (CAR)*	Introduction to the Easy Connect system*	99
	System settings (CAR)*	99


Communications and multimedia	101
Steering wheel controls*	101
Multimedia	105
Opening and closing	106
Central locking system	106
Keys	110
Radio frequency remote control*	110
Anti-theft alarm*	111
Boot hatch	113
Electric windows	114
Tilting panoramic roof*	116
Lights and visibility	117
Lights	117
Interior lights	122
Visibility	123
Windscreen wiper and rear window wiper sys-	
tems	123
Rear view mirrors	125
Seats and head restraints	127
Adjusting the seat and head restraints	127
Seat functions	128
Transport and practical equipment	130
Practical equipment	130
Luggage compartment	133
Roof rack/roof luggage rack*	135
Air conditioning	137
Heating, ventilation and cooling	137
Heating and fresh air	139 141
Air conditioning*	
Climatronic*	143 145
Driving	
Address	145 147
Braking and parking	147
	149 152
Braking and stability systems	-
Manual gearbox Automatic gearbox*	158 158
Run-in and economical driving	158 164
Kull-III allu econolilical driving	104

Table of Contents


Engine management and exhaust gas purifica-	
tion system	166
Driving tips	169
Driver assistance systems	170
Start-Stop System*	170
Fatigue detection (break recommendation)*	171
Parking aid	173
Rear Assist "Rear View Camera"*	177
Cruise speed* (cruise control - GRA)	180
"SEAT Drive Profile" system	182
Towing bracket device and trailer	183
Trailer mode	183
Retrofitting a towing bracket*	185
Advice	187
Care and maintenance	187
Accessories and modifications to the vehi-	
cle	187
Care and cleaning	188
Care of the vehicle exterior	189
Caring for the vehicle interior	194
Checking and refilling levels	196
Refuelling	196
Fuel	196
Working in the engine compartment	198
Engine oil	201
Cooling system	204
Brake fluid	206
Windscreen washer reservoir	207
Vehicle battery	207 210
Wheels	210
Wheels and tyres	210
Winter service	214
Technical data	216
Technical specifications	216
Important information	216
Information on fuel consumption	217

Index	233
Dimensions	231
Engine data	219
Wheels	218
Trailer mode	217


Exterior view




Exterior view



Interior view (left-hand drive)



Interior view (right-hand drive)



How it works

Opening and closing

Doors



Fig. 1 Remote control key: buttons.



Fig. 2 Centre console: Central lock buttons.

Locking and unlocking the vehicle using the key

The essentials

- Locking: press the 🗗 >>> Fig. 1 button.
- Unlocking: press the 🗇 >>> Fig. 1 button.
- Unlocking the rear lid: press the ↔ **WFig. 1** button until all the turn signals on the vehicle briefly light up.

Locking and unlocking with the central locking switch

- Locking: press the ☐ >>> Fig. 2 button. None of the doors can be opened from the outside.
 The doors can be opened from the inside by pulling the inside door handle.
- Unlocking: press the 🕆 🐝 Fig. 2 button.



Rear lid



Fig. 3 Rear lid: opening from the outside.

The rear lid opening system operates electrically. It is activated by using the handle on the boot lid.

This system may or may not be operative, depending on the situation of the vehicle.

If the rear lid is locked then it cannot be opened, however if it is unlocked then the opening system is operative and the rear lid may be opened.

To lock/unlock, press the button \Leftrightarrow or button $\widehat{\Box}$ **>> Fig. 1** on the remote control key.

A warning appears on the instrument panel display if the rear lid is open or not properly closed.* An audible warning is also given if the boot lid is opened while the vehicle is moving faster than 6 km/h (4 mph)*.

- Opening the rear lid: Pull on the release lever and lift it up **>>> Fig. 3**. The rear lid opens automatically.
- Closing the rear lid: Hold it by one of the handles on the interior lining and close it by pushing gently.

»» ⚠ in Opening and closing on page 114

SOS »page 10

Unlocking the rear lid manually



Fig. 4 Unlocking the rear lid manually.

This allows the vehicle to be opened if the central locking does not work (for example, if the battery is flat)

There is a groove in the luggage compartment allowing access to the emergency opening mechanism.


Opening the rear lid from inside the luggage compartment

• Insert the key in the groove and unlock the locking system, turning the key from right to left, as shown by the arrow **»** Fig. 4.

Bonnet



Fig. 5 Release lever in the driver's footwell area.





• Opening the bonnet: Pull the lever under the dashboard **>>> Fig. 5** (1).

• Lifting up the bonnet: press the release catch under the bonnet upwards **»** Fig. 6 (2). The arrester hook under the bonnet is released.

• Release the bonnet stay and secure it in the fixture designed for this in the bonnet.



» ▲ in safety notes for work in the engine compartment on page 198

»» page 198

Electric windows*




Fig. 7 Detail of the driver door: controls for the windows.

- Opening the window: Press the 🗷 button.
- Closing the window: Pull the 🗷 button.

Buttons on the driver door

- (1) Window on the front left door
- 2 Window on the front right door
- 3 Safety switch for deactivating the electric window buttons on the rear doors (only 5door vehicles)
- Window on the rear left door (only 5-door vehicles)
- Window on the right rear door (only 5door vehicles)



» ▲ in Opening and closing of the electric windows* on page 114

»» page 114

Panoramic roof*




Fig. 8 On the interior roof lining: Panoramic sunroof controls

- Opening: Press the **>>> Fig. 8** (A) button once only. If you keep it pressed down, it will open to the desired position.
- Closing: Press the **»** Fig. 8 (B) button once only. If you keep it pressed down, it will close to the desired position.

Restoring one-touch opening and closing

• Close the sunroof manually until it is completely closed. Release the button.

• Press the closing button again, keeping it pressed down, until a complete opening and closing cycle has taken place.



»» page 11

SOS

Operation of the panoramic sunroof




Fig. 9 Emergency operation of the panoramic/tilting sunroof.

In case of a breakdown, the sunroof may be closed manually.

• Remove the plastic cover by inserting a screwdriver into the rear section.

»

• Insert an Allen key (4 mm) into the opening as far as possible and close the sunroof.

Before driving

Manually adjusting the front seats



Fig. 10 Front seats: manual seat adjustment.

- 1 Forward/back: pull the lever and move the seat forwards or backwards.
- 2 Raising/lowering: pull/push the lever.
- (3) Tilting the backrest: turn the hand wheel.

(4) Folding down the backrest (only 3-door vehicles): pull the lever and push the backrest forward.



»≫ ⚠ in Adjusting the front seats on page 127

Adjusting the head restraints




Fig. 11 Front seat: adjustment of the head restraint.

• Grab the sides of the head restraints with both hands and push upwards to the desired position. To lower it, repeat the same action, pressing the 1 button on the side.



)) $\stackrel{\mbox{\scriptsize whith}}{\bigtriangleup}$ in Adjusting or disassembling the head restraints on page 128

W page 60 W pa

»» page 60, »» page 128

Adjustment of the seat belt




Fig. 12 Positioning and removing the seat

belt buckle.




Fig. 13 Correct seat belt and head restraint positions, viewed from front and the side.

To adjust the seat belt around your shoulders, adjust the height of the seats.

The shoulder part of the seat belt should be well centred over it, never over the neck. The seat belt lies flat and fits comfortably on the upper part of the body.

The lap part of the seat belt lies across the pelvis, never across the stomach. The seat belt lies flat and fits comfortably on the pelvis.



» page 63



Seat belt tensioners

During a collision, the seat belts on the front seats are retracted automatically.

The tensioner can be triggered only once.





» ▲ in Service and disposal of belt tensioners on page 66

»» page 65

Adjusting the exterior mirrors




Fig. 14 Detail of the driver door: control for the exterior mirror.

Adjusting the exterior mirrors: Turn the knob to the corresponding position:

L/R Turning the knob to the desired position, adjust the mirrors on the driver

side (L, left) and the passenger side (R, right) to the direction desired.

G→ Folding in mirrors.



» ▲ in Electric exterior mirrors* on page 126



» page 126

Adjusting the steering wheel



Fig. 15 Lever in the lower left side of the steering column.

• Adjusting the position of the steering wheel: Pull the **» Fig. 15 (1)** lever down, move the steering wheel to the desired position and lift the lever back up until it locks.



» ▲ in Adjusting the steering wheel position on page 58

Airbags

front airbags




Fig. 16 Driver airbag located in steering wheel.





Fig. 17 Front passenger airbag located in dash panel.

The front airbag for the driver is located in the steering wheel **» Fig. 16** and the airbag for the front passenger is located in the dash panel **» Fig. 17**. Airbags are identified by the word "AIRBAG".

When the driver and front passenger airbags are deployed, the covers remain attached to the steering wheel and dashboard, respectively **»** Fig. 16 **»** Fig. 17.

In conjunction with the seat belts, the front airbag system gives the driver and the front passenger additional protection for the head and chest in the event of a severe frontal collision.

The special design of the airbag allows the controlled escape of the propellant gas when an occupant puts pressure on the bag. Thus, the head and chest are surrounded and protected by the airbag. After the collision, the airbag deflates sufficiently to allow visibility.



Deactivating the front passenger front airbag



Fig. 18 Front passenger front airbag switch.

To deactivate the front passenger front airbag:

• Open the glove compartment on the front passenger side.

• Insert the key blade into the slot provided in the deactivation switch.

• Approximately $\frac{3}{4}$ of the length of the key blade remains inserted (the maximum).

• Turn the key blade, changing its position to **OFF**. Do not force it. If you have difficulty, ensure that you have inserted the key as far as it will go.

• Finally, check the control lamp on the instrument panel where it shows **PASSENGER AIR BAG OFF** %; the following should appear **OFF**.



» ▲ in Deactivation of front passenger front airbag* on page 71

»» page 70

Side airbags*



Fig. 19 Side airbag in driver's seat.




Fig. 20 Illustration of completely inflated side airbag on left side of vehicle.

The side airbags are located in the driver's seat and front passenger seat backrests **>>> Fig. 19**. The locations are identified by the text "AIRBAG" in the upper region of the backrests.

In conjunction with the seat belts, the side airbag system provides additional protection for the upper body in the event of a severe side collision.

In a side collision, the side airbags reduce the risk of injury to passengers to the areas of the body facing the impact. In addition to their normal function of protecting the occupants in a collision, the front and rear outer seat belts also hold the passengers in the event of a side collision; this is how these airbags provide maximum protection.



Head-protection airbags*



Fig. 21 Location and deployment area of the head-protection airbag.

There is a head airbag on each side of the interior above the doors **» Fig. 21**. Airbags are identified by the word "AIRBAG".

The area framed in red is covered by the head-protection airbag when it is deployed **w** Fig. 21 (deployment area). Therefore, objects should never be placed or mounted in this area **w** \triangle in Curtain airbags* on page 70.

In the event of a side collision the curtain airbag is triggered on the impact side of the vehicle.

The head-protection airbags reduce the risk of injury to passengers in the front and rear side seats facing the impact.



»» \land in Curtain airbags* on page 70

Child seats

Important information regarding the front passenger's airbag

AIRBAG	
	R57-0120

Fig. 22 Passenger's side sun visor: airbag sticker.



Fig. 23 On the rear frame of the passenger side door: airbag sticker.

A sticker with important information about the passenger airbag is located on the passenger's sun visor and/or on the passenger side door frame.



» ▲ in Important information regarding the front passenger's airbag on page 72

»» page 72

Ways to secure a child seat




Fig. 24 On the rear seats: Possible installations for the child seat.

Figure **>>>** Fig. 24 (A) shows the basic child restraint system mounting using lower retaining rings and the upper retaining strap. Figure **>>>** Fig. 24 (B) shows the child restraint system mounting using the vehicle seat belt.

You can secure a child seat to the rear seat or front passenger seat in the following ways:

- Child seats in groups **0 to 3** can be secured with a seat belt.
- Child seats for groups **0**, **0+** and **1** can be fastened without seatbelts, using the "ISO-FIX" system, using the "ISOFIX" **>>>** page **18** securing rings.
- During installation of some models of group I, II and III child seats in the rear seat, difficulty may arise in mounting given that the seat comes into contact with the head re-

straint. In this case, adjust the height of the head restraint or remove it from the seat following the instructions in the corresponding chapter **>> page 128**. Once you remove the child seat, replace the head restraint in its original position.

»

	Seating position			
Weight group	Front pas- senger seat ^{a)}	Rear side seat	Rear central seat	
Group 0 to 10 kg	U*	U	U	
Group 0+ to 13 kg	U*	U	U	
Group I 9 to 18 kg	U*	U	U	
Group II 15 to 25 kg	U*	U	U	
Group III 22 to 36 kg	U*	U	U	

- U: Suitable for universal restraint systems for use in this weight group.
- *: Move the front passenger seat as far back as possible, as high as possible and always disable the airbag.

The systems include the child restraint system mounting with an upper retaining strap (Top Tether) and lower anchoring points on the seat.



 a) Compliance with current national legislation and the manufacturer's instructions is required when using or installing child seats.

"ISOFIX" and Top Tether child seat mounting system*

Child seats can be secured quickly, easily and safely on the rear outer seats with the "ISOFIX" and Top Tether* system.

Two "ISOFIX" retaining rings are fitted on each rear seat. In some vehicles, the rings are secured to the seat frame and, in others, they are secured to the rear floor. The "ISO- FIX" rings are located between the rear seat backrest and the seat cushioning. The Top Tether* rings are located at the rear of the backrests of the rear seats (behind the seat backrest or in the boot). To understand the compatibility of the "ISO-FIX" systems in the vehicle, consult the table below.

The body weight permitted and information regarding sizes **A** to **F** is indicated on the label on child seats with "**universal**" or "**semiuniversal**" certification.

				Vehicle Isofix positions
Weight group	Size class Electrical equipment		Mounting direction	Rear side seats
Dahu anniar	F	ISO/L1	Backward-facing	Х
Baby carrier	G	ISO/L2	Backward-facing	Х
Group 0 to 10 kg	E	ISO/R1	Backward-facing	IU
	E	ISO/R1	Backward-facing	IU
Group 0+ to 13 kg	D	ISO/R2	Backward-facing	IU
	C	ISO/R3	Backward-facing	IU
	D	ISO/R2	Backward-facing	IU
	C	ISO/R3	Backward-facing	IU
Group I 9 to 18 kg	В	ISO/F2	Forward-facing	IU
	B1	ISO/F2X	Forward-facing	IU
	A	ISO/F3	Forward-facing	IU
Group II 15 to 25 kg			Forward-facing	
Group III 22 to 36 kg			Forward-facing	

19

- IU: Suitable for ISOFIX universal child restraint systems approved for use in this weight group.
- X: ISOFIX position not suitable for ISOFIX child restraint systems for this weight group or size class.

» 🗥 in Safety instructions on page 73

Top Tether* retainer straps

Mount the child seat with the "ISOFIX systems"




Fig. 25 ISOFIX securing rings.

When removing or fitting the child seat, please be sure to follow the manufacturer's instructions.

- Press the child seat onto the "ISOFIX" retaining rings until the child seat can be heard to engage securely. If the child seat is fitted with any other anti-rotation system, follow the manufacturer instructions carefully.
- Pull on both sides of the child seat to ensure that it is secure.

Child seats with the "ISOFIX" and Top Tether* attachment system are available from Technical Services.



Fig. 26 Position of the Top Tether rings on the back of the rear seat.

Child seats with the Top Tether system come with a strap for securing the seat to the vehicle anchor point, located at the back of the rear seat backrest and provide greater restraint.

The objective of this strap is to reduce the forward movement of the child seat in a crash, to reduce the risk of injuries to the head from hitting the inside of the vehicle.

Using the Top Tether in rear-facing mounted seats

Currently, there are very few rear-facing child safety seats that have Top Tether. Please carefully read and follow the seat manufacturer instructions to learn the proper way to install the Top Tether strap.

Securing the Top Tether* of the child seat to the anchorage point



Fig. 27 Retainer strap: correct adjustment and fitting.

Securing to the anchorage point located on the rear of the backrest

- Follow the manufacturer's instructions to deploy the child seat Top Tether retainer strap.
- Guide the strap under the rear seat head restraint **» Fig. 27** (lift the head restraint where necessary).
- Slide the strap and secure it properly with the anchorage of the backrest.
- Firmly tighten the Top Tether belt following the manufacturer's instructions.

Releasing the retaining strap

• Loosen the strap following the manufacturer's instructions.

 Push the lock and release it from the anchoring support.

» A in Safety instructions on page 73

Starting the vehicle

Ignition lock




Fig. 28 Ignition key positions.

Switch ignition on: Place the key in the ignition and start the engine.

Locking and unlocking the steering wheel

· Engaging the steering wheel lock: Remove the key from the ignition and turn the wheel until it locks. In vehicles with an automatic gearbox, the gear lever must be in the **P** position in order to remove the key. If necessary,

press the locking key on the selector lever and release it again.

• Unlocking the steering wheel: Put the key into the ignition and turn it at the same time as the steering wheel in the direction indicated by the arrow. If it is not possible to turn the steering wheel, it may be because it is locked.

Turning on/switching off the ignition, glow plugs reheating

- Switch ignition on: Turn the key to the (2) position.
- Switch ignition off. Turn the key to the 1 position.
- Diesel vehicles or: The glow plugs reheat when the ignition is switched on

Starting the engine

- Manual gearbox: press the clutch pedal all the way down and move the gearbox lever into neutral.
- Automatic gearbox: Press the brake pedal and move the selector lever to the P position or into N.
- Turn the key to the (3) position. The key automatically returns to the (2) position. Do not press the accelerator.

Start-Stop System*

When you stop and release the clutch pedal, the Start-Stop system* turns off the engine. The ignition remains switched on.



» ▲ in Ignition key positions on page 147



>>> page 147

Lights and visibility

Headlight switch



 Turn the switch to the required position »» Fig. 29.

Sym- bol	Ignition switch- ed off	Ignition is switch- ed on	
0	Fog lights, dipped beam and side lights off.	Light off or daytime driving light on.	
AUTO	The "Coming home" and "Leaving home" guide lights may be switched on.	Automatic control of dipped beam and day- time running light.	
∋o o£	Side light on.		
≣D	Dipped beam head- light off	Dipped beam switch- ed on.	

D Front fog lights: move the switch to the first position, from positions AUTO, $D \in D$.

() **Frear fog light:** move the switch completely from positions **AUTO**, ≫ e or *∎***D**.

Switching off fog lights: Push the switch or turn it to the **1** position.




» ▲ in Switching lights on and off on page 117



»» page 117

Turn signal and main beam lever

The essentials



More the lever to the required position:

- (1) Right turn signal: Right-hand parking light (ignition switched off).
- (2) Left turn signal: Left-hand parking light (ignition switched off).
- 3 Main beam switched on: Control lamp ID lit up on the instrument panel.
- ④ Headlight flasher: lit up when the lever is pushed. Control lamp ID lit up.

Lever all the way down to switch it off.



»» ⚠ in Turn signal and main beam lever on page 119

»» page 119

Hazard warning lights



Fig. 31 Dash panel: switch for hazard warning lights.

Switched on, for example:

- When approaching a traffic jam
- In an emergency
- The vehicle has broken down
- When towing or being towed



»» ⚠ in Hazard warning lights ▲ on page 122

»» page 121

Interior lights

	B0:04/2
Fig. 32 Detail of headliner: f ing.	ront interior light-

Knob	Function	
0	Switches interior lights off.	
來	Switches interior lights on.	
Ę	Switches door contact control on (central po- sition). The interior lights come on automatically when the vehicle is unlocked, a door is opened or the key is removed from the igni- tion.	Fig rea
	The lights go off a few seconds after all the doors are closed, the vehicle is locked or the ignition is switched on.	Mo ①

Knob Function <u>2</u> Turning the reading light on and off » page 122 Windscreen wipers and window wiper blade 3 6 2 1



g. 33 Operating the windscreen wiper and ear wiper

ore the lever to the required position:

OFF Windscreen wiper off.

Mo	More the lever to the required position:		
1	1	Windscreen wipers interval wipe. Using the control w Fig. 33 (A) adjust the interval (vehicles without rain sensor), or the sensitivity of the rain sensor.	
2	LOW	Slow wipe.	
3	HIGH	Continuous wipe.	
4	1x	Short wipe. Brief press, short clean. Hold the lever down for more time to increase the wipe frequency.	
5	Ŵ	Automatic wipe. The windscreen washer function is activated by pushing the lever forwards, and simultaneously the wind- screen wipers start.	
6	\Box	Interval wipe for rear window. The wiper will wipe the window approximately every six seconds.	
7	Ê	The rear window wash function is activa- ted by pressing the lever, and the rear wip- er starts simultaneously.	
Z	<u>î</u>	» ▲ in Windscreen wipers on page 123	
L	9	»» page 123	



»» page 54

23

Easy Connect

CAR menu settings (Setup)



To select the settings menus, press the Easy Connect (CAR) button and the (Setup) function button.

The actual number of menus available and the name of the various options will depend on the vehicle's electronics and equipment.

- Switch the ignition on.
- If the Infotainment System is off, switch it on.



- Press the system's (MENU) button and then the system's (MR) **** Fig. 34** button or (MR) button to go to the **CAR** menu **** Fig. 35**.
- Press the function button Setup to open the menu Vehicle settings >>> Fig. 35.
- To select a function in the menu, press the desired button.

When you press the menu button, the last selected menu will always be displayed. When the function button check box is activated \mathbf{V} , the function is active.

Any changes made using the settings menus are automatically saved on closing the BACK menus.

Menu	Submenu	Possible setting	Description
ESC system	-	Activation of the Electronic Stability Programme (ESC)	»» page 152
Tyres	Tyre pressure monitoring	Tyre pressure storing (Calibration)	» page 213
	Winter tyres	Activation and deactivation of the speed warning. Setting the speed warning value	» page 214

Menu	Submenu	Possible setting	Description
Driver assistance	Fatigue detection	Activation/deactivation	»» page 171
Parking and manoeu- vring	ParkPilot	Automatically activate, front volume, front sound settings, rear volume, rear sound settings, adjust volume	»» page 173
	Vehicle interior lighting	Instrument and switch lighting, footrest lighting	»» page 122
Vehicle lights	Coming home/Leaving home func- tion	Start time for "Coming home" function, start time for "Leaving home" function	»» page 119
Windscreen wipers	Windscreen wipers	Automatic windscreen wipers, wipe when reversing	» page 23
Opening and closing	Radio-operated remote control	Convenience open function	»» page 116
Opening and closing	Central locking system	Unlocking doors, automatic locking/unlocking, audible confirmation	» page 106
Multifunction display	-	Current consumption, average consumption, volume to fill up, convenience consum- ers, ECOAdvice, travelling time, distance travelled, digital speed display, average speed, speeding warning, oil temperature, coolant temperature, restore data "from start", restore data "total calculation"	» page 25
Date and time	-	Time source, set the time, automatic summer time (DST) setting, select time zone, time format, set the date, date format	-
Measurement units	-	Distance, speed, temperature, volume, consumption	-
Service	-	Chassis number, date of next SEAT service inspection, date of next oil change service	» page 33
Factory settings	-	All settings can be reset: driver assistance, parking and manoeuvring, lights, rear view mirrors, opening and closing, multi-function display	-



»» 🛆 in CAR menu (Setup) on page 100

»» page 99

Driver information system

Introduction

With the ignition switched on, it is possible to read the different functions of the display by scrolling through the menus. In vehicles with multifunction steering wheel, the multifunction display can only be operated with the steering wheel buttons.

The number of menus displayed on the instrument panel will vary according to the vehicle electronics and equipment.

»

A specialised workshop will be able to programme or modify additional functions, according to the vehicle equipment. SEAT recommends visiting a SEAT Official Service.

Some menu options can only be read when the vehicle is at a standstill.

As long as a priority 1 warning is displayed, it will not be possible to read the menus. Some warning messages can be confirmed and made to disappear with the windscreen wiper lever button or the multifunction steering wheel button.

The information system also provides the following information and displays (depending on the vehicle's equipment):

Driving data >>> page 29

- Vehicle status
- MFD from departure
- MFD from refuelling
- MFD total calculation

Assist systems >>> table on page 27

Reverse (optional)

Navigation >>> Booklet Navigation system

Audio >>> Booklet Radio or >>> Booklet Navigation system

Telephone >>> Booklet Radio or >>> Booklet Navigation system

Vehicle »» table on page 27

▲ WARNING

Any distraction may lead to an accident, with the risk of injury.

The essentials

• Do not operate the instrument panel controls when driving.

Operating the instrument panel menus



Fig. 36 Windscreen wiper lever: control buttons.



Fig. 37 Right side of multifunction steering wheel: control buttons.

The driver information system is controlled with the multifunction steering wheel buttons **»> Fig. 37** or with the windscreen wiper lever **>> Fig. 36** (if the vehicle is not equipped with multifunction steering wheel).

Enabling the main menu

• Switch the ignition on.

• If a message or vehicle pictogram appears, press button **»** Fig. 36 ① on the windscreen wiper lever or button () on the multifunction steering wheel **»** Fig. 37.

If managed from the windscreen wiper lever: to display the main screen »» page 27 or to return to the main menu from another menu hold down the rocker button »» Fig. 36
(2).

• If managed from the multifunction steering wheel: the main menu list is not displayed. To go from point to point in the main menu,

press button ⊲⊡ or ⊡⊳ several times **≫ Fig. 37**.

Select a submenu

• Press the rocker switch **»** Fig. 36 (2) on the windscreen wiper lever up or down or turn the thumbwheel of the multifunction steering wheel **»** Fig. 37 until the desired option appears marked on the menu.

• The selected option is displayed between two horizontal lines. In addition, a triangle is displayed on the right: **4**

• To consult the submenu option, press button **»> Fig. 36 (1)** on the windscreen wiper lever or button **(a)** on the multifunction steering wheel **»> Fig. 37**.

Making changes according to the menu

 Make the desired changes with the rocker switch on the windscreen wiper lever or the thumbwheel of the multifunction steering wheel. To increase or decrease the values more quickly, turn the thumbwheel faster.

• Mark or confirm the selection with button **>>> Fig. 36 (1)** on the windscreen wiper lever or button (**w**) on the multifunction steering wheel **>>> Fig. 37**.

Menu

Menu	Function
Driving data	Information and possible configura- tions of the multifunction display (MFD) » page 29, » page 99.
Assist systems	Information and possible configura- tions of the driver assistance systems » page 99.
Navigation	Information instructions from the activated navigation system: when a route guidance is activated, the turning arrows and proximity bars are displayed. The appearance is similar to the Easy Connect system. If route guidance is not activated, the direction of travel (compass) and the name of the street along which you are driving are shown >> Booklet Navigation system.
Audio	Station display on the radio. Track name on the CD. Track name in Media mode » Book - let Radio or » Booklet Navigation sys- tem.
Telephone	Information and possible configura- tions of the mobile phone preinstalla- tion » Booklet Radio or » Booklet Nav- igation system.
Lap timer*	In a racing circuit, measurement and memorisation of lap times by the vehi- cle and comparison with previously measured best times w page 31.

Menu	Function
Vehicle status	Display of the current warning or infor- mation texts and other system compo- nents, depending on the equipment w page 99 .

Outside temperature display

When the outside temperature is below $+4^{\circ}C$ ($+39^{\circ}F$), the "ice crystal" symbol (warning of risk of freezing) is also displayed. At first, this symbol flashes and then it remains lit until the outside temperature rises above $+6^{\circ}C$ ($+43^{\circ}F$) » Δ in Indications on the display on page 96.

When the vehicle is at a standstill or when travelling at very low speeds, the temperature displayed may be higher than the true outside temperature as a result of the heat produced by the engine.

The temperatures measured range from -40° C to $+50^{\circ}$ C (-40°F to $+122^{\circ}$ F).

Gear-change indicator



Fig. 38 Instrument panel: gear-change indicator (manual gearbox).

A gear change will be recommended if the gear you are in is not the most economical choice. If no gear-change is recommended, it means that you are already in the most economical gear.

Vehicles with a manual gearbox

The following display symbols **>>> Fig. 38** mean:

- **Change to a higher gear**: the suggested gear appears to the **right** of the current gear when a **higher gear is recommended**.
- **Change to a lower gear**: the suggested gear appears to the **left** of the current gear when a **lower gear is recommended**.

The gear recommendation may occasionally skip a gear (2nd \blacktriangleright 4th).

Vehicles with an automatic gearbox*

The display is only visible in tiptronic mode **>>>** page 161.

The following display symbols mean:

- † Shifting up a gear
- | Shifting down a gear

() CAUTION

The gear-change indicator is intended to help save fuel, but it is not intended to recommend the right gear for all driving situations. In certain situations, only the driver can choose the correct gear (for instance when overtaking, driving up a steep gradient or towing a trailer).

i Note

The display disappears from the instrument panel when you press the clutch pedal.

Bonnet, rear lid and doors open




Fig. 39 A: bonnet open; B: rear lid open; C: front left door open; D: rear right door open (5-door vehicles only).

When the ignition is switched on or when driving, the bonnet, rear lid or doors that are open will be indicated on the instrument panel display, and, as applicable, this will be indicated audibly. The display may vary according to the type of instrument panel fitted.

3

Illustra- tion	Key to » Fig. 39
A	Do not continue driving! The bonnet is open or is not properly closed w page 198.
В	Do not continue driving! The rear lid is open or is not properly closed w page 9.
C, D	Do not continue driving! A vehicle door is open or is not properly closed w page 106.

Warning and information messages

The system runs a check on certain components and functions when the ignition is switched on and while the vehicle is moving. Faults in the operation are displayed on the screen using red and yellow symbols and messages on the instrument panel display (**w** 10% page 98, **w** page 35) and, in some cases, with audible warnings. The display may vary according to the type of instrument panel fitted.

Priority 1 warning (red symbols)

Symbol flashing or lit; partly combined with audible warnings.

Stop the vehicle! It is dangerous >>> 🛆 in Warning symbols on page 99!

Check the function that is faulty and repair it. If necessary, request assistance from specialised personnel.

Priority 2 warning (yellow symbols)

Symbol flashing or lit; partly combined with audible warnings.

A faulty function, or fluids which are below the correct levels may cause damage to the vehicle! **>>> ①** in Warning symbols on page 99

Check the faulty function as soon as possible. If necessary, request assistance from specialised personnel.

Informative text

Information relating to different vehicle processes.

Assist systems submenu

Assist systems menu	Function
Fatigue de- tection*	Switching the fatigue detection on or off (pause recommendation) » page 171.

Journey data

Memory

The MFD (multifunction display) shows different values for the journey and the consumption.

Changing between display modes on the MFD

• In vehicles without multifunction steering wheel: Press the rocker switch (TMP) on the windscreen wiper lever **>>> Fig. 36**.

• Vehicles with a multifunction steering wheel: turn the thumbwheel **>>> Fig. 37**.

Multifunction display memory

The multifunction display is equipped with three memories that work automatically: MFD from departure, MFD from refuelling and MFD total calculation. On the screen display, you can read which memory is currently displayed.

Toggle between memories with the ignition on and the memory displayed

Press the (MK/RESET) button on the windscreen wiper lever or the (MK) button of the multifunction steering wheel.

the same style of driving is main-

tained. This is calculated using

the current fuel consumption.

Menu	Function	Personalising t	
MFD from de- parture	Display and storage of the values for the journey and the consumption from when the ignition is switched on to when it is switched off. If the journey is continued in less than 2 hours after the ignition is switched off, the new data is added to the data already stored in the memory. The memory will automati- cally be deleted if the journey is in- terrupted for more than 2 hours.	which of the po be shown on th with the button Setup >>> po Data summa	ıry
	Display and storage of the values for	Menu	Function
MFD from re- fuelling	the journey and the consumption. By refuelling, the memory will be erased automatically.	Current fuel consumption	The current fuel consumption di play operates throughout the journey, in litres/100 km; and with the engine running and the
	The memory records the values for a		vehicle stopped, in litres/hour.
MFD total calculation	specific number of partial trips, up to a total of 19 hours and 59 minutes, or 1999.9 km or 9999 km, depend- ing on the model of instrument pan- el. On reaching either of these lim- its ^a), the memory is automatically erased and starts to count from 0 again.	Average fuel consumption	After turning on the ignition, ave age fuel consumption in li- tres/100 km will be displayed at ter travelling about 100 metres. Otherwise horizontal lines are displayed. The value shown is up dated approximately every 5 sec onds. ACT®*: Depending on the equip ment, number of active cylinder.
It varies accordin	g to the instrument panel version.		ment, number of active cylinder
	nory manually nemory that you wish to erase.	Operating	Approximate distance in km tha can still be travelled with the fue remaining in the tank, assuming

range

• Hold the (OK/RESET) button of the multifunction steering wheel or the (**o**K) button of the multifunction wheel pressed down for about 2 seconds.

Menu	Function
Travelling time	This indicates the hours (h) and minutes (min) since the ignition was switched on.
Distance cov- ered	Distance covered in km (m) after switching on the ignition.
Average speed	The average speed will be shown after a distance of about 100 me- tres has been travelled. Otherwise horizontal lines are displayed. The value shown is updated ap- proximately every 5 seconds.
Digital dis- play of speed	Current speed displayed in digital format.
Speed warning	If the stored speed is exceeded (between 30 - 250 km/h, or 19 -
Speed warning at mph	155 mph), an audible warning is given together with a visual warn- ing.
Oil tempera- ture	Updated engine oil temperature digital display
Coolant tem- perature gauge	Digital display of the current tem- perature of the liquid coolant.
	Travelling time Distance cov- ered Average speed Digital dis- play of speed Speed warning at km/hor Speed warning at mph Oil tempera- ture Coolant tem-

Storing a speed with the speed warning

 Select the display Speed warning at --- km/h (--- mph)

• Press the button (OK/RESET) on the windscreen wiper lever or the button **(N**) on the multifunction steering wheel to store the current speed and activate the warning.

• To switch system on: adjust to the desired speed within 5 seconds using the rocker switch The on the windscreen wiper lever or by turning the thumbwheel on the multifunction steering wheel. Next, press the button (MINESSET) or (MR) again or wait several seconds. The speed is stored and the warning activated.

• To switch system off: press the button (M/NESET) or (M). The stored speed is deleted.

Engine oil temperature display

The engine reaches its operating temperature when in normal driving conditions, the oil temperature is between **80°C** (178°F) and **120°C** (248°F). If the engine is required to work hard and the outside temperature is high, the engine oil temperature can increase. This does not present any problem as long as the warning lamps $\underbrace{\clubsuit}$ **30** table on page 36 or $\underbrace{\clubsuit}$ **30** table on page 36 do not appear on the display.

Vehicles without multifunction steering wheel

 Press the rocker switch **>>> Fig. 36** (2) until the main menu appears. Enter into **Driving data**. With the button (2) move to the oil temperature gauge.

Vehicles with multifunction steering wheel

• Enter the submenu **Driving data** and turn the thumbwheel until the oil temperature display appears.

Additional electrical appliances

 Operation with the windscreen wiper lever*: Press the rocker switch »» Fig. 36 (2) until the main menu appears. Enter into the section Driving data. With the rocker switch, move to the display Convenience consumers.

• Operation with the multi-function steering wheel*: Move with the buttons ① or ② to Driving data and enter with OK. Turn the thumbwheel to the right until the Convenience consumers display appears.

In addition, a scale will inform you of the current sum of all the additional appliances.

Saving tips

Tips on how to save fuel will be displayed in conditions that increase fuel consumption. Follow them to reduce consumption. The indications appear automatically only with the efficiency programme. After a time, the tips will disappear automatically. If you wish to hide a saving tip immediately after it appears, press any button on the windscreen wiper lever*/multifunction steering wheel*.

i Note

- If you hide a saving tip, it will reappear after you switch the ignition on again.
- The saving tips do not appear in all situations, but rather with a large separation of time.

Timer*

You can access the timer via the selection menu **>>> page 27**.

It allows you to manually time lap times on a racing circuit, memorise them and compare them to the vehicle's previous best times.

The following menus can be displayed:

- Stop
- Lap
- Pause
- Partial time
- Statistics

Change from one menu to another

• Vehicles without multifunction steering wheel: press the rocker switch (TRP) in the windscreen wiper lever.

• Vehicles with multifunction steering wheel: press \triangle or \bigtriangledown .

Menu "Stop"	
Start	The timer starts. If there are existing laps and they are included in the statistics, it will begin with the number of laps in question. It is only possible to begin with a new first lap if the statistics have been re- set first in the Statistics menu.
Since start	The timer begins when the vehicle sets off. If the vehicle is already moving, the timer begins once the vehicle has stopped.
Statistics	The Statistics menu is displayed on the screen.
Menu "Lap"	
New lap	The timer of the current lap stops and a new lap starts immediately. The time for the lap you have just completed is included in the statistics.
Partial time	For about 5 seconds a partial time is displayed. The timer continues in par- allel.

Menu "Lap"

Stop

	The current lap timer will be interrup-
5	ted. The lap does not end. The Pause
	menu is displayed.

Menu "Pause"	
Continue	The interrupted timer continues.
New lap	A new timer starts. The halted lap ends and is included in the statistics.
Interr. lap	The timer of the current lap ends and is cancelled. It is not included in the statistics.
End	The current timer ends. The lap is in- cluded in the statistics.

Menu "Partial time"		
Partial time	For about 5 seconds a partial time is displayed. The timer continues in par- allel.	
New lap	The timer of the current lap stops and a new lap starts immediately. The time for the lap you have just completed is included in the statistics.	
Stop	The current lap timer will be interrup- ted. The lap does not end. The Pause menu is displayed.	

Menu "Long-term Statistics"

	View of the latest lap times: - total time - best lap time - worst lap time - average lap duration A maximum of 10 laps is possible, and a total duration of 99 hours, 59 mi- nutes and 59 seconds. If one of the 2 limits is reached, you will have to reset the statistics in order to begin a new timer.
Back	This returns to the previous menu.
Resetting to zero	All the memorised statistical data are reset.

△ WARNING

Do your best to avoid handling the timer while driving.

- Only set the timer or consult statistics when the vehicle is stationary.
- · While driving, do not handle the timer in complicated driving situations.

Speed warning device

The speed warning device warns the driver when they have exceeded the pre-set speed limit by 3 km/h (2 mph). An audible warning signal sounds, and the warning lamp Θ and the driver message Speed limit excee**ded!** will be displayed simultaneously on the

instrument panel. The warning lamp Θ switches off when reducing speed below the stored maximum limit.

Speed warning programming is recommended if you wish to be reminded of a maximum speed, such as when travelling in a country with different speed limits or for a maximum speed for winter tyres.

Setting speed limit warning

You can use the radio or the Easy Connect* to set, alter or cancel the speed limit warning.

Vehicles with radio: press the button (SETUP)
 control button \$ Driver Assistant >
 Speed warning.

• Vehicles with Easy Connect: press the button Systems or else Vehicle systems > Driver assistant > Speed warning.

The warning limit can be set from 30 to 240 km/h (20 to 149 mph). The adjustment is made at 10 km/h (5 mph) intervals.

i Note

 Please bear in mind that, even with the speed warning function, it is still important to keep an eye on the vehicle speed with the speedometer and to observe the legal speed limits.

• The speed limit warning function in the version for some countries warns you at a speed of 120 km/h (75 mph). This is a factory-set speed limit.

Service intervals

The service interval indication appears on the instrument panel display $\gg \square$ Fig. 113 (3).

SEAT distinguishes between services with engine oil change (e.g. Oil change service) and services without engine oil change (e.g. Inspection).

In vehicles with **Services established by time or mileage**, the service intervals are already pre-defined.

In vehicles with LongLife Service, the intervals are determined individually. Thanks to technological progress, maintenance work has been greatly reduced. Because of the technology used by SEAT, with this service you only need to change the oil when the vehicle so requires. To calculate this change (max. 2 years), the vehicle's conditions of use and individual driving styles are considered. The advance warning first appears 20 days before the date established for the corresponding service. The kilometres (miles) remaining until the next service are always rounded up to the nearest 100 km (miles) and the time is given in complete days. The current service message cannot be viewed

until 500 km after the last service. Prior to this, only lines are visible on the display.

Inspection reminder

When the Service date is approaching, when the ignition is switched on a **Service remind**er is displayed.

Vehicles without text messages: a spanner — will be displayed on the instrument panel plus an indication in km.

The kilometres indicated are the maximum number of kilometres that can be travelled until the next service. After a few seconds, the display mode changes. A clock symbol appears and the number of days until the next service is due.

Vehicles with text messages: Service in --- km or --- days will be shown on the instrument panel display.

Service due

When **the service date is due**, an audible warning is given when the ignition is switched on and the spanner displayed on the screen flashes for a few seconds \checkmark .

Vehicles with text messages: **Service now** will be shown on the instrument panel display.

Reading a service notification

With the ignition switched on, the engine off and the vehicle at a standstill, the current **service notification** can be read:

Press and hold the button (4) for more than 5 seconds to consult the service message.

When the **service date has passed**, a minus sign is displayed in front of the number of kilometres or days.

Vehicles with text messages: the following message is displayed: Service --- km (miles) or --- days ago.

The time can also be set via the **(MR)** key and <u>(Setup)</u> function button in the Easy Connect system **>>> (CS) page 99**.

Resetting service interval display

If the service was not carried out by a SEAT dealership, the display can be reset as follows:

- Switch off the ignition, press and hold button **»** (28) Fig. 113 (4).
- Switch ignition back on.
- Release the (4) >>> (2) Fig. 113 button and press it again for the next 20 seconds.

i Note

• The service message disappears after a few seconds, when the engine is started or when

 $(\mbox{OK/RESET})$ is pressed on the windscreen wiper lever, or (\mbox{OK}) on the multifunction steering wheel.

• In vehicles with the LongLife system in which the battery has been disconnected for a long period of time, it is not possible to calculate the date of the next service. Therefore the service interval display may not be correct. In this case, bear in mind the maximum service intervals permitted in the »» Booklet Maintenance Programme.

Cruise control

Operating the cruise control system (CCS)*



Fig. 40 Turn signal and main beam headlight lever: switches and controls for operating the CCS

• Switching on the CCS: Move switch **>>> Fig. 40 (1)** to **ON**. The system is on. If no speed has been programmed, the system will not control it.

Activating the CCS: Press button **»** Fig. 40
(2) in the SET/- area. The current speed is memorised and controlled.

- Temporarily switching off the CCS: Move switch **>>>** Fig. 40 (1) to **CANCEL** or push the brake. The cruise control system is switched off temporarily.
- Reactivating the CCS: Press button **>>> Fig. 40 (2)** in **RES/+**. The memorised speed is saved and controlled again.
- Increasing stored speed during CCS regulation: press button (2) in **RES/+**. The vehicle accelerates until the new stored speed.
- Reducing stored speed during CCS regulation: press button (2) in SET/- to lower the speed by 1 km/h (1 mph). Speed is reduced until reaching the new stored speed.

• Switching off the CCS: Move switch **>>> Fig. 40 (1)** to **OFF**. The system is disconnected and the memorised speed is deleted.



»» 🛆 in Operation on page 181



»» page 180

Warning lamps

On the instrument panel





Fig. 41 Instrument panel, on dash panel

Red warning lamps



@ !	Lit up or flashing: Do not continue driving! Fault in the steering.	»» page 145
4	Driver or passenger has not fas- tened seat belt.	» page 62
	Use the foot brake!	

Yellow warning lamps



Central warning lamp: additional information on the instrument panel display

35

$\langle O \rangle$	Front brake pads worn.	
骨	<i>it lights up:</i> Fault in the ESC, or disconnection caused by the system.	
	flashes: ESC or ASR activated.	»» page 152
C	ASR manually deactivated. <i>Or else</i> : ESC in Sport mode.	
(ABS)	ABS faulty or does not work.	
劧	Front fog lights switched on.	» page 21
()‡	Rear fog light switched on.	» page 21
Ċ	<i>lights up or flashes:</i> fault in the emission control system.	» page 168
200	<i>it lights up:</i> pre-heating of diesel engine.	» page
00	<i>flashes:</i> fault in the diesel engine management.	168
EPC	fault in the petrol engine management.	
® !	<i>lights up or flashes:</i> fault in the steering system.	»» page 145
ŝ	Tyre pressure too low, or fault in the tyre pressure monitoring system.	₩ page 213
₿	Fuel tank almost empty.	»» page 98
.	Fault in airbag system and seat belt tensioners.	» page 66

36

Other warning lamps

\$¢	Left or right turn signal.	»» page 22	
	Hazard warning lights on.	» page 121	
¢¹¢	Trailer turn signals	»» page 183	
((S))	it lights up: Press the foot brake! <i>flashes:</i> the selector lever locking button has not engaged.		
*	<i>it lights up:</i> cruise control activated or speed limiter switched on and active.	» page	
. ,	<i>flashes:</i> the speed set by the speed limiter has been exceeded.	34	
٤D	Main beam on or flasher on.	»» page 22	

On the instrument panel display



Fig. 42 On the instrument panel display: door open.

윻	Do not continue driving! With the corresponding indica- tion: door(s), rear lid or bonnet open or not properly closed.	» page 106 » page 9 » page 198	
<u>_</u> E	Ignition: Do not carry on driv- ing! Engine coolant level too low, coolant temperature too high	»» page 204	
	<i>Flashing:</i> Fault in the engine coolant system.	204	
ist.	Do not continue driving! Engine oil pressure too low.	»» page 201	

		The essentials
page	(A)	Start-Stop system activated.
57	R	Start-Stop system unavailable

ECO

)	Start-Stop system activated.	»» page
ý	Start-Stop system unavailable.	170
0	Low consumption driving status	»» page 27

On the instrument panel

	PASSENGER AIR BAG OFF
Fig. 43 Wa	Irning lamp for disabling the front

Front passenger front airbag is »» page OFF 💥 disabled (PASSENGER AIR BAG

66 OFF %).

»» 🛆 in Warning symbols on page 99

» page 98

Gearbox lever

Manual gearbox




Fig. 44 Gear shift pattern of a 5 or 6-speed manual gearbox

The position of the gears is indicated on the gearbox lever >>> Fig. 44.

- Press the clutch pedal and keep your foot right down.
- · Move the gearbox lever to the required position.
- Release the clutch.

Selecting reverse gear

- Press the clutch pedal and keep your foot right down.
- With the gearbox lever in neutral, push it upwards, move it to the left as far as it will go and then forwards to select reverse >>> Fig. 44 R.

<u>* *</u>	Fault in the battery.	»» page 207
\ <u>B</u> /	Driving light totally or partially faulty.	»» page 83
-ሺ-	Fault in the cornering light sys- tem.	»» page 117
- 33 >	Diesel particulate filter blocked	»» page 167
Ô	Level of windscreen washer fluid too low.	
۲ <u>۲</u> ۲;	Flashing: Fault in the oil level de- tection. Control manually.	
	201 Ignition: Insufficient engine oil.	
٥	Fault in the gearbox.	
SAFE	Immobiliser active.	
,	Service interval display	
*	Mobile telephone is connected wia Bluetooth to the original telephone device. where the original telephone device.	
Î	Mobile telephone battery charge lett meter. Available only for devices gat pre-installed in factory. sys	
Freezing warning. The outside temperature is lower than +4°C (+39°F).		»» page 27

»

• Release the clutch.



» ▲ in Driving with manual gearbox on page 158

» page 158

Automatic gearbox*




Fig. 45 Automatic gearbox: selector lever po sitions.

- P Parking lock
- R Reverse gear

- N Neutral (idling)
- D Drive (forward)
- S Sport programme: drive (forward)
- +/- Tiptronic mode: pull the lever forwards
 (+) to go up a gear or backwards (-) to go down a gear.

The essentials

P	»» page 158
S0S	»» page 38

Manual release of selector lever



Fig. 46 Manual release of the selector lever.


If there is a fault in the power system to the electronic selector lever lock system (flat battery, blown fuse) or the system itself is faulty, the selector lever cannot be moved from position \mathbf{P} in the normal manner, which prevents the vehicle from being moved. The selector lever must be unlocked using the manual release.

- Apply the handbrake.
- Pull gently on both sides at the front of the selector lever cover.
- Also loosen the cover at the rear.
- Press the yellow plastic part with your finger in the direction indicated by the arrow **W Fig. 46**.

• Press the interlock button on the selector lever knob at the same time and move the selector lever to position **N** (if the selector lever is moved back to position **P**, it will lock again).

Air conditioning

How does Climatronic* work?



Buttons/controls

1 Interior temperature setting

Display

- 2 Selected interior temperature
- ③ Degrees Centigrade or Fahrenheit
- 4 Automatic air conditioning mode
- 5 Defrost or demist windscreen
- 6 Air flow direction
- 7 Air recirculation
- 8 Air conditioning on/off
- 9 Selected blower speed

Buttons/controls

- 10 Set blower speed
- (1) Interior temperature sensors
- 12 Defrost or demist windscreen
- 13 Automatic mode
- (14) Air distribution to windows
- (15) Air distribution to upper body
- 16 Air distribution to footwells
- 17 Air recirculation
- (18) Air conditioning on/off

Fig. 47 In the centre console: Climatronic controls



»» 🛆 in General notes on page 137

39

»» page 143

How does the manual air conditioning work*?




Fig. 48 In the centre console: Manual air conditioning controls

- (A) Temperature
- (B) Blower
- Air distribution

— Air distribution towards the windscreen in order to demist or defrost.

- 党 Air distribution to upper body.
- 🕺 Air distribution to footwell

– Air distribution to the windscreen and the footwell.

(D) Air recirculation

(E) A/C: Switching the cooling system on



» A in General notes on page 137

»» page 141

How does the heating and the fresh air system work?




Fig. 49 In the centre console: heating system and fresh air controls.

(A) Temperature

(B) Blower

C Air distribution

W - Air distribution towards the windscreen in order to demist or defrost.

- 党 Air distribution to upper body.
- 🚽 Air distribution to footwell

🖏 – Air distribution to the windscreen and the footwell.

(D) Air recirculation



»» 🛆 in General notes on page 137



>>> page 139

Fluid Level control

Filling capacities

Capacities		
Fuel tank	45 litres. 7 litre re- serve.	
Windscreen washer fluid con- tainer in vehicles without head- light washer	3 litres	
Windscreen washer fluid con- tainer in vehicles with headlight washer	4.5 litres	

Fuel




Fig. 50 Fuel tank flap with tank cap attached.

The tank flap is released manually and is located at the rear of the vehicle on the right. The tank holds approximately 45 litres.

Opening the fuel tank cap

- Lift the lid.
- Hold the cap firmly with one hand, then insert the key into the lock and rotate 180° to the left.
- Unscrew the cap, turning it anticlockwise.

Closing the fuel tank cap

- Screw the tank cap to the right until it "clicks".
- Turn the key in the lock, without releasing the cap, clockwise through 180°.

• Remove the key and close the flap until it clicks into place. The tank cap is secured with an anti-loss attachment.



Oil




Fig. 51 Engine oil dipstick.



Fig. 52 In the engine compartment: Engine oil filler cap

The level is measured using the dipstick located in the engine compartment **>>>** 129 page 201.

The oil should leave a mark between zones (A) and (C). It should never exceed zone (A).

• Zone (A): Do not add oil.

• Zone (B): You can add oil but keep the level in that zone.

• Zone C: Add oil up to zone B.

Topping up engine oil

- Unscrew cap from oil filler opening.
- Add oil slowly.

• At the same time, check the level to ensure you do not add too much.

• When the oil level reaches at least zone (B), unscrew the engine oil filler cap carefully.

»

Oil properties

Engine type	Specification
Petrol without flexible serv- ice interval	VW 502 00/VW 504 00
Petrol with flexible service interval (LongLife)	VW 504 00
Diesel. Engines without Par- ticulate filter (DPF)	VW 505 01/VW 506 01/VW 507 00
Diesel. Particulate Filter En- gines (DPF). With or without flexible service interval (with and without LongLife) ^{a)}	VW 507 00

 $^{\mathrm{a})}\,$ Only use recommended oils, otherwise you may damage the engine.

Engine oil additives

No type of additive should be mixed with the engine oil. The deterioration caused by these additives is not covered by the warranty.



» ▲ in Changing engine oil on page 204



» page 201

Coolant



Fig. 53 Engine compartment: coolant expansion tank cap.

The coolant tank is located in the engine compartment **>>>** [2] page 201.

When the engine is cold, replace the coolant when the level is below **MIN**.

Coolant specifications

The engine cooling system is supplied from the factory with a specially treated mixture of water and at least 40 % of the additive **G13** (TL-VW 774)), purple. This mixture gives the necessary frost protection down to -25° C (-13° F) and protects the light alloy parts of the engine cooling system against corrosion. It also prevents scaling and considerably raises the boiling point of the coolant.

To protect the cooling system, the percentage of additive must always be at least 40 %,

even in warm climates where anti-freeze protection is not required.

If for weather reasons further protection is necessary, the proportion of additive may be increased, but only up to 60 %; otherwise antifreeze protection will diminish and this will worsen cooling.

When the coolant is topped up, use a mixture of distilled water and at least 40 % of the G13 or G12 plus-plus (TL-VW 774 G) additive (both are purple) to obtain an optimum anticorrosion protection **>>> ①** in Topping up coolant on page 206. The mixture of G13 with G12 plus (TL-VW 774 F), G12 (red) or G11 (green-blue) engine coolants will significantly reduce anti-corrosion protection and should therefore be avoided **>>> ①** in Topping up coolant on page 206.



» ▲ in Topping up coolant on page 205

>>> page 204

Brake fluid



Fig. 54 Engine compartment: brake fluid reservoir cap

The brake fluid reservoir is located in the engine compartment **» page 201**.

The level should be between the MIN and MAX marks. If it is below MIN, please visit a Technical Service.



 \gg \triangle in Changing the brake fluid on page 207

>>> page 206

Windscreen washer




Fig. 55 In the engine compartment: windscreen washer reservoir top.

The windscreen washer reservoir is located in the engine compartment $\gg \square$ page 201.

To top up, mix water with a product recommended by SEAT.

In cold temperatures, add anti-freeze for windows.



»» 🛆 in Topping up the windscreen washer reservoir water on page 207

»» page 207

Battery

The battery is located in the engine compartment »» 🕰 page 201. It does not require

maintenance. It is checked as part of the Inspection Service.



» \Lambda in Symbols and warnings on handling the battery on page 208



»» page 207

Emergencies

Fuses

Fuse location



Fig. 56 On the driver-side dash panel: fuse box cover




Fig. 57 In the engine compartment: fuse box cover

Opening and closing the fuse box situated below the dash panel

- · Opening: remove the fuse box cover >>> Fig. 56.
- Closing: click the cover back into place.

To open the engine compartment fuse box

- Raise the bonnet.
- Press the locking tabs to release the fuse box cover »» Fig. 57
- Then lift the cover out.
- To **fit** the cover, place it on the fuse box. Push the locking tabs down until they click audibly into place.

Identifying fuses situated below the dash panel by colours

Colour	Amp rating
Black	1
Purple	3
Light brown	5
Brown	7.5
Red	10
Blue	15
Yellow	20
White or transparent	25


Colour	Amp rating
Green	30
Orange	40



»» 🛆 in Introduction on page 80

» page 80

Replacing a blown fuse



Preparation

• Switch off the ignition, lights and all electrical equipment.

• Open the corresponding fuse box »» 🕰 page 81.

Identifying a blown fuse

A fuse is blown if its metal strip is ruptured **>>> Fig. 58**.

• Point a lamp at the fuse to see if it has blown.

To replace a fuse

• Remove the fuse.

• Replace the blown fuse by one with an *identical* amperage rating (same colour and markings) and *identical* size.

• Replace the cover again or close the fuse box lid.

Bulbs

Bulbs (12 V)

Light source used for each function

Double headlights	Туре
Dipped beam headlights	H7 Long Life
Main beam headlights	H7
Side lights	W5W Long Life
Turn signal	PY 21W

Double headlights	Туре
DRL (day light)	LED ^{a)}

 $^{\rm a)}\,$ In case of a LED failure, go to an authorised workshop to have it replaced.

Single headlight	Туре
Dipped/main beam headlights	H4 Long Life
Side lights	W5W Long Life
Turn signal	PY 21W
DRL (day light)	P21W SLL

Xenon/adaptive head- lights*	Туре
Dipped/main beam headlights	D1S ^{a)}
Side lights	LED ^{b)}
Turn signal	PY 21W
DRL (day light)	LED ^{b)}

^{a)} This light should be changed by an Authorised Service.

 $^{\mathrm{b})}\,$ In case of a LED failure, go to an authorised workshop to have it replaced.

w page 83

Action in the event of a puncture

What to do first

• Park the vehicle on a horizontal surface and in a safe place as far away from traffic as possible.

- Apply the handbrake.
- Switch on the hazard warning lights.
- Manual gearbox: select the 1st gear.
- *Automatic gearbox:* Move the selector lever to position **P**.
- If you are towing a trailer, unhitch it from your vehicle.
- Have the vehicle tool kit* **>>> page 47** and the spare wheel **>>> C** page 75 ready.

• Observe the applicable legislation for each country (reflective vest, warning triangles, etc.).

• All occupants should leave the vehicle and wait in a safe place (for instance behind the roadside crash barrier).

• Always observe the above steps and protect yourself and other road users.

• If you change the wheel on a slope, block the wheel on the opposite side of the car with a stone or similar to prevent the vehicle from moving.

Repairing a tyre with the anti-puncture kit




Fig. 59 Standard representation: contents of the anti-puncture kit.

The anti-puncture kit is located under the floor panel in the luggage compartment.

Sealing the tyre

- Unscrew the tyre valve cap and insert. Use the **» Fig. 59 (1)** tool to remove the insert. Place it on a clean surface.
- Shake the tyre sealant bottle vigorously **>>> Fig. 59** (10).
- Screw the inflator tube **>>> Fig. 59** (3) into the sealant bottle. The bottle's seal will break automatically.

- Remove the lid from the filling tube **W** Fig. 59 (3) and screw the open end of the tube into the tyre valve.
- With the tyre sealant bottle upside down, fill the tyre with the contents of the sealant bottle.
- Remove the bottle from the valve.
- Place the insert back into the tyre valve using the tool **» Fig. 59** (1).

Inflating the tyre

- Screw the compressor tyre inflator tube **>>> Fig. 59 (5)** into the tyre valve.
- Check that the air bleed screw is closed **>>> Fig. 59** (7).
- Start the engine and leave it running.
- Insert the connector **» Fig. 59** (9) into the vehicle's 12-volt socket **»** (28) page 133.
- Turn the air compressor on with the ON/OFF switch **»** Fig. 59 (8).
- Keep the air compressor running until it reaches 2.0 to 2.5 bar (29-36 psi/200-250 kPa). **A maximum of 8 minutes**.
- Disconnect the air compressor.
- If it does not reach the pressure indicated, unscrew the tyre inflator tube from the valve.
- Move the vehicle 10m so that the sealant is distributed throughout the tyre.

- Screw the compressor tyre inflator into the valve.
- Repeat the inflation process.
- If the indicated pressure still cannot be reached, the tyre is too badly damaged. Stop and request assistance from an authorised technician.
- Disconnect the air compressor. Unscrew the tyre inflator tube from the tyre valve.
- When the tyre pressure is between 2.5 and 2.0 bars, continue driving without exceeding 80 km/h (50 mph).
- Check the pressure again after 10 minutes **>>> page 78.**



» ▲ in TMS (Tyre Mobility System)* on page 76



»» page 76

Changing a wheel

Vehicle tool kit



Fig. 60 Underneath the floor panel of the luggage compartment: vehicle tool kit.

- 1 An adapter for the anti-theft wheel bolts*
- 2 Towline anchorage
- 3 Box spanner for wheel bolts*
- 4 Jack*
- (5) Wire hook for pulling off the wheel covers*/wheel bolt cap clip.



» 🛆 in Vehicle tools on page 75



Wheel covers*



Fig. 61 Remove the wheel cover.

The wheel covers must be removed for access to the wheel bolts.

Removing

- Remove the wheel cover using the wire hook **»** Fig. 61.
- Hook this into one of the cut-outs of the wheel cover.

Fitting

- Fit the wheel cover onto the wheel rim by pressing it firmly.
- Put pressure on the point of the cut-out for the valve.
- Next fit the rest of the wheel cover

Wheel bolt caps*



Fig. 62 Wheel: wheel bolts with caps.


Removal

- Fit the plastic clip (vehicle tools) over the cap until it clicks into place **»** Fig. 62.
- Remove the cap with the plastic clip.

Anti-theft wheel bolts*

Loosening the wheel bolts

Raising the vehicle



A special adapter (vehicle tools) is required to remove the anti-theft wheel bolts.

- Remove the wheel cover* or the cap*.
- Insert the special adapter (vehicle tools) onto the anti-theft wheel bolt and push it on as far as it will go.
- Insert the wheel brace (vehicle tools) onto the adapter as far as it will go.
- Remove the wheel bolt >>> page 48.

i Note

Make a note of the code number of the antitheft wheel bolt and keep it in a safe place, but not in your vehicle. If you need a new adapter, you can obtain it from the SEAT Official Service, indicating the code number.




Fig. 64 Wheel: loosen the wheel bolts.

 Insert the box spanner (vehicle tools) onto the wheel bolt as far as it will go. An adapter is required to unscrew or tighten the antitheft wheel bolts **>>** page 48.

 Turn the wheel bolt approximately one turn to the left **>>> Fig. 64** (arrow). To apply the required torque, hold the wheel brace at the end. If it is not possible to loosen a wheel bolt, carefully apply pressure with one foot on the end of the box spanner. Hold on to the vehicle for support and take care not to slip.

▲ WARNING

Slightly loosen the wheel bolts (one turn) before raising the vehicle with the jack*. If not, an accident may occur.





 Place the jack* (vehicle tools) on firm ground. If necessary use a large, strong board or similar support. If the surface is slippery (for example tiles) place the jack on a rubber mat or similar to prevent it from slipping » △.

• Find the support point on the strut (sunken area) closest to the wheel to be changed **>>> Fig. 65**.

• Place the jack under the jacking point and turn the crank until the arm of the jack is directly below the vertical rib under the door sill.

 Align the jack so that the arm of the jack fits around the rib under the door sill and the movable base plate of the jack is flat on the ground **»** Fig. 66.

• Continue turning the jack* until the wheel is slightly lifted off the ground.

▲ WARNING

- Make sure that the jack* remains stable. If the surface is slippery or soft, the jack* could slip or sink, respectively, with the resultant risk of injury.
- Only raise the vehicle with the jack* supplied by the manufacturer. Other vehicles could slip, with the consequent risk of injury.
- Only mount the jack* on the support points designed for this purpose on the strut, and always align the jack correctly. If you do not, the jack* could slip as it does not have an adequate grip on the vehicle: risk of injury!
- The height of the parked vehicle can change as a result of variations in temperature and loading.

() CAUTION

The vehicle must not be raised on the crossbar. Only place the jack* on the points designed for this purpose on the strut. Otherwise, the vehicle may be damaged.

Removing and fitting the wheel

Change the wheel after loosening the wheel bolts and raising the vehicle with the jack.

Taking off the wheel

- Unscrew the wheel bolts using the box spanner and place them on a clean surface.
- Take off the wheel >>> ①.

Putting on the spare wheel

When fitting tyres with a compulsory rotation direction, observe the instructions in **>>> page 49**.

- Mount the wheel.
- Screw on the wheel bolts in position and tighten them loosely with a box spanner.
- Carefully lower the vehicle using the jack*.
- Tighten the wheel bolts in diagonal pairs using the wheel brace.

The wheel bolts should be clean and turn easily. Before fitting the spare wheel, inspect the wheel condition and hub mounting surfaces. These surfaces must be clean before fitting the wheel.

() CAUTION

When removing/fitting the wheel, the rim may hit and damage the brake disc. For this reason, please take care and get a second person to assist you.

Tyres with compulsory rotation direction

A directional tread pattern can be identified by the arrows on the sidewall that point in the direction of rotation. Always observe the direction of rotation indicated when fitting the wheel to guarantee optimum properties of this type of tyres with regard to grip, noises, wear and aquaplaning.

If it is absolutely necessary to fit the spare tyre* against the direction of rotation, drive with care as this means the tyre does not offer optimum driving properties. This is of particular importance when the road surface is wet.

To return to directional tread tires, replace the punctured tyre as soon as possible and restore the obligatory direction of rotation of all tyres.

Subsequent work

- Alloy wheels: replace the wheel bolt caps.
- Plate wheels: replace the wheel hubcap.
- Return all tools to their proper storing location.
- If the replaced wheel does not fit in the spare wheel housing, store it safely in the luggage compartment **» (P) page 133**.
- Check the tyre pressure of the newly mounted tyre as soon as possible.
- In vehicles fitted with a tyre pressure indicator, adjust the pressure and store it in memory **>>> page 213**.
- Have the tightening torque of the wheel bolts checked as soon as possible with a torque wrench (it should be 120 Nm). Meanwhile, drive carefully.
- Have the flat tyre replaced as quickly as possible.

Snow chains

Use

Snow chains should only be used on the *front* wheels.

• Check that they are correctly seated after driving for a few yards; correct the position if

necessary, in accordance with the manufacturer's fitting instructions.

- Keep your speed below 50 km/h (30 mph).
- If there is a danger of being trapped despite having mounted the chains, it is best to disable the driving wheels (ASR) in the ESC **>>>** 12% page 152.

Snow chains will improve *braking ability* as well as *traction* in winter conditions.

For technical reasons snow chains may only be used with the following wheel rim/tyre combination.

175/70R14 185/60R15	Chains with links not exceeding 15 mm (including the chain closure)
215/45R16	Chains with links not exceeding 9 mm (including the chain closure)
215/40R17	Chains with links not exceeding 7 mm (including the chain closure)

Remove wheel covers and any integral trim ring before fitting snow chains.

Remove the chains when roads are free of snow. Driving characteristics worsen, and the wheels become damaged quickly and may even be rendered unusable.

Snow chains should be correctly tightened in accordance with the manufacturer's instruc-

tions. This will prevent the chains coming into contact with the wheel housing.

Emergency towing of the vehicle

Towing



Fig. 67 Right side of the front bumper: Towing ring.



Fig. 68 Right side of the rear bumper: Towing ring.

Towline anchorages

Attach the bar or rope to the towline anchorages.

The essentials

The towline anchorages are located under the floor panel in the luggage compartment, next to the vehicle tools **»** page 47.

Screw the front towline anchorage into the screw connection **» Fig. 67** and tighten it with the wheel brace. The rear towline anchorage is under the rear bumper, on the right.

Tow rope or tow bar

It is easier and safer for the vehicle to be towed using a tow bar. You should only use a tow-rope if you do not have a tow-bar.

A tow rope should be slightly elastic to reduce the loading on both vehicles. It is advisable to use a tow rope made of synthetic fibre or similarly elastic material.

Attach the tow rope or the tow bar only to the towline anchorages provided or a towing bracket.

Notes for the driver of the towing vehicle

• The tow rope must be taut before you drive off.

• Release the clutch very carefully when starting the vehicle (manual gearbox), or accelerate gently (automatic gearbox).

Driving style

Towing requires some experience, especially when using a tow *rope*. Both drivers should realise how difficult it is to tow a vehicle. Inexperienced drivers should not attempt to tow.

Do not pull too hard with the towing vehicle and take care to avoid jerking the tow rope. When towing on an unpaved road, there is always a risk of overloading and damaging the anchorage points.

The ignition of the vehicle being towed must be switched on to prevent the steering wheel from locking and also to allow the use of the turn signals, horn, windscreen wipers and washers.

Place the gear lever in neutral on vehicles with a manual gearbox. With an automatic gearbox, place the lever in \mathbf{N} .

The brake servo only works when the engine is running. When not running, you must apply considerably more pressure to the brake pedal.

As the power assisted steering does not work if the engine is not running, you will need more strength to steer than you normally would.



» 🛆 in Notes on page 79

»» page 79

Tow-starting

If the engine will not start, first try starting it using the battery of another vehicle **»> page 52.** You should only attempt to towstart a vehicle if charging the battery does not work. This is done by leveraging wheel movement.

When tow-starting a vehicle with a **petrol engine**, do not tow it more than a *short* distance, otherwise unburned fuel can enter the catalytic converter.

However, if your vehicle has to be tow-started:

- Engage 2nd or 3rd gear.
- Keep the clutch pressed down.
- Switch the ignition on.
- Once both vehicles are moving, release the clutch.

• As soon as the engine starts, press the clutch and move the gear lever into neutral. This helps to prevent driving into the towing vehicle.



»» 🛆 in Notes on page 79

»» page 79

How to jump start

Jump leads

The jump lead must have a sufficient wire cross section.

If the engine fails to start because of a discharged battery, the battery can be connected to the battery of another vehicle to start the engine.

Jump leads

Jump leads must comply with standard **DIN 72553** (see cable manufacturer's instructions). The wire cross section must be at least 25 mm² for petrol engines and at least 35 mm² for diesel engines.

i Note

• The vehicles must not touch each other, otherwise electricity could flow as soon as the positive terminals are connected.

• The discharged battery must be properly connected to the on-board network.

How to jump start: description




Fig. 69 Diagram of connections for vehicles without Start-Stop system.




Fig. 70 Diagram of connections for vehicles with Start-Stop system.

Jump lead terminal connections

1. Switch off the ignition of both vehicles $\longrightarrow \Delta$.

- Connect one end of the *red* jump lead to the positive + terminal of the vehicle with the flat battery (A) >>>> Fig. 69.
- 3. Connect the other end of the *red* jump lead to the positive terminal (+) in the vehicle providing assistance (B).
- For vehicles without Start-Stop system: connect one end of the black jump lead to the negative terminal
 of the vehicle providing the current
 B
 w Fig. 69.
- For vehicles with Start-Stop system: connect one end of the black jump lead (2) to a suitable ground terminal, to a solid piece of metal in the engine block, or to the engine block itself **>> Fig. 70**.
- Connect the other end of the black jump lead (X) to a solid metal component bolted to the engine block or to the engine block itself of the vehicle with the flat battery. Do not connect it to a point near the battery (A).
- 6. Position the leads in such a way that they cannot come into contact with any moving parts in the engine compartment.

Starting

7. Start the engine of the vehicle with the boosting battery and let it run at idling speed.

 Start the engine of the vehicle with the flat battery and wait for 2 or 3 minutes until the engine is running.

The essentials

Removing the jump leads

- 9. Before you remove the jump leads, switch off the dipped beam headlights if they are switched on.
- 10.Turn on the heater blower and heated rear window in the vehicle with the flat battery. This helps minimise voltage peaks which are generated when the leads are disconnected.
- 11.When the engine is running, disconnect the leads in reverse order to the details given above.

Make sure the battery clamps have sufficient metal-to-metal contact with the battery terminals.

If the engine fails to start, switch off the starter after about 10 seconds and try again after about a minute.

▲ WARNING

• Please note the safety warnings referring to working in the engine compartment >>> Page 198, Working in the engine compartment.

• The battery providing assistance must have the same voltage as the flat battery (12 V) and approximately the same capacity (see imprint on battery). Failure to comply could result in an explosion.

- Never use jump leads when one of the batteries is frozen. Danger of explosion! Even after the battery has thawed, battery acid could leak and cause chemical burns. If a battery freezes, it should be replaced.
- Keep sparks, flames and lighted cigarettes away from batteries, danger of explosion. Failure to comply could result in an explosion.
- Observe the instructions provided by the manufacturer of the jump leads.
- Do not connect the negative cable from the other vehicle directly to the negative terminal of the flat battery. The gas emitted from the battery could be ignited by sparks. Danger of explosion.
- Do not attach the negative cable from the other vehicle to parts of the fuel system or to the brake line.
- The non-insulated parts of the battery clamps must not be allowed to touch. The jump lead attached to the positive battery terminal must not touch metal parts of the vehicle, this can cause a short circuit.
- Position the leads in such a way that they cannot come into contact with any moving parts in the engine compartment.
- Do not lean on the batteries. This could result in chemical burns.

X

i Note

The vehicles must not touch each other, otherwise electricity could flow as soon as the positive terminals are connected.

Changing the windscreen wiper blades

Changing the wiper blades




Fig. 71 Wipers in service position




Fig. 72 Changing the windscreen wiper blade.

To change the blades it is necessary to move the wipers from the rest position into the service position.

Do not change the windscreen wipers when out of the service position, as it could cause paint to flake off the bonnet due to friction with the windscreen wiper arm.

Service position (for changing wiper blades)

- Ensure that the wiper blades are not frozen.
- Turn the ignition on and off and then (within approximately 9 seconds) push the windscreen wiper lever down (short wipe). The windscreen wipers will move to the service position **»** Fig. 71.

Removing the wiper blade

- Lift the windscreen wiper arm.
- Press the securing tab down (1) >>> Fig. 72.

• Extract the wiper blade from the wiper arm.

Fitting the wiper blade

• Insert the wiper blade onto the windscreen wiper arm until it clicks into place.

• Place the windscreen wiper arms to their initial position.



» ▲ in Changing the windscreen and rear window wiper blades on page 78

»» page 78

Changing the rear window wiper blade




Fig. 73 Removing and fitting the rear window wiper blade.

Removing the wiper blade

• Lift the wiper arm away from the glass

55

• Slide the blade adapter in the direction of the arrow and remove the blade **»** Fig. 73 A.

Fitting the wiper blade

• With one hand, hold the top end of the wiper arm.

• Place the blade as shown in **>>> Fig. 73 B** and slide the adapter along until it engages.



»» ⚠ in Changing the windscreen and rear window wiper blades on page 78



»» page 78

Safety

Safe driving

Safety first!

This chapter contains important information, tips, suggestions and warnings that you should read and consider for both your own safety and for your passengers' safety.

 This manual contains important information about the operation of the vehicle, both for the driver and the passengers. The other sections of the on-board documentation also contain further information that you should be aware of for your own safety and for the safety of your passengers.

• Ensure that the on-board documentation is kept in the vehicle at all times. This is especially important when lending or selling the vehicle to another person.

Advice about driving

Before setting off

For your own safety and the safety of your passengers, always note the following points before every trip:

Make sure that the vehicle's lights and turn signals are working properly.

Safetv

- Check tyre pressure.
- Ensure that all windows provide a clear and good view of the surroundings.
- Ensure that all luggage is correctly secured
 >> page 133.
- Make sure that no objects can interfere with the pedals.
- Adjust front seat, head restraint and mirrors properly according to your size.
- Ensure that the passenger in the central rear seat always has the head restraint in the correct position for use.
- Instruct passengers to adjust the head restraints according to their height.
- Protect children with appropriate child seats and properly applied seat belts
 » page 72.
- Assume the correct sitting position. Instruct your passengers also to assume a proper sitting position **>>> page 57**.
- Fasten your seat belt securely. Instruct your passengers also to fasten their seat belts properly **>>> page 61**.

What affects driving safety?

As a driver, you are responsible for yourself and your passengers. When your concentration or driving safety is affected by any circumstance, you endanger yourself as well as others on the road \mathfrak{W} , for this reason:

- Always pay attention to traffic and do not get distracted by passengers or telephone calls.
- Never drive when your driving ability is impaired (e.g. by medication, alcohol, drugs).
- Observe traffic laws and speed limits.
- Always reduce your speed as appropriate for road, traffic and weather conditions.
- When travelling long distances, take breaks regularly at least every two hours.
- If possible, avoid driving when you are tired or stressed.

When driving safety is impaired during a trip, the risk of injury and accidents increases.

Safety equipment

Never put your safety or the safety of your passengers in danger. In the event of an accident, the safety equipment may reduce the

Safe driving

risk of injury. The following list includes most of the safety equipment in your SEAT:

- Three-point seat belts
- Belt tension limiter for the front and rear side seats
- Belt tensioners for the front seats
- Front airbags
- Side airbags in the front seat backrests, with chest and head protection
- "ISOFIX" anchor points for "ISOFIX" rear child seat system
- Height-adjustable front head restraints
- Rear-centre head restraints with in-use position and non-use position
- Adjustable steering column

The safety equipment mentioned above works together to provide you and your passengers with the best possible protection in the event of an accident. However, these safety systems can only be effective if you and your passengers are sitting in a correct position and use this equipment properly.

Safety is everyone's business!

Correct position for passengers

Correct sitting position for driver




Fig. 74 The proper distance between driver and steering wheel



Fig. 75 Correct head restraint position for the driver.

For your own safety and to reduce the risk of injury in the event of an accident, we recom-

mend the following adjustments for the driver:

- Adjust the steering wheel so that there is a distance of at least 25 cm between the steering wheel and the centre of your chest »> Fig. 74.
- Ensure that you can reach the highest point of the steering wheel.
- Adjust the head restraint so that its upper edge is at the same level as the top of your head, or as close as possible to the same level as the top of your head **»** Fig. 75.
- Move the seat backrest to an upright position so that your back rests completely against it.
- Fasten your seat belt securely >>> page 61.
- Keep both feet in the footwell so that you have the vehicle under control at all times.

Adjustment of the driver's seat >>> page 127.

• An incorrect sitting position of the driver can lead to severe injuries.

»

Safety

 Adjust the driver's seat so that there is at least 25 cm distance between the centre of the chest and the centre of the steering wheel w Fig. 74. If distance is less than 25 cm, the airbag system may not protect you properly.

 If your physical constitution prevents you from maintaining the minimum distance of 25 cm, contact a specialised workshop. The workshop will help you decide if special specific modifications are necessary.

• When driving, always hold the steering wheel with both hands on the outside of the ring at the 9 o'clock and 3 o'clock positions. This reduces the risk of injury when the driver airbag is triggered.

• Never hold the steering wheel at the 12 o'clock position, or in any other manner (e.g. in the centre of the steering wheel). In such cases, if the airbag is triggered, you may sustain injuries to the arms, hands and head.

 To reduce the risk of injury to the driver during sudden braking manoeuvres or an accident, never drive with the backrest tilted far back! The airbag system and seat belts can only provide optimal protection when the backrest is in an upright position and the driver is wearing his or her seat belt correctly.

• Adjust the head restraint properly to achieve optimal protection.

Adjusting the steering wheel position

Read the additional information carefully >>> 2 page 13

A WARNING

• Never adjust the position of the steering wheel when the vehicle is moving, as this could cause an accident.

• Move the lever up firmly so the steering wheel position does not accidentally change during driving. risk of accident!

 Make sure you are capable of reaching and firmly holding the upper part of the steering wheel: risk of accident!

 If you adjust the steering wheel so that it points towards your face, the driver airbag will not protect you properly in the event of an accident. Make sure that the steering wheel points towards your chest.

Correct sitting position for front passenger

For your own safety and to reduce the risk of injury in the event of an accident, we recommend the following adjustments for the front passenger:

 Move the front passenger seat back as far as possible » ▲.

- Move the seat backrest to an upright position so that your back rests completely against it.
- Adjust the head restraint so that its upper edge is at the same level as the top of your head, or as close as possible to the same level as the top of your head **>>> page 60**.
- Always keep both feet in the footwell in front of the front passenger seat.
- Fasten your seat belt securely >>> page 61.

It is possible to deactivate the front passenger airbag in **exceptional circumstances >>> page 70**.

Adjusting the front passenger seat **>>> 12:**

- An incorrect sitting position of the front passenger can lead to severe injuries.
- Adjust the front passenger seat so that there is at least 25 cm between your chest and the dash panel. If distance is less than 25 cm, the airbag system may not protect you properly.
- If your physical constitution prevents you from maintaining the minimum distance of 25 cm, contact a specialised workshop. The workshop will help you decide if special specific modifications are necessary.

 Always keep your feet in the footwell when the vehicle is moving; never rest them on the dash panel, out the window or on the seat. An incorrect sitting position exposes you to an increased risk of injury in case of a sudden braking or an accident. If the airbag is triggered, you could sustain severe injuries due to an incorrect sitting position.

• To reduce the risk of injury to the front passenger in events such as sudden braking manoeuvres or an accident, never travel with the backrest tilted far back! The airbag system and seat belts can only provide optimal protection when the backrest is in an upright position and the front passenger is wearing his or her seat belt properly. The further the seat backrests are tilted to the rear, the greater the risk of injury due to incorrect positioning of the belt web or to the incorrect sitting position!

• Adjust the head restraint correctly in order to achieve maximum protection.

Correct sitting position for rear seat passengers

To reduce the risk of injury in the event of a sudden braking manoeuvre or an accident, passengers on the rear seat bench must consider the following:

- Sit up straight.
- Adjust the head restraint to the correct position >>> page 60.

- Always keep both feet in the footwell in front of the rear seat.
- Fasten your seat belt securely >>> page 61.
- Use an appropriate child restraint system when you take children in the vehicle
 >>> page 72.

▲ WARNING

• If the passengers in the rear seats are not sitting properly, they could sustain severe injuries.

• Adjust the head restraint correctly in order to achieve maximum protection.

• Seat belts can only provide optimal protection when seat backrests are in an upright position and the vehicle occupants are wearing their seat belts correctly. If passengers In the rear seats are not sitting in an upright position, the risk of injury due to incorrect positioning of the seat belt increases.

Examples of incorrect sitting positions

Seat belts can provide optimal protection only when the belt webs are properly positioned. Incorrect sitting positions substantially reduce the protective function of seat belts and increase the risk of injury due to incorrect seat belt position. As the driver, you are responsible for all passengers, especially children. Never allow anyone to assume an incorrect sitting position in the vehicle while travelling *≫* A.

The following list contains examples of sitting positions that could be dangerous for all vehicle occupants. The list is not complete, but we would like to make you aware of this issue.

Therefore, whenever the vehicle is in motion:

- Never stand in the vehicle.
- Never stand on the seats.
- Never kneel on the seats.
- Never tilt your seat backrest far to the rear.
- Never lean against the dash panel.
- Never lie on the rear bench.
- Never sit on the front edge of a seat.
- Never sit sideways.
- Never lean out of a window.
- Never put your feet out of a window.
- Never put your feet on the dash panel.
- Never put your feet on the surface of a seat.
- Do not allow anyone to travel in the footwell.
- Never travel without wearing the seat belt.
- Do not allow anyone to travel in the luggage compartment.

»

Safety

A WARNING

• Any incorrect sitting position increases the risk of severe injuries.

 Sitting in an incorrect position exposes the vehicle occupants to severe injuries if airbags are triggered, by striking a vehicle occupant who has assumed an incorrect sitting position.

 Before the vehicle moves, assume the proper sitting position and maintain it throughout the trip. Before every trip, instruct your passengers to sit properly and to stay in this position during the trip >>> page 57, Correct position for passengers.

Correct adjustment of front head restraints

Properly adjusted head restraints are an important part of passenger protection and can reduce the risk of injuries in most accident situations.

 Adjust the head restraint so that its upper edge is, as far as possible, at the same level as the top of your head, or at the very least, at eye level »» Fig. 76.

▲ WARNING

 Travelling with the head restraints removed or improperly adjusted increases the risk of severe injuries. An improper adjustment of the head restraints may cause death in an accident and increase the risk of suffering injuries during abrupt braking actions or unexpected manoeuvres.

• The head restraints must always be adjusted according to the height of the passenger.

Correct adjustment of rear head restraints




Fig. 77 Rear head restraint adjustment.

The rear head restraints have 2 positions:

• Raised position or position for use (A) **>>> Fig. 77.** In this position, the head restraint is used normally, protecting the occupant of the rear seats, along with the rear seat belts.

• Rest position, not in use (B) Fig. 77. This position improves the driver's rear visibility.

To fit the head restraint in position for use (A), pull on the edges with both hands in the direction of the arrow. To place it in rest position (B), lower the head restraint.

• Whenever a passenger is seated on the rear seats, the head restraint should be placed in the position for use (A).



Fig. 76 Correctly adjusted head restraint as viewed from the front and the side.

• Do not swap the centre rear head restraint with either of the outer seat rear head restraints. Risk of injury in case of an accident!

i Note

Note the instructions on the head restraints adjustment.

Pedal area

Pedals

- Ensure that you can always press the accelerator, brake and clutch pedals unimpaired to the floor.
- Ensure that the pedals can return unimpaired to their initial positions.
- Ensure that the floor mats are securely fastened during the trip and do not obstruct the pedals **>>>** △.

Only use floor mats which leave the pedals clear and which are secured to prevent them from slipping. You can obtain suitable floor mats from a specialised dealership.

If a brake circuit fails, the brake pedal must be pressed down thoroughly in order to stop the vehicle.

Wear suitable footwear

Always wear shoes which support your feet properly and give you a good feeling for the pedals.

🛆 WARNING

• If the pedals are obstructed, an accident may occur. Risk of serious injuries.

 Never lay or fit floor mats or other floor coverings over the original floor mats. This would reduce the pedal area and could obstruct the pedals. Risk of accident.

• Never place objects in the driver footwell. An object could move into the pedal area and impair pedal operation. In the event of a sudden driving or braking manoeuvre, you will not be able to operate the brake, clutch or accelerator pedal. Risk of accident!

Seat belts

Why wear a seat belt?

Number of seats

Your vehicle has **five** seats, two in the front and three in the rear. Each seat is equipped with a three-point seat belt.

In some versions, your vehicle is approved **only** for four seats. Two front seats and two rear seats.

• Never transport more than the permitted amount of people in your vehicle.

• Every vehicle occupant must properly fasten and wear the seat belt belonging to his or her seat. Children must be protected with an appropriate child restraint system.

Safety

Seat belt lamp*



The control lamp illuminates to remind the driver to fasten his seat belt.

Before starting the vehicle:

- Fasten your seat belt securely.
- Instruct your passengers to fasten their seat belts properly before driving off.
- Protect children by using a child seat according to the child's height and weight.

When the ignition is switched on, the control lamp \clubsuit in the instrument panel lights up* if the driver or passenger* have not fastened their seat belts.

An audible warning signal will sound for a few seconds if the seat belts are not fastened as the vehicle drives off and reaches a speed of more than approximately 25 km/h (15 mph) or if the seat belts are unfastened while the vehicle is in motion. The warning lamp will also flash \clubsuit .

The \bigstar lamp goes out when the driver and passenger seat belts are fastened with the ignition switched on.

The protective function of seat belts



Fig. 79 Drivers with properly worn seat belts will not be thrown forward in the event of sudden braking

Properly worn seat belts hold the occupants in the proper position. These also help prevent uncontrolled movements that may result in serious injury and reduce the risk of being thrown out of the vehicle.

Vehicle occupants wearing their seat belts correctly benefit greatly from the ability of the belts to absorb kinetic energy. In addition, the front part of your vehicle and other passive safety features (such as the airbag system) are designed to absorb the kinetic energy released in a collision. Taken together, all these features reduce the releasing kinetic energy and consequently, the risk of injury. This is why it is so important to fasten seat belts before every trip, even when "just driving around the corner".

Ensure that your passengers wear their seat belts as well. Accident statistics have shown that wearing seat belts is an effective means of substantially reducing the risk of injury and improving the chances of survival when involved in a serious accident. Furthermore, properly worn seat belts improve the protection provided by airbags in the event of an accident. For this reason, wearing a seat belt is required by law in most countries.

Although your vehicle is equipped with airbags, the seat belts must be fastened and worn. The front airbags, for example, are only triggered in some cases of head-on collision. The front airbags will not be triggered during minor frontal or side collisions, rear-end collisions, rollovers or accidents in which the airbag trigger threshold value in the control unit is not exceeded.

Therefore, you should always wear your seat belt and ensure that all vehicle occupants have fastened their seat belts properly before you drive off!

Seat belts

Safety instructions on using seat belts

- Always wear the seat belt as described in this section.
- Ensure that the seat belts can be fastened at all times and are not damaged.

🛆 WARNING

- If seat belts are worn incorrectly or not at all, the risk of severe injuries increases. The optimal protection from seat belts can be achieved only if you use them properly.
- Fasten your seat belt before every trip even when driving in town. Other vehicle occupants must also wear the seat belts at all times, otherwise they run the risk of being injured.
- The seat belt cannot offer its full protection if the seat belt is not positioned correctly.
- Never allow two passengers (even children) to share the same seat belt.
- Always keep both feet in the footwell in front of your seat as long as the vehicle is in motion.
- Never unbuckle a seat belt while the vehicle is in motion. Risk of fatal injury.
- The seat belt must never be twisted while it is being worn.
- The seat belt should never lie on hard or fragile objects (such as glasses or pens, etc.) because this can cause injuries.

• Do not allow the seat belt to be damaged or jammed, or to rub on any sharp edges.

- Never wear the seat belt under the arm or in any other incorrect position.
- Loose, bulky clothing (such as an overcoat over a jacket) impairs the proper fit and function of the seat belts, reducing their capacity to protect.
- The slot in the seat belt buckle must not be blocked with paper or other objects, as this can prevent the latch plate from engaging securrely.
- Never use seat belt clips, fastening rings or similar items to alter the position of the belt webbing.
- Frayed or torn seat belts or damage to the connections, belt retractors or parts of the buckle could cause severe injuries in the event of an accident. Therefore, you must check the condition of all seat belts at regular intervals.
- Seat belts which have been worn in an accident and stretched must be replaced by a specialised workshop. Renewal may be necessary even if there is no apparent damage. The belt anchorage should also be checked.
- Do not attempt to repair a damaged seat belt yourself. The seat belts must not be removed or modified in any way.
- The belts must be kept clean, otherwise the retractors may not work properly.

Head-on collisions and the laws of physics



Fig. 80 A driver not wearing a seat belt is thrown forward violently



Fig. 81 The unbelted passenger in the rear seat is thrown forward violently, hitting the driver who is wearing a seat belt.

It is easy to explain how the laws of physics work in the case of a head-on collision: when a vehicle starts moving, a type of energy

Safety

called "kinetic energy" is created both in the passengers and inside the vehicle.

The amount of "kinetic energy" depends on the speed of the vehicle and the weight of the vehicle and its passengers. The higher the speed and the greater the weight, the more energy there is to be "absorbed" in an accident.

The most significant factor, however, is the speed of the vehicle. If the speed doubles from 25 km/h (15 mph) to 50 km/h (30 mph), for example, the corresponding kinetic energy is multiplied by four.

Because the vehicle occupants in our example are not restrained by seat belts, in the event of crashing against a wall, all of the occupants' kinetic energy will be absorbed solely by said impact.

Even at speeds of 30 km/h (19 mph) to 50 km/h (30 mph), the forces acting on bodies in a collision can easily exceed one tonne (1000 kg). At greater speed these forces are even higher.

Vehicle occupants not wearing seat belts are not "attached" to the vehicle. In a head-on collision, they will move forward at the same speed their vehicle was travelling just before the impact. This example applies not only to head-on collisions, but to all accidents and collisions. Even at low speeds the forces acting on the body in a collision are so great that it is not possible to brace oneself with one's hands. In a frontal collision, unbelted passengers are thrown forward and will make violent contact with the steering wheel, dash panel, windscreen or whatever else is in the way **»** Fig. 80.

It is also important for rear passengers to wear seat belts properly, as they could otherwise be thrown forward violently through the vehicle interior in an accident. Passengers in the rear seats who do not use seat belts endanger not only themselves but also the front occupants **»** Fig. 81.

How to properly adjust your seatbelt

Fastening and unfastening the seat belt




Fig. 82 Positioning and removing the seat belt buckle.



Fasten your seat belt

The seat belt cannot offer its full protection if the seat belt is not positioned correctly.

- Adjust the seat and head restraint correctly.
- To fasten the belt, take hold of the latch plate and pull it slowly across your chest and lap.

• Insert the latch plate into the buckle for the appropriate seat and push it down until it is securely locked with an audible click **>>> Fig. 82**.

• Pull the belt to ensure that the latch plate is securely engaged in the buckle.

The seat belts are equipped with an automatic retractor on the shoulder strap. Full freedom of movement is permitted when the shoulder belt is pulled slowly. However, during sudden braking, during travel in steep areas or bends and during acceleration, the automatic retractor on the shoulder belt is locked.

The automatic belt retractors on the front seats are fitted with seat belt tensioners **>>> page 65**.

Releasing the seat belt

• Press the red button on the belt buckle **≫ Fig. 82**. The latch plate is released and springs out **≫** <u>∧</u>.

• Guide the belt back by hand so that it rolls up easily and the trim is not damaged.

Positioning seat belts

Seat belts offer their maximum protection only when they are properly positioned.

∆ WARNING

• The seat belts offer best protection only when the backrests are in an upright position and the seat belts have been fastened properly.

• Never put the latch plate in the buckle of another seat. If you do this, the seat belt will not protect you properly and the risk of injury is increased.

• Never unbuckle a seat belt while the vehicle is in motion. If you do, you increase the risk of sustaining severe or fatal injuries.

- An incorrectly worn seat belt can cause severe injuries in the event of an accident.
- The shoulder part of the seat belt must lie on the centre of the shoulder, never across the neck. The seat belt must lie flat and fit comfortably on the torso
- The lap part of the seat belt must lie across the pelvis, never across the stomach. The seat belt must lie flat and fit comfortably on the pelvis Pull the belt tight if necessary to take up any slack.
- For pregnant women, the lap part of the seat belt must lie as low as possible over the pelvis, never across the stomach, and always lie flat so that no pressure is exerted on the abdomen **»** Fig. 83.
- Always engage the retractor lock when you are securing a child seat in group 0, 0+ or 1 >>> page 72.
- Read and observe the warnings >>> page 63.

Belt pretensioners*

How the seat belt tensioner works

Read the additional information carefully

The seat belts for the occupants in the front seats are equipped with belt tensioners. Sensors will trigger the belt pretensioners during severe head-on, lateral and rear collisions only if the seat belt is being worn. This retracts and tightens the seat belts, reducing the forward motion of the occupants.

The belt tensioners will not be triggered in the event of minor collisions, if the vehicle overturns, or in accidents where no major forces act on the vehicle.

i Note

• If the seat belt tensioners are triggered, a fine dust is produced. This is normal and it is not an indication of fire in the vehicle.

 The relevant safety requirements must be observed when the vehicle or components of the system are scrapped. Specialised workshops are familiar with these regulations, which are also available to you.

Service and disposal of belt tensioners

The belt tensioners are components of the seat belts that are installed in the seats of your vehicle. If you work on the belt tensioners or remove and install parts of the system when performing other repair work, the seat belt may be damaged. The consequence may be that, in the event of an accident, the belt tensioners function incorrectly or may not function at all.

So that the effectiveness of the seat belt tensioner is not reduced and that removed parts

Safety

do not cause any injuries or environmental pollution, regulations, which are known to the specialised workshops, must be observed.

🛆 WARNING

 Improper use or repairs not carried out by qualified mechanics increase the risk of severe or fatal injuries. The belt tensioners may fail to trigger or may trigger in the wrong circumstances.

• Never attempt to repair, adjust, remove or install parts of the belt tensioners or seat belts.

• The seat belt tensioner, seat belt and automatic retractor cannot be repaired.

 Any work on the belt tensioners and seat belts, including the removal and refitting of system parts in conjunction with other repair work, must be performed by a specialised workshop only.

• The belt tensioners will only provide protection for one accident and must be changed if they have been activated.

Airbag system

Brief introduction

Why is it so important to wear a seat belt and to sit correctly?

For the inflating airbags to achieve the best protection, the seat belt must always be worn properly and the correct sitting position must be assumed.

The airbag system is not a substitute for seat belts, but it is an integral part of the vehicle's overall passive safety system. Please bear in mind that the airbag system can only work effectively when the vehicle occupants are wearing their seat belts correctly and have adjusted the head restraints properly. Therefore, it is most important to properly wear the seat belts at all times, not only because this is required by law in most countries, but also for your safety **>>** page 61, Why wear a seat belt?.

The airbag inflates in a matter of seconds, so if you are not properly seated when the airbag is triggered, you may sustain fatal injuries. Therefore, it is essential that all vehicle occupants assume a correct sitting position while travelling.

Sharp braking before an accident may cause a passenger not wearing a seat belt to be thrown forward into the area of the deploying

Airbag system

airbag. In this case, the inflating airbag may inflict critical or fatal injuries on the occupant. This also applies to children.

Always maintain the greatest possible distance between yourself and the front airbag. This way, the front airbags can completely deploy when triggered, providing their maximum protection.

The most important factors that will trigger an airbag are: the type of accident, the angle of collision and the speed of the vehicle.

Whether or not the airbags are triggered depends primarily on the vehicle deceleration rate resulting from the collision and detected by the control unit. If the vehicle deceleration occurring during the collision and measured by the control unit remains below the specified reference values, the front, side and/or curtain airbags will not be triggered. Take into account that the visible damage in a vehicle involved in an accident, no matter how serious, is not a determining factor for the airbags to have been triggered.

• Wearing the seat belt incorrectly or assuming an incorrect sitting position can lead to critical or fatal injuries.

• All vehicle occupants, including children, who are not properly belted can sustain critical or fatal injuries if the airbag is triggered. Children up to 12 years old should always travel on the rear seat. Never transport children in the vehicle if they are not restrained or the restraint system is not appropriate for their age, size or weight.

• If you are not wearing a seat belt, or if you lean forward or to the side while travelling or assume an incorrect sitting position, there is a substantially increased risk of injury. This increased risk of injury will be further increased if you are struck by an inflating airbag.

• To reduce the risk of injury from an inflating airbag, always wear the seat belt properly.

• Always adjust the front seats properly.

Description of airbag system

The airbag system mainly comprises (as per vehicle equipment):

• an electronic control and monitoring system (control unit)

- frontal airbags for driver and passenger,
- side airbags,
- curtain airbags,
- a control lamp 🕸 on the dash panel **>>> page 68.**
- key-operated switch for front passenger airbag,

• a control lamp for disabling/enabling the front passenger airbag.

The airbag system operation is monitored electronically. The airbag control lamp will illuminate for a few seconds every time the ignition is switched on (self-diagnosis).

There is a fault in the system if the control lamp \mathfrak{Y} :

- does not light up when the ignition is switched on **>>> page 68**,
- turns off after 4 seconds after the ignition is switched on,
- turns off and then lights up again after the ignition is switched on,
- illuminates or flashes while the vehicle is moving.

The airbag system is not triggered if:

- the ignition is switched off
- there is a minor frontal collision
- there is a minor side collision
- there is a rear-end collision
- the vehicle turns over.

🛆 WARNING

• The seat belts and airbags can only provide maximum protection if the occupants are seated correctly >>> page 57, Correct position for passengers.

• If a fault has occurred in the airbag system, have the system checked immediately by a specialised workshop. Otherwise, during a

>>

Safety

frontal collision the system might not trigger correctly or may fail to trigger at all.

Airbag activation

The airbags deploy extremely rapidly, within thousandths of a second, to provide additional protection in the event of an accident. A fine dust may develop when the airbag deploys. This is normal and it is not an indication of fire in the vehicle.

The airbag system is only ready to function when the ignition is on.

In special accidents instances, several airbags may activate at the same time.

In the event of minor head-on and side collisions, rear-end collisions, overturning or rollover of the vehicle, airbags **do not activate**.

Activation factors

The conditions that lead to the airbag system activating in each situation cannot be generalised. Some factors play an important role, such as the properties of the object the vehicle hits (hard/soft), angle of impact, vehicle speed, etc.

Deceleration trajectory is key for airbag activation.

The control unit analyses the collision trajectory and activates the respective restraint system.

If the deceleration rate is below the predefined reference value in the control unit the airbags will not be triggered, even though the accident may cause extensive damage to the car.

The following airbags are triggered in serious head-on collisions

- Driver airbag.
- Front passenger front airbag

The following airbags are triggered in serious side-on collisions

- Front side airbag on the side of the accident.
- Rear side airbag on the side of the accident.

• Curtain (head) airbag on the side of the accident.

In an accident with airbag activation:

- the interior lights switch on (if the interior light switch is in the courtesy light position);
- the hazard warning lights switch on;
- all doors are unlocked;
- the fuel supply to the engine is cut.

Airbag control lamp and seat belt tensioner 🕱

The control lamp monitors all airbags and seat belt tensioners in the vehicle, including control units and wiring connections.

Monitoring of airbag and belt tensioner system

Both the airbag and belt tensioner systems operation is constantly monitored electronically. The control lamp \mathfrak{B} will light up for a few seconds every time the ignition is switched on (self-diagnosis).

The system must be checked when the control lamp \mathfrak{A} :

- does not light up when the ignition is switched on,
- turns off after 4 seconds after the ignition is switched on
- turns off and then lights up again after the ignition is switched on
- illuminates or flashes while the vehicle is moving.

In the event of a malfunction, the warning lamp remains on continuously. Have the airbag system inspected immediately by a specialised workshop.

Airbag system

If any of the airbags are disabled by a Technical Service, the warning lamp flashes for several more seconds after verification and will turn off if there is no fault.

🛆 WARNING

• If there is a malfunction, the airbag and belt tensioner system cannot properly perform its protective function.

• If a malfunction occurs, have the system checked immediately by a specialised workshop. Otherwise, in the event of an accident, the airbag system and belt tensioners may not be triggered, or may not be triggered correctly.

Airbag safety instructions

Front airbags

Read the additional information carefully >>> 2 page 14.

- The seat belts and airbags can only provide maximum protection if the occupants are seated correctly >>> page 57, Correct position for passengers.
- The deployment space between the front passengers and the airbags must not in any case be occupied by other passenger, pets and objects.

• The airbags provide protection for just one accident; replace them once they have deployed.

- It is also important not to attach any objects such as cup holders or telephone mountings to the surfaces covering the airbag units.
- Do not attempt to modify components of the airbag system in any way.

Side airbags*

Read the additional information carefully >>> 2 page 15.

▲ WARNING

 If you do not wear a seat belt, if you lean forward, or are not seated correctly while the vehicle is in motion, you are at a greater risk of injury if the side airbag system is triggered in an accident.

 In order for the side airbags to provide their maximum protection, the prescribed sitting position must always be maintained with seat belts fastened while travelling.

 Occupants of the outer seats must never carry any objects or pets in the deployment space between them and the airbags, or allow children or other passengers to travel in this position. It is also important not to attach any accessories (such as cup holders) to the doors. This would impair the protection offered by the side airbags.

• The built-in coat hooks should be used only for lightweight clothing. Do not leave any heavy or sharp-edged objects in the pockets.

• Great forces, such as hard blows or kicks, must not be exerted upon the backrest bolster because the system may be damaged. In this case, the side airbags would not be triggered.

 Under no circumstances should protective covers be fitted over seats with side airbags unless the covers have been approved for use in your vehicle. Because the airbag deploys from the side of the backrest, the use of conventional seat covers would obstruct the side airbag, seriously reducing the airbag's effectiveness.

• Any damage to the original seat upholstery or around the seams of the side airbag units must be repaired immediately by a specialised workshop.

• The airbags provide protection for just one accident; replace them once they have deployed.

Any work on the side airbag system or removal and installation of the airbag components for other repairs (such as removal of the front seat) should only be performed by a specialised workshop. Otherwise, faults may occur during the airbag system operation.

• Do not attempt to modify components of the airbag system in any way.

»

Safety

• The side and head airbags are managed through sensors located in the interior of the front doors. To ensure the correct operation of the side and curtain (head) airbags neither the doors nor the door panels should be modified in any way (e.g. fitting loudspeakers). If the front door is damaged, the airbag system may not work correctly. All work carried out on the front door must be done in a specialised workshop.

• In a side-on collision the side airbags will not work if the sensors do not correctly measure the pressure increase on the interior of the doors, due to air escaping through the areas with holes or openings in the door panel.

• Never drive if the interior door panels have been removed or if the panels have not been correctly fitted.

 Never drive the vehicle if the loudspeakers in the door panels have been removed, unless the holes left by the loudspeakers have been closed properly.

• Always check that the openings are closed or covered if additional loudspeakers or other equipment are fitted inside the door panels.

• Any work carried out to the doors should be made in an authorised specialised workshop.

Curtain airbags*

Read the additional information carefully >>> 2 page 15.

▲ WARNING

The airbag is deployed at high speed in fractions of a second.

• Do not obstruct the head-protection airbag deployment areas.

• Never secure objects over the curtain airbag cover or in its deployment area.

• Occupants of the front seats and rear side seats must never carry any other people, animals or objects in the deployment space between them and the airbags. Make sure that all the vehicle occupants, including children, observe this.

• The clothes hangers are intended only for light articles of clothing. Do not leave any heavy or sharp-edged objects in the pockets.

• Do not mount accessories on the doors.

• Use only sun blinds which have been expressly approved for use in your vehicle.

• Do not turn the sun blinds towards the windows if there are objects, e.g. pens or garage remote controls, secured to them.

Deactivating airbags

Deactivation of front passenger front airbag*



Fig. 84 In the glove compartment: Switch for activating and deactivating the front passenger airbag



Fig. 85 Centre side of dash panel: control lamp for deactivated front passenger airbag in centre console

Airbag system

Read the additional information carefully

If you fit a rear-facing child seat to the front passenger seat, the front passenger front airbag must be de-activated.

When the front passenger airbag is **deactivated**, this means that only the front passenger front airbag is deactivated. All the other airbags in the vehicle remain activated.

Activating the front passenger front airbag

- Switch the ignition off.
- Open the glove compartment on the front passenger side.
- Insert the key into the slot of the switch for deactivating the front passenger airbag
 W Fig. 84. About 3/4 of the key should enter, as far as it will go.
- Then turn the key gently to the **ON** position. Do not force it if you feel resistance, and make sure you have inserted the key fully.
- When the ignition is switched on, check whether the control lamp PASSENGER AIR BAG OFF ⅔: on the dash panel does ≫ Fig. 85 not light up ≫ △.

∆ WARNING

• It is the driver's responsibility to ensure that the key-operated switch is set to the correct position. • You should deactivate the front passenger front airbag only if you have to use a rear-facing child seat in exceptional cases >>> page 72, Transporting children safely.

• Never install a child seat facing backwards on the front passenger seat unless the front passenger front airbag has been disabled. Otherwise, there is a risk of death.

• As soon as the child seat is no longer needed on the front passenger seat, enable the front passenger front airbag again.

• Only deactivate the front passenger front airbag when the ignition is off, otherwise a fault may occur in the airbag system, which could cause the airbag to not deploy properly or not deploy at all in case of an accident.

• Never leave the key in the airbag disabling switch as it could get damaged or enable or disable the airbag during driving.

 When the passenger airbag is deactivated, if the control lamp PASSENGER AIR BAG OFF \$%; is not continuously lit up when the front passenger airbag is disabled, there may be a fault in the airbag system:

- Have the airbag system inspected immediately by a specialised workshop.
- Do not use a child seat on the front passenger seat! The front passenger front airbag could be triggered in the event of an accident, even if there is a fault in the system and, as a result, a child could sustain serious or fatal injuries.
- It is unpredictable whether the front passenger airbag will deploy in the event of

an accident. Warn all your passengers of this.

Safety

Transporting children safely

Safety for children

Introduction

For safety reasons, as we have learned from accident statistics, we recommend that children under 12 years of age travel in the rear seats. Depending on their age, height and weight, children travelling in rear seats must use a child seat or a seat belt. For safety reasons, the child seat should be installed in the rear seat, behind the front passenger seat or in the centre back seat.

The physical laws involved and the forces acting in a collision apply also to children **>>> page 63**. But unlike adults, children do not have fully developed muscle and bone structures. This means that children are subject to a greater risk of injury.

To reduce the risk of injuries, children must always use special child restraint systems when travelling in the vehicle.

We recommend the use of child safety products from the SEAT Original Accessories Programme, which includes systems for all ages made by "Peke" (not for all countries).

These systems have been especially designed and approved, complying with the ECE-R44. regulation. Follow the manufacturer's instructions and observe any statutory requirements when installing and using child seats. Always read and note **>>> page 72**.

We recommend you always carry the manufacturer's Child Seat Instruction Manual together with the on-board documentation.

Important information regarding the front passenger's airbag

Read the additional information carefully >>> 🗁 page 16.

Read and always observe the safety information included in the following chapters:

• Safety distance with respect to the passenger airbag **>>> page 66**.

 Objects between the passenger and the passenger side airbag >>> A in Front airbags on page 69.

The passenger side front airbag, when enabled, is a serious risk for a child that is facing backward since the airbag can strike the seat with such force that it can cause serious or fatal injuries. Children up to 12 years old should always travel on the rear seat.

Therefore we strongly recommend you to transport children on the rear seats. This is the safest location in the vehicle. Alternatively, the front passenger airbag can be disabled with a key-operated switch **»» page 70**. When transporting children, use a child seat appropriate to the age and size of each child.

• If a child seat is secured to the front passenger seat, the risk to the child of sustaining critical or fatal injuries in the event of an accident increases.

- An inflating front passenger airbag can strike the rear-facing child seat and project it with great force against the door, the roof or the backrest.
- Never install a child seat facing backwards on the front passenger seat unless the front passenger front airbag has been disabled. Risk of potentially fatal injuries to the child! However, if it is necessary, in exceptional cases, to transport a child in the front passenger seat, the front passenger front airbag must always be disabled »» page 70, Deactivation of front passenger front airbag*. If the front passenger seat has a height adjustment option, move it to the highest position.
- For those vehicles that do not include a key lock switch to deactivate the airbag, the vehicle must be taken to a technical service.
- All vehicle occupants, especially children, must assume the proper sitting position and be properly belted in while travelling.
- Never hold children or babies on your lap, this can result in potentially fatal injuries to the child!

 Never allow a child to be transported in a vehicle without being properly secured, or to stand up or kneel on a seat while travelling. In an accident, the child could be flung through the vehicle, causing possibly fatal injuries to themselves and to the other vehicle occupants.

• If children assume an improper sitting position when the vehicle is moving, they expose themselves to greater risk of injury in the event of a sudden braking manoeuvre or in an accident. This is particularly important if the child is travelling on the front passenger seat and the airbag system is triggered in an accident; as this could cause serious injury or even death.

- A suitable child seat can protect your child!
- Never leave a child alone in the child seat or inside the vehicle because depending on the season, very high temperatures may be reached inside a parked vehicle, which could be fatal.
- Children who are less than 1.5 metres tall must not wear a normal seat belt without a child seat, as this could cause injuries to the abdominal and neck areas during a sudden braking manoeuvre or in an accident.
- Do not allow the seat belt to become twisted and the seat belt should be properly in place >>> page 61.
- Only one child may occupy a child seat >>> page 73, Child seats.

• When a child seat is mounted in the rear seats, the door child-proof lock should be activated >>> page 109.

Child seats

Safety instructions

Read the additional information carefully >>> 2 page 16.

🛆 WARNING

When travelling, children must be secured in the vehicle with a restraint system suitable for age, weight and size.

• Read and always observe information and warnings concerning the use of child seats >>> page 72.

🛆 WARNING

The retaining rings are designed only for use with "ISOFIX" and Top Tether* system child seats.

 Never secure other child seats that do not have the "ISOFIX" or Top Tether* system, or retaining belts or objects to the fastening rings - this can result in potentially fatal injuries to the child.

• Ensure that the child seat is secured correctly using the "ISOFIX" and Top Tether* securing rings.

An undue installation of the safety seat will increase the risk of injury in the event of a crash.

• Never tie the retainer strap to a hook in the luggage compartment.

• Never secure or tie luggage or other items to the lower anchorages (ISOFIX) or the upper ones (Top Tether).

Categorisation of child seats into groups

Only use child seats that are officially approved and suitable for the child.

Child seats are subject to the regulation ECE-R 44. ECE-R stands for: Economic Commission for Europe Regulation.

The child seats are grouped into 5 categories:

Group 0: Up to 10 kg (up to around 9 months)

Group 0+: Up to 13 kg (up to around 18 months)

Group 1: from 9 to 18 kg (up to approx. 4 years old)

Group 2: from 15 to 25 kg (up to approx. 7 years old)

»

Safety

Group 3: From 22 to 36 kg (over around 7 years old)

Child seats that have been tested and approved under the ECE R44 standard bear the test mark on the seat (the letter E in a circle with the test number below it).

Follow the manufacturer's instructions and observe any statutory requirements when installing and using child seats.

We recommend you to always include the manufacturer's Child Seat Instruction Manual together with the on-board documentation.

SEAT recommends you use child seats from the **Original Accessories Catalogue**. These child seats have been designed and tested for use in SEAT vehicles. You can find the right child seat for your model and age group at SEAT dealers.

▲ WARNING

Read and always observe information and warnings concerning the use of child seats >>> page 72.

Self-help

Emergencies

Self-help

Emergency equipment

Emergency warning triangle*

The use of reflective warning triangles is obligatory in emergencies in some countries. As are the first aid kit and a set of spare light bulbs.

The warning triangle is under the storage compartment which is located under the luggage compartment floor.

i Note

• The warning triangle is not part of the vehicle's standard equipment.

• The warning triangle should meet legal requirements.

First-aid kit and fire extinguisher*

The first-aid kit can go in the storage compartment which is located under the luggage compartment floor.

The fire extinguisher* is attached to the luggage compartment carpet with Velcro.

i Note

- The first-aid kit and the fire extinguisher are not part of the vehicle's standard equipment.
- The first aid kit must comply with legal requirements.
- Observe the expiry date of the contents of the first aid kit. After it has expired you should purchase a new one.
- The fire extinguisher must comply with legal requirements.
- Ensure that the fire extinguisher is fully functional. The fire extinguisher should, therefore, be checked regularly. The sticker on the fire extinguisher will inform you of the next date for checking.
- Before acquiring accessories and emergency equipment see the instructions in "Accessories and spares" »>> page 187.

Vehicle tools

Read the additional information carefully

Some of the items listed are only provided in certain model versions, or are optional extras.

A WARNING

• The factory-supplied jack is only designed for changing wheels on this model. On no ac-

count attempt to use it for lifting heavier vehicles or other loads. Risk of injury.

- Use the jack only on a firm, level ground.
- Never start the engine when the vehicle is on the jack. Risk of accident.
- If work is to be carried out underneath the vehicle, this must be secured by suitable means. Otherwise, there is a risk of injury.

i Note

The jack does not generally require any maintenance. If required, it should be greased using universal type grease.

Spare wheel (temporary spare wheel)*

The temporary spare wheel is stored under the floor panel in the luggage compartment and is attached by a thumbnut.

How to use the temporary spare wheel

If you ever have a punctured tyre or loss of pressure, the temporary spare wheel is only intended for temporary use until you reach a workshop. Change it for a duty wheel as soon as possible.

Please note the following restrictions when using the temporary spare wheel. This temporary spare wheel has been specially designed for your vehicle, thus, it cannot be

»

Emergencies

changed with the temporary spare wheel from another vehicle.

No other type of tyre (normal summer or winter tyre) may be fitted on the compact temporary spare wheel rim.

Snow chains

For technical reasons, snow chains must not be used on the temporary spare wheel.

If you have a puncture on one of the front wheels when using snow chains, fit the temporary spare wheel in place of one of the rear wheels. Fit the snow chains on the rear wheel that you have removed and replace the punctured front wheel with this wheel.

Extraction of the spare wheel in vehicles with SEAT SOUND 6 speakers (with *subwoofer*)*

- Disassemble the *subwoofer's* floor panel (carpet) as follows:
- Pull the carpet upwards to remove it.
- Disconnect the *subwoofer's* speaker cable.
- Turn the securing wheel anti-clockwise.
- Remove the *subwoofer* speaker and the spare wheel.

• When replacing the spare wheel, place the *subwoofer* speaker in the direction indicated by the arrow and with the word "FRONT" facing forward.

• Reconnect the speaker cable and firmly rotate the securing wheel clockwise so that the *subwoofer* system and wheel are firmly in place.

🛆 WARNING

 After fitting the temporary spare wheel, check the tyre pressures as soon as possible.
 Failure to do so may cause an accident. The tyre pressures are listed on the inside of the fuel tank flap.

- Do not drive at over 80 km/h (50 mph) when the temporary spare wheel is fitted on the vehicle: risk of accident!
- Avoid heavy acceleration, hard braking and fast cornering: risk of accident!
- Never use more than one temporary spare wheel at the same time, risk of accident.
- No other type of tyre (normal summer or winter tyre) may be fitted on the compact temporary spare wheel rim.

Tyre repair

TMS (Tyre Mobility System)*

Read the additional information carefully >>> 🗁 page 46

The Anti-puncture kit* (Tyre Mobility System) will reliably seal punctures caused by the penetration of a foreign body of up to about

4 mm in diameter. Do not remove foreign objects, e.g. screws or nails, from the tyre.

After inserting the sealant residue in the tyre, you must again check the tyre pressure about 10 minutes after starting the engine.

You should only use the tyre mobility set if the vehicle is parked in a safe place, you are familiar with the procedure and you have the necessary tyre mobility set! Otherwise, you should seek professional assistance.

Do not use the tyre sealant in the following cases:

- If the wheel rim has been damaged.
- In outside temperatures below -20°C (-4°F).
- In the event of cuts or perforations in the tyre greater than 4 mm.
- If you have been driving with very low pressure or a completely flat tyre.
- If the sealant bottle has passed its use by date.

Using the tyre mobility system can be dangerous, especially when filling the tyre at the roadside. Please observe the following rules to minimise the risk of injury:

• Stop the vehicle safely as soon as possible. Park it at a safe distance from surrounding traffic to fill the tyre.

Self-help

• Ensure the ground on which you park is flat and solid.

• All passengers and particularly children must keep a safe distance from the work area.

• Turn on the hazard warning lights to warn other road users.

• Use the tyre mobility system only if you are familiar with the necessary procedures. Otherwise, you should seek professional assistance.

• The tyre mobility set is intended for temporary emergency use only until you can reach the nearest specialised workshop.

• Replace the repaired tyre with the tyre mobility set as soon as possible.

• The sealant is a health hazard and must be cleaned immediately if it comes into contact with the skin.

• Always keep the tyre mobility set out of the reach of small children.

• Never use a jack, even if it has been approved for your vehicle.

• Always stop the engine, apply the handbrake lever firmly and engage gear if using a manual gearbox, in order to reduce the risk of vehicle involuntary movement.

🛆 WARNING

A tyre filled with sealant does not have the same performance properties as a conventional tyre.

• Never drive faster than 80 km/h (50 mph).

• Avoid heavy acceleration, hard braking and fast cornering.

• Drive for only 10 minutes at a maximum speed of 80 km/h (50 mph) and then check the tyre.

${\ensuremath{\, \mathrm{ \ensuremath{\mathbb R}}}}$ For the sake of the environment

Dispose of used or expired sealant observing any legal requirements.

i Note

• A new bottle of sealant can be purchased at SEAT dealerships.

• Take into account the separate instruction manual of the tyre mobility set* manufacturer.

Contents of the tyre mobility system*




Fig. 86 Standard representation: contents of the anti-puncture kit.

The anti-puncture kit is located underneath the floor covering in the luggage compartment. It includes the following components **»> Fig. 86**:

- 1 Tyre valve remover
- 2 Sticker indicating maximum speed "max. 80 km/h" or "max. 50 mph"
- 3 Filler tube with cap
- (4) Air compressor
- 5 Tube for inflating tyres
- Warning provided by tyre pressure monitoring system (it can also be integrated in the compressor).

Emergencies

- (7) Air bleed screw (in its place, the compressor may have a button).
- 8 ON/OFF switch
- 9 12 volt connector
- 10 Bottle of sealant
- Spare tyre valve

The **valve insert remover** (1) has a gap at the lower end for a valve insert. The valve insert can only be screwed or unscrewed in this way. This also applies to its replacement part (1).

∆ WARNING

When inflating the wheel, the air compressor and the inflator tube may become hot.

- Protect hands and skin from hot parts.
- Do not place the hot flexible inflator tube or hot air compressor on flammable material.
- Allow them to cool before storing the device.

 If it is not possible to inflate the tyre to at least 2.0 bars (29 psi / 200 kPa), the tyre is too badly damaged. The sealant is not in a good condition to seal the tyre. Do not continue driving. Seek specialist assistance.

() CAUTION

Switch off the air compressor after a maximum of 8 operational minutes to avoid overheating! Before switching on the air compressor again, let it cool for several minutes.

Check after 10 minutes of driving

Screw in the inflator tube **» Fig. 86** (5) again and check the pressure on the gauge (6).

1.3 bar (19 psi / 130 kPa) and lower:

• Stop the vehicle! The tyre cannot be sealed sufficiently with the tyre mobility set.

• You should obtain professional assistance \mathfrak{m} .

1.4 bar (20 psi / 140 kPa) and higher:

• Set the tyre pressure to the correct value again.

• Carefully resume your journey, without exceeding 80 km/h (50 mph), until you reach the nearest specialised workshop and replace the tyre.

🛆 WARNING

Driving with an unsealed tyre is dangerous and can cause accidents and serious injury.

- Do not continue driving if the tyre pressure is 1.3 bar (19 psi / 130 kPa) and lower.
- Seek specialist assistance.

Changing the windscreen wiper blades

Changing the windscreen and rear window wiper blades

Read the additional information carefully

Perfect wiper blade condition is essential for clear vision. Damaged wiper blades should be replaced immediately.

The windscreen wiper blades are supplied as standard with a layer of graphite. This layer is responsible for ensuring that the wipe is silent. If the graphite layer is damaged, the noise of the water as it is wiped across the windscreen will be louder.

Check the condition of the wiper blades regularly. **If the wipers scrape across the glass**, they should be changed if they are damaged, or cleaned if they are dirty **>>> ①**.

If this does not produce the desired results, the setting angle of the windscreen wiper arms might be incorrect. They should be checked by a specialised workshop and corrected if necessary.

🛆 WARNING

Do not drive unless you have good visibility through all windows!

• Clean the windscreen wiper blades and all windows regularly.

• The wiper blades should be changed once or twice a year.

① CAUTION

• Damaged or dirty windscreen wipers could scratch the glass.

 Never use fuel, nail varnish remover, paint thinner or similar products to clean the windows. This could damage the windscreen wiper blades.

• Never move any windscreen wiper by hand. This could cause damage.

 To prevent damage to the bonnet and the windscreen wiper arms, the latter should only be lifted off the windscreen when in service position.

i Note

• The windscreen wiper arms can be moved to the service position only when the bonnet is properly closed.

• You can also use the service position, for example, if you want to fix a cover over the windscreen in the winter to keep it clear of ice.

Towing or tow-starting

Notes

Read the additional information carefully

Please observe the following points if you use a tow rope:

Notes for the driver of the towing vehicle

- Move the vehicle slowly until the cable is taut. Then accelerate gradually.
- Begin and change gears cautiously. If you are driving an automatic vehicle, accelerate gently.
- Remember that the brake servo and power steering are not working in the vehicle you are towing. Brake sooner than normal and pressing the pedal gently.

Notes for the driver of the towed vehicle

 Ensure that the tow rope remains taut at all times when towing.

Towing vehicles with an automatic gearbox

- Put the selector lever into position "N".
- Do not drive faster than 50 km/h (31 mph).
- Do not tow further than 50 km.
- If a breakdown vehicle is used, the vehicle must be towed with the front wheels raised.

If the vehicle has no electrical power, the brake lights, turn signals and all other lights will no longer function. Do not have the vehicle towed away. Failure to follow this instruction could result in an accident.

A WARNING

Vehicle handling and braking capacity change considerably during towing. Please observe the following instructions to minimise the risk of serious accidents and injury:

- As the driver of the vehicle being towed:
 - You should depress the brake much harder as the brake servo does not operate.
 Pay the utmost attention to avoid crashing into the towing vehicle.
 - More strength is required at the steering wheel as the power steering does not operate when the engine is switched off.
- As the driver of the towing vehicle:
 - Accelerate with particular care and caution.
 - Avoid sudden braking and manoeuvres.
 - Brake earlier than usual and more smoothly.

() CAUTION

When tow-starting, fuel could enter the catalytic converter and damage it.

»

Emergencies

i Note

• Observe legal requirements when towing or tow-starting.

• Switch on the hazard warning lights of both vehicles. However, observe any regulations to the contrary.

• For technical reasons, vehicles with an automatic gearbox must not be tow-started.

• If there is no lubricant in the gearbox as the result of a fault, you must raise the driven wheels while the vehicle is being towed.

• If the vehicle has to be towed more than 50 km (30 miles), the front wheels should be raised during towing, and towing should be carried out by a qualified person.

• The steering wheel is locked when the vehicle has no electrical power. The vehicle must then be towed with the front wheels raised. Towing should be carried out by a qualified person.

• The towline anchorage should always be kept in the vehicle.

Towline anchorages



Fig. 87 Towline anchorage at the front of the vehicle

Read the additional information carefully >>> 21 page 51

Fitting the front towline anchorage

- Take the towline anchorage from the onboard tool set.
- Remove the front cover by pressing down on its left-hand side. For FR finishes, press down and pull outwards. For the rest of the Sport finishes, remove the cover by inserting a screwdriver into the lower slot and levering gently.
- Bolt the anchorage to its limit to the *left*, in the direction of the arrow **>>> Fig. 87**.

Rear towline anchorage

There is a towline anchorage at the rear on the right below the rear bumper.

Fuses and bulbs

Fuses

Introduction

Due to the constant updating of vehicles, fuse assignments based on equipment and the use of the same fuse for various electrical components, it is not possible to provide an up-to-date summary of the fuse positions for the electrical components at the time this manual was printed. For detailed information about the fuse positions, please consult a technical service.

In general, a fuse can be assigned to various electrical components. Likewise, an electrical component can be protected by several fuses.

Only replace fuses when the cause of the problem has been solved. If a newly inserted fuse blows after a short time, you must have the electrical system checked by a specialised workshop as soon as possible.

The high voltages in the electrical system can give serious electrical shocks, causing burns and even death!

• Never touch the electrical wiring of the ignition system.

Fuses and bulbs

• Take care not to cause short circuits in the electrical system.

▲ WARNING

Using unsuitable fuses, repairing fuses or bridging a current circuit without fuses can cause a fire and serious injury.

• Never use a fuse with a higher value. Only replace fuses with a fuse of the same amperage (same colour and markings) and size.

• Never repair a fuse.

• Never replace a fuse by a metal strip, staple or similar.

() CAUTION

• To prevent damage to the vehicle's electric system, before replacing a fuse always turn off the ignition, the lights and all electrical elements and remove the key from the ignition.

• If you replace a fuse with higher-rating fuse, you could cause damage to another part of the electrical system.

• Protect the fuse boxes when open to prevent the entry of dust or humidity as they can damage the electrical system.

• Always carefully remove the fuse box covers and refit them correctly to avoid problems with your vehicle.

i Note

• One component may have more than one fuse.

• Several components may run on a single fuse.

• In the vehicle, there are more fuses than those indicated in this chapter. These should only be changed by a specialised workshop.

• Positions not containing a fuse do not appear in the following tables.

• Some of the equipment listed in the tables below pertain only to certain versions of the model or are optional extras.

• Please note that the above lists, while correct at the time of printing, are subject to change.

Fuses to the left of the instrument panel

Read the additional information carefully

Only replace fuses with a fuse of the same amperage (same colour and markings) and size.

Control box 1

No.	Consumer/Amps		
1	Left lights	40	
2	Central locking	40	

No.	Consumer/Amps		
3	Power C63 (30 Power)	30	
4	PTC Relay (Engine glow)	50	
5	Left pillar connector A pin 22 (motor for closing window on driver's side)	30	
6	For closing back left window (motor)	30	
7	Horn	20	
9	Panoramic roof	30	
10	Active suspension	7.5	
11	Headlight washer system relay	30	
12	MIB display	5	
13	(RL-15) SIDO Kl.15 supply (inputs 29 and 55)	30	
14	Removing ignition key, diagnostics, headlight lever (flashers), switching on dipped /side beams (rotating lights)		
15	Air and heat control (supply)	7.5	
	Automatic gearbox lever	7.5	
16	Instrument panel	5	
17	Dwa Sensor, Alarm horn	7.5	
23	Dual windscreen cleaner pump	7.5	
24	Engine heater, heating control box (supply)	30	
26	12V Relay socket	20	

chnical data

dvice

No.	Consumer/Amps	
27	Rear window wiper motor	15
28	Lighter	20
29	Airbag control unit, airbag deactiva- tion warning lamp	10
30	Reverse, Mirror joysticks, RKA, switch- ing on heated seats, int. pressure A.C, heating A.C. controls (supply), electro- chromic mirror, PDC control, switching on front and rear fog lights (rotating lights).	7.5
31	Petrol gauge	5
32	AFS headlights, headlight regulator (signal and adjustment), LWR Cent, di- agnostics, front headlight lever (switch on), Dimmer (headlight adjust- ment)	7.5
33	Start-Stop relay, clutch sensor	5
34	Heated jets	5
35	Soundaktor control feed, GRA feed, Kühlerlüfter central feed	5
36	Heated seats	10
37	Additional diagnostics	10
38	Right hand lights A/66 feed	40
39	ABS Pump (rear battery)	40
41	Heated rear window	30
42	Passenger side window controls	30

Emergencies

No.	Consumer/Amps	
43	Rear right window control	30
44	Reversing camera	10
45	Windscreen wiper feed lever, diagnos- tics	10
47	ABS Ventil (rear battery)	25
	EKP TDI relay (fuel pump feed)	30
49	EKP MPI relay (fuel pump feed)	20
	TFSI pump gauge control	15
50	Multimedia Radio (power supply)	20
51	Heated mirrors	10
53	Rain sensor	5
54	30 ZAS (ignition switch)	5
55	Heated seats	10

Fuse arrangement in engine compartment

Read the additional information carefully

Only replace fuses with a fuse of the same amperage (same colour and markings) and size.

No.	Consumer/Amps		
	Fan, condenser	40	
1	TK8 fan, condenser	50	
2	Glow plugs	50	
3	ABS Pump		
3	EMBOX2-13 (TA8)	20	
4	PTC glow phase 2	40	
5	PTC glow phase 3	40	
6	BDM, 30 ReF	5	
7	MSG (KL30)		
8	Windscreen wipers		
9	Automatic gear box control, AQ 160 Control box		
10	ABS Ventil	25	
10	EMBOX2-11 (TA8)	5	
11	Vacuum pump motor	20	
	Injectors		
12	TDI fuel metering adjuster, TA8 exhaust temperature sensor	10	
13	Servo sensor	5	
14	Coolant pump high/low temperature, gauge (relay EKP)	10	
15	50 controls motor diag	5	

Fuses and bulbs

No.	Consumer/Amps	
16	Starter motor	30
17	Controls motor (MSG KL87)	20
18	PTC Relays, TOG sensor, engine valves, PWM fan	10
19	Lambda sensors	
	Glow plug relay, Heizrohr	5
	Ignition coil	20
20	Pre-wired motor (coolant pump, varia- ble valve distributor, active carbon solenoid valve filter, pressure valve, secondary air inlet valve)	10

Changing bulbs

General notes

Read the additional information carefully >>> page 45

Before changing any bulb, first turn off the failed device.

Do not touch the glass part of the bulb with your bare hands. The fingerprints left on the glass will vaporise as a result of the heat generated by the bulb, reducing bulb life and causing condensation on the reflector surface, thus reducing effectiveness. A bulb must only be replaced by one of the same type. The type is indicated on the bulb, either on the glass part or on the base.

Xenon headlights

With this type of headlight, the user can replace the turn signal bulb. Replacement of the dipped/main beam bulb must be done by Technical Services, given that complex elements must be removed from the vehicle and the automatic control system that incorporates it must be reset.

The Xenon bulbs discharge 2.5 times the light flux and have an average lifespan of 5 times more than that of halogen bulbs, this means that, except due to unusual circumstances, there is no need to change the bulbs for the whole life of the vehicle.

▲ WARNING

• Take particular care when working on components in the engine compartment if the engine is warm, there is a risk of burns.

• Bulbs are highly sensitive to pressure. The glass can break when you touch the bulb, causing injury.

• The high voltage element of gas discharge bulbs* (xenon light) must be handled correctly. Otherwise, there is a risk of death.

• When changing bulbs, please take care not to injure yourself on sharp parts in the head-light housing.

() CAUTION

• Remove the ignition key before working on the electric system. Otherwise, a short circuit could occur.

• Switch off the lights or parking lights before you change a bulb.

🏶 For the sake of the environment

Please ask your specialist retailer how to dispose of used bulbs in the proper manner.

i Note

• Depending on weather conditions (cold or wet), the front lights, the fog lights, the tail lights and the turn signals may be temporarily misted. This has no influence on the useful life of the lighting system. By switching on the lights, the area through which the beam of light is projected will quickly be demisted. However, the edges may continue to be misted.

 Please check at regular intervals that all lighting (especially the exterior lighting) on your vehicle is functioning properly. This is not only in the interest of your own safety, but also that of all other road users.

• Before changing a bulb, make sure you have the correct new bulb.

• Do not touch the glass part of the bulb with your bare hands, use a cloth or paper towel instead. The residue left by the fingerprints


»

Emergencies

would vaporise as a result of the heat generated by the bulb, they will be deposited on the reflector and will impair its surface.

Single headlight bulb change

Position of the bulbs



- A Side lights Dipped beam/main beam.
- **B** Turn signal light.
- C DRL (day light)

Turn signal and DRL (day light) light





Fig. 89 Single headlight DRL light (day light).



- Fig. 90 Single turn signal lamp.
- Raise the bonnet.
- Turn the bulb holder >>> Fig. 89 (1) or
 >>> Fig. 90 (2) to the left and pull.
- Remove the bulb by pressing on the bulb holder and turning it anti-clockwise at the same time.

- Installation involves all of the above steps in reverse sequence.

Dipped/main beam headlights and side light




Fig. 91 Single headlight.




Fig. 92 Dipped beam/main beam and side light of the single headlight.

Remove the cover

- Raise the bonnet.
- Move the loop **» Fig. 91** (1) in the direction of the arrow and remove the cover.

Changing the dipped/main beam headlight

- Remove connector **>>> Fig. 92** (3) from the bulb.
- Unclip the retainer spring **»> Fig. 92** (2) pressing inwards to the right.
- Extract the bulb and fit the replacement so that the lug on the base fits into the recess on the reflector.
- Fit the connector.
- Fit the cover and close the strap. Make sure that the gasket sits well on the casing cover during the operation.
- Check whether the new bulb is working.

Changing the side light


- Extract the bulb holder **»** Fig. 92 (4) outwards.
- Remove the bulb by pulling it out and fitting the new one.
- Installation involves all of the above steps in reverse sequence.
- Fit the cover and close the strap. Make sure that the gasket sits well on the casing cover during the operation.

- Check whether the new bulb is working.

Fuses and bulbs


Double headlight bulb change

Position of the bulbs



- Fig. 93 Double headlight.
- A Side lights
- B Main beam headlights
- C Dipped beam headlights
- D Turn signal
- E DRL (LED day light)

Side light and main beam






Fig. 95 Side light and main beam headlights.

Remove the cover

- Raise the bonnet.
- Move the loop 1 in the direction of the arrow and remove the cover **»** Fig. 94.

Emergencies

Emergencies

Changing the side light

- Remove connector **»** Fig. 95 (2) by pulling outward.
- Remove the bulb by pulling it out and fitting the new one.
- Installation involves all of the above steps in reverse sequence.
- Fit the cover and close the strap. Make sure that the gasket sits well on the casing cover during the operation.
- Check whether the new bulb is working.

Changing the main beam bulb

- Remove connector **>>> Fig. 95** (3) by pulling outward.
- Extract the bulb and fit the replacement so that it sits correctly into the cut-out on the reflector.
- Installation involves all of the above steps in reverse sequence.
- Fit the cover and close the strap. Make sure that the gasket sits well on the casing cover during the operation.
- Check whether the new bulb is working.

Dipped beam headlight





Fig. 96 Double headlight.



- Fig. 97 Dipped beam headlights.
- Raise the bonnet.
- Move the loop **» Fig. 96** (1) in the direction of the arrow and remove the cover.
- Remove connector **»** Fig. 97 (2) from the bulb.

- Unclip the retainer spring **>>> Fig. 97** (3) pressing inwards to the right.
- Extract the bulb and fit the replacement so that the lug on the base fits into the recess on the reflector.
- Fit the connector.
- Fit the cover and close the strap. Make sure that the gasket sits well on the casing cover during the operation.
- Check whether the new bulb is working.

Turn signal light



- Fig. 98 Turn signal light.
- Raise the bonnet.
- Turn the bulb holder **»> Fig. 98** (1) to the left and pull.




Fig. 101 Front fog light.



- Remove the bolt **»** Fig. 101 (1) from the fog light grille with a screwdriver.
- Subsequently, remove the clips located on the edge of the grill with gentle leverage. \gg

- Remove the bulb by pressing on the bulb holder and turning it anti-clockwise at the same time.

- Installation involves all of the above steps in reverse sequence.

Changing the AFS headlight bulbs

Position of the bulbs




Fig. 99 AFS headlight bulbs.

A Turn signal

B Xenon headlight (dipped beam/main beam)

Changing the xenon bulb

The procedure for changing the bulb is the same on both sides of the vehicle.

Fuses and bulbs

∧ WARNING

This type of bulb should be changed at a specialised workshop.

Turn signal bulb

B6J-0430

- Fig. 100 Turn signal light.
- Raise the bonnet.
- Turn bulb holder **»** Fig. 100 (A) to the left and pull.
- Remove the bulb by pressing on the bulb holder and turning it anti-clockwise at the same time.
- Installation involves all of the above steps in reverse sequence.

Front fog light bulb



- Remove the 3 bolts >>> Fig. 102 (2) to remove the fog light.
- Remove the metal clip situated on the upper part of the fog light by pulling towards the exterior of the vehicle **»** Fig. 102 (3).

FR version fog-light bulb




Fig. 103 Fog light: access to the connector and to the light bulb holder.

- Remove the 4 bolts (A) >>> Fig. 103 from the inside of the wheel housing and the 2 bottom bolts (B) >>>> Fig. 103 from the bumper with a screwdriver.
- Pull the bumper to release it from its anchorages to access the connector and the light bulb holder.

i Note

Due to the difficulty of accessing fog light bulbs, have them replaced at a Technical Service or specialised workshop.

Remove the bulb holder



Fig. 104 Front fog light.

- Remove connector >>> Fig. 104 (1) from the bulb.
- Turn the bulb holder >>> Fig. 104 (2) to the left and pull.
- Remove the bulb by pressing on the bulb holder and turning it counter-clockwise at the same time.
- Installation involves all of the above steps in reverse sequence.
- Check that the bulb works properly.

Changing the tail light bulbs

Summary of LED tail lights

LED

- Brake lights
- Side lights

Bulbs

- Retro fog light
- Reverse lights
- Turn signal

Access to tail lights






• Open the rear lid.

• Turn the bolt in the direction of the arrow, by hand or with a screwdriver **»** Fig. 105.

• Remove the tail light, by pulling it outwards.

Changing the tail light bulbs



• Remove the connector from housing (A) **>>> Fig. 105**.

Fuses and bulbs

• Remove the bulb holder, separating it from the casing. To do this, press tabs (B) in the direction of the arrows **>>> Fig. 106**.

Changing bulbs. LED lamps


Carry out the same operations as in lights fitted with bulbs.

If necessary, remove the socket, as if it were a bulb.


If the brake light and/or side light with LEDs have to be replaced, the tail light must be replaced.

Changing the side and interior bulbs

Turn signals



- Press the turn signal to the left or to the right to remove the bulb.
- Remove the bulb holder from the turn signal.
- Remove the failed bulb and replace with a new bulb.
- Insert the bulb holder in the turn signal guide until it clicks into place.
- First fit the turn signal in the opening in the chassis, fastening the tabs 1) >>> Fig. 108, and then fit in the bulb as shown by the arrow (2) >>> Fig. 108.



Emergencies


Number plate light

- Insert the flat part of a screwdriver into the special slot and remove the bulb.
- Remove the bulb holder, by turning it until it is free.
- Change the bulb.
- Replace the bulb holder, by turning it until it fits fully.
- Fit the light into the space and press until you hear a "click".

Additional brake light*

Given the difficulty involved in the replacement of this light it should be done by Technical Services.

Interior light and front reading lights



To remove the glass

- Insert a fine screwdriver between the casing and the glass **»** Fig. 109.
- Carefully remove the glass, levering it to avoid possible damage.

To replace the bulbs


- Pull the bulbs outwards.
- To remove the central bulb, hold and press to one side.


Assembly

- Proceed in the reverse order, pressing gently on the outer edge of the side light.
- First fit the glass with the fastening tabs over the frame of the switch. Next press the

front part until the two long tabs click on the support.

Luggage compartment light*






- Extract the bulb by pressing on its inside edge -arrow- using the flat side of a screwdriver **>>> Fig. 110**.

Fuses and bulbs

 Press the bulb sideways and remove it from its housing **>>> Fig. 111**. Operation



Operation

Controls and displays

General instrument panel

1	Door release lever	
2	Light switch	117
3	Headlight range control*	121
4	Air vents	
5	Lever for:	
	– Turn signals/main beam head- lights	119
	– Cruise control*	180
6	Instrument panel and warning lamps:	
	– Instruments	94
	– Warning and indication lamps	35
7	Steering wheel with horn and	
	– Driver airbag	66
	- On-board computer controls	25
	 Controls for radio, telephone, navigation and speech dialogue system >>> Booklet Radio 	
	 Paddle levers for tiptronic gear- shift (automatic gearbox) 	161

8 Steering and starter lock	147
9 Lever for:	
 Windscreen wipers and washer 	123
 Window washer-wiper system* 	123
 Multi-function display control* 	25
Infotainment system:	
 Depending on the equipment, glove compartment with: 	130
 CD player* and/or SD card* >>> Booklet Radio 	
12 Passenger airbag*	14
(13) Switches for:	
 Heating and ventilation 	139
 Air conditioning* 	141
– Climatronic*	143
Depending on the equipment, but- tons for:	
- SEAT Drive Profile	182
 Park assist system 	173
- Hazard warning lights	121
 Airbag off warning lamp*6 	8,70
15 Depending on the equipment:	
– USB/AUX-IN input	105
 Cigarette lighter/Power socket 	132
16 Drink holder/Ashtray	131

Controls and displays

17	Controls in the centre console:	
	– Start-Stop operation button	170
	- Tyre pressure monitoring*	213
	– Heated rear window	123
	- Heated seats*	128
	– Central locking*	108
18	Handbrake lever	149
19	Gear lever	
	– Automatic*	158
	– Manual	158
20	Storage space	
21	Pedals	61
22	Steering column control lever*	13
23	Bonnet release lever	199
24	Fuse housing	80
25	Control for adjusting electric exteri- or mirrors*	126
26	Electric window controls*	114


i Note

Some of the items of equipment listed here are fitted only on certain model versions or are optional extras.

Instruments and warning/control lamps

Instruments

General instrument panel



The layout of the instruments depends upon the model and the engine.

 Rev counter (with the engine running, in hundreds of revolutions per minute)
 » page 95.

The beginning of the red zone of the rev counter indicates the maximum speed in any gear after running-in and with the engine hot. However, it is advisable to change up a gear or move the selector lever to **D** (or lift your foot off the accelerator) before the needle reaches the red zone **>>> ①**.

- 2 Engine coolant temperature display >>> page 97.
- 3 Displays on the screen >>> page 95.
- (4) Adjuster button and display >>> page 97.

Fig. 113 Instrument panel, on dash panel

5 Speedometer.

6 Fuel gauge »» page 98.

🛆 WARNING

Any distraction may lead to an accident, with the risk of injury.

• Do not operate the instrument panel controls when driving.

Instruments and warning/control lamps

() CAUTION

• To prevent damage to the engine, the rev counter needle should only remain in the red zone for a short period of time.

• When the engine is cold, avoid high revs and heavy acceleration and do not make the engine work hard.

🛞 For the sake of the environment

Changing up a gear in time reduces fuel consumption and noise.

Rev counter

The rev counter indicates the number of engine revolutions per minute **»** Fig. 113 (1).

Together with the gear-change indicator, the rev counter offers you the possibility of using the engine of your vehicle at a suitable speed.

The start of the red zone on the dial indicates the maximum engine speed which may be used briefly when the engine is warm and after it has been run in properly. Before reaching this range, you should change to a higher gear for vehicles with a manual gearbox or for automatic gearboxes put the selector lever in "D" or take your foot off the accelerator pedal. We recommend that you avoid high revs and that you follow the recommendations on the gear-change indicator. Consult the additional information in **>>>** 1 page 28, Gear-change indicator.

() CAUTION

Never allow the rev counter needle 1 **» Fig. 113** to go into the red zone on the scale for more than a very brief period, otherwise there is a risk of engine damage.

🛞 For the sake of the environment

Changing up a gear early will help you to save fuel and minimise emissions and engine noise.

Indications on the display

A variety of information can be viewed on the instrument panel display **»> Fig. 113 (3)** depending on the vehicle equipment:

- Bonnet, rear lid and doors open **>>> [1]? page 28**.
- Information and warning texts.
- Mileage.
- Time.
- Navigation instructions.
- Outside temperature.
- Compass.

- Shift lever position »» page 158.
- Recommended gear (manual gearbox) >>> 28.
- Multifunction display (MFD) and menus with different setting options **>>>** 💭 page 25.
- Service interval display »» 🗇 page 33.
- Second speed display »» 🔁 page 25.
- Speed warning function **>>>** 🗁 page 32.
- Start-Stop system status display **>>> page 170**.
- Low consumption driving status (ECO) **>>> page 96**
- Identifying letters on engine (MKB).
- Active cylinder management display (ACT[®])* >>> page 165

Distance travelled

The *odometer* registers the total distance travelled by the car.

The *odometer* (**trip**) shows the distance travelled since the last odometer reset. The last digit of the trip recorder indicates distances of 100 metres or one tenths of a mile.

- Briefly press the button **» Fig. 113** (4) to reset the trip recorder to 0.
- Keep the button (4) pressed for about 3 seconds and the previous value will be displayed.

Operation

Time

To set the time, keep the button **»** Fig. 113
(4) pressed for more than 3 seconds to select the hour or minute display.

• To continue setting the time, press the upper or lower part of the button (4). Hold button down to scroll through the numbers quickly.

• Press the button (4) again in order to finish setting the time.

The time can also be set via the CAR key and Setup function button in the Easy Connect system **>>>** page 99.

Compass

With the ignition on and the navigation system on, the cardinal point corresponding to the direction of travel of the vehicle is displayed on the instrument panel.

Selector lever position

The selected gear is displayed on the side of the selector lever and on the instrument panel display. In positions **D** and **S**, and with the Tiptronic, the corresponding gear is also displayed.

Recommended gear (manual gearbox)

The recommended gear in order to save fuel is displayed on the instrument panel while you are driving **w** f page 28.

Second speed display (mph or km/h)

In addition to the speedometer, the speed can also be displayed in a different unit of measurement (in miles or in km per hour).

This option cannot be deactivated in models destined for countries in which the second speed must always be visible.

The second speed display can be adjusted in the Easy Connect system via the (MR) key and the (Setup) function button **>>> page 99**.

Speed warning

When the speed setting is exceeded, this will be indicated on the instrument panel display. This is very useful, for example when using winter tyres that are not designed for driving at the maximum speed of the vehicle **w 129 page 32**.

The speed warning settings can be adjusted in the Easy Connect system via the (M) key and the (Setup) function button **>>> page 99**.

Start-Stop operating display

Updated information relating to the status is displayed on the instrument panel **>>> page 170**.

Low consumption driving status (ECO)*

Depending on the equipment, when driving, the **"ECO"** display appears on the instrument panel when the vehicle is in low consumption status due to active cylinder management (ACT[®])* **>>> (DP page 30**.

Identifying letters on engine (MKB)

Hold the button **»** Fig. 113 (4) down for more than 15 seconds to display the identifying letters of the vehicle engine (MKB). To do this, the ignition must be switched on and the engine switched off.

Observe the safety warnings »» \triangle in Warning symbols on page 99.

Even though outside temperatures are above freezing, some roads and bridges may be icy.

 At outside temperatures above +4°C (+39°F), even when the "ice crystal symbol" is not visible, there may still be patches of ice on the road.

• Do not rely on the outside temperature indicator!

i Note

• Different versions of the instrument panel are available and therefore the versions and instructions on the display may vary. In the case of displays without warning or information texts, faults are indicated exclusively by the warning lamps.

• Depending on the equipment, some settings and instructions can also be carried out in the Easy Connect system.

• When several warnings are active at the same time, the symbols are shown successively for a few seconds and will stay on until the fault is rectified.

Odometer



Fig. 114 Instrument panel: odometer and reset button.

The distance covered is displayed in "kilometres" or miles "m". It is possible to change the measurement units (kilometres "km"/miles "m") in the radio/Easy Connect*. Please refer to the Easy Connect* Instructions Manual for more details.

Odometer/trip recorder

The odometer shows the total distance covered by the vehicle.

The trip recorder shows the distance that has been travelled since it was last reset. It is used to measure short trips. The last digit of the trip recorder indicates distances of 100 metres or tenths of a mile.

The trip recorder can be set to zero by pressing (0.0/SET) **W Fig. 114**.

Fault display

If there is a fault in the instrument panel, the letters **DEF** will appear in the trip recorder display. Have the fault repaired immediately, as far as is possible.

Coolant temperature gauge

For vehicles with no coolant temperature gauge, a control lamp \bot appears for high coolant temperatures **» page 204**. Please note **» 0**.

The coolant temperature gauge 2 **>>> Fig. 113** only works when the ignition is switched on. In order to avoid engine damage, please read the following notes for the different temperature ranges.

Engine cold

If only the diodes in the lower part of the scale light up, this indicates that the engine has not yet reached operating temperature. Avoid high revs and heavy acceleration and do not make the engine work hard.

Normal temperature

If in normal operations, the diodes light up until the central zone, it means that the engine has reached operating temperature. At high outside temperatures and when making the engine work hard, the diodes may continue lighting up and reach the upper zone. This is no cause for concern, provided the control lamp $\frac{1}{2}$ does not light up on the instrument panel digital display.

Heat range

When the diodes light up in the upper area of the display and the control lamp appears \downarrow on the instrument panel display, the coolant temperature is excessive **»» page 204**.

() CAUTION

>>

Operation

 Additional lights and other accessories in front of the air inlet reduce the cooling effect of the coolant. At high outside temperatures and high engine loads, there is a risk of the engine overheating.

• The front spoiler also ensures proper distribution of the cooling air when the vehicle is moving. If the spoiler is damaged this can reduce the cooling effect, which could cause the engine to overheat. Seek specialist assistance.

Fuel level



The display (6) ****** Fig. 113 only works when the ignition is switched on. When the display reaches the reserve mark, the lower diode lights up in red and the control lamp \mathbb{B} appears ****** page 94. When the fuel level is very low, the lower diode flashes in red. The distance to empty fuel level is displayed on the instrument panel (3) **** Fig. 113**.

You can consult the tank capacity of your vehicle in the **»** f page 40 section.

① CAUTION

Never run the fuel tank completely dry. An irregular fuel supply could cause misfiring. In this way the unburned fuel can reach the exhaust system, which could cause the catalytic converter to overheat resulting in damage.

Warning and control lamps

Warning symbols

Read the additional information carefully >>> 25

There are red warning symbols (priority 1) and yellow warning symbols (priority 2).

Warning messages, Priority 1 (red)

If one of these faults occurs, the warning lamp will light up or flash and will be accompanied by **three audible warnings**. This is a **danger** warning. Stop the vehicle and switch off the engine. Check the fault and correct it. Obtain professional assistance if necessary.

If several priority 1 faults are detected at the same time, the symbols will be displayed one

after the other for about 2 seconds at a time and will continue until the fault is corrected.

No menus will be shown in the display for the duration of a priority 1 warning message.

Examples of priority 1 warning messages (red)

- Brake system symbol (1) with the warning message STOP BRAKE FLUID INSTRUC-TION MANUAL or STOP BRAKE FAULT IN-STRUCTION MANUAL.
- Coolant symbol & with the warning message STOP SEE COOLANT INSTRUCTION MANUAL.
- Engine oil pressure symbol 🖘 with the warning message STOP ENGINE OIL PRESSURE LOW! INSTRUCTION MANUAL.

Warning messages, Priority 2 (yellow)

If one of these faults occurs, the corresponding warning lamp lights up and is accompanied by **an audible warning**. Check the corresponding function as soon as possible although the vehicle may be used without risk.

If several priority 2 warning messages are detected at the same time, the symbols are displayed one after the other for about 2 seconds at a time. After a set time, the information text will disappear and the symbol will be shown as a reminder at the side of the display. **Priority 2** warning messages will not be shown until all **Priority 1** warning messages have been dealt with!

Examples of priority 2 warning reports (yellow):*

• Fuel warning light with the information text **PLEASE REFUEL**.

▲ WARNING

If the warning lamps and messages are ignored, the vehicle may stall in traffic, or may cause accidents and severe injuries.

• Never ignore the warning lamps or text messages.

• Stop the vehicle safely as soon as possible.

• Park the vehicle away from traffic and ensure that there are no highly flammable materials under the vehicle that could come into contact with the exhaust system (e.g. dry grass, fuel).

 A faulty vehicle represents a risk of accident for the driver and for other road users. If necessary, switch on the hazard warning lamps and put out the warning triangle to advise other drivers.

• Before opening the bonnet, switch off the engine and allow it to cool.

• In any vehicle, the engine compartment is a hazardous area and could cause severe injuries >>> page 198.

() CAUTION

Failure to heed the control lamps and text messages when they appear may result in faults in the vehicle.

Introduction to the Easy Connect system*

System settings (CAR)*

CAR menu (Setup)

Read the additional information carefully

To select the settings menus, press the Easy Connect (MR) button and the (Setup) function button.

The actual number of menus available and the name of the various options in these menus will depend on the vehicle's electronics and equipment.

Pressing the menu button will always take you to the last menu used.

When the function button check box is activated \mathbf{v} , the function is active.

Pressing the menu button 🗈 will always take you to the last menu used.

Any changes made using the settings menus are automatically saved on closing those menus.

Operation

Function buttons in the vehicle settings menu	Page
ESC system	»» page 152
Tyres	»» page 213
Driver assistance	» table on page 24
Parking and manoeuvring	»» page 173
Vehicle lights	» table on page 24
Mirrors and windscreen wipers	» table on page 24
Opening and closing	» table on page 24
Multifunction display	» table on page 24
Date and time	» table on page 24
Units	» table on page 24
Service	»» page 95
Factory settings	» table on page 24

Any distraction may lead to an accident, with the risk of injury. Operating the Easy Connect system while driving could distract you from traffic.

Communications and multimedia

Steering wheel controls*

General information

The steering wheel includes a multifunction module from where it is possible to control the audio, telephone and radio/navigation functions without needing to distract the driver.

There are two versions of the multifunction module:

• Audio system + telephone without voice control version (MID): for controlling the audio functions available (radio, audio CD, MP3, iPod^{®1)}, USB¹⁾, SD¹⁾) and Bluetooth system from the steering wheel.

• Audio system + telephone with voice control version (HIGH): for controlling the audio functions available (radio, audio CD, MP3, iPod^{®1}, USB¹, SD¹) and Bluetooth system from the steering wheel.

¹⁾ Depending on the vehicle equipment.

Operation

Operating the telephone and audio system without voice control (MID)

C D A		
	G H Fig. 116 Controls on the steering wheel.	


Button	Radio	Media (except AUX)	AUX	Telephone	Navigation
A	<i>Turn:</i> Turn volume up/down <i>Press:</i> Mute	<i>Turn:</i> Turn volume up/down <i>Press:</i> Mute	<i>Turn:</i> Turn volume up/down <i>Press:</i> Mute	<i>Turn:</i> Turn volume up/down <i>Press:</i> Mute	<i>Turn:</i> Turn volume up/down <i>Press:</i> Mute
B	Short press: access to the tele- phone menu in the instrument panel®.	Short press: access to the tele- phone menu in the instrument panel ^{a)} .	Short press: access to the tele- phone menu in the instrument panel®.	Short press: answer/hang up calls, enable/open the tele- phone menu. Hold down: reject an incoming call/switch to private mode/re- dial®.	Short press: access to the tele- phone menu in the instrument panel®.
C	Search for last station	Short press: switch to the previ- ous song Hold down: quick rewind	No function	No function	No function
D	Search for the next station	Short press: switch to the next song Hold down: fast forward	No function	No function	No function
(E) , (F)	Change menu on instrument panel ^{a)}	Change menu on instrument panel ^{a)}	Change menu on instrument panel ^{a)}	Change menu on instrument panel ^{a)}	Change menu on instrument panel ^{a)}
6	MID: change source	MID: change source	MID: change source	MID: change source	MID: change source

Button	Radio	Media (except AUX)	AUX	Telephone	Navigation	
H	<i>Turn:</i> Next/previous preset ^{b)} <i>Press:</i> Acts on the MFD	<i>Turn</i> : Next/previous song ^{b)} <i>Press:</i> Acts on the MFD	<i>Turn:</i> No function <i>Press:</i> Acts on the MFD	<i>Turn:</i> Acts on the MFD <i>Press:</i> Confirm	<i>Turn:</i> Changes menu or memory on instrument panel <i>Press:</i> Operates on instrument panel	

a) According to the vehicle's equipment package.

b) Only if the dash panel is in audio menu.

Operating the telephone and audio system with voice control (HIGH)



mode

Operation

Button	Radio	Media (except AUX)	AUX	Telephone ^{a)}	Navigation ^{a)}
C	Search for last station	Short press: switch to the previ- ous song Hold down: quick rewind	No function	No function ^{b)}	Radio/media functionality (ex- cept AUX)
D	Search for the next station	Short press: switch to the next song Hold down: fast forward	No function	No function ^{b)}	Radio/media functionality (ex- cept AUX)
(E), (F)	Change menu on instrument panel	Change menu on instrument panel	Change menu on instrument panel	Change menu on instrument panel	Change menu on instrument panel
6	Enable/disable voice control ^{a)}	Enable/disable voice control ^{a)}	Enable/disable voice control ^{a)}	No function ^{b)}	Enable/disable voice control
H	<i>Turn:</i> Next/previous preset ^{c)} <i>Press:</i> Acts on the MFD or con- firms the menu option of the dash panel depending on the menu option	Turn: Next/previous song ⁽⁾ Press: Acts on the MFD or con- firms the menu option of the dash panel depending on the menu option	Turn: Acts upon the dash panel menu depending on where it is located Press: Acts on the MFD or con- firms the menu option of the dash panel depending on the menu option	Turn: Acts upon the dash panel menu depending on where it is located Press: Acts on the MFD or con- firms the menu option of the dash panel depending on the menu option	Turn: Acts upon the dash panel menu depending on where it is located Press: Acts on the MFD or con- firms the menu option of the dash panel depending on the menu option

^{a)} According to the vehicle's equipment package.

^{b)} When a call is being made, radio/media functionality (except AUX).

c) Only if the dash panel is in audio menu.

Multimedia

USB/AUX-IN input



Depending on the features and the country, the vehicle may have a USB/AUX-IN connection.

The USB/AUX-IN input is located above the storage compartment in the front centre console **»** Fig. 118.

The operating description is located in the respective Instruction Manuals of the audio system or the navigation system.

Opening and closing

Central locking system

Description

Read the additional information carefully >>> 2 page 9.

The central locking system enables you to lock and unlock all doors and the rear lid by just pushing the button.

Central locking can be activated by using any of the following options:

• the key, by inserting it into the driver door cylinder and rotating it in the opening direction. Depending on the vehicle version, either all doors will be unlocked or only the driver door will be unlocked. All doors will be locked on locking the vehicle using the key.

• the interior central lock button >>> page 108.

• the radio frequency remote control, using the buttons on the key >>> page 110.

Various functions are available to improve the vehicle safety:

- Locking system "Safe*"
- Selective* unlocking system
- Self-locking system to prevent involuntary unlocking

 Automatic speed dependent locking and unlocking system*

Operation

Emergency unlocking system

Unlocking the vehicle*

 Press button (2) >>> Fig. 122 on remote control to unlock all the doors and rear lid.

Locking the vehicle*

Press button (a) >>> Fig. 122 on the remote control to lock all doors and the rear lid or turn the key in the door to lock all doors and the rear lid.

• Locking from the outside carelessly or without good visibility may lead to bruising, particularly in the case of children.

• When locking a vehicle, never leave children unaccompanied inside, as from the outside it will be difficult to provide assistance if required.

• Having the doors locked prevents intruders from getting in, for example when stopped at a traffic light.

i Note

For anti-theft security, only the driver door is fitted with a lock cylinder.

"Safe" security system**

This is an anti-theft device which consists of a double lock for the door locks and a deactivation function for the boot in order to prevent forced entry.

Activation

The "safe" system is activated when the vehicle is locked using the key or the remote control.

To activate it with the key, rotate once it is inserted in the door lock cylinder in the locking direction.

To activate the system using the remote control, press the lock button once $\widehat{\textbf{()}}$ on the remote.

Once this system is activated, opening doors from the outside and the inside is not possible. The rear lid can not be opened. The central lock button does not work.

When the ignition is switched off, the instrument panel display indicates that the "Safe" system is on.

Deactivation

Rotate the key inserted in the lock cylinder twice towards the locking direction.

To activate the system using the remote control, press the lock button on the remote twice (a) in less than five seconds.

Opening and closing

On deactivating the "Safe" system, the alarm volumetric sensor is also deactivated.

With the "Safe" switched off, doors can be opened from the interior but not from the exterior.

See "Selective unlocking system*"

"Safe" status

On the driver door, there is warning lamp visible from outside the vehicle through the window which shows the "Safe" system status.

We will know that "Safe" system is activated by the flashing warning lamp. The indicator will flash on all vehicles, fitted and nor fitted with an alarm, until they unlock.

Remember:

Safe activated with or without an alarm: warning lamp flashes continuously.

Safe deactivated without an alarm: the warning lamp stays off.

Safe deactivated with an alarm: the warning lamp stays off.

▲ WARNING

No one should remain inside the vehicle if the "Safe" system is activated because opening the doors will not be possible in the event of an emergency neither from the inside nor the outside and help from the outside is made difficult. Danger of death. Passengers could become trapped inside in case of emergency.

Selective unlocking system*

This system allows to unlock either just the driver door or all the vehicle.

Driver door unlock button

Unlock once. Use either the key or the remote control.

Once the key is inserted in the lock cylinder, rotate once in the unlock direction. The driver door will remain without "Safe" and unlocked. In vehicles fitted with an alarm, see the Anti-theft Alarm section » page 111.

Using the remote control, press the unlock button on the remote (2) once. The "Safe" system for all the vehicle is deactivated, only the driver door is unlocked and both the alarm and the warning lamp are also turned off.

Unlocking all doors and the luggage compartment

The unlock button on the remote control must be pressed twice (2) so that all doors and the luggage compartment can be opened.

Press twice within 5 seconds to deactivate the "Safe" system for all vehicle, to unlock all

doors and to use the luggage compartment. The warning lamp and the alarm (only vehicles fitted with one) are turned off.

Unlocking the luggage compartment

See »» 🔁 page 9.

Activating the selective unlocking system*

With the door open, insert a key into the start cylinder and start the ignition. Insert the other key into the driver door lock and turn in the opening direction for at least 3 seconds. The turn signals will flash twice.

Deactivating the selective unlocking system*

With the door open, insert a key into the start cylinder and start the ignition. Insert the other key into the driver door lock and turn in the locking direction for at least 3 seconds. The turn signals will flash once.

Self-locking system to prevent involuntary unlocking

It is an anti-theft system and prevents the unintentional unlocking of the vehicle.

If the vehicle is unlocked and none of the doors (including the boot) are opened within 30 seconds, it re-locks automatically.

Automatic speed-dependent locking and unlocking system*

This is a safety system which prevents access to the vehicle from the outside when it is running (e.g. when stopped at a traffic light).

Locking

The doors will lock automatically if the speed of 15 km/h (9 mph) is exceeded. The rear lid will lock automatically if the speed of 6 km/h (4 mph) is exceeded.

If the vehicle is stopped and any of its doors open, when starting again and exceeding the mentioned speed, all doors will lock again.

Unlocking

On withdrawing the ignition key, the vehicle will returns to its status prior to self-locking.

Each door can be unlocked and opened independently from the inside (for example, when a passenger gets out). To do it, simply operate the lever inside the door.

Activating the system*

With the ignition on, press the locking key on the central locking system within 3 to 10 seconds.

Deactivating the system*

With the ignition on, press the unlocking key on the central locking system within 3 to 10 seconds.

In both cases, if the operation has been carried out correctly, the locking lamp will flash (a) **w Fig. 119**.

∆ WARNING

The door handles must not be operated when the vehicle is running: the door would open.

i Note

If the airbags are triggered during an accident, the vehicle is unlocked, except for the luggage compartment. It is possible to lock the vehicle from inside with the central locking, after turning the ignition off and back on again.

Central lock button*





Read the additional information carefully

The central lock button allows you to lock and unlock the vehicle from the inside.

The central lock button also works with the ignition switched off, except when the "safe" system is activated.

Please note the following if you lock your vehicle with the central lock button:

- Locking the doors and rear lid prevents access from the *outside* (for safety reasons, e.g. when stopped at a traffic light).
- The driver door cannot be locked while it is open. This avoids the user from forgetting his key inside the vehicle.

Opening and closing

• All doors can be unlocked separately from inside the vehicle. Do this by pulling the door release lever *once*.

▲ WARNING

- If the vehicle is locked, children and disabled people may be trapped inside it.
- Repeated operation of central locking will prevent the central lock button from working for a few seconds. Then, it can only be unlocked in case it has been previously locked. After few seconds, the central locking becomes operative again.
- The central lock button is not operative when the vehicle is locked from the outside (with the remote control or the key).

i Note

- Vehicle locked, 🔒 button.
- Vehicle unlocked, 🕝 button.

Childproof lock

✓ Valid for vehicles: 5-door versions



Fig. 120 Childproof lock on the left hand side door.

The childproof lock prevents the rear doors from being opened from the inside. This system prevents minors from opening a door accidentally while the vehicle is running.

This function is independent of the vehicle electronic opening and locking systems. It only affects rear doors. It can only be activated and deactivated manually, as described below:

Activating the childproof lock

- Unlock the vehicle and open the door in which you wish to activate the childproof lock.
- With the door open, rotate the groove in the door using the ignition key, anti-clockwise for the left-hand side doors **>>> Fig. 120**

and clockwise for the right-hand side doors.

Deactivating the childproof lock

- Unlock the vehicle and open the door whose childproof lock you want to deactivate.
- With the door open, rotate the groove in the door using the ignition key, anti-clockwise for the right-hand side doors, and clockwise for the left-hand side doors
 >> Fig. 120.

Once the childproof lock is activated, the door can only be opened from the outside. The childproof lock can be activated or deactivated by inserting the key in the groove when the door is open, as described above.

Keys

Set of keys



The set of keys may consists of the following, depending on the version of your vehicle:

- a remote control key **>>> Fig. 121** (A)
- a key without remote control (B),
- a plastic key tab* 🔘.

or

- two keys without remote control (B)
- a plastic key tab* C.

Duplicate keys

If you need a replacement key, go to a Technical Service with your vehicle identification number.

A WARNING

• An incorrect use of the keys can cause serious injuries.

 Never leave children or disabled persons in the vehicle. In case of emergency, they may not be able to leave the vehicle or manage on their own.

 An uncontrolled use of the key could start the engine or activate any electric equipment (e.g. electric windows), causing risk of accident. The doors can be locked using the remote control key. This could become an obstacle for assistance in an emergency situation.

 Never forget the keys inside the vehicle. An unauthorised use of your vehicle could result in injury, damage or theft. Therefore always take the key with you when you leave the vehicle.

• Never remove the key from the ignition if the vehicle is in motion. Otherwise, the steering could suddenly block and it would be impossible to steer the vehicle.

① CAUTION

There are electronic components in the remote control key. Avoid wetting and hitting the keys.

Radio frequency remote control*

Unlocking and locking the vehicle



Fig. 122 Assignment of buttons on the remote control key.



Fig. 123 Range of the radio frequency remote control.

Advic

Opening and closing

The radio frequency remote control key is used to lock and unlock the vehicle from a distance.

By using button (4) ***** Fig. 122** on the control, the key shaft is released.

Unlocking the vehicle 🕑 >>> Fig. 122 (1).

Locking the vehicle 🛛 🐝 Fig. 122 (2).

Unlocking the rear lid. Press button **>>> Fig. 122** ③ until all the turn signals on the vehicle flash briefly. When the unlocking button ③ ③ is pressed, you have 2 minutes to open the door. Once this time has passed, it will lock again.

Moreover, the battery indicator on the key **>>> Fig. 122** (arrow), will flash.

The remote control transmitter and the batteries are integrated in the key. The receiver is inside the vehicle. The maximum range depends on different factors. The range is reduced as the batteries start to lose power.

▲ WARNING

Read and observe the relevant warnings >>> \triangle in Set of keys on page 110.

i Note

• The radio frequency remote control key functions only when you are within range >>> Fig. 123. If the vehicle cannot be unlocked or locked by using the radio frequency remote control, the remote control key will have to be resynchronised. For this, go to your technical services.

Replacing the battery

If the battery indicator does not flash when the buttons are pushed, the battery must be replaced.

() CAUTION

The use of inappropriate batteries may damage the radio frequency remote control. For this reason, always replace the dead battery with another of the same size and power.

$\,\,{\ensuremath{\mathfrak{B}}}\,$ For the sake of the environment

Used batteries must be disposed of at an appropriate waste facility or through an authorised service, given that their components can affect the environment.

Synchronising the remote control key

If it is not possible to unlock or lock the door with the remote control, it should be resynchronised.

While the vehicle is open:

- Press the button 2 >>> Fig. 122 on the remote control.
- Then close the vehicle using the key shaft within one minute.

While the vehicle is closed:

- Press the button Fig. 122 on the remote control.
- Then close the vehicle using the key shaft within one minute.

It is possible that the vehicle could no longer be opened and closed with the remote control if the button *i* is repeatedly pressed outside of the effective range of the radio frequency remote control. The remote control key will have to be resynchronised.

Spare remote control keys are available at your Technical Service, where they must be matched to the locking system.

Up to five remote control keys can be used.

Anti-theft alarm*

Description of anti-theft alarm system*

The anti-theft alarm makes it more difficult to break into the vehicle or steal it. The system

will initiate acoustic and optical warning signals when your vehicle is tried to be forced.

The anti-theft alarm system is automatically switched on when locking the vehicle. The system is immediately activated and the turn signal light located on the driver door will flash along with the turn signals, indicating that the alarm and the locking security system (double lock) have been turned on.

If any of the doors or the bonnet are open, they will not be included in the protection zones of the vehicle when the alarm is connected. If the door or the bonnet are subsequently closed, they will be automatically included in the protection areas of the vehicle and the turn signals will flash accordingly when the doors close.

- The turn signal light will flash twice on opening and deactivating the alarm.
- The turn signal light will flash once on closing and activating the alarm.

When does the system trigger an alarm?

The system triggers an alarm, if the following unauthorised actions are carried out when the vehicle is locked:

• Mechanical opening of the vehicle with the vehicle key without switching on the ignition in the next 15 seconds (in certain markets,

such as the Netherlands, the alarm is activated immediately).

- A door is opened.
- Opening the bonnet.
- The rear lid is opened.

• Ignition switched on with a non-validated key.

• Movements in the driving compartment (vehicles with a volume sensor).

- Towing of the vehicle¹⁾.
- Vehicle tilt angle¹⁾.
- Undue manipulation of the alarm.
- Battery handling.

In this case, the acoustic signals will go off and the turn signal will flash for approximately 30 seconds. This cycle may be repeated up to 10 times depending on the country.

Opening all the doors in manual mode

In vehicles without an alarm, when opening the driver door manually, all doors are opened.

How to switch the alarm off

To deactivate the anti-theft alarm, turn the key in the opening direction, open the door

and switch the ignition on, or press the unlock button O on the remote control.

In vehicles equipped with an anti-theft alarm system, you have 15 seconds to insert the key in the ignition lock and activate the ignition if the vehicle is opened using the driver door key.

Otherwise, the alarm will trigger for 30 sec. and the ignition will be blocked.

i Note

- After 28 days, the indicator light will be switched off to prevent the battery from draining if the vehicle has been left parked for a long period of time. The alarm system remains activated.
- The alarm will trigger again if attempts are made to open another protection zone.
- The alarm system can be activated or deactivated using the radio frequency remote control» page 110.
- The anti-theft alarm is not activated when the vehicle is locked from within using the central locking button (a).
- If the vehicle battery is run down or flat then the anti-theft alarm will not operate correctly.
- Vehicle monitoring remains active even if the battery is disconnected or not working for any reason.

Opening and closing

• The alarm is triggered immediately if one of the battery cables is disconnected while the alarm system is active.

Vehicle interior monitoring and antitow system*

Monitoring or control function incorporated in the anti-theft alarm* which detects unauthorised vehicle entry by means of ultrasound.

Activation

 It is automatically switched on when the anti-theft alarm is activated.

Deactivation

- Open the vehicle with the key, either mechanically or by pressing the *i* button on the remote control. The time period from when the door is opened until the key is inserted into the contact should not exceed 15 seconds, otherwise the alarm will be triggered.
- Press the button (a) on the remote control twice. The volumetric sensor and tilt sensors will be deactivated. The alarm system remains activated.

The vehicle interior monitoring and the antitow system are automatically switched on again next time the vehicle is locked. The vehicle interior monitoring and anti-tow sensor (tilt sensor) are automatically switched on when the anti-theft alarm is switched on. In order to activate it, all the doors and the rear lid must be closed.

If you wish to switch off the vehicle interior monitoring and the anti-tow system, it must be done each time that the vehicle is locked; if not, they will be automatically switched on.

The vehicle interior monitoring and the antitow system should be switched off if animals are left inside the locked vehicle (otherwise, their movements will trigger the alarm) or when, for example, the vehicle is transported or has to be towed with only one axle on the ground.

False alarms

Interior monitoring will only operate correctly if the vehicle is completely closed. Please observe related legal requirements.

The following cases may cause a false alarm:

- Open windows (partially or fully),
- Tilting panoramic sunroof open (partially or completely),

• Movement of objects inside the vehicle, such as loose papers, items hanging from the rear vision mirror (air fresheners), etc.

i Note

• If the vehicle is relocked and the alarm is activated without the volumetric sensor function, relocking will activate the alarm with all its functions, except the volumetric sensor. This function is reactivated when the alarm is switched on again, unless it is deliberately switched off.

- If the alarm has been triggered by the volumetric sensor, this will be indicated by a flashing of the warning lamp on the driver door when the vehicle is opened. The flash is different to the flash indicating the alarm is activated.
- The vibration of a mobile phone left inside the vehicle may cause the vehicle interior monitoring alarm to trigger, as both sensors react to movements and shakes inside the vehicle.

• If on activating the alarm, any door or the rear lid is open, only the alarm will be activated. The vehicle interior monitoring and the anti-tow system will only be activated once all the doors are closed (including the rear lid).

Boot hatch

Opening and closing

Read the additional information carefully >>> 🗁 page 9

»

🛆 WARNING

• Always close the rear lid properly. Risk of accident or injury.

• The rear lid must not be opened when the reverse or rear fog lights are lit. This may damage the tail lights.

• Do not close the rear lid by pushing it down with your hand on the rear window. The glass could smash. Risk of injury!

• Ensure the rear lid is locked after closing it. If not, it may open unexpectedly while driving.

• Never allow children to play in or around the vehicle. A locked vehicle can be subjected to extremely high and low temperatures, depending on the time of year, thus causing serious injuries/illness. It could even have fatal consequences. Close and lock both the rear lid and all the other doors when you are not using the vehicle.

• Closing the rear lid without observing and ensuring it is clear could cause serious injury to you and to third parties. Make sure that no one is in the path of the rear lid.

• Never drive with the rear lid open or halfclosed, exhaust gases may enter into the interior of the vehicle. Danger of poisoning!

• If you only open the rear lid, do not leave the key inside. The vehicle cannot be opened if the key is left inside.

Electric windows

Opening and closing of the electric windows*




Fig. 124 Detail of the driver door: controls for the front and rear windows (5-door vehicles with front and rear electric windows).

Read the additional information carefully

The front and rear electric windows can be operated by using the controls on the driver door. The other doors each have a switch for their own window.

Always close the windows fully if you park the vehicle or leave it unattended $\gg \Delta$.

You can use the electric windows for approx. 10 minutes after switching off the ignition if neither the driver door nor the front passenger door has been opened and the key has not been removed from the ignition. Safety switch not pressed: buttons on rear doors are activated.

Safety switch pressed: buttons on rear doors are deactivated.

Observe the safety warnings »» A in Set of keys on page 110.

• Incorrect use of the electric windows can result in injury.

 Never close the rear lid without observing and ensuring it is clear, to do otherwise could cause serious injury to you and third parties. Make sure that no one is in the path of a window.

• If the ignition is switched on, the electric equipment could be activated with risk of injury, for example, in the electric windows.

- The doors can be locked using the remote control key. This could become an obstacle for assistance in an emergency situation.
- Therefore always take the key with you when you leave the vehicle.
- The electric windows will work until the ignition has been switched off and one of the front doors has been opened.

• If necessary, use the safety switch to disable the rear electric windows. Make sure that they have been disabled.

Opening and closing

i Note

If the window is not able to close because it is stiff or because of an obstruction, the window will automatically open again >>> page 115. If this happens, check why the window could not be closed before attempting to close it again.

One-touch opening and closing*

One-touch opening and closing means you do not have to hold down the button.

Buttons **» Fig. 124** (1), (2), (4) and (5) have two positions for opening windows and two for closing them. This makes it easier to open and close windows to the desired position.

One-touch closing

 Pull up the window button briefly up to the second position. The window closes fully.

One-touch opening

 Push down the window button briefly up to the second position. The window opens fully.

Resetting one-touch opening and closing

 The automatic open and close function will not work if the battery has been temporarily disconnected. The function can be restored as follows:

- Close the window as far as it will go by lifting and holding the electric window switch.
- Release the switch and then lift it again for 1 second. This will re-enable the automatic function.

If you push (or pull) a button to the first stage, the window will open (or close) until you release the button. If you push or lift the button briefly to the second stage, the window will open (one-touch opening) or close (one-touch closing) automatically. If you operate the button while the window is opening or closing, it stops at this position.

Roll-back function

The roll-back function reduces the risk of injury when the electric windows close.

- If a window is obstructed when closing automatically, the window stops at this point and lowers immediately \mathfrak{W} Δ .
- Next, check why the window does not close before attempting it again.
- If you try within the following 10 seconds and the window closes again with difficulty or there is an obstruction, the automatic closing will stop working for 10 seconds.
- If the window is still obstructed, the window will stop at this point.

• If there is no obvious reason why the window cannot be closed, try to close it again by pulling the tab within ten seconds. The window closes with maximum force. **The rollback function is now deactivated.**

If more than 10 seconds pass, the window will open fully when you operate one of the buttons. One-touch closing is reactivated.

🛆 WARNING

- Incorrect use of the electric windows can result in injury.
- Always take the ignition key with you when leaving the vehicle, even if you only intend to be gone for a short time. Please ensure that children are never left alone inside the vehicle.
- The electric windows will work until the ignition has been switched off and one of the front doors has been opened.
- Closing the windows without observing and ensuring it is clear could cause serious injury to you and third parties. Make sure that no one is in the path of a window.
- Never allow people to remain in the vehicle when you close the vehicle from the outside. The windows cannot be opened even in an emergency.
- The roll-back function does not prevent fingers or other parts of the body getting pinched against the window frame. Risk of accident.

Convenience opening/closing*

Using the door lock*

- Hold the key in the door lock of the driver door in either the locking or the unlocking position until all windows are either opened or closed.
- Release the key to interrupt this function.

Using the remote control

- Keep the locking/unlocking button pressed for the electric window risers to open/close; if you stop pressing the button, the window raising/lowering function is stopped.
- If the automatic raising is stopped and immediately after, the opening button is kept pressed, the window risers will lower.
- Once the windows are completely closed, the turn signals will flash.

Tilting panoramic roof*

Opening or closing of the tilting panoramic roof

Read the additional information carefully

The panoramic/tilting sunroof is opened and closed by using the switch when the ignition is switched on.

Always close the panoramic/tilting sunroof fully if you park the vehicle or leave it unattended \mathfrak{W} .

The tilting sunroof can be operated for up to about ten minutes after the ignition has been switched off, provided the driver door and the front passenger door are not opened.

Sun visor

The sun visor is opened and closed manually (independently of the panoramic/tilting sunroof).

- Incorrect use of the tilting sunroof can result in injury.
- Never close the tilting sunroof without first checking that there are no obstructions. Risk of serious injury to you or others. Make sure that no one is in the path of the tilting sunroof.

• Always take the vehicle key with you when you leave the vehicle.

 Never leave children or disabled persons in the vehicle, particularly if they have access to the keys. Unsupervised use of a key could mean that the engine is started or that electrical equipment is used (e.g. electric tilting sunroof) with a risk of accident. The doors can be locked using the remote control key. This could become an obstacle for assistance in an emergency situation.

- The tilting sunroof continues to function until one of the front doors is opened and the key removed from the ignition.
- Ensure that no object and/or end is between the glass and the sunroof when the one-touch opening/closing function is reset.

Convenience closing*

Using the door lock

- Hold the key in the door lock of the driver door in the locking position until the tilting sunroof is closed.
- Release the key to interrupt this function.

Using the remote control

- Push the lock button on the remote control for approximately 3 seconds. The tilting sunroof closes.
- Press the unlock button to interrupt the function.


Roll-back function of the tilting panoramic sunroof*

The tilting panoramic sunroof has a *roll-back function* which prevents larger objects getting trapped when the roof is closed. The rollback function does not prevent fingers getting pinched against the roof opening. The tilting sunroof stops and opens again immediately if it is obstructed when closing.

Lights and visibility

Lights

Control lamps



¢¢

It lights up

Left or right turn signal.

The control lamp flashes twice as fast when a turn signal is faulty.

It lights up

Main beam on or flasher on >>> page 119.

Several warning and control lamps light up for a few seconds when the ignition is switched on, signalling that the function is being verified. They will switch off after a few seconds.

A WARNING

Observe the safety warnings » ▲ in Warning symbols on page 99.

Switching lights on and off

Read the additional information carefully

The legal requirements regarding the use of vehicle lights in each country must be observed.

The driver is personally responsible for the correct use and adjustment of the lights in all situations.

Never drive with just the side lights on, there is a risk of accident. The side lights are not bright enough to illuminate the road ahead and to ensure that other road users are able to see you. Always use your dipped beam headlights if it is dark or if visibility is poor.

i Note

• The dipped beam headlights will only work with the ignition on. The side lights come on automatically when the ignition is turned off.

- If the lights are left on after the key has been taken out of the ignition lock, an audible warning sounds while the driver door remains open. This is a reminder to switch the lights off.
- The rear fog light can dazzle drivers behind you. You should use the rear fog light only when visibility is very poor. For this reason, when you exceed approximately 60 km/h (38

mph), a warning will appear on the instrument panel: Turn off the fog light!.

• The use of the lighting described here is subject to the relevant statutory requirements.

Automatic lighting*

Activation

 Rotate the switch to the AUTO position, this indication will light up.

Deactivation

- Turn the light switch to **0**.

Automatic lighting

If automatic headlight control is switched on, dipped beam headlights are automatically switched on by a photosensor if you drive into a tunnel, for example.

▲ WARNING

• Even if the automatic headlight control is switched on, the dipped beam headlights will not be switched on with fog. Therefore, the dipped beam must be switched on manually.

i Note

• For those vehicles with the automatic headlight system, when the key is removed from the ignition, the audible warning will only sound if the light knob is in position $\Im \ll$ or $\mathbb{S}\mathbb{D}$.

 If the daylight driving automatic light function is switched on, the front fog lights or rear fog light cannot be switched on in addition.

• The use of the lighting described here is subject to the relevant statutory requirements.

• Do not put stickers on the windscreen in front of the sensor. This may cause disruptions or faults in the automatic lighting system.

 The rain sensor switches on the dipped beam headlights when the windscreen wipers have been operating continuously for a few seconds and it switches the lights off when the continuous or interval wipe is switched off for some minutes.

Daytime running lights

📂 » table on page 2

The daytime running lights are enabled automatically when the ignition is switched on.

Daytime running lights are signalling devices for improving road safety. The lights are built into the headlights and come on each time the ignition is turned on if the light switch is in position **0** or **AUTO**. It is automatically switched off when the dipped beam lights are turned on.

The side lights or daytime driving lights are not bright enough to illuminate the road ahead and to ensure that other road users are able to see you.

- Always use your dipped beam head lights if it is raining or if visibility is poor.
- The rear lights do not come on with the daytime driving light. A vehicle which does not have the rear lights on may not be visible to other drivers in the darkness, if it is raining or in conditions of poor visibility.

i Note

See legal requirements for each country.

Fog lights



Lights and visibility

Switching on the front fog lights*

• Turn the switch from position **AUTO** ≫< or **g** to the first stop and pull it. The symbol ‡0 in the light switch lights up.

Switching on the rear fog light (vehicles with front fog lights)

• Turn the lights control from position AUTO ⇒ or *§*○ to the second stop and pull it **>> A** in **Switching lights on and off on page 117**. A lamp on the control and warning lamps panel lights up.

Switching on the rear fog light (vehicles with no front fog lights)

• Turn the light control to the end from position ≫ or © and pull it. A lamp on the control and warning lamps panel lights up.

Turn signal and main beam lever

Read the additional information carefully

Parking lights P€

• Switch the ignition off and remove the key from the lock.

• Move the turn signal lever up or down to turn the right or left-hand parking lights on, respectively.

Convenience turn signals

For the convenience turn signals, move the lever as far as possible upwards or downwards and release the lever. The turn signal will flash three times.

The convenience turn signals are activated and deactivated in the Easy Connect system via the (MR) key and the (Setup) function button » page 99.

In vehicles that do not have the corresponding menu, this function can be deactivated in a specialised workshop.

The main beam can dazzle other drivers. Risk of accident! Never use the main beam headlights or the headlight flasher if they could dazzle other drivers.

i Note

 If the convenience turn signals are operating (three flashes) and the other convenience turn signals are switched on, the active part stops flashing and only flashes once in the new part selected.

• The *turn signals* only work when the ignition is switched on. The corresponding warning lamp \diamondsuit or \diamondsuit flashes in the instrument panel. The control lamp \diamondsuit flashes when the turn signals are operated, provided a trailer is correctly attached and connected to the vehicle. If a turn signal bulb is defective, the control lamp flashes at double speed. If the trailer turn signal bulbs are defective, the control lamp $^{\rm oto}$ does not light up. Change the bulb.

• The main beam headlights can only be switched on if the dipped beam headlights are already on. The warning lamp ID then comes on in the instrument panel.

• The *headlight flasher* comes on for as long as you pull the lever – even if no other lights are switched on. The warning lamp \mathbb{E} then comes on in the instrument panel.

• When the *parking lights* are switched on, the headlight and the tail light on the corresponding side of the vehicle light up. The parking lights will only work if the key is removed from the ignition. If said light is on, an audible warning will be emitted while the driver door is open.

• If the turn signal lever is left on after the key has been taken out of the ignition lock, an acoustic signal sounds when the driver door is opened. This is intended as a reminder to switch off the turn signal, unless you wish to leave the parking light on.

Coming Home/Leaving Home Function*

The Coming Home function is controlled manually. The Leaving Home function is controlled with a photosensor.

If the Coming Home or Leaving Home function is connected, the front side and dipped >>>

lights, the tail lights and the number plate light will light up to provide assistance.

Coming home function

The Coming Home function is activated by switching off the ignition and briefly flashing the lights. When the driver door is opened, the Coming Home lighting comes on. If the driver door is already open when the lights are flashed briefly, the Coming Home lighting comes on **immediately**.

When the last door of the vehicle or the rear lid is closed, the Coming Home function starts and the switching off the headlights is delayed.

The Coming Home lighting switches off in the following cases:

• On completion of the time period established for the delay in switching off the lights after all the vehicle doors and the rear lid have been closed.

• If, 30 seconds after being connected, any doors or the rear lid remain open.

- If the light switch is turned to position **0**.
- If the ignition is switched on.

Automatic Leaving Home function

The Leaving Home function is activated when the vehicle is unlocked if:

• the light control is in position AUTO and

• the photosensor detects "darkness".

The Leaving Home lighting switches off in the following cases:

- If the time period for the delay in switching off the headlights has ended
- If the vehicle is locked again.
- If the light switch is turned to position **0**.
- If the ignition is switched on.

Manual Leaving Home function

In vehicles without an automatic headlight system (light sensor), if the manual Coming Home function is activated when leaving the car, upon returning to the car and unlocking it the manual Leaving Home function will be activated automatically.

i Note

 To activate the Coming/Leaving home function, the rotary light switch must be in position AUTO and the light sensor must detect darkness.

 If the ignition key is removed while the lights are on, the lights flash briefly and the driver door opens, no audible warning is heard, since with the Coming Home function on, the lights are automatically switched off after a period of time (except when the light switch is in position »< or gD.

Adaptive headlights* (for driving round bends)




Fig. 126 Cornering lighting using adaptive headlights.

When driving around bends, the headlights will light the most important areas of the road.

This cornering light gives better illumination of the side of the road and the corner area. The dynamic lighting is controlled automatically according to speed and the steering wheel angle.

The two main headlights move at different angles to avoid that the front of the vehicle is left completely in the dark.

i Note

The system operates from a speed of about 10 km/h (6 mph).

Lights and visibility

Fog lights with cornering function*

This is an additional light source to dipped beam headlights to light up the road as a bend is taken.

The cornering light operates with the lights switched on and when driving at less than 40 Km/h (25 mph). Ignition occurs by turning the steering or connecting the turn signal.

Forward gear

- If the steering wheel is turned to the right, or the right-hand turn signal operated, the right-hand fog light turns on.
- If the steering wheel is turned to the left, or the left-hand turn signal operated, the lefthand fog light turns on.

In reverse, both fog lights turn on.

i Note

When the fog lamps are on, the cornering function is activated and both headlights are continuously on.

Instrument and switch lighting, headlight range control



Fig. 127 Dash panel: headlight range control

Instrument and switch lighting

The lighting level of instruments, controls and displays can be adjusted through the infotainment system with the CAR button and the (SETUP) function button **>>** 24.

The instrument lighting (some dials and needles), the centre console lighting and the lighting of the displays are regulated by a photodiode incorporated in the instrument panel.

The instrument lighting (needles) is switched on when the ignition is on and the **light is off**. The instrument lighting is dimmed automatically as the daylight starts to fade. It goes out completely when ambient light is very low. This function is intended to remind the driver to switch on the dipped beam headlights in good time when light conditions become poor.

Headlight range control

By using the electrical headlight range control you can adjust the headlight range to the load level that is being carried in the vehicle **» Fig. 127**. This way, it is possible to avoid dazzling oncoming traffic more than necessary. At the same time, by using the correct headlight settings, the driver has the best possible lighting for the road ahead.

The headlights can only be adjusted when the dipped beam is switched on. Turn the wheel downwards to lower the headlight beam from the basic setting **0**.

Dynamic headlight range control

Vehicles with gas discharge bulbs (xenon bulbs) are equipped with dynamic headlight range control. When you switch on the lights, their range regulates itself according to the vehicle load.

Vehicles with gas discharge bulbs do not have headlight range control.

Hazard warning lights 🛆

Read the additional information carefully

The hazard warning lights are used to draw the attention of other road users to your vehicle in emergencies.

If your vehicle breaks down:

- 1. Park your vehicle at a safe distance from moving traffic.
- Press the button to switch on the hazard warning lights » ▲.
- 3. Switch the ignition off.
- 4. Apply the handbrake.
- 5. For a manual gearbox, engage 1st gear; for an automatic gearbox, move the gear lever to **P**.
- 6. Use the warning triangle to draw the attention of other road users to your vehicle.
- 7. Always take the vehicle key with you when you leave the vehicle.

All turn signals flash simultaneously when the hazard warning lights are switched on. The two turn signal turn signal lamps $\langle \neg \beta \rangle$ and the turn signal lamp in the switch \triangle will flash at the same time. The simultaneous hazard warning lights also work when the ignition is switched off.

∆ WARNING

• The risk of an accident increases if your vehicle breaks down. Always use the hazard warning lights and a warning triangle to draw the attention of other road users to your stationary vehicle.

• Due to the high temperatures that the catalytic converter can reach, never park in an area where the catalytic converter could come into contact with highly inflammable materials, for example dry grass or spilt petrol. This could start a fire.

i Note

• The battery will run down if the hazard warning lights are left on for a long time, even if the ignition is switched off.

• The use of the hazard warning lights described here is subject to the relevant statutory requirements.

Interior lights

Interior and reading lights

Read the additional information carefully >>> 🗁 page 23

Luggage compartment lighting

The light is activated when the rear lid is open, even when the ignition and lights are turned off. For this reason, ensure that the rear lid is always closed.

Glove compartment light

When opening the glove compartment on the passenger side, the glove compartment light will automatically turn on and will turn off upon closure.

Ambient light*

📂 » table on page 2

The ambient lighting lights up the central console area and the footwell area.

They will switch on fully when the doors are opened and will decrease in intensity while driving when the dipped beam headlight is on.

The intensity of the ambient light* can be adjusted using the Easy Connect menu (see Adjusting Lights > Interior lighting >> 12 page 24).

i Note

If not all the vehicle doors are closed, the interior lights will be switched off after approx. 10 minutes, providing the ignition key has been removed and the courtesy light position selected. This prevents the battery from discharging.

Lights and visibility

Visibility

Heated rear window



The heated rear window only works when the engine is running. When it is switched on, a lamp lights up on the switch.

After approximately 8 minutes, the heating device of the rear window switches off automatically.

* For the sake of the environment

The heated rear window should be switched off as soon as the glass is demisted. By saving electrical power you can also save fuel.

i Note

To avoid possible damage to the battery, an automatic temporary disconnection of this

function is possible, coming back on when normal operating conditions are re-established.

Sun visors




Fig. 129 Sun visor on the driver side.

The sun visors for the driver and the front passenger can be pulled out of their central supports and turned towards the doors in the direction of the arrow >>> Fig. 129. Never pull them downwards.

The driver sun visor has compartments for cards, and the passenger sun visor has a vanity mirror with a cover*.

i Note

Incorrect use of the sun visor (e.g. pulling them downwards once they are open) may result in broken hinges. This damage is not covered by the vehicle warranty.

Windscreen wiper and rear window wiper systems

Control lamp*





Windscreen wiper fluid level too low

This serves as a reminder to fill up the reservoir at the earliest opportunity >>> page 207.

Windscreen wipers

Read the additional information carefully »» 🔁 page 23

∧ WARNING

- Worn and dirty wiper blades reduce visibility and safety levels while driving.
- In cold conditions you should not use the wash/wipe system unless you have warmed the windscreen with the heating and ventilation system. The windscreen washer fluid could otherwise freeze on the windscreen and obscure your view of the road.
- Always note the corresponding warnings »» 🔁 page 54.

»

▲ WARNING

The rain sensor* may not detect enough rain to switch on the wipers.

• If necessary, switch on the wipers manually when water on the windscreen obstructs visibility.

() CAUTION

In icy conditions, always check that the wiper blades are not frozen to the glass before using the wipers for the first time. If you switch on the windscreen wipers when the wiper blades are frozen to the windscreen, you could damage both the wiper blades and the wiper motor.

i Note

• The windscreen wipers will only work when the ignition is switched on.

• The heat output of the heated jets* is controlled automatically when the ignition is switched on, depending upon the outside temperature.

 In certain versions of vehicles with alarms, the windscreen wiper will only work in interval/rain sensor mode when the ignition is on and the bonnet closed.

 When the interval wipe function is on, the intervals are directly proportional to the speed. This way, the higher the vehicle speed the shorter the intervals. If you stop the vehicle with the windscreen wiper in position 1 or 2, it will automatically change to a lower position speed. The set speed will be resumed when the vehicle pulls away.

• The windscreen will be wiped again after approximately five seconds once the "automatic wash/wipe system" has been activated, provided the vehicle is moving (drip function). If you activate the wipers less than 3 seconds after the drip function, a new wash sequence will begin without performing the last wipe. For the "drip" function to work again, you have to turn the ignition off and then on again.

• Do not put stickers on the windscreen in front of the rain sensor*. This may cause sensor disruption or faults.

Rear window wiper




Fig. 130 Windscreen wiper lever: rear window wiper.

Switching on the interval wipe

Press the lever forward to position 6
 >>> Fig. 130. The wiper will wipe the window approximately every 6 seconds.

Switching off the interval wipe function

 Pull the lever back from position 6 toward the steering wheel. The wiper will continue to function for a short period if you switch off whilst the wipers are in motion.

Switching on the window wiper and washer system

- Press the lever fully forwards to position (7)
 >>> Fig. 130. The wiper and washer operate at the same time. The rear window wash system will function as long as you hold the lever in this position.
- Release the lever. The washer system stops and the wipers continue until the end of the cycle.
- Move the lever towards the steering wheel to switch off.

- Worn and dirty wiper blades reduce visibility and safety levels while driving.
- Always note the corresponding warnings >>> 🗁 page 54.

Lights and visibility

() CAUTION

In icy conditions, always check that the wiper blade is not frozen to the glass before using the wiper for the first time. If you switch on the wiper when the wiper blade is frozen to the glass, this could damage both the wiper blade and the wiper motor.

i Note

• The rear window wiper will only work when the ignition is switched on.

 Depending on the version of the model, when you engage reverse gear and with the headlight wiper activated, this can start a wipe.

Headlight washer*

The headlight washers clean the headlight lenses.

The headlight washers are activated automatically when the windscreen washer is used and the window wiper lever is pulled towards the steering wheel for at least 1.5 seconds – provided the dipped beam headlights or main beams are switched on. Clean off stubborn dirt (insects, etc.) from the headlights at regular intervals, for instance when filling the fuel tank.

i Note

• To ensure that the headlight washers work properly in winter, keep the nozzle holders in the bumper free of snow and remove any ice with a de-icer spray.

• To remove water, the windscreen wipers will be activated from time to time, the headlight washers will be activated every three cycles.

Rear view mirrors

Interior mirror

It is dangerous to drive if you cannot see clearly through the rear window.

Interior mirror with automatic anti-dazzle function*

The anti-dazzle function is activated every time the ignition is switched on.

When the anti-dazzle function is enabled, the interior rear vision mirror will darken **auto-matically** according to the amount of light it receives. The anti-dazzle function is cancelled if reverse gear is engaged.

i Note

• The automatic anti-dazzle function will only work properly if the sun blind* for the rear window is retracted and there are no other objects preventing light from reaching the interior rear vision mirror.

• If you have to stick any type of sticker on the windscreen, do not do so in front of the sensors. Doing so could prevent the anti-dazzle function from working well or even from working at all.

Folding in the exterior mirrors manually

The exterior mirrors of the vehicle may be folded in. For this, press the mirror housing towards the vehicle.

i Note

Before washing the vehicle with an automatic car wash, fold in the exterior mirrors to avoid damage.

Electric exterior mirrors*



Fig. 131 Exterior mirror controls.

Read the additional information carefully

The exterior mirrors can be adjusted using the rotary knob in the driver door.

Basic setting of exterior mirrors

- Turn knob >>> Fig. 131 to position L (left exterior mirror).
- 2. Turn the rotary knob to position the exterior mirror so that you have a good view to the rear of the vehicle.
- 3. Turn the knob to position **R** (right exterior mirror).
- Swivel the rotary knob to position the exterior mirror so that you have a good view to the rear of the vehicle » ▲.

Heated exterior mirrors*

- Press the demisting button I >>> Fig. 128
- The mirrors demist for some minutes to prevent draining the battery unnecessarily.
- If necessary, press the button again to repeat the function.
- The exterior mirror heating is not activated in temperatures above approximately +20°C (+68°F).

Folding in the exterior mirrors electrically*

 Turn the control **>>** Fig. 131 to position fold in the exterior mirrors. You should always fold in the exterior mirrors if you are driving through an automatic car wash. This will help prevent damage.

Folding exterior mirrors back out to the extended position*

 Turn the knob to position L or R to return the exterior mirrors to their original position **≫** A.

▲ WARNING

• Convex or aspheric mirrors increase the field of vision however the objects appear smaller and further away in the mirrors. If you use these mirrors to estimate the distance to vehicles behind you when changing lane, you could make a mistake. Risk of accident.

- If possible, use the rear vision mirror to estimate distances to vehicles behind you.
- Make sure that you do not get your finger trapped between the mirror and the mirror base when folding back the mirrors. Risk of injury!

🏶 For the sake of the environment

The exterior mirror heating should be switched off when it is no longer needed. Otherwise, it is an unnecessary fuel waste.

i Note

- If the electrical adjustment ever fails to operate, the mirrors can be adjusted by hand by lightly pressing the edge of the mirror glass.
- In vehicles with electric exterior mirrors, the following points should be observed: if, due to an external force (e.g. being knocked while manoeuvring), the adjustment of the mirror housing is altered, the mirror will have to be fully folded electrically. Do not readjust the rear vision mirror housing by hand, as this will interfere with the mirror adjuster function.
- The rear vision mirrors can be adjusted separately or simultaneously, as described above.
- The fold-in function on the exterior mirrors will not activate at speeds over 40 km/h (25 mph).

Seats and head restraints

Adjusting the seat and head restraints

Adjusting the front seats

Read the additional information carefully

The safe driving chapter contains important information, tips, suggestions and warnings that you should read and observe for your own safety and the safety of your passengers »> page 56.

🛆 WARNING

 Never adjust the driver or front passenger seat while the vehicle is in motion. While adjusting your seat, you will assume an incorrect sitting position. Risk of accidents. Adjust the driver or front passenger seat only when the vehicle is stationary.

 To reduce the risk of injury to the driver and front passenger in case of a sudden braking or an accident, never drive with the backrest tilted towards the rear. The maximum protection of the seat belt can be achieved only when the backrests are in an upright position and the driver and front passenger have properly adjusted their seat belts. The further the

backrests are tilted to the rear, the greater the risk of injury due to improper positioning of the belt web!

- Exercise caution when securing the seat height into forwards/backwards position. Injuries can be caused if the seat height is adjusted without due care and attention.
- To move the seat forwards and backwards, pull upwards and not sideways on the lever, as the force exerted on it in that direction could damage it.

Folding and lifting the backrest of the front seats

✓ Applies to vehicles with 3 doors:



Fig. 132 Front seats: lever for folding down the backrest.

Read the additional information carefully

Vehicles without the Easy-Entry function

- To fold the backrest, pull the lever 1 upwards and push the backrest forwards.
- To **unfold** the backrest, push it back.

Vehicles with the Easy-Entry function

- To fold the backrest, pull the lever 1 upwards and push the backrest forwards. You can push the seat forwards at the same time to make entry to the rear seats easier.
- To **unfold** the backrest, first move the seat **completely** back.

The Easy-Entry function facilitates the access to the vehicle rear seats. Before lifting the backrest, return the seat to the original position. The seat inserts when the backrest is lifted.

Adjusting or disassembling the head restraints




Fig. 133 Adjusting and removing the head restraints.

Read the additional information carefully

Adjusting height (front seats)

- Press the button on the side and pull upwards to the desired position.
- To lower the head restraint, press the button and push head restraint downwards.
- Make sure that it engages securely into one of its positions.

Adjusting height (rear seats)

- Press the button on the side and pull upwards to the desired position.
- To lower the head restraint, press the button and push head restraint downwards.

 Make sure that the head restraint engages securely in one of its positions >>> page 60.

Removing the head restraint

- Push the head restraint up as far as it will go.
- Press the button **>>> Fig. 133** (arrow).
- Pull head restraint out of fitting without releasing the button.

Fitting the head restraint

- Insert the head restraint into the guides on the corresponding backrest.
- Push head restraint down.
- Adjust the head restraint to suit body size
 >>> page 60.

▲ WARNING

• Never drive if the head restraints have been removed. Risk of injury.

• Never drive if the head restraints are in an unsuitable position (the lowest position) as there is a risk of serious injury.

- After refitting the head restraint, you must always adjust it properly for height to achieve optimal protection.
- Please observe the safety warnings in »» in Correct adjustment of front head restraints on page 60.

i Note

- To fit and remove the rear head restraints, gently tilt the seat backrest forwards.
- When fitting the head restraints again, insert the tubes as far as possible into the guides without pressing the button.

Seat functions

Heated seats* 🚽



Fig. 134 Front seat heating switch.

The front seat cushions and backrests can be heated electrically.

- Press the corresponding switch **>>> Fig. 134** to switch on the seat heating.
- Press once to connect the heating at maximum force. The two LEDs illuminate
 >> Fig. 134. After 15 minutes of high

intensity, the upper LED goes out, the system is deactivated for 2 minutes and is then reactivated at low intensity (the lower LED remains on permanently).

- Press the switch again to set the heating to minimum force. (The lower LED lights up).
- To disconnect the heating, press the switch again.

() CAUTION

To avoid damaging the heating elements, please do not kneel on the seat or apply sharp pressure at a single point to the seat cushion and backrest.

i Note

The seats are only heated electrically when the engine is running.

Folding down the back seat



Fig. 135 Folding up the rear seat cushion.



Fig. 136 Button for unlocking the rear backrest.

Folding seat down

- Remove the head restraint >>> page 128.
- Pull the front edge of the seat cushion
 >> Fig. 135 (1) upwards in the direction of the arrow.

- Lift the cushion (2) forwards in the direction of the arrow.
- Pull the release button >>> Fig. 136 in the direction of the arrow and fold the backrest forwards.
- Insert the head restraints in the spaces on the rear of the seat cushion which are visible when the seat cushion is lowered.

Folding seat forward

- Remove the head restraints from the spaces in the seat cushion.
- Lift the backrest, and before securing it, replace the head restraints in the seat cushion, and then click the seat correctly onto the locking rails.
- Once the backrest is locked, pull on the central seat belt or directly on the backrest to check that the backrest has properly engaged in position.
- Check that the position lever is in neutral position.
- Lower the cushion and push it backwards below the seat belt buckles.
- Press the front part of the cushion downwards.

On split rear seats*, the backrest and cushion can be lowered and raised respectively in two sections.

▲ WARNING

• Please be careful when folding back the backrest! Injuries can be caused if the seat height is adjusted without due care and attention.

• Do no trap or damage seat belts when raising the backrest.

 After raising the backrest, check it has engaged properly in position. Do this by pulling on the central seat belt or directly on the backrest and check that the position lever is in the neutral position.

• The three point automatic seat belt only works correctly when the backrest of the central seat is correctly engaged.

Transport and practical equipment

Practical equipment

Glove compartment



Fig. 137 Passenger side: glove compartment.



Fig. 138 Glove compartment: storage compartment for instruction manual.

The compartment can be opened by pulling the lever **>>> Fig. 137**.

This compartment can hold documents in A4 format, a water bottle of 1.5 L, etc.

Depending on the vehicle equipment, the CD player is located in the glove compartment. Separate operating instructions are enclosed for this equipment in the corresponding Instruction Manual.

▲ WARNING

Always keep the storage compartment cover closed while the vehicle is in motion in order to reduce the risk of injury caused by a sudden braking or by an accident.

Storage compartment on the driver side



Fig. 139 Compartment on the driver side

Transport and practical equipment

Storage pocket in the seat*

There is a storage compartment on the driver side

Storage compartment under the front seats*



Fig. 140 Storage compartment under the right front passenger seat.

To open

- The compartment is opened by pulling on the lever and assisting it with your hand.

To close

 Press the cover inwards until the closed drawer "clicks" into position.

i Note

The storage drawer will hold a maximum weight of 1.5 kg.



Fig. 141 Storage pocket.

There is a storage pocket on the rear of the front seats.

Storage compartment in front door panel*

In this storage compartment a 1.5l water bottle, etc. can be stored.

Front drink holder*



Fig. 142 Front drink holders in the centre console.

In the central console, in front of the gear lever, there are two drinks holders **»** Fig. 142.

▲ WARNING

- Do not put hot drinks in the drink holders. During sudden or normal driving manoeuvres, when braking suddenly or in case of an accident, the hot drink could spill. Risk of scalding.
- Never use rigid materials (for example, glass or ceramic), since they could cause injury in the case of an accident.
- When travelling, the drinks holder should always be closed to prevent risk in the event of sudden breaking or accident.

Rear drink holder*



ng. 145 Dimonolation in the centre console.

On the rear part of the centre console, behind the handbrake, there is a drink holder* installed **»** Fig. 143.

This drinks holder has a capacity for a bottle of up to 1 litre.





Fig. 144 Front ashtray.

Opening and closing the ashtray

- To open the ashtray, lift the cover
 >> Fig. 144.
- To close, push the cover down.

Emptying the ashtray

- Extract the ashtray and empty it.

▲ WARNING

Never put paper in the ashtray. Hot ash could ignite the paper in the ashtray and cause a fire.

Cigarette lighter*



- Press on the cigarette lighter **»** Fig. 145 to activate it **»** A.
- Wait for the lighter to spring out.
- Pull out the cigarette lighter and light the cigarette on the glowing coil.

- Improper use of the cigarette lighter can lead to serious injuries or start a fire.
- Using the lighter carefully. Carelessness or negligence when using the cigarette lighter can cause burns and serious injuries.
- The lighter only works when the ignition is turned on or the engine is running. To avoid the risk of fire, never leave children alone inside the vehicle.

Transport and practical equipment

Electrical power socket




Fig. 146 Front power socket.

i Note

- The use of electrical appliances with the engine switched off will cause a battery discharge.
- Before using any electrical accessories, see the instructions in »» page 187.

Luggage compartment

Loading the luggage compartment



The 12 Volt cigarette lighter power socket can also be used for other electrical components with a power rating of up to 120 Watt. When the engine is switched off, however, the vehicle battery will discharge. For further information see **»** page 187.

The power sockets and the connected accessories will only operate when the ignition is on or when the engine is running. Improper use of the sockets or electrical accessories can lead to serious injuries or cause a fire. To avoid the risk of injury, never leave children alone inside the vehicle.

① CAUTION

Always use the correct type of plugs to avoid damaging the sockets.

Fig. 147 Position heavy items as far forward as possible.

All luggage and other loose objects must be safely secured in the luggage compartment. Unsecured objects which shift back and forth could affect safety or driving characteristics of the vehicle by shifting the centre of gravity.

Distribute the load evenly in the luggage compartment.

- Place heavy objects as far forward as possible in the luggage compartment
 » Fig. 147.
- Place the heavy objects first.
- Secure heavy objects to the fitted fastening rings* >>> page 134.
- Secure loose loads with a luggage net* or with non-elastic straps secured to the fastening rings*.

- Loose luggage and other objects in the luggage compartment could cause serious injuries.
- Always stow objects in the luggage compartment and secure them with the fastening rings*.
- During sudden manoeuvres or accidents, loose objects can be thrown forward, injuring vehicle occupants or even third parties. This increased risk of injury will be further increased if a loose object is struck by an inflating airbag. If this happens, objects may shoot outward like a missile. Risk of fatal injury.
- Always keep all objects in the luggage compartment and use appropriate grips to secure them, particularly in the case of heavy objects.
- Never exceed the allowed axle weights or allowed maximum weight. If said weights are exceeded, the driving characteristics of the

vehicle may change, leading to accidents, injuries and damage to the vehicle.

- Please note that the centre of gravity may shift when transporting heavy objects; this may affect vehicle handling and lead to an accident. Therefore, it is essential to adjust your speed and driving style accordingly, to avoid accidents.
- Never leave your vehicle unattended, especially when the rear lid is open. Children could climb into the luggage compartment, closing the door behind them; they will be trapped and run the risk of death.
- Never allow children to play in or around the vehicle. Close and lock all the doors and rear lid when you leave the vehicle. Before you lock the vehicle, make sure that there are no adults or children in the vehicle.
- Please observe the notes on the >>> page 56.

() CAUTION

Hard objects on the rear shelf could chafe against the wires of the heating element in the heated rear window and cause damage.

i Note

- The tyre pressure must be adjusted according to the load. When necessary check the tyre pressures on the label located on the inside fuel tank flap » page 210.
- Air circulation in the vehicle helps reduce fogging of the windows. Used air escapes

through ventilation slits in the side trim of the luggage compartment. Ensure that the ventilation slots are never covered.

• Straps for securing the load to the fastening rings* are commercially available from accessory shops.

Fastening rings*



Fig. 148 Location of fastening rings in luggage compartment.

There may be four fastening rings included in the luggage compartment for fastening luggage and other objects **»** Fig. 148 (arrows).

- Always use suitable and undamaged straps to secure luggage and other objects to the fastening rings »» ▲ in Loading the luggage compartment on page 133.
- Pull up the fastening rings to attach the straps.

Example: An object weighing 4.5 kg is lying unsecured in the vehicle. During a frontal collision at a speed of 50 km/h (31 mph), this object generates a force corresponding to 20 times its weight. That means that the effective weight of the object increases to approximately 90 kg. You can imagine the severity of the injuries which might be sustained if this "object" strikes an occupant as it flies through the interior of the vehicle. This increased risk of injury will be further increased if a loose object is struck by an inflating airbag.

▲ WARNING

- If pieces of baggage or other objects are secured to the fastening rings with inappropriate or damaged retaining cords, injuries could result in the event of braking manoeuvres or accidents.
- Never secure a child seat on the fastening rings.

Transport and practical equipment

Rear shelf



Fig. 149 Rear shelf

Removing the shelf

- Unhook the loops **>>> Fig. 149** (B) from housings (A).
- Extract the cover from its slot, in its rest position and pull outwards.

A WARNING

Do not place heavy or hard objects on the rear shelf, because they will endanger the vehicle occupants in case of sudden braking.

() CAUTION

- Before closing the rear lid, ensure that the rear shelf is correctly fitted.
- An overloaded luggage compartment could mean that the rear shelf is not correctly seated and it may be bent or damaged.

• If the luggage compartment is overloaded, remove the tray.

i Note

• Ensure that, when placing items of clothing on the luggage compartment cover, rear visibility is not reduced.

Roof rack/roof luggage rack*

Introduction

Please observe the following points if you intend to carry loads on the roof:

• For safety reasons, only luggage racks and accessories supplied by SEAT Official Services are recommended.

 It is essential that you follow the assembly instructions included with the bars exactly, being especially careful to position front and rear luggage compartment cover bars on the special housings in the longitudinal bars.
 You must also respect their position according to the direction of travel indicated in the assembly manual. Not following these instructions may damage the bodywork.

• Pay special attention to the tightening torque of the attachment bolts and check them following a short journey. If necessary, retighten the bolts and check them at regular intervals.

• Distribute the load evenly. A maximum load of 40 kg is permitted for each roof rack system support bar, the load must be distributed evenly along the entire length. However, the maximum load permitted for the entire roof (including the support system) of 75 kg must not be exceeded nor the total weight recommended for the entire vehicle. See the "Technical Data" section.

• When transporting heavy or large objects on the roof, any change in the normal vehicle behaviour due to a change in the centre of gravity or an increased wind resistance must be taken into account. For this reason, a suitable speed and driving style must be used.

• On vehicles fitted with a sliding/tilting sunroof*, make sure it does not hit the load on the roof upon opening.

Attach the cross bars of the roof carrier system




Fig. 150 Ibiza model: attachment points for the roof railings for the roof carrier system.



Fig. 151 Ibiza SC model: attachment points for the roof railings for the roof carrier system.

The crossbars are the basis of a series of special roof carrier systems. For safety reasons, special fixtures must be used to safely transport luggage, bicycles, skis, surf boards or boats on the roof. Suitable accessories can be acquired at SEAT dealerships.

Always secure the crossbars and the roof carrier system properly. Always take the assembly instructions that come with the crossbars and the roof carrier system in question into account.

Ibiza Model

The front and rear attachment points (1) and (2) are only visible when the doors are open **w** Fig. 150.

Ibiza SC Model

The front attachment points ① are only visible when the doors are open; the rear attachment points ③ are marked on the top edge of the side window with arrow heads **>>> Fig. 151**.

A WARNING

Incorrect attachment and use of the crossbars and the roof carrier system may cause the whole system to detach from the roof and cause an accident and injuries.

• Always take the manufacturer assembly instructions into account.

• Use only crossbars and the roof carrier system when they are in perfect condition and are properly secured.

• Secure the crossbars and the roof carrier system properly.

- Check threaded joints and attachments travelling and if necessary tighten them after you have travelled a short distance. When making long trips, check the threaded joints whenever you stop for a rest.
- Always fit the special roof carrier systems correctly for wheels, skis and surfboards, etc.
- Do not modify or repair the crossbars or roof carrier system.

i Note

Always read the assembly instructions that come with the crossbars and the roof carrier system carefully and keep them in the vehicle.

Air conditioning

Air conditioning

Heating, ventilation and cooling

General notes

Read the additional information carefully >>> 29 page 39

Pollution filter

The pollution filter (a combined particulate filter and active carbon filter) serves as a barrier against impurities in the outside air, including dust and pollen.

For the climate control system to work with maximum efficiency, the pollution filter must be replaced at the specified intervals in the Maintenance Programme.

If the filter loses efficiency prematurely due to use in areas reaching very high pollution levels, the pollen filter must be changed more frequently than stated in the Service Schedule.

▲ WARNING

Reduced visibility through the windows increases the risk of serious accidents.

• Always ensure that all windows are free of ice and snow, and that they are not fogged,

so as to maintain good visibility of everything outside.

 The maximum heat output required to defrost windows as quickly as possible is only available when the engine has reached its normal running temperature. Only drive when you have good visibility.

 Always ensure that you use the heating system, fresh air system, air conditioner and the heated rear window to maintain good visibility to the outside.

• Never leave the air recirculation on for a long period of time. If the cooling system is switched off and air recirculation mode switched on, the windows can mist over very quickly, considerably limiting visibility.

• Switch air recirculation mode off when it is not required.

Stuffy or used air will increase fatigue and reduce driver concentration possibly resulting in a serious accident.

 Never leave the fresh air fan turned off or use the air recirculation for long periods of time; the air in the vehicle interior will not be refreshed.

() CAUTION

• If you suspect that the air conditioner is damaged, switch it off with the $\overline{A/C}$ button to

prevent further damage and have it checked by a specialised workshop.

• Repairs to the air conditioner require specialist knowledge and special tools. Therefore, we recommend you to take the vehicle to a specialised workshop.

i Note

- If the humidity and temperature outside the vehicle are high, condensation can drip off the evaporator in the cooling system and form a pool underneath the vehicle. This is normal and does not indicate a leak.
- Keep the air intake slots in front of the windscreen free of snow, ice and leaves to ensure heating and cooling are not impaired, and to prevent the windows from misting over.
- The air from the vents flows through the vehicle interior and is extracted by slots in the luggage compartment designed for this purpose. Therefore, you should avoid obstructing these slots with any kind of object.
- The air conditioner operates most effectively with the windows and the sliding/tilting sunroof* closed. However, if the temperature inside the vehicle is excessive because of the sun, the air inside can be cooled faster by opening the windows for a short time.
- Do not smoke while air recirculation mode is on, as smoke drawn into the air conditioning system leaves residue on the evaporator, producing a permanent unpleasant odour.

»

• At low outside temperatures, the compressor switches off automatically and cannot be switched on even with the (AUTO) button.

 It is advisable to turn on the air conditioning at least once a month, to lubricate the system gaskets and prevent leaks. If a decrease in the cooling capacity is detected, a Technical Service should be consulted to check the system.


• To ensure correct operation, the grilles on both sides of the screen must not be obstructed.

• When the engine is under extreme strain, switch off the compressor for a moment.

Economic use of the air conditioning

When the air conditioning is switched on, the compressor consumes engine power and has influence on fuel consumption. Consider the following points in order to have the system operating in the minimum possible time. • If the vehicle interior has overheated due to an excessive solar radiation, it is best to open the windows or doors to allow the hot air to escape.

• While in motion, the air conditioning should not be switched on if the windows or the sunroof* are open.



Air outlets

Air conditioning


Air distribution

Symbol »» page 139	Main air output through out- lets
	1, 2
* <i>i</i>	5
*ی	1, 2, 5
ٹھ	3, 4

Outlets (3) and (4) can be closed or opened separately using the slats and the air flow directed as required.

Heating and fresh air

Controls



• Use turn controls (A), (B) and (C) >>> Fig. 153 to adjust the temperature, blower speed and air distribution.

• Press the () button to switch air recirculation mode on or off. When the function is activated, a warning light on the button is turned on.

Temperature

Switch (A) adjusts temperature. The desired temperature inside the vehicle cannot be lower than the ambient temperature. Maximum heat output, which is needed to defrost the windows quickly, is only available when the engine has reached its operating temperature.

Blower

The air flow can be set at four speeds with switch (B). The blower should always be set at the lowest speed when driving slowly.

Air distribution

Control **(C**) for setting the flow of air in the required direction.

☞ – Air distribution towards the windscreen in order to demist. For safety reasons, it is not recommended to switch air recirculation on.

- 郑 Air distribution to upper body.
- 🝰 Air distribution to footwell

 $\mathbbm{3}$ – Air distribution to the windscreen and the footwell.

🛆 WARNING

• For your safety, the windows should never be fogged up or covered with snow or ice. This is essential to ensure good visibility. Please familiarise yourself with the correct operation of the heating and ventilation system, including the demist/defrost functions for the windows.

i Note

• Please consider the general notes >>> page 137.

Air recirculation 👁

Air recirculation prevents unpleasant smells from entering the interior.

Connecting the recirculation

In any position of rotary switch \bigcirc except thaw:

• Press button (D) **W** Fig. 153 and the lamp in the button will illuminate.

Disconnecting the recirculation

• If the lamp is on, press button ()) and the lamp will go off, indicating that the entry of outside air has been activated.

»

If the rotary switch (C) **WFig. 153** is in the thaw position, the recirculation flap will always be open and air will always enter from the outside.

If the rotary switch (c) is switched from any position to the thaw position, recirculation will be automatically deactivated.

▲ WARNING

• In air recirculation mode, no cold air from the outside enters the vehicle interior. The windows can quickly fog over if the heating is switched off. Therefore, never leave the air recirculation mode switched on for a long time (risk of accident).

Vehicle ventilation or heating

Ventilating the vehicle interior

- Turn the temperature selector >>>> Fig. 153
 A anticlockwise.
- Turn blower switch **B** to any of the head settings 1-4.
- Set the airflow to the desired direction using air distribution control **(**.
- Open the relevant air outlets.

Interior heating

Turn the temperature selector **»** Fig. 153
 (A) clockwise to select the desired temperature.

Operation

- Turn blower switch (B) to any of the head settings 1-4.
- Set the airflow to the desired direction using air distribution control C.
- Open the relevant air outlets.

Defrosting the windscreen

- Turn the temperature selector **» Fig. 153** (A) clockwise to reach the maximum temperature.
- Turn the blower switch B to setting 4.
- Turn air distribution control to @.
- Close outlet ③.
- Open and turn outlet (4) towards the side windows.

Keeping the windscreen and the side windows demisted

- Turn the temperature selector **>>> Fig. 153** A to the heating area.
- Turn blower switch (B) to any of the head settings 2-3.
- Turn air distribution control to @.
- Close outlets ③

 Open and turn outlets (4) towards side windows.

Once the windows are demisted and as a preventive measure, the control O can be set in position B, thus obtaining greater comfort while preventing the windows from misting again.

Heating

Maximum heat output, which is needed to defrost the windows quickly, is only available when the engine has reached its operating temperature.

i Note

Remember that the temperature of the engine coolant should be optimum to ensure that the heating system functions correctly (except in vehicles fitted with additional heating*).

Air conditioning

Air conditioning*

Controls




Fig. 154 Air conditioning controls on the dash panel.

- (A) Temperature selector >>> page 141
- B Blower control. There are four speed settings for the blower. At low speed, it is recommended to set the blower to a minimum of 1 to improve the intake of fresh air.
- C Air distribution control >>> page 141
- D Air recirculation button 📾 >>> page 142
- (E) A/C button Switches on the cooling system » page 141

The air conditioning system only works when the engine is running and the fan is switched on. • Using the rotary switches (A), (B) and (C) **W** Fig. 154 you can adjust temperature, blower speed and air distribution.

• To switch a function on or off, press the appropriate button () or (E). When the function is activated, a red warning light on the button is turned on.

To demist the windscreen

- Turn air distribution to @.
- Turn the fan control to one of the two levels depending on the speed required.
- Rotate the temperature control to the desired level of comfort.
- Close outlets ③
- Open and turn outlets (4) towards side windows.

For your safety, the windows should never be fogged up or covered with snow or ice. This is essential to ensure good visibility. Please familiarise yourself with the correct operation of the heating and ventilation system, including the demist/defrost functions for the windows.

i Note

Please consider the general notes.

Vehicle interior heating or cooling system

Interior heating

- Turn off the cooling system using the
 >> Fig. 154 (A/C) button (the button light turns off).
- Turn the temperature selector (A) to set the desired temperature inside the vehicle.
- Turn the blower switch to any of the settings 1-4.
- Set the air distribution control C to the air flow configuration desired: (b) (towards the windscreen), (b) (towards the chest), (c) (towards the footwell) and (c) (towards the windscreen and footwell areas).

Interior cooling

- Turn off the cooling system using the A/C button (the button light turns on).
- Turn the temperature control switch until the desired interior temperature is reached.
- Turn the blower switch to any of the settings 1-4.
- Set the air distribution control to the air flow configuration desired: ((towards the windscreen), (2) (towards the chest), (2) (towards the footwell) and ((towards the windscreen and footwell areas).

Heating

Maximum heat output, which is needed to defrost the windows quickly, is only available when the engine has reached its operating temperature.

Coolant system

When the air conditioning is switched on, the temperature and the air humidity go down. This way, if the outside humidity is extreme, the air conditioning prevents the misting of the windows and therefore, comfort is improved.

If the air conditioning does not work, this may be due to the following reasons:

- The engine is stationary.
- The fan blower is switched off.
- The outside temperature is lower than approximately +3°C (+37°F).

• The air conditioning system compressor has been temporarily switched off because of an increased engine coolant temperature.

• The air conditioner fuse is faulty.

• Another fault in the vehicle. Have the air conditioning checked by a specialised workshop.

Air recirculation 📾

Air recirculation prevents unpleasant smells, e.g. when passing through a tunnel or in queuing traffic, from entering the interior.

If the rotary switch (C) **W** Fig. 154 is in the thaw position, the recirculation flap will always be open (button light off).

If the rotary switch (C) is switched from any position to the thaw position, recirculation will be automatically deactivated.

Connecting the recirculation

In any position of rotary switch \bigcirc except thaw:

• Press button (**D**) **>>> Fig. 154**, the switch's lamp will light up, indicating that air recirculation inside the vehicle has been activated.

Disconnecting the recirculation

In any position of rotary switch \bigcirc except thaw:

• Press button ()) again and the button's lamp will go off, indicating that air recirculation from the outside has been activated.

In the thaw position of rotary switch **(C)**, the entry of air into the vehicle interior is always from the outside.


In air recirculation mode, no cold air from the outside enters the vehicle interior. If the air conditioner is switched off, the windows can quickly mist over. Therefore, never leave the air recirculation mode switched on for a long time (risk of accident).

i Note

- When engaging reverse gear, the air recirculation is connected automatically to prevent the entrance of exhaust gases in the vehicle on travelling backwards. The control lamp on the button () does not light up.
- If the temperature control is turned to the coldest setting (blue point) and the (A/C) button is on, the "Air recirculation" function is automatically activated in order to cool the vehicle faster using less energy, and its function control lamp will light up.
- If the function is not deactivated by pressing the button, it will deactivate after approximately 20 minutes.

Climatronic*

General notes



Read the additional information carefully >>> 🗁 page 39

Climatronic automatically maintains a comfortable temperature. To do so, it automatically regulates the supplied air temperature and the blower and air distribution levels. The system also allows for the effect of sunlight, so there is no need for manual adjustment. It also has a humidity sensor that helps to automatically demist the windscreen.

Automatic operations >>> page 144 guarantee maximum comfort any time of year.

Climatronic description

Cooling only works if the following conditions are met:

- The engine is running
- the outside temperature is above +2°C (+36°F);
- A/C 18 **>>> Fig. 155** switched on.

Starting the Climatronic

The corresponding function will be switched on when a button is pressed, turning on the air conditioning if it was switched off, with the exception of button () **Fig. 155** (recirculation).

Fig. 155 Climatronic: controls.

Switching off the Climatronic

- Turn control 10 to the left until the segments of column (9) **W** Fig. 155 switch off.
- After **1 second** has elapsed, turn the control again to switch off the display.

In order to ensure engines subject to heavy loads are cooled, the air conditioning compressor is switched off in the event of high coolant temperatures.

Recommended setting for all seasons of the year

• Set the required temperature. We recommend +22 °C (72°F).

»

• Press the AUTO button 13 >>> Fig. 155.

• Adjust vents **3** and **4 >>> page 138** so that the air flow is directed slightly upwards.

Change between degrees Centigrade and degrees Fahrenheit

Keep the (AUTO) and (A/C) **w** Fig. 155 buttons held down for **2 seconds** at the same time. The data is displayed on the screen in the units required.

i Note

• A visit to the specialised service once a year is recommended to clean the Climatronic system.

• The interior temperature sensor ① **>> Fig. 155** is at the bottom. Do not cover it with stickers or the like, as this could have a negative effect on Climatronic operations.

Automatic mode

Automatic mode is used to maintain a constant temperature and demist the windows inside the vehicle.

Switching on automatic mode

- Set the interior temperature between +16°C (+64°F) and +29°C (+84°F).
- Adjust vents **3** and **4 >>> page 138** so that the air flow is directed slightly upwards.

• Press the AUTO button (13) **Fig. 155** and AUTO displayed on the screen.

Automatic mode is switched off by pressing the air distribution buttons or increasing or decreasing the blower speed. However, the temperature remains regulated.

Adjusting the temperature

• When you switch on the ignition, control (1) **>>> Fig. 155** can be used to set the required interior temperature.

It is possible to select interior temperatures from +16°C (+64°F) to +29°C (+84°F). In this range the temperature is regulated automatically. If a temperature below +16°C (+64°F) is selected, "LO" is displayed on the screen. If a temperature above +29°C (+84°F) is selected, "HI" is displayed on the screen. At both extremes, Climatronic works at maximum cooling or heating power, respectively. The temperature is not regulated.

In the event of prolonged, irregular distribution of the air flow from the outlets (particularly the footwells) and significant differences in temperature, e.g. on leaving the vehicle, sensitive people may catch cold.

Air recirculation

Air recirculation prevents unpleasant smells, e.g. when passing through a tunnel or in queuing traffic, from entering the interior.

Switching on air recirculation mode

• Press button (a) (17) ******* Fig. 155 and the as symbol is displayed on the screen.

Switching off air recirculation mode

• Press button (a) (1) **** Fig. 155** and the a symbol disappears from the screen.

Read and observe the safety warnings »» \triangle in General notes on page 137.

i Note

If air recirculation mode remains on for 15 minutes, the ∞ symbol will start to flash on the screen to indicate prolonged air recirculation. If air recirculation is not switched off, the symbol will continue to flash for about 5 minutes.

Blower selection

Climatronic automatically regulates blower speed according to the interior temperature.

It is possible, however, to set the blower speed to suit requirements.

• Turn control (1) **>>> Fig. 155** counter-clockwise (to lower the speed) or clockwise (to increase the speed).

Climatronic will switch off when the blower switches off.

∆ WARNING

Read and observe the safety warnings >>> \triangle in General notes on page 137.

Windscreen defrost

Switching on windscreen defrosting

Switching off windscreen defrosting

• Press button **MAX** 12 **>>> Fig. 155** several times or press the AUTO button.

The temperature is regulated automatically. The air output is increased from vents **1** and **2 w** page **138**.

Driving

Address

Introduction

The power steering is not hydraulic but electromechanical. The advantage of this steering is that it foes not need flexible hydraulic pipes, hydraulic oil, pump, filter or other parts. The electromechanical system saves fuel. Whereas a hydraulic system needs continuous oil pressure, electromechanical steering only needs power when it is used.

In vehicles with electromechanical steering, the assisted steering function automatically adjusts according to vehicle speed, steering wheel torque and wheel orientation. The power steering only works when the engine is running.

▲ WARNING

If the power steering does not work, you will need much more strength to turn the wheel. This has a considerable effect on vehicle safety.

• The power steering only works when the engine is running.

• Never allow the vehicle to move when the engine is switched off.

• Never remove the key from the ignition while the vehicle is moving. The steering lock

could be engaged and vehicle steering would not work.

i Note

The ignition of the vehicle being towed must be switched on to prevent the steering wheel from locking and also to allow the use of the turn signals, horn, windscreen wipers and washers.

Control lamp

The control lamp should light up for a few seconds when the ignition is switched on. It should go out once the engine is started.

@ !	It lights up red
The electromechani- cal steering is dam- aged.	Have the steering checked im- mediately by a specialised work- shop.
@ !	It lights up yellow
Electromechanical steering operation is limited.	See a specialised workshop im- mediately and have the steering checked. If the yellow warning lamp does not light up again after the en- gine is restarted and the vehicle has travelled a short distance, you do not need to take it to a specialised workshop.

@ !	It lights up yellow
The 12-volt battery was disconnected and has been recon- nected.	Take the vehicle for a short run at 15-20 km/h (9-12 mph).

@ !	It flashes yellow
The steering column is tight.	Turn the wheel a little to both sides.
The steering column does not unlock or lock.	Remove the key from the ignition and switch the ignition back on. If necessary, check the messag- es displayed on the instrument panel display. Do not drive on if the steering column remains locked after the ignition has been switched on. Seek specialist assistance.

WARNING

If the warning lamps and the corresponding messages are ignored when they light up, the vehicle may stall in traffic and cause accidents and severe injuries.

 Never ignore the warning lamps or messages.

 Stop the vehicle at the next opportunity and in a safe place.

i Note

Failure to heed the control lamps and corresponding text messages when they light up may result in damage to the vehicle.

Information relating to different vehicle processes.

In order to make the vehicle more difficult to steal, you should always lock the steering before leaving the vehicle.

Mechanical steering lock

The steering column is locked when the key is removed from the ignition lock and the vehicle is stationary.

Activating the steering lock

- Park the vehicle **>>> page 149**.
- Remove the ignition key.
- Turn the steering wheel slightly until the steering lock has engaged.

Deactivating the steering lock

- Turn the steering wheel slightly to release the lock.
- Insert the key in the ignition lock.
- · Hold the steering wheel in this position and switch on the ignition.

Electromechanical steering

In vehicles with electromechanical steering, the assisted steering function automatically adjusts according to vehicle speed, steering wheel torque and wheel orientation. The power steering only works when the engine is running.

You should take into account that you will need considerably more power than normal to steer the vehicle if the power steering is not working correctly or at all.

Power-assisted steering

Power-assisted steering helps the driver in critical situations. In counter-steering, it assists by applying additional torque $\gg \Delta$.

∧ WARNING

Power-assisted steering, together with the ESC, helps the driver to control vehicle steering in critical situations. However, the driver is ultimately responsible for steering the vehicle at all times. Power-assisted steering does not remove this responsibility.

Starting and stopping the engine

Ignition key positions



Fig. 156 Ignition key positions.

Read the additional information carefully

Ignition switched off, steering lock (1)

In this position **>>>** Fig. 156, the ignition and the engine are OFF and the steering may be locked.

For the **Steering lock** to operate without the ignition key, turn the steering wheel until it locks with an audible sound. You should always lock the steering wheel when you leave your vehicle. This will help prevent vehicle theft $\mathbf{w} \Delta$.

Driving

Switching the ignition or the glow plug system on 2

Turn the ignition key to this position and release it. If the key cannot be turned or it is difficult to turn from position (1) to position (2), move the steering wheel from one side to the other; this will release it.

Starting 3

The engine is started when the key is in this position. Electrical devices with high power consumption are switched off temporarily at the same time.

Each time that the vehicle is restarted, the ignition key must be turned to position **1**. The **repetitive start prevention lock** of the ignition prevents possible damage to the starter motor if the engine is already running.

• The ignition key must NOT be removed from the lock until the vehicle comes to a standstill. Otherwise, the steering could be immediately blocked- Risk of accident!

 Always remove the key from the ignition when leaving the vehicle, even if only for a short period. This is especially important if children or disabled people are left alone in the vehicle. They could accidentally start the engine or work electrical equipment such as the electric windows, resulting in an accident. • Unsupervised use of the key could start the engine or any electrical system, such as the electric windows. This could result in serious injury.

() CAUTION

The starter motor will only work when the engine is stopped (ignition key position (3)).

Electronic immobiliser "SAFE"

The electronic immobiliser prevents unauthorised persons from driving the vehicle.

Inside the key there is a chip that deactivates the electronic immobiliser automatically when the key is inserted into the ignition.

The electronic immobiliser will be activated again automatically as soon as you pull the key out of the ignition lock.

The engine can only be started using a genuine SEAT key with its correct code.

If the following message* is shown on the instrument panel display: **SAFE**, the vehicle cannot be started.

The engine can, however, be started if the appropriate coded SEAT genuine key is used. **>>**

i Note

A perfect operation of the vehicle is ensured if genuine SEAT keys are used.

Starting petrol engines

The engine can only be started using a genuine SEAT key with its correct code.

- Move the gearbox lever to the neutral position and depress the clutch pedal thoroughly and hold it in this position for the starter to turn the engine on.
- Turn the ignition key to the starting position >>> page 147.
- Let go of the ignition key as soon as the engine starts; the starter motor must not run on with the engine.

After starting a very hot engine, you may need to slightly press down the accelerator.

When starting a cold engine, it may be a little noisy for the first few seconds until oil pressure has built up in the hydraulic valve compensators. This is quite normal, and no cause for concern.

If the engine does not start immediately, switch the starter off after 10 seconds and try again after half a minute. If the engine still does not start, the fuel pump fuse should be checked **>>> page 80**, Fuses.

▲ WARNING

- Never start or run the engine in unventilated or closed rooms. The exhaust gases contain carbon monoxide, an odourless and colourless poisonous gas. Risk of fatal accidents. Carbon monoxide can cause loss of consciousness and result in death.
- Never leave the vehicle unattended if the engine is running.
- Never use "cold start sprays", they could explode or cause the engine to run at high revs. Risk of injury.

• CAUTION

 When the engine is cold, you should avoid high engine speeds, driving at full throttle and over-loading the engine. Risk of engine damage.

• The vehicle should not be pushed or towed more than 50 metres to start the engine. Unburnt fuel could enter the catalytic converter and damage it.

• Before attempting to push-start or tow a vehicle in order to start it, you should first try to start it using the battery of another vehicle. Please observe and follow the notes on the >>> 2, page 52, How to jump start.

🛞 For the sake of the environment

Do not warm-up the engine by running the engine with the vehicle stationary. Start off immediately, driving gently. This helps the engine reach operating temperature faster and reduces emissions.

Starting diesel engines

The engine can only be started using a genuine SEAT key with its correct code.

- Move the gearbox lever to the neutral position and depress the clutch pedal thoroughly and hold it in this position for the starter to turn the engine on.
- Turn the ignition key to position **»** Fig. 156
 (2). The warning lamp \$\overline{m}\$ will light for engine pre-heating.
- When the lamp turns off, turn the ignition key to position (3) to start the engine. Do not press the accelerator.
- Release the ignition key as soon as the engine starts. The starter motor should not turn at the same time.

When starting a cold engine, it may be a little noisy for the first few seconds until oil pressure has built up in the hydraulic valve compensators. This is quite normal, and no cause for concern.

If there are problems starting the engine, see the **w** 2 page 52.

Glow plug system for the diesel engine

To avoid unnecessary discharging of the battery, do not use any other major electrical equipment while the glow plugs are pre-heating.

Start the engine as soon as the glow plug warning lamp goes out.

Starting a diesel engine after the fuel tank has been completely run dry

If the fuel tank has been completely run dry, it may take longer than normal (up to one minute) to start a diesel engine after refuelling. This is because the fuel system must eliminate air first.

Observe the safety warnings » ▲ in Starting petrol engines on page 148.

() CAUTION

• When the engine is cold, you should avoid high engine speeds, driving at full throttle and over-loading the engine. Risk of engine damage.

• The vehicle should not be pushed or towed more than 50 metres to start the engine. Unburnt fuel could enter the catalytic converter and damage it.

• Before attempting to push-start or tow a vehicle in order to start it, you should first try to start it using the battery of another vehicle.

Please observe and follow the notes on the >>> 💭 page 52, How to jump start.

🛞 For the sake of the environment

Do not warm-up the engine by running the engine with the vehicle stationary. You should drive off as soon as you start the engine. This helps the engine reach operating temperature faster and reduces emissions.

Switching off the engine

- Stop the vehicle.

Turn the ignition key to position **» Fig. 156** 1.

After switching the engine off, the radiator fan may run on for up to 10 minutes. It is also possible that the fan turns itself on once more if the coolant temperature increases due to the heat accumulated in the engine compartment or due to its prolonged exposure to solar radiation.

🛆 WARNING

• Never switch the engine off until the vehicle is completely stationary.

• The brake servo works only when the engine is running. With the engine switched off, more strength is needed to brake. As normal brake operation cannot be performed, risk of accidents and serious injury may exist.

- The steering lock can be immediately blocked once the key is removed from the ignition. The vehicle cannot be steered. Risk of accident.
- Power-assisted steering does not work when the engine is off, and more strength is needed to turn the wheel.
- If the key is removed from the ignition lock the steering lock could be engaged and vehicle steering would not work.

() CAUTION

When the engine has been running under a heavy load for a long period, heat can accumulate in the engine compartment and cause engine damage. For this reason, idle the engine for approximately 2 minutes before switching it off.

Braking and parking

Braking capacity and braking distance

The efficiency of the brakes depends directly on the **brake pad** wear. This wear depends to a great extent on the conditions under which the vehicle is operated and the way the vehicle is driven. If you often drive in town, drive short distances or have a sporty driving style, we recommend that you have the thickness

of your brake pads checked by technical services more frequently than recommended in the Maintenance Programme.

If you drive with **wet brakes**, for example, after crossing areas of water, on days of heavy rainfall or even after washing the car, the effect of the brakes is reduced as the brake discs are wet or even frozen (in winter): in this case, the brake should be "dried" by pressing the brake pedal several times.

▲ WARNING

Longer braking distances and faults in the brake system increase the risk of accidents.

 New brake pads must be run in and do not have the correct friction during the first 200 km. This reduced braking capacity may be compensated for by pressing on the brake pedal a little harder, which also applies when the brake pads have to be changed further on.

• If brakes are wet or frozen, or if you are driving on roads which have been salted, braking power may be lower than normal.

 On steep slopes, if brakes are excessively used, they will overheat. Before driving down a long steep slope, it is advisable to reduce speed and change down into a lower gear or range (depending on the type of transmission). Thus, make use of engine braking and relieve the brakes.

• Never let the brakes "drag" by applying light pressure. Continuous braking will cause

the brakes to overheat and the braking distance will increase. Apply and then release the brakes alternately.

• Never let the vehicle run with the engine switched off. The braking distance is increased considerably when the brake servo is not active.

• If the brake fluid loses its viscosity and is subjected to heavy use, vapour bubbles can form in the brake system. This reduces the efficiency of the brakes.

 Non-standard or damaged front spoilers could restrict the airflow to the brakes and cause them to overheat. Before purchasing accessories please observe the relevant instructions >>> page 187, Modifications.

 If a brake system circuit fails, the braking distance will be increased considerably. Contact a specialised workshop immediately and avoid unnecessary journeys.

Control lamp

Situations in which the warning lamp lights up (!)*

• the brake fluid level is too low **>>> page 206**.

• there is a fault in the brake system.

This warning lamp can light up together with the ABS system warning lamp.

 If the brake warning lamp does not go out or if it lights up when driving, the brake fluid level in the reservoir is too low so there is a risk of an accident >>> page 206, Brake fluid.
 Stop the vehicle and do not drive on. Obtain technical assistance.

 If the brake warning lamp lights up (2) together with the ABS lamp (2) this could be due to an ABS fault. This could cause the rear wheels to lock quickly when you brake. This could cause the rear to break away. Risk of skidding. Stop the vehicle and seek technical assistance.

Handbrake




Fig. 157 Handbrake between the front seats.

The handbrake should be applied firmly to prevent the vehicle from accidentally rolling away. Always apply the handbrake when you leave your vehicle and when you park.

Applying the handbrake

Pull the handbrake lever up firmly
 » Fig. 157.

Releasing the handbrake

Pull the lever up slightly and press the release knob in the direction of the arrow
 >>> Fig. 157 and guide the handbrake lever down fully >>> △.

Always pull the handbrake *all the way up*, so there is less risk of driving off with it still engaged **>>>** \triangle .

The handbrake warning lamp (2) lights up when the handbrake is applied and the ignition switched on. The warning lamp turns off when the handbrake is released.

▲ WARNING

 Never use the handbrake to stop the vehicle when it is in motion. The braking distance is considerably longer, because braking is only applied to the rear wheels. Risk of accident!

 If the handbrake is only partially released, this will cause the rear brakes to overheat, which can impair the function of the brake system and could lead to an accident. This also causes premature wear on the rear brake pads.

() CAUTION

Always apply the handbrake before you leave the vehicle. Put it in 1st gear as well. In vehicles with an automatic gearbox, place the gear lever in position P.

Parking

The handbrake should always be firmly applied when the vehicle is parked.

Always note the following points when parking the vehicle:

- Use the brake pedal to stop the vehicle.
- Apply the handbrake.
- Put it in 1st gear.
- Switch the engine off and remove the key from the ignition. Turn the steering wheel slightly to engage the steering lock.
- Always take you keys with you when you leave the vehicle >>> A.

Additional notes on parking the vehicle on gradients:

Turn the steering wheel so that the vehicle rolls against the kerb if it started to roll.

• If the vehicle is parked facing **downhill**, turn the front wheels so that they point *towards the kerb*.

• If the vehicle is parked facing **uphill**, turn the front wheels so that they point *away from the kerb*.

• Secure the vehicle as usual by applying the handbrake firmly and putting it in 1st gear.

• Take measures to reduce the risk of injury when you leave your vehicle unattended.

- Never park where the hot exhaust system could ignite inflammable materials, such as dry grass, low bushes, spilt fuel etc.
- Never allow vehicle occupants to remain in the vehicle when it is locked. They would be unable to open the vehicle from the inside, and could become trapped in the vehicle in an emergency. In the event of an emergency, locked doors will delay assistance to vehicle occupants.
- Never leave children alone in the vehicle. They could set the vehicle in motion, for example, by releasing the handbrake or the gearbox lever.

• Depending on weather conditions, it may become extremely hot or cold inside the vehicle. This can be fatal.

Braking and stability systems

Electronic Stability Control (ESC)*

This Electronic Stability System reduces the risk of skidding and improves the vehicle's stability and ability to hold the road.

The Electronic Stability Control (ESC) contains the electronic differential lock (EDL) and the traction control system (ASR). The ESC works together with the ABS. Both control lamps will light up if the ESC or ABS systems are faulty.

The ESC system is started automatically when the engine is started.

The ESC system is always active and cannot be switched off. With the Easy Connect system it is only possible to deactivate the ASR or else select Sport mode.

The ASR can be deactivated when wheel spin is desirable **>>> page 153**.

For example:

• When driving with snow chains.

• When driving in deep snow or on loose surfaces.

• When the vehicle is stuck, to rock it backwards and forwards.

Press the button to switch the ASR back on when you no longer need wheel spin.

Electronic Stability Control (ESC)*

The ESC reduces the risk of skidding by braking the wheels individually.

The system uses the steering wheel angle and road speed to calculate the changes of direction desired by the driver, and constantly compares them with the actual behaviour of the vehicle. When irregularities occur, for example, if the vehicle begins to skid, the ESC brakes the appropriate wheel automatically.

The forces acting on the braked wheel bring the vehicle back to a stable condition. If the vehicle tends to oversteer (the rear end slides out), the system will act on the front wheel on the outside of the turn.

Control lamp

There are two control lamps for the electronic stability control. The lamp \$ provides information concerning function and \$ disconnection status.

Both control lamps light up together when the ignition is switched on and should turn off after approximately 2 seconds. This is the time taken for the function check.

This programme includes the ABS, EDL and ASR. It also includes emergency braking assistance (BAS).

The control lamp $\stackrel{\mbox{\scriptsize fl}}{\sim}$ has the following functions:

- It flashes whilst driving when the ASR/ESC is activated.
- It will light up if there is a fault in the ESC.

• As the ESC operates in conjunction with the ABS, the ESC light will also come on if a fault should occur in the ABS.

If the ESC control lamp \Re lights up and stays on after the engine is started, this may mean that the control system has temporarily switched off the ESC. In this case the ESC can be reactivated by switching the ignition off and then on again. If the control lamp goes out, this means the system is fully functional.

The $\ensuremath{\k lamp provides information about the disconnection status of the system:

• It stays lit when the ASR is disconnected on pressing the switch & or if we select ESC Sport mode, only by means of Easy Connect.

 Do not forget that the electronic stability control ESC cannot defy the laws of physics. This should be kept in mind, particularly on slippery and wet roads and when towing a trailer.

• Always adapt your driving style to suit the condition of the roads and the traffic situation. The greater safety provided by the ESC should not encourage you to run any risks.

() CAUTION

• To ensure that the ESC works correctly, all four wheels must be fitted with the same tyres. Any differences in the rolling radius of the tyres can cause the system to reduce engine power when this is not desired.

 Any modifications made to the vehicle (for example, to the engine, brake system, running gear or to the combination of wheels and tyres) may affect the operation of the ABS, EDL, ESC and ASR.

Traction control system (ASR)*

The traction control system prevents the driven wheels from spinning when the vehicle is accelerating. This system always includes ABS.

Description and operation of the traction control system during acceleration (ASR)

On front-wheel drive vehicles, the ASR system intervenes, reducing engine power and preventing the driven wheels from slipping during acceleration. The system works in the entire speed range in conjunction with ABS. If a failure occurs in the ABS, the ASR will also stop working.

TCS helps the car to start moving, accelerate and climb a gradient in slippery conditions where this may otherwise be difficult or even impossible. The ASR automatically switches on when the engine is started. If necessary, it could be connected or disconnected by means of the Easy Connect system.

When the ASR is off, the warning lamp lights up 4. The ASR should normally be left on. Only in exceptional circumstances, when wheel spin is required, can they be turned off using the ESC button, for example:

- With compact temporary spare wheel.
- When using the snow chains.
- When driving in deep snow or on soft terrain.
- When the vehicle is bogged-down, to free it "by rocking it."

The ASR should be switched on again as soon as possible.

Control lamp

There are two control lamps for the traction control system: ft and 붊. Both control lamps light up together when the ignition is switched on and should turn off after approximately 2 seconds. This is the time taken for the function check.

The 🕄 lamp has the following function:

• It flashes when the ASR is working if the vehicle is moving.

If the system is deactivated or if it has any fault, the warning lamp will remain lit. The warning lamp will also light up if a fault should occur in the ABS because the ASR operates in conjunction with the ABS. For further information, see **>>** page 153.

The $\ensuremath{\hat{a}}\xspace$ lamp provides information about the disconnection status of the system:

• It stays lit when the ASR is disconnected via Easy Connect.

By means of Easy Connect, the ASR function is reactivated and the warning lamp switched off.

- Remember that not even the ASR can defy the laws of physics. This should be kept in mind, particularly on slippery and wet roads and when towing a trailer.
- Always adapt your driving style to suit the condition of the roads and the traffic situation. The greater safety provided by the ASR should not encourage you to run any risks.

() CAUTION

 To ensure that the ASR works correctly, identical tyres should be fitted on all four wheels. Any differences in the rolling radius of the tyres can cause the system to reduce engine power when this is not desired.

»

 Any modifications made to the vehicle (for example, to the engine, brake system, running gear or to the combination of wheels and tyres) may affect the operation of the ABS and ASR.

Connecting/disconnecting ESC and ASR

The ESC is switched on automatically when the engine is started, and only works when the engine is running and includes the ABS, EDS and ASR systems.

The ASR and ESC function should only be switched off in situations in which traction is insufficient, among others:

• When driving in deep snow or on surfaces that are not very firm.

• To "free" the vehicle if it gets stuck.

Then switch the ASR and ESC function back on.

Depending on finishes and versions, it is possible either to disconnect only the ASR or else activate ESC Sport mode.

ESC in "Sport" mode

Sport mode can be connected via the Easy Connect **>>> page 99** system menu. The ability of the ESC to stabilise the vehicle is limited; the traction control system (ASR) becomes disabled $ightarrow \Delta$.

The control lamp & lights up. For vehicles with a driver information system*, the driver will be shown the electronic stability control (ESC) option: sport. Warning! Limited stability.

Disable ESC "Sport" mode

Through the Easy Connect system menu »> page 99. The warning lamp & will switch off. For vehicles with a driver information system*, the driver will be shown the electronic stability control (ESC) option: on.

Disable ASR

The Easy Connect system menu is used to switch off the ASR **>>> page 99.** The traction control system will be disabled.

The control lamp $\frac{1}{8}$ lights up. For vehicles with a driver information system* the driver will be informed that **ASR is disabled**.

Activate ASR

The Easy Connect system menu **>>> page 99** is used to switch on the ASR. The traction control system will be enabled.

• Activate or deactivate the ASR or ESC function in the Easy Connect system by means of the button (AR) and the function buttons (Setup) and (ESC System).

You should switch on the ESC Sport mode only if the traffic conditions and your driving ability allow you to do so safely: risk of skidding!

• With ESC in Sport mode, the stabilising function will be limited to allow for a sportier drive. The driving wheels could spin and the vehicle could skid.

i Note

If the ASR is disconnected or the ESC's Sport mode is selected, cruise control* will be switched off.

Electronic differential lock (EDS)*

The EDL operates along with the ABS in vehicles equipped with Electronic Stability Control (ESC)*.

EDL helps the vehicle to start moving, accelerate and climb a gradient in slippery conditions where this may otherwise be difficult or even impossible.

It uses the ABS sensors to monitor the speed of the driven wheels.

At speeds of up to approximately 80 km/h (50 mph), it is able to balance out differences in the speed of the driven wheels of approximately 100 rpm/min caused by a *partially* slippery road surface. It does this by braking the wheel which has lost traction and distributing more driving force to the other driven wheel via the differential.

To prevent the disc brake of the braking wheel from overheating, the EDL cuts out automatically if subjected to excessive loads. The vehicle will continue to function normally without EDL. For this reason, the driver is not informed that the EDL has been switched off.

The EDL will switch on again automatically when the brake has cooled down.

Control lamp

A malfunction in the EDL is indicated by the ABS control lamp ((a) **>>> page 155.** Take the vehicle to a specialised workshop as soon as possible.

▲ WARNING

 When accelerating on a slippery surface, for example on ice and snow, press the accelerator carefully. Despite EDL, the driven wheels may start to spin. This could impair the vehicle's stability.

 Always adapt your driving style to suit road conditions and the traffic situation. Do not let the extra safety afforded by EDL tempt you into taking any risks when driving, this can cause accidents.

() CAUTION

Modifications to the vehicle (e.g. to the engine, the brake system, running gear or any components affecting the wheels and tyres) could affect the efficiency of the EDL » page 187.

Hydraulic Brake Assist (HBA)*

The function (Hydraulic Brake Assist HBA) is only included in vehicles with ESC.

In an emergency, most drivers brake in time, but not with maximum force. This results in unnecessarily long braking distances.

This is when the brake assist system comes into action. When pressing the brake pedal rapidly, the assistant interprets it as an emergency. It very quickly builds up the full brake pressure so that the ABS can be activated more quickly and efficiently, thus reducing braking distance.

Do not reduce the pressure on the brake pedal, since the brake assist system switches off automatically as soon as you release the brake.

Automatic hazard warning lights activation

The brake lights flash automatically to indicate that the vehicle is braking suddenly or in an emergency situation. If the emergency braking continues until the vehicle comes to a standstill, the hazard warning lights will then come on and the brake lights will remain on permanently from that moment. The warning lights will automatically switch off when the vehicle begins to move again or when the "warning" light button is pressed.

∆ WARNING

• The risk of accident is higher if you drive too fast, if you do not keep your distance from the vehicle in front, and when the road surface is slippery or wet. The increased accident risk cannot be reduced by the brake assist system.

• The brake assist system cannot defy the laws of physics. Slippery and wet roads are dangerous even with the brake assist system! Therefore, it is essential that you adjust your speed to suit the road and traffic conditions. Do not let the extra safety features tempt you into taking any risks when driving.

Anti-lock brake system (ABS)

The anti-lock brake (ABS) system prevents the wheels from locking during braking and is an important part of the vehicle's active safety system.

»

How the ABS works

If one of the wheels turns too slowly in relation to the vehicle's speed, and is close to locking, the system will reduce the braking pressure to this wheel. The driver is made aware of this control process by a **pulsating of the brake pedal** and audible noise. This is a deliberate warning to the driver that one or more of the wheels is tending to lock and the ABS control function has intervened. In this situation it is important to keep the brake pedal fully depressed so the ABS can regulate the brake application. Do not "pump".

If you brake hard on a slippery road surface, the best possible control is retained as the wheels do not lock.

However, ABS will not necessarily guarantee shorter braking distances in *all* conditions. Braking distance could even be further if you brake on gravel or on fresh snow on a slippery surface.

Control lamp

The control lamp ⊕ lights up for a few seconds when the ignition is switched on. It goes out again after the system has run through an automatic test sequence.

There is a fault in the ABS if:

• The control lamp () does not light up when the ignition is switched on.

• The control lamp does not go out again after a few seconds.

• The control lamp lights up when the vehicle is moving.

The vehicle can still be braked in the normal way, without the ABS function. Take the vehicle to a specialised workshop as soon as possible.

If there is a fault in the ABS, the ESC* and the tyre pressure control lamp will also light up.

Brake system fault

If the ABS warning lamp O lights up together with the brake warning lamp O, there is a fault in the ABS function and in the brake system O.

 The anti-lock brake system cannot defy the laws of physics. Slippery and wet roads are dangerous even with ABS! If you notice that the ABS is working (to counteract locked wheels under braking), you should reduce speed immediately to suit the road and traffic conditions. Do not let the extra safety features tempt you into taking any risks when driving.

• The effectiveness of ABS is also determined by the tyres fitted >>> page 210.

• If the running gear or brake system is modified, the effectiveness of the ABS could be severely limited.

• Before opening the bonnet, read and observe the warnings >>> page 198, Working in the engine compartment.

• If the brake system warning lamp (2) should light up together with the ABS warning lamp (3), stop the vehicle immediately and check the brake fluid level in the reservoir >>> page 206, Brake fluid. If the brake fluid level has dropped below the "MIN" mark you must not drive on. Risk of accident. Obtain technical assistance.

• If the brake fluid level is correct, the fault in the brake system may have been caused by a failure of the ABS system. This could cause the rear wheels to lock quickly when you brake. This could cause the rear to break away. Risk of skidding. Stop the vehicle and seek technical assistance.

Electronic differential lock (XDS)*

When taking a curve, the driveshaft differential mechanism allows the outer wheel to turn at a higher speed than the inner wheel. In this way, the wheel that is turning faster (outer wheel) receives less drive torque than the inner wheel. This may mean that in certain situations the torque delivered to the inner wheel is too high, causing the wheels to spin. On the other hand, the outer wheel is receiving a lower drive torque than it could transmit. This causes an overall loss of lateral

grip on the front axle, resulting in understeer or "lengthening" of the trajectory.

The XDS system can detect and correct this effect via the sensors and signals of the ESC.

Via the ESC, the XDS will brake the inside wheel and counter the excess driving torque of that wheel. This means that the driver's desired trajectory is much more precise.

The XDS system works in combination with the ESC and is always active, even when ASR traction control is disconnected or the ESC is in Sport mode.

Brake servo

The brake servo increases the pressure you apply to the brake pedal. It works **only when the engine is running**.

If the brake servo is not functioning, e.g. due to a malfunction, or if the vehicle is being towed, you will have to press the brake pedal considerably harder to make up for the lack of servo assistance.

∆ WARNING

The braking distance can also be affected by external factors.

• Never let the vehicle coast with the engine switched off. Failure to follow this instruction could result in an accident. The braking dis-

tance is increased considerably when the brake servo is not active.

 If the brake servo is not working, for example when the vehicle is being towed, you will have to press the brake pedal considerably harder than normal.

Hill driving assistant*

This function is only included in vehicles with ESC.

The hill driving assistant helps the driver to move off and upward on a hill when the vehicle is stationary.

The system maintains brake pressure for approximately two seconds after the driver takes his foot off the brake pedal to prevent the vehicle from lurching backward when it is started. During these 2 seconds, the driver has enough time to release the clutch pedal and accelerate without the vehicle moving and without having to use the handbrake, making start-up easier, more comfortable and safer.

These are the basic operation conditions:

- being on a ramp or hill/slope,
- doors closed,
- vehicle completely stationary,
- engine running and foot on the brake,

• besides having a gear engaged or being in neutral for manual gear change and with the selector lever at position **S**, **D** or **R** for an automatic gearbox.

This system is also active when reversing uphill.

🛆 WARNING

- If you do not start the vehicle immediately after taking your foot off the brake pedal, the vehicle may start to roll back under certain conditions. Depress the brake pedal or use the hand brake immediately.
- If the engine stalls, depress the brake pedal or use the hand brake immediately.
- When following a line of traffic uphill, if you want to prevent the vehicle from rolling back accidentally when starting off, hold the brake pedal down for a few seconds before starting off.

i Note

The Official Service or a specialist workshop can tell you if your vehicle is equipped with this system.

Manual gearbox

Driving with manual gearbox

Read the additional information carefully

Certain versions of the model may include a 6-speed manual gearbox, and its diagram is shown on the gearbox lever.

The reverse gear can only be engaged when the car is stationary. When the engine is running and before engaging this gear, wait about 6 seconds with the clutch pressed down thoroughly in order to protect the gearbox.

The reverse lights switch on when the reverse gear is selected and the ignition is on.

▲ WARNING

• When the engine is running, the vehicle will start to move as soon as a gear is engaged and the clutch released.

• Never select the reverse gear when the vehicle is in motion. Risk of accident.

i Note

• Do not rest your hand on the gear lever while driving. The pressure of your hand could cause premature wear on the selector forks in the gearbox. • When changing gear, you should always depress the clutch fully to avoid unnecessary wear and damage.

• Do not "slip" the clutch to hold the vehicle on a hill. This causes premature wear and damage to the clutch.

 Do not leave your foot on the clutch pedal; although the pressure may seem insignificant, it can cause the premature wear of the clutch plate. Use the foot rest when you do not need to change gear.

Gear-change indicator

 \checkmark Valid for vehicles: with a manual gearbox

The recommended gear for saving fuel is indicated on the dash screen of certain vehicles during driving.

Display	Meaning
3	The optimal gear is selected.
4	Changing to a higher gear is recommended.
2	Changing to a lower gear is recommended.

Information regarding the "cleanliness" of the diesel particulate filter

The exhaust system manager detects that the diesel particulate filter is nearly saturated and contributes to self-cleaning by recommending the optimal gear. For this purpose,

it might be necessary to drive momentarily with a high rpm **>>> page 167**.

🛆 WARNING

The gear change indicator is only an auxiliary function and in no case should be a substitute for careful driving.

 The responsibility of choosing the correct gear depending on the situation (e.g. overtaking, driving up or down a slope or towing a trailer) lies with the driver.

🛞 For the sake of the environment

Selecting the correct gear can help to save fuel.

i Note

The recommended gear display is switched off when the clutch pedal is pressed.

Automatic gearbox*

Driving programmes

Read the additional information carefully

The automatic gearbox has got two gearbox programmes.

Selecting the normal programme

- Put the selector lever into position D.

Selecting the sport programme

- Put the selector lever into position S.

If you select the normal programme, **D**, you will drive in the economy mode, i.e. the programme is designed to reduce fuel consumption. The gearbox changes up into a higher gear as soon as possible and down into a lower gear as late as possible.

If you select the sport programme, **S**, you will drive in a sporty mode, i.e. a programme in which shifts into high gears are postponed in order to use the full power of the engine.

Selector lever positions

Read the additional information carefully >>> 28

Selector lever positions

The gear selected is displayed on the side of the selector lever and on the display¹⁾ in the combi-instrument. The currently selected

gear for the automatic gearbox will also be shown on the display.

Tiptronic gear indicator

If the automatic gearbox is shifted manually, the selected gears are shown on the screen at all times¹⁾.

P - parking lock

When the selector lever is in this position, the driven wheels are locked mechanically.

Position **P** on the lever must only be selected if the vehicle is stationary.

To move selector lever from position **P**, the locking button on the selector lever handle must be pressed and the brake pedal depressed at the same time while the ignition is switched on.

To put the selector lever in position **P**, simply press the lock button down and, if necessary, depress the brake pedal down.

R - Reverse gear

The reverse gear is engaged in this position.

Reverse gear must be engaged only when the vehicle is stationary and the engine is idling.

To move the selector lever to position \mathbf{R} , press the lock button down and, at the same time, press the brake pedal down, with the ignition switched on.

With the selector lever in position **R** and the ignition switched on the following occurs:

- Reverse lights light up.
- The air conditioner automatically changes the air recirculation mode.
- The wiper starts if the windscreen washer is on.
- The parking distance warning system* switches on.

N - Neutral (idling)

If this position is selected, the gearbox is in neutral. Power is not transmitted to the wheels and the engine does not have a braking function.

Never use the ${\bf N}$ position to drive down a long hill. There is no engine braking and the brakes are subjected to excessive stain.

You could damage the automatic gearbox if you drive down hills with the gearbox lever in position **N** and the engine switched off.

D - Drive (forward)

In this position the gearbox automatically changes to a lower or higher gear, according to the engine's requirements, the driving style and speed. The braking effect of the engine when driving downhill is very limited when the selector is in this position. The instrument panel display shows the selected gear as well as the selector lever in position **D**.

When travelling at speeds lower than 5 km/h (3 mph) or when the vehicle is stationary, press the brake pedal to change the selector lever from position \mathbf{N} to position \mathbf{D} .

S - Standard driving position (Sport programme)

When the selector lever is in position **S**, it will automatically change up into a higher gear later, and change down into a low gear, if compared with position **D**. This way, it is possible to take full advantage of the engine reserve power, depending on the engine demand, driving style and speed. The braking effect of the engine when driving downhill is very limited. On the instrument panel display the selected gear is shown as well as the selector lever to position **S**.

To select gear range **S**, press the lock button on the selector lever.

A WARNING

As a driver, you should never leave your vehicle if the engine is running and a gear range is engaged. If you have to leave your vehicle while the engine is running, you must apply the parking brake and put the selector lever in position P.

 If the engine is running and if D or R is engaged, you will need to hold the car on the foot brake. The car will creep forward as the power transmission is not fully interrupted even when the engine is idling.

• Never accelerate when moving the selector lever or you may cause an accident.

• Never move the selector lever to R or P when driving. Risk of accident!

• Before driving down a long, steep slope, it is advisable to reduce speed and change into a lower gear.

• If you stop the vehicle up hill, always hold the foot brake strongly depressed down to stop it from rolling back.

 Never allow the brake to rub and do not use the brake pedal too often or for long periods. Constant braking will cause the brakes to overheat and will considerably reduce the brake effect. This increases the braking distance and could cause the brake system to fail.

• Never allow the car to roll down a gradient with the gear in neutral N, or in selector lever position D, even if the engine is not running.

• If the vehicle moves with no control, an accident and serious injury may occur.

∆ WARNING

Never switch the engine off until the vehicle is stationary. You could lose control of your vehicle. This could cause an accident and serious injury.

• The airbags and belt tensioners do not work when the ignition is switched off.

• The brake servo does not work with the engine off. You need more force to stop the vehicle.

• Power steering does not work when the engine is not running. That is why it is much more difficult to turn the steering wheel.

 Never remove the key from the ignition if the vehicle is in motion. The steering lock could suddenly engage, and you would not be able to steer the vehicle.

() CAUTION

If you allow the vehicle to move when the engine is switched off or with the selector lever in position "N", take your foot off the accelerator and wait until the engine starts idling before returning to position "D".

Selector lever lock



The selector lever lock in position P or N prevents gears from being engaged inadvertently, which would cause the vehicle to move.

The selector lever lock is released as follows:

- Switch the ignition on.
- Press and hold the brake pedal and press the selector lever lock on the left of the selector lever at the same time **>>> Fig. 158**.

The warning lamp (S) on the instrument panel lights up when the brake pedal should be applied. This is essential when the selector lever is taken from the P or N positions.

Level lock only engages with the vehicle stationary at a speed of up to 5 km/h (3 mph). At speeds of over 5 km/h (3 mph) the selector lever lock is automatically deactivated in position N. The selector lever lock is not engaged if the selector lever is moved quickly through position N (e.g. when shifting from R to D). This makes it possible, for instance, to "rock" the vehicle backwards and forwards if it is stuck in snow or mud. The selector lever lock engages automatically if the brake pedal is not depressed and the lever is in position N for more than about 1 second.

Selecting gears manually with Tiptronic mode*



Fig. 159 Changing gear with Tiptronic.



Fig. 160 Steering wheel with paddle levers for automatic gearbox.

The Tiptronic system allows the driver to select gears manually.

Changing gear with the selector lever

- Press the selector lever from position **D** to the right into the tiptronic selector gate.
- Lightly press the selector lever forward
 >> Fig. 159 (+) to change up to a higher gear.
- Lightly press the selector lever backward
 >> Fig. 159 to change down to a lower gear.

Changing gear with the steering wheel paddle levers*

- Press the right paddle lever + towards the steering wheel to change up **>>> Fig. 160**.
- Press the left paddle lever

 towards the steering wheel to change down >>> Fig. 160. >>>

chnical data

Using the paddle levers on the steering wheel, you can access manual driving mode regardless of the pre-selected driving mode.

General information about driving in tiptronic mode

When accelerating, the automatic gearbox / DSG automatic gearbox goes into a higher gear a little before the engine reaches its maximum permitted revolutions.

If a lower gear is selected, the automatic gearbox / DSG automatic gearbox will only change down when the engine cannot go over its maximum permitted revolutions.

If "tiptronic" is selected whilst the vehicle is in motion and the automatic gearbox / DSG automatic gearbox is in third gear and selector lever position **D**, "tiptronic" mode will then also be in third gear.

Changing gears in the normal or sport programme using the steering wheel paddle levers

If the paddle levers **» Fig. 160** are used in the normal or sport programme, the system switches temporarily to "tiptronic" mode. To exit "Tiptronic" mode again, press the right paddle lever \bigcirc towards the steering wheel for approximately one second. You will also leave "tiptronic" mode if the paddle levers are not moved for a certain time.

i Note

 The gear paddle levers on the steering wheel can be operated with the selector lever in any position and with the vehicle in motion.

Driving tips

The gearbox changes gear ratios automatically as the vehicle moves.

Starting

- Start the engine with the selector lever in position **P** or **N**.

Driving

- Press and hold the brake pedal.
- Holding down the lock button (button on the selector lever), select **R** or **D**.
- Release the lever and wait a little for the gearbox to engage the gear (a slight movement can be felt).
- Release the brake and press the accelerator
 >>> ▲ in Selector lever positions on page 160.

Stopping briefly

 If stopping for a short time, keep the vehicle stationary by pressing the foot brake hard to prevent the vehicle moving backwards on a slope or "creeping" forwards, e.g. at traffic lights. The selector lever does not need to be put into the positions ${\bf P}$ or ${\bf N}$ for this.

- Do not press the accelerator.

Parking

- Press and hold the brake pedal until the vehicle comes to a standstill *≫* <u>A</u> in Selector lever positions on page 160.
- Apply the handbrake.
- By pressing the lock button down, move the selector lever to P and release the lock button.

Driving up and down hills

- Press the selector lever from position "D" to the right into the tiptronic selector gate.
- Lightly press the selector lever back to change down.

Holding the car on a hill

 The brake must be always pressed down to prevent the vehicle from "rolling backwards"» A in Selector lever positions on page 160. Do not try to prevent the vehicle from "rolling backwards" by increasing the engine speed while a range of gears is selected.

»

Driving

Starting the vehicle up hills

- Apply the handbrake.
- With a selected gear, accelerate slowly and at the same time, release the handbrake.

The steeper the slope, the lower the needed gear. This increases the braking effect of the engine. For example, when driving down a very steep slope in third gear. If the engine brake effect is not enough, the vehicle will speed up. The automatic gearbox automatically changes up to prevent the engine overrevving. Use the foot brake to reduce speed and change into 3rd gear using Tiptronic* **>>** A in Selector lever positions on page 160.

Your vehicle has an automatic interlock which prevents the selector lever from being put into a position for driving forwards or in reverse from positions ${\bf P}$ or ${\bf N}$ if the brake pedal is not depressed.

The ignition key cannot be removed unless the selector lever is in position **P**.

Control lamp "Pressing brake pedal" (S)

When the warning lamp next to the selector lever lights up, press the brake pedal. This is necessary when the automatic gearbox selector lever is moved out of positions \mathbf{P} or \mathbf{N} . A text message or instructions to perform necessary operations may appear on the instrument panel.

() CAUTION

• If you stop the vehicle up hills, do not attempt to stop it from rolling back by depressing the accelerator when a gear has been selected. Otherwise, the automatic gearbox may overheat causing damage. Pull the handbrake up or fully depress the brake pedal to prevent the vehicle from rolling away.

• If you allow the vehicle to roll when the engine is not running, or with the selector lever in position N, a lack of lubrication in the automatic gearbox will damage it.

Kick-down feature

This feature allows maximum acceleration.

If you press the accelerator down thoroughly, the gearbox automatically changes down, depending on speed and engine speed, into a lower gear to take full advantage of give the vehicle maximum acceleration.

The gearbox does not change gear until the engine reaches the maximum determined engine speed for the gear.

You could lose control of the vehicle if you accelerate on slippery road surfaces. Risk of serious injury.

• Be particularly careful when using the kickdown features on slippery road surfaces. With a fast acceleration, the vehicle could lose traction and skid.

• You should use the kick-down feature only when traffic and weather conditions allow it to be used safely.

Gearbox malfunctions

• Gearbox: Fault! Stop the vehicle and place the lever in the position P.

There is a fault in the gearbox. Stop the vehicle in a safe place and do not continue driving. Seek specialist assistance.

① Gearbox: System fault! You may continue driving.

Have the fault corrected by a specialised workshop without delay.

③ Gearbox: System fault! You can continue driving with restrictions. Reverse gear disabled

Take the vehicle to a specialised workshop and have the fault repaired without delay.

③ Gearbox: System fault! You can continue driving in D until switching off the engine

Stop the vehicle in a safe place well away from moving traffic. Seek specialist assistance.

① Gearbox: too hot. Adapt your driving accordingly

Continue driving at moderate speeds. When the warning lamp switches off, you can continue driving in a normal manner.

① Gearbox: press the brake and engage a gear again.

If the fault was caused by a gearbox with a high temperature, this driver message will be displayed when the gearbox has cooled again.

Run-in and economical driving

Running in a new engine

The engine needs to be run in over the first 1,500 km (900 miles).

Up to 1000 kilometres (600 miles)

- Do not drive at speeds of more than 2/3 the maximum speed.
- Do not accelerate hard.
- Avoid high engine revolutions.
- Do not tow a trailer.

From 1000 to 1500 kilometres (600 to 900 miles)

 Speeds can be *gradually* increased to the maximum road speed or maximum permissible engine speed (rpm).

During its first few hours of running, the internal friction in the engine is greater than later on, when all the moving parts have bedded in.

${\ensuremath{\, \mathrm{ \ensuremath{\mathbb R}}}}$ For the sake of the environment

If the engine is run in gently, its life will be increased and its oil consumption reduced.

Tyre and brake pad run-in

New tyres should be run-in carefully for the first 500 km (300 miles). New brake pads should be run-in carefully for the first 200 km (125 miles).

During the first 200 km (125 miles), you can compensate for the reduced braking effect by applying more pressure to the brake pedal. In case of a sharp braking, the braking distance will be longer with new brake pads than with brake pads which have been run-in.

🛆 WARNING

• At first, new tyres do not give maximum grip, and require running-in. This may cause

an accident. Drive particularly carefully in the first 500 km (300 miles).

 New brake pads must be "run in" and do not have the correct friction properties during the first 200 km (125 miles). However, the reduced braking capacity may be compensated by pressing on the brake pedal a little harder.

Environmental compatibility

Environmental protection is a top priority in the design, choice of materials and manufacture of your new SEAT.

Constructive measures to encourage recycling

- Joints and connections designed for easy dismantling.
- Modular construction to facilitate dismantling.
- Increased use of single-grade materials.
- Plastic parts and elastomers are marked in accordance with ISO 1043, ISO 11469 and ISO 1629.

Choice of materials

- Use of recycled materials.
- Use of compatible plastics in the same part if its components are not easily separated.
- Use of recycled materials and/or materials originating from renewable sources.

• Reduction of volatile components, including odour, in plastic materials.

• Use of CFC-free coolants.

Ban on heavy metals, with the exceptions dictated by law (Annex II of ELV Directive

2000/53/EC): cadmium, lead, mercury, hexavalent chromium.

Manufacturing methods

- Reduction of the quantity of thinner in the protective wax for cavities.
- Use of plastic film as protection during vehicle transport.
- Use of solvent-free adhesives.
- Use of CFC-free coolants in cooling systems.
- Recycling and energy recovery from residues (RDF).
- Improvement in the quality of waste water.
- Use of systems for the recovery of residual heat (thermal recovery, enthalpy wheels, etc.).
- The use of water-soluble paints.

Economical and environmentallyfriendly driving

Fuel consumption, environmental pollution and wear to the engine, brakes and tyres de-

pends in large part on your driving style. By adopting an economical driving style and anticipating the traffic situation ahead, you can easily reduce fuel consumption by 10-15%. Some tips on how to help you reduce pollution while saving money are listed below.

Active cylinder management (ACT®)

Depending on the equipment, the vehicle may have active cylinder management (ACT[®]).

The active cylinder management (ACT®) may automatically deactivate some of the engine cylinders if the driving situation does not require too much power. When it is switched off, no fuel is injected into these cylinders, hence total fuel consumption may be reduced. The number of active cylinders can be seen on the instrument panel display **mage 20**.

Drive anticipating the traffic situation

A vehicle uses most fuel when accelerating. When you anticipate situations, you have to brake less often and, thus, accelerate less. If it is possible, let the vehicle roll with a **gear engaged**, for example, if you see a red light ahead. The braking effect achieved in this way helps to reduce the wear of brakes and tyres; emissions and fuel consumption are reduced to zero (disconnection due to inertia).

Change gear early to save energy

An effective way of saving fuel is to change up *quickly* through the gears. Running the engine at high rpm in the lower gears uses an unnecessary amount of fuel.

Manual gearbox: shift up from first to second gear as soon as possible. We recommend that, whenever possible, you change to a higher gear upon reaching 2000 rpm. Follow the "recommended gear" indication that appears on the instrument panel » page 158.

Avoid driving at high speed

We advise you not to drive at the top speed permitted by the vehicle. Fuel consumption, exhaust emissions and noise levels all increase very rapidly at higher speeds. Driving at moderate speeds will help to save fuel.

Avoid idling

It is worthwhile switching off the engine when waiting in a traffic jam, at level crossings or at traffic lights with a long red phase. The fuel saved after only 30 - 40 seconds is greater than the amount of fuel needed to restart the engine.

The engine takes a long time to warm up when it is idling. Mechanical wear and pollutant emissions are also especially high during this initial warm-up phase. It is therefore best to drive off immediately after starting

the engine. Avoid running the engine at high speed.

Periodic maintenance

Periodic maintenance work guarantees that, before beginning a journey, you will not consume more than the required amount of fuel. A well-serviced engine gives you the benefit of **improved fuel efficiency** as well as maximum reliability and an enhanced resale value.

A badly serviced engine can consume up to 10% more fuel than necessary.

Avoid short journeys

To reduce the consumption and emission of polluting exhaust gases, the engine and the exhaust gas filtration systems should reach the optimum **operating temperature**.

With the engine cold, fuel consumption is proportionally higher. The engine does not warm up and fuel consumption does not normalise until having driven approximately *four* kilometres (2.5 miles). This is why we recommend avoiding short trips whenever possible.

Maintain the correct tyre pressures

Bear in mind that keeping the tyres at an adequate pressure saves fuel. If the tyre pressure is just one bar (14.5 psi/100 kPa) too low, fuel consumption can increase by as much as 5%. Due to the greater rolling resistance, under-inflation also increases tyre **wear** wear and impairs handling.

The tyre pressures should always be checked when the tyres are *cold*.

Do not use **winter tyres** all year round as they increase fuel consumption by up to 10%.

Avoid unnecessary weight

Given that every kilo of **extra weight** will increase the fuel consumption, it is advisable to always check the luggage compartment to make sure that no unnecessary loads are being transported.

A roof rack is often left in place for the sake of convenience, even when it is no longer needed. At a speed of 100 km/h (62 mph) and 120 km/h (75 mph) your vehicle will use about 12% more fuel as a result of the extra wind resistance caused by the roof rack even when it is not in use.

Save electricity

The engine activates the alternator, which produces electricity. With the need for electricity, fuel consumption also increases. Because of this, always turn off electrical devices when you do not need them. Examples of devices that use a lot of electricity are: the blower at high speeds, the rear window heating or the seat heaters*.

i Note

• If your vehicle has *Start-Stop*, it is not recommended that you switch this function off.

• It is recommended that you *close the windows* when driving at more than 60 km/h (37 mph).

- Do not drive with your foot resting *on the clutch pedal*, as the pressure can make the plate spin, more fuel will be used and it can burn the clutch plate lining, causing a serious fault.
- Do not hold the car on a hill with the clutch, use the foot brake or hand brake, using the latter to start. The fuel consumption will be lower and you will prevent the clutch plate from being damaged.

 On descents, use the engine brake, changing to the gear that is more suitable for the slope. Fuel consumption will be "zero" and the brakes will not suffer.

Engine management and exhaust gas purification system

Introduction

 Because of the high temperatures which can occur in the exhaust purification system (catalytic converter or diesel particulate filter), do not park the vehicle where the

exhaust can come into contact with flammable materials under the car (e.g. on grass or at the forest edge). Fire hazard!

• Do not apply wax underneath the vehicle around the area of the exhaust system: Fire hazard!

i Note

While the control lamps , , , PC or T remain lit, there may be engine problems, fuel consumption may increase and the engine may lose power.

Catalytic converter

To maintain the useful life of the catalytic converter

- Use only unleaded petrol with petrol engines, as lead damages the catalytic converter.
- Do not let the fuel get too low in the tank.
- For engine oil changes, do not replenish with too much engine oil »» page 203, Topping up engine oil.
- Never tow the vehicle to start it, use jump leads if necessary >>> 12 page 52.

If you notice misfiring, uneven running or loss of power when the vehicle is moving, reduce speed immediately and have the vehicle inspected at the nearest specialised workshop. In general, the exhaust warning lamp will light up when any of the described symptoms occur» page 98. If this happens, unburnt fuel can enter the exhaust system and escape into the environment. The catalytic converter can also be damaged by overheating.

① CAUTION

Never run the fuel tank completely dry because the irregularity of the fuel supply may cause ignition problems. This allows unburnt fuel to enter the exhaust system, which could cause overheating and damage the catalytic converter.

🛞 For the sake of the environment

Even when the emission control system is working perfectly, there may be a smell of sulphur from the exhaust gas under some conditions. This depends on the sulphur content of the fuel used. Quite often the problem can be solved by changing to another brand of fuel.

Diesel engine particulate filter*




Fig. 161 Vehicle data sticker on back cover of the Maintenance Programme.

Your vehicle is fitted with a DPF (Diesel Particulate Filter) if the vehicle data sticker (back cover of the "Maintenance Programme") lists the code PR 7GG **»** Fig. 161.

The diesel engine particulate filter eliminates most of the soot from the exhaust gas system. Under normal driving conditions, the filter cleans itself. If this is not possible (for example, multiple short trips) the filter will be obstructed by soot and the diesel engine particulate filter warning lamp will light up. This does not represent a fault, it is a warning that indicates that the filter has not been able to regenerate automatically and that you must perform a cleaning cycle, as indicated below.

Accumulation of soot in the diesel engine particulate filter*

If the control lamp slights up you should help the filter clean itself by driving in the appropriate manner.

To do this, drive about 15 minutes in fourth or fifth gear (automatic gearbox: S gear range) at a minimum speed of 60 km/h (37 mph), with the engine running at approximately 2,000 rpm. In this way, the soot build up in the filter is burned. When cleaning is successful, the control lamp turns off.

If the lamp (does not turn off, or the three lamps turn on (particulate filter), fault in the emission control system (and glow plugs (), drive the vehicle to a specialised workshop and have the fault repaired at the earliest opportunity.

▲ WARNING

Always drive according to the road weather conditions, the terrain and traffic. Driving recommendations should never lead to illegal manoeuvres in surrounding traffic.

① CAUTION

 Your vehicle is not designed to use biodiesel fuel. Never, under any circumstances refuel with biodiesel. The use of biodiesel fuel could damage the engine and the fuel system. The addition of biodiesel to diesel by the diesel producer in accordance with standard EN 590 is authorised and will not cause damage to the engine or the fuel system.

• Using diesel fuel with a high sulphur content may significantly reduce the useful life of the diesel particulate filter. Your Technical Service will be able to tell you which countries have diesel with a high sulphur content.

Engine management* EPC

This warning lamp monitors the engine management system for petrol engines.

The warning lamp **EPC** (Electronic Power Control) lights up when the ignition is switched on while system operation is being verified. It should go out once the engine is started.

If there is a fault in the electronic engine management system while you are driving, this warning lamp will light up. Take the vehicle to a specialised workshop as soon as possible and have the engine checked.

Emission control system* 🖎

Control lamp 🖒 flashes:

When there is misfiring that can damage the catalytic converter. Reduce speed and drive carefully to the nearest specialised workshop to have the engine checked.

The control lamp 🖒 lights up:

If a fault has developed during driving which has reduced the quality of the exhaust gas (e.g. lambda probe fault). Reduce speed and drive carefully to the nearest specialised workshop to have the engine checked.

Engine pre-heating/fault system* or

The warning lamp lights up to show that the glow plugs are preheating the diesel engine.

The control lamp tot lights up

If the control lamp ϖ lights up when the engine is started it means that the glow plugs are preheating. The engine can be started straight away when the lamp switches off.

Control lamp or flashes

If a fault develops in the engine management system while you are driving, the glow plug system lamp will flash ∞ . Take the vehicle to a specialised workshop as soon as possible and have the engine checked.

Driving tips

Driving abroad

To drive abroad, the following must be taken into consideration:

- For vehicles fitted with a catalytic converter ensure that unleaded petrol is available for the journey. See the chapter "Refuelling". Automobile organisations will have information about service station networks selling unleaded fuel.
- In some countries, it is possible that your car model is not sold, and therefore some spare parts are not available or the technical services may only be able to carry out limited repairs.

SEAT importers and distributors will gladly provide information about the technical preparation that your vehicle requires and also about necessary maintenance and repair possibilities.

Adhesive strips for headlights

In countries where vehicles drive on the other side of the road to your home country, the asymmetric dipped beam may dazzle drivers of oncoming vehicles.

To prevent dazzling, you must apply stickers to certain parts of the headlight lenses. Fur-

ther information is available at any Technical Service.

Drivina

In vehicles with adaptive headlights, the rotation system must previously be disconnected. To do this, please go to a specialised workshop.

Driving on flooded roads

To prevent damage to the vehicle when driving through water, for example, along a flooded road, please observe the following:

- The water should never come above the lower edge of the bodywork.
- Drive at pedestrian speed.

After driving through water, mud, sludge, etc., the braking effect can be delayed slightly due to moisture build-up on the discs and brake pads. Applying the brakes carefully several times will remove the moisture and restore the full braking effect.

() CAUTION

 Driving through flooded areas may severely damage vehicle components such as the engine, transmission, running gear or electrical system. • Whenever driving through water, the Start-Stop system* must be switched off >>> page 170.

i Note

• Check the depth of the water before entering the flooded zone.

- Do not stop in the water, drive in reverse, or stop the engine in any situation.
- Note that vehicles travelling in the opposite direction may splash water that could exceed the maximum permitted water height for your vehicle.
- Avoid driving through salt water (corrosion).

Driver assistance systems

Start-Stop System*

Description and operation

The Start-Stop function stops the engine when the vehicle is stopped and starts it automatically when required.

Vehicles with a manual gearbox

- When the vehicle is stopped, put it into neutral and release the clutch pedal. The engine will switch off. The warning lamp (A) will appear on the instrument panel display.
- When the clutch pedal is pressed the engine will start up again. The warning lamp will switch off.

Vehicles with an automatic gearbox

- Use the foot brake to bring the vehicle to a stop and keep the brake pedal pressed down with your foot. The engine will switch off. The warning lamp (A) will appear in the display.
- When you take your foot off the brake pedal the engine will start up again. The warning lamp will switch off.

Start-Stop function conditions

- The driver seat belt must be buckled.
- The bonnet must be closed.
- The engine must be at operating temperature.

Operation

- The steering wheel must be straight.
- The vehicle must be on flat ground.
- The vehicle must not be in reverse.
- A trailer must not be connected.
- The temperature of the interior must be within the comfort limits (A/C) button should be selected).
- The windscreen de-mist function must be off.
- If in an increase in airflow is **not** requested.
- The temperature must not be set to **HI** or **LO**.
- The driver door must be closed.
- The diesel particulate filter must not be in regeneration mode, for diesel engines.
- The battery charge must not be low for the next start.
- Battery temperature must be between -1°C (+30°F) and +55°C (+131°F).

Start-Stop function interruption

In the following situations, the Start-Stop function will be interrupted and the engine will automatically start:

- The vehicle starts moving.
- The brake pedal is pressed several times in a row.
- The battery has been discharged excessively.
- The Start-Stop System is manually deactivated.
- The windscreen de-mist function is turned on.
- The temperature of the interior exceeds the comfort limits $(\underline{A/C})$ button).
- If the airflow is increased by more than 3 presses.
- Temperature setting **HI** or **LO** is selected.
- The engine coolant temperature is insufficient.
- The alternator is faulty, for example the Vbelt has ruptured.
- If any of the conditions described in the previous section are not fulfilled.

When the engine is turned off by the Start-Stop function, this is displayed on the instrument panel.

If the Start-Stop system is not switched on, the $\ensuremath{\mathfrak{P}}$ warning lamp will appear on the instrument panel.

Driver assistance systems

A WARNING

Never allow the vehicle to move with the engine off for any reason. You could lose control of your vehicle. This could cause an accident and serious injury.

- The brake servo does not work with the engine off. You need more force to stop the vehicle.
- Power steering does not work when the engine is not running. That is why it is much more difficult to turn the steering wheel.
- Turn off the Start-Stop system when driving through water (fording streams, etc.).

i Note

- For vehicles with the Start-Stop function and a manual gearbox, when the engine is started, the clutch must be pressed.
- When the conditions for the Start-Stop function are not fulfilled, the instrument panel displays the Start-Stop indicator dimmed.
- If the steering wheel is turned more than 270°, it will not be possible to start the vehicle again. To start the vehicle, straighten the steering wheel so that it is turned less than 270°.
- There are different versions of the dash panel; the display of indications on the screen may differ.

Activating and deactivating the Start-Stop function



Fig. 162 The Start-Stop function button.

Every time the ignition is switched on, the Start-Stop function is automatically activated.

Manually deactivating the Start-Stop function

- Press the (@)")>>> Fig. 162 button located on the centre console. When the Start-Stop function is switched off, the warning lamp comes on.
- If the Start-Stop function is operating then the engine starts immediately.

Switching the Start-Stop function on manually

 Press the (@) >>>> Fig. 162 button located on the centre console. The warning lamp will switch off.

Fatigue detection (break recommendation)*

Introduction

📂 » table on page 2

The Fatigue detection informs the driver when their driving behaviour shows signs of fatigue.

▲ WARNING

Do not let the comfort afforded by the Fatigue detection system tempt you into taking any risks when driving. Take regular breaks, sufficient in length when making long journeys.

- The driver always assumes the responsibility of driving to their full capacity.
- Never drive if you are tired.

 The system does not detect the tiredness of the driver in all circumstances. Consult the information in the section w page 172, System limitations.

»

• In some situations, the system may incorrectly interpret an intended driving manoeuvre as driver tiredness.

• No warning is given in the event of the effect called microsleep!

• Please observe the indications on the instrument panel and act as is necessary.

i Note

• Fatigue detection has been developed for driving on motorways and well paved roads only.

• If there is a fault in the system, have it checked by a specialised workshop.

Function and operation



Fig. 163 On the instrument panel display: fatigue detection symbol.

Fatigue detection determines the driving behaviour of the driver when starting a journey,

making a calculation of tiredness. This is constantly compared with the current driving behaviour. If the system detects that the driver is tired, an audible warning is given with a sound and an optic warning is shown with a symbol and complementary message on the instrument panel display **»** Fig. 163. The message on the instrument panel display is shown for approximately 5 seconds, and depending on the case, is repeated. The system stores the last message displayed.

The message on the instrument panel display can be switched off by pressing the **(M/REET)** button on the windscreen wiper lever or the button **(M)** on the multi function steering wheel **(M)** page 25.

The message can be recalled to the instrument panel display using the multifunction display **33** page 25.

Conditions of operation

Driving behaviour is only calculated on speeds above about 65 km/h (40 mph) up to around 200 km/h (125 mph).

Switching on and off

Fatigue detection can be activated or deactivated in the Easy Connect system with the button (EAR) and the function button (Setup) >>> page 99. A mark indicates that the adjustment has been activated.

System limitations

The Fatigue detection has certain limitations inherent to the system. The following conditions can limit the Fatigue detection or prevent it from functioning.

- At speeds below 65 km/h (40 mph)
- At speeds above 200 km/h (125 mph)
- When cornering
- On roads in poor condition
- In unfavourable weather conditions
- When a sporty driving style is employed
- In the event of a serious distraction to the driver

Fatigue detection will be restored when the vehicle is stopped for more than 15 minutes, when the ignition is switched off or when the driver has unbuckled their seat belt and opened the door.

In the event of slow driving during a long period of time (below 65 km/h, 40 mph) the system automatically re-establishes the tiredness calculation. When driving at a faster speed the driving behaviour will be recalculated.

Parking aid

General information

Various systems are available to help you when parking or manoeuvring in tight spaces, depending on the equipment fitted on your vehicle.

The **rear parking aid** is an audible assistant that warns about obstacles located *behind* the vehicle **» page 174**.

During parking, **Parking System Plus** assists the driver by visually and audibly warning them about obstacles detected *in front* and *behind* the vehicle **»** page 174.

 Always pay attention, also when looking straight ahead, to traffic and the vehicle surroundings. The assistance systems are not a replacement for driver awareness. When inserting or removing the vehicle from a parking space, or when performing similar manoeuvres the driver always assumes the responsibility.

• Adapt your speed and driving style at all times to suit visibility, weather, road and traffic conditions.

• The ultrasound sensors have blind spots in which obstacles and people are not registered. Pay special attention to children and animals.

• Always keep visual control of the vehicle surroundings: use the mirrors for additional help.

() CAUTION

Parking Aid functions may be negatively affected by different factors that may lead to damage to the vehicle or its immediate surrounds:

- Under certain circumstances, the system does not detect or display certain objects:
 - Objects such as chains, trailer draw bars, fences, posts and thin trees.
 - Objects that are located above the sensors, such as protrusions in a wall.
 - Objects with certain surfaces or structures, such as wire mesh fences or powder snow.
- Certain surfaces of objects and garments do not reflect the ultrasound sensors' signals. The system cannot detect, at least correctly, these objects or people wearing such clothes.
- Ultrasound sensor signals may be affected by external sound sources. In certain circumstances this may prevent them from detecting people or objects.

 Please note that low obstacles detected by the system may no longer be registered by the sensors as the car moves closer, so the system will not give any further warning. In certain circumstances, objects such as high kerbs that could damage the bottom of the vehicle are not detected either.

- If the first warning from the ParkPilot is ignored, the vehicle could suffer considerable damage.
- The knocks or damage on the radiator grille, bumper, wheel arch and vehicle underbody can adjust the orientation of the sensors. This can affect the parking aid function. Have the function checked by a specialised workshop.

i Note

• In certain situations, the system can give a warning even though there is no obstacle in the detected area, e.g:

- with rough or cobbled floors or ground with long grass;
- with external ultrasound sources, such as cleaning vehicles or other vehicles;
- In downpours, intense snow or dense exhaust gases;
- if the registration plate (front or rear) is not properly affixed to the bumper surface;
- or in locations such as the brow of a hill.
- In order to guarantee good system operation, keep the ultrasound sensors clean, free of snow or ice, and do not cover them with adhesives or other objects.
- If you use high-pressure or vapour equipment to clean the ultrasound sensors, apply

it directly only very briefly and always from a distance of more than 10 cm.

• Retrofitting of accessories to the vehicle, such as a bicycle rack, may interfere with the operation of the Parking Aid.

• In order to familiarise yourself with the system, it is advised that you practice parking in an area or car park that is free from traffic. There must be good weather and light conditions.

• The volume and tone of the warnings can be modified, in addition to the indications >>> page 177.

• In vehicles without a driver information system, these parameters can be modified in a SEAT Official Service or in a specialised workshop.

• Please observe information on towing a trailer >>> page 177.

• The display on the Easy Connect screen shows a slight time delay.

Rear parking aid*

The rear Parking Aid assists the driver in parking by means of audible warning sounds.

Description

There are sensors integrated in the rear bumper. When the sensors detect an obstacle, you are alerted by audible warnings. Make particularly sure that the sensors are not covered by adhesives, residues and the like, as this could affect the system's operation. Cleaning instructions **»** page 191.

The approximate measurement range of the rear sensors is:

side area	0.60 m
central area	1.60 m


If you maintain separation from the obstacle, the volume of the warning begins to reduce after four seconds (does not affect the tone of the constant warning).

Activating/Deactivating

When engaging reverse gear, the parking aid is automatically switched on. This is confirmed with a short warning.

On disengaging reverse gear, the Parking Aid system is disconnected immediately.

Parking system plus*



Parking system plus assists you audibly and visually when parking.

There are sensors integrated in the front and rear bumpers. When they detect an obstacle, you are alerted by audible warnings and visually on the Easy Connect system.

In the event of danger of a frontal collision, the audible warnings come from the front of the vehicle, and in the event of the danger of a rear-end collision they come from the rear.

Make particularly sure that the sensors are not covered by adhesives, residues and the like, as this could affect the system's operation. Cleaning instructions **»** page 191.

The approximate measurement range of the sensors is:

(A) 1.20 m

B 0.60 m

- C 1.60 m
- **D** 0.60 m

As you approach the obstacle, the time interval between the audible warnings will be reduced. When you reach around 0.30 m the warning will be constant: do not continue to move forward (or backward)!

If you maintain separation from the obstacle, the volume of the warning begins to reduce after four seconds (does not affect the tone of the constant warning).

Parking Aid operation



Fig. 165 Centre console: parking aid butto

Manual connection of Parking Aid

• Press the Pm button once.

Driver assistance systems

Manual disconnection of Parking Aid

• Press the P^M button *again*.

Manual disconnection of Parking Aid display (the audible sounds remain active)

• Press a button on the main menu of the factory-assembled infotainment system.

• OR: press the BACK function button.

Automatic connection of Parking Aid

• Engage reverse gear or turn the selector lever to position **R**.

• OR: If the vehicle approaches an obstacle that is in its forwards path at a speed below 10 km/h (6 mph) »> page 175, Automatic activation. The obstacle is detected as of a distance of approx. 95 cm if the automatic connection is activated in the infotainment system. A reduced display is shown.

Automatic disconnection of Parking Aid

- Move the selector lever to position P.
- **OR**: accelerate to more than approx. 10 km/h (6 mph) forward.

Temporary suppression of sound in Parking Aid

 \bullet Press the ${\ensuremath{\mathbb T}}$ function button found on the steering wheel.

Change from reduced view to full view

- Engage reverse gear or turn the selector lever to position **R**.
- OR: press the car icon in reduced view.

If necessary, switch to the rear-assist image (Rear View Camera "RVC")

- Engage reverse gear or turn the selector lever to position **R**.
- OR: Press the RVC function button.

A short confirmation signal will be heard and the button symbol will light up yellow when the system is switched on.

Automatic activation



Fig. 166 Miniature indication of automatic activation

When the Parking System Plus is switched on automatically, a miniature of the vehicle will

be displayed and the segments will be shown on the left side of the screen **» Fig. 166**.

Automatic activation occurs when slowly approaching an obstacle located in front of the vehicle. It only operates every time the speed is reduced below approximately 10 km/h (6 mph) for the first time.

If the parking aid is switched off using the P^{AL} button, the following actions must be carried out in order for it to automatically switch on:

- Switch off the ignition and switch it on again.
- **OR**: accelerate above 10 km/h (6 mph) before reducing speed below this number again.
- **OR**: place the selector lever in position **P** and then move it from this position.
- **OR**: switch on and off the automatic activation in the Easy Connect system menu.

The automatic activation with parking aid miniature indication can be switched on and off from the Easy Connect system menu **page 24**:

• Switch the ignition on.

• Select: CAR button > Settings > Parking and manoeuvring.

• Select the **Automatic activation** option. When the function button check box is activated \mathbf{G} , the function is on.

Operation

If the system has been activated automatically, an audible sound warning will only be given when obstacles in front are at a distance of less than 50 cm.

() CAUTION

The automatic connection of the Parking Aid only works when you are driving slowly. If driving style is not adapted to the circumstances, an accident and serious injury or damage may be caused.

Segments of the visual indication



Fig. 167 Parking Aid display on the Easy Connect system screen.

The distance of separation from the obstacle can be estimated using the segments around the vehicle.

The optical indication of the segments works as follows:

- White segments: a white segment is dis
 - played when the obstacle is not within the vehicle's trajectory or the direction of travel is in the opposite direction to its location, and it is more than 30 cm from the vehicle.
- Yellow segments: obstacles located in the vehicle's trajectory and which are more than 30 cm away from the vehicle are displayed in yellow.
- **Red segments:** obstacles that are less than 30 cm away from the vehicle are displayed in red.

Moreover, with the SEAT Media System Plus/Navi System radios, a yellow trail indicates the vehicle's expected journey based on the steering wheel angle.

Whenever the obstacle is located in the vehicle's direction of travel, the corresponding audible warning will sound.

As the vehicle approaches an obstacle, the segments are displayed closer to the vehicle. When the penultimate segment is displayed, this means that the vehicle has reached the collision zone. In the collision zone, the obstacles are represented in red, including those out of the path. Do not continue to move forward (or backward) $\gg \Delta$ in General information on page 173, $\gg 0$ in General information on page 173 !

Driver assistance systems

Adjusting the display and audible warnings

The settings for the display and audible warnings are controlled via the Easy Connect*.

Automatic activation

✓ on – activates the Automatic activation option >>> page 175.

□ off - deactivates the Automatic activation option >>> page 175.

Front volume*

Volume in the front and rear area.

Front sound settings/sharpness*

Frequency (tone) of the sound in the front area.

Rear volume*

Volume in the rear area.

Rear sound settings/sharpness*

Frequency (tone) of the sound in the rear area.

Adjust volume

With the parking aid switched on, the active audio/video source volume will be reduced to the intensity of the selected setting.

Error messages

When the Parking Aid is activated or when it is switched on, if a message reporting a Parking aid error is displayed on the instrument panel, there is a fault in the system.

If the fault doesn't disappear before disconnecting the ignition, next time that parking aid is engaged in reverse, it will not be indicated.

Parking System Plus*

If there is a fault in the parking aid system a message will appear on the instrument panel indicating the error. In addition the P®L key LED will blink.

If there is a fault in a sensor, the symbol \triangle is displayed on the Easy Connect display in front of/behind the vehicle. If a rear sensor is faulty, only the obstacles in the areas (A) and (B) are displayed **W** Fig. 164. If a front sensor is faulty, only the obstacles in the areas (C) and (D) are displayed.

Have the fault corrected by a specialised workshop without delay.

Towing bracket

In vehicles equipped with a towing bracket device from the factory, when the trailer is connected electrically, the Parking Aid rear sensors will not be activated when reverse gear is engaged, when the selector lever is turned to position ${\bm R}$ or when the button ${\bm P}_{\text{Pl}}$ is pressed.

Parking System Plus

The distance to possible obstacles at the rear of the vehicle will not be displayed on the screen and nor will it be indicated by means of audible sound signals.

The Easy Connect system screen will only display objects detected at the front, and the vehicle's trajectory will be hidden.

Rear Assist "Rear View Camera"*

Operating and safety warnings

• The Rear Assist does not make it possible to precisely calculate the distance from obstacles (people, vehicles, etc.) and nor can it overcome the system's own limits, hence using it may cause serious accidents and injuries if used negligently or without due care. The driver should be aware of his/her surroundings at all times to ensure safe driving.

• The camera lens expands and distorts the field of vision and displays the objects on the

screen in a different, vague manner. The perception of distances is also distorted by this effect.

 Some objects may, due to the resolution of the display screen - not be displayed in a satisfactory manner or may not be displayed at all. Take special care with thin posts, fences, railings or trees that might not be displayed on screen and could damage the vehicle.

• The rear assist has blind spots where it is not possible to represent people or objects (small children, animals and certain objects cannot be detected in its field of vision). Monitor the vehicle's surrounding area at all times.

• Keep the camera lens clean, free of ice and snow, and do not cover it.

• The system is not a replacement for driver awareness. Supervise the parking operation at all times, as well as the vehicle's surrounding area. Adapt your speed and driving style at all times to suit visibility, weather, road and traffic conditions.

• Do not be distracted from the traffic by looking at the screen.

 The images on the rear assist screen are only two-dimensional. Due to a lack of spatial depth, protruding parts or holes in the road, for example, are more difficult to detect or may not be seen at all.

 Vehicle load modifies the representation of the orientation lines displayed. The width represented by the lines diminishes with vehicle load. Pay special attention to the vehicle's surroundings when the inside of the vehicle of the luggage compartment is carrying a heavy load.

• In the following situations, the objects or other vehicles shown in the navigation system display appear to be further away or closer than they really are: Pay special attention:

- On moving from a horizontal plane to a slope.
- On moving from a slope to a horizontal plane.
- If the vehicle is heavily loaded at the rear.
- When the vehicle approaches objects that are not on the ground surface or are jutting out from it. These objects may also be outside the camera's angle of vision when reversing.

i Note

• It is important to take great care and pay special attention if you are not yet familiar with the system.

• Rear assist will not be available if the vehicle's rear lid is open.

Instructions for use




Fig. 168 On the rear bumper: location of the rear assist camera

📂 » table on page 2

A camera on the rear bumper aids the driver during reverse parking or manoeuvring **>>> Fig. 168.** The camera image is viewed together with orientation lines projected by the system on the Infotainment system screen. The bottom of the screen displays part of the bumper corresponding to the number plate area that will be used as reference by the driver.

Rear assist settings:

Rear assist offers the user the possibility to change the image's *brightness*, *contrast* and *colour* settings.

To change these settings:

• Park the vehicle in a safe place.

Driver assistance systems

- Apply the parking brake.
- Switch the ignition on.
- If necessary, switch on the Infotainment system.
- Engage reverse gear or turn the selector lever to position **R**.
- Press the ** function button displayed on the right of the image.
- Make the desired adjustments on the menu by pressing the -/+ function buttons or by moving the corresponding scroll button.

Necessary conditions for parking and manoeuvring with the rear assist

The system should not be used in the following cases:

- If the image displayed is not very reliable or is distorted, for example low visibility or dirty lens.
- If the area behind the vehicle is not displayed very clearly or is incomplete.
- If the vehicle is heavily loaded at the rear.
- If the position and installation angle of the camera have been changed, e.g. after a rearend collision. Have the system checked by a specialised workshop.

Familiarising yourself with the system

To familiarise yourself with the system, the orientation lines and their function, SEAT rec-

ommends practising parking and manoeuvring with the rear assist in a place without too much traffic or in a car park when there are good weather and visibility conditions.

Cleaning the camera lens

Keep the camera lens clean and clear of snow and ice:

- Moisten the lens using a normal alcoholbased glass cleaning product and clean the lens with a dry cloth.
- Remove snow using a small brush.
- Use de-icing spray to remove any ice.

() CAUTION

• Never use abrasive cleaning products to clean the camera lens.

• Do not use hot or warm water to remove ice or snow from the camera lens. Doing so could damage the camera.

Parking and manoeuvring with the rear assist




Fig. 169 Display on the Infotainment system screen: orientation lines.

Switching the system on and off

- The rear assist will switch on when the ignition is on or the engine running, on engaging reverse gear (manual gearbox) or on changing the selector lever to the **R** position (automatic gearbox).
- The system switches off 8 seconds after disengaging reverse gear (manual gearbox) or removing the selector lever from the **R** position (automatic gearbox). The system will also disconnect immediately after the ignition is switched off.
- The camera will stop transmitting images above the speed of 15 km/h (9 mph) with reverse engaged.

Operation

>>

Operation

In combination with the Parking System Plus **>>> page 173**, the camera image will cease to be transmitted immediately when reverse gear is disengaged or when the selector lever is moved from the **R** position, and the optical information provided by the Parking Aid system will be displayed.

Also in combination with the system, the rear assist image can also be concealed:

• By pressing one of the Infotainment system buttons on the display.

• **OR**: By pressing the miniature vehicle that appears on the left of the screen (which switches to the full-screen mode of the Parking System Plus's optical system).

If you wish to display the rear assist image again:

- Disengage reverse, or change the selector lever's position, engage reverse again or move the selector lever to position **R**.
- OR: Press the RVC function button¹⁾

Meaning of the orientation lines

>>> Fig. 169

- Side lines: extension of the vehicle (the approximate width of the vehicle plus the rear view mirrors) on the road surface.
- (2) End of the side lines: the area marked in green ends approximately 2 m behind the vehicle on the road surface.
- Intermediate line: indicates a distance of approximately 1 m behind the vehicle on the road surface.
- 4 Red horizontal line: indicates a safe distance of approximately 40 cm at the rear of the vehicle on the road surface.

Parking manoeuvre

- Place the vehicle in front of the parking space and engage reverse gear (manual gearbox) or move the selector to the **R** position (automatic gearbox).
- Reverse slowly, and turn the steering wheel so that the side orientation lines lead to-wards the parking space.
- Guide the vehicle into the parking space so that the side orientation lines run parallel to it.

Cruise speed* (cruise control - GRA)

Operation



Fig. 170 Turn signal and main beam headlight lever: switch and rocker switch for the cruise control.

Read the additional information carefully

The CCS is able to maintain the set speed in the range from approx. 30 km/h (19 mph) to 180 km/h (112 mph).

Once the speed setting has been saved, you may take your foot off the accelerator.

¹⁾ WARNING: the **RVC** (Rear View Camera) function button will only be activated and available when the reverse gear is engaged or the selector lever is set to position **R**.

When the cruise control is on and a speed is programmed, the indicator on the instrument panel* is lit.

If the cruise control system is *switched off*, the for symbol is switched off. The system will also be switched off fully when the **1st** gear is engaged.*

Switching on the cruise control system

• Move the switch **>>> Fig. 170** (1) towards the left to **ON**.

Setting speed

• Briefly press the lower part of the rocker switch SET- **»** Fig. 170 (2) once when you have reached the speed you wish to set.

When you release the rocker switch, the current speed is set and held constant.

Switching off the cruise control system

• Move the control (1) towards the right to **OFF** or turn the ignition off if the vehicle is stationary.

▲ WARNING

It could be dangerous to use the cruise control system if it is not possible to drive at constant speed.

• Do not use the cruise control system when driving in dense traffic, on roads with lots of bends or on roads with poor conditions (with ice, slippery surfaces, loose grit or gravel), as this could cause an accident.

 Always switch the cruise control system off after using it in order to avoid involuntary use.

• It is dangerous to use a set speed which is too high for the current road, traffic or weather conditions. Risk of accident.

i Note

The cruise control cannot maintain a constant speed when descending downhill. It will increase due to its own weight. Use the foot brake to slow the vehicle.

Adjusting the stored speed*

The speed can be altered without touching the accelerator or the brake.

Setting a higher speed

 Press the upper part of the rocker switch RES+ w Fig. 170 (2) to increase the speed. The vehicle will continue to accelerate as long as you keep the rocker switch pressed. When you release the switch, the new speed is stored.

Setting a lower speed

• Press the lower part of the rocker switch **SET- »Fig. 170 (2)** to reduce the speed. The

vehicle will automatically reduce its speed for as long as you keep the switch pressed. When you release the switch, the new speed is stored.

When you increase speed with the accelerator and then release the pedal, the system will automatically restore the set speed. This will not be the case, however, if the vehicle speed exceeds the stored speed by more than 10 km/h (6 mph) for longer than 5 minutes. The speed will have to be stored again.

Cruise control is switched off if you reduce speed by depressing the brake pedal. Reactivate the control by pressing once on the upper part of the rocker switch **RES+ w Fig. 170 (2)**.

Temporary deactivation of cruise control*

The cruise control system will be switched off in the following situations:

- if the brake pedal is depressed,
- if the clutch pedal is depressed,
- if the vehicle is accelerated to over 180 km/h (112 mph),
- when the lever 1 is moved in the direction
- of **OFF** without being fully engaged.

Operation

To resume cruise control, release the brake or clutch pedal or reduce the vehicle speed to less than 180 km/h (112 mph) and press once on the upper part of the rocker switch RES+ Fig. 170 (2).

Complete system deactivation

Vehicles with a manual gearbox

The system **is completely turned off** by moving the control **w Fig. 170** (1) all the way to the right hand side (set into the OFF position), or when the vehicle is stationary, switching off the ignition.

Vehicles with an automatic gearbox

To completely disengage the system, the selector lever must be placed in one of the following positions: **P**, **N**, **R** or **1** or with the vehicle stopped and the ignition turned off.

"SEAT Drive Profile" system

Function and operation



Fig. 171 In the centre console: button to adjust the "SEAT Drive Profile" system

The "SEAT Drive Profile" system modifies the suspension system's characteristics and power steering behaviour.

you can choose between 2 different settings with different characteristics.

CONVEN-	Balanced setting, suitable, e.g. for day-to-
IENCE	day use.
SPORT	This gives the vehicle sporty characteristics and is suitable for a sporty driving style.

Settings can be changed when the vehicle is stationary or in movement. When a "SEAT Drive Profile" setting is changed it is activated immediately.

Selecting the system setting

• If necessary, switch on the ignition.

• To select **SPORT** mode, press the **SPORT >>> Fig. 171** button until it lights up.

The **CONVENIENCE** mode is active when the **(FYORT)** button is not lit. The set mode remains selected after the ignition is switched off.

CUPRA vehicle version

The modes of operation for the CUPRA are Normal and Sport rather than Comfort and Sport. The vehicle always starts up in Normal. The last selection does not remain once the vehicle is turned off.

Adjusting the "SEAT Drive Profile" modifies driving properties. The "SEAT Drive Profile" system should never encourage you to take risks.

• Adapt your speed and driving style at all times to suit visibility, weather, road and traffic conditions.

🛆 WARNING

If the warning lamps and the corresponding messages are ignored when they light up, the vehicle may stall in traffic and cause accidents and severe injuries.

• Never ignore the warning lamps or messages.

 Stop the vehicle at the next opportunity and in a safe place.

CAUTION (

Failure to heed the control lamps and corresponding text messages when they light up may result in damage to the vehicle.

i Note

If the "SEAT Drive Profile" system presents a fault, the § symbol appears on the instrument panel, with the message Fault: Damping setting.

Indication on the display and warning lamp

Ô

There is a fault in the "SEAT Drive Profile" suspension.

See a specialised workshop immediately and have the "SFAT Drive Profile" suspension checked. If the yellow warning lamp does not light up again after the engine is restarted and the vehicle has travelled a short distance, you do not need to take it to a specialised workshop.

Some warning and control lamps will light up briefly when the ignition is switched on to check certain functions. They will switch off after a few seconds.

∧ WARNING

If the warning lamps and the corresponding messages are ignored when they light up, the vehicle may stall in traffic and cause accidents and severe injuries.

• Never ignore the warning lamps or messag-

es.

∧ WARNING

Changing the "SEAT Drive Profile" settings while the vehicle is in motion can distract you from the road and lead to accidents.

() CAUTION

Failure to heed the control lamps when they light up and the corresponding messages may result in damage to the vehicle.

i Note

If the "SEAT Drive Profile" system does not work as described in this chapter, have it checked immediately by a specialised workshop.

Towing bracket device and trailer

Trailer mode

What do you need to bear in mind when towing a trailer?

Your vehicle may be used to tow a trailer when fitted with the correct equipment.

If the car is supplied with a factory-fitted towing bracket it will already have the necessary technical modifications and meet the statutory requirements for towing a trailer. If you wish to retrofit a towing bracket, consult >>> page 185.

Connectors

Your vehicle is fitted with a 12-pin connector for the electrical connection between the trailer and the vehicle.

If the trailer has a 7-pin plug you will need to use an adapter cable. It is available at any Technical Service.

Trailer weight/drawbar load

Never exceed the authorised trailer weight. If you do not load the trailer up to the maximum permitted trailer weight, you can then climb correspondingly steeper slopes. »

Operation

The maximum trailer weights listed are only applicable for **altitudes** up to 1000 m above sea level. With increasing altitude the engine power and therefore the vehicle climbing ability are impaired because of the reduced air density. The maximum trailer weight has to be reduced accordingly. The weight of the vehicle and trailer combination must be reduced by 10% for every further 1000 m (or part thereof). The gross combination weight is the actual weight of the laden vehicle plus the actual weight of the laden trailer. When possible, operate the trailer with the maximum permitted drawbar load on the ball joint of the towing bracket, but do not exceed the specified limit.

The figures for **trailer weights** and **drawbar loads** that are given on the data plate of the towing bracket are for certification purposes only. The correct figures for your specific model, which may be *lower* than these figures for the towing bracket, are given in the vehicle documentation or in **»** chapter Technical Data.

Distributing the load

Distribute loads in the trailer so that heavy objects are as near to the axle as possible. Loads carried in the trailer must be secured to prevent them moving.

Tyre pressure

Set tyre pressure to the maximum permissible pressure shown on the sticker on the inside of the fuel tank flap. Set the tyre pressure of the trailer tyres in accordance with the trailer manufacturer's recommendations.

Exterior mirrors

Check whether you can see enough of the road behind the trailer with the standard rear vision mirrors. If this is not the case, you should have additional exterior mirrors fitted. Both exterior mirrors should be mounted on hinged extension brackets. Adjust the mirrors to give sufficient vision to the rear.

A WARNING

Never transport people in a trailer. This could result in fatal accidents.

i Note

 Towing a trailer places additional demands on the vehicle. We recommend additional services between the normal inspection intervals if the vehicle is used frequently for towing a trailer.

• Find out whether special regulations apply to towing a trailer in your country.

Ball coupling of towing bracket*

The ball coupling is provided with instructions on fitting and removing the ball coupling of the towing bracket.

The towing bracket ball coupling must be stored securely in the luggage compartment to prevent them being flung through the vehicle and causing injury.

i Note

• By law, the ball coupling must be removed if a trailer is not being towed if it obscures the number plate.

Driving tips

Driving with a trailer always requires extra care.

Weight distribution

The weight distribution of a loaded trailer with an unladen vehicle is very unfavourable. However, if this cannot be avoided, drive extra slowly to allow for the unbalanced weight distribution.

Speed

The stability of the vehicle and trailer is reduced with increasing speed. For this reason, it is advisable not to drive at the maximum permissible speed in an unfavourable road, weather or wind conditions. This applies especially when driving downhill.

You should always reduce speed immediately if the trailer shows the slightest sign of **snaking**. Never try to stop the "snaking" by increasing speed.

Always brake in due course. If the trailer has an **overrun brake**, apply the brakes *gently at first* and then, firmly. This will prevent the jerking that can be caused by locking of trailer wheels. Select a low gear in due course before going down a steep downhill. This enables you to use the engine braking to slow down the vehicle.

Reheating

At very high temperatures and during prolonged slopes, driving with a low gear and high engine speed; always monitor whether the excessive coolant temperature gauge is activated **w** page 204.

Retrofitting a towing bracket*




Fig. 172 IBIZA/IBIZA SC: attachment points for towing bracket.

If a towing bracket is to be fitted after the vehicle is purchased, this must be completed according to the instructions of the towing bracket manufacturer. The attachment points A for the towing bracket are underneath the vehicle.

The distance between the centre of the ball coupling and the ground should never be lower than the indicated value, even with a fully loaded vehicle and including the maximum drawbar load.

Elevation values for securing the towing bracket:

	IBIZA/IBIZA SC
B	65 mm (minimum)
0	350 mm to 420 mm (fully laden vehicle)
D	959 mm
E	438 mm
(1)	209 mm

Fitting a towing bracket

• Driving with a trailer involves an extra effort for the vehicle. Therefore, before fitting a towing bracket, please contact a Technical Service to check whether your cooling system needs modification.

• The legal requirements in your country must be observed (e.g. the fitting of a separate control lamp).

• Certain vehicle components, for example the rear bumper, must be removed and reinstalled. The towing bracket securing bolts must be tightened using a torque wrench,

Operation

and a power socket must be connected to the vehicle electrical system. This requires specialised knowledge and tools.

• Figures in the illustration show the elevation value and the attachment points which must be considered if you are retrofitting a towing bracket.

▲ WARNING

The towing brackets should be fitted at a specialised workshop.

• If the towing bracket is incorrectly installed, there is a serious danger of accident.

• For your own safety, please observe the tow bracket manufacturer's instructions.

() CAUTION

• If the power socket is incorrectly installed, this could cause damage to the vehicle electrical system.

i Note

• SEAT recommends that the towing hooks be fitted at a specialised workshop. In certain versions this may entail fitting a heat insulating plate, which is why it is recommended that you go to a SEAT Dealer. In the event that the plate is not installed correctly, SEAT is exempt from any liability.

• Due to the specific design of the exhaust, the fitting of a conventional towing hook is

not recommended for some sportier versions. Please consult your Technical Service.

Care and maintenance

Advice

Care and maintenance

Accessories and modifications to the vehicle

Accessories, replacement of parts and modifications

Your vehicle is designed to offer a high standard of active and passive safety.

Before purchasing accessories and parts, and before making technical changes to your vehicle, we recommend that you consult your Technical Service.

SEAT dealerships will be happy to provide you with the latest information about the use, legal requirements and recommendations from the manufacturer regarding accessories and spare parts.

We recommend you use only SEAT Approved Accessories® and SEAT Approved Spare

Parts®. This way, SEAT can guarantee that the product in question is suitable, reliable and safe. SEAT Technical Services have the necessary experience and facilities to ensure that parts are correctly and professionally installed. Despite a continuous observation of the market, SEAT is not able to assess the reliability, safety and suitability of parts that **SEAT has not approved**. For this reason, SEAT cannot assume responsibility for any non-genuine parts used, even if these parts have been approved by an official testing agency or are covered by an official approval certificate.

Any **retro-fitted equipment** which has a direct impact on the driver's control of the vehicle, such as a cruise control system or electronically-controlled suspension, must be approved by SEAT for use in your vehicle and bear the **e** mark (the European Union's authorisation symbol).

If **any additional electrical devices** are fitted which do not serve to control the vehicle itself, such as refrigerator boxes, laptops or ventilator fans, they must bear the **CE** mark (European Union manufacturer conformity declaration).

∆ WARNING

Accessories, for example telephone holders or cup holders, should never be fitted on the covers, or within the working range, of the airbags. Otherwise, there is a danger of injury if the airbag is triggered in an accident.

Modifications

Modifications must always be carried out according to our specifications. Unauthorised modifications to the electronic components or software in the vehicle may cause malfunctions. Due to the way the electronic components are linked together in networks, other indirect systems may be affected by the faults. This can seriously impair safety, lead to excessive wear of components, and also invalidate your vehicle registration documents.

SEAT Technical Services cannot be held liable for any damage caused by modifications and/or work incorrectly performed. For this reason, we recommend having all work performed by a SEAT Technical Service using **SEAT**[®] Original Spare Parts.

Any type of work or modification performed incorrectly on your vehicle can lead to malfunctions and can cause accidents.

Roof aerial*

The vehicle can be fitted with a foldable* and anti-theft* roof aerial which can be folded backwards, for example when going through an automatic car wash.

187

To fold

Unscrew the aerial rod, tilting it backwards into a horizontal position and then screw in again.

To return to working position

Continue in the reverse order to the previous instruction.

() CAUTION

If an automatic car wash tunnel is used, before entering the tunnel, put the aerial down parallel to the roof and do not tighten to avoid damage.

Mobile phones and two-way radios

SEAT has approved for your vehicle the use of mobile telephones and two-way radios providing under the following conditions:

• The external aerial should be correctly installed.

• The transmitting power should be a maximum 10 watts.

The optimal reach of the equipment is only achieved with an external aerial.

First consult your Technical Service if you wish to use a mobile telephone or a two-way radio with a transmitting power output in excess of 10 watts. Here you will receive information concerning the technical possibilities for retrofitting this equipment.

Mobile telephones and two-way radios should be only fitted by a specialised workshop, for example a SEAT dealership.

▲ WARNING

• Always concentrate primarily on driving. If you are distracted while driving you could have an accident.

 Never attach the telephone mountings to the surfaces covering the airbag units or within the range of the airbags. There is a high danger of injury if the airbag is triggered.

• Using your mobile telephones or two-way radios in the vehicle without an external aerial, electromagnetic radiation in the vehicle could exceed authorised limits. This also may occur to external aerials that have not been correctly installed.

() CAUTION

Failure to consider the above-mentioned conditions could cause the electronics to malfunction. The most common causes of faults are:

- no external aerial,
- · external aerial incorrectly installed,
- transmitting power output in excess of 10 watts.

i Note

Please observe the operating instructions of your mobile telephone/two-way radio.

Care and cleaning

General notes

Vehicle maintenance

Regular care and washing help to **maintain the value** of the vehicle. This may also be one of the requirements for acknowledging warranty claims in the event of bodywork corrosion or paint defects.

The best way to protect your vehicle against the harmful effects of the environment is through correct maintenance and *frequent* washing. The longer substances such as insect remains, bird droppings, resinous tree sap, road dirt, industrial deposits, tar, soot or road salt and other aggressive materials remain on the vehicle, the more damage they do to the paintwork. High temperatures, for instance in strong sunlight, further intensify the corrosive effect.

After winter, a period when salt is put on the roads, it is important to have the **underside** of the vehicle washed thoroughly.

Care and maintenance

Products for vehicle maintenance

Car-care products are available in your Technical Services. Keep the product instructions until you have used them up.

🛆 WARNING

 Car-care products can be toxic. Because of this, they must always be kept closed in their original container. Keep them out of the reach of children. Failure to comply could result in poisoning.

 Always read and observe the instructions and warnings on the package before using car-care products. Improper use could cause health problems or damage the vehicle. The use of certain products may produce noxious vapours; they should be used in well ventilated areas.

• Never use fuel, turpentine, engine oil, nail varnish remover or other volatile fluids. These are toxic and highly flammable. Risk of fire and explosion.

• Before washing your vehicle, or carrying out any maintenance, switch the engine off, apply the handbrake firmly and remove the key from the ignition.

() CAUTION

Never attempt to remove dirt, mud or dust if the surface of the vehicle is dry. Never use a dry cloth or sponge for cleaning purposes. This could damage the paintwork or the windows of your vehicle. Soak dirt, mud or dust with plenty of water.

🛞 For the sake of the environment

• When purchasing car care products, try to select ones that are not harmful to the environment.

• The waste from car-care products should not be disposed of with ordinary household waste. Observe the disposal information on the package.

Care of the vehicle exterior

Automatic car wash tunnel

The vehicle paintwork is so durable that the vehicle can normally be washed without problems in an automatic car wash tunnel. However, the paintwork wear depends to a large extent on the kind of the car wash tunnel, the brushes used, its water filtering and the type of cleaning and preservative products.

Before going through a car wash, be sure to take the usual precautions such as closing the windows and sunroof. There is nothing to note apart from that.

If the vehicle has special accessories such as spoilers or a roof rack or two-way radio aerial, etc., it is advisable to consult the car wash tunnel operator first. After washing, **the brakes** could take some time to respond as the brake discs and pads could be wet, or even frozen in winter. "Dry" the brakes by braking several times.

Water, ice and salt on the brake system can reduce braking effectiveness. Risk of accident.

() CAUTION

Before putting the vehicle through the car wash, do not tighten the aerial if it is folded because it can be damaged.

Hand-washing

Vehicle washing

- First soften the dirt and rinse it off with water.
- Clean your vehicle from top to bottom with a soft sponge, a glove or a brush. Use very light pressure.
- Rinse the sponge or glove often with clean water.
- Special car shampoo should only be used for very stubborn dirt.
- Leave the wheels, sill panels etc. until last, using a different sponge or glove.

- Rinse the vehicle thoroughly with water.
- Dry the vehicle surface gently with a chamois leather.
- In cold temperature, dry the rubber seals and their surfaces to prevent them from freezing. Apply silicone spray to the rubber seals.

After washing the vehicle

 After washing, avoid sudden and sharp braking. "Dry" the brakes by braking several times.

▲ WARNING

- Wash your vehicle with the ignition switched off.
- Protect your hands and arms from cuts on sharp metal edges when cleaning the underbody, the inside of the wheel housings etc. Risk of injury.
- Water, ice and salt on the brake system can reduce braking effectiveness. Risk of accident.

() CAUTION

 Never remove dirt, mud or dust if the vehicle surface is dry. Never use a dry cloth or sponge for cleaning purposes. This could scratch the paintwork or glass on your vehicle. • Washing the vehicle in low temperatures: when washing the vehicle with a hose, do not direct water into the lock cylinders or the gaps around the doors, rear lid, or sunroof. Risk of freezing.

🛞 For the sake of the environment

To protect the environment, the vehicle should be washed only in specially provided wash bays, to prevent toxic, oil-laden waste water from entering the sewer system. In some places, washing vehicles outside wash bays is prohibited.

i Note

Do not wash the vehicle in direct sunlight.

Washing the vehicle with a high pressure cleaner

Be particularly careful when using a high pressure cleaner!

- Always observe the instructions for the high-pressure cleaner, particularly those concerning the pressure and the spraying distance.
- Increase the spraying distance for soft materials and painted bumpers.

- Do not use a high pressure cleaner to remove ice or snow from windows
 >>> page 192.
- Never use concentrated jet nozzles ("rotating jets") » ▲.
- After washing, avoid sudden and sharp braking. "Dry" the brakes by braking several times **>>> page 149**.

∆ WARNING

- Never wash tyres with a concentrated jet ("rotating nozzle"). Even at large spraying distances and short cleaning times, damage can occur to the tyres. This may cause an accident.
- Water, ice and salt on the brake system can reduce braking effectiveness. Risk of accident.

() CAUTION

- Do not use water hotter than +60°C (+140°F). This could damage the vehicle.
- To avoid damage to the vehicle, keep a sufficient distance from sensitive materials such as flexible hoses, plastic, soundproofing material, etc. This also applies to bumpers painted in the colour of the bodywork. The closer the nozzle is to the surface, the greater the wear on the material.

Care and maintenance

Stickers attached by the factory

Follow these directions to avoid damaging the stickers:

- Do not use high pressure cleaners.
- To remove ice or snow from the stickers do not use window scrapers or ice scrapers.
- Do not polish the stickers.
- Do not use dirty cloths or sponges.
- Preferably wash using a soft sponge and soft neutral soap.

Sensors and camera lenses

- Use a small brush to remove snow and a de-icer spray to remove ice.
- Clean the sensors with a solvent-free product and a soft, dry cloth.
- Moisten the camera lens using a standard alcohol-based glass cleaning agent and clean the lens with a dry cloth.

() CAUTION

- When you clean the vehicle with a pressure washer:
 - Stay a suitable distance from the sensors on the front and rear bumpers.
 - Do not clean the camera lenses or surrounding area with the pressure washer.

• Never use warm or hot water to remove snow and ice from the reverse camera lens, as it could crack the lens.

• Never use abrasive cleaning agents on the lens.

Vehicle paint maintenance

Regular waxing protects the paintwork.

You need to apply wax to your vehicle if water does not form small drops and run off the paintwork when it is *clean*.

Good quality *hard wax products* are available at your Technical Service.

Regular wax applications help to protect the paintwork from environmental contaminants **>>> page 188**. It is also effective in protecting against minor scratches.

Even if a **wax solution** is used regularly in the vehicle washing tunnel, it is advisable to protect the paint with a hard wax coating at least twice a year.

Polishing the paintwork

Polishing is only necessary if the paint has lost its shine, and the gloss cannot be brought back by applying wax. Polishing products can be purchased in your Technical Service. The vehicle must be waxed after polishing if the polish used does not contain wax compounds to seal the paint **»» page 191, Vehicle paint maintenance.**

() CAUTION

To prevent damage to the paintwork:

• Do not use polishes and hard wax on painted parts with a matt finish or on plastic parts.

• Do not polish your vehicle in a sandy or dusty environment.

Caring for plastic parts

If normal washing fails to clean plastic parts, clean them with approved **solvent-free** plastic cleaning and care products.

() CAUTION

• The use of liquid air freshener directly over the air vents of the vehicle may damage the plastic parts if the liquid is accidentally spilled.

• Cleaning products which contain solvents will damage the material.

Cleaning of windows and mirrors

Cleaning windows

- Moisten the windows with commercially available, alcohol based glass cleaner.
- Dry the windows with a clean chamois leather or a lint-free cloth.

Removing snow

- Use a small brush to remove snow from the windows and mirrors.

Removing ice

- Use a de-icer spray.

Use a clean cloth or chamois leather to dry the windows. The chamois leathers used on painted surfaces are not suitable to clean windows because they are soiled with wax deposits which could smear the windows.

If possible, use a de-icing spray to remove ice. If you use an ice scraper, push it in one direction only without swinging it.

Use window cleaner or a silicone remover to clean rubber, oil, grease and silicone deposits off.

Wax deposits can only be removed with a special cleaner available at your Technical Service. Wax deposits on the windscreen could cause the wiper blades to judder. Adding a window cleaner that dissolves wax to

the windscreen washer fluid prevents wiper blades from juddering, but wax deposits are not removed.

() CAUTION

- Never use warm or hot water to remove snow and ice from windows and mirrors. This could cause the glass to crack!
- The heating element for the rear window is located on the inner side of the window. To prevent damage, do not put stickers over the heating elements on the inside of the window.

Cleaning windscreen wiper blades

Clean wiper blades improve visibility.

- 1. Use a soft cloth to remove dust and dirt from the windscreen wiper blades.
- 2. Use window cleaner to clean the windscreen wiper blades. Use a sponge or a cloth to remove stubborn dirt.

Care of rubber seals

If rubber seals are well looked after, they will not freeze so quickly.

1. Use a soft cloth to remove dust and dirt from the rubber seals.

2. Apply a specialist care product to the rubber seals.

The rubber strips on the doors, windows, etc. will remain pliable and last longer if they are treated with a suitable rubber care product from time to time (for example silicone spray).

Caring for rubber seals will also prevent premature ageing and leaks. The doors will be easier to open. If rubber seals are well looked after, they will not freeze so quickly in winter.

Door lock cylinder

The door lock cylinders can freeze up in winter.

To de-ice the lock cylinders you should only use spray with lubricating and anti-corrosive properties.

Cleaning chrome parts

- 1. Clean chrome parts with a damp cloth.
- 2. Polish chrome parts with a soft, dry cloth.

If this does not provide satisfying results, use a specialist **chrome cleaning product**.

Chrome cleaning products will remove stains from the surface.

① CAUTION

To prevent scratching chrome surfaces:

• Never use an abrasive cleaning product on chrome.

• Do not clean or polish chrome parts in a sandy or dusty environment.

Steel wheel rims

 Clean steel wheel rims regularly using a separate sponge.

Use an industrial cleaner to remove brake dust. Any damage to the paint on steel wheel rims should be repaired before starting to rust.

• Never wash tyres with a cylindrical jet. Even at large spraying distances and short cleaning times, damage can occur to the tyres. This may cause an accident.

• Water, ice and salt on the brake system can reduce braking effectiveness. Risk of accident. Directly after washing, avoid sudden and sharp braking. "Dry" the brakes by braking several times >>> page 149, Braking capacity and braking distance.

Alloy wheel rims

Every two weeks

- Wash salt and brake dust from alloy wheels.
- Use an acid free detergent to clean the wheel rims.

Every 3 months

- Apply a hard wax compound to the wheels.

Alloy wheels require regular attention to preserve their appearance. If road salt and brake dust are not often removed, the aluminium finish will be impaired.

Always use an acid-free detergent for alloy wheel rims.

Car polish or other abrasive agents should not be used for maintaining the rims. If the protective coating is damaged, e.g. by flying stones, the damaged area should be repaired immediately.

Observe the safety warnings >>> \triangle in Steel wheel rims on page 193.

Vehicle underbody protection

The vehicle underbody is coated to protect it from chemical and mechanical damage.

The protective coating can be damaged when driving. We recommend that you check the protective coating under the body and on the running gear, and retouch it if necessary, before and after the winter season.

We recommend that you go to your Technical Service to carry out repair work and additional anti-corrosion work.

Do not apply underseal or anti-corrosion coatings to the exhaust pipes, catalytic converter or the heat shields on the exhaust system. The heat of the exhaust system or the engine could cause them to ignite. Risk of fire.

Cleaning engine compartment

Take special care when cleaning the engine compartment.

Anti-corrosion treatment

The engine compartment and the surface of the power unit are given anti-corrosion treatment at the factory.

Good corrosion protection is particularly important in winter when the vehicle is frequently driven on salted roads. To prevent the salt corroding the vehicle, the entire engine compartment should be thoroughly cleaned before and after winter.

Technical Services have the proper products for cleaning and preservation as well as the necessary workshop equipment. For this reason, we recommend having this work performed by them.

The anti-corrosion protection is usually removed if the engine compartment is cleaned with grease removing solutions, or if you have the engine cleaned. On commissioning this work, ensure that all surfaces, seams, joints and components in the engine compartment are given anti-corrosion treatment.

A WARNING

• When working in the engine compartment, always observe the safety warnings >>> page 198.

- Before opening the bonnet, switch the engine off, apply the handbrake firmly and always remove the key from the ignition.
- Allow the engine to cool before you clean the engine compartment.
- Do not clean, for example, the vehicle underbody, wheel arches or wheel trims without protecting your hands and arms. You may cut yourself on sharp-edged metal parts. Failure to comply could result in injury.
- Moisture, ice and salt on the brake system may affect braking effectiveness. Risk of accident. Directly after washing, avoid sudden and sharp braking.
- Never touch the radiator fan. It is temperature-controlled and could start automatically,

even when the key is removed from the ignition!

🛞 For the sake of the environment

Fuel, grease and oil deposits can be removed when the engine is washed. The polluted water must be cleaned in an oil separator. For this reason, engine washing should be carried out only by a specialised workshop or a petrol station.

Caring for the vehicle interior

Cleaning plastic parts and the dash panel

- Use a clean, damp cloth to clean plastic parts and the dash panel.
- If this does not provide satisfactory results, use a special **solvent-free** plastic cleaning product.

▲ WARNING

Never clean the dash panel and the airbag module surface with cleaners containing solvents. Solvents cause the surface to become porous. If the airbag triggered, plastic parts could become detached and cause injuries.

() CAUTION

Cleaning products which contain solvents will damage the material.

Cleaning wooden trim*

- Clean the wooden trim with a water-moistened clean cloth.
- If this does not provide satisfactory results, use a *gentle* soap solution.

() CAUTION

Cleaning products which contain solvents will damage the material.

Cleaning upholstery and fabric trim

Cloth seat covers and fabric trim on the doors, headlining etc. can be cleaned with a special interior cleaner or with dry foam and a soft brush.

Cleaning the radio and climate controls

To clean the radio and/or climate controls, use a soft damp cloth. For more resistant dirt, a neutral soap solution may be used.

Care and maintenance

Cleaning leather*

Normal cleaning

 Moisten a cotton or woollen cloth with water and wipe over the leather surfaces.

Cleaning stubborn stains

- More stubborn dirt can be removed using a mild soap solution (pure liquid soap; two tablespoons diluted in one litre of water) and a cloth.
- Do not let the water soak through the leather or soak into the seams.
- Then wipe off with a soft, dry cloth.

Leather maintenance

- The leather should be treated twice a year with a special leather-care product, available at Technical Services.
- Apply these products very sparingly.
- Then wipe off with a soft cloth.

SEAT does everything possible to preserve the genuine qualities of this natural product. Due to the natural properties of the specially selected hides employed, the finished leather has a certain sensitivity to grease and dirt, etc. so a degree of care is required in everyday use and when looking after the leather.

Dust and grit in the pores and seams can scratch and damage the surface. If the vehi-

cle is under solar radiation for long periods, the leather should be protected to prevent it from fading. However, slight colour variations in high-quality natural leather are normal.

() CAUTION

• Do not use solvents, wax polish, shoe cream, spot removers or similar products on leather.

• To avoid damage, stubborn stains should be removed by a specialised workshop.

Seat belt cleaning

A dirty belt may not work properly. Check all seat belts regularly and keep them clean.

Seat belts cleaning

- Pull the dirty seat belt right out and unroll it.
- Clean dirty seat belts with a *gentle* soap solution.
- Allow it to dry.
- Do not roll the seat belt up until it is dry.

If large stains form on the belts, the automatic belt retractor will not work correctly.

• Do not use chemical cleaning agents on the seat belts, as this can impair the strength of the webbing. Ensure that seat belts do not come into contact with corrosive fluids.

- Check the condition of the seat belts at regular intervals. If you notice that the belt webbing, fittings, retractor mechanism or buckle of any of the belts is damaged, the belt must be replaced by a specialised workshop.
- Do not attempt to repair a damaged seat belt yourself. The seat belts must not be removed or modified in any way.

() CAUTION

After cleaning, allow seat belts to dry completely before rolling them up. Otherwise, the belt retractors could become damaged.

Checking and refilling levels

Refuelling

Refuelling

Read the additional information carefully

If the automatic filler nozzle is operated correctly, it will switch itself off as soon as the tank is "full". Never attempt to fill beyond this point, as this will fill the expansion chamber. Fuel may leak out if ambient conditions are warm.

The correct fuel grade for your vehicle is given on a sticker on the inside of the fuel tank flap.

∆ WARNING

- Fuel is highly flammable and can cause serious burns and other injuries.
 - Never smoke or come into contact with sparks when filling the fuel tank of the vehicle or a spare fuel canister with fuel. This is an explosion hazard.
 - Follow legal requirements for the use of spare fuel canisters.
 - For safety reasons we do not recommend carrying a spare fuel canister in the vehicle. The canister could be damaged in an accident and leak.

• If, in exceptional circumstances, you have to carry a spare fuel canister, please observe the following:

- Never fill the spare fuel canister inside the vehicle or on it. An electrostatic charge could build up during filling, causing the fuel fumes to ignite. This could cause an explosion. Always place the canister on the ground to fill it.
- Insert the fuel nozzle into the mouth of the canister as far as possible.
- If the spare fuel canister is made of metal, the filling nozzle must be in contact with the canister during filling. This helps prevent an electrostatic charge building up.
- Never spill fuel in the vehicle or in the luggage compartment. Fuel vapours are explosive. Danger of death.

() CAUTION

- Fuel spills should be removed from the paintwork immediately.
- Never run the tank completely dry. Irregular fuel supply can cause misfiring. As a result, unburnt fuel could enter the catalytic converter and cause damage.
- When filling the fuel tank after having run it completely dry on a vehicle with a diesel engine the ignition must be switched on for at least 30 seconds before starting the engine. Subsequently, when you start the engine it may take longer than normal to start firing

(up to one minute). This is due to the fact that the fuel system has to purge itself of air before starting.

$\,\,{\ensuremath{\mathfrak{R}}}\,$ For the sake of the environment

Do not try to put in more fuel after the automatic filler nozzle has switched off, this may cause the fuel to overflow if it becomes warm.

Fuel

Types of petrol

The correct grade of petrol is listed inside the fuel tank flap.

The vehicle is equipped with a catalytic converter and must only be run on **unleaded pet**rol. The petrol must comply with European Standard EN 228 or German standard DIN 51626-1 and must be **unleaded**. You can refuel with a maximum ethanol proportion of 10 % (E10). The types of petrol are differentiated by their octane rating (RON).

The following titles appear on the corresponding adhesive on the fuel tank flap:

Checking and refilling levels

Super unleaded 95 octane or normal 91 octane unleaded petrol

We recommend you use super 95 octane petrol. If this is not available: normal 91 octane petrol, with a slight decrease in power.

Super unleaded petrol with a minimum of 95 octanes

You should use super petrol with a minimum of 95 octanes.

If super is not available, *in an emergency* you may refuel with normal 91 octane petrol. In this case only use moderate engine speeds and a light throttle. Refuel with super as soon as possible.

Super unleaded 98 octane or super 95 octane unleaded petrol

We recommend you use super plus 98 octane petrol. If this is not available: super 95 octane petrol, with a slight decrease in power.

If super is not available, *in an emergency* you may refuel with normal 91 octane petrol. In this case only use moderate engine speeds and a light throttle. Refuel with super as soon as possible.

Petrol additives

The quality of the fuel influences the behaviour, power and service life of the engine. This is why the petrol you use should carry suitable additives already included by the petrol industry, free of metals. These additives will help to prevent corrosion, keep the fuel system clean and prevent deposits from building up in the engine.

If good-quality petrol with metal-free additives is not available or engine problems arise, the necessary additives must be added when refuelling **>>> ①**.

Not all petrol additives have been shown to be effective. The use of unsuitable petrol additives may cause significant damage to the engine and the catalytic converter. Metal additives should never be used. Metal additives for may also be contained in petrol additives for improving anti-detonation ratings or octane ratings.

SEAT recommends "genuine Volkswagen Group Fuel Additives for petrol engines". These additives can be bought at SEAT dealers, where information on how to use them can also be obtained.

() CAUTION

• Do not refuel if the filler indicates that the fuel contains metal. LRP (*lead replacement petrol*) fuels contain high concentrations of metal additives. Using them may damage the engine!

• Never refuel with fuels containing a large proportion of ethanol (for example, E50, E85). This could damage the fuel system.

• Just filling one full tank of leaded fuel or fuel containing other metal additives would seriously impair the efficiency of the catalytic converter.

• Only use fuel additives that have been approved by SEAT. Octane boosting or antiknock additives may contain metal additives that could seriously damage the engine or the catalytic converter. These additives must not be used.

• High engine speed and full throttle can damage the engine when using petrol with an octane rating lower than the correct grade for the engine.

i Note

• You may use petrol with a high octane number than the one recommended for your engine.

• In those countries where unleaded petrol is not available, you may refuel with a fuel with a low lead content.

Diesel fuel

Please note the information on the inside of the fuel tank flap.

We recommend the use of **diesel** fuel which complies to European standard EN 590. If diesel fuel which meets European standard EN 590 is not available, the Cetane number (CZ) must, at minimum, be 51. If the engine is equipped with a particulate filter, the sulphur content of the fuel must be below 50 parts per million.

Winter-grade diesel

Summer fuel becomes thicker in winter and it is more difficult to start the engine. For this reason, petrol stations in some countries also offer winter diesel with improved fluidity when cold (winter-grade diese).

Water in the fuel filter1)

If your vehicle has a diesel engine and is equipped with a **fuel filter with a water separator**, the instrument panel may display the

following warning: **W4ter** in the **fuel filter**. If this is the case, take the vehicle to a specialised workshop so that they can drain the fuel filter.

① CAUTION

- The vehicle is not designed for the use of FAME fuel (biodiesel). The fuel system would be damaged if you used biodiesel.
- Do not mix fuel additives, the so-called "thinners", petrol or similar additives with diesel fuel.
- If poor-quality diesel fuel is used, it may be necessary to drain the fuel filter more frequently than is specified in the Maintenance

Advice

Programme. We recommend having this done by a specialised workshop. If water is allowed to collect in the filter, this can cause engine performance problems.

Working in the engine compartment

safety notes for work in the engine compartment

Read the additional information carefully >>> 20 page 10

Before starting any work on the engine or in the engine compartment:

- 1. Switch off the engine and remove the key from the ignition.
- 2. Apply the handbrake.
- 3. Move the gear lever to neutral or the selector lever to position P.
- 4. Wait for the engine to cool down.
- 5. Keep children away from the vehicle.
- 6. Raise the bonnet **»» page 199**.

You should not do any work in the engine compartment unless you know exactly how to

carry out the jobs and have the correct tools! Have the work carried out by a specialised workshop if you are uncertain.

All service fluids and consumables, e.g. coolant, engine oil, spark plugs and batteries, are under constant development. SEAT provides a constant flow of information to Technical Services concerning modifications. For this reason, we recommend you have service fluids and consumables replaced by a Technical Service. Please observe the relevant instructions **» page 187**. The engine compartment of the vehicle is a hazardous area **»** A.

All work on the engine or in the engine compartment, e.g. checking and refilling fluids, involves the danger of injury and burns, accidents and even fire.

- Never open the bonnet if you see steam, smoke or coolant escaping from the engine compartment. Otherwise, there is a risk of sustaining burns. Wait until no more steam or coolant is emitted, then allow the engine to cool before carefully opening the bonnet.
- Switch off the engine and remove the key from the ignition.
- Apply the handbrake and move the gear lever to neutral or selector lever to position P.
- Keep children away from the vehicle.

¹⁾ Valid for the market: Algeria.

Checking and refilling levels

• Never touch hot engine parts. There is a risk of burns.

• Never spill liquids on a hot engine or on a hot exhaust gas system. This is a fire hazard.

• Avoid causing short-circuits in the electrical system, particularly at the points where the jump leads are attached >>> 🗁 page 52. The battery could explode.

 Never touch the radiator fan. It is temperature controlled and could start automatically, even when the engine has been switched off and the key removed from the ignition!

• Never cover the engine with additional insulating materials such as a blanket. Risk of fire!

Do not unscrew the cap on the coolant expansion tank when the engine is hot. If the coolant is hot, the cooling system will be pressurised!

• Protect face, hands and arms by covering the cap with a large, thick cloth to protect against escaping coolant and steam.

• Always make sure you have not left any objects, such as cleaning cloths or tools, in the engine compartment.

 If you have to work underneath the vehicle, you must use suitable stands additionally to support the vehicle, there is a risk of accident!. A hydraulic jack is insufficient for securing the vehicle and there is a risk of injury.

 If any work has to be performed when the engine is started or with the engine running, there is an additional, potentially fatal, safety risk from the rotating parts, such as the drive belts, alternator, radiator fan, etc., and from the high-voltage ignition system. You should also observe the following:

- Never touch the electrical wiring of the ignition system.
- Ensure that jewellery, loose clothing and long hair do not get trapped in rotating engine parts. Danger of death. Before starting any work remove jewellery, tie back and cover hair, and wear tight-fitting clothes.
- Never accelerate with a gear engaged without taking the necessary precautions. The vehicle could move, even if the handbrake is applied. Danger of death.

• If work has to be carried out on the fuel system or on electrical components, you must observe the following safety notes in addition to the above warnings:

- Always disconnect the battery from the on-board network. The vehicle must be unlocked when this is done, otherwise the alarm will be triggered.
- Do not smoke.
- Never work near naked flames.
- Always have a fire extinguisher on hand.

A WARNING

If the bonnet is not correctly closed, it could suddenly open while driving leaving the driver without visibility. This could result in a serious accident. After closing the bonnet, always check that it is properly secured by the locking mechanism in the lock carrier piece. The bonnet must be flush with the surrounding body panels.

• While driving, if you notice that the bonnet is not correctly closed then stop immediately and close it correctly.

• Only open and close the bonnet when there is nobody within its range.

() CAUTION

When topping up service fluids, make sure not to mistake them. Using the wrong fluids could cause serious malfunctions and engine damage!

${\ensuremath{\mathscr{R}}}$ For the sake of the environment

Service fluids leaks are harmful to the environment. For this reason you should make regular checks on the ground underneath your vehicle. If you find spots of oil or other fluids, have your vehicle inspected in a specialised workshop.

Opening the bonnet

Read the additional information carefully

The bonnet is released from inside the vehicle.

Before opening the bonnet ensure that the windscreen wipers are in rest position.

A WARNING

Hot coolant can scald!

• Never open the bonnet if you see steam, smoke or coolant escaping from the engine compartment.

• Wait until no more steam, smoke or coolant is emitted from the bonnet, then carefully open the bonnet.

• When working in the engine compartment, always observe the safety warnings >>> page 198.

Closing the bonnet

- Slightly lift the bonnet.
- Release the bonnet stay and replace it in its support.
- At a height of approximately 30 cm let it fall so it locks.

If the bonnet does not close, do not press downwards. Open it again and let it fall as mentioned above.

∆ WARNING


If the bonnet is not closed properly, it could open while you are driving and completely obscure your view of the road. Risk of accident.

• After closing the bonnet, always check that it is properly secured. The bonnet must be flush with the surrounding body panels.

 If you notice that the bonnet latch is not secured when the vehicle is moving, stop the vehicle immediately and close the bonnet properly. Risk of accident.

Checking and refilling levels

Checking levels






Fig. 174 For vehicles with the battery in the luggage compartment.

From time to time, the levels of the different fluids in the vehicle must be checked. Never fill with incorrect fluids, otherwise serious damage to the engine may be caused.

- Coolant expansion tank
- 2 Engine oil level dipstick
- ③ Engine oil filler cap
- 4 Brake fluid reservoir
- 5 Vehicle battery
- 6 Windscreen washer reservoir

The checking and refilling of service fluids are carried out on the components mentioned above. These operations are described in **>>>** page 198.

Overview

You will find further explanations, instructions and restrictions on the technical specifications as of **>>> page 216**.

Fig. 173 Diagram for the location of the various elements.

i Note

The layout of parts may vary depending on the engine.

Engine oil

General notes

The engine comes with a special, multi-grade oil that can be used all year round.

The specifications (VW standards) set out in the following page should appear on the container of the service oil; when the container displays the specific standards for petrol and diesel engines together, it means that the oil can be used for both types of engines.

We recommend that the oil change indicated in the Maintenance Programme, be performed by a technical service or specialised workshop.

The correct oil specifications for your engine are listed in the **>>> () page 42**.

Service intervals

Service intervals can be flexible (LongLife service) or fixed (dependent on time/distance travelled).

If the PR code that appears on the back of the Maintenance Programme booklet is PR QI6, this means that your vehicle has the LongLife service program. If it lists the codes QI1, QI2, QI3, QI4 or QI7, the interval service is dependent on the time/distance travelled.

Flexible service intervals (LongLife service intervals*)

Special oils and processes have been developed which, depending on the characteristics and individual driving profiles, enable the extension of the oil change service (Long-Life service intervals). Because this oil is essential for extending the service intervals, it **must only** be used observing the following indications:

• Avoid mixing it with oil for fixed service intervals.

• Only in exceptional circumstances, if the engine oil level is too low **» page 203** and LongLife oil is not available, it is permitted to top up (once) with oil for **fixed service intervals » (upt age 42** (up to a maximum of 0.5 litres).

Fixed service intervals*

gramme.

If your vehicle does not have the "LongLife service interval" or it has been disabled (by request), you may use oils for **fixed service intervals**, which also appear in **w Pape 42**. In this case, your vehicle must be serviced after a fixed interval of 1 year/15,000 km (10,000 miles) (whatever comes first) **w Booklet Maintenance Pro**-

 In exceptional circumstances, if the engine oil level is too low » page 203 and you cannot obtain the oil specified for your vehicle, you can add a small quantity of oil conforming to the specification ACEA A2 or ACEA A3 (petrol engines) or ACEA B3 or ACEA B4 (diesel engines) (up to 0.5 l).

Vehicles with diesel particulate filter*

The Maintenance Programme states whether your vehicle is fitted with a diesel particulate filter.

Only VW 507 00 engine oil, with reduced ash formation, may be used in diesel engines equipped with particulate filter. Using other types of oil will cause a higher soot concentration and reduce the life of the DPF. Therefore:

• Avoid mixing this oil with other engine oils.

 Only in exceptional circumstances, if the engine oil level is too low » page 203 and you cannot obtain the oil specified for your vehicle, you can use a small quantity of oil (once) conforming to the VW 506 00, VW 506 01, VW 505 00, VW 505 01 or ACEA B3/ACEA B4 specification. (up to 0.5 l).

i Note

Before a long trip, we recommend finding an engine oil that conforms to the corresponding VW specifications and recommend keeping it in the vehicle. This way, the correct engine oil will always be available for a top-up if needed.

Warning lamp

If this warning lamp 🐄 is red it indicates that the engine oil pressure is too low.

Checking and refilling levels

If this warning symbol starts to flash, and is accompanied by three **audible warnings**, switch off the engine and check the oil level. If necessary, add more oil **» page 203**.

If the warning lamp flashes although the oil level is correct, *stop* driving. Do not even run the engine at idle speed! Obtain technical assistance.

Checking oil level

If the warning lamp is yellow 🛣 the engine oil level should be checked as soon as possible. Top up the oil at the next opportunity **»** page 203.

Oil level sensor faulty*

If the *myellow* warning lamp flashes, take the vehicle to a specialised workshop to have the oil level sensor checked. Until then it is advisable to check the oil level every time you refuel.

Check engine oil level




Fig. 175 Engine oil dipstick.

Read the additional information carefully

Checking oil level

- Park the vehicle in a horizontal position.
- Briefly run the engine at idle speed until the operating temperature is reached and then stop.
- Wait for about two minutes.
- Pull out the dipstick. Wipe the dipstick with a clean cloth and insert it again, pushing it in as far as it will go.
- Then pull it out again and check the oil level. Top up with engine oil if necessary.

Depending on how you drive and the conditions in which the vehicle is used, oil consumption can be up to 0.5 l/1000 km. Oil consumption is likely to be higher for the first 5,000 km. For this reason the engine oil level must be checked at regular intervals, preferably when filling the tank and before a journey.

🛆 WARNING

Any work carried out in the engine compartment or on the engine must be carried out cautiously.

• When working in the engine compartment, always observe the safety warnings >>> page 198.

① CAUTION

If the oil level is above the area (A) do not start the engine. This could result in damage to the engine and catalytic converter. Contact a Technical Service.

Topping up engine oil

Read the additional information carefully

Before opening the bonnet, read and observe the warnings \rightarrow in safety notes for work in the engine compartment on page 198.

The position of the oil filler opening is shown in the corresponding engine compartment illustration **>>> page 201**.

Engine oil specification »» 🗇 page 42.

A WARNING

Oil is highly inflammable! Ensure that no oil comes into contact with hot engine components when topping up.

① CAUTION

If the oil level is above the area (A) do not start the engine. This could result in damage to the engine and catalytic converter. Contact a specialised workshop.

🛞 For the sake of the environment

The oil level must never be above area (A). Otherwise oil can be drawn in through the crankcase breather and escape into the atmosphere via the exhaust system.

Changing engine oil

Read the additional information carefully

The engine oil must be changed at the intervals given in the service schedule.

We recommend that you have the engine oil changed by a Technical Service.

The oil change intervals are shown in the Maintenance Programme.

Only change the engine oil yourself if you have the specialist knowledge required!

- Before opening the bonnet, read and observe the warnings >>> page 198, safety notes for work in the engine compartment.
- Wait for the engine to cool down. Hot oil may cause burn injuries.
- Wear eye protection to avoid injuries, such as acid burns, caused by splashes of oil.
- When removing the oil drain plug with your fingers, keep your arm horizontal to help prevent oil from running down your arm.
- Wash your skin thoroughly if it comes into contact with engine oil.
- Engine oil is poisonous! Used oil must be stored in a safe place out of the reach of children.

CAUTION

No additives should be used with engine oil. This could result in engine damage. Any damage caused by the use of such additives would not be covered by the factory warranty.

 Because of disposal problems and the special tools and specialist knowledge required, we recommend that you have the engine oil and filter changed by a Technical Service.

- Never pour oil down drains or into the ground.
- Use a suitable container when draining the used oil. It must be large enough to hold all the engine oil.

Cooling system

Control lamp

There is a fault if:

- The 🕹 lamp does not go out again after a few seconds.
- The ⊥ lamp lights up or flashes while the vehicle is running, and three **acoustic warning signals are emitted »** ∧.

This means that either the coolant level is too low or the coolant temperature is too high.

Coolant temperature too high

If the Lamp lights up, stop the vehicle, turn off the engine and wait for it to cool down. Check the coolant level.

If the coolant level is correct, the overheating may be caused by a malfunction of the radiator fan. Check the radiator fan fuse and have it replaced if necessary **» page 80**.

If the control lamp lights up again after driving on for a short distance, **stop the vehicle** **and switch the engine off**. Contact a Technical Service or a specialised workshop.

Coolant level too low

If the \pounds lamp lights up, stop the vehicle, turn off the engine and wait for it to cool down. First check the coolant level. If the level of the coolant is below the "MIN" mark, top up with coolant liquid »» \triangle .

🛆 WARNING

- If your vehicle is immobilised for technical reasons, move it to a safe distance from traffic. Turn the engine off, turn the hazard lights on and place the warning triangle.
- Never open the bonnet if you can see or hear steam or coolant escaping from the engine compartment. Risk of scalding. Wait until you can no longer see or hear escaping steam or coolant.
- The engine compartment is a dangerous area. Before carrying out any work in the engine compartment, switch off the engine and allow it to cool down. Always note the corresponding warnings >>> page 198.

Topping up coolant

Read the additional information carefully

Top up coolant when the level is below the MIN (minimum) mark.

Checking coolant level

- Park the vehicle in a horizontal position.
- Switch the ignition off.
- Read off the coolant level on coolant expansion tank. When the engine is cold, the coolant level should be between the marks.
 When the engine is hot, it may be slightly above the upper mark.

Topping up coolant

- Wait for the engine to cool down.
- Cover the coolant expansion tank cap with a cloth and carefully unscrew it to the left
 >>>> ▲.
- Top up the coolant only if there is still coolant in the expansion tank, otherwise you could **damage the engine**. If there is no coolant in the expansion tank, do not continue driving. You should obtain professional assistance » 0.
- If there is still some coolant in the expansion tank, top up to the upper mark.
- Top up with coolant until the level becomes stable.
- Screw the cap back on correctly.

Any loss of coolant fluid normally indicates a leak in the cooling system. Take the vehicle straight to a specialised workshop to have the cooling system examined. If there are no leaks in the engine cooling system, a loss of coolant can only occur if the coolant boils and is forced out of the system as a result of overheating.

- The cooling system is under pressure. Do not unscrew the cap on the coolant expansion tank when the engine is hot: risk of burns!
- The antifreeze and coolant fluid can be a health hazard. Therefore, the antifreeze should be stored in the original container in a safe place out of reach of children. Failure to comply could result in poisoning.
- If working inside the engine compartment, remember that, even when the ignition is switched off, the radiator fan may start up automatically, and therefore there is a risk of injury.

If there is not enough anti-freeze in the coolant system, the engine may fail leading to serious damage.

- Please make sure that the percentage of additive is correct with respect to the lowest expected ambient temperature in the zone in which the vehicle is to be used.
- When the outside temperature is very low, the coolant could freeze and the vehicle would be immobilised. In this case, the heating would not work either and inadequately dressed passengers could die of cold.

() CAUTION

Do not top up the expansion tank with coolant fluid if it is empty! Air could enter the cooling system. In this case, stop driving. Seek specialist assistance. Otherwise, there is a risk of engine damage.

() CAUTION

The original additives should never be mixed with coolants which are not approved by SEAT. Otherwise, you run the risk of causing severe damage to the engine and the engine cooling system.

If the fluid in the expansion tank is not purple but is, for example, brown, this indicates that the G13 additive has been mixed with an inadequate coolant. The coolant must be changed as soon as possible if this is the case! This could result in serious faults and engine damage.

🛞 For the sake of the environment

Coolants and additives can contaminate the environment. If any fluids are spilled, they should be collected and correctly disposed of, with respect to the environment.

Brake fluid

Checking the brake fluid level

Read the additional information carefully >>> 2 page 43

The position of the brake fluid reservoir is shown in the corresponding engine compartment illustration **»> page 201**. The brake fluid reservoir has a black and yellow cap.

The brake fluid level drops slightly when the vehicle is being used as the brake pads are automatically adjusted as they wear.

However, if the level goes down noticeably in a short time, or drops below the "MIN" mark, there may be a leak in the brake system. A display on the instrument panel will warn you if the brake fluid level is too low **»** page 98.

▲ WARNING

Before opening the bonnet to check the brake fluid level, read and observe the warnings »>> page 198.

Changing the brake fluid

The Maintenance Programme indicates brake fluid change intervals.

We recommend that you have the brake fluid changed by a Technical Service.

Before opening the bonnet, please read and follow the warnings \rightarrow **in safety notes for work in the engine compartment on page 198** in section "Safety notes for working in the engine compartment".

In the course of time, brake fluid becomes hygroscopic and absorbs water from the ambient air. If the water content in the brake fluid is too high, the brake system could corrode. This also considerably reduces the boiling point of the brake fluid. Heavy use of the brakes may then cause a vapour lock which could impair the braking effect.

Be sure to always use the correct brake fluid. Only use brake fluid that expressly meets the VW 501 14 standard.

You can buy VW 501 14 standard brake fluid in a SEAT dealership or a SEAT Official Service. If none is available, use only high-quality brake fluid that meets DIN ISO 4925 CLASS 4 standards, or USA Standards FMVSS 116 DOT 4.

Using any other kind of brake fluid or one that is not of a high quality may affect operation of the brake system and reduce its effectiveness. Never use a brake fluid if the container does not state that it complies with VW 501 14, DIN ISO 4925 CLASS 4 standards, or USA standards FMVSS 116 DOT 4.

∧ WARNING

Brake fluid is poisonous. Old brake fluid impairs the braking effect.

• Before opening the bonnet to check the brake fluid level, read and observe the warnings »» page 198.

 Brake fluid should be stored in the closed original container in a safe place out of reach of children. There is a toxic risk.

 Perform the brake fluid change according to the Maintenance Programme. Heavy use of the brakes may cause a vapour lock if the brake fluid is left in the brake system for too long. This would seriously affect the effectiveness of the brakes and the safety of the vehicle. This may cause an accident.

\bigcirc CAUTION

Brake fluid damages the vehicle paintwork. Wipe off any brake fluid from the paintwork immediately.

* For the sake of the environment

The brake pads and brake fluid must be collected and disposed of according the applicable regulations. The SEAT Technical Service network has the necessary equipment and gualified personnel for collecting and disposing of this waste material.

Windscreen washer reservoir

Topping up the windscreen washer reservoir water

Read the additional information carefully »» 🗇 page 43

The windscreen washer and the headlight washers are supplied with fluid from the windscreen washer fluid container in the engine compartment. The container holds approx. 3 litres; in vehicles with headlight washers* it holds approx. 4.5 litres.

The tank is in the engine compartment.

Plain water is not enough to clean the windscreen and headlights. We recommend that you always add a product to the windscreen washer fluid. Approved windscreen cleaning products exist on the market with high detergent and anti-freeze properties, these may be added all-year-round. Please follow the dilution instructions on the packaging.

∧ WARNING

Any work carried out in the engine compartment or on the engine must be carried out cautiously.

 When working in the engine compartment, always observe the safety warnings »» page 198.

() CAUTION

· Never put radiator anti-freeze or other additives into the windscreen washer fluid.

 Always use approved windscreen cleansing products diluted as per instructions. If you use other washer fluids or soap solutions, the tiny holes in the fan-shaped nozzles could become blocked.

Vehicle battery

Symbols and warnings on handling the battery

Read the additional information carefully » 12 page 43

6	Wear eye protection
\triangle	Battery acid is extreme


C

 \bigotimes

6

elv corrosive. Wear protective gloves and eve protection!

Fires, sparks, open flames and smoking are prohibited!





Keep children away from acid and batteries!

▲ WARNING

Always be aware of the danger of injury and chemical burns as well as the risk of accident or fire when working on the battery and the electrical system:

• Wear eye protection. Protect your eyes, skin and clothing from acid and particles containing lead.

 Battery acid is extremely corrosive. Wear protective gloves and eye protection. Do not tilt the batteries. This could spill acid through the vents.

• Rinse battery acid from eyes immediately for several minutes with clear water. Then seek medical care immediately. Neutralise any acid splashes on the skin or clothing with a soapy solution, and rinse off with plenty of water. If acid is swallowed by mistake, consult a doctor immediately.

 Fires, sparks, open flames and smoking are prohibited. When handling cables and electrical equipment, avoid causing sparks and electrostatic charge. Never short the battery terminals. High-energy sparks can cause injury.

 A highly explosive mixture of gases is released when the battery is under charge. The batteries should be charged in a well-ventilated room only.

• Keep children away from acid and batteries.

• Before working on the electrical system, you must switch off the engine, the ignition and all electrical devices. The negative cable on the battery must be disconnected. When a light bulb is changed, you need only switch off the light.

• Deactivate the anti-theft alarm by unlocking the vehicle before you disconnect the battery! The alarm will otherwise be triggered.

• When disconnecting the battery from the vehicle on-board network, disconnect first the negative cable and then the positive cable.

• Switch off all electrical devices before reconnecting the battery. Reconnect first the positive cable and then the negative cable. Never reverse the polarity of the connections. This could cause an electrical fire.

 Never charge a frozen battery, or one which has thawed. This could result in explosions and chemical burns. Always replace a battery which has frozen. A flat battery can also freeze at temperatures close to 0°C (+32°F).

• Ensure that the vent hose is always connected to the battery.

• Never use a defective battery. This could cause an explosion. Replace a damaged battery immediately.

• For vehicles with the battery in the luggage compartment: Check that the battery gas ventilation hose is securely attached.

() CAUTION

• Never disconnect the battery if the ignition is switched on or if the engine is running.

This could damage the electrical system or electronic components.

 Do not expose the battery to direct sunlight over a long period of time, as the intense ultraviolet radiation can damage the battery housing.

 If the vehicle is left standing in cold conditions for a long period, protect the battery from "freezing". If it freezes it will be damaged.

Warning lamp



Alternator fault.

The control lamp 🖆 lights up when the ignition is switched on. It should go out when the engine has started running.

If the control lamp ➡ lights up while driving, the alternator is no longer charging the battery. You should immediately drive to the nearest specialised workshop.

You should avoid using electrical equipment that is not absolutely necessary because this will drain the battery.

Checking the battery electrolyte level

The electrolyte level should be checked regularly in high-mileage vehicles, in hot countries and in older batteries.

- Open the bonnet and open the battery cover at the front » △ in safety notes for work in the engine compartment on page 198
 >> △ in Symbols and warnings on handling the battery on page 208. For vehicles with the battery under the spare wheel, open the rear lid and lift the floor covering. The battery is located next to the spare wheel.
- Check the colour display in the "magic eye" on the top of the battery.
- If there are air bubbles in the window, tap the window gently until they disperse.

The position of the battery is shown in the corresponding engine compartment diagram **>>>** page 201. The location of the battery in the luggage compartment can be seen in **>>> Fig. 174**.

The "magic eye" indicator, located on the top of the battery changes colour, depending on the charge state and electrolyte level of the battery.

There are two different colours:

- Black: correct charge status.
- Transparent/clear yellow: the battery must be replaced. Contact a specialised workshop.

Charging or changing the battery

The battery is maintenance-free and is checked during the inspection service. All work on the vehicle battery requires specialist knowledge.

If you often drive short distances or if the vehicle is not driven for long periods, the battery should be checked by a specialised workshop between the scheduled services.

If the battery has discharged and you have problems starting the vehicle, the battery might be damaged. If this happens, we recommend you have the vehicle battery checked by a Technical Service where it will be re-charged or replaced.

Charging the battery

The vehicle battery should be charged by a specialised workshop only, as batteries using special technology have been installed and they must be charged in a controlled environment.

Replacing a vehicle battery

The battery has been developed to suit the conditions of its location and has special safety features.

Genuine SEAT batteries meet the maintenance, performance and safety specifications of your vehicle.

• We recommend you use only maintenancefree or cycle free leak-proof batteries which comply with standards T 825 06 and VW 7 50 73. This standard applies as of 2001.

${oldsymbol{\Re}}$ For the sake of the environment

Batteries contain toxic substances such as sulphuric acid and lead. They must be disposed of appropriately and must not be disposed of with ordinary household waste.

Wheels

Wheels and tyres

General notes

Avoiding damage

- If you have to drive over a kerb or similar obstacle, drive very slowly and at a right angle.
- Keep grease, oil and fuel off the tyres.
- Inspect the tyres regularly for damage (cuts, cracks or blisters, etc.). Remove any foreign objects embedded in the treads.

Storing tyres

- When you remove the tyres, mark them in order to maintain the same direction of rotation when they are installed again.
- When removed, the wheels and/or tyres should be stored in a cool, dry and preferably dark location.
- Store tyres in a vertical position, if they are not fitted on wheel rims.

New tyres

New tyres must be run in >>> page 164.

The tread depth of new tyres may vary, according to the type and make of tyre and the tread pattern.

Concealed damage

Damage to tyres and rims is often not readily visible. If you notice unusual vibrations or the vehicle pulling to one side, this may indicate that one of the tyres is damaged. They should be checked immediately by a Technical Service.

Tyres with directional tread pattern

An arrow on the tyre sidewall indicates the direction of rotation on tyres with directional tread. Always observe the direction of rotation indicated when fitting the wheel. This guarantees optimum grip and helps to avoid aquaplaning, excessive noise and wear.

▲ WARNING

• New tyres do not have maximum grip during the first 500 km. Drive particularly carefully to avoid possible accidents.

• Never drive with damaged tyres. This may cause an accident.

• If you notice unusual vibrations or if the vehicle pulls to one side when driving, stop the vehicle immediately and check the tyres for damage.

Tyre pressure monitoring system



Fig. 176 Location of the tyre pressure sticker.

The correct tyre pressure can be seen on the sticker on the inside of the fuel tank flap **>>> Fig. 176**.

- 1. Read the required tyre inflation pressure from the sticker. The values refer to Summer tyres.
- The tyre pressures should only be checked when the tyres are cold. The slightly raised pressures of warm tyres must not be reduced.
- 3. Adjust the tyre pressure to the load you are carrying.

Wheels

Tyre pressure

The correct tyre pressure is especially important at high speeds. The pressure should therefore be checked at least once a month and before starting a journey.

Depending on the vehicle, tyre pressure can be adjusted to medium load to improve driving comfort ("comfort" tyre pressure). When driving with comfort tyre pressure fuel consumption may increase slightly.

∆ WARNING

A tyre can easily burst if the pressure is too low, causing an accident!

 At continuously high speeds, a tyre with insufficient pressure flexes more. In this way it becomes too hot, and this can cause tread separation and tyre blow-out. Always observe the recommended tyre pressures.

• If the tyre pressure is too low or too high, the tyres will wear prematurely and the vehicle will not handle well. Risk of accident!

${old H}$ For the sake of the environment

Under-inflated tyres will increase fuel consumption.

Tyre useful life



Fig. 177 Tyre tread wear indicators.




Fig. 178 Diagram for changing wheels

The useful life of tyres is dependent on tyre pressure, driving style and fitting.

Wear indicators

The original tyres on your vehicle have 1.6 mm high "tread wear indicators" **W Fig. 177**, running across the tread. Depending on the make, there will be 6 to 8 of them evenly spaced around the tyre. Markings on the tyre sidewall (for instance the letters "TWI" or other symbols) indicate the positions of the tread wear indicators. The minimum tread depth required by law is 1.6 mm (measured in the tread grooves next to the tread wear indicators). Worn tyres must be replaced. Different figures may apply in export countries **w** Δ .

Tyre pressure

Incorrect tyre pressure causes premature wear and could cause tyre blow-out. For this reason, the tyre pressure should be checked at least once per month **»** page 210.

Driving style

Fast cornering, heavy acceleration and hard braking all increase tyre wear.

Changing wheels around

If the front tyres are worn considerably more than the rear ones it is advisable to change them around as shown **»> Fig. 178**. The useful life of all the tyres will then be about the same time.

Wheel balance

The wheels on new vehicles are balanced. However, various factors encountered in normal driving can cause them to become unbalanced, which results in steering vibration. Unbalanced wheels should be rebalanced, as they otherwise cause excessive wear on steering, suspension and tyres. A wheel must also be rebalanced when a new tyre is fitted.

Incorrect wheel alignment

Incorrect running gear alignment causes excessive tyre wear, impairing the safety of the vehicle. If tyres show excessive wear, you should have the wheel alignment checked by a Technical Service.

∆ WARNING

There is a serious danger of accidents if a tyre bursts during driving!

 The tyres must be replaced at the latest when the tread wear indicators are worn >>> page 211. Failure to follow this instruction could result in an accident. Worn tyres do not grip well at high speeds on wet roads. There is also a greater risk of "aquaplaning".

 At continuously high speeds, a tyre with insufficient pressure flexes more. This causes it to overheat. This can cause tread separation and tyre blow-out. Risk of accident. Always observe the recommended tyre pressures.

• If tyres show excessive wear, you should have the running gear checked by a Technical Service.

• Keep chemicals such as oil, fuel and brake fluid away from tyres.

• Damaged wheels and tyres must be replaced immediately!

Advice

 ${\ensuremath{\mathscr{R}}}$ For the sake of the environment

Under-inflated tyres will increase fuel consumption.

New tyres and wheels

New tyres and wheels have to be run in.

The tyres and wheel rims are an essential part of the vehicle's design. Those approved by SEAT are specially matched to the characteristics of the vehicle and make a major contribution to good road-holding and safe handling $\gg \Delta$.

Tyres should be replaced at least in pairs and not individually (i.e. both front tyres or both rear tyres together). A knowledge of tyre designations makes it easier to choose the correct tyres. Radial tyres have the tyre designations marked on the sidewall, for example:

195/65 R15 91T

This contains the following information:

- 195 Tyre width in mm
- 65 Height/width ratio in %
- R Tyre construction: Radial
- 15 Rim diameter in inches
- 91 Load rating code
- T Speed rating

The tyres could also have the following information:

- A direction of rotation symbol
- "Reinforced" denotes heavy-duty tyres.

The manufacturing date is also indicated on the tyre sidewall (possibly only on the inner side of the wheel).

"DOT ... 1103 ..." means, for example, that the tyre was produced in the 11th week of 2003.

We recommend that work on tyres and wheels be carried out by a Technical Service. They are familiar with the procedure and have the necessary special tools and spare parts as well as the proper facilities for disposing of the old tyres.

Any technical service has full information on the technical requirements when installing or changing tyres, wheels or wheel trims.

 We recommend that you use only wheels and tyres which have been approved by SEAT for your model. Failure to do so could impair vehicle handling. Risk of accident.

 Avoid running the vehicle on tyres that are more than 6 years old. If you have no alternative, you should drive slowly and with extra care at all times.

Wheels

• Never use old tyres or those with an unknown "history of use".

 If wheel trims are retrofitted, you must ensure that the flow of air to the brakes is not restricted. This could cause the brake system to overheat.

• All four wheels must be fitted with radial tyres of the same type, size (rolling circumference) and the same tread pattern.

🛞 For the sake of the environment

Old tyres must be disposed of according to the laws in the country concerned.

i Note

• A SEAT Service Centre should be consulted to find out whether wheels or tyres of different sizes to those originally fitted by SEAT can be fitted, and to find out about the combinations allowed between the front axle (axle 1) and the rear axle (axle 2).

 For technical reasons, it is not generally possible to use the wheels from other vehicles. This can also apply to wheels of the same model. The use of wheels or tyres which have not been approved by SEAT for use with your model may invalidate the vehicle's type approval for use on public roads.

 If the spare tyre is not the same as the tyres that are mounted on the vehicle (e.g. winter tyres) you should only use the spare tyre for a short period of time and drive with extra care. Refit the normal road wheel as soon as possible.

Wheel bolts

The design of wheel bolts is matched to the rims. If different wheel rims are fitted, the correct wheel bolts with the right length and correctly shaped bolt heads must be used. This ensures that wheels are fitted securely and that the brake system functions correctly.

In certain circumstances, you should not use wheel bolts from a different vehicle, even if it is the same model **» page 187**.

▲ WARNING

If the wheel bolts are not tightened correctly, the wheel could become loose while driving. Risk of accident.

• The wheel bolts must be clean and turn easily. Never apply grease or oil to them.

• Use only wheel bolts which belong to the wheel.

 If the prescribed torque of the wheel bolts is too low, they could loosen whilst the vehicle is in motion. Risk of accident! If the tightening torque is too high, the wheel bolts and threads can be damaged.

() CAUTION

The prescribed tightening torque for wheel bolts for steel and alloy wheels is 120 Nm.

Tyre pressure



Fig. 179 Centre console: tyre monitoring system button.

The tyre monitoring lamp $(\underline{U})^*$ compares wheel revolutions and with it, using the ESC, the wheel diameter of each wheel. If the diameter of a wheel changes, the tyre control lamp (\underline{U}) lights up. The wheel diameter changes when:

- Tyre pressure is insufficient.
- The tyre structure is damaged.
- The vehicle is unbalanced because of a load.

• The wheels of one axle are under more pressure (for example, driving with a trailer or on steep slopes).

- The vehicle is fitted with snow chains.
- The temporary spare wheel is fitted.
- The wheel on one axle is changed.

Tyre pressure adjustment

On adjusting tyre pressure or changing one or more wheels, the **» Fig. 179** button must be kept pressed down, with the ignition on, until an acoustic signal is heard.

Store the new tyre pressure in the Easy Connect system with the button (M) and the function button (Setup) >>> (12) page 24.

If the wheels are under excessive load (for example, driving with a trailer or heavy load), the tyre pressure must be increased to the recommended value for a full load (see the sticker on the inside of the fuel flap). If the tyre monitor system button is pressed down, the new tyre pressures are confirmed.

The tyre pressure control lamp (!) lights up

If the tyre pressure of a wheel is much lower than the value set by the driver, then the tyre pressure control lamp $\mathfrak{W} \Delta$ will light up.

▲ WARNING

• When the tyre pressure control lamp lights up, reduce speed immediately and avoid any

sudden turning or braking manoeuvre. Stop when possible, and check the tyre pressure and status.

• The driver is responsible for maintaining correct tyre pressures. For this reason, tyre pressure must be regularly checked.

 Under certain circumstances (e.g. when driving in a sporty manner, in winter conditions or on a dirt track) the tyre control lamp may light up belatedly or may function incorrectly.

i Note

If the battery is disconnected, the yellow warning lamp (1) lights up after turning the ignition on. This should turn off after a brief journey.

Winter service

Winter tyres

In winter conditions winter tyres will considerably improve the vehicle's handling. The design of summer tyres (width, rubber compound, tread pattern) gives less grip on ice and snow.

Winter tyres must be inflated to a pressure of 0.2 bar (2.9 psi/20 kPa) higher than the pressures specified for summer tyres (see sticker on fuel tank flap).

Winter tyres must be fitted on all four wheels.

Information on permitted **winter tyre sizes** can be found in the vehicle's registration documentation. Use only radial winter tyres. All tyre sizes listed in the vehicle documentation also apply to winter tyres.

Winter tyres lose their effectiveness when the tread is worn down to a depth of 4 mm.

The speed rating code \gg page 212, New tyres and wheels determines the following speed limits for winter tyres: $\gg \triangle$

- Q max. 160 km/h (99 mph)
- S max. 180 km/h (112 mph)
- T max. 190 km/h (118 mph)
- H max. 210 km/h (130 mph)

In some countries, vehicles which can exceed the speed rating of the fitted tyre must have an appropriate sticker in the driver's field of view. These stickers are available from your technical service. The legal requirements of each country must be followed.

Do not have winter tyres fitted for unnecessarily long periods. Vehicles with summer tyres handle better when the roads are free of snow and ice.

If you have a flat tyre, please refer to the notes on the spare wheel **>>> page 212**, New tyres and wheels.

Wheels

The maximum speed for the winter tyres must not be exceeded. Otherwise, this could lead to damage and risk of accident.

\circledast For the sake of the environment

Fit your summer tyres again as soon as possible. They are quieter, do not wear so quickly and reduce fuel consumption.

Technical data

Technical specifications

Important information

Important

The information in the vehicle documentation always takes precedence over the information in this Instruction Manual.

All technical specifications provided in this documentation are valid for the standard model in Spain. The vehicle data card included in the Maintenance Programme or the vehicle registration documents shows which engine is installed in the vehicle.

The figures may be different depending whether additional equipment is fitted, for different models, for special vehicles and for other countries.

Abbreviations used in the technical specifications section

kW	Kilowatt, engine power measurement.
PS	Pferdestärke (horsepower), formerly used to denote engine power.
rpm	Revolutions per minute - engine speed.
Nm	Newton metres, unit of engine torque.
CZ	Cetane number, indication of the diesel combustion power.
RON	Research octane number, indication of the knock resistance of petrol.

Vehicle identification data




Fig. 180 Vehicle data sticker (luggage compartment).



Vehicles for certain export countries do not have an identification plate.

Chassis number

The VIN is located in the Easy Connect, on the vehicle data sticker and under the windscreen, on the driver side **»** Fig. 181. Additionally, the chassis number is located in the engine compartment, on the right-hand side. The number is engraved on the top side rail, and is partially covered.

Identification plate

The type plate is located on the rear pillar of the front right door.

Vehicle data sticker

The data sticker is placed on the inside of the spare wheel well, in the boot and on the rear cover of the Maintenance Programme.

Technical specifications

The following information is provided on the vehicle data sticker: **>>> Fig. 180**

- Vehicle identification number (chassis number)
- (2) Vehicle type, model, capacity, engine type, finish, engine power and gearbox type
- 3 Engine code, gearbox code, external paint code and internal equipment code
- Optional extras and PR numbers

Chassis number

The vehicle identification number can be read from outside the vehicle through a viewer in the windscreen **» Fig. 181**. The viewer is located near the lower corner of the windscreen. The chassis number is printed on the right water drain channel. The water drain channel is located between the suspension turret and the fender. To access the chassis number, open the bonnet **» page 198**.

Information on fuel consumption

Fuel consumption

Approved consumption values are derived from measurements performed or supervised by certified EU laboratories, according to the legislation in force at the time (for more information, see the Publications Office of the European Union on the EUR-Lex website: © European Union, http://eur-lex.europa.eu/) and apply to the specified vehicle characteristics.

The values relating to fuel consumption and CO_2 emissions can be found in the documentation provided to the purchaser of the vehicle at the time of purchase.

Fuel consumption and CO_2 emissions depend on the equipment/features of each individual vehicle, as well as on the driving style, road conditions, traffic conditions, environmental conditions, load or number of passengers.

i Note

In practice, and considering all the factors mentioned here, consumption values can differ from those calculated in the current European regulations.

Weights

Kerb weight refers to the basic model with a fuel tank filled to 90% capacity and without optional extras. The figure quoted includes 75 kg to allow for the weight of the driver.

Special versions, optional equipment fittings or retro-fitting accessories will increase the weight of the vehicle \mathfrak{W} Δ .

∆ WARNING

 Please note that the centre of gravity may shift when transporting heavy objects; this may affect vehicle handling and lead to an accident. Always adjust your speed and driving style to suit road conditions and requirements.

• Never exceed the gross axle weight rating or the gross vehicle weight rating. If the permissible axle load or the permissible total weight is exceeded, the driving characteristics of the vehicle may change, leading to accidents, injuries and damage to the vehicle.

Trailer mode

Trailer weights

Trailer weight

The trailer weights and drawbar loads approved are selected in intensive trials according to precisely defined criteria. The approved trailer weights are valid for vehicles in the *EU* for maximum speeds of 80 km/h (50 mph) (in certain circumstances up to 100 km/h (62 mph)). The figures may be different in other countries. All data in the official vehicle documentation takes precedence over these data at all times **w** \triangle . *****

Drawbar loads

The *maximum* permitted drawbar load on the ball joint of the towing bracket must not exceed **75 kg**.

In the interest of road safety, we recommend that you always tow approaching the maximum drawbar load. The response of the trailer on the road will be poor, if the drawbar load is too small.

If the maximum permissible drawbar load cannot be met (e.g. with small, empty and light-weight single axle trailers or tandem axle trailers with a wheelbase of less than 1 metre), a minimum of 4% of the actual trailer weight is legally required for the drawbar load.

▲ WARNING

 For safety reasons, you should not drive at speeds above 80 km/h (50 mph) when towing a trailer. This also applies in countries where higher speeds are permitted.

 Never exceed the maximum trailer weights or the drawbar load. If the permissible axle load or the permissible total weight is exceeded, the driving characteristics of the vehicle may change, leading to accidents, injuries and damage to the vehicle.

Wheels

Tyre pressure, snow chains, wheel bolts

Tyre pressures

The sticker with the tyre pressure values can be found on the inside of the fuel tank flap. The tyre pressure values given there are for *cold* tyres. Do not reduce the slightly raised pressures of warm tyres $\mathbf{w} \Delta$.

The pressure for winter tyres is 0.2 bar higher than that of summer tyres (2.9 psi / 20 kPa).

Snow chains

Snow chains may be fitted only to the front wheels, and only for the following tyres:

175/70R14 185/60R15	Chains with links not exceeding 15 mm (including the chain closure)
215/45R16	Chains with links not exceeding 9 mm (including the chain closure)
215/40R17	Chains with links not exceeding 7 mm (including the chain closure)

Wheel bolts

After the wheels have been changed, the **tightening torque** of the wheel bolts should be checked as soon as possible with a torque wrench \mathfrak{W} . The tightening torque for steel and alloy wheels is **120** Nm.

 Check the tyre pressure at least once per month. Checking the tyre pressure is very important. If the tyre pressure is too high or too low, there is an increased danger of accidents - particularly at high speeds.

 If the tightening torque of the wheel bolts is too low, they could loosen while the vehicle is in motion. Risk of accident! If the tightening torque is too high, the wheel bolts and threads can be damaged.

i Note

We recommend that you ask your Technical Service for information about appropriate wheel, tyre and snow chain size.

Engine data

Petrol engine 1.0 MPI 55 kW (75 PS)

Power output in kW (PS) at rpm	Maximum torqu	ue (Nm at rpm) No. of cylinders/displacement (cm³)			Fuel		
55 (75)/6,200	95/3,000)-4,300		3/999		Super 95	RON/Normal 91 RON ^{a)}
^{a)} Slight power loss.							
Outputs and weights		IBIZA		IBIZA Start-Stop	IE	BIZA SC	IBIZA SC Start-Stop
Top speed (km/h)		172		172		172	172
Acceleration from 0-80 km/h (seconds)		9.5		9.5		9.5	9.5
Acceleration from 0-100 km/h (seconds)		14.3		14.3		14.3	14.3
Maximum authorised weight (kg)		1,530		1,540		1,530	1,540
Weight in running order (with driver) (kg)		1,043		1,049		1,043	1,049
Maximum authorised weight on front axle (kg)	1	790		800		790	800
Maximum authorised weight on rear axle (kg)		790		790		790	790
Permitted roof load (kg)		75		75		75	75
Maximum trailer weight without brakes (kg)		520		520		520	520
Weight of trailer with brakes, gradients up to 8	3% (kg)	1,000		1,000		1,000	1,000
Weight of trailer with brakes, gradients up to 1	12% (kg)	800		800		800	800

Petrol engine 1.2 TSI 66 kW (90 PS)

Power output in kW (PS) at rpm	Maximum torque (Nm at rpm)	No. of cylinders/displacement (cm ³)	Fuel
66 (90)/4,400-5,400	160/1,400-3,500	4/1,197	Super 95 RON/Normal 91 RON ^{a)}
^{a)} Slight power loss.			
Outputs and weights		IBIZA	IBIZA SC
Top speed (km/h)		184	184
Acceleration from 0-80 km/h (seconds)		7.0	7.0
Acceleration from 0-100 km/h (seconds)		10.7	10.7
Maximum authorised weight (kg)		1,580	1,580
Weight in running order (with driver) (kg)		1,089	1,089
Maximum authorised weight on front axle (kg)	840	840
Maximum authorised weight on rear axle (kg)		790	790
Permitted roof load (kg)		75	75
Maximum trailer weight without brakes (kg)		540	540
Weight of trailer with brakes, gradients up to a	8% (kg)	1,100	1,100
Weight of trailer with brakes, gradients up to	12% (kg)	1,000	1,000

Technical specifications

Petrol engine 1.6 MPI 66 kW (90 PS)

Power output in kW (PS) at rpm	Maximum torque (Nm at rpm)	No. of cylinders/displacement (cm ³)	Fuel
66 (90)/4,250-6,000	155/3,800-4,000	4/1,598	Super 95 RON/Normal 91 RON ^{a)}
^{a)} Slight power loss.			
Outputs and weights		IBIZA	IBIZA SC
Top speed (km/h)		185	185
Acceleration from 0-80 km/h (seconds)		7.0	7.0
Acceleration from 0-100 km/h (seconds)		10.6	10.6
Maximum authorised weight (kg)		1,570	1,570
Weight in running order (with driver) (kg)		1,079	1,079
Maximum authorised weight on front axle (kg))	830	830
Maximum authorised weight on rear axle (kg)		790	790
Permitted roof load (kg)		75	75
Maximum trailer weight without brakes (kg)		530	530
Weight of trailer with brakes, gradients up to 8	3% (kg)	1,000	1,000
Weight of trailer with brakes, gradients up to 2	12% (kg)	1,000	1,000

Petrol engine 1.0 EcoTSI 70 kW (95 PS) Start-Stop

Power output in kW (PS) at rpm	Maximum torque (Nm at rpm)		No. of cylinders/displaceme	nt (cm³)	Fuel	
70 (95)/5,000-5,500	160/1,500-3,500		3/999	Super 95	Super 95 RON/Normal 91 RON ^{a)}	
^{a)} Slight power loss.						
Outputs and weights		IBIZA	IBIZA ecomotive	IBIZA SC	IBIZA SC ecomotive	
Top speed (km/h)		187	191	187	191	
Acceleration from 0-80 km/h (seconds)		6.9	6.9	6.9	6.9	
Acceleration from 0-100 km/h (seconds)		10.4	10.4	10.4	10.4	
Maximum authorised weight (kg)		1,590	1,590	1,590	1,590	
Weight in running order (with driver) (kg)		1,095	1,095	1,095	1,095	
Maximum authorised weight on front axle (kg)		850	850	850	850	
Maximum authorised weight on rear axle (kg)		790	790	790	790	
Permitted roof load (kg)		75	75	75	75	
Maximum trailer weight without brakes (kg)		540	500	540	500	
Weight of trailer with brakes, gradients up to 8	3% (kg)	1000	500	1000	500	
Weight of trailer with brakes, gradients up to 1	2% (kg)	900	500	900	500	

Petrol engine 1.0 EcoTSI 81 kW (110 PS) Start-Stop

Power output in kW (PS) at rpm	Maximum torque	e (Nm at rpm)	No. of cylinders/displacem	ent (cm³)		Fuel	chnical d
81 (110)/5,000-5,500	200/2,000	-3,500	3/999		Super 95	RON/Normal 91 RON ^{a)}	Techn
^{a)} Slight power loss.							F
Outputs and weights		IBIZA Manual	IBIZA Automatic		IZA SC Ianual	IBIZA SC Automatic	Advice
Top speed (km/h)		197	197		197	197	Adv
Acceleration from 0-80 km/h (seconds)		6.3	6.2		6.3	6.2	
Acceleration from 0-100 km/h (seconds)		9.2	9.3		9.2	9.3	
Maximum authorised weight (kg)		1,600	1,630	:	1,600	1,630	ation
Weight in running order (with driver) (kg)		1,109	1,140		1,109	1,140	Oneration
Maximum authorised weight on front axle (kg)		860	900		860	900	
Maximum authorised weight on rear axle (kg)		790	780		790	780	ر م
Permitted roof load (kg)		75	75		75	75	rdencie
Maximum trailer weight without brakes (kg)		550	570		550	570	erde
Weight of trailer with brakes, gradients up to 8	% (kg)	1,100	1,100	:	1,100	1,100	Fme
Weight of trailer with brakes, gradients up to 1	2% (kg)	1,000	1,000		1,000	1,000	

Petrol engine 1.2 TSI 81 kW (110 PS)

Power output in kW (PS) at rpm	Maximum torque (Nm at rpm)	No. of cylinders/displacement (cm³)	Fuel
81 (110)/4,600-5,600	175/1,400-4,000	4/1197	Super 95 RON/Normal 91 RON ^{a)}
^{a)} Slight power loss.			
Outputs and weights		IBIZA	IBIZA SC
Top speed (km/h)		197	197
Acceleration from 0-80 km/h (seconds)		6.2	6.2
Acceleration from 0-100 km/h (seconds)		9.1	9.1
Maximum authorised weight (kg)		1,590	1,590
Weight in running order (with driver) (kg)		1,102	1,102
Maximum authorised weight on front axle (kg)	860	860
Maximum authorised weight on rear axle (kg)		780	780
Permitted roof load (kg)		75	75
Maximum trailer weight without brakes (kg)		550	550
Weight of trailer with brakes, gradients up to a	8% (kg)	1,100	1,100
Weight of trailer with brakes, gradients up to	12% (kg)	1,100	1,100

Technical specifications

Petrol engine 1.6 MPI 81 kW (110 PS)

Power output in kW (PS) at rpm	Maximum torqu	e (Nm at rpm)	No. o	of cylinders/displaceme	nt (cm³)		Fuel	Technical da
81 (110)/5,800	155/3,800	0-4,000		4/1,598		Super 95	RON/Normal 91 RON ^{a)}	echni
^{a)} Slight power loss.								1
Outputs and weights		IBIZA Manual		IBIZA Automatic		BIZA SC Manual	IBIZA SC Automatic	Advice
Top speed (km/h)		196		197		196	197	Adv
Acceleration from 0-80 km/h (seconds)		6.4		6.6		6.4	6.6	
Acceleration from 0-100 km/h (seconds)		9.8		8.7		9.8	8.7	
Maximum authorised weight (kg)		1,580		1,620		1,580	1,620	ation
Weight in running order (with driver) (kg)		1,085		1,126		1,085	1,126	Operation
Maximum authorised weight on front axle (kg)		840		890		840	890	0
Maximum authorised weight on rear axle (kg)		790		780		790	780	S
Permitted roof load (kg)		75		75		75	75	Emergencies
Maximum trailer weight without brakes (kg)		540		560		540	560	erge
Weight of trailer with brakes, gradients up to 8%	% (kg)	1,100		1,100		1,100	1,100	Em
Weight of trailer with brakes, gradients up to 12	2% (kg)	1,100		1,100		1,100	1,100	

Petrol engine 1.4 EcoTSI ACT 110 kW (150 PS) Start-Stop

Power output in kW (PS) at rpm	Maximum torque (Nm at rpm)	No. of cylinders/displacement (cm ³)	Fuel
110 (150)/5,000-6,000	250/1,500-3,500	4/1,395	Super 95 RON/Normal 91 RON ^{a)}
^{a)} Slight power loss.			
Outputs and weights		IBIZA	IBIZA SC
Top speed (km/h)		220	220
Acceleration from 0-80 km/h (seconds)		5.3	5.3
Acceleration from 0-100 km/h (seconds)		7.6	7.6
Maximum authorised weight (kg)		1,630	1,630
Weight in running order (with driver) (kg)		1,143	1,143
Maximum authorised weight on front axle (kg))	890	890
Maximum authorised weight on rear axle (kg)		790	790
Permitted roof load (kg)		75	75
Maximum trailer weight without brakes (kg)		570	570
Weight of trailer with brakes, gradients up to 8	8% (kg)	1,200	1,200
Weight of trailer with brakes, gradients up to 2	12% (kg)	1,200	1,200

Petrol engine 1.8 TSI 141 kW (192 PS) Start-Stop

Power output in kW (PS) at rpm	Maximum torque (Nm at rpm)	No. of cylinders/displ	lacement (cm³) Fuel
141 (192)/4,300-6,200	320/1,450-4,200	4/1,798	Super 95 RON/Normal 91 RON ^{a)}
^{a)} Slight power loss.			
Outputs and weights			IBIZA SC
Top speed (km/h)			235
Acceleration from 0-80 km/h (seconds)			5.1
Acceleration from 0-100 km/h (seconds)			6.7
Maximum authorised weight (kg)			1,700
Weight in running order (with driver) (kg)			1,260
Maximum authorised weight on front axle (kg))		950
Maximum authorised weight on rear axle (kg)			800
Permitted roof load (kg)			75
Maximum trailer weight without brakes (kg)			-
Weight of trailer with brakes, gradients up to 8	3% (kg)		-
Weight of trailer with brakes, gradients up to 1	12% (kg)		-

Diesel engine 1.4 TDI 55 kW (75 PS)

Power output in kW (PS) at rpm	Maximum to	orque (Nm at rpm)	No. of cylinders/displacem	ient (cm³)	Fuel
55 (75)/3,000-3,750	210/1	1,500-2,000	3/1,422	Min, diese	acc. to DIN EN 590 51 CN
Outputs and weights		IBIZA	IBIZA Start-Stop	IBIZA SC	IBIZA SC Start-Stop
Top speed (km/h)		171	173	171	173
Acceleration from 0-80 km/h (seconds)		8.6	8.5	8.6	8.5
Acceleration from 0-100 km/h (seconds)		12.9	13.0	12.9	13.0
Maximum authorised weight (kg)		1,640	1,640	1,640	1,640
Weight in running order (with driver) (kg)		1,150	1,155	1,150	1,155
Maximum authorised weight on front axle (kg)		900	910	900	910
Maximum authorised weight on rear axle (kg)		790	770	790	770
Permitted roof load (kg)		75	75	75	75
Maximum trailer weight without brakes (kg)		570	570	570	570
Weight of trailer with brakes, gradients up to 8	% (kg)	1,100	1,100	1,100	1,100
Weight of trailer with brakes, gradients up to 1	2% (kg)	1,000	1,000	1,000	1,000

Technical specifications

Diesel engine 1.4 TDI 66 kW (90 PS)

Power output in kW (PS) at rpm	Maximum to	orque (Nm at rpm)	No. of cyl	inders/displacem	ent (cm ³)	Fuel	
66 (90)/2,750-3,500	230/1	,500-2,500		3/1,422		Min, diesel acc. to DIN EN 590 51 CN	
Outputs and weights		IBIZA	IBIZA Start-Stop	IBIZA Automatic	IBIZA SC	IBIZA SC Start-Stop	IBIZA SC Automatic
Top speed (km/h)		182	182	182	182	182	182
Acceleration from 0-80 km/h (seconds)		7.4	7.4	7.4	7.4	7.4	7.4
Acceleration from 0-100 km/h (seconds)		10.9	10.9	10.9	10.9	10.9	10.9
Maximum authorised weight (kg)		1,640	1,640	1,670	1,640	1,640	1,670
Weight in running order (with driver) (kg)		1,150	1,155	1,165	1,150	1,155	1,165
Maximum authorised weight on front axle (kg)		900	910	940	900	910	940
Maximum authorised weight on rear axle (kg)		790	780	780	790	780	780
Permitted roof load (kg)		75	75	75	75	75	75
Maximum trailer weight without brakes (kg)		570	570	580	570	570	580
Weight of trailer with brakes, gradients up to 8%	(kg)	1,200	1,200	1,200	1,200	1,200	1,200
Weight of trailer with brakes, gradients up to 12%	(kg)	1,100	1,100	1,100	1,100	1,100	1,100

Diesel engine 1.4 TDI 77 kW (105 PS)

Power output in kW (PS) at rpm	Maximum to	orque (Nm at rpm)	No. of cylinders/displacem	ient (cm³)	Fuel	
77 (105)/3,500-3,750	250/1	,750-2,500	3/1,422		Min, diesel acc. to DIN EN 590 51 CN	
Outputs and weights		IBIZA with Start-Stop	IBIZA without Start-Stop		ZA SC tart-Stop	IBIZA SC without Start-Stop
Top speed (km/h)		192	192	1	192	192
Acceleration from 0-80 km/h (seconds)		6.9	6.9	6	6.9	6.9
Acceleration from 0-100 km/h (seconds)		9.9	9.9	9	9.9	9.9
Maximum authorised weight (kg)		1,650	1,650	1,	,650	1,650
Weight in running order (with driver) (kg)		1,161	1,156	1,	,161	1,156
Maximum authorised weight on front axle (kg)		920	920	9	920	920
Maximum authorised weight on rear axle (kg)		780	780	7	780	780
Permitted roof load (kg)		75	75		75	75
Maximum trailer weight without brakes (kg)		580	570	5	580	570
Weight of trailer with brakes, gradients up to 8	% (kg)	1,200	1,200	1,	,200	1,200
Weight of trailer with brakes, gradients up to 1	2% (kg)	1,100	1,100	1,	,100	1,100

Technical specifications

Dimensions

← A → ← B →	← _ E _ → ← _ F _ →
Fig. 182 Dimensions	G → →

Fig. 182		IBIZA	IBIZA SC
A/B	Front and rear projections (mm)	857/735	857/717
с	Wheelbase (mm)	2,469	2,469
D	Length (mm)	4,061	4,043
E/F	Front/rear ^{a)} track width (mm)	1,465/1,457	1,465/1,457
G	Width (mm)	1,693	1,693
н	Height at kerb weight (mm)	1,445	1,428
	Turning radius (m)	10.7	10.7

^{a)} This data will change depending on the type of wheel rim.

Index

A

ABS 155
control lamp 156
Accessories 187
Additional electrical appliances (efficiency pro-
gramme) 31
Adjusting
front head restraints 60, 128
lights 121
rear head restraints 60
Adjusting the front seats
adjusting the lumbar support 127
Adjusting the head restraints
front head restraints 128
rear head restraints 60
Adjusting the seat 127
Adjustment
CAR menu
seats
AFS headlight bulbs
Airbag covers
Airbags
description
Airbag system
control lamp 68
deactivation of front airbag 70
description
front airbags 14, 69
functioning 68
head-protection airbags 15
side airbags 15

Air conditioning 39, 141
climatronic
controls 141
general notes 137
manual air conditioning 40
Air outlets
Air recirculation
air conditioning
heating and fresh air
Alarm system
switching off 112
Alloy wheel rims
Alternator
warning lamp 208
Ambient lighting
Anti-freeze
Anti-lock brake system 152, 154, 155
control lamp
Anti-puncture
Anti-puncture kit
check after 10 minutes
Anti-puncture set
Anti-puncture set
Anti-theft alarm system
switching off 112
Aquaplaning 212
Aspects to note before setting off
ASR
control lamp 153
Assistance systems
parking aid 173, 174
Assistance Systems
fatigue detection 171
Assisted starting
Audible warning signal
seat belt not fastened
warning and control lamps

Automatic car wash tunnel	189
Automatic gearbox	158
driving programmes	158
driving tips	162
kick-down device	163
manual release of selector lever	. 38
selecting gears with Tiptronic	161
selector lever lock	161
selector lever positions	159
tiptronic	158
Automatic lighting	118
AUX-IN	105

В

Back seat

folding down and raising the back seat back-

rest	
Ball coupling	
Battery	111
Before setting off	56
Belt pretensioners	
Biodiesel	197
Bonnet	10, 198, 201
closing	200
opening	199
Boot hatch	113
Boot lid	113
Brake assist	152
Brake fluid	43, 206
changing	206
Brake pads	
Brakes	
brake fluid	206
new Brake pads	149
Brake servo	
Brake system	206

Braking

brake assist 1	52
Braking distance 1	49
Braking system	
warning lamp 1	50
Bulbs	
changing the bulbs	83
Buzzer 1	19

С

Capacities 40
fuel tank
Car care
exterior 189
Catalytic converter 166, 167
malfunction 167
CCS
Central locking
anti-theft alarm 111
automatic speed-dependent locking 108
central locking button 108
electric windows 116
key by remote control 110
selective unlocking system 107
self-locking system to prevent involuntary un-
locking
unlocking system 108
Central locking system 106
safe security system 106
Cetane number (diesel fuel) 197
Changing a
DRL light bulb 84
Changing a bulb
additional brake light 90
luggage compartment light 90
tail light bulbs
turn signal light 86

Changing a double headlight bulb	
dipped beam headlights	86
double headlight bulbs	85
Changing an AFS headlight bulb	87
turn signal light	87
xenon light	87
Changing a single headlight bulb	
side light	85
single headlight bulbs	84
turn signal light	84
Changing a wheel	47
subsequent work	50
Changing double headlight bulb	
side light	85
Changing settings	
CAR menu	24
	78
Changing the bulbs	
AFS headlight bulbs	87
fog light bulbs	87
general notes	83
interior light and reading light	90
number plate light	90
turn signals	89
Changing the double headlight bulb	
main beam	86
Changing the single headlight bulbs	
dipped/main beam	
,	52
Checking levels	
engine compartment 2	201
Child-proof locking	
electric windows 1	.14
Child seat	
categorisation in groups	73

Child as sta	< 70
Child seats 10	-
ISOFIX system	
safety instructions 10	-
securing with the seat belt	
Top Tether system 18	8,20
Chrome parts	
cleaning	192
Cigarette lighter	132
Cleaning	188
alloy wheel rims	193
chrome parts	192
engine compartment	193
fabric	194
high pressure cleaners	190
leather	195
plastic parts 191,	194
radio and climate controls	194
rubber seals	192
seat belts	195
steel wheel rims	193
stickers	191
upholstery	194
washing the vehicle	189
windows and exterior mirrors	192
windscreen wiper blades	192
wooden trim	194
Climatronic	
adjusting the temperature	144
air recirculation	144
automatic mode	144
blower selection	144
controls	144
general notes	137
windscreen defrost	145
Close	

Closing 106 bonnet 200 tilting panoramic roof 116 windows 114 Coming Home 119
Coming Home Function 119
Contact key 147
Control and warning lamps
alternator
anti-lock brake system (ABS) 156
ASR 153
braking system
diesel particulate filter
EDL
emission control
engine oil 202
ESC 152
instrument panel 37
lights 117
steering column lock 145
windscreen washer fluid 123
Controls and displays
general instrument panel
operating the audio system 102
operating the telephone and audio system 102
Convenience closing
tilting panoramic sunroof 116
windows 116
Convenience opening
windows 116
Coolant
checking level 205
Coolant level
control lamp 204

Coolant temperature
control lamp 204
safety instructions 205
cooling system
checking coolant 205
Cooling system
checking coolant 204
coolant temperature gauge
topping up coolant 204, 205
Correct position 57
Correct sitting position
front passenger 58
rear seat passengers 59
Cruise control 34, 180
adjusting the stored speed 181
complete deactivation 182
control lamp 180
temporary deactivation 181
Current 133
n

Dangers in not using the seat belt
Dash panel 35
Data sticker
Deactivating the front passenger front airbag 14
Deactivation of front airbag 70
Diesel
diesel particulate filter 166
refuelling 197
Diesel engine particulate filter
Diesel particulate filter
malfunction 167
Digital clock 94
Dimensions
Direction of rotation
tyres 49
Display

Disposal
seat belt tensioners 66
Door handle
de-icing 192
Door lock
de-icing 192
Door lock cylinder
de-icing 192
Door release lever 93
Doors
childproof locks 109
opening and closing 9
Double headlight bulbs 85
Driver
see Correct sitting position 57, 58, 59
Driver information system
additional electrical appliances 31
assist systems 29
bonnet, rear lid and doors open 28
engine oil temperature 31
gear-change indicator 28
journey data 29
menu 27
operation 25
outside temperature 27
saving tips 31
service intervals 33
speed warning 32
timer 31
warning and information messages 29
Driving
driving abroad 169
driving through water 169
economical driving 165
with a trailer 184

Driving abroad

Driving abroad
headlights
petrol
Driving assistance systems
cruise control 180
Driving data
data summary 30
memory 29
Driving on flooded roads 169
Driving safety 56
Driving with a trailer 183
DSG 158
Duplicate keys 110
Dust and pollen filter 137
Dynamic headlight range control 121

E

L10
see Ethanol (fuel) 196
Easy Connect 24, 99
EDL
see Electronic differential lock 154
EDS 154
Efficiency programme
additional electrical appliances
saving tips
Electrical power socket 133
Electric windows 11, 114
convenience opening/closing 116
Electrolyte 209
Electronic differential lock 152, 154
control lamp 155, 156
Electronic differential lock (XDS) 156
Electronic immobiliser 147
Electronic stability control (ESC) 154
Electronic Stability Control (ESC) 152

Emergencies
bulbs 45
changing a wheel 47
changing the battery 209
emergency towing of the vehicle
emergency warning triangle
fire extinguisher
first-aid kit 75
fuses
hazard warning lights 121
Jump leads 52
panoramic/tilting sunroof 11
puncture
replacing a blown fuse
spare wheel 75
vehicle tools
Emergency operation
selector lever
Emergency warning triangle
Emission control system
control lamp
Emissions data 216
Engine
assisted starting
running in
Start-Stop system 170
Engine compartment 10, 198, 201
battery
brake fluid 206
closing
coolant 204, 205
engine oil
opening 199
safety notes
windscreen washer liquid 207

Engine coolant	42
checking level 2	04
G12 plus-plus	42
G13	42
specifications	42
Engine data 2	19
Engine fault	
control lamp 1	68
Engine management 1	66
control lamp 1	68
Engine oil 41, 2	01
changing 201, 2	04
check oil level 2	03
consumption 2	03
diesel	01
engine oil dipstick 2	03
inspection service 2	01
maintenance intervals 2	01
oil properties	41
specifications 2	01
temperature display	31
topping up 2	03
Engine oil pressure	
control lamp 2	02
Environment	
	65
environmental compatibility 1	64
Environmental tips	
- J	96
Equipment 1	87
	52
electronic stability control 152, 1	54
	54
see also Electronic Stability Control (ESC) 1	52
	96
Exhaust gas emission control system 1	67

Exhaust gas purification system

5	
catalytic converter	166
diesel particulate filter	166
Extending	
the luggage compartment	129
exterior lighting	
changing the bulbs	
Exterior mirrors	125
adjusting	13
control	126
folding in electrically	126
folding in manually	125
heated	126
Exterior view	5,6

F

Fabric: cleaning 194
Fastening rings 134
Fatigue detection 171
Fault in electronic differential lock (EDL)
control lamp 155
Faulty bulbs
changing the bulbs 83
Filling the fuel tank 196
Filling the tank 196
fuel gauge 98
Fire extinguisher 75
First-aid kit 75
Floor mats 61
Fluid Level control 40
Fog-light bulb
FR version
Fog light bulb 87
Front airbags 14, 69
safety instructions 69
Front ashtray 132
Front drink holder 131

Front passenger front airbag
control lamp 68
deactivation 14
Front seat
manual adjustment 12
Front seat backrest
folding 127
lifting 127
Fuel 41, 196
consumption 217
diesel
ethanol 196
fuel gauge 98
refuelling 196
saving 165
Fuel consumption 165
why does fuel consumption increase? 167
Fuel tank cap
opening and closing 41
Fuel tank flap
opening and closing 41
Fuses 44, 80
fuse box
identifying blown fuses 45
identifying by colours 44
preparation before replacing 44
replacing 44
G
Gear-change indicator

 Gearbox lever
 37

 Gear change
 37

 automatic
 38

 changing gears (manual gearbox)
 158

 manual
 37

 manual gear change
 158

 Gear engaged
 37

Gear recommendation	. 28
General instrument panel	
controls and displays	. 93
turn signal and main beam lever	119
warning and indication lamps	. 35
General overview of the engine compartment	201
Glove compartment	130
Glow plug system	149

Η

Handbrake 149, warning lamp	
5 1	
Hazard warning lights 22,	
НВА	
Head-on collisions and the laws of physics	. 63
Head-protection airbags	
description	. 15
safety instructions	. 15
Headlight range control	
Headlights	
driving abroad	169
fog lights	
headlight washer	
-	
Head restraints	
adjustment	
front head restraints	
rear head restraints	. 60
Headrests	. 12
adjustment	128
front	. 60
rear	. 60
Heated rear window	
heating element wires	192
switch	123
Heating	140
defrosting the windscreen	140
demisting the windscreen and side windows	140
demisting the windscreen and side windows	140

Heating and fresh air 40, 139
Heating and fresh air system
controls 139
Heating system 140
Hill driving assistant 157
Horn
How to jump start 52
description 52
Hydraulic Brake Assist
automatic hazard warning lights activation 155

I

Identification plate 2	16
Identifying letters on engine 2	16
Ignition	47
Ignition lock 21, 1	47
Incorrect sitting position	59
Indications on the display	95
assist systems submenu	29
compass	96
distance travelled	95
doors, bonnet and rear lid open	28
driver information system	25
ECO	96
journey data	29
МКВ	96
outside temperature	27
recommended gear	96
SEAT Drive Profile 1	83
second speed display	96
selector lever position	96
selector lever positions 1	59
service intervals	33
speed warning	96
Start-Stop	96
time	96
warning and information messages	29

Infotainment system 24
Inspection
Inspection service
Instrument cluster
Instrument panel
display
instruments
odometer
service interval indication
warning and control lamps
Interior lights
Interior mirror 125
anti-dazzle 125
Interior view
left guide 7
right-hand drive
ISOFIX
ISOFIX system
ISOFIX System

J

Jack	47
mounting points	48
Journey data	25
Jump leads	52

Κ

Key-operated switch
unlocking and locking 110
Keys
replacing the battery 111
spare key 110
synchronise 111
unlocking and locking 110
vehicle key 110

Kick-down

automatic gearbox		163
-------------------	--	-----

L

1 1 11 44	~
Leaving Home 11	
Leaving Home Function 11	
Lifting the vehicle 4	
Lighting of the instrument panel, 12	
Lights	
adaptive headlights 12	
additional brake light 9	
automatic lighting 11	
changing the bulbs 8	
coming home 11	9
control and warning lamps 11	7
daytime running lights 11	8
fog lights 11	8
fog lights with cornering function 12	1
headlight range control 12	1
interior light and front reading lights	0
interior lights 12	2
leaving home 11	9
lighting of the instrument panel 12	1
light switch 11	7
luggage compartment light	0
main beam lever 11	
main beams 2	2
number plate light 9	0
parking lights 11	9
reading lights 12	2
turn signal lever 11	9
turn signals 8	9
Light switch 2	1
Load compartment in the luggage compartment	
see Loading the luggage compartment 13	3
Loading the luggage compartment 13	3

Loading the vehicle

	fastening rings 13	34
	luggage compartment	9
	roof luggage rack 13	85
L	ocking and unlocking	
	with the central lock button 10)8
L	uggage 13	33
L	uggage compartment	33
	luggage compartment lighting 12	
	store the rear shelf 13	85
	unlocking manually 1	0
	see also Loading the luggage compartment . 13	33
L	uggage compartment lid 1	0

Μ

Main beam lever	119
Maintenance and cleaning	187
maintenance intervals	201
Malfunction	
catalytic converter	167
diesel particulate filter	167
gearbox	163
Manual gearbox	158
Mobile	188
Mobile phones	188
Modifications	187
Multimedia	105

Ν

Noises

tyres	49
Number of seats	61

0

Octane rating	(petrol)	 	 						 196

Odometer
reset button
total
trip recorder
Oil change 204
Oil properties 41
One-touch opening and closing
electric windows 115
Open and close 106
rear lid 113
Opening 106
bonnet 10
fuel tank flap 196
tilting panoramic roof 116
windows 114
Opening and closing
bonnet 10
by remote control 110
fuel tank flap 196
in the lock cylinder 9
rear lid 113
rear lid of the luggage compartment
tilting panoramic roof 116
windows 114
with the central lock button 108
Outside temperature 27

Ρ

Parking	151
Parking aid	173
Parking Aid	
adjusting the display and audible warnings .	177
automatic activation	175
fault	177
parking system plus	174
rear parking aid	174
sensors and camera: cleaning	191

towing bracket 177
visual indication 176
Parking aid system
see Parking aid 173, 174
Parking distance warning system
see Parking aid 173, 174
Parking (automatic gearbox)
ParkPilot
see Parking aid 173, 174
Particulate filter (diesel)
Parts
Passenger
see Correct sitting position 57, 58, 59
Pedals
Petrol
additives 196
refuelling
Plastic parts: cleaning 191, 194
Pollution filter
Positioning seat belts
during pregnancy
seat belts
Power-assisted steering
Power steering
Pre-heating system
control lamp
Products for vehicle maintenance 188
Puncture
action 45

R

Radio frequency remote control	110
Raising the vehicle	48
Rear Assist	177
instructions for use	178
parking	179

screen 178
special characteristics 179
Rear Assist system 177
Rear drink holder 132
Rear fog light
control lamp 117
Rear seat passengers
see Correct sitting position 57, 58, 59
Rear shelf
store
Rear View Camera 177
Rear view mirror 125
Rear view mirrors 125
Rear window automatic wiper-washer 124
Rear window wiper 124
Rear Window wiper 123
Rear window wiper blade
changing
cleaning
Refuelling 196
opening fuel tank flap 196
Repair work 187
Replacement
parts
Replacement keys 110
Replacement parts 187
Replacing the battery
of the vehicle key 111
Reset the trip recorder
Rev counter
Rims
changing a wheel 47
Roll-back function
tilting panoramic sunroof 117
windows 115
Roof aerial

Roof carrier system	135
Roof luggage rack	135
attach the cross bars	136
Roof rack	135
Rubber seals	
care	
Run-in	210
brake pads	164
tyres	164
Running in	
engine	164

S

safe
driving safe 56
Safe
Safe Security system 106
Safety
child safety
child seats
deactivating the front passenger airbag 14
Safe driving
Safety equipment
Safety instructions
coolant temperature
front airbags
head-protection airbags 15
side airbags
using child seats
Safety notes
seat belt tensioners
using seat belts
Saving tips (efficiency programme)
Saving ups (enciency programme)
heating 128

Seat belt position

for pregnant women 12
seat belts 12
Seat belts 61
adjustment 12,64
control lamp 62
protective function 62
purpose 61, 66
safety notes 63
unfastened 63
Seat belt tensioners 13
control lamp 68
SEAT Drive Profile 182
indications on the display 183
SEAT Drive Profile System 182
Seat heating 128
Selective opening 107
Selector lever (automatic gearbox)
manual release 38
positions 159
Service intervals 33
Service notification: read 34
Side airbags
description 15
safety instructions 69
Side and interior bulbs 89
Signal lever 22
Single headlight bulbs 84
Sitting position
driver 57
Snow chains 50, 218
Spanner symbol 33
Spare wheel 75
Speed limiter 180
Speed warning 32
Speed warning device 32
Sport Mode 154

Index Switching the ignition on and off 21, 147

Start-Stop
activating and deactivating 171
function 170
Start-Stop System 170
Starting the engine 148
after the fuel tank has been run dry 149
diesel
petrol
Starting the vehicle
Steel wheel rims
cleaning 193
Steering
control lamp 145
electromechanical 146
power 146
power-assisted steering 146
steering column lock 146
Steering wheel
adjustment 13
Steering wheel controls 101
Steering wheel height adjustment
Storage compartment
glove compartment lighting 122
of front door panel 131
on the driver side 130
on the front passenger side 130
right front seat 131
storage pocket in the seat
Storage compartments 130
Sun visor
sliding/tilting sunroof 116
Sun visors 123
Switch
hazard warning lights 121
Switching off the engine 149
Switching off the lights 117
Switching on the lights 117

т
Tail light bulbs
Tail lights
access 88
change 89
summary 88
Taking care of your vehicle 188
Technical specifications 216
Temperature display
engine oil 31
outside temperature 27
Tightening the belt 65
Tightening torque of wheel bolts 218
Tilting panoramic roof 116
closing 116
opening 116
Tilting panoramic sunroof 11
convenience closing 116
roll-back function 117
Timer 31
lap times 31
menu 31
statistics 31
Tiptronic (automatic gearbox) 158
Tire Mobility Set
inflating a tyre
Top speed 32
Top Tether 18, 20
Top Tether system 18
Top Tether System 20
Tow-starting 52, 79
Towing bracket
ball coupling 184
retrofitting 185

Towing bracket device 183 Towing the vehicle 51, 79 Towline anchorage 183
front
rear
Towline anchorages 51, 80
Traction control system 152, 153, 154
control lamp 153
Trailer
mode 183, 217
parking Aid 177
Trailer turn signals
control lamp 119
Trailer weights
Transporting children 72
Transporting items
fastening rings 134
Transporting objects
roof carrier system 135
roof luggage rack 135
Turn signal lever 119
Turn signals
control lamp 119
Two-way radios
Tyre mobility set
components
sealing a tyre
Tyre Mobility System
see Anti-puncture kit
Tyre pressure monitoring system
Tyre pressures
Tyre profile
Tyre repair
Tyre repair kit
see Anti-puncture kit
2007

Tyres
changing 47
new tyres 212
pressure 210, 211, 213
useful life 211
wear indicators 211
with directional tread 49
with directional tread pattern
Tyre tread depth 211
Tyre wear 211

U

Unfastening the seat belt 12, 64
Unlocking and locking
by remote control 110
with the central lock button 108
Unlocking manually
rear lid
Upholstery: cleaning 194
USB/AUX-IN input 105

V

Vanity mirror	23
data sticker 2	
identification data 2	216
identification number	216
raising	48
vehicle identification number 2	216
Vehicle battery 43, 2	207
assisted starting	52
changing 2	209
charging 2	209
connecting and disconnecting	207
disconnect and connect	34
electrolyte level	209
winter conditions 2	207

Vehicle care

windscreen wipers service position 54
Vehicle documentation compartment 130
Vehicle interior heating or cooling system 141
Vehicle interior monitoring and anti-tow system
activation 113
Vehicle paint
code 216
Vehicle paintwork
Maintenance 191
polishing 191
products for vehicle maintenance 189
Vehicle seats
vehicle tools
Vehicle tools
housing 75
Vehicle underbody
protection 193
Vehicle washing 189
Ventilation
Ventilation slits 134

W

Warning and control lamp
cruise control 180
Warning and control lamps 98
audible warning signal
engine management 168
engine pre-heating/fault system 168
instrument panel display 36
Warning and indication lamps
airbags 70
instrument panel 35
seat belt 62
tyres 213

Warning messages

red
yellow
Warning symbols
see also Warning and control lamps
Warning triangle 121
Washing
care of the vehicle exterior
Washing the vehicle 189
high pressure cleaners 190
stickers 191
Weights
Wheel balance 211
Wheel bolts 218
anti-theft 48
caps
loosening 48
tightening torque 213
Wheel cover
removing
Wheels
anti-theft bolts 48
chains
changing 47
new wheels 212
removing and fitting 49
snow chains 50
wheel cover
Windows
electric
removing ice 192
Window wiper blade 23
Windscreen and rear window wiper blades 78
Windscreen defrosting 140
Windscreen washer 43, 123
Windscreen washer fluid
control lamp 123

Windscreen washer water

check 207
filling amounts 207
topping up 207
Windscreen wiper blades
cleaning
Windscreen wipers
winuscieen wipers
lifting the wiper blades
replacing the wiper blades
service position
Winter conditions
battery 207
diesel
snow chains 50
thawing windows 192
tyres
Winter tyres
sizes 214

Χ

XDS 156

SEAT S.A. is permanently concerned about continuous development of its types and models. For this reason we ask you to understand, that at any given time, changes regarding shape, equipment and technique may take place on the car delivered. For this reason no right at all may derive based on the data, drawings and descriptions in this current handbook.

All texts, illustrations and standards in this handbook are based on the status of information at the time of printing. Except for error or omission, the information included in the current handbook is valid as of the date of closing print.

Re-printing, copying or translating, whether total or partial is not allowed unless SEAT allows it in written form.

SEAT reserves all rights in accordance with the "Copyright" Act.

All rights on changes are reserved.

R This paper has been manufactured using bleached non-chlorine cellulose.

© SEAT S.A. - Reprint: 15.11.16







