

WT
SECTION
ROAD WHEELS & TIRES

A
B
C
D

WT

CONTENTS

<p>BASIC INSPECTION 4</p> <p>DIAGNOSIS AND REPAIR WORK FLOW 4</p> <p style="padding-left: 20px;">Work Flow4</p> <p>INSPECTION AND ADJUSTMENT 6</p> <p>TRANSMITTER WAKE UP OPERATION6</p> <p style="padding-left: 20px;">TRANSMITTER WAKE UP OPERATION : De- scription6</p> <p style="padding-left: 20px;">TRANSMITTER WAKE UP OPERATION : Trans- mitter Wake-up Procedure6</p> <p>ID REGISTRATION PROCEDURE6</p> <p style="padding-left: 20px;">ID REGISTRATION PROCEDURE : Description.....6</p> <p style="padding-left: 20px;">ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure7</p> <p>SYSTEM DESCRIPTION 9</p> <p>TPMS 9</p> <p style="padding-left: 20px;">System Diagram9</p> <p style="padding-left: 20px;">System Description9</p> <p style="padding-left: 20px;">Component Parts Location 10</p> <p style="padding-left: 20px;">Component Description 10</p> <p>DIAGNOSIS SYSTEM (LOW TIRE PRES- SURE WARNING CONTROL UNIT)11</p> <p style="padding-left: 20px;">Diagnosis Description 11</p> <p style="padding-left: 20px;">CONSULT-III Function 12</p> <p>DTC/CIRCUIT DIAGNOSIS14</p> <p>C1704, C1705, C1706, C1707 LOW TIRE PRESSURE14</p> <p style="padding-left: 20px;">Description 14</p> <p style="padding-left: 20px;">DTC Logic 14</p> <p style="padding-left: 20px;">Diagnosis Procedure 14</p> <p>C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)16</p> <p style="padding-left: 20px;">Description 16</p>	<p style="padding-left: 20px;">DTC Logic16</p> <p style="padding-left: 20px;">Diagnosis Procedure16</p> <p style="padding-left: 20px;">Special Repair Requirement19</p> <p>C1716, C1717, C1718, C1719 TRANSMITTER (PRESSDATA)20</p> <p style="padding-left: 20px;">Description20</p> <p style="padding-left: 20px;">DTC Logic20</p> <p style="padding-left: 20px;">Diagnosis Procedure20</p> <p style="padding-left: 20px;">Component Inspection21</p> <p style="padding-left: 20px;">Special Repair Requirement21</p> <p>C1720, C1721, C1722, C1723 TRANSMITTER22</p> <p style="padding-left: 20px;">Description22</p> <p style="padding-left: 20px;">DTC Logic22</p> <p style="padding-left: 20px;">Diagnosis Procedure22</p> <p style="padding-left: 20px;">Special Repair Requirement25</p> <p>C1728 RECEIVER ID26</p> <p style="padding-left: 20px;">Description26</p> <p style="padding-left: 20px;">DTC Logic26</p> <p style="padding-left: 20px;">Diagnosis Procedure26</p> <p>C1729 VEHICLE SPEED SIG ERR29</p> <p style="padding-left: 20px;">Description29</p> <p style="padding-left: 20px;">DTC Logic29</p> <p style="padding-left: 20px;">Diagnosis Procedure29</p> <p>C1750, C1751, C1752, C1753 RECEIVER30</p> <p style="padding-left: 20px;">Description30</p> <p style="padding-left: 20px;">DTC Logic30</p> <p style="padding-left: 20px;">Diagnosis Procedure30</p> <p>C1754 LOW TIRE PRESSURE WARNING CONTROL UNIT32</p> <p style="padding-left: 20px;">Description32</p> <p style="padding-left: 20px;">DTC Logic32</p> <p style="padding-left: 20px;">Diagnosis Procedure32</p> <p style="padding-left: 20px;">Special Repair Requirement34</p>	<p>F</p> <p>G</p> <p>H</p> <p>I</p> <p>J</p> <p>K</p> <p>L</p> <p>M</p> <p>N</p> <p>O</p> <p>P</p>
--	--	--

C1755, C1756, C1757, C1758 POOR RECEIVING CONDITIONS	35	TURN SIGNAL LAMP BLINKS	65
Description	35	Description	65
DTC Logic	35	Diagnosis Procedure	65
Diagnosis Procedure	35	ID REGISTRATION CANNOT BE COMPLETED	66
U1000 CAN COMM CIRCUIT	37	Description	66
Description	37	Diagnosis Procedure	66
DTC Logic	37	NORMAL OPERATING CONDITION	67
Diagnosis Procedure	37	Description	67
U1010 CONTROL UNIT (CAN)	38	NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING	68
Description	38	NVH Troubleshooting Chart	68
DTC Logic	38	PRECAUTION	69
Diagnosis Procedure	38	PRECAUTIONS	69
POWER SUPPLY AND GROUND CIRCUIT	39	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	69
Description	39	Service Notice or Precautions	69
Component Function Check	39	PREPARATION	70
Diagnosis Procedure	39	PREPARATION	70
TIRE PRESSURE WARNING CHECK SWITCH	41	Special Service Tool	70
Description	41	Commercial Service Tool	70
Component Function Check	41	PERIODIC MAINTENANCE	71
Diagnosis Procedure	41	ROAD WHEEL	71
LOW TIRE PRESSURE WARNING LAMP	43	Adjustment	71
Description	43	REMOVAL AND INSTALLATION	74
Component Function Check	43	ROAD WHEEL TIRE ASSEMBLY	74
Diagnosis Procedure	43	Exploded View	74
ECU DIAGNOSIS INFORMATION	45	Removal and Installation	74
TPMS CONTROL UNIT	45	Inspection	74
Reference Value	45	TPMS CONTROL UNIT	76
Wiring Diagram - TIRE PRESSURE MONITORING SYSTEM -	47	Exploded View	76
DTC Inspection Priority Chart	55	Removal and Installation	76
DTC Index	56	TRANSMITTER	77
SYMPTOM DIAGNOSIS	58	Exploded View	77
TPMS	58	Removal and Installation	77
Symptom Table	58	TIRE PRESSURE RECEIVER	79
LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON	61	Exploded View	79
Description	61	FRONT TIRE PRESSURE RECEIVER	79
Diagnosis Procedure	61	FRONT TIRE PRESSURE RECEIVER : Removal and Installation	79
LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN OFF	62	REAR TIRE PRESSURE RECEIVER	79
Description	62	REAR TIRE PRESSURE RECEIVER : Removal and Installation	79
Diagnosis Procedure	62		
LOW TIRE PRESSURE WARNING LAMP BLINKS	63		
Description	63		
Diagnosis Procedure	63		

SERVICE DATA AND SPECIFICATIONS
(SDS)80

SERVICE DATA AND SPECIFICATIONS
(SDS)80
Road Wheel80
Tire Air Pressure80

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P



DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000005575206

DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

It is also important to clarify customer concerns before starting the inspection. Reproduce the symptom, and understand it fully. Interview the customer about the concerns carefully. In some cases, it is necessary to check the symptoms by driving the vehicle with the customer.

CAUTION:

Customers are not professionals. Never assume “maybe the customer means...” or “maybe the customer mentioned this symptom.

>> GO TO 2.

2. BASIC INSPECTION

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check the tire pressure for all wheels and adjust to the specified value. Refer to [WT-80. "Tire Air Pressure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Inspect or repair the tires or wheels.

3. CHECK LOW TIRE PRESSURE WARNING LAMP

Check low tire pressure warning lamp display.

Does not low tire pressure warning lamp turn OFF?

YES >> GO TO 4.

NO >> INSPECTION END

4. CRUISE TEST

Start the engine and drive the vehicle.

>> GO TO 5.

5. PERFORM SELF-DIAGNOSIS

 **With CONSULT-III**

Perform “AIR PRESSURE MONITOR” of self-diagnosis.

Is any DTC detected?

YES >> GO TO 7.

NO >> GO TO 6.

6. CHECK SYMPTOM

Perform trouble diagnosis for the applicable symptom. Refer to [WT-58. "Symptom Table"](#).

Is the cause of the malfunction detected?

YES >> GO TO 8.

NO >> GO TO 10.

7. CIRCUIT DIAGNOSIS

Inspect the malfunctioning system indicated by the DTC code that is detected during self-diagnosis. Refer to [WT-56. "DTC Index"](#).

>> GO TO 8.

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

8. REPAIR WORK

Repair or replace the malfunctioning part.

>> GO TO 9.

9. PERFORM SELF-DIAGNOSIS

1. Select "SELF-DIAG RESULTS" in "AIR PRESSURE MONITOR".
2. Touch "ERASE" on CONSULT-III screen to erase memory of the low tire pressure warning control unit.
3. Drive the vehicle.
4. Perform "AIR PRESSURE MONITOR" of self-diagnosis.

Is any DTC detected?

- YES >> GO TO 7.
NO >> GO TO 10.

10. FINAL CHECK

1. Perform a cruise test.
2. Check that the low tire pressure warning lamp turn OFF.

Dose the tire pressure warning lamp turn OFF?

- YES >> INSPECTION END
NO >> GO TO 2.

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT TRANSMITTER WAKE UP OPERATION

TRANSMITTER WAKE UP OPERATION : Description

INFOID:000000005243057

If the transmitter or low tire pressure warning control unit is replaced, always perform the transmitter wake-up procedure.

TRANSMITTER WAKE UP OPERATION : Transmitter Wake-up Procedure


INFOID:000000005243058

1. TRANSMITTER WAKE-UP PROCEDURE

1. Turn the ignition switch ON.
2. Contact the transmitter activation tool (J-45295) (1) to the side of the tire at the location to the transmitter.
3. Press and hold the transmitter activation tool button while pushing the tool to the tire surface. (approximately for 5 seconds)

CAUTION:

Perform the wake-up procedure starting from the vehicle front left wheel, then repeat the procedure in the order of the front right wheel, rear right wheel, and rear left wheel.



4. Check that the low tire pressure warning lamp blinks in the pattern shown as per the following. The pattern indicates that the transmitter wake-up procedure for the wheel is completed.

Low tire pressure warning lamp blinking timing		Activation tire position
ON OFF	a : 0.3 sec. b : 1.3 sec.	Front LH
ON OFF	a : 0.3 sec. b : 1.3 sec.	Front RH
ON OFF	a : 0.3 sec. b : 1.3 sec.	Rear RH
ON OFF	a : 0.3 sec. b : 1.3 sec.	Rear LH
ON OFF	a : 2 sec. b : 0.2 sec.	All tires

SEIA0762E

5. Check that the turn signal lamps blink twice when the transmitter wake-up procedure for all wheels is completed.
6. Check that the low tire pressure warning lamp turns OFF, after the transmitter wake-up procedure is completed for all wheels and turns OFF.

Is the transmitter wake-up procedure completed?

- YES >> Perform the transmitter ID registration procedure. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).
- NO >> Perform trouble diagnosis for the transmitter. Refer to [WT-16, "Diagnosis Procedure"](#).

ID REGISTRATION PROCEDURE

ID REGISTRATION PROCEDURE : Description

INFOID:000000005243059

If the transmitter or low tire pressure warning control unit is replaced, always perform the transmitter ID registration.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure INFOID:000000005243060

1. TRANSMITTER ID REGISTRATION PROCEDURE

Ⓜ With CONSULT-III.

1. Display the "WORK SUPPORT" screen and select "ID REGIST".

Is the transmitter activation tool (J-45295) used for the transmitter ID registration procedure?


- YES >> GO TO 2.
NO >> GO TO 3.

2. TRANSMITTER ID REGISTRATION PROCEDURE (WITH THE TRANSMITTER ACTIVATION TOOL)

1. Turn the ignition switch ON.
2. Select the start button on the "ID REGIST" screen.
3. Contact the transmitter activation tool (J-45295) (1) to the side of the tire at the location to the transmitter.
4. Press and hold the transmitter activation tool button while pushing the tool to the tire surface. (approximately for 5 seconds)

CAUTION:

Perform the ID registration procedure starting from the vehicle front left wheel, then repeat the procedure in the order of the front right wheel, rear right wheel, and rear left wheel.



5. When ID registration is completed, check the following pattern at each wheel.

Se-quence	ID registration position	Turn signal lamp	CONSULT-III
1	Front left wheel	2 blinks	"Red" ↓ "Green"
2	Front right wheel		
3	Rear right wheel		
4	Rear left wheel		

6. After the ID registration procedure for all wheels is completed, press "End" to end ID registration, and check that ID registration for all wheels is completed.

Is the check result normal?

- YES >> ID registration END.
NO >> Performs trouble diagnosis of the Tire Pressure Monitoring System (TPMS). Refer to [WT-66](#), "[Diagnosis Procedure](#)".

3. TRANSMITTER ID REGISTRATION PROCEDURE (WITHOUT THE TRANSMITTER ACTIVATION TOOL)

1. Adjust the tire pressure for all wheels to match the list below.

Tire position	Tire pressure kPa (kg/cm ² , psi)
Front LH	240 (2.4, 34)
Front RH	220 (2.2, 31)
Rear RH	200 (2.0, 29)
Rear LH	180 (1.8, 26)

2. Drive the vehicle at a speed at more than 40 km/h (25 MPH) for 3 minutes or more, then perform the transmitter ID registration procedure.
3. After ID registration for all wheels is completed, press "End" to end ID registration.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

ID registration position	CONSULT-III
Front LH	"Red" ↓ "Green"
Front RH	
Rear RH	
Rear LH	

4. Adjust the tire pressures for all wheels to the specified value. Refer to [WT-80, "Tire Air Pressure"](#).

Is ID registrations for all wheels completed?

YES >> ID registration END.

NO >> Performs trouble diagnosis of the Tire Pressure Monitoring System (TPMS). Refer to [WT-66, "Diagnosis Procedure"](#).

TPMS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

TPMS

System Diagram

INFOID:000000005243061



System Description

INFOID:000000005243062

- If the tire pressure is less than the specified value, the low tire pressure warning lamp illuminates that the tire pressure is less than the specified value.
- The signal from each control unit is communicated via CAN communication.


Control unit	Signal status
Low tire pressure warning control unit	The low tire pressure warning lamp signal is transmitted to the BCM via CAN communication.
BCM	The low tire pressure warning lamp signal is transmitted to the unified meter and A/C amp. via CAN communication.
AV control unit	The tire pressure signal is received from the low tire pressure warning control unit via CAN communication.
ABS actuator and electric unit (control unit)	The vehicle speed signal (ABS) is received from the low tire pressure warning control unit via CAN communication.

TPMS

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000005243063



- | | | |
|---|-----------------------------------|---------------------------------------|
| 1. Transmitter | 2. Front tire pressure receiver | 3. Rear tire pressure receiver |
| 4. Low tire pressure warning control unit | 5. Low tire pressure warning lamp | 6. Tire pressure warning check switch |
| A. Wheel | B. Fender protector (rear side) | C. Inside rear wheel house protector |
| D. Glove box assembly removed | E. Inside combination meter | F. Behind instrument lower panel LH |

Component Description

INFOID:000000005243064

Component parts	Function
Transmitter	WT-16, "Description" .
Tire pressure receiver	WT-30, "Description" .
Low tire pressure warning control unit	WT-32, "Description" .
Tire pressure warning check switch	WT-41, "Description" .
Unified meter and A/C amp.	Receives the tire pressure information via CAN communication, and operates the low tire pressure warning lamp.
Low tire pressure warning lamp	<ul style="list-style-type: none"> • When a tire pressure is low, the warning lamp illuminates. • When a flat tire occurs, the warning lamp illuminates. • When an electrical malfunction in the Tire Pressure Monitoring System (TPMS) is detected, the lamp first flashes, and then remains illuminated.

DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)

Diagnosis Description

INFOID:000000005243065

Description


During driving, the transmitter installed at each road wheel transmits the tire pressure information signal to the receiver. The receiver receives the tire pressure signal and transmits it to the low tire pressure warning control unit. The low tire pressure warning control unit judges whether or not the tire pressure is OK based on the tire pressure information signal, and if it judges that the tire pressure is low, it transmits the information via CAN communication to the BCM.

After receiving the tire pressure malfunction information via CAN communication, the BCM transmits the tire pressure malfunction information via CAN communication to the combination meter.

After receiving the tire pressure information via CAN communication from the BCM, the combination meter illuminates the low tire pressure warning lamp in order to warn the driver.

Self-diagnosis procedure

1. Initiate diagnosis mode by short-circuiting the low tire pressure warning check switch to the ground.
2. The blinking pattern of the low tire pressure warning lamp indicates the conditions of the malfunction.



NOTE:

If the low tire pressure warning lamp is blinking repeatedly at 5 Hz, there is no malfunction occurring in the system.

Flickering pattern	Items	Diagnostic item is detected when...	Check item
15	Tire pressure value (Front LH)	Front LH tire pressure drops to 182 kPa (1.82 kg/cm ² , 26.5 psi) or less	WT-14
16	Tire pressure value (Front RH)	Front RH tire pressure drops to 182 kPa (1.82 kg/cm ² , 26.5 psi) or less	
17	Tire pressure value (Rear RH)	Rear RH tire pressure drops to 182 kPa (1.82 kg/cm ² , 26.5 psi) or less	
18	Tire pressure value (Rear LH)	Rear LH tire pressure drops to 182 kPa (1.82 kg/cm ² , 26.5 psi) or less	
21	Transmitter no data (Front LH)	Data from front LH transmitter cannot be received.	WT-16
22	Transmitter no data (Front RH)	Data from front RH transmitter cannot be received.	
23	Transmitter no data (Rear RH)	Data from rear RH transmitter cannot be received.	
24	Transmitter no data (Rear LH)	Data from rear LH transmitter cannot be received.	

DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)

< SYSTEM DESCRIPTION >

Flickering pattern	Items	Diagnostic item is detected when...	Check item
31	Transmitter checksum error (Front LH)	Checksum data from front LH transmitter is malfunctioning.	WT-22
32	Transmitter checksum error (Front RH)	Checksum data from front RH transmitter is malfunctioning.	
33	Transmitter checksum error (Rear RH)	Checksum data from rear RH transmitter is malfunctioning.	
34	Transmitter checksum error (Rear LH)	Checksum data from rear LH transmitter is malfunctioning.	
35	Transmitter pressure data error (Front LH)	Air pressure data from front LH transmitter is malfunction.	WT-20
36	Transmitter pressure data error (Front RH)	Air pressure data from front RH transmitter is malfunction.	
37	Transmitter pressure data error (Rear RH)	Air pressure data from rear RH transmitter is malfunction.	
38	Transmitter pressure data error (Rear LH)	Air pressure data from rear LH transmitter is malfunction.	
41	Transmitter function code error (Front LH)	Function code data from front LH transmitter is malfunctioning.	WT-22
42	Transmitter function code error (Front RH)	Function code data from front RH transmitter is malfunctioning.	
43	Transmitter function code error (Rear RH)	Function code data from rear RH transmitter is malfunctioning.	
44	Transmitter function code error (Rear LH)	Function code data from rear LH transmitter is malfunctioning.	
51	Receiver ID registration not completed.	Receiver ID registration cannot be performed.	WT-26
52	Vehicle speed signal error	Speed signal is not detected.	WT-30
54	EEPROM read error	Tire Pressure Monitoring System (TPMS) malfunction in the low tire pressure warning control unit	WT-32
55	Low communication performance (Front LH)	The data signal from the front LH wheel transmitter cannot be detected due to external electromagnetic interference. (DTC C1708 is displayed at the same time.)	WT-35
56	Low communication performance (Front RH)	The data signal from the front RH wheel transmitter cannot be detected due to external electromagnetic interference. (DTC C1709 is displayed at the same time.)	
57	Low communication performance (Rear RH)	The data signal from the rear RH wheel transmitter cannot be detected due to external electromagnetic interference. (DTC C1710 is displayed at the same time.)	
58	Low communication performance (Rear LH)	The data signal from the rear LH wheel transmitter cannot be detected due to external electromagnetic interference. (DTC C1711 is displayed at the same time.)	
No flickering	Tire pressure warning check switch	Tire pressure warning check switch circuit is open.	—

Erase the diagnosis history.

After performing self-diagnosis by short-circuiting the Tire Pressure warning check switch to the body, turn the ignition switch OFF.

CONSULT-III Function

INFOID:000000005243066

FUNCTION

DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)

< SYSTEM DESCRIPTION >

The diagnosis functions (main functions) include the following: "WORK SUPPORT", "SELF DIAGNOSTIC RESULT", "DATA MONITOR", "ACTIVE TEST", and "ECU IDENTIFICATION".

Mode	FUNCTION DESCRIPTION
Work Support	In this mode, it is possible to make quick and accurate adjustments by following the instructions on the CONSULT-III display.
Self Diagnostic Result	Receives self-diagnosis results from the low tire pressure warning control unit, and indicates DTCs and the number of malfunctions.
Data Monitor	Receives input/output signals from the low tire pressure warning control unit and indicates and stores them to facilitate locating the causes of malfunctions.
Active Test	Sends command to the low tire pressure warning control unit to change output signals and check operation of output system.
ECU identification	Displays the part number of the low tire pressure warning control unit.

WORK SUPPORT

Refer to [WT-7. "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).

SELF-DIAGNOSTIC RESULT

Operation procedure

Before starting self-diagnosis, start the engine and drive the vehicle at faster than 40 km/h (25 MPH) for longer than 3 minutes.

Display Item List

Refer to [WT-56. "DTC Index"](#).

DATA MONITOR

Display Item List

Monitor item (Unit)	Remarks
VHCL SPEED SE (km/h) or (MPH)	Vehicle speed
AIR PRESS FL (kPa), (kg/cm ²) or (Psi)	Air pressure of tires
AIR PRESS FR (kPa), (kg/cm ²) or (Psi)	
AIR PRESS RR (kPa), (kg/cm ²) or (Psi)	
AIR PRESS RL (kPa), (kg/cm ²) or (Psi)	
ID REGST FL1	ID is registered: Done ID is not registered: Yet
ID REGST FR1	
ID REGST RR1	
ID REGST RL1	
WARNING LAMP	Low tire pressure warning lamp ON: On Low tire pressure warning lamp OFF: Off
BUZZER	Combination meter buzzer ON: On Combination meter buzzer OFF: Off

ACTIVE TEST

After completing the work below, perform an active test.

- Before performing self-diagnosis, register the transmitter IDs.
- Erase the self-diagnosis result history.

Test item list

Test item	Condition	Details
BUZZER	Vehicle stopped	Check that the buzzer operates correctly.
WARN LAMP	The system is normal	Perform a test to check that the low tire pressure warning lamp illuminates correctly.

ECU IDENTIFICATION

Low tire pressure warning control unit part number can be read.

C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS


C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

Description

INFOID:000000005549601

The transmitter (1) is installed at the position of the air valve on the road wheel (2). It measures the tire pressure and transmits the tire pressure information by radio waves.

⇐ :Outside



DTC Logic

INFOID:000000005549602

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1704	LOW PRESSURE FL	Front LH wheel pressure is or Less 182 kPa (1.86 kg/cm ² , 26.4 psi) or less	Low tire pressure
C1705	LOW PRESSURE FR	Front RH wheel pressure is or less 182 kPa (1.86 kg/cm ² , 26.4 psi) or less	
C1706	LOW PRESSURE RR	Rear RH wheel pressure is or less 182 kPa (1.86 kg/cm ² , 26.4 psi) or less	
C1707	LOW PRESSURE RL	Rear LH wheel pressure is or less 182 kPa (1.86 kg/cm ² , 26.4 psi) or less	

DTC REPRODUCTION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check the tire pressure for all wheels and adjust to the specified value. Refer to [WT-80, "Tire Air Pressure"](#).

3. Perform "AIR PRESSURE MONITOR" of self-diagnosis.

Is DTC "C1704", "C1705", "C1706", or "C1707" detected?

YES >> Perform trouble diagnosis. Refer to [WT-14, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000005549603

1. CHECK TIRE PRESSURE

Check the air pressure of all wheels. Refer to [WT-80, "Tire Air Pressure"](#).

Is the inspection result normal?

YES >> Replace any malfunctioning transmitters.

NO >> After adjusting the air pressure, GO TO 2.

2. CHECK TIRE PRESSURE SIGNAL

Ⓜ With CONSULT-III

C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Within 5 minutes, select "DATA MONITOR" of "AIR PRESSURE MONITOR" and display the tire pressure for all wheels.
3. Check that the tire pressures match the standard value.

Monitor item	Condition	Displayed value
AIR PRESS FL	Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.	Air pressure of tires
AIR PRESS FR		
AIR PRESS RR		
AIR PRESS RL		

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Repair or replace error-detected parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WT

C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

< DTC/CIRCUIT DIAGNOSIS >


C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

Description

INFOID:000000005549604

The transmitter (1) is installed at the position of the air valve on the road wheel (2). It measures the tire pressure and transmits the tire pressure information by radio waves.

⇐ :Outside



DTC Logic

INFOID:000000005549605

DTC logic

DTC	Display Item	Malfunction detected condition	Possible causes
C1708	[NO DATA] FL	Tire pressure data signal from the front LH wheel transmitter cannot be detected.	<ul style="list-style-type: none"> • Harness or connector connection malfunction (Tire pressure receiver, low tire pressure warning control unit) • Transmitter ID registration incomplete • Transmitter error • Low transmitter battery voltage
C1709	[NO DATA] FR	Tire pressure data signal from the front RH wheel transmitter cannot be detected.	
C1710	[NO DATA] RR	Tire pressure data signal from the rear RH wheel transmitter cannot be detected.	
C1711	[NO DATA] RL	Tire pressure data signal from the rear LH wheel transmitter cannot be detected.	

DTC REPRODUCTION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "C1708", "C1709", "C1710" or "C1711" detected?

- YES >> Perform trouble diagnosis. Refer to [WT-16, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000005549606

1. CHECK TIRE PRESSURE SIGNAL

Ⓜ With CONSULT-III

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Within 5 minutes, select "DATA MONITOR" of "AIR PRESSURE MONITOR".
3. Read the values that are displayed for "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR", and "AIR PRESS RL".

Monitor item	condition	Displayed value
AIR PRESS FL	Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.	Air pressure of tires
AIR PRESS FR		
AIR PRESS RR		
AIR PRESS RL		

C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

< DTC/CIRCUIT DIAGNOSIS >

Is a tire pressure of 0 kPa (psi) displayed for all wheels?

- YES >> GO TO 2.
 NO >> GO TO 4.

2. CHECK RECEIVER CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the low tire pressure warning control unit harness connector and tire pressure receiver harness connector.
3. Check the continuity between the harness connector terminals of the low tire pressure warning control unit and tire pressure receiver.

CHECK RECEIVER POWER CIRCUIT

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M96	10	E53 (Front LH)	1	Existed
	9	E19 (Front RH)		
	8	B43 (Rear LH)		
	7	B251 (Rear RH)		

CHECK RECEIVER SIGNAL CIRCUIT

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M96	6	E53 (Front LH)	3	Existed
	5	E19 (Front RH)		
	4	B43 (Rear LH)		
	3	B251 (Rear RH)		

CHECK RECEIVER SIGNAL (SENSITIVITY) CIRCUIT

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M96	22	E53 (Front LH)	2	Existed
	21	E19 (Front RH)		
	20	B43 (Rear LH)		
	19	B251 (Rear RH)		

CHECK RECEIVER GROUND CIRCUIT

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M96	26	E53 (Front LH)	4	Existed
	25	E19 (Front RH)		
	24	B43 (Rear LH)		
	23	B251 (Rear RH)		

4. Check the continuity between the low tire pressure warning control unit harness connector and the ground.

CHECK RECEIVER POWER CIRCUIT

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	10	Ground	Not existed
	9		
	8		
	7		

C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

< DTC/CIRCUIT DIAGNOSIS >

CHECK RECEIVER SIGNAL CIRCUIT

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	6	Ground	Not existed
	5		
	4		
	3		

CHECK RECEIVER SIGNAL (SENSITIVITY) CIRCUIT

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	22	Ground	Not existed
	21		
	20		
	19		

CHECK RECEIVER GROUND CIRCUIT

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	26	Ground	Not existed
	25		
	24		
	23		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3. CHECK TIRE PRESSURE RECEIVER POWER SUPPLY CIRCUIT

1. Connect the low tire pressure warning control unit harness connector.
2. Turn the ignition switch ON.

CAUTION:

Never start the engine.

3. Check the voltage between the tire pressure receiver harness connector and ground.

Tire pressure receiver		—	Voltage
Connector	Terminal		
E53 (Front LH)	1	Ground	9 - 16 V
E19 (Front RH)			
B43 (Rear LH)			
B251 (Rear RH)			

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the tire pressure receiver.

4. REGISTER THE TRANSMITTER ID

Perform transmitter ID registration. Refer to [WT-7. "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).

Is transmitter ID registration completed?

YES >> GO TO 5.

NO >> Replace the transmitter.

5. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT

Ⓟ With CONSULT-III

C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

< DTC/CIRCUIT DIAGNOSIS >

1. Drive for several minutes at a speed of 40 km/h (25 MPH) or more, then stop the vehicle.
2. Within 15 minutes, select "AIR PRESSURE MONITOR" of "DATA MONITOR" and display the tire pressure for all wheels.
3. Check that the tire pressure is the specified value.

Monitor item	Condition	Displayed value
AIR PRESS FL	Drive for several minutes at a speed of 40 km/h (25 MPH) or more, then stop the vehicle.	Air pressure of tire pressure
AIR PRESS FR		
AIR PRESS RR		
AIR PRESS RL		

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace the low tire pressure warning control unit.

Special Repair Requirement

INFOID:000000005549607

WT

1.CHECK TIRE PRESSURE

Check the tire pressure of all wheels. Refer to [WT-80, "Tire Air Pressure"](#).

Does the tire pressure match the specified value?

- YES >> GO TO 2.
NO >> Check the road wheels and tires. Adjust the tire pressures to the specified values.

2.REGISTER TRANSMITTER ID

Perform transmitter ID registration. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).

>> END

C1716, C1717, C1718, C1719 TRANSMITTER (PRESSDATA)

< DTC/CIRCUIT DIAGNOSIS >


C1716, C1717, C1718, C1719 TRANSMITTER (PRESSDATA)

Description

INFOID:000000005549608

The transmitter (1) is installed at the position of the air valve on the road wheel (2). It measures the tire pressure and transmits the tire pressure information by radio waves.

↔ :Outside



DTC Logic

INFOID:000000005549609

DTC logic

DTC	Display Item	Malfunction detected condition	Possible causes
C1716	[PRESSDATA ERR] FL	The tire pressure data from the front LH wheel is malfunction.	<ul style="list-style-type: none"> • Transmitter ID registration incomplete • Transmitter malfunction
C1717	[PRESSDATA ERR] FR	The tire pressure data from the front RH wheel is malfunction.	
C1718	[PRESSDATA ERR] RR	The tire pressure data from the rear RH wheel is malfunction.	
C1719	[PRESSDATA ERR] RL	The tire pressure data from the rear LH wheel is malfunction.	

DTC REPRODUCTION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check the tire pressure for all wheels and adjust to the specified value. Refer to [WT-80, "Tire Air Pressure"](#).

3. Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "C1716", "C1717", "C1718", or "C1719" detected?

YES >> Perform trouble diagnosis. Refer to [WT-20, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000005549610

1. CHECK TIRE PRESSURE SIGNAL

Ⓜ With CONSULT-III

1. Check and adjust the tire pressure for all wheels. Refer to [WT-80, "Tire Air Pressure"](#).

2. Perform transmitter ID registration for all wheels. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).

3. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.

4. Stop the vehicle and within 15 minutes select "DATA MONITOR" of "AIR PRESSURE MONITOR" and read the tire pressure for all wheels.

5. Check that "DATA MONITOR" displays a tire pressure of 438.60 kPa (4.47 kg/cm², 63.60 psi).

Is the inspection result normal?

C1716, C1717, C1718, C1719 TRANSMITTER (PRESSDATA)

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace the malfunctioning transmitter.
NO >> GO TO 2.

2.CHECK TPMS

Check the transmitters. Refer to [WT-21, "Component Inspection"](#).

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Perform trouble diagnosis of the low tire pressure warning control unit. Refer to [WT-32, "Diagnosis Procedure"](#).

Component Inspection

INFOID:000000005549611

1.CHECK TRANSMITTERS

 With CONSULT-III

1. Adjust the tire pressures to the specified value for all wheels. Refer to [WT-80, "Tire Air Pressure"](#).
2. Perform transmitter ID registration for all wheels. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).
3. Drive for several minutes at a speed of 40 km/h (25 MPH) or more, then stop the vehicle.
4. Within 15 minutes, select "DATA MONITOR" of "AIR PRESSURE MONITOR" to display the tire pressure for all wheels.
5. Check that "DATA MONITOR" displays a tire pressure of 438.60 kPa (4.47 kg/cm², 63.60 psi).

Monitor item	condition	Displayed value
AIR PRESS FL	Drive for several minutes at a speed of 40 km/h (25 MPH) or more, then stop the vehicle.	Air pressure of tire pressure
AIR PRESS FR		
AIR PRESS RR		
AIR PRESS RL		

Is the inspection result normal?

- YES >> Replace the malfunctioning transmitter.
NO >> INSPECTION END

Special Repair Requirement

INFOID:000000005549612

1.CHECK TIRE PRESSURE

Check the tire pressure of all wheels. Refer to [WT-80, "Tire Air Pressure"](#).

Does the tire pressure match the specified value?

- YES >> GO TO 2.
NO >> Check the road wheels and tires. Adjust the tire pressures to the specified values.

2.REGISTER TRANSMITTER ID

Perform transmitter ID registration. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).

>> END

C1720, C1721, C1722, C1723 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >


C1720, C1721, C1722, C1723 TRANSMITTER

Description

INFOID:000000005549613

The transmitter (1) is installed at the position of the air valve on the road wheel (2). It measures the tire pressure and transmits the tire pressure information by radio waves.

↔ :Outside



DTC Logic

INFOID:000000005549614

DTC logic

DTC	Display Item	Malfunction detected condition	Possible causes
C1720	[CODE ERR] FL	Checksum data from front LH transmitter is malfunctioning.	<ul style="list-style-type: none"> • Tire pressure receiver malfunction • Transmitter error • Low tire pressure warning control unit malfunction
C1721	[CODE ERR] FR	Checksum data from front RH transmitter is malfunctioning.	
C1722	[CODE ERR] RR	Checksum data from rear RH transmitter is malfunctioning.	
C1723	[CODE ERR] RL	Checksum data from rear LH transmitter is malfunctioning.	

DTC REPRODUCTION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓟ With CONSULT-III

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "C1720", "C1721", "C1722" or "C1723" detected?

- YES >> Perform trouble diagnosis. Refer to [WT-22, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000005549615

1. CHECK TIRE PRESSURE SIGNAL

Ⓟ With CONSULT-III

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Within 5 minutes, select "DATA MONITOR" of "AIR PRESSURE MONITOR".
3. Read the values that are displayed for "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR", and "AIR PRESS RL".

Display Item	Condition	Displayed value
AIR PRESS FL	Drive for 3 minutes at a speed of 40 km/h (25MPH) or more, then drive normally for 10 minutes.	Air pressure of tire pressure
AIR PRESS FR		
AIR PRESS RR		
AIR PRESS RL		

Is the tire pressure of 0 kPa displayed for all wheels?

- YES >> GO TO 2.

C1720, C1721, C1722, C1723 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 4.

2. CHECK HARNESS BETWEEN LOW TIRE PRESSURE WARNING CONTROL UNIT AND TIRE PRESSURE RECEIVER

1. Turn the ignition switch OFF.
2. Disconnect low tire pressure warning control unit harness connector and tire pressure receiver harness connector.
3. Check the continuity between low tire pressure warning control unit harness connector and tire pressure receiver harness connector.

CHECK RECEIVER POWER CIRCUIT

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M96	10	E53 (Front LH)	1	Existed
	9	E19 (Front RH)		
	8	B43 (Rear LH)		
	7	B251 (Rear RH)		

CHECK RECEIVER SIGNAL CIRCUIT

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M96	6	E53 (Front LH)	3	Existed
	5	E19 (Front RH)		
	4	B43 (Rear LH)		
	3	B251 (Rear RH)		

CHECK RECEIVER SIGNAL (SENSITIVITY) CIRCUIT

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M96	22	E53 (Front LH)	2	Existed
	21	E19 (Front RH)		
	20	B43 (Rear LH)		
	19	B251 (Rear RH)		

CHECK RECEIVER GROUND CIRCUIT

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M96	26	E53 (Front LH)	4	Existed
	25	E19 (Front RH)		
	24	B43 (Rear LH)		
	23	B251 (Rear RH)		

4. Check the continuity between low tire pressure warning control unit harness connector and ground.

CHECK RECEIVER POWER CIRCUIT

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	10	Ground	Not existed
	9		
	8		
	7		

C1720, C1721, C1722, C1723 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

CHECK RECEIVER SIGNAL CIRCUIT

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	6	Ground	Not existed
	5		
	4		
	3		

CHECK RECEIVER SIGNAL (SENSITIVITY) CIRCUIT

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	22	Ground	Not existed
	21		
	20		
	19		

CHECK RECEIVER GROUND CIRCUIT

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	26	Ground	Not existed
	25		
	24		
	23		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.CHECK TIRE PRESSURE RECEIVER

Check the tire pressure receivers. Refer to [WT-26. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the tire pressure receiver.

4.CHECK TIRE PRESSURE MONITORING CONTROL SYSTEM

Check the Tire Pressure Monitoring System (TPMS). Refer to [WT-32. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace the low tire pressure warning control unit.

5.CHECK TRANSMITTERS

1. Drive for several minutes at a speed of 40 km/h (25 MPH) or more, then stop the vehicle.
2. Within 15 minutes, select "DATA MONITOR" of "AIR PRESSURE MONITOR" and display the tire pressure for all wheels.
3. Check that the tire pressures is the specified value.

Display Item	Condition	Displayed value
AIR PRESS FL	Drive for several minutes at a speed of 40 km/h (25 MPH) or more, then stop the vehicle.	Air pressure of tire pressure
AIR PRESS FR		
AIR PRESS RR		
AIR PRESS RL		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the transmitter.

C1720, C1721, C1722, C1723 TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

Special Repair Requirement

INFOID:000000005549616

1.CHECK TIRE PRESSURE

Check the tire pressure of all wheels. Refer to [WT-80, "Tire Air Pressure"](#).

Does the tire pressure match the specified value?

YES >> GO TO 2.

NO >> Check the road wheels and tires. Adjust the tire pressures to the specified values.

2.REGISTER TRANSMITTER ID

Perform transmitter ID registration. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).

>> END

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WT

C1728 RECEIVER ID


< DTC/CIRCUIT DIAGNOSIS >

C1728 RECEIVER ID

Description

INFOID:000000005549617

The front (A) tire pressure receiver (1) and rear (B) tire pressure receiver (2) receive the tire pressure signal by radio waves from the transmitter at each wheel, and transmit the tire pressure signal to the low tire pressure warning control unit.



JSEIA0007ZZ

DTC Logic

INFOID:000000005549618

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1728	RECEIVER ID NO REG	Receiver ID registration cannot be performed.	<ul style="list-style-type: none"> Tire pressure receiver malfunction Low tire pressure warning control unit malfunction

DTC REPRODUCTION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

- Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
- Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "C1728" detected?

- YES >> Perform trouble diagnosis. Refer to [WT-26, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure


INFOID:000000005549619


1. CHECK RECEIVER INPUT SIGNAL

- Turn the ignition switch ON.
CAUTION:
Never start engine.
- Use an oscilloscope and check the input signal waveform between the low tire pressure warning control unit harness connector terminals and the ground. Refer to [WT-45, "Reference Value"](#).

C1728 RECEIVER ID

< DTC/CIRCUIT DIAGNOSIS >

Connector	Terminal	—	Standard	
M96	3	Ground	Stand by status (Approx. 4.5 V)	 OCC3879D
	4			
	5			
	6			

Connector	Terminal	—	Standard	
M96	3	Ground	When signal is received (Approx. 4.5 V)	 OCC3880D
	4			
	5			
	6			

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> GO TO 2.

2. CHECK TIRE PRESSURE RECEIVER POWER SUPPLY CIRCUIT

1. Disconnect the tire pressure receiver harness connector.
2. Check the voltage between the tire pressure receiver harness connector and ground.

Tire pressure receiver		—	Voltage
Connector	Terminal	Ground	7 - 16 V
E53 (Front LH)	1		
E19 (Front RH)			
B43 (Rear LH)			
B251 (Rear RH)			

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace the malfunctioning harness or connector.

3. CHECK TIRE PRESSURE RECEIVER GROUND CIRCUIT

1. Disconnect the low tire pressure warning control unit harness connector.
2. Check the continuity between the low tire pressure warning control unit harness connector and tire pressure receiver harness connector.

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M96	26	E53 (Front LH)	4	Existed
	25	E19 (Front RH)		
	24	B43 (Rear LH)		
	23	B251 (Rear RH)		

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace the malfunctioning harness or connector.

4. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT CIRCUIT

Check the low tire pressure warning control unit circuit. Refer to [WT-32, "Diagnosis Procedure"](#).

C1728 RECEIVER ID

< DTC/CIRCUIT DIAGNOSIS >

Is the low tire pressure warning control unit circuit normal?

- YES >> Replace the tire pressure receiver.
- NO >> Repair or replace error-detected parts.

C1729 VEHICLE SPEED SIG ERR

< DTC/CIRCUIT DIAGNOSIS >

C1729 VEHICLE SPEED SIG ERR

Description

INFOID:000000005549620

Uses CAN communications from the ABS actuator and electric unit (control unit) to receive the vehicle speed signal, and activates the Tire Pressure Monitoring System (TPMS) when the vehicle speed is 40 km/h (25MPH) or more.

DTC Logic

INFOID:000000005549621

DTC logic

DTC	Display Item	Malfunction detected condition	Possible causes
C1729	VHCL SPEED SIG ERR	Speed signal is not detected.	<ul style="list-style-type: none">CAN communication malfunctionLow tire pressure warning control unit malfunctionABS actuator and electric unit (control unit) malfunction

DTC REPRODUCTION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

- Drive for several minutes at a speed of 40 km/h (25MPH) or more, then stop the vehicle.
- Perform "AIR PRESSURE MONITOR self-diagnosis".

Is DTC "C1729" detected?

- YES >> Perform trouble diagnosis. Refer to [WT-29. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000005549622

1. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

Ⓜ With CONSULT-III

Perform "ABS" self-diagnosis.

Is DTC detected?

- YES >> Check malfunctioning circuit.
NO >> GO TO 2.

2. PERFORM THE SELF-DIAGNOSIS

Ⓜ With CONSULT-III

Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "C1729" detected?

- YES >> Replace the low tire pressure warning control unit.
NO >> GO TO 3.

3. CHECK INFORMATION

Ⓜ With CONSULT-III

Select "DATA MONITOR" of "AIR PRESSURE MONITOR" and check the input/output values. Refer to [WT-45. "Reference Value"](#).

Is the inspection result normal?

- YES >> Check pin terminal and connection of each harness connector for malfunctioning conditions.
NO >> Replace the low tire pressure warning control unit.

C1750, C1751, C1752, C1753 RECEIVER


< DTC/CIRCUIT DIAGNOSIS >

C1750, C1751, C1752, C1753 RECEIVER

Description

INFOID:000000005549623

The front (A) tire pressure receiver (1) and rear (B) tire pressure receiver (2) receive the tire pressure signal by radio waves from the transmitter at each wheel, and transmit the tire pressure signal to the low tire pressure warning control unit.



DTC Logic

INFOID:000000005549624

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1750	[RECEIVER ERR] FL	The front LH tire pressure receiver dose not receive a signal.	Tire pressure receiver malfunction
C1751	[RECEIVER ERR] FR	The front RH tire pressure receiver dose not receive a signal.	
C1752	[RECEIVER ERR] RR	The rear RH tire pressure receiver dose not receive a signal.	
C1753	[RECEIVER ERR] RL	The rear LH tire pressure receiver dose not receive a signal.	

DTC REPRODUCTION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "C1750", "C1751", "C1752", or "C1753" detected?

- YES >> Perform trouble diagnosis. Refer to [WT-30, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000005549625

1. CHECK TIRE PRESSURE RECEIVER INPUT SIGNAL

1. Turn the ignition switch ON.


CAUTION:
Never start engine.

C1750, C1751, C1752, C1753 RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

- Use an oscilloscope and check the input signal waveform between the low tire pressure warning control unit harness connector terminals and ground. Refer to [WT-45, "Reference Value"](#).

Connector	Terminal	—	Standard
M96	3	Ground	Stand by status (Approx. 4.5 V)
	4		
	5		
	6		



Is the inspection result normal?

- YES >> INSPECTION END
 NO >> GO TO 2.

2. CHECK TIRE PRESSURE RECEIVER POWER SUPPLY CIRCUIT

- Disconnect the tire pressure receiver harness connector.
- Check the voltage between the tire pressure receiver harness connector and ground.

Connector	Terminal	—	Voltage
E53 (Front LH)	1	Ground	7 - 16 V
E19 (Front RH)			
B43 (Rear LH)			
B251 (Rear RH)			

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace error-detected part.

3. CHECK TIRE PRESSURE RECEIVER GROUND CIRCUIT

- Disconnect the low tire pressure warning control unit harness connector and tire pressure receiver harness connector.
- Check the continuity between the low tire pressure warning control unit harness connector and tire pressure receiver harness connector.

Low tire pressure warning control unit	Tire pressure receiver		Continuity
M96	26	E53 (Front LH)	Existed
	25	E19 (Front RH)	
	24	B43 (Rear LH)	
	23	B251 (Rear RH)	

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace error-detected part.

4. CHECK FOR CHANGE TO THE TIRE PRESSURE RECEIVER INSTALLATION POSITION. (EXAMPLE: FRONT LH RECEIVER OK/NG JUDGMENT)

☑ With CONSULT-III

- Exchange the front LH tire pressure receiver with the front RH tire pressure receivers.
- Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "C1751" detected?

- YES >> Replace the front RH tire pressure receiver.
 NO >> Perform trouble diagnosis of the low tire pressure warning control unit. Refer to [WT-32, "Diagnosis Procedure"](#).

C1754 LOW TIRE PRESSURE WARNING CONTROL UNIT


< DTC/CIRCUIT DIAGNOSIS >

C1754 LOW TIRE PRESSURE WARNING CONTROL UNIT

Description

INFOID:000000005549626

- After the low tire pressure warning control unit (1) receives the tire pressure signal from the tire pressure receiver, it controls the operation of the low tire pressure warning lamp and buzzer.
- Performs self-diagnosis of the Tire Pressure Monitoring System (TPMS).



DTC Logic

INFOID:000000005549627

DTC logic

DTC	Display Item	Malfunction detected condition	Possible causes
C1754	CONT UNIT (EEPROM)	Tire Pressure Monitoring System (TPMS) malfunction in the low tire pressure warning control unit	Low tire pressure warning control unit malfunction

DTC REPRODUCTION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

④ With CONSULT-III

1. Drive for several minutes at a speed of 40 km/h (25 MPH) or more, then stop the vehicle.
2. Stop the vehicle and perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "C1754" detected?

- YES >> Perform trouble diagnosis. Refer to [WT-32, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000005549628

1. CHECK POWER VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the low tire pressure warning control unit harness connector.
3. Check the voltage between the harness connectors of the low tire pressure warning control unit and the ground.

Low tire pressure warning control unit		—	Voltage
Connector	Terminal		
M96	15	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> If the results of any of the following check items are not normal, repair or replace the malfunctioning part.
- 10 A fuse [No. 3 in fuse block (J/B)]
 - Harness open circuit or short circuit between the ignition switch and harness connector terminal 15 of the low tire pressure warning control unit.
 - Check battery voltage.

2. CHECK GROUND CIRCUIT

Check the continuity between the low tire pressure warning control unit harness connector and ground.

C1754 LOW TIRE PRESSURE WARNING CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	32	Ground	Existed

Are the check results normal?

YES >> GO TO 3.

NO >> If an open circuit or other damage is detected, malfunctioning part.

3. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT AND TIRE PRESSURE RECEIVER CIRCUIT

1. Check the continuity between the low tire pressure warning control unit harness connector and tire pressure receiver harness connector.

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M96	6	E53 (Front LH)	3	Existed
	22		2	
	10		1	
	26		4	
	5	E19 (Front RH)	3	
	21		2	
	9		1	
	25		4	
	4	B43 (Rear LH)	3	
	20		2	
	8		1	
	24		4	
	3	B251 (Rear RH)	3	
	19		2	
	7		1	
	23		4	

2. Check the continuity between the low tire pressure warning control unit harness connector and ground.

C1754 LOW TIRE PRESSURE WARNING CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	6	Ground	Not existed
	22		
	10		
	26		
	5		
	21		
	9		
	25		
	4		
	20		
	8		
	24		
	3		
	19		
	7		
23			

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4.PERFORM THE SELF-DIAGNOSIS

④ With CONSULT-III

1. Perform transmitter ID registration for all wheels. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).
2. Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "C1754" detected?

YES >> Replace the low tire pressure warning control unit.

NO >> Check for looseness or damage at the harness connector pins of the low tire pressure warning control unit. Repair or replace if necessary.

Special Repair Requirement

INFOID:00000000549629

1.CHECK TIRE PRESSURE

Check the tire pressure of all wheels. Refer to [WT-80, "Tire Air Pressure"](#).

Does the tire pressure match the specified value?

YES >> GO TO 2.

NO >> Check the road wheels and tires. Adjust the tire pressures to the specified values.

2.REGISTER TRANSMITTER ID

Perform transmitter ID registration. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).

>> END

C1755, C1756, C1757, C1758 POOR RECEIVING CONDITIONS

< DTC/CIRCUIT DIAGNOSIS >

C1755, C1756, C1757, C1758 POOR RECEIVING CONDITIONS

Description

INFOID:000000005549630

A DTC is detected if the radio signal output from the transmitter is interrupted by external electromagnetic interference for 10 minutes or more.

DTC Logic

INFOID:000000005549631

DTC logic

DTC	Display Item	Malfunction detected condition	Possible causes
C1755	PR RECEIV COND FL	The data signal from the front LH wheel transmitter cannot be detected due to external electromagnetic interference. (DTC C1708 is displayed at the same time.)	External electromagnetic interference
C1756	PR RECEIV COND FR	The data signal from the front RH wheel transmitter cannot be detected due to external electromagnetic interference. (DTC C1709 is displayed at the same time.)	
C1757	PR RECEIV COND RR	The data signal from the rear RH wheel transmitter cannot be detected due to external electromagnetic interference. (DTC C1710 is displayed at the same time.)	
C1758	PR RECEIV COND RL	The data signal from the rear LH wheel transmitter cannot be detected due to external electromagnetic interference. (DTC C1711 is displayed at the same time.)	

CAUTION:

If DTC C1755, C1756, C1757, or C1758 (low communication performance) is detected along with, C1708, C1709, C1710, or C1711 (no transmitter data) first diagnose C1755, C1756, C1757, or C1758 (low communications performance).

DTC REPRODUCTION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "C1755", "C1756", "C1757", or "C1758" detected?

- YES >> Perform trouble diagnosis. Refer to [WT-35, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000005549632

1. REGISTER THE TRANSMITTER ID

Perform transmitter ID registration for all wheels. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).

Is ID registration for all wheels completed?

- YES >> GO TO 2.
NO >> Change the work location and perform ID registration again, then perform trouble diagnosis. Refer to [WT-66, "Diagnosis Procedure"](#).

2. CHECK TIRE PRESSURE SIGNAL

Ⓜ With CONSULT-III

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Within 5 minutes, select "DATA MONITOR" of "AIR PRESSURE MONITOR".
3. Display the following: "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR", and "AIR PRESS RL".
4. Check that the displayed tire pressures is the specified value.

C1755, C1756, C1757, C1758 POOR RECEIVING CONDITIONS

< DTC/CIRCUIT DIAGNOSIS >

Monitor item	Condition	Displayed value
AIR PRESS FL	Drive for 3 minutes at a speed of 40 km/h (25MPH) or more, then drive normally for 10 minutes.	Air pressure of tire pressure
AIR PRESS FR		
AIR PRESS RR		
AIR PRESS RL		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Change the work location, then GO TO 1.

3.CHECK THE DIAGNOSIS RESULTS

Ⓜ With CONSULT-III

1. Erase the self-diagnosis memory of the low tire pressure warning control unit.
2. Turn ignition switch OFF, and wait for 10 seconds or more.
3. Perform "AIR PRESSURE MONITOR" self-diagnosis.

Are DTC "C1755", "C1756", "C1757", or "C1758" and "C1708", "C1709", "C1710", or "C1711" detected?

YES >> Change the work location, then GO TO 1.

NO >> GO TO 4.

4.CHECK TIRE PRESSURE SIGNAL

Ⓜ With CONSULT-III

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Within 5 minutes, select "DATA MONITOR" of "AIR PRESSURE MONITOR".
3. Display the following: "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR", and "AIR PRESS RL".
4. Check that the tire pressures is the specified value.

Monitor item	Condition	Displayed value
AIR PRESS FL	Drive for 3 minutes at a speed of 40 km/h (25MPH) or more, then drive normally for 10 minutes.	Air pressure of tire pressure
AIR PRESS FR		
AIR PRESS RR		
AIR PRESS RL		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Change the work location, then GO TO 1.

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

U1000 CAN COMM CIRCUIT

Description

INFOID:000000005549633

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicates data but selectively reads required data only.

DTC Logic

INFOID:000000005549634

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	Low tire pressure warning control unit is not communicating CAN communication signal for 2 seconds or more.	<ul style="list-style-type: none">• CAN communication malfunction• Malfunction of low tire pressure warning control unit

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓜ With CONSULT-III

1. Turn the ignition switch OFF to ON.
2. Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "U1000" detected?

- YES >> Proceed to trouble diagnosis procedure. Refer to [WT-37, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000005549635

1. PERFORM SELF-DIAGNOSIS

Ⓜ With CONSULT-III

Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "U1000" detected?

- YES >> CAN specification chart. Refer to [LAN-29, "CAN System Specification Chart"](#).
NO >> INSPECTION END

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000005549636

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicates data but selectively reads required data only.

DTC Logic

INFOID:000000005549637

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1010	CONTROL UNIT (CAN)	Detecting error during the initial diagnosis of CAN controller of low tire pressure warning control unit.	Malfunction of low tire pressure warning control unit

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

Ⓔ With CONSULT-III

1. Turn the ignition switch OFF to ON.
2. Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "U1010" detected?

- YES >> Proceed to trouble diagnosis procedure. Refer to [WT-38. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000005549638

1. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT

Check low tire pressure warning control unit harness connector for disconnection or deformation.

Is the inspection result normal?

- YES >> Replace low tire pressure warning control unit. Refer to [WT-76. "Exploded View"](#).
NO >> Repair or replace error-detected parts.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

Description

INFOID:000000005549639

Supply power to the low tire pressure warning control unit.

Component Function Check

INFOID:000000005549640

1.CHECK THE ILLUMINATION OF THE TIRE PRESSURE WARNING LAMP

Check that the low tire pressure warning lamp is turned OFF after illuminating for approximately 1 second, when the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Perform trouble diagnosis. Refer to [WT-39. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005549641

1.CHECK FUSE/FUSIBLE LINK

Check for fusing of the fuse and fusible link at the low tire pressure warning control unit.

- Check the 10 A fuse [No. 3 inside the fuse block (J/B)]

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

2.POWER SUPPLY SYSTEM CHECK

1. Turn the ignition switch OFF.
2. Disconnect the low tire pressure warning control unit harness connector.
3. Turn the ignition switch ON.

CAUTION:

Never start engine.

4. Check the continuity between the low tire pressure warning control unit harness connector and the ground.

Low tire pressure warning control unit		—	Voltage
Connector	Terminal		
M96	15	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3.GROUND SYSTEM INSPECTION

1. Turn the ignition switch OFF.
2. Check the continuity between the low tire pressure warning control unit harness connector and the ground.

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	32	Ground	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

4.CHECK TIRE PRESSURE RECEIVER POWER SUPPLY CIRCUIT

1. Connect the low tire pressure warning control unit harness connector.
2. Disconnect the tire pressure receiver harness connector.
3. Check the voltage between the tire pressure receiver harness connector and ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WT

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Tire pressure receiver		—	Voltage
Connector	Terminal		
E53 (Front LH)	1	Ground	7 - 16 V
E19 (Front RH)			
B43 (Rear LH)			
B251 (Rear RH)			

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

5. CHECK RECEIVER GROUND CIRCUIT

1. Disconnect the low tire pressure warning control unit harness connector.
2. Check the continuity between the harness connector terminals of the receiver and the low tire pressure warning control unit.

Tire pressure receiver		Low tire pressure warning control unit		Continuity
Connector	Terminal	Connector	Terminal	
E53 (Front LH)	4	M96	26	Existed
E19 (Front RH)			25	
B43 (Rear LH)			24	
B251 (Rear RH)			23	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

TIRE PRESSURE WARNING CHECK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

TIRE PRESSURE WARNING CHECK SWITCH

Description

INFOID:000000005549642

The following item can be checked by grounding the tire pressure warning check switch harness connector terminal.

Component Function Check

INFOID:000000005549643

1. CHECK LOW TIRE PRESSURE WARNING LAMP OPERATION

Check if low tire pressure warning lamp blinks 1 second and then goes off after turning ignition switch ON.

Is inspection result normal?

YES >> GO TO 2.

NO >> Check low tire pressure warning lamp. Refer to [WT-43. "Diagnosis Procedure"](#).

2. CHECK TIRE PRESSURE WARNING CHECK SWITCH OPERATION

1. Ground the tire pressure warning check switch harness connector terminal.
2. Check the low tire pressure warning lamp blinks.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to trouble diagnosis procedure. Refer to [WT-41. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005549644

1. CHECK TIRE PRESSURE WARNING CHECK SWITCH POWER SUPPLY CIRCUIT

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check the voltage between tire pressure warning check switch connector and ground.

Tire pressure warning check switch		—	Voltage
Connector	Terminal		
M23	1	Ground	7.6 - 14.6 V

Is the inspection result normal?

YES >> Repair or replace low tire pressure warning control unit. Replace low tire pressure warning control unit. Refer to [WT-76. "Exploded View"](#).

NO >> GO TO 2.

2. CHECK TIRE PRESSURE WARNING CHECK SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect low tire pressure warning control unit harness connector
3. Check the continuity between low tire pressure warning control unit harness connector and tire pressure warning check switch connector.

Low tire pressure warning control unit		Tire pressure warning check switch		Continuity
Connector	Terminal	Connector	Terminal	
M96	12	M23	1	Existed

4. Check the continuity between low tire pressure warning control unit harness connector and ground.

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	12	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

TIRE PRESSURE WARNING CHECK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT

Check the low tire pressure warning control unit input/output signal. Refer to [WT-45, "Reference Value"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check low tire pressure warning control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace damaged parts. Replace low tire pressure warning control unit. Refer to [WT-76, "Exploded View"](#).

LOW TIRE PRESSURE WARNING LAMP


< DTC/CIRCUIT DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP

Description

INFOID:000000005549645

Uses CAN communication from the low tire pressure warning control unit to illuminate the low tire pressure warning lamp on the combination meter.



Condition	Low tire pressure warning lamp
Ignition switch OFF.	OFF
Ignition switch ON.	Illuminates for 1 second, then turns OFF.
When tire pressure is low [Tire pressure is 182 kPa (1.86 kg/cm ² , 26.4 psi)* or less	ON
Tire Pressure Monitoring System (TPMS) error	Flashes for 1 minute, then stays illuminated.

*: Tire pressure at each condition differs.

Component Function Check

INFOID:000000005549646

1. CHECK THE ILLUMINATION OF THE LOW TIRE PRESSURE WARNING LAMP

Check that the low pressure warning lamp is turned OFF after illuminating for approximately 1 second, when the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Perform trouble diagnosis. Refer to [WT-43, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000005549647

1. POWER SUPPLY AND GROUND CIRCUIT

Check power supply and ground circuit. Refer to [WT-39, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

2. PERFORM THE SELF-DIAGNOSIS

Ⓜ With CONSULT-III

Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is DTC "U1000" detected?

YES >> Perform trouble diagnosis for CAN communication system. Refer to [WT-37, "Diagnosis Procedure"](#).

NO >> GO TO 3.

3. CHECK LOW TIRE PRESSURE WARNING LAMP SIGNAL

Ⓜ With CONSULT-III

1. Turn the ignition switch ON.

CAUTION:

Never start engine.

2. Select "DATA MONITOR" of "AIR PRESSURE MONITOR".

LOW TIRE PRESSURE WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

3. Read out the value of "WARNING LAMP".

Does the data monitor display change from ON to OFF?

YES >> GO TO 4.

NO >> Replace the low tire pressure warning control unit. Refer to [WT-76. "Exploded View"](#).

4.CHECK COMBINATION METER POWER SUPPLY CIRCUIT

Perform trouble diagnosis of the combination meter power supply circuit.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

TPMS CONTROL UNIT

Reference Value

INFOID:000000005243114


VALUES ON THE DIAGNOSIS TOOL

CAUTION:

The reference values in the table below come from the control unit calculation data. The normal values may in some cases be displayed even though the power circuit (harness) is open or shorted.

Monitor item	Data monitor	
	Condition	Reference values for normal operation
VHCL SPEED SE	Drive the vehicle.	Vehicle speed (km/h) or (MPH)
AIR PRESS FL	Start the engine and drive at a speed of 40 km/h (25 MPH) or more for 10 minutes.	Tire pressure (kg/cm ²), (kPa) or (Psi)
AIR PRESS FR		
AIR PRESS RR		
AIR PRESS RL		
ID REGST FL1	Ignition switch ON	ID registered: Done ID not registered: Yet
ID REGST FR1		
ID REGST RR1		
ID REGST RL1		
WARNING LAMP		Low tire pressure warning lamp ON: On Low tire pressure warning lamp OFF: Off
BUZZER	Combination meter buzzer ON: On Combination meter buzzer OFF: Off	

TERMINAL LAYOUT




PHYSICAL VALUES

Terminal No. (Wire color)	Description		Condition	Value (Approx.)
	Signal name	Input/ Output		
1 (P)	CAN-L	—	—	—
2 (L)		—	—	—

TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)		
	Signal name	Input/ Output				
3 (O)	Ground	Tire pressure receiver signal	Input	Ignition switch ON	Stand by status (Approx. 4.5 V)	 <p style="text-align: right; font-size: small;">OCC3879D</p>
4 (L)						
5 (R)					6 (P)	
7 (SB)						Ground
8 (R)						
9 (GR)						
10 (G)						
12 (SB)	Ground	Tire pressure warning check switch	Output	Always	Approx. 7.6 - 14.6 V	
15 (Y)	Ground	Ignition switch	Input	Ignition switch ON	Battery voltage	
19 (W)	Ground	Tire pressure receiver signal (sensitivity)	Input	Ignition switch ON	Approx. 0.7 V	
20 (BR)						
21 (LG)						
22 (V)						
23 (B)	Ground	Tire pressure receiver ground	—	—	0 V	
24 (Y)						
25 (W)						
26 (P)						
30 (LG)	Ground	Hazard lamp	Output	Hazard lamp switch ON	0 V	
				Hazard lamp switch OFF	Battery voltage	
32 (B)	Ground	Ground	—	—	0 V	


TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - TIRE PRESSURE MONITORING SYSTEM -

INFOID:000000005612683

TIRE PRESSURE MONITORING SYSTEM



2009/07/29


JCEWA0156GB

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

PM : With automatic drive positioner
OP : Without automatic drive positioner




JCEWA0157GB

TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

TIRE PRESSURE MONITORING SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	THBDW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	W	-
5	G	-
6	G	-
7	P	-
8	O	-
9	W	-
10	SB	-
11	SB	-
12	B	-
13	G	-
14	R	-
15	W	-
16	SHIELD	-
17	L	-
18	P	-
19	G	-
20	Y	-
21	W	-
23	V	-
24	P	-
25	BR	-
26	GR	-
27	O	-
28	W	-
29	SHIELD	-
38	B	-
39	B	-
40	LG	-
41	G	-
42	GR	-
43	SB	-
44	V	-
45	GR	-
50	B	-
51	V	-
32	SB	-

53	SHIELD	-
54	BR	-
55	Y	-
56	SHIELD	-
57	P	-
58	L	-
59	SHIELD	-
60	L	-
61	P	-
62	GR	-
63	G	-
64	O	-
65	W	-
66	V	-
67	LG	-
68	Y	-
69	G	-
70	GR	-
71	G	-
72	B	-
73	W	-
74	V	-
75	O	-
76	LG	-
77	L	-
78	GR	-
79	W	-
80	L	-
81	P	-
82	L	-
83	P	-
84	SB	-
85	R	-
86	Y	-
87	B	-
88	G	-
89	BR	-
90	W	-
91	R	-
92	O	-
93	BR	-
94	V	-
95	Y	-
96	O	-
97	W	-
98	GR	-
99	W	-

Connector No.	B43
Connector Name	TIRE PRESSURE RECEIVER REAR LH
Connector Type	RN04FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	VCC
2	P	RSSI
3	L	SIG
4	G	GND

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

TIRE PRESSURE MONITORING SYSTEM

Connector No.	E201
Connector Name	WIRE TO WIRE
Connector Type	TH80PW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	R	-
3	BR	-
4	SB	-
6	O	-
7	GR	-
8	W	-
10	G	-
11	BR	-
12	Y	-
13	SHIELD	-
14	G	-
15	R	-
16	SHIELD	-
17	LG	-
18	GR	-
19	V	-
20	SB	-
21	LG	-
22	B	- [With entertainment system] - [Without entertainment system]
23	GR	- [With entertainment system] - [Without entertainment system]
24	W	- [With entertainment system] - [Without entertainment system]
25	SHIELD	- [With entertainment system] - [Without entertainment system]
26	V	- [With entertainment system] - [Without entertainment system]
27	V	-
28	SHIELD	-
29	O	-
30	P	-
31	W	-
32	GR	-
33	SB	-
34	LG	-
40	V	- [With ICC] - [Without ICC]
41	SB	- [With ICC]

41	Y	- [Without ICC] - [With ICC]
42	W	- [Without ICC] - [With ICC]
43	BR	- [Without ICC] - [With ICC]
44	R	- [Without ICC] - [With ICC]
45	G	- [Without ICC] - [With ICC]
46	O	- [Without ICC] - [With ICC]
47	L	- [Without ICC] - [With ICC]
48	P	- [Without ICC] - [With ICC]
49	G	- [Without ICC] - [With ICC]
50	SHIELD	- [Without ICC] - [With ICC]
51	W	- [Without ICC] - [With ICC]
52	R	- [Without ICC] - [With ICC]
53	G	- [Without ICC] - [With ICC]
54	L	- [Without ICC] - [With ICC]
55	SB	- [Without ICC] - [With ICC]
60	GR	- [Without ICC] - [With ICC]
61	LG	- [Without ICC] - [With ICC]
62	SB	- [Without ICC] - [With ICC]
63	P	- [Without ICC] - [With ICC]
64	BR	- [Without ICC] - [With ICC]
65	O	- [Without ICC] - [With ICC]
66	Y	- [Without ICC] - [With ICC]
67	W	- [Without ICC] - [With ICC]
68	SHIELD	- [Without ICC] - [With ICC]
69	G	- [Without ICC] - [With ICC]
71	SB	- [Without ICC] - [With ICC]
72	V	- [Without ICC] - [With ICC]
73	LG	- [Without ICC] - [With ICC]
74	W	- [Without ICC] - [With ICC]
75	BR	- [Without ICC] - [With ICC]
76	V	- [Without ICC] - [With ICC]
77	LG	- [Without ICC] - [With ICC]
80	O	- [Without ICC] - [With ICC]
81	G	- [Without ICC] - [With ICC]
82	P	- [Without ICC] - [With ICC]
83	Y	- [Without ICC] - [With ICC]
84	R	- [Without ICC] - [With ICC]
85	SB	- [Without ICC] - [With ICC]
86	GR	- [Without ICC] - [With ICC]
87	L	- [Without ICC] - [With ICC]
91	V	- [Without ICC] - [With ICC]
92	W	- [Without ICC] - [With ICC]
93	R	- [Without ICC] - [With ICC]
94	LG	- [Without ICC] - [With ICC]
95	GR	- [Without ICC] - [With ICC]
96	W	- [Without ICC] - [With ICC]


97	G	-
98	O	-
99	L	-
100	Y	-

Connector No.	E251
Connector Name	TIRE PRESSURE RECEIVER REAR RH
Connector Type	FRH4FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	VCC
2	R	RSSI
3	Y	SIG
4	GR	GND

Connector No.	E19
Connector Name	TIRE PRESSURE RECEIVER FRONT RH
Connector Type	FRH4FB



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	VCC
2	G	RSSI
3	R	SIG
4	W	GND

Connector No.	E41
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	BAA42FB-AH2A-LH



Terminal No.	Color of Wire	Signal Name [Specification]
1	B	GND
2	G	UBMR
3	R	UBVR
4	B	GND
5	Y	DS FL
6	O	DP RL
7	BR	DP RR
9	B	DP FR
10	W	DS FR
12	L	VAC
14	P	CAN-L
15	SHIELD	AGND
19	P	LIST
25	Y	BUS-L
26	R	DP FL
27	GR	DS RL
28	G	UZ
29	LG	DS RR
30	SB	BLS
31	R	VDC OFF SW
35	L	CAN-H
45	B	BUS-H

TPMS CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WT


TIRE PRESSURE MONITORING SYSTEM

Connector No.	E53
Connector Name	TIRE PRESSURE RECEIVER FRONT LH
Connector Type	RHDMFB



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	VCC
2	O	RSSI
3	W	SIG
4	BR	GND

Connector No.	E108
Connector Name	WIRE TO WIRE
Connector Type	TH8DFW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	O	-
3	SB	-
4	LG	-
5	Y	-
6	W	-
7	G	-
8	V	-
9	R	-
10	BR	-
11	B	-
12	G	-
13	R	-
14	W	-
15	SHIELD	-
16	SB	-
17	L	-
18	P	-

19	G	-
20	W	- [With ICC] - [Without ICC]
21	BR	- [With ICC] - [Without ICC]
22	V	- [With ICC] - [Without ICC]
23	G	-
24	L	- [With ICC] - [Without ICC]
25	Y	- [With ICC] - [Without ICC]
26	SHIELD	-
28	G	-
29	LG	-
30	O	-
31	BR	-
32	W	-
33	Y	-
34	O	-
35	SB	-
36	P	-
37	Y	-
38	GR	-
39	LG	-
41	LG	-
42	V	-
43	R	-
44	G	-
45	GR	-
46	W	-
47	L	-
48	P	-
49	SB	-
50	BR	-
51	B	-
52	Y	-
53	O	-
54	R	-
55	SB	-
56	P	-
59	P	-
60	SB	-
61	V	-
62	P	-
63	LG	-
64	L	-
65	O	-
66	L	-
68	L	-
70	SHIELD	-
71	G	-
72	G	-

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS36FW-M2




Terminal No.	Color of Wire	Signal Name [Specification]
1A	O	-
2A	G	-
3A	L	-
4A	P	-
5A	V	-
6A	Y	-
7A	R	-
8A	L	-

TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

TIRE PRESSURE MONITORING SYSTEM

Connector No.	M16
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



94	L	-
95	G	-
96	W	-
100	Y	-

35	L	-
36	P	-
37	G	-
38	R	-
39	G	-
41	L	-
42	W	-
43	R	-
44	LG	-
45	GR	-
46	W	-
47	L	-
48	P	-
49	O	-
50	LG	-
51	SB	-
52	Y	-
53	O	-
54	BR	-
55	SB	-
56	P	-
59	SB	-
60	SB	-
61	V	-
62	P	-
63	R	-
64	L	-
65	O	-
66	L	-
68	V	-
70	SHIELD	-
71	O	-
72	GR	-
73	W	-
74	SB	-
76	V	-
77	V	-
78	Y	-
80	O	-
81	L	-
82	W	-
83	Y	-
84	L	-
85	P	-
86	BR	-
87	P	-
88	V	-
89	G	-
90	P	-
91	R	-
92	R	-
93	GR	-

Terminal No.	Color of Wire	Signal Name (Specification)
1	G	-
2	O	-
3	SB	-
4	LG	-
5	GR	-
6	W	-
7	G	-
8	W	-
9	P	-
10	BR	-
11	B	-
12	G	-
13	R	-
14	W	-
15	SHIELD	-
16	BR	-
17	L	-
18	P	-
19	G	-
20	W	- [With ICC]
20	GR	- [Without ICC]
21	BR	- [With ICC]
21	R	- [Without ICC]
22	R	- [With ICC]
22	L	- [Without ICC]
23	G	-
24	L	- [With ICC]
24	P	- [Without ICC]
25	Y	- [With ICC]
25	W	- [Without ICC]
26	SHIELD	-
28	GR	-
29	V	-
30	O	-
31	BR	-
32	W	-
33	Y	-
34	L	-


JCEWA0161GB

TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

TIRE PRESSURE MONITORING SYSTEM

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	W	-
5	G	-
6	P	-
7	V	-
8	O	-
9	W	-
10	W	-
11	O	-
12	B	-
13	G	-
14	R	-
15	W	-
16	SHIELD	-
17	L	-
18	P	-
19	G	-
20	R	-
21	LG	-
23	V	-
24	P	-
25	BR	-
26	GR	-
27	O	-
28	W	-
29	SHIELD	-
38	B	-
39	B	-
40	LG	-
41	G	-
42	Y	-
43	SB	-
44	W	-
45	B	-
50	B	-
51	V	-
52	LG	-

53	SHIELD	-
54	BR	-
55	Y	-
56	SHIELD	-
57	P	-
58	L	-
59	SHIELD	-
60	L	-
61	BR	-
62	R	-
63	Y	-
64	L	-
65	W	-
66	V	-
67	LG	-
68	Y	-
69	G	-
70	V	-
71	W	-
72	B	-
73	W	-
74	LG	-
75	P	-
76	LG	-
77	SR	-
78	GR	-
79	R	-
80	L	-
81	P	-
82	L	-
83	P	-
84	SB	-
85	W	-
86	Y	-
87	B	-
88	G	-
89	O	-
90	W	-
91	R	-
92	O	-
93	BR	-
94	V	-
95	Y	-
96	O	-
97	W	-
98	R	-
99	G	-
99	O	-

- [With VK engine]
- [With VG engine]

Connector No.	M23
Connector Name	TIRE PRESSURE WARNING CHECK SWITCH
Connector Type	TK02PW



Terminal No.	Color of Wire	Signal Name [Specification]
1	SB	-

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	O	BATTERY POWER SUPPLY
2	LG	COMMUNICATION SIGNAL (METER->AMP)
3	GR	COMMUNICATION SIGNAL (AMP->METER)
5	B	GROUND
6	W	ALTERNATOR SIGNAL
7	P	AIR BAG SIGNAL
10	G	SECURITY INDICATOR SIGNAL
15	B	GROUND
16	B	METER CONTROL SWITCH GROUND
21	R	IGNITION POWER SUPPLY
22	B	GROUND
24	BR	COMMUNICATION SIGNAL (LCD->AMP)
25	Y	COMMUNICATION SIGNAL (AMP->LCD)
26	R	VEHICLE SPEED SIGNAL (6-PULSE)
27	V	PARKING BRAKE SWITCH SIGNAL
28	W	BRAKE FLUID LEVEL SWITCH SIGNAL
29	SB	SEAT BELT BUCKLE SW (DRIVER SIDE)
30	G	PASSENGER SEAT BELT WARNING SIGNAL
31	L	WASHER LEVEL SWITCH SIGNAL
34	O	ILL. COR. OUT
36	LG	SELECT SWITCH SIGNAL

37	SB	ENTER SWITCH SIGNAL
38	L	TRIP A/B RESET SWITCH SIGNAL
39	P	ILLUMINATION CONTROL SWITCH SIGNAL (-)
40	O	ILLUMINATION CONTROL SWITCH SIGNAL (+)

Connector No.	M66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
4	P	STOP LAMP SWITCH SIGNAL
5	L	MANUAL MODE SHIFT UP SIGNAL
6	O	PADDLE SHIFTER UP SIGNAL
7	GR	COMMUNICATION SIGNAL (AMP->METER)
8	L	VEHICLE SPEED SIGNAL (6-PULSE)
9	SB	FRONT SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
10	W	MANUAL MODE SIGNAL
11	G	NON-MANUAL MODE SIGNAL
14	BR	COMMUNICATION SIGNAL (LCD->AMP)
20	L	ION SENSOR SIGNAL
23	Y	AT SNOW SWITCH SIGNAL
25	V	MANUAL MODE SHIFT DOWN SIGNAL
26	G	PADDLE SHIFTER DOWN SIGNAL
27	LG	COMMUNICATION SIGNAL (METER->AMP)
28	R	VEHICLE SPEED SIGNAL (6-PULSE)
30	V	PARKING BRAKE SWITCH SIGNAL
34	Y	COMMUNICATION SIGNAL (AMP->LCD)
38	L	BLOWER MOTOR CONTROL SIGNAL

A B C D E F G H I J K L M N O P

WT

TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

TIRE PRESSURE MONITORING SYSTEM

Connector No.	M67
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH32FW-NH



41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
41	V	ACC POWER SUPPLY
42	Y	FUEL LEVEL SENSOR SIGNAL
43	R	INTAKE SENSOR SIGNAL
44	LG	IN-VEHICLE SENSOR SIGNAL
45	P	AMBIENT SENSOR SIGNAL
46	O	SUNLOAD SENSOR SIGNAL
47	V	GAS SENSOR SIGNAL
53	G	IGNITION POWER SUPPLY
54	O	BATTERY POWER SUPPLY
55	B	GROUND
56	L	CAN-H
57	W	BRAKE FLUID LEVEL SWITCH SIGNAL
58	B	FUEL LEVEL SENSOR GROUND
59	GR	INTAKE SENSOR GROUND
60	L	IN-VEHICLE SENSOR GROUND
61	BR	AMBIENT SENSOR GROUND
62	SB	SUNLOAD SENSOR GROUND
63	R	ION MODE SIGNAL
65	O	ECV SIGNAL
69	L	A/C LAN SIGNAL
70	R	EACH DOOR MOTOR POWER SUPPLY
71	B	GROUND
72	P	CAN-L

Connector No.	M66
Connector Name	LOW TIRE PRESSURE WARNING CONTROL UNIT
Connector Type	TH32FW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
1	P	CAN-(L)
2	L	CAN-(H)
3	O	RR TUNER (SSG)
4	L	RL TUNER (SSG)
5	R	FR TUNER (SSG)
6	P	FL TUNER (SSG)
7	SB	RR TUNER (VCC)
8	R	RL TUNER (VCC)
9	GR	FR TUNER (VCC)
10	G	FL TUNER (VCC)
12	SB	SW
15	Y	IGN
19	W	RR TUNER (RSSJ)
20	BR	FR TUNER (RSSJ)
21	LG	RL TUNER (RSSJ)
22	V	FL TUNER (RSSJ)
23	B	RR TUNER (GND)
24	Y	RL TUNER (GND)
25	W	FR TUNER (GND)
26	P	FL TUNER (GND)
30	LG	BCM FLASHER
32	B	GROUND

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TH60MW-CS1E-TM4



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	
2	BR	
3	V	
4	SB	
6	Y	
7	B	
8	W	
10	W	
11	BR	
12	GR	
13	SHIELD	
14	L	

Terminal No.	Color of Wire	Signal Name [Specification]
15	P	
16	SHIELD	
17	Y	
18	Y	
19	LG	
20	SB	
21	LG	
22	B	
23	GR	
24	W	
25	V	
26	R	
27	W	
28	SHIELD	
29	O	
30	P	
31	W	
32	W	
33	SB	
40	V	
41	SB	
42	Y	
43	W	
44	P	
45	B	
46	R	
47	L	
48	P	
49	G	
50	SHIELD	
51	O	
52	GR	
53	G	
54	L	
55	P	
60	LG	
61	R	
62	SB	
63	V	
64	Y	

Terminal No.	Color of Wire	Signal Name [Specification]
65	BR	
66	O	
67	W	
68	SHIELD	
69	LG	
71	SB	
72	V	
73	V	
74	LG	
75	R	
76	BR	
77	LG	
80	R	
81	L	
82	Y	
83	O	
84	W	
85	SB	
86	B	
87	P	
91	L	
92	L	
93	G	
94	W	
95	V	
96	G	
97	G	
98	L	
99	LG	
100	Y	

Connector No.	M118
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	M03FB-LC



1	2	3
---	---	---


Terminal No.	Color of Wire	Signal Name [Specification]
1	W	BAT (E/L)
2	Y	POWER WINDOW POWER SUPPLY (BAT)
3	O	POWER WINDOW POWER SUPPLY (RAP)

TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


TIRE PRESSURE MONITORING SYSTEM

Connector No.	M119
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	HS18FW-GS



Terminal No.	Color of Wire	Signal Name [Specification]
4	P	INT ROOM LAMP PWR SUPPLY (BAT SAVE)
5	V	PASSENGER DOOR UNLOCK OUTPUT
7	Y	STEP LAMP OUTPUT
8	V	ALL DOOR FUEL LID LOCK OUTPUT
9	G	DRIVER DOOR FUEL LID UNLOCK OUTPUT
10	BR	REAR DOOR UNLOCK OUTPUT
11	R	BAT (FUZE)
13	B	GND
15	Y	ACC IND
17	W	TURN SIGNAL RH (FRONT)
18	O	TURN SIGNAL LH (FRONT)
19	SB	ROOM LAMP TIMER


Connector No.	M122
Connector Name	PCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color of Wire	Signal Name [Specification]
72	R	ROOM ANT2-
73	G	ROOM ANT2+
74	SB	PASSENGER DOOR ANT-
75	BR	PASSENGER DOOR ANT+
76	V	DRIVER DOOR ANT-
77	LG	DRIVER DOOR ANT+
78	Y	ROOM ANT1-
79	BR	ROOM ANT1+
80	GR	NATS ANT AMP
81	W	NATS ANT AMP

Terminal No.	Color of Wire	Signal Name [Specification]
82	P	IGN RELAY (F/B) CONT
83	GR	KEYLESS ENTRY RECEIVER SIGNAL
87	BR	COMBI SW INPUT 5
88	V	COMBI SW INPUT 3
89	SB	PUSH SW
90	P	CAN-L
91	L	CAN-H
92	LG	KEY SLOT ILL
93	V	ON IND
95	O	ACC RELAY CONT
96	GR	A/T SHIFT SELECTOR POWER SUPPLY
97	L	S/L CONDITION 1
98	P	S/L CONDITION 2
99	R	SHIFT P
100	G	PASSENGER DOOR REQUEST SW
101	SB	DRIVER DOOR REQUEST SW
102	O	BLOWER FAN MOTOR RELAY CONT
103	BR	KEYLESS ENTRY RECEIVER POWER SUPPLY
106	W	S/L UNIT POWER SUPPLY
107	LG	COMBI SW INPUT 1
108	R	COMBI SW INPUT 4
109	Y	COMBI SW INPUT 2
110	G	HAZARD SW
111	GR	S/L UNIT COMM


Connector No.	M202
Connector Name	AV CONTROL UNIT
Connector Type	TH24FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
36	O	SIGNAL VCC
37	LG	SIGNAL GND
38	R	HP
39	BR	COMM (DISP->CONT)
40	B	RGB AREA (V/S) SIGNAL
41	SHIELD	SHIELD
42	G	RGB SYNC
43	B	RGB (R/RED) SIGNAL
44	W	RGB (G/GREEN) SIGNAL
45	R	RGB (B/BLUE) SIGNAL
46	V	COMPOSITE IMAGE SIGNAL GND
47	SB	COMPOSITE IMAGE SIGNAL


Terminal No.	Color of Wire	Signal Name [Specification]
48	Y	INVERTER VCC
49	BR	INVERTER GND
50	W	YP
51	Y	COMM (CONT->DISP)
52	SHIELD	SHIELD
57	SHIELD	SHIELD
58	SHIELD	SHIELD

Connector No.	M204
Connector Name	AV CONTROL UNIT
Connector Type	TH42FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
76	LG	AV COMM (L)
77	SR	AV COMM (H)
78	LG	AV COMM (L)
79	SB	AV COMM (H)
80	P	CAN-L
81	L	CAN-H
82	BR	SW GND
86	SHIELD	SHIELD
87	L	TEL VOICE SIGNAL (+)
88	P	TEL VOICE SIGNAL (-)
92	R	VEHICLE SPEED SIGNAL (8-PULSE)
93	V	PARKING BRAKE SIGNAL
94	O	REVERSE SIGNAL
95	G	IGNITION SIGNAL
96	SB	DISK EJECT SIGNAL
102	B	AUX SOUND SIGNAL GND
103	W	AUX SOUND SIGNAL LH (+)
104	R	AUX SOUND SIGNAL RH (+)

Connector No.	M210
Connector Name	AV CONTROL UNIT
Connector Type	TH22FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
64	GR	DRIVER DOOR SW SIGNAL
65	V	PARKING BRAKE SIGNAL
67	B	COMPOSITE IMAGE SIGNAL GND
68	R	COMPOSITE IMAGE SIGNAL
71	SHIELD	MICROPHONE VCC
72	G	MICROPHONE GND
73	R	COMM (CONT->DISP)
74	P	CAN-L
75	LG	AV COMM (L)
76	LG	AV COMM (L)
79	R	ILLUMINATION
80	G	IGNITION SIGNAL
81	O	REVERSE SIGNAL
82	R	VEHICLE SPEED SIGNAL (8-PULSE)
83	SHIELD	SHIELD
84	W	COMPOSITE IMAGE SYNC SIGNAL
87	R	MICROPHONE SIGNAL
88	SHIELD	SHIELD
89	G	COMM (DISP->CONT)
90	L	CAN-H
91	SB	AV COMM (H)
92	SB	AV COMM (H)

DTC Inspection Priority Chart

When multiple DTCs are detected simultaneously, check one by one as per on the following priority list.

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Priority	Detection items
1	<ul style="list-style-type: none"> • U1000 CAN COMM CIRCUIT • U1010 CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> • C1704 LOW PRESSURE FL • C1705 LOW PRESSURE FR • C1706 LOW PRESSURE RR • C1707 LOW PRESSURE RL
3	<ul style="list-style-type: none"> • C1755 PR RECEIV COND FL • C1756 PR RECEIV COND FR • C1757 PR RECEIV COND RR • C1758 PR RECEIV COND RL
4	<ul style="list-style-type: none"> • C1708 [NO DATA] FL • C1709 [NO DATA] FR • C1710 [NO DATA] RR • C1711 [NO DATA] RL
5	<ul style="list-style-type: none"> • C1716 [PRESSDATA ERR] FL • C1717 [PRESSDATA ERR] FR • C1718 [PRESSDATA ERR] RR • C1719 [PRESSDATA ERR] RL
6	<ul style="list-style-type: none"> • C1720 [CODE ERR] FL • C1721 [CODE ERR] FR • C1722 [CODE ERR] RR • C1723 [CODE ERR] RL
7	C1728 RECEIVER ID NO REG
8	C1729 VHCL SPEED SIG ERR
9	<ul style="list-style-type: none"> • C1750 [RECEIVER ERR] FL • C1751 [RECEIVER ERR] FR • C1752 [RECEIVER ERR] RR • C1753 [RECEIVER ERR] RL
10	C1754 CONT UNIT (EEPROM)

DTC Index

INFOID:000000005243117

DTC	Display Item	Reference
C1704	LOW PRESSURE FL	WT-14
C1705	LOW PRESSURE FR	
C1706	LOW PRESSURE RR	
C1707	LOW PRESSURE RL	
C1708	[NO DATA] FL	WT-16
C1709	[NO DATA] FR	
C1710	[NO DATA] RR	
C1711	[NO DATA] RL	
C1716	[PRESSDATA ERR] FL	WT-20
C1717	[PRESSDATA ERR] FR	
C1718	[PRESSDATA ERR] RR	
C1719	[PRESSDATA ERR] RL	
C1720	[CODE ERR] FL	WT-22
C1721	[CODE ERR] FR	
C1722	[CODE ERR] RR	
C1723	[CODE ERR] RL	
C1728	RECEIVER ID NO REG	WT-26

TPMS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

DTC	Display Item	Reference	
C1729	VHCL SPEED SIG ERR	WT-29	A
C1750	[RECEIVER ERR] FL	WT-30	B
C1751	[RECEIVER ERR] FR		
C1752	[RECEIVER ERR] RR		
C1753	[RECEIVER ERR] RL		
C1754	CONT UNIT (EEPROM)	WT-32	C
C1755	PR RECEIV COND FL	WT-35	D
C1756	PR RECEIV COND FR		
C1757	PR RECEIV COND RR		
C1758	PR RECEIV COND RL		
U1000	CAN COMM CIRCUIT	WT-37	WT
U1010	CONTROL UNIT (CAN)	WT-38	

F
G
H
I
J
K
L
M
N
O
P

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

TPMS

Symptom Table

INFOID:000000005549648

LOW TIRE PRESSURE WARNING LAMP SYMPTOM CHART

TPMS

< SYMPTOM DIAGNOSIS >

Diagnosis items	Symptom (Ignition switch ON)	Low tire pressure warning lamp	Cause	Action
Low tire pressure warning lamp	The low tire pressure warning lamp illuminates for 1 second, then turns OFF.	  ON 1 sec > stays OFF <small>SEIA0592E</small>	Wake-up operation for all transmitters at wheels is completed.	No system malfunctions
	The low tire pressure warning lamp repeats blinking ON for 2 seconds and OFF for 0.2 seconds.	 Blinks:  ON 2 sec > OFF 0.2 sec <small>SEIA0593E</small>	Wake-up operation for all transmitters at wheels is not completed.	Perform the wake-up operation for all transmitters at wheels. Refer to WT-6, "TRANSMITTER WAKE UP OPERATION : Transmitter Wake-up Procedure" .
	The low tire pressure warning lamp blinks once.	 Blinks 1 time ON 0.3 sec > OFF 1.3 sec <small>SEIA0594E</small>	The front left transmitter is not activated.	Perform the wake-up operation for the transmitter at front left wheel. Refer to WT-6, "TRANSMITTER WAKE UP OPERATION : Transmitter Wake-up Procedure" .
	The low tire pressure warning lamp repeats blinking twice.	  Blinks 2 times ON 0.3 sec > OFF 0.3 sec <small>SEIA0595E</small>	The front right transmitter is not activated.	Perform the wake-up operation for the transmitter at front right wheel. Refer to WT-6, "TRANSMITTER WAKE UP OPERATION : Transmitter Wake-up Procedure" .
	The low tire pressure warning lamp repeats blinking for 3 times.	   Blinks 3 times ON 0.3 sec > OFF 0.3 sec <small>SEIA0596E</small>	The rear right transmitter is not activated.	Perform the wake-up operation for the transmitter at rear right wheel. Refer to WT-6, "TRANSMITTER WAKE UP OPERATION : Transmitter Wake-up Procedure" .
	The low tire pressure warning lamp repeats blinking for 4 times.	    Blinks 4 times ON 0.3 sec > OFF 0.3 sec <small>SEIA0597E</small>	The rear left transmitter is not activated.	Perform the wake-up operation for the transmitter at rear left wheel. Refer to WT-6, "TRANSMITTER WAKE UP OPERATION : Transmitter Wake-up Procedure" .
	The low tire pressure warning lamp turns ON and stays illuminated.	 Comes ON and stays ON <small>SEIA0598E</small>	Low tire pressure	Check the tire pressure for all wheels and adjust to the specified value. Refer to WT-80, "Tire Air Pressure" .

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

TPMS

< SYMPTOM DIAGNOSIS >

Diagnosis items	Symptom (Ignition switch ON)	Low tire pressure warning lamp	Cause	Action
Low tire pressure warning lamp	The low tire pressure warning lamp repeats blinking at 0.5-second intervals for 1 minute, and then stays illuminated.	 <p style="text-align: center;">Blinks 1 min</p> <p style="text-align: center;">ON 0.5 sec > OFF 0.5 sec and stays ON</p> <p style="text-align: center;"><small>SEIA0788E</small></p>	The combination meter fuse is open or removed (or pulled out).	Check and install the combination meter fuse. If necessary, replace the fuse.
			The low tire pressure warning control unit harness connector is removed.	Check the connection conditions of the low tire pressure warning control unit harness connector, and repair if necessary.
			Tire Pressure Monitoring System (TPMS) malfunction.	<ul style="list-style-type: none"> • Perform CONSULT-III self-diagnosis. Refer to WT-12, "CONSULT-III Function". • If necessary, perform transmitter ID registration. Refer to WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure".
Turn signal lamp	The turn signal lamps do not blink twice when the transmitter is activated. Or the buzzer does not sound.	—	<ol style="list-style-type: none"> 1. The transmitter activation tool (J-45295) does not activate. 2. The ignition switch is OFF when the transmitter wake-up operation is performed. 3. The transmitter activation tool (J-45295) is not used in the correct position. 4. The transmitter is already waked up. 	<ol style="list-style-type: none"> 1. Replace the battery in the transmitter activation tool (J-45295). 2. Turn the ignition switch ON when performing the transmitter wake-up operation. 3. Operate the transmitter activation tool (J-45295) in the correct position when performing the wake-up operation. 4. No procedure.

NOTE:

If transmitter wake-up operation is not completed for two or more transmitters, the applicable low tire pressure warning lamp blinking patterns are displayed continuously.

(Example: Blinks once/OFF/blinks 3 times = Wake-up operation is not completed at the front left wheel and rear right wheel transmitters.)

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

Description

INFOID:000000005549649

The low tire pressure warning lamp does not illuminate when the ignition switch is turned ON.

Diagnosis Procedure

INFOID:000000005549650

1. CHECK LOW TIRE PRESSURE WARNING LAMP

Perform trouble diagnosis of the low tire pressure warning lamp. Refer to [WT-43, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace error-detected parts.

NO >> Repair or replace error-detected parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

WT

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN OFF

Description

INFOID:000000005549651

The low tire pressure warning lamp does not turn OFF after several seconds is passed after engine starts.

Diagnosis Procedure

INFOID:000000005549652

1. CHECK TIRE PRESSURE

1. Turn the ignition switch ON.

CAUTION:

Never start the engine.

2. Check the tire pressure for all wheels and adjust to the specified value. Refer to [WT-80, "Tire Air Pressure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Inspect or repair the tires or wheels.

2. CHECK LOW TIRE PRESSURE WARNING LAMP

Check low tire pressure warning lamp display.

Does not low tire pressure warning lamp turn OFF?

YES >> GO TO 3.

NO >> INSPECTION END

3. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT

Ⓟ With CONSULT-III

Perform "AIR PRESSURE MONITOR" self-diagnosis.

Is any DTC detected?

YES >> Check the DTC. Refer to [WT-56, "DTC Index"](#).

NO >> GO TO 4.

4. CHECK POWER SUPPLY AND GROUND

Check the power supply and ground circuit. Refer to [WT-39, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace low tire pressure warning control unit. Refer to [WT-76, "Exploded View"](#).

NO >> Repair or replace damaged parts.

LOW TIRE PRESSURE WARNING LAMP BLINKS

< SYMPTOM DIAGNOSIS >


LOW TIRE PRESSURE WARNING LAMP BLINKS

Description

INFOID:000000005549654

- The low tire pressure warning lamp blinks when the ignition switch is turned ON.
- Blinking mode

When the low tire pressure warning lamp blinks as shown in the figure, the transmitter is not waked up. Perform the transmitter wake-up operation. Refer to [WT-6. "TRANSMITTER WAKE UP OPERATION : Transmitter Wake-up Procedure"](#).



Diagnosis Procedure

INFOID:000000005549654

1. CHECK POWER OF TIRE PRESSURE WARNING CHECK SWITCH CONNECTOR

1. Turn the ignition switch ON.
2. Check the voltage between the tire pressure warning check switch and the ground.

Tire pressure warning check switch		—	Voltage
Connector	Terminal		
M23	1	Ground	7.6 - 14.6 V

Is the output voltage normal?

- YES >> Repair or replace the low tire pressure warning control unit. Or, replace the low tire pressure warning control unit.
- NO >> GO TO 2.

2. CHECK TIRE PRESSURE WARNING CHECK SWITCH CONNECTOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the low tire pressure warning control unit harness connector.
3. Check the continuity between the terminals of the low tire pressure warning control unit harness connector and the tire pressure warning check switch the connector.

Low tire pressure warning control unit		Tire pressure warning check switch		Continuity
Connector	Terminal	Connector	Terminal	
M96	12	M23	1	Existed

4. Check the continuity between the low tire pressure warning control unit harness connector and the ground.

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M96	12	Ground	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace error-detected parts.

3. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT

Check the input/output signals of the low tire pressure warning control unit. Refer to [WT-45. "Reference Value"](#).

Is the inspection result normal?

LOW TIRE PRESSURE WARNING LAMP BLINKS

< SYMPTOM DIAGNOSIS >

YES >> Replace the low tire pressure warning control unit.

NO >> GO TO 4.

4.CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT HARNESS CONNECTOR

Check for looseness or damage at the harness connector pins of the low tire pressure warning control unit.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

TURN SIGNAL LAMP BLINKS

< SYMPTOM DIAGNOSIS >

TURN SIGNAL LAMP BLINKS

Description

INFOID:000000005549655

DESCRIPTION

The turn signal lamp blinks when the ignition switch is turned ON.

Diagnosis Procedure

INFOID:000000005549656

1. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT

1. Check low tire pressure warning control unit input/output signal. Refer to [WT-45, "Reference Value"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT CIRCUIT

 With CONSULT-III

Perform "AIR PRESSURE MONITOR" self-diagnosis. Refer to [WT-32, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

3. CHECK TIRE PRESSURE WARNING CONTROL UNIT AND BCM CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect low tire pressure warning control unit harness connector and BCM harness connector.
3. Check the continuity between low tire pressure warning control unit harness connector and BCM harness connector.

Low tire pressure warning control unit		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M96	30	M122	110	Existed

Is the inspection result normal?

YES >> Check the BCM. Refer to [BCS-4, "CONFIGURATION \(BCM\) : Work Procedure"](#).

NO >> Repair or replace error-detected parts.

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

ID REGISTRATION CANNOT BE COMPLETED

< SYMPTOM DIAGNOSIS >

ID REGISTRATION CANNOT BE COMPLETED

Description

INFOID:000000005549657

DESCRIPTION

The ID of the transmitter installed in each wheel cannot be registered in the tire pressure monitoring system. Inspect the transmitter or the tire pressure monitoring system circuit.

Diagnosis Procedure

INFOID:000000005549658

1. CHECK ID REGISTRATION

1. Perform ID registration of all transmitters. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).
2. Drive at a speed of 40 km/h (25 MPH) or more for 3 minutes, and then drive the vehicle at any speed for 10 minutes.
3. Within 5 minutes, select "DATA MONITOR" of "AIR PRESSURE MONITOR" and display the tire pressure for all wheels.
4. Check that the displayed tire pressure is the specified value.

Monitored item	Condition	Display value
AIR PRESS FL	Start the engine and drive at a speed of 40 km/h (25 MPH) or more for several minutes.	Approximately equal to the indication on vehicle information display.
AIR PRESS FR		
AIR PRESS RR		
AIR PRESS RL		

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2. CHECK TRANSMITTER

1. Perform trouble diagnosis for transmitters. Refer to [WT-16, "Diagnosis Procedure"](#).
2. Perform ID registration of all transmitters. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).

Can ID registration of all transmitters be completed?

YES >> INSPECTION END

NO >> Replace the transmitter. Refer to [WT-77, "Exploded View"](#).

NORMAL OPERATING CONDITION


< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:000000005549659

If the low tire pressure warning lamp blinks as shown in the figure after the ignition switch is turned ON, the transmitter is not waked up. Perform the transmitter wake-up operation. Refer to [WT-6, "TRANSMITTER WAKE UP OPERATION : Transmitter Wake-up Procedure"](#).



A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

INFOID:000000005550830

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Symptom			Possible cause and SUSPECTED PARTS													Reference page				
			Improper installation, looseness	Out-of-round	unbalance	Incorrect tire pressure	Uneven tire wear	Deformation or damage	Non-uniformity	Incorrect tire size	PROPELLER SHAFT	DIFFERENTIAL	FRONT AXLE AND FRONT SUSPENSION	REAR AXLE AND REAR SUSPENSION	TIRES	ROAD WHEELS	DRIVE SHAFT	BRAKE	STEERING	
TIRES	Noise	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	2WD models: FSU-9 , FSU-12 AWD models: FSU-27 , FSU-30 WT-74 , "Inspection" MA-36 , "WHEELS (BONDING WEIGHT TYPE) : Adjustment" WT-80 , "Tire Air Pressure" MA-36 , "WHEELS (BONDING WEIGHT TYPE) : Adjustment"	
	Shake	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	— — WT-80 , "Tire Air Pressure"	
	Vibration				x				x	x		x	x						NVH in DLN section. NVH in DLN section.	
	Shimmy	x	x	x	x	x	x	x	x			x	x		x	x			NVH in FAX and FSU sections. NVH in RAX and RSU sections.	
	Judder	x	x	x	x	x	x		x			x	x		x				Refer to TIRES in this chart. Refer to ROAD WHEEL in this chart.	
	Poor quality ride or handling	x	x	x	x	x	x		x			x		x	x					NVH in FAX, RAX section. NVH in BR section. NVH in ST section.
	ROAD WHEEL	Noise	x	x	x				x		x	x	x	x			x	x	x	
		Shake	x	x	x				x		x		x	x	x		x	x	x	
Shimmy, Judder		x	x	x				x				x	x	x			x	x		
Poor quality ride or handling		x	x	x				x				x	x	x						

x: Applicable

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005588465

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Service Notice or Precautions

INFOID:000000005243132

- Low tire pressure warning lamp blinks for 1min, then turns ON when occurring any malfunction except low tire pressure. Erase the memory with CONSULT-III, or register the ID to turn low tire pressure warning lamp OFF. Refer to [WT-11. "Diagnosis Description"](#), [WT-7. "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).
- ID registration is required when replacing or rotating wheels, replacing transmitter or low tire pressure warning control unit. Refer to [WT-76. "Exploded View"](#).
- Replace grommet seal, valve core and cap of transmitter in TPMS, when replacing each tire by reaching the wear limit. Refer to [WT-77. "Exploded View"](#).

PREPARATION

< PREPARATION >

PREPARATION

PREPARATION

Special Service Tool


INFOID:000000005243133

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-45295) Transmitter activation tool  SEIA0462E	ID registration

Commercial Service Tool

INFOID:000000005243134

Tool name	Description
Power tool  PBIC0190E	Loosening wheel nuts

ROAD WHEEL

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

ROAD WHEEL

Adjustment

INFOID:000000005243136

BALANCING WHEELS (BONDING WEIGHT TYPE)

Preparation Before Adjustment

Using releasing agent, remove double-faced adhesive tape from the road wheel.

CAUTION:

- **Be careful not to scratch the road wheel during removal.**
- **After removing double-faced adhesive tape, wipe clean traces of releasing agent from the road wheel.**

Wheel Balance Adjustment

If a tire balance machine has adhesion balance weight mode settings and drive-in weight mode setting, select and adjust a drive-in weight mode suitable for road wheels.

1. Set road wheel on tire balance machine using the center hole as a guide. Start the tire balance machine.
2. When inner and outer unbalance values are shown on the tire balance machine indicator, multiply outer unbalance value by $5/3$ to determine balance weight that should be used. Select the outer balance weight with a value closest to the calculated value above and install to the designated outer position of, or at the designated angle in relation to the road wheel.

CAUTION:

- **Never install the inner balance weight before installing the outer balance weight.**
- **Before installing the balance weight, always to clean the mating surface of the road wheel.**

- a. Indicated unbalance value $\times 5/3 =$ balance weight to be installed

Calculation example:

$23 \text{ g (0.81 oz)} \times 5/3 = 38.33 \text{ g (1.35 oz)} \Rightarrow 37.5 \text{ g (1.32 oz)}$ balance weight (closer to calculated balance weight value)


NOTE:

Note that balance weight value must be closer to the calculated balance weight value.

Example:

$36.2 \Rightarrow 35 \text{ g (1.23 oz)}$

$36.3 \Rightarrow 37.5 \text{ g (1.32 oz)}$



- b. Installed balance weight in the position.


ROAD WHEEL

< PERIODIC MAINTENANCE >

- When installing balance weight (1) to road wheels, set it into the grooved area (A) on the inner wall of the road wheel as shown in the figure so that the balance weight center (B) is aligned with the tire balance machine indication position (angle) (C).

CAUTION:

- Always use genuine NISSAN adhesion balance weights.
- Balance weights are non-reusable; always replace with new ones.
- Never install more than three sheets of balance weight.



JPEIC0040ZZ

- If calculated balance weight value exceeds 50 g (1.76 oz), install two balance weight sheets in line with each other as shown in the figure.

CAUTION:


Never install one balance weight sheet on top of another.

- Start the tire balance machine again.
- Install drive-in balance weight on inner side of road wheel in the tire balance machine indication position (angle).

CAUTION:

Never install more than two balance weight.

- Start the tire balance machine. Make sure that inner and outer residual unbalance values are 5 g (0.17 oz) each or below.
- If either residual unbalance value exceeds 5 g (0.17 oz), repeat installation procedures.



PEIA0033E

Limit

Dynamic (At flange): Refer to [WT-80, "Road Wheel"](#).


Static (At flange): Refer to [WT-80, "Road Wheel"](#).

TIRE ROTATION

- Follow the maintenance schedule for tire rotation service intervals. Refer to [MA-5, "Explanation of General Maintenance"](#).
- When installing the wheel, tighten wheel nuts to the specified torque.

CAUTION:

- Never include the T-type spare tire when rotating the tires.
- When installing wheels, tighten them diagonally by dividing the work two to three times in order to prevent the wheels from developing any distortion.
- Be careful not to tighten wheel nut at torque exceeding the criteria for preventing strain of disc rotor.
- Use NISSAN genuine wheel nuts for aluminum wheels.



Wheel nuts tightening torque : Refer to [WT-80, "Road Wheel"](#).

ROAD WHEEL

< PERIODIC MAINTENANCE >

- Perform the ID registration, after tire rotation. Refer to [WT-7. "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

ROAD WHEEL TIRE ASSEMBLY


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

ROAD WHEEL TIRE ASSEMBLY

Exploded View

INFOID:000000005550902



1. Tire assembly

Refer to [GI-4. "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000005550903

REMOVAL

1. Remove wheel nuts.
2. Remove tire assembly.

INSTALLATION

Install in the reverse order of removal.

Inspection

INFOID:000000005243135


ALUMINUM WHEEL

1. Check tires for wear and improper inflation.
2. Check wheels for deformation, cracks and other damage. If deformed, remove wheel and check wheel runout.
 - a. Remove tire from aluminum wheel and mount on a tire balance machine.
 - b. Set dial indicator as shown in the figure.
 - c. If the lateral deflection (A) or vertical deflection (B) for radial runout value exceeds the limit, replace aluminum wheel.

Limit

A: Refer to [WT-80. "Road Wheel"](#).

B: Refer to [WT-80. "Road Wheel"](#).



STEEL WHEEL

1. Check tires for were and improper inflation.

ROAD WHEEL TIRE ASSEMBLY

< REMOVAL AND INSTALLATION >

2. Check wheels for deformation, clacks and other damage. If deformed, remove wheel and check wheel runout.
 - a. Remove tire from steel wheel and mount wheel on a tire balance machine.
 - b. Set two dial indicators as shown in the illustration.
 - c. Set each dial indicator to "0".
 - d. Rotate wheel and check dial indicators at several points around the circumference of the wheel.
 - e. Calculate runout at each point as shown below.

Lateral runout limit (A): $(1+2)/2$

Radial runout limit (B): $(3+4)/2$

- f. Select maximum positive runout value and the maximum negative value. Add the two values to determine total runout.

CAUTION:


In case a positive or negative value is not available, use the maximum value (negative or positive) for total runout.

Limit

A: Refer to [WT-80, "Road Wheel"](#).

B: Refer to [WT-80, "Road Wheel"](#).

- g. If the total runout value exceeds limit, replace steel wheel.



A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P


TPMS CONTROL UNIT

< REMOVAL AND INSTALLATION >

TPMS CONTROL UNIT

Exploded View

INFOID:000000005243137



1. Low tire pressure warning control unit 2. Bracket

◀: Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

Removal and Installation

INFOID:000000005243138

REMOVAL

1. Remove the glove box assembly. Refer to [IP-11, "Exploded View"](#).
2. Remove the instrument lower panel RH. Refer to [IP-11, "Exploded View"](#).
3. Disconnect low tire pressure warning control unit connector.
4. Remove the low tire pressure warning control unit control unit.

INSTALLATION

Install in the reverse order of removal.

- Perform ID registration after replacing low tire pressure warning control unit. Refer to [WT-7, "ID REGISTRATION PROCEDURE : Transmitter ID Registration Procedure"](#).


TRANSMITTER

< REMOVAL AND INSTALLATION >

TRANSMITTER

Exploded View

INFOID:000000005243139



- | | | |
|----------------|-----------------|--------------|
| 1. Transmitter | 2. Grommet seal | 3. Valve nut |
| 4. Valve core | 5. Cap | |


Refer to [GI-4, "Components"](#) for symbols in figure.

Removal and Installation


INFOID:000000005243140

REMOVAL

1. Deflate tire. Unscrew transmitter retaining nut and allow transmitter to fall into tire.
2. Gently bounce tire so that transmitter falls to bottom of tire. Place on tire changing machine and break both tire beads ensuring that the transmitter remains at the bottom of the tire.



3. Turn tire so that valve hole is at bottom and bounce so that transmitter (1) is near valve hole. Carefully lift tire onto turntable and position valve hole (and transmitter) 270 degree from mounting/dismounting head (2).
4. Lubricate tire well and remove first side of the tire. Reach inside the tire and remove the transmitter.




INSTALLATION

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

TRANSMITTER

< REMOVAL AND INSTALLATION >

1. Put first side of tire onto rim.



2. Mount transmitter on rim and tighten nut.

CAUTION:


Speed for tightening nut should be less than 10 rpm.

3. Place wheel on turntable of tire machine. Ensure that transmitter (1) is 270 degree from mounting head (2) when second side of tire is fitted.

NOTE:

Do not touch transmitter at mounting head.

4. Lubricate tire well and fit second side of tire as normal. Ensure that tire does not rotate relative to rim.
5. Inflate tire and fit to appropriate wheel position.
6. Perform the transmitter wake-up after replacing transmitter. Refer to [WT-6. "TRANSMITTER WAKE UP OPERATION : Transmitter Wake-up Procedure"](#).




TIRE PRESSURE RECEIVER

< REMOVAL AND INSTALLATION >

TIRE PRESSURE RECEIVER

Exploded View



1. Front tire pressure receiver
2. Rear tire pressure receiver

Refer to [GI-4, "Components"](#) for symbols in the figure.

← Vehicle front

FRONT TIRE PRESSURE RECEIVER

FRONT TIRE PRESSURE RECEIVER : Removal and Installation

INFOID:000000005243142

REMOVAL

1. Remove fender protector (rear). Refer to [EXT-25, "FENDER PROTECTOR : Exploded View"](#).
2. Remove mounting bolt for the front tire pressure receiver.
3. Disconnect front tire pressure receiver harness connector.
4. Remove front tire pressure receiver.

INSTALLATION

Installation is the reverse order of removal.

REAR TIRE PRESSURE RECEIVER

REAR TIRE PRESSURE RECEIVER : Removal and Installation

INFOID:000000005243143

REMOVAL

1. Remove rear wheel house protector. Refer to [EXT-27, "REAR WHEEL HOUSE PROTECTOR : Exploded View"](#).
2. Remove mounting bolt for the rear tire pressure receiver.
3. Disconnect rear tire pressure receiver harness connector.
4. Remove rear tire pressure receiver.

INSTALLATION

Installation is the reverse order of removal.

A
B
C
D
WT
F
G
H
I
J
K
L
M
N
O
P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Road Wheel

INFOID:000000005243144

ALUMINUM WHEEL (CONVENTIONAL)

Item		Limit
Radial runout	Lateral deflection	Less than 0.3 mm (0.012 in)
	Vertical deflection	
Allowable unbalance	Dynamic (At flange)	Less than 5 g (0.17 oz) (one side)
	Static (At flange)	Less than 10 g (0.35 oz)

STEEL WHEEL (FOR EMERGENCY USE)

Item		Limit
Radial runout	Lateral deflection	Less than 1.5 mm (0.059 in)
	Vertical deflection	

Tire Air Pressure

INFOID:000000005243146

Unit: kPa (kg/cm², psi)

Item	Standard	
	Front	Rear
P265/60R18 109V	230 (2.3, 33)	
P265/50R20 106V	230 (2.3, 33)	
P265/45R21 104V	230 (2.3, 33)	
265/45R21 104W	230 (2.3, 33)	
T175/90D18 110M	420 (4.2, 60)	