

SECTION MA
MAINTENANCE

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
MA

CONTENTS

PREPARATION	3	DRIVE BELT	18
PREPARATION	3	DRIVE BELT : Exploded View	18
Special Service Tool	3	DRIVE BELT : Checking	18
Commercial Service Tool	3	DRIVE BELT : Tension Adjustment	18
PERIODIC MAINTENANCE	4	ENGINE COOLANT	18
GENERAL MAINTENANCE	4	ENGINE COOLANT : Draining	18
FOR NORTH AMERICA	4	ENGINE COOLANT : Refilling	19
FOR NORTH AMERICA : Explanation of General Maintenance	4	ENGINE COOLANT : Flushing	20
FOR MEXICO	5	RESERVOIR TANK CAP	21
FOR MEXICO : General Maintenance	6	RESERVOIR TANK CAP : Inspection	21
PERIODIC MAINTENANCE	8	RADIATOR	21
FOR NORTH AMERICA	8	RADIATOR : Inspection	22
FOR NORTH AMERICA : Introduction of Periodic Maintenance	8	FUEL LINES	22
FOR MEXICO	11	FUEL LINES : Inspection	22
FOR MEXICO : Introduction of Periodic Maintenance	11	AIR CLEANER FILTER	22
RECOMMENDED FLUIDS AND LUBRICANTS	14	AIR CLEANER FILTER : Removal and Installation	22
FOR NORTH AMERICA	14	AIR CLEANER FILTER : Inspection (Viscous Paper Type)	23
FOR NORTH AMERICA : Fluids and Lubricants	14	ENGINE OIL	23
FOR NORTH AMERICA : Engine Oil Recommendation	14	ENGINE OIL : Draining	23
FOR NORTH AMERICA : Anti-Freeze Coolant Mixture Ratio	15	ENGINE OIL : Refilling	24
FOR MEXICO	15	OIL FILTER	24
FOR MEXICO : Fluids and Lubricants	15	OIL FILTER : Removal and Installation	24
FOR MEXICO : SAE Viscosity Number	16	OIL FILTER : Inspection	25
FOR MEXICO : Engine Coolant Mixture Ratio	17	SPARK PLUG	25
ENGINE MAINTENANCE	18	SPARK PLUG : Removal and Installation	25
		SPARK PLUG : Inspection	26
		EVAP VAPOR LINES	26
		EVAP VAPOR LINES : Inspection	26
		CHASSIS MAINTENANCE	27
		EXHAUST SYSTEM	27
		EXHAUST SYSTEM : Inspection	27



A/T FLUID	27	DISC BRAKE	36
A/T FLUID : Inspection	27	DISC BRAKE : Inspection	36
A/T FLUID : Changing	27	DISC BRAKE : Front Disc Brake	36
A/T FLUID : Adjustment	29	DISC BRAKE : Rear Disc Brake	37
TRANSFER FLUID	29	STEERING GEAR AND LINKAGE	37
TRANSFER FLUID : Inspection	29	STEERING GEAR AND LINKAGE : Inspection	37
TRANSFER FLUID : Draining	30	POWER STEERING FLUID AND LINES	37
TRANSFER FLUID : Refilling	30	POWER STEERING FLUID AND LINES : Inspec-	
FRONT PROPELLER SHAFT: 2S56A	30	tion	38
FRONT PROPELLER SHAFT: 2S56A : Inspec-		AXLE AND SUSPENSION PARTS	38
tion	30	AXLE AND SUSPENSION PARTS : Inspection	38
REAR PROPELLER SHAFT: 3S80A-R	31	DRIVE SHAFT	38
REAR PROPELLER SHAFT: 3S80A-R : Inspec-		DRIVE SHAFT : Inspection	39
tion	31	BODY MAINTENANCE	40
REAR PROPELLER SHAFT: 3F80A-R	31	LOCKS, HINGES AND HOOD LATCH	40
REAR PROPELLER SHAFT: 3F80A-R : Inspec-		LOCKS, HINGES AND HOOD LATCH : Lubricat-	
tion	31	ing	40
FRONT DIFFERENTIAL GEAR OIL: F160A	31	SEAT BELT, BUCKLES, RETRACTORS, AN-	
FRONT DIFFERENTIAL GEAR OIL: F160A : In-		CHORS AND ADJUSTERS	40
spection	31	SEAT BELT, BUCKLES, RETRACTORS, AN-	
FRONT DIFFERENTIAL GEAR OIL: F160A :		CHORS AND ADJUSTERS : Inspection	40
Draining	32	SERVICE DATA AND SPECIFICATIONS	
FRONT DIFFERENTIAL GEAR OIL: F160A : Re-		(SDS)	41
filling	32	SERVICE DATA AND SPECIFICATIONS	
REAR DIFFERENTIAL GEAR OIL: R190	32	(SDS)	41
REAR DIFFERENTIAL GEAR OIL: R190 : Inspec-		DRIVE BELT	41
tion	32	DRIVE BELT : Drive Belt	41
REAR DIFFERENTIAL GEAR OIL: R190 : Drain-		ENGINE COOLANT	41
ing	33	ENGINE COOLANT :	
REAR DIFFERENTIAL GEAR OIL: R190 : Refill-		Periodical Maintenance Specification	41
ing	33	ENGINE OIL	41
WHEELS (BONDING WEIGHT TYPE)	33	ENGINE OIL :	
WHEELS (BONDING WEIGHT TYPE) : Wheel		Periodical Maintenance Specification	41
Balance Adjustment (Aluminum Wheel)	33	SPARK PLUG	41
WHEELS (BONDING WEIGHT TYPE) : Tire Rota-		SPARK PLUG : Spark Plug	41
tion	35	ROAD WHEEL	41
BRAKE FLUID LEVEL AND LEAKS	35	ROAD WHEEL : Road Wheel	41
BRAKE FLUID LEVEL AND LEAKS : Inspection ...	35		
BRAKE LINES AND CABLES	35		
BRAKE LINES AND CABLES : Inspection	35		
BRAKE FLUID	35		
BRAKE FLUID : Changing	36		

PREPARATION

< PREPARATION >


PREPARATION

PREPARATION

Special Service Tool





INFOID:000000009241053

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name		Description
KV10115801 (J-38956) Oil filter wrench	 <p style="text-align: center; font-size: small;">S-NT375</p>	Removing and installing oil filter a: 64.3 mm (2.531 in)

Commercial Service Tool

INFOID:000000009241054

Tool name		Description
Power tool	 <p style="text-align: center; font-size: small;">PBIC0190E</p>	Loosening nuts and bolts
Spark plug wrench	 <p style="text-align: center; font-size: small;">JPBIA0399ZZ</p>	Removing and installing spark plug a : 14 mm (0.55 in)
Radiator cap tester	 <p style="text-align: center; font-size: small;">PBIC1982E</p>	Checking radiator and radiator cap
Radiator cap tester adapter	 <p style="text-align: center; font-size: small;">S-NT564</p>	Adapting radiator cap tester to radiator cap and water outlet (front) filler neck a : 28 (1.10) dia. b : 31.4 (1.236) dia. c : 41.3 (1.626) dia. Unit: mm (in)

GENERAL MAINTENANCE

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

GENERAL MAINTENANCE FOR NORTH AMERICA

FOR NORTH AMERICA : Explanation of General Maintenance

INFOID:000000009241055

General maintenance includes those items which should be checked during the normal day-to-day operation of the vehicle. They are essential if the vehicle is to continue operating properly. The owners can perform checks and inspections themselves or have their **INFINITI** retailers do them.

OUTSIDE THE VEHICLE

The maintenance items listed here should be performed from time to time, unless otherwise specified.

Item		Reference page
Tires	Check the pressure with a gauge often and always prior to long distance trips. Adjust the pressure in all tires, including the spare, to the pressure specified. Check carefully for damage, cuts or excessive wear.	WT-68
Wheel nuts	When checking the tires, make sure no nuts are missing, and check for any loose nuts. Tighten if necessary.	—
Tire rotation	Tires should be rotated every 5,000 miles (8,000 km).	MA-35
Tire Pressure Monitoring System (TPMS) transmitter components	Replace the TPMS transmitter grommet seal, valve core and cap when the tires are replaced due to wear or age.	WT-64
Wheel alignment and balance	If the vehicle should pull to either side while driving on a straight and level road, or if you detect uneven or abnormal tire wear, there may be a need for wheel alignment. If the steering wheel or seat vibrates at normal highway speeds, wheel balancing may be needed. For additional information regarding tires, refer to "Important Tire Safety Information" (US) or "Tire Safety Information" (Canada) in the INFINITI Warranty Information Booklet.	FSU-7 (2WD) FSU-8 (2WD) FSU-29 (AWD) FSU-30 (AWD) RSU-6 MA-33
Windshield	Clean the windshield on a regular basis. Check the windshield at least every six months for cracks or other damage. Repair as necessary.	—
Windshield wiper blades	Check for cracks or wear if they do not wipe properly.	—
Doors and engine hood	Check that all doors and the engine hood operate properly. Also make sure that all latches lock securely. Lubricate if necessary. Make sure that the secondary latch keeps the hood from opening when the primary latch is released. When driving in areas using road salt or other corrosive materials, check lubrication frequently.	MA-40
Lamps	Make sure that the headlamps, stop lamps, tail lamps, turn signal lamps, and other lamps are all operating properly and installed securely. Also check headlamp aim. Clean the headlamps on a regular basis.	—

INSIDE THE VEHICLE

The maintenance items listed here should be checked on a regular basis, such as when performing periodic maintenance, cleaning the vehicle, etc.

Item		Reference page
Warning lamps and chimes	Make sure that all warning lamps and chimes are operating properly.	—
Windshield wiper and washer	Check that the wipers and washer operate properly and that the wipers do not streak.	—
Windshield defroster	Check that the air comes out of the defroster outlets properly and in sufficient quantity when operating the heater or air conditioner.	—
Steering wheel	Check that it has the specified play. Check for changes in the steering condition, such as excessive play, hard steering or strange noises. Free play: Less than 35 mm (1.38 in)	—

GENERAL MAINTENANCE

< PERIODIC MAINTENANCE >

Item		Reference page	
Seats	Check seat position controls such as seat adjusters, seatback recliner, etc. to make sure they operate smoothly and that all latches lock securely in every position. Check that the head restraints move up and down smoothly and that the locks (if equipped) hold securely in all latched positions. Check that the latches lock securely for folding-down rear seatbacks.	—	A
Seat belts	Check that all parts of the seat belt system (e.g. buckles, anchors, adjusters and retractors) operate properly and smoothly, and are installed securely. Check the belt webbing for cuts, fraying, wear or damage.	MA-40	B
Accelerator pedal	Check the pedal for smooth operation and make sure the pedal does not catch or require uneven effort. Keep the floor mats away from the pedal.	—	C
Brakes	Check that the brake does not pull the vehicle to one side when applied.	—	D
Brake pedal and booster	Check the pedal for smooth operation and make sure it has the proper distance under it when depressed fully. Check the brake booster function. Be sure to keep the floor mats away from the pedal.	BR-9 BR-16	E
Parking brake	Check that the lever or pedal has the proper travel and make sure that the vehicle is held securely on a fairly steep hill when only the parking brake is applied.	PB-5	F
Automatic transmission “Park” mechanism	Check that the lock release button on the selector lever operates properly and smoothly. On a fairly steep hill check that the vehicle is held securely with the selector lever in the P (Park) position without applying any brakes.	—	G

UNDER THE HOOD AND VEHICLE

The maintenance items listed here should be checked periodically (e.g. each time you check the engine oil or refuel).

Item		Reference page	
Windshield washer fluid	Check that there is adequate fluid in the tank.	—	H
Engine coolant level	Check the coolant level when the engine is cold.	CO-7	I
Radiator and hoses	Check the front of the radiator and clean off any dirt, insects, leaves, etc., that may have accumulated. Make sure the hoses have no cracks, deformation, deterioration or loose connections.	MA-22	J
Brake fluid level	Make sure that the brake fluid level is between the “MAX” and “MIN” lines on the reservoir.	MA-35	K
Battery	Check the fluid level in each cell. It should be between the “MAX” and “MIN” lines. Vehicles operated in high temperatures or under severe conditions require frequent checks of the battery fluid level.	PG-98	L
Engine drive belts	Make sure that no belt is frayed, worn, cracked or oily.	MA-18	M
Engine oil level	Check the level on the oil level gauge after parking the vehicle on a level spot and turning off the engine.	LU-7	N
Power steering fluid level and lines	Check the level when the fluid is cold, with the engine off. Check the lines for proper attachment, leaks, cracks, etc.	MA-38	O
Exhaust system	Make sure there are no loose supports, cracks or holes. If the sound of the exhaust seems unusual or there is a smell of exhaust fumes, immediately locate the trouble and correct it.	MA-27	
Underbody	The underbody is frequently exposed to corrosive substances such as those used on icy roads or to control dust. It is very important to remove these substances, otherwise rust will form on the floor pan, frame, fuel lines and around the exhaust system. At the end of winter, the underbody should be thoroughly flushed with plain water, being careful to clean those areas where mud and dirt can easily accumulate.	—	
Fluid leaks	Check under the vehicle for fuel, oil, water or other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioner after use is normal. If you should notice any leaks or gasoline fumes are evident, check for the cause and correct it immediately.	—	MA

FOR MEXICO

GENERAL MAINTENANCE

< PERIODIC MAINTENANCE >

FOR MEXICO : General Maintenance

INFOID:000000009241056

General maintenance includes those items which should be checked during the normal day-to-day operation of the vehicle. They are essential if the vehicle is to continue operating properly. The owners can perform the checks and inspections themselves or they can have their **INFINITI** dealers do them.

OUTSIDE THE VEHICLE

The maintenance items listed here should be performed from time to time, unless otherwise specified.

Item	Reference page	
Doors and hood	Check that all doors and the hood operate smoothly as well as the back door, trunk lid and hatch. Also make sure that all latches lock securely. Lubricate if necessary. Make sure that the secondary latch keeps the hood from opening when the primary latch is released. When driving in areas using road salt or other corrosive materials, check lubrication frequently.	MA-40
Lamps	Clean the headlamps on a regular basis. Make sure that the headlamps, stop lamps, tail lamps, turn signal lamps, and other lamps are all operating properly and installed securely. Also check the aim of the headlamps.	—
Tires	Check the pressure with a gauge often and always prior to long distance trips. Adjust the pressure in all tires, including the spare, to the pressure specified. Check carefully for damage, cuts or excessive wear.	WT-68
Tire rotation	In the case that Two-Wheel Drive (2WD) and front & rear tires are same size; Tires should be rotated every 10,000 km (6,000 miles). Tires marked with directional indicators can only be rotated between front and rear. Make sure that the directional indicators point in the direction of wheel rotation after the tire rotation is completed. In the case that Four-Wheel Drive (4WD) and front & rear tires are same size; Tires should be rotated every 5,000 km (3,000 miles). Tires marked with directional indicators can only be rotated between front and rear. Make sure that the directional indicators point in the direction of wheel rotation after the tire rotation is completed. In the case that front tires are different size from rear tires; Tires cannot be rotated. However, the timing for tire rotation may vary according to your driving habits and the road surface conditions.	MA-35
Tire Pressure Monitoring System (TPMS) transmitter components (if equipped)	Replace the TPMS transmitter grommet seal, valve core and cap when the tires are replaced due to wear or age.	WT-64
Wheel alignment and balance	If the vehicle should pull to either side while driving on a straight and level road, or if you detect uneven or abnormal tire wear, there may be a need for wheel alignment. If the steering wheel or seat vibrates at normal highway speeds, wheel balancing may be needed.	FSU-7 (2WD) FSU-8 (2WD) RSU-6 MA-33
Windshield	Clean the windshield on a regular basis. Check the windshield at least every six months for cracks or other damage. Repair as necessary.	—
Wiper blades	Check for cracks or wear if not functioning correctly.	—

INSIDE THE VEHICLE

The maintenance items listed here should be checked on a regular basis, such as when performing periodic maintenance, cleaning the vehicle, etc.

Item	Reference page	
Accelerator pedal	Check the pedal for smooth operation and make sure that the pedal does not catch or require uneven effort. Keep the floor mats away from the pedal.	—
Brake pedal	Check the pedal for smooth operation and make sure that it is the proper distance from the floor mat when depressed fully. Check the brake booster function. Be sure to keep the floor mats away from the pedal.	BR-9
Parking brake	Check the parking brake operation regularly. Check that the lever (if equipped) or the pedal (if equipped) has the proper travel. Also make sure that the vehicle is held securely on a fairly steep hill when only the parking brake is applied.	PB-5
Seat belts	Check that all parts of the seat belt system (for example, buckles, anchors, adjusters and retractors) operate properly and smoothly, and are installed securely. Check the belt webbing for cuts, fraying, wear or damage.	MA-40

GENERAL MAINTENANCE

< PERIODIC MAINTENANCE >

Item		Reference page	
Steering wheel	Check for changes in the steering condition, such as excessive play, hard steering or strange noises. Check that it has the specified play. Free play: Less than 35 mm (1.38 in)	—	A
Warning lamps and chimes	Make sure that all warning lamps and chimes are operating properly.	—	B
Windshield defogger	Check that the air comes out of the defogger outlets properly and in good quantity when operating the heater or air conditioner.	—	C
Windshield wiper and washer	Check that the wipers and washer operate properly and that the wipers do not streak.	—	D

UNDER THE HOOD AND VEHICLE

The maintenance items listed here should be checked periodically (for example, each time you check the engine oil or refuel.)

Item		Reference page	
Battery	Except for maintenance free battery; Check the fluid level in each cell. It should be between the "UPPER" and "LOWER" lines. Vehicles operated in high temperatures or under severe conditions require frequent checks of the battery fluid level.	PG-98	E
Brake (and clutch) fluid level(s)	For Manual Transmission (MT) model; Make sure that the brake and clutch fluid levels are between the "MAX" and "MIN" lines on the reservoir(s). Except for Manual Transmission (MT) model; Make sure that the brake fluid level is between the "MAX" and "MIN" lines on the reservoir.	MA-35	F
Coolant level	Check the coolant level when the coolant is cold. Make sure that the coolant level is between the "MAX" and "MIN" lines on the reservoir.	CO-7	G
Engine drive belt(s)	Make sure that drive belt(s) is/are not frayed, worn, cracked or oily.	MA-18	H
Engine oil level	Check the level after parking the vehicle (on a level ground) and turning off the engine.	LU-7	
Fluid leaks	Check under the vehicle for fuel, oil, water or other fluid leaks after the vehicle has been parked for a while. Water dripping from the air conditioner after use is normal. If you should notice any leaks or if fuel fumes are evident, check for cause and have it corrected immediately.	—	I
Power steering fluid level and lines	Check the level when the fluid is cold with the engine off. Check the lines for proper attachment, leaks, cracks, etc.	MA-38	J
Windshield washer fluid	Check that there is adequate fluid in the reservoir.	—	K

MA

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE FOR NORTH AMERICA

FOR NORTH AMERICA : Introduction of Periodic Maintenance

INFOID:000000009717391

The following tables show the normal maintenance schedule. Depending upon weather and atmospheric conditions, varying road surfaces, individual driving habits and vehicle usage, additional or more frequent maintenance may be required.

Periodic maintenance beyond the last period shown on the tables requires similar maintenance.

Emission Control System Maintenance

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary.

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000)	5	10	15	20	25	30	35	40	45
	Months	(8)	(16)	(24)	(32)	(40)	(48)	(56)	(64)	(72)
Drive belt	NOTE (1)								I*	
Air cleaner filter	NOTE (2)						R			
EVAP vapor lines					I*				I*	
Fuel lines					I*				I*	
Fuel filter	NOTE (3)									
Engine coolant*	NOTE (4)(5)									
Engine oil		R	R	R	R	R	R	R	R	R
Engine oil filter (Use genuine NISSAN engine oil filter or equivalent)		R	R	R	R	R	R	R	R	R
Spark plugs (Iridium-tipped type)	NOTE (6)	Replace every 105,000 miles (168,000 km)								
Intake and exhaust valve clearance*	NOTE (7)									

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000)	50	55	60	65	70	75	80	85	90
	Months	(80)	(88)	(96)	(104)	(112)	(120)	(128)	(136)	(144)
Drive belt	NOTE (1)	I*		I*		I*		I*		I*
Air cleaner filter	NOTE (2)			R						R
EVAP vapor lines				I*				I*		
Fuel lines				I*				I*		
Fuel filter	NOTE (3)									
Engine coolant*	NOTE (4)(5)									
Engine oil		R	R	R	R	R	R	R	R	R
Engine oil filter (Use genuine NISSAN engine oil filter or equivalent)		R	R	R	R	R	R	R	R	R
Spark plugs (Iridium-tipped type)	NOTE (6)	Replace every 105,000 miles (168,000 km)								
Intake and exhaust valve clearance*	NOTE (7)									

MAINTENANCE OPERATION		MAINTENANCE INTERVAL						Reference Page
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000)	95	100	105	110	115	120	
	Months	(152)	(160)	(168)	(176)	(184)	(192)	
Drive belt	NOTE (1)		I*		I*		I*	MA-18
Air cleaner filter	NOTE (2)						R	MA-22
EVAP vapor lines			I*				I*	MA-26

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

MAINTENANCE OPERATION		MAINTENANCE INTERVAL						Reference Page	
		Miles x 1,000 (km x 1,000) Months	95 (152) 114	100 (160) 120	105 (168) 126	110 (176) 132	115 (184) 138		120 (192) 144
Perform at number of miles, kilometers or months, whichever comes first.									
Fuel lines			I*					I*	MA-22
Fuel filter	NOTE (3)								—
Engine coolant*	NOTE (4)(5)								MA-18
Engine oil		R	R	R	R	R	R	R	LU-7
Engine oil filter (Use genuine NISSAN engine oil filter or equivalent)		R	R	R	R	R	R	R	MA-24
Spark plugs (Iridium-tipped type)	NOTE (6)	Replace every 105,000 miles (168,000 km)							MA-25
Intake and exhaust valve clearance*	NOTE (7)								EM-10

NOTE:

- (1) After 40,000 miles (64,000 km) or 48 months, inspect every 10,000 miles (16,000 km) or 12 months. Replace the drive belts if found damaged.
- (2) If operating mainly in dusty conditions, more frequent maintenance may be required.
- (3) Maintenance-free item. For service procedures, refer to the FL section.
- (4) First replacement interval is 105,000 miles (168,000 km) or 84 months. After first replacement, replace every 75,000 miles (120,000 km) or 60 months.
- (5) Use only Genuine NISSAN long life Antifreeze/Coolant (blue) or equivalent with proper mixture ratio of 50% anti-freeze and 50% demineralized or distilled water. Mixing any other type of coolant or the use of non-distilled water will reduce the life expectancy of the factory fill coolant.
- (6) Replace spark plug when the plug gap exceeds 1.4 mm (0.055 in) even if within specified periodic replacement mileage.
- (7) Periodic maintenance is not required. However, if valve noise increases, inspect valve clearance.

* Maintenance items and intervals with "*" are recommended by INFINITI for reliable vehicle operation. The owner need not perform such maintenance in order to maintain the emission warranty or manufacturer recall liability. Other maintenance items and intervals are required.

Chassis and Body Maintenance

Abbreviations: R = Replace. I = Inspect. Correct or replace if necessary.

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								
		Miles x 1,000 (km x 1,000) Months	5 (8) 6	10 (16) 12	15 (24) 18	20 (32) 24	25 (40) 30	30 (48) 36	35 (56) 42	40 (64) 48
Perform at number of miles, kilometers or months, whichever comes first.										
Brake lines & cables			I			I		I		I
Brake pads & rotors★			I			I		I		I
Brake fluid★						R				R
Automatic transmission fluid	NOTE (1)									
Transfer fluid & differential gear oil	NOTE (2)		I			I		I		I
Steering gear & linkage, axle & suspension parts★						I				I
Tire rotation	NOTE (3)									
Propeller shaft (AWD models) & drive shaft boots★			I			I		I		I
Exhaust system★						I				I
In-cabin microfilter					R			R		R
Stop lamp switch & brake pedal position switch	NOTE (4)		I			I		I		I

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000)	50 (80)	55 (88)	60 (96)	65 (104)	70 (112)	75 (120)	80 (128)	85 (136)	90 (144)
	Months	60	66	72	78	84	90	96	102	108
Brake lines & cables		I		I		I		I		I
Brake pads & rotors★		I		I		I		I		I
Brake fluid★				R				R		
Automatic transmission fluid	NOTE (1)									
Transfer fluid & differential gear oil	NOTE (2)	I		I		I		I		I
Steering gear & linkage, axle & suspension parts★				I				I		
Tire rotation	NOTE (3)									
Propeller shaft (AWD models) & drive shaft boots★		I		I		I		I		I
Exhaust system★				I				I		
In-cabin microfilter				R			R			R
Stop lamp switch & brake pedal position switch	NOTE (4)	I		I		I		I		I

MAINTENANCE OPERATION		MAINTENANCE INTERVAL						Reference Page
Perform at number of miles, kilometers or months, whichever comes first.	Miles x 1,000 (km x 1,000)	95 (152)	100 (160)	105 (168)	110 (176)	115 (184)	120 (192)	
	Months	114	120	126	132	138	144	
Brake lines & cables			I		I		I	MA-35
Brake pads & rotors★			I		I		I	MA-36
Brake fluid★			R				R	MA-36
Automatic transmission fluid	NOTE (1)							MA-27
Transfer fluid & differential gear oil	NOTE (2)		I		I		I	MA-29 MA-31 (F160A) MA-32 (R190)
Steering gear & linkage, axle & suspension parts★			I				I	MA-37 MA-38
Tire rotation	NOTE (3)							MA-4 MA-35
Propeller shaft (AWD models) & drive shaft boots★			I		I		I	MA-30 (2S56A) MA-31 (3S80A-R) MA-31 (3F80A-R) MA-39
Exhaust system★			I				I	MA-27
In-cabin microfilter				R			R	VTL-17
Stop lamp switch & brake pedal position switch	NOTE (4)		I		I		I	BR-9

NOTE:

- Maintenance items with “★” should be performed more frequently according to “Maintenance Under Severe Driving Conditions”.
- (1) Automatic transmission fluid maintenance-free.
- (2) If towing a trailer, using a camper or car-top carrier, or driving on rough or muddy roads, change (not just inspect) oil at every 20,000 miles (32,000 km) or 24 months.
- (3) Refer to “Tire rotation” under the “GENERAL MAINTENANCE” heading earlier in this section.
- (4) Inspect the clearance between the brake pedal and the switches.

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

MAINTENANCE UNDER SEVERE DRIVING CONDITIONS

The maintenance intervals shown on the preceding pages are for normal operating conditions. If the vehicle is mainly operated under severe driving conditions as shown below, more frequent maintenance must be performed on the following items as shown in the table.

Severe driving conditions

- Repeated short trips of less than 5 miles (8 km).
- Repeated short trips of less than 10 miles (16 km) with outside temperatures remaining below freezing.
- Operating in hot weather in stop-and-go "rush hour" traffic.
- Extensive idling and/or low speed driving for long distances, such as police, taxi or door-to-door delivery use.
- Driving in dusty conditions.
- Driving on rough, muddy, or salt spread roads.
- Towing a trailer, using a camper or a car-top carrier.

Maintenance operation: Inspect = Inspect and correct or replace as necessary.

Maintenance item	Maintenance operation	Maintenance interval	Reference page
Brake fluid	Replace	Every 10,000 miles (16,000 km) or 12 months	MA-36
Brake pads & rotors	Inspect	Every 5,000 miles (8,000 km) or 6 months	MA-36
Steering gear & linkage, axle & suspension parts	Inspect	Every 5,000 miles (8,000 km) or 6 months	MA-37 MA-38
Propeller shaft (AWD models) & drive shaft boots	Inspect	Every 5,000 miles (8,000 km) or 6 months	MA-30 (2S56A) MA-31 (3S80A-R) MA-31 (3F80A-R) MA-39
Exhaust system	Inspect	Every 5,000 miles (8,000 km) or 6 months	MA-27

FOR MEXICO

FOR MEXICO : Introduction of Periodic Maintenance

INFOID:000000009717392

The following tables show the normal maintenance schedule. Depending upon weather and atmospheric conditions, varying road surfaces, individual driving habits and vehicle usage, additional or more frequent maintenance may be required.

Periodic maintenance beyond the last period shown on the tables requires similar maintenance.

ENGINE AND EMISSION CONTROL MAINTENANCE

Abbreviations: I = Inspect and correct or replace as necessary, R = Replace, E = Check and correct the engine coolant mixture ratio

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference page
Perform either at number of kilometers (miles) or months, whichever comes first.	km x 1,000 (Miles x 1,000) Months	12 (7.5)	24 (15)	36 (22.5)	48 (30)	60 (37.5)	72 (45)	84 (52.5)	96 (60)	
Engine compartment and under vehicle										
Intake & exhaust valve clearance	See NOTE (1)									EM-10
Drive belts	See NOTE (2)				I				I	MA-18
Engine oil (Use recommended oil.)★		R	R	R	R	R	R	R	R	LU-7
Engine oil filter (Use Genuine NISSAN engine oil filter or equivalent.)★		R	R	R	R	R	R	R	R	MA-24
Engine coolant	See NOTE (3)				E				E	MA-18
Cooling system					I				I	CO-7 MA-21 MA-22
Fuel lines					I				I	MA-22
Air cleaner filter (Viscous paper type)★		Replace every 36,000 km (22,500 miles) or 24 months								MA-22
Fuel filter (In-tank type)	See NOTE (4)									—

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference page
	km x 1,000 (Miles x 1,000) Months	12 (7.5) 6	24 (15) 12	36 (22.5) 18	48 (30) 24	60 (37.5) 30	72 (45) 36	84 (52.5) 42	96 (60) 48	
Perform either at number of kilometers (miles) or months, whichever comes first.										
Spark plugs (Iridium-tipped type)	See NOTE (5)	Replace every 96,000 km (60,000 miles)								MA-25
EVAP vapor lines (With carbon canister)					I				I	MA-26

NOTE:

- Maintenance items with “★” should be performed more frequently according to “Maintenance Under Severe Driving Conditions”.

- (1) Periodic maintenance is not required. However, if valve noise increases, check valve clearance.
- (2) Replace the drive belts if found damaged or if the auto belt tensioner reading reaches the maximum limit.
- (3) Use Genuine NISSAN Engine Coolant (blue) or equivalent in its quality, in order to avoid possible aluminium corrosion within the engine cooling system caused by the use of non-genuine engine coolant. Check and correct the engine coolant mixture ratio every 48,000 km (30,000 miles) or 24 months. First replacement interval is 168,000 km (105,000 miles) or 96 months. After first replacement, replace every 84,000 km (52,500 miles) or 48 months.
- (4) Fuel filter is maintenance-free. For service procedures, refer to FL section.
- (5) Replace spark plug when the plug gap exceeds 1.4 mm (0.055 in) even within specified periodic replacement mileage.

CHASSIS AND BODY MAINTENANCE

Abbreviations: I = Inspect and correct or replace as necessary, R = Replace, L = Lubricate

MAINTENANCE OPERATION		MAINTENANCE INTERVAL								Reference page
	km x 1,000 (Miles x 1,000) Months	12 (7.5) 6	24 (15) 12	36 (22.5) 18	48 (30) 24	60 (37.5) 30	72 (45) 36	84 (52.5) 42	96 (60) 48	
Underhood and under vehicle										
Brake line & cables			I		I		I		I	MA-35
Brake fluid (For level & leaks)			I		I		I		I	MA-35
Brake fluid★					R				R	MA-36
Automatic transmission fluid	NOTE (1)									MA-27
Power steering fluid & lines (For level & leaks)			I		I		I		I	MA-38
Exhaust system					I				I	MA-27
Differential gear oil (For level & leaks)★			I		I		I		I	MA-32
Steering gear & linkage, axle & suspension parts★					I				I	MA-37 MA-38
Outside and inside										
Wheel alignment (If necessary, rotate & balance wheels)			I		I		I		I	FSU-7 FSU-8 RSU-6 MA-33
Brake pads, rotors, drums & linings★			I		I		I		I	MA-36 BR-17 BR-19
Foot brake & parking brake (For free play, stroke & operation)			I		I		I		I	BR-9 PB-5
Air conditioner filter★			R		R		R		R	VTL-17
Stop lamp switch & brake pedal position switch			I		I		I		I	BR-9

NOTE:

PERIODIC MAINTENANCE

< PERIODIC MAINTENANCE >

★ Maintenance items with “★” should be performed more frequently according to “Maintenance Under Severe Driving Conditions”.

- (1) Automatic transmission fluid is maintenance-free.
- (2) Inspect the clearance between the brake pedal and the switches.

MAINTENANCE UNDER SEVERE DRIVING CONDITIONS

The maintenance intervals shown on the preceding pages are for normal operating conditions. If the vehicle is mainly operated under severe driving conditions as shown below, more frequent maintenance must be performed on the following items as shown in the table.

Severe driving conditions

- A — Driving under dusty conditions
- B — Driving repeatedly short distances
- C — Towing a trailer or caravan
- D — Extensive idling
- E — Driving in extremely adverse weather conditions or in areas where ambient temperatures are either extremely low or extremely high
- F — Driving in high humidity or mountainous areas
- G — Driving in areas using salt or other corrosive areas
- H — Driving on rough and/or muddy roads or in the desert
- I — Driving with frequent use of braking or in mountainous areas

Maintenance operation: Inspect = Check and correct or replace as necessary.

Driving condition										Maintenance item	Maintenance operation	Maintenance interval	Reference page
A	Air cleaner filter (Viscous paper type)	Replace	More frequently	MA-22
A	B	C	D	Engine oil & engine oil filter	Replace	Every 6,000 km (3,750 miles) or 3 months	MA-23 MA-24
.	F	Brake fluid	Replace	Every 24,000 km (15,000 miles) or 12 months	MA-36
.	.	C	H	.	Differential gear oil	Replace	Every 36,000 km (22,500 miles) or 24 months	MA-32
.	G	H	.	.	Steering gear & linkage, axle & suspension parts	Inspect	Every 24,000 km (15,000 miles) or 12 months	MA-37 MA-38
A	.	C	.	.	.	G	H	I	.	Brake pads, rotors, drums & linings	Inspect	Every 12,000 km (7,500 miles) or 6 months	MA-36 BR-17 BR-19
A	Air conditioner filter	Replace	More frequently	VTL-17

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O

MA

RECOMMENDED FLUIDS AND LUBRICANTS

< PERIODIC MAINTENANCE >

RECOMMENDED FLUIDS AND LUBRICANTS FOR NORTH AMERICA

FOR NORTH AMERICA : Fluids and Lubricants

INFOID:000000009241061

		Capacity (Approximate)			Recommended Fluids/Lubricants
		US measure	Imp measure	Liter	
Engine oil Drain and refill	With oil filter change	5-1/8 qt	4-1/4 qt	4.9	Genuine NISSAN engine oil or equivalent ^{*1} • Engine oil with API Certification Mark ^{*2} • Viscosity SAE 5W-30 ^{*2}
	Without oil filter change	4-7/8 qt	4 qt	4.6	
Dry engine (Overhaul)		6 qt	5 qt	5.7	
Cooling system	With reservoir tank	11-4/8 qt	9-5/8 qt	10.9	Pre-diluted Genuine NISSAN Long Life Anti-freeze/ Coolant (blue) or equivalent
	Reservoir tank	1 qt	6/8 qt	0.9	
Automatic transmission fluid		9-3/4 qt ^{*9}	8-1/8 qt ^{*9}	9.2 ^{*9}	Genuine NISSAN Matic S ATF ^{*3}
Differential gear oil	Front	1-3/8 pt	1-1/8 pt	0.65	Genuine NISSAN Differential Oil Hypoid Super GL-5 80W-90 or API GL-5, Viscosity SAE 80W-90 ^{*4}
	Rear	2-1/4 pt	1-7/8 pt	1.05	API GL-5 Synthetic gear oil, Viscosity SAE 75W-90 ^{*5}
Transfer fluid		2-1/8 pt	1-3/4 pt	1.0	Genuine NISSAN Matic J ATF ^{*6}
Power steering fluid (PSF) ^{*10}		1-1/8 qt	7/8 qt	1.0	Genuine NISSAN PSF or equivalent ^{*7}
Brake fluid		—	—	—	Genuine NISSAN Super Heavy Duty Brake Fluid ^{*8} or equivalent DOT 3 (US FMVSS No. 116)
Multi-purpose grease		—	—	—	NLGI No. 2 (Lithium soap base)
Windshield washer fluid		—	—	—	Genuine NISSAN Windshield Washer Concentrate Cleaner & Antifreeze or equivalent
Fuel recommendation		—	—	—	Refer to GI-27, "Fuel" .

*1: INFINITI recommends Genuine NISSAN Engine Oil available at an INFINITI retailer.

*2: For additional information, see "Engine Oil Recommendation".

*3: Using automatic transmission fluid other than Genuine NISSAN Matic S ATF will cause deterioration in driveability and automatic transmission durability, and may damage the automatic transmission, which is not covered by the INFINITI new vehicle limited warranty.

*4: For hot climates, viscosity SAE 90 is suitable for ambient temperatures above 32°F (0°C).

*5: See an INFINITI retailer for service for synthetic oil.

*6: Using transfer fluid other than Genuine NISSAN Matic J ATF will cause deterioration in driveability and transfer durability, and may damage the transfer, which is not covered by the INFINITI new vehicle limited warranty.

*7: DEXRON™ VI type ATF may also be used.

*8: Available in mainland U.S.A. through an INFINITI retailer.

*9: The fluid capacity is the reference value.

*10: Without direct adaptive steering models.

FOR NORTH AMERICA : Engine Oil Recommendation

INFOID:000000009241062

NISSAN recommends the use of an energy conserving oil in order to improve fuel economy. Select only engine oils that meet the American Petroleum Institute (API) certification and International Lubricant Standardization and Approval Committee (ILSAC) certification and SAE viscosity standard. These oils have the API certification mark on the front of the container. Oils which do not have the specified quality label should not be used as they could cause engine damage.

RECOMMENDED FLUIDS AND LUBRICANTS

< PERIODIC MAINTENANCE >



① API certification mark

② API service symbol

FOR NORTH AMERICA : Anti-Freeze Coolant Mixture Ratio

INFOID:000000009241063

The engine cooling system is filled at the factory with a pre-diluted mixture of 50% Genuine NISSAN Long Life Antifreeze/Coolant (blue) and 50% water to provide year-round anti-freeze and coolant protection. The anti-freeze solution contains rust and corrosion inhibitors. Additional engine cooling system additives are not necessary.

WARNING:

- Never remove the radiator or coolant reservoir cap when the engine is hot. Wait until the engine and radiator cool down. Serious burns could be caused by high pressure fluid escaping from the radiator.
- The radiator is equipped with a pressure type radiator cap. To prevent engine damage, use only a genuine NISSAN radiator cap.

CAUTION:

- When adding or replacing coolant, be sure to use only Genuine NISSAN Long Life Antifreeze/Coolant (blue) or equivalent. Genuine NISSAN Long Life Antifreeze/Coolant (blue) is pre-diluted to provide antifreeze protection to -34°F (-37°C). If additional freeze protection is needed due to weather where you operate your vehicle, add Genuine NISSAN Long Life Antifreeze/Coolant (blue) concentrate following the directions on the container. If an equivalent coolant other than Genuine NISSAN Long Life Antifreeze/Coolant (blue) is used, follow the coolant manufacturer's instructions to maintain minimum antifreeze protection to -34°F (-37°C). The use of other types of coolant solutions other than Genuine NISSAN Long Life Antifreeze/Coolant (blue) or equivalent may damage the engine cooling system.
- Mixing any other type of coolant other than Genuine NISSAN Long Life Antifreeze/Coolant (blue), including Genuine NISSAN Long Life Antifreeze/Coolant (green), or the use of non-distilled water will reduce the life expectancy of the factory-fill coolant.

FOR MEXICO

FOR MEXICO : Fluids and Lubricants

INFOID:000000009241064

		Capacity (Approximate)		Recommended Fluids/Lubricants
		Liter	Imp measure	
Engine oil Drain and refill	With oil filter change	4.9	4-1/4 qt	Genuine NISSAN engine oil* ¹ API grade SL, SM or SN* ¹ ILSAC grade GF-3, GF-4 or GF-5* ¹ Viscosity SAE 5W-30
	Without oil filter change	4.6	4 qt	
Dry engine (engine overhaul)		5.7	5 qt	
Cooling system	With reservoir tank	10.9	9-5/8 qt	Genuine NISSAN Engine Coolant (blue) or equivalent* ²
	Reservoir tank	0.9	6/8 qt	
Automatic transmission fluid		9.2* ⁴	8-1/8 qt* ⁴	Genuine NISSAN Matic S ATF* ³
Differential gear oil		1.05	1-7/8 pt	Genuine NISSAN Differential Oil Hypoid Super-S GL-5 synthetic 75W-90 or equivalent* ⁵
Power steering fluid (PSF)* ⁷		1.0	7/8 qt	Genuine NISSAN PSF or equivalent* ⁶

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O

MA

RECOMMENDED FLUIDS AND LUBRICANTS

< PERIODIC MAINTENANCE >

	Capacity (Approximate)		Recommended Fluids/Lubricants
	Liter	Imp measure	
Brake fluid	—	—	Genuine NISSAN Brake Fluid, or equivalent DOT 3 (US FMVSS No.116)
Multi-purpose grease	—	—	NLGI No. 2 (Lithium soap base)

*1: For additional information, see "SAE Viscosity Number".

*2: Use Genuine NISSAN Engine Coolant (blue) or equivalent in its quality, in order to avoid possible aluminum corrosion within the engine cooling system caused by the use of non-genuine engine coolant.

Note that any repairs for the incidents within the engine cooling system while using non-genuine engine coolant may not be covered by the warranty even if such incidents occurred during the warranty period.

*3: Using automatic transmission fluid other than Genuine NISSAN Matic S ATF will cause deterioration in driveability and automatic transmission durability, and may damage the automatic transmission, which is not covered by warranty.

*4: The fluid capacity is the reference value.

*5: See an INFINITI dealer for service for synthetic oil.

*6: DEXRON™ VI type ATF may also be used.


*7: Without direct adaptive steering models.

FOR MEXICO : SAE Viscosity Number

INFOID:000000009241065

GASOLINE ENGINE

- 5W-30 is preferable.
If 5W-30 is not available, select the viscosity, from the chart, that is suitable for the outside temperature range.




DIFFERENTIAL GEAR OIL

RECOMMENDED FLUIDS AND LUBRICANTS

< PERIODIC MAINTENANCE >

- 75W-90 for the differential gear is preferable.



JPIIA0001GB

INFOID:000000009241066

FOR MEXICO : Engine Coolant Mixture Ratio

The engine cooling system is filled at the factory with a high-quality, year-round and extended life engine coolant. The high quality engine coolant contains the specific solutions effective for the anti-corrosion and the anti-freeze function. Therefore, additional cooling system additives are not necessary.

CAUTION:

- When adding or replacing coolant, be sure to use only Genuine NISSAN Engine Coolant or equivalent in its quality with the proper mixture ratio. See the examples shown right.

The use of other types of engine coolant may damage the engine cooling system.

- When checking the engine coolant mixture ratio by the coolant hydrometer, use the chart below to correct your hydrometer reading (specific gravity) according to coolant temperature.

Outside temperature down to		Composition	
°C	°F	Engine coolant (Concentrated)	Demineralized water or distilled water
-15	5	30%	70%
-35	-30	50%	50%

SMA089D

Mixed coolant specific gravity

Unit: specific gravity

Engine coolant mixture ratio	Coolant temperature °C (°F)			
	15 (59)	25 (77)	35 (95)	45 (113)
30%	1.046 - 1.050	1.042 - 1.046	1.038 - 1.042	1.033 - 1.038
50%	1.076 - 1.080	1.070 - 1.076	1.065 - 1.071	1.059 - 1.065

WARNING:

Never remove the radiator cap when the engine is hot. Serious burns could be caused by high pressure fluid escaping from the radiator. Wait until the engine and radiator cool down.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O

MA

ENGINE MAINTENANCE


< PERIODIC MAINTENANCE >

ENGINE MAINTENANCE

DRIVE BELT

DRIVE BELT : Exploded View

INFOID:000000009603483



- | | | |
|---|--|-----------------------------|
| ① Power steering oil pump* ¹
Idler pulley* ² | ② Alternator | ③ Drive belt auto-tensioner |
| ④ Idler pulley | ⑤ Crankshaft pulley | ⑥ A/C compressor |
| ⑦ Idler pulley | ⑧ Drive belt | ⑨ Idler pulley |
| Ⓐ Possible use range | Ⓑ Range when new drive belt is installed | Ⓒ Indicator |
| Ⓓ View Ⓓ | | |

- *1: Without DIRECT ADAPTIVE STEERING
- *2: With DIRECT ADAPTIVE STEERING

DRIVE BELT : Checking

INFOID:000000009603484

WARNING:

Be sure to perform this step when engine is stopped.

- Check that the indicator Ⓒ (notch on fixed side) of drive belt auto-tensioner is within the possible use range Ⓐ.

NOTE:

- Check the drive belt auto-tensioner indication when the engine is cold.
- When new drive belt is installed, the indicator (notch on fixed side) should be within the range Ⓑ in the figure.
- Visually check the entire drive belt for wear, damage or crack.
- If the indicator (notch on fixed side) is out of the possible use range or belt is damaged, replace drive belt.

DRIVE BELT : Tension Adjustment

INFOID:000000009603485

Refer to [EM-152, "Drive Belt"](#).

ENGINE COOLANT

ENGINE COOLANT : Draining

INFOID:000000009603496

WARNING:

- To avoid being scalded, never change engine coolant when the engine is hot.

ENGINE MAINTENANCE


< PERIODIC MAINTENANCE >

- Wrap a thick cloth around reservoir tank cap and carefully remove reservoir tank cap. First, turn reservoir tank cap a quarter of a turn to release built-up pressure. Then turn reservoir tank cap all the way.
 - Never spill engine coolant on drive belt.
1. Remove front under cover. Refer to [EXT-32, "FRONT UNDER COVER : Exploded View"](#).
 2. Connect drain hose.

NOTE:


Use a general-purpose hose with the dimensions shown in the figure.

- A : ϕ 8 - 9 mm (0.31 - 0.35 in)
B : 145 mm (5.71 in)



3. Open radiator drain cock ① at the bottom of radiator, and then remove reservoir tank cap.

- ② : Drain hose
← : Vehicle front



When draining all of engine coolant in the system, open water drain plugs on cylinder block. Refer to [EM-87, "Setting"](#).

4. Check drained engine coolant for contaminants such as rust, corrosion or discoloration. If contaminated, flush the engine cooling system. Refer to [CO-9, "Flushing"](#).
5. Disconnect drain hose.

ENGINE COOLANT : Refilling

INFOID:000000009603497

CAUTION:

- Do not reuse O-rings.
- Do not put additive such as waterleak preventive, since it may cause cooling waterway clogging.
- When refilling use Genuine NISSAN Long Life Antifreeze/Coolant (blue) or equivalent in its quality mixed with water (distilled or demineralized). Refer to [MA-14, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (FOR NORTH AMERICA), [MA-15, "FOR MEXICO : Fluids and Lubricants"](#) (FOR MEXICO).

1. Remove air duct (inlet). Refer to [EM-29, "Exploded View"](#).
2. Install reservoir tank if removed, and radiator drain cock.

CAUTION:

Be sure to clean drain cock and install with new O-ring.

Tightening torque : Refer to [CO-13, "Exploded View"](#).

If water drain plugs on cylinder block are removed, close and tighten them. Refer to [EM-129, "Disassembly and Assembly"](#).

3. Check that each hose clamp has been firmly tightened.

ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >


4. Fill up the engine cooling system with engine coolant.

- Ⓐ : MAX
- Ⓑ : MIN

Pour engine coolant through reservoir tank filler neck slowly of less than 3 ℓ (3-1/8 US qt, 2-5/8 Imp qt) a minute to allow air in system to escape.

Engine coolant capacity (With reservoir tank at "MAX" level) : Refer to [CO-26, "Periodical Maintenance Specification"](#).

Reservoir tank engine coolant capacity (At "MAX" level) : Refer to [CO-26, "Periodical Maintenance Specification"](#)



5. Install reservoir tank cap.
 6. Start engine, and stop at once.
 7. Leave engine for about 10sec. Then check the coolant level at the reservoir tank.
 8. Refill reservoir tank to "MAX" level line with engine coolant.
 9. Repeat step 5 through 8 until engine coolant level no longer drops.
 10. Install reservoir tank cap.
 11. Warm up engine until opening thermostat. Standard for warming-up time is approximately 10 minutes at 2,000 rpm.
 - Check thermostat opening condition by touching radiator hose (lower) to see a flow of warm water.
- CAUTION:**
Watch water temperature gauge so as not to overheat engine.
12. Stop the engine and cool down to less than approximately 50°C (122°F).
 - Cool down using fan to reduce the time.
 - Check the engine coolant level. If the level is low, refill with engine coolant and repeat the steps from Step 4.
 13. Refill reservoir tank to "MAX" level line with engine coolant.
 14. Check cooling system for leakage with engine running.
 15. Check flow noise, according to the following steps.

CAUTION:
To check flow noise, turn OFF the radio and close the windows, doors, and the hood.

 - a. Allow the engine to become cold [approximately 50°C (122°F) or less].
 - b. Start the engine, maintain 1000 rpm for approximately 30 seconds, and increase the engine speed from 1000 to 3000 rpm. Repeat this cycle three times.
 - c. Check that flow noise can be heard from the heater core during the Step b operation.
 - d. If flow noise can be heard, repeat from Step 15 of Refilling to Step c of Flow Noise Verification Method.
 - e. Check that the reservoir tank cap is tightened.
 16. Install air duct (inlet). Refer to [EM-29, "Exploded View"](#).

ENGINE COOLANT : Flushing

INFOID:000000009603498

1. Install reservoir tank if removed, and radiator drain cock.

CAUTION:
Be sure to clean drain cock and install with new O-ring.

Tightening torque : Refer to [CO-13, "Exploded View"](#).

If water drain plugs on cylinder block are removed, close and tighten them. Refer to [EM-87, "Setting"](#).

2. Fill radiator and reservoir tank with water and reinstall reservoir tank cap.

ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >

Tightening torque : Refer to [CO-13. "Exploded View"](#).

3. Run the engine and warm it up to normal operating temperature.
4. Rev the engine two or three times under no-load.
5. Stop the engine and wait until it cools down.
6. Drain water from the system. Refer to [CO-7. "Draining"](#).
7. Repeat steps 1 through 6 until clear water begins to drain from radiator.
8. Check that the reservoir tank cap is tightened.

RESERVOIR TANK CAP


RESERVOIR TANK CAP : Inspection

INFOID:000000009603494


- Check valve seat (A) of reservoir tank cap.

(B) : Metal plunger

- Check if valve seat is swollen to the extent that the edge of the plunger (B) cannot be seen when watching it vertically from the top.
- Check if valve seat has no soil and damage.




- Pull negative-pressure valve to open it, and check that it close completely when released.
- Check that there is no dirt or damage on the valve seat of reservoir tank cap negative-pressure valve.
- Check that there are no unusualness in the opening and closing conditions of negative-pressure valve.



- Check reservoir tank cap relief pressure.

Standard and limit : Refer to [CO-26. "Radiator"](#).

- When connecting reservoir tank cap to the radiator cap tester and the radiator cap tester adapter (commercial service tool) (A), apply engine coolant to the cap seal surface.



- Replace reservoir tank cap if there is an unusualness related to the above three.

CAUTION:

When installing reservoir tank cap, thoroughly wipe out the reservoir tank to remove any waxy residue or foreign material.

RADIATOR

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
MA

ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >

RADIATOR : Inspection

INFOID:000000009603495

Check radiator for mud or clogging. If necessary, clean radiator as follows:

- Be careful not to bend or damage radiator fins.
 - When radiator is cleaned without removal, remove all surrounding parts such as radiator cooling fan assembly and horns. Then tape harness and connectors to prevent water from entering.
1. Apply water by hose to the back side of the radiator core vertically downward.
 2. Apply water again to all radiator core surfaces once per minute.
 3. Stop washing if any stains no longer flow out from radiator.
 4. Blow air into the back side of radiator core vertically downward.
 - Use compressed air lower than 490 kPa (5 kg/cm², 71 psi) and keep distance more than 30 cm (11.8 in).
 5. Blow air again into all the radiator core surfaces once per minute until no water sprays out.

FUEL LINES


FUEL LINES : Inspection

INFOID:000000009603499

Inspect fuel lines, fuel filler cap and fuel tank for improper attachment, leakage, cracks, damage, loose connections, chafing or deterioration.

- Ⓐ : Engine
- Ⓑ : Fuel line
- Ⓒ : Fuel tank

If necessary, repair or replace damaged parts.




AIR CLEANER FILTER

AIR CLEANER FILTER : Removal and Installation


INFOID:000000009603486

REMOVAL

1. Remove air duct (inlet).
2. Unhook clips Ⓐ.



3. Lift up air cleaner cover ①, and remove air cleaner filter ②.



ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >


INSTALLATION

Note the following, and install in the reverse order of removal.

- Install the air cleaner filter by aligning the seal with the notch of air cleaner body.
- Insert the pawl ③ of air cleaner cover ① into air cleaner body ② and fix with clip.

Ⓐ : Before installation

Ⓑ : After installation



AIR CLEANER FILTER : Inspection (Viscous Paper Type)

INFOID:000000009759969

INSPECTION AFTER REMOVAL

Examine with eyes that there is no stain, clogging, or damage on air cleaner element.

- Remove dusts (such as dead leaves) on air cleaner element surface and inside cleaner case.
- If clogging or damage is observed, replace the air cleaner element.

CAUTION:

Never clean the viscous paper type air cleaner element by blowing as there is a risk of deterioration of its performance

MAINTENANCE INTERVAL

Refer to [MA-8, "FOR NORTH AMERICA : Introduction of Periodic Maintenance"](#) (For North America) or [MA-11, "FOR MEXICO : Introduction of Periodic Maintenance"](#) (For Mexico).

ENGINE OIL

ENGINE OIL : Draining

INFOID:000000009603490

WARNING:

- **Never get burn yourself, as engine oil may be hot.**
- **Prolonged and repeated contact with used engine oil may cause skin cancer. Try to avoid direct skin contact with used engine oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.**

1. Warm up the engine, and check for engine oil leakage from engine components. Refer to [LU-7, "Inspection"](#).
2. Stop the engine and wait for 10 minutes.
3. Loosen oil filler cap.
4. Remove bolts of front under cover rear side. (2WD models)
5. Fold the rear side of the front under cover forward, and fix it using a clip. (2WD models)
6. Remove drain plug and then drain engine oil.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O

ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >

ENGINE OIL : Refilling

INFOID:000000009603491

1. Install drain plug with new washer. Refer to [EM-46, "2WD : Exploded View"](#) (2WD) or [EM-47, "AWD : Exploded View"](#) (AWD).

CAUTION:

Be sure to clean drain plug and install with new washer.

2. Refill with new engine oil.
Engine oil specification and viscosity: Refer to [MA-14, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (FOR NORTH AMERICA) or [MA-15, "FOR MEXICO : Fluids and Lubricants"](#) (FOR MEXICO).

Engine oil capacity : Refer to [LU-22, "Periodical Maintenance Specification"](#).

CAUTION:

- When filling engine oil, do not pull out oil level gauge.
 - The refill capacity depends on the engine oil temperature and drain time. Use these specifications for reference only.
 - Always use oil level gauge to determine the proper amount of engine oil in engine.
3. Warm up the engine and check area around drain plug and oil filter for engine oil leakage.
 4. Stop the engine and wait for 10 minutes.
 5. Check the engine oil level. Refer to [LU-7, "Inspection"](#).

OIL FILTER

OIL FILTER : Removal and Installation

INFOID:000000009603492

REMOVAL

CAUTION:


- Oil filter is provided with relief valve. Use genuine NISSAN oil filter or equivalent.
- Never get burned when engine and engine oil may be hot.
- When removing, prepare a shop cloth to absorb any engine oil leakage or spillage.
- Never allow engine oil to adhere to drive belt.
- Completely wipe off any engine oil that adheres to engine and vehicle.

2WD models

1. Remove bolts of front under cover rear side.
2. Fold the rear side of the front under cover forward, and fix it using a clip.
3. Using oil filter wrench [SST: KV10115801 (J-38956)] (B), remove oil filter.

Ⓐ : The figure shows front under cover removed.

↔ : Engine front



AWD models


1. Remove front under cover, using a power tool. Refer to [EXT-32, "FRONT UNDER COVER : Exploded View"](#).

ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >


- Using oil filter wrench [SST: KV10115801 (J-38956)] (B), remove oil filter.

- Ⓐ : The figure shows front under cover removed.
⇐ : Engine front



INSTALLATION


- Remove foreign materials adhering to oil filter installation surface.
- Apply engine oil to the oil seal contact surface of new oil filter.



- Screw oil filter manually until it touches the installation surface, then tighten it by 2/3 turn Ⓐ. Or tighten to the specification.

Oil filter:

: 17.7 N·m (1.8 kg·m, 13 ft·lb)



OIL FILTER : Inspection

INFOID:000000009603493

INSPECTION AFTER INSTALLATION

- Check the engine oil level. Refer to [LU-7, "Inspection"](#).
- Start the engine, and check there is no leak of engine oil.
- Stop the engine and wait for 10 minutes.
- Check the engine oil level, and adjust the level. Refer to [LU-7, "Inspection"](#).

SPARK PLUG

SPARK PLUG : Removal and Installation

INFOID:000000009603488

REMOVAL

- Remove engine cover, using a power tool. Refer to [EM-26, "Exploded View"](#).
- Remove air cleaner assembly and air duct (bank 1 and bank 2). Refer to [EM-29, "Exploded View"](#).
- Remove electric throttle control actuator. Refer to [EM-31, "Exploded View"](#).
- Remove ignition coil. Refer to [EM-50, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O


MA

ENGINE MAINTENANCE

< PERIODIC MAINTENANCE >

5. Remove spark plug with a spark plug wrench (commercial service tool).

(a) : 14 mm (0.55 in)



INSTALLATION

Installation is the reverse order of removal.

SPARK PLUG : Inspection

INFOID:000000009603489

INSPECTION AFTER REMOVAL

Use the standard type spark plug for normal condition.

Spark plug (Standard type) : Refer to [EM-152, "Spark Plug"](#).

CAUTION:


- Never drop or shock spark plug.
- Never use a wire brush for cleaning.
- If plug tip is covered with carbon, use spark plug cleaner to clean.

Cleaner air pressure


: Less than 588 kPa (6 kg/cm², 85 psi)

Cleaning time

: Less than 20 seconds



- Check and adjustment of plug gap is not required between change intervals.



EVAP VAPOR LINES

EVAP VAPOR LINES : Inspection

INFOID:000000009241083

1. Visually inspect EVAP vapor lines for improper attachment and for cracks, damage, loose connections, chafing and deterioration. Refer to [EC-574, "FOR NORTH AMERICA : Inspection"](#) (For USA and Canada).
2. Inspect fuel tank filler cap vacuum relief valve for clogging, sticking, etc.
Refer to [EC-374, "Component Inspection"](#) (For USA and Canada), [EC-575, "FOR MEXICO : Inspection"](#) (For Mexico).

CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >

CHASSIS MAINTENANCE


EXHAUST SYSTEM

EXHAUST SYSTEM : Inspection

INFOID:000000009603517

Check exhaust pipes, muffler and mounting for improper attachment, leaks, cracks, damage or deterioration.

- If anything is found, repair or replace damaged parts.




A/T FLUID

A/T FLUID : Inspection

INFOID:000000009603518

FLUID LEAKAGE

- Check transaxle surrounding area (oil seal and plug etc.) for fluid leakage.
- If anything is found, repair or replace damaged parts and adjust A/T fluid level. Refer to [TM-207. "Adjustment"](#).



A/T FLUID : Changing

INFOID:000000009697244


Recommended fluid and fluid capacity : Refer to [MA-14. "FOR NORTH AMERICA : Fluids and Lubricants"](#) (For North America), [MA-15. "FOR MEXICO : Fluids and Lubricants"](#) (For Mexico).

CAUTION:

- Use only recommended ATF. Never mix with other ATF.
- Using ATF other than recommended ATF will cause deterioration in driveability and A/T durability, and may damage the A/T, which is not covered by the INFINITI new vehicle limited warranty.
- When filling ATF, be careful not to scatter heat generating parts such as exhaust.

1. Step 1

- a. Install the O-ring (315268E000) (A) to the charging pipe (310811EA5A) (B).



2. Step 2

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O

MA

CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >

- a. Use CONSULT to check that the ATF temperature is 40°C (104°F) or less.
- b. Lift up the vehicle.
- c. Remove the drain plug from the oil pan, and then drain the ATF.
- d. When the ATF starts to drip, temporarily tighten the drain plug to the oil pan.

NOTE:

Never replace drain plug and drain plug gasket with new ones yet.

- e. Remove overflow plug from oil pan.
- f. Install the charging pipe (A) to the overflow plug hole.

CAUTION:

Tighten the charging pipe by hand.

- g. Install the bucket pump hose (B) to the charging pipe.

CAUTION:

Insert the bucket pump hose all the way to the end of the charging pipe.

- h. Fill approximately 3 liters (3-1/8 US qt, 2-5/8 Imp qt) of the ATF.
- i. Remove the bucket pump hose to remove the charging pipe, and then temporarily tighten the overflow plug to the oil pan.

CAUTION:

Quickly perform the procedure to avoid ATF leakage from the oil pan.

- j. Lift down the vehicle.
- k. Start the engine and wait for approximately 3 minutes.
- l. Stop the engine.

3. Step 3

- a. Repeat "Step 2".

4. Final Step

- a. Use CONSULT to check that the ATF temperature is 40°C (104°F) or less.

- b. Lift up the vehicle.

- c. Remove the drain plug from the oil pan, and then drain the ATF.

- d. When the ATF starts to drip, tighten the drain plug to the oil pan to the specified torque. Refer to [TM-218, "Exploded View"](#).

CAUTION:

Never reuse drain plug and drain plug gasket.

- e. Remove overflow plug from oil pan.

- f. Install the charging pipe (A) to the overflow plug hole.

CAUTION:

Tighten the charging pipe by hand.

- g. Install the bucket pump hose (B) to the charging pipe.

CAUTION:

Insert the bucket pump hose all the way to the end of the charging pipe.

- h. Fill approximately 3 liters (3-1/8 US qt, 2-5/8 Imp qt) of the ATF.
- i. Remove the bucket pump hose to remove the charging pipe, and then temporarily tighten the overflow plug to the oil pan.

CAUTION:



Quickly perform the procedure to avoid ATF leakage from the oil pan.

- j. Lift down the vehicle.
- k. Start the engine.
- l. Make the ATF temperature approximately 40°C (104°F).

NOTE:

The ATF level is greatly affected by the temperature. Always check the ATF temperature on "ATF TEMP 1" of "Data Monitor" using CONSULT.

- m. Park vehicle on level surface and set parking brake.



CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >

- n. Shift the selector lever through each gear position. Leave selector lever in "P" position.
- o. Lift up the vehicle when the ATF temperature reaches 40°C (104°F), and remove the overflow plug from the oil pan.
- p. When the ATF starts to drip, tighten the overflow plug to the oil pan to the specified torque. Refer to [TM-218, "Exploded View"](#).

CAUTION:

Never reuse overflow plug.

A/T FLUID : Adjustment

INFOID:000000009697245

Recommended fluid and fluid capacity : Refer to [MA-14, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (For North America), [MA-15, "FOR MEXICO : Fluids and Lubricants"](#) (For Mexico).

CAUTION:

- Use only recommended ATF. Never mix with other ATF.
- Using ATF other than recommended ATF will cause deterioration in driveability and A/T durability, and may damage the A/T, which is not covered by the INFINITI new vehicle limited warranty.
- When filling ATF, be careful not to scatter heat generating parts such as exhaust.
- Always maintain the ATF temperature within between 35°C (95°F) and 45°C (113°F) while checking with CONSULT when the ATF level adjustment is performed.

1. Install the O-ring (315268E000) (A) to the charging pipe (310811EA5A) (B).
2. Start the engine.
3. Make the ATF temperature approximately 40°C (104°F).

NOTE:

The ATF level is greatly affected by the temperature. Always check the ATF temperature on "ATF TEMP 1" of "Data Monitor" using CONSULT.

4. Park vehicle on level surface and set parking brake.
5. Shift the selector lever through each gear position. Leave selector lever in "P" position.
6. Lift up the vehicle.
7. Check the ATF leakage from transmission.
8. Remove overflow plug from oil pan.
9. Install the charging pipe (A) to the overflow plug hole.

CAUTION:

Tighten the charging pipe by hand.

10. Install the bucket pump hose (B) to the charging pipe.

CAUTION:

Insert the bucket pump hose all the way to the end of the charging pipe.

11. Fill approximately 0.5 liters (1/2 US qt, 1/2 Imp qt) of the ATF.
12. Check that the ATF leaks when removing the charging pipe and the bucket pump hose. If the ATF does not leak, refill the ATF.
13. When the ATF starts to drip, tighten the overflow plug to the oil pan to the specified torque. Refer to [TM-218, "Exploded View"](#).

CAUTION:

Never reuse overflow plug.

TRANSFER FLUID



TRANSFER FLUID : Inspection

INFOID:000000009697228

FLUID LEAKAGE

Check transfer surrounding area (oil seal, drain plug, and filler plug etc.) for fluid leakage.

FLUID LEVEL




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O

MA

CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >


1. Remove filler plug ① and gasket. Then check that fluid is filled up from mounting hole for the filler plug.
CAUTION:
Never start engine while checking fluid level.
2. Set a new gasket onto filler plug, and install it on transfer and tighten to the specified torque. Refer to [DLN-64. "Exploded View"](#).
CAUTION:
Never reuse gasket.



INFOID:000000009697229

TRANSFER FLUID : Draining

1. Run the vehicle to warm up the transfer unit sufficiently.
2. Stop the engine, and remove the drain plug ① to drain the transfer fluid.
3. Set a new gasket onto drain plug, and install it on the transfer and tighten to the specified torque. Refer to [DLN-64. "Exploded View"](#).
CAUTION:
Never reuse gasket.



INFOID:000000009697230


TRANSFER FLUID : Refilling

1. Remove filler plug ① and gasket. Then fill fluid up to mounting hole for the filler plug.

Recommended fluid and capacity : Refer to [MA-14, "FOR NORTH AMERICA : Fluids and Lubricants"](#).

CAUTION:
Carefully fill the fluid. (Fill up for approximately 3 minutes.)

2. Leave the vehicle for 3 minutes, and check the fluid level again.
3. Set a new gasket onto filler plug, and install it on transfer and tighten to the specified torque. Refer to [DLN-64. "Exploded View"](#).
CAUTION:
Never reuse gasket.



FRONT PROPELLER SHAFT: 2S56A

FRONT PROPELLER SHAFT: 2S56A : Inspection

INFOID:000000009697231

APPEARANCE AND NOISE

Check the propeller shaft tube surface for dents or cracks. If malfunction is detected, replace propeller shaft assembly.

VIBRATION

If vibration is present at high speed, adjust the propeller shaft phase first.

1. Check the propeller shaft for bend and damage. If damaged, replace propeller shaft assembly.
2. Perform a cruise test drive to check the propeller shaft for runout. If vibration occurs, separate propeller shaft at final drive companion flange; then change the phase between companion flange and propeller shaft by the one bolt hole at a time and install propeller shaft.

CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >

3. If vibration is still detected, measure propeller shaft runout after removing it. Refer to [DLN-89, "Inspection"](#).

REAR PROPELLER SHAFT: 3S80A-R

REAR PROPELLER SHAFT: 3S80A-R : Inspection

INFOID:000000009697232


APPEARANCE AND NOISE

- Check the propeller shaft tube surface for dents or cracks. If malfunction is detected, replace propeller shaft assembly.
- If center bearing is noisy or damaged, replace propeller shaft assembly.

VIBRATION

If vibration is present at high speed, adjust the propeller shaft phase first.

1. Check the propeller shaft for bend and damage. If damaged, replace propeller shaft assembly.
2. If the alignment mark **(A)** of the propeller shaft **(1)** and the alignment mark **(B)** of the companion flanges on the final drive are not on an axis, re-install these parts to a closer position as possible.
3. Perform a cruise test drive to check the propeller shaft for runout after installation. If vibration still occurs, separate propeller shaft at final drive companion flange; then change the phase between companion flange and propeller shaft by the one bolt hole at a time and install propeller shaft.
4. If vibration is still detected, measure propeller shaft runout after removing it. Refer to [DLN-100, "Inspection"](#).



REAR PROPELLER SHAFT: 3F80A-R

REAR PROPELLER SHAFT: 3F80A-R : Inspection

INFOID:000000009697233


APPEARANCE AND NOISE

- Check the propeller shaft tube surface for dents or cracks. If malfunction is detected, replace propeller shaft assembly.
- If center bearing is noisy or damaged, replace propeller shaft assembly.

VIBRATION

If vibration is present at high speed, adjust the propeller shaft phase first.

1. Check the propeller shaft for bend and damage. If damaged, replace propeller shaft assembly.
2. If the alignment mark **(A)** of the propeller shaft **(1)** and the alignment mark **(B)** of the companion flanges on the final drive are not on an axis, re-install these parts to a closer position as possible.
3. Perform a cruise test drive to check the propeller shaft for runout after installation. If vibration still occurs, separate propeller shaft at final drive companion flange; then change the phase between companion flange and propeller shaft by the one bolt hole at a time and install propeller shaft.
4. If vibration is still detected, measure propeller shaft runout after removing it. Refer to [DLN-111, "Inspection"](#).



FRONT DIFFERENTIAL GEAR OIL: F160A

FRONT DIFFERENTIAL GEAR OIL: F160A : Inspection

INFOID:000000009697234

OIL LEAKAGE

Make sure that oil is not leaking from final drive assembly or around it.

OIL LEVEL

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O

MA

CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >

- Remove filler plug ① and check oil level from filler plug mounting hole as shown in the figure.


CAUTION:

Never start engine while checking oil level.

- Set a gasket on filler plug and install it on final drive assembly. Refer to [DLN-131, "Exploded View"](#).

CAUTION:

Never reuse gasket.




FRONT DIFFERENTIAL GEAR OIL: F160A : Draining

INFOID:000000009697235

1. Stop engine.
2. Remove drain plug ① and drain gear oil.
3. Set a gasket on drain plug and install it to final drive assembly and tighten to the specified torque. Refer to [DLN-131, "Exploded View"](#).

CAUTION:

Never reuse gasket.



FRONT DIFFERENTIAL GEAR OIL: F160A : Refilling

INFOID:000000009697236


1. Remove filler plug ①. Fill with new gear oil until oil level reaches the specified level near filler plug mounting hole.

Recommended oil and capacity : Refer to [MA-14, "FOR NORTH AMERICA : Fluids and Lubricants"](#).

2. After refilling oil, check oil level. Set a gasket to filler plug, then install it to final drive assembly. Refer to [DLN-131, "Exploded View"](#).

CAUTION:

Never reuse gasket.



REAR DIFFERENTIAL GEAR OIL: R190

REAR DIFFERENTIAL GEAR OIL: R190 : Inspection

INFOID:000000009697237

OIL LEAKAGE

Make sure that oil is not leaking from final drive assembly or around it.

OIL LEVEL

- Remove filler plug ① and check oil level from filler plug mounting hole as shown in the figure.


CAUTION:

Never start engine while checking oil level.

- Set a gasket on filler plug and install it on final drive assembly. Refer to [DLN-169, "Exploded View"](#).

CAUTION:

Never reuse gasket.



CHASSIS MAINTENANCE


< PERIODIC MAINTENANCE >

REAR DIFFERENTIAL GEAR OIL: R190 : Draining

INFOID:000000009697238

1. Stop engine.
2. Remove drain plug ① and drain gear oil.
3. Set a gasket on drain plug and install it to final drive assembly and tighten to the specified torque. Refer to [DLN-169, "Exploded View"](#).

CAUTION:
Never reuse gasket.



REAR DIFFERENTIAL GEAR OIL: R190 : Refilling


INFOID:000000009697239

1. Remove filler plug ①. Fill with new gear oil until oil level reaches the specified level near filler plug mounting hole.

Recommended oil and capacity : Refer to [MA-14, "FOR NORTH AMERICA : Fluids and Lubricants" \(For North America\)](#), [MA-15, "FOR MEXICO : Fluids and Lubricants" \(For Mexico\)](#).

2. After refilling oil, check oil level. Set a gasket to filler plug, then install it to final drive assembly. Refer to [DLN-169, "Exploded View"](#).

CAUTION:
Never reuse gasket.



WHEELS (BONDING WEIGHT TYPE)

WHEELS (BONDING WEIGHT TYPE) : Wheel Balance Adjustment (Aluminum Wheel)

INFOID:000000009697240

PREPARATION BEFORE ADJUSTMENT

Using releasing agent, remove double-faced adhesive tape from the road wheel.

CAUTION:

- Be careful not to scratch the road wheel during removal.
- After removing double-faced adhesive tape, wipe clean traces of releasing agent from the road wheel.

ADJUSTMENT

- The details of the adjustment procedure are different for each model of wheel balancer. Therefore, refer to each instruction manual.
- If a tire balance machine has adhesion balance weight mode settings and drive-in weight mode setting, select and adjust a drive-in weight mode suitable for aluminum wheels.

1. Set road wheel on tire balance machine using the center hole as a guide. Start the tire balance machine.
2. When inner and outer unbalance values are shown on the tire balance machine indicator, multiply outer unbalance value by 5/3 to determine balance weight that should be used. Select the outer balance weight with a value closest to the calculated value above and install to the designated outer position of, or at the designated angle in relation to the road wheel.

CAUTION:

- Never install the inner balance weight before installing the outer balance weight.
- Before installing the balance weight, always to clean the mating surface of the road wheel.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O

MA

CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >

- a. Indicated unbalance value $\times 5/3 =$ balance weight to be installed

Calculation example:

23 g (0.81 oz) $\times 5/3 = 38.33$ g (1.35 oz) \Rightarrow 40 g (1.41 oz) balance weight (closer to calculated balance weight value)


NOTE:

Note that balance weight value must be closer to the calculated balance weight value.

Example:

37.4 \Rightarrow 35 g (1.23 oz)

37.5 \Rightarrow 40 g (1.41 oz)




- b. Installed balance weight in the position.

- When installing balance weight ① to road wheels, set it into the grooved area ① on the inner wall of the road wheel as shown in the figure so that the balance weight center ② is aligned with the tire balance machine indication position (angle) ③.

CAUTION:


- Always use genuine NISSAN balance weights.
- Balance weights are non-reusable; always replace with new ones.
- Never install three or more sheets of balance weight.



- c. If calculated balance weight value exceeds 50 g (1.76 oz), install two balance weight sheets in line with each other as shown in the figure.

CAUTION:

Never install one balance weight sheet on top of another.



3. Start the tire balance machine again.
4. Install drive-in balance weight on inner side of road wheel in the tire balance machine indication position (angle).

CAUTION:

Never install three or more balance weight.

5. Start the tire balance machine. Check that the inner and outer residual unbalance value is within the allowable unbalance value.

CAUTION:

If either residual unbalance value exceeds limit, repeat installation procedures.

CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >

Allowable unbalance value

Dynamic (At flange) : Refer to [WT-68, "Road Wheel"](#).

Static (At flange) : Refer to [WT-68, "Road Wheel"](#).

WHEELS (BONDING WEIGHT TYPE) : Tire Rotation


INFOID:000000009697241

- Follow the maintenance schedule for tire rotation service intervals. Refer to [MA-4, "FOR NORTH AMERICA : Explanation of General Maintenance"](#).

- When installing the wheel, tighten wheel nuts to the specified torque. Refer to [WT-62, "Exploded View"](#).

CAUTION:

- When installing wheels, tighten them diagonally by dividing the work two to three times in order to prevent the wheels from developing any distortion.
- Be careful not to tighten wheel nut at torque exceeding the criteria.
- Use NISSAN genuine wheel nut.




BRAKE FLUID LEVEL AND LEAKS

BRAKE FLUID LEVEL AND LEAKS : Inspection

INFOID:000000009241119

- If fluid level is extremely low, check brake system for leaks.




BRAKE LINES AND CABLES

BRAKE LINES AND CABLES : Inspection

INFOID:000000009241120

- Check brake fluid lines and parking brake cables for improper attachment, leaks, chafing, abrasions, deterioration, etc.



BRAKE FLUID

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
MA


CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >

BRAKE FLUID : Changing

INFOID:000000009241121

1. Drain brake fluid from each bleed valve.
2. Refill until new brake fluid comes out from each bleed valve. Use same procedure as in bleeding hydraulic system to refill brake fluid.
Refer to [BR-14, "Bleeding Brake System"](#).
 - Refill with recommended Genuine NISSAN Super Heavy Duty Brake Fluid or equivalent DOT 3 (US FMVSS No. 116). Refer to [MA-14, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (For North America), [MA-15, "FOR MEXICO : Fluids and Lubricants"](#) (For Mexico).
 - Never reuse drained brake fluid.
 - Be careful not to splash brake fluid on painted areas.



DISC BRAKE

DISC BRAKE : Inspection


INFOID:000000009241122

DISC ROTOR

Check condition, wear, and damage.


CALIPER

- Check for leakage.



BRAKE PAD

- Check for wear or damage.



DISC BRAKE : Front Disc Brake

INFOID:000000009697242

BRAKE CALIPER 2 PISTON TYPE

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	1.5 (0.059)
	Wear thickness	26.0 (1.024)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.035 (0.0014)

CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >

BRAKE CALIPER 4 PISTON TYPE

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	2.0 (0.079)
	Wear thickness	30.0 (1.181)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.035 (0.0014)

DISC BRAKE : Rear Disc Brake

INFOID:000000009697243

BRAKE CALIPER 1 PISTON TYPE

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	2.0 (0.079)
	Wear thickness	14.0 (0.551)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.055 (0.0022)

BRAKE CALIPER 2 PISTON TYPE

Unit: mm (in)

Item		Limit
Brake pad	Wear thickness	2.0 (0.079)
	Wear thickness	18.0 (0.709)
Disc rotor	Thickness variation (measured at 8 positions)	0.015 (0.0006)
	Runout (with it attached to the vehicle)	0.055 (0.0022)


STEERING GEAR AND LINKAGE

STEERING GEAR AND LINKAGE : Inspection

INFOID:000000009241125

STEERING GEAR

- Check gear housing and boots for looseness, damage and grease leakage.
- Check connection with steering column for looseness.



STEERING LINKAGE

Check ball joint, dust cover and other component parts for looseness, wear, damage and grease leakage.

POWER STEERING FLUID AND LINES

MA

CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >

POWER STEERING FLUID AND LINES : Inspection


INFOID:000000009715255

Check fluid level in reservoir tank with engine off.


Use "HOT" range at fluid temperatures of 50 to 80°C (122 to 176°F) or "COLD" range at fluid temperatures of 0 to 30°C (32 to 86°F).

CAUTION:

- Do not overfill.
- Recommended fluid is Genuine NISSAN PSF or equivalent. Refer to [MA-14, "FOR NORTH AMERICA : Fluids and Lubricants"](#) (For North America), [MA-15, "FOR MEXICO : Fluids and Lubricants"](#) (For Mexico).



- Check lines for improper attachment, leaks, cracks, damage, loose connections, chafing and deterioration.
- Check rack boots for accumulation of power steering fluid.





AXLE AND SUSPENSION PARTS

AXLE AND SUSPENSION PARTS : Inspection

INFOID:000000009241127

Check front and rear axle and suspension parts for excessive play, cracks, wear or other damage.

- Shake each wheel to check for excessive play.
- Check wheel bearings for smooth operation.
- Check axle and suspension nuts and bolts for looseness.
- Check strut (shock absorber) for oil leakage or other damage.
- Check suspension ball joint for grease leakage and ball joint dust cover for cracks or other damage.



DRIVE SHAFT


CHASSIS MAINTENANCE

< PERIODIC MAINTENANCE >

DRIVE SHAFT : Inspection

INFOID:000000009241128

Check boot and drive shaft for cracks, wear, damage and grease leakage.



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O

MA

BODY MAINTENANCE

< PERIODIC MAINTENANCE >

BODY MAINTENANCE

LOCKS, HINGES AND HOOD LATCH

LOCKS, HINGES AND HOOD LATCH : Lubricating

INFOID:000000009241129

For hood and hood lock control illustration.

- Hood: Refer to [DLK-175, "Exploded View"](#).
- Hood lock control: Refer to [DLK-215, "Exploded View"](#).

For door and door lock illustration.

- Front door: Refer to [DLK-191, "Exploded View"](#).
- Front door lock: Refer to [DLK-223, "Exploded View"](#).
- Rear door: Refer to [DLK-199, "Exploded View"](#).
- Rear door lock: Refer to [DLK-228, "Exploded View"](#).

For trunk lid and trunk lid lock illustration.

- Trunk lid: Refer to [DLK-208, "Exploded View"](#).
- Trunk lid lock: Refer to [DLK-232, "Exploded View"](#).

SEAT BELT, BUCKLES, RETRACTORS, ANCHORS AND ADJUSTERS

SEAT BELT, BUCKLES, RETRACTORS, ANCHORS AND ADJUSTERS : Inspection

INFOID:000000009241130

For front seat belt illustration. Refer to [SB-8, "Exploded View"](#).

For rear seat belt illustration. Refer to [SB-13, "Exploded View"](#).

CAUTION:

- **After any collision, inspect all seat belt assemblies, including retractors and other attached hardwares (i.e. anchor bolt, guide rail set). Nissan recommends to replace all seat belt assemblies in use during a collision, unless not damaged and properly operating after minor collision.**

Also inspect seat belt assemblies not in use during a collision, and replace if damaged or improperly operating.

Seat belt pre-tensioner should be replaced even if the seat belts are not in use during a frontal collision where the driver and passenger air bags are deployed.

- **If any component of seat belt assembly is questionable, do not repair.**

Replace as seat belt assembly.

- **If webbing is cut, frayed, or damaged, replace belt assembly.**
- **Never oil tongue and buckle.**
- **Use a genuine NISSAN seat belt assembly.**

For details, refer to [SB-10, "SEAT BELT RETRACTOR : Inspection"](#), [SB-14, "SEAT BELT RETRACTOR : Inspection"](#) in SB section.

- Check anchors for loose mounting
- Check belts for damage
- Check retractor for smooth operation
- Check function of buckles and tongues when buckled and released

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

DRIVE BELT

DRIVE BELT : Drive Belt

INFOID:0000000009603683

DRIVE BELT

Tension of drive belt	Belt tension is not necessary, as it is automatically adjusted by drive belt auto-tensioner.
-----------------------	--

ENGINE COOLANT

ENGINE COOLANT : Periodical Maintenance Specification

INFOID:0000000009603686

ENGINE COOLANT CAPACITY (APPROXIMATE)

Unit: ℓ (US qt, Imp qt)

Engine coolant capacity [With reservoir tank ("MAX" level)]	10.9 (11-4/8, 9-5/8)
Reservoir tank engine coolant capacity (At "MAX" level)	0.9 (1, 6/8)

ENGINE OIL

ENGINE OIL : Periodical Maintenance Specification

INFOID:0000000009603685

ENGINE OIL CAPACITY (APPROXIMATE)

Unit: ℓ (US qt, Imp qt)

Drain and refill	With oil filter change	4.9 (5-1/8, 4-1/4)
	Without oil filter change	4.6 (4-7/8, 4)
Dry engine (Overhaul)		5.7 (6, 5)

SPARK PLUG

SPARK PLUG : Spark Plug

INFOID:0000000009603684

SPARK PLUG

Unit: mm (in)

Make	DENSO
Standard type	FXE24HR11
Gap (Nominal)	1.1 (0.043)

ROAD WHEEL

ROAD WHEEL : Road Wheel

INFOID:0000000009781698

CONVENTIONAL

Item		Limit
Runout	Axial runout	Less than 0.3 mm (0.012 in)
	Radial runout	
Allowable unbalance	Dynamic (At flange)	Less than 5 g (0.17 oz) (one side)
	Static (At flange)	Less than 10 g (0.35 oz)

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

MA