

# EX

SECTION  
EXHAUST SYSTEM

## CONTENTS

<b>PRECAUTION</b> .....	2	<b>PERIODIC MAINTENANCE</b> .....	4
<b>PRECAUTIONS</b> .....	2	<b>EXHAUST SYSTEM</b> .....	4
Removal and Installation .....	2	Inspection .....	4
<b>PREPARATION</b> .....	3	<b>REMOVAL AND INSTALLATION</b> .....	5
<b>PREPARATION</b> .....	3	<b>EXHAUST SYSTEM</b> .....	5
Special Service Tool .....	3	Exploded View .....	5
Commercial Service Tool .....	3	Removal and Installation .....	6
		Inspection .....	8

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Removal and Installation

INFOID:000000009235853

#### CAUTION:

- Be sure to use genuine exhaust system parts or equivalents which are specially designed for heat resistance, corrosion resistance, and shape.
- Perform the operation with the exhaust system fully cooled down because the system will be hot just after engine stops.
- Be careful not to cut your hand on the heat insulator edge.
- Never use silicon-containing products (e.g. oil) to prevent malfunctions such as the interference with the conduction of electricity and the occurrence of noise in the radio.

# PREPARATION

< PREPARATION >

## PREPARATION


### PREPARATION

#### Special Service Tool

INFOID:0000000009235854

EX



The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV10114400 (J-38365) Heated oxygen sensor wrench	 Loosening or tightening heated oxygen sensor 2 <b>For 22 mm (0.87 in) (a) width hexagon nut</b>

#### Commercial Service Tool

INFOID:0000000009235855

F

(Kent-Moore No.) Tool name	Description
A: (J-43897-18) B: (J-43897-12) Heated oxygen sensor thread cleaner	 Reconditioning the exhaust system threads before installing a new heated oxygen sensor (Use with anti-seize lubricant shown below.) <b>A: J-43897-18 [18 mm (0.71 in) dia.] for zirconia heated oxygen sensor</b> <b>B: J-43897-12 [12 mm (0.47 in) dia.] for titania heated oxygen sensor</b> <b>C: Mating surface shave cylinder</b> <b>D: Flutes</b>
( — ) Anti-seize lubricant (Permatex 133AR or equivalent meeting MIL specification MIL-A-907)	 Lubricating heated oxygen sensor thread cleaner when reconditioning exhaust system threads
( — ) Power tool	 Loosening bolts and nuts

## EXHAUST SYSTEM

< PERIODIC MAINTENANCE >


### PERIODIC MAINTENANCE EXHAUST SYSTEM

#### Inspection

INFOID:000000009235856

Check exhaust pipes, muffler and mounting for improper attachment, leaks, cracks, damage or deterioration.

- If anything is found, repair or replace damaged parts.



SMA211A

# EXHAUST SYSTEM


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION EXHAUST SYSTEM

### Exploded View

INFOID:000000009235857

EX



- |                          |                  |                          |
|--------------------------|------------------|--------------------------|
| (1) Exhaust diffuser     | (2) Main muffler | (3) Mounting rubber (RH) |
| (4) Mounting rubber (LH) | (5) Gasket       | (6) Center muffler       |
| (7) Mounting rubber      | (8) Gasket       | (9) Exhaust front tube   |
| (10) Clamp               | (11) Clamp       | (12) Heat insulator      |

# EXHAUST SYSTEM

## < REMOVAL AND INSTALLATION >

(13) Gasket	(14) Heated oxygen sensor 2 (bank 1)	(15) Three way catalyst (bank 1)
(16) Collar	(17) Grommet	(18) Exhaust mounting bracket
(19) Three way catalyst (bank 2)	(20) Heated oxygen sensor 2 (bank 2)	
: N·m (kg·m, in-lb)		
: N·m (kg·m, ft-lb)		
: Always replace after every disassembly.		


## Removal and Installation

INFOID:000000009235858

### REMOVAL

- Disconnect each joint and mounting using power tool.
- Remove heated oxygen sensor 2 as follows:
  - Using heated oxygen sensor wrench [SST: KV10114400 (J-38365)] (C), removal heated oxygen sensor 2.

(A) : Bank 1  
(B) : Bank 2  
 : Vehicle front




### CAUTION:

- Discard any heated oxygen sensor which has been dropped from a height of more than 0.5 m (19.7 in) onto a hard surface such as a concrete floor; use a new one.
- Before installing new heated oxygen sensor, clean exhaust system threads using Oxygen Sensor Thread Cleaner (commercial service tool) and approved Anti-seize lubricant (commercial service tool).


### Diffuser

1. Expand the portion (A) of inside diffuser (1) in the direction (B) with a flat blade screwdriver.

(2) : Main muffler



2. Hammer the portion (A) of diffuser (1) to remove it in the rearward direction of vehicle.



### INSTALLATION

Note the following, and install in the reverse order of removal.

- Check for deformation of the grommets (17 of Components).
- Insert the collar (16 of Components) vertically.

# EXHAUST SYSTEM

## < REMOVAL AND INSTALLATION >


- Temporarily tighten nuts and bolts when installing exhaust pipe assembly. Tighten them to the specified torque when connecting the vehicle rear to the vehicle front.

Diffuser

- Insert diffuser ① by using a plastic hammer.


**CAUTION:**

Never damage the portion Ⓐ of the diffuser.



JPBIA6567ZZ

- Check that the portion Ⓑ of diffuser ② is tightly fitted to the portion Ⓐ of main muffler ①.



JPBIA6568ZZ

**CAUTION:**

- Always replace exhaust tube gaskets with new ones when reassembling.
- Discard any heated oxygen sensor 2 which has been dropped onto a hard surface such as a concrete floor. Use a new one.
- Before installing a new heated oxygen sensor 2, clean exhaust system threads using the heated oxygen sensor thread cleaner (commercial service tool: J-43897-18 or J-43897-12), and apply the anti-seize lubricant (commercial service tool).
- Never over torque heated oxygen sensor 2. Doing so may cause damage to heated oxygen sensor 2, resulting in the "MIL" coming on.
- Prevent rust preventives from adhering to the sensor body.
- If heat insulator is badly deformed, repair or replace it. If deposits such as mud pile up on the heat insulator, remove them.
- When installing heat insulator avoid large gaps or interference between heat insulator and each exhaust pipe.
- Remove deposits from the sealing surface of each connection. Connect them securely to avoid gases leakage.
- Temporarily tighten mounting nuts on the exhaust manifold side and mounting bolts on the vehicle side. Check each part for unusual interference, and then tighten them to the specified torque.
- When installing each mounting rubber, avoid twisting or unusual extension in up/down and right/left directions.

# **EXHAUST SYSTEM**

< REMOVAL AND INSTALLATION >

## **Inspection**

INFOID:000000009235859

### **INSPECTION AFTER INSTALLATION**

- Check clearance between tail tube and rear bumper is even.
- With engine running, check exhaust tube joints for gas leaks and unusual noises.
- Check to ensure that mounting brackets and mounting rubbers are installed properly and free from undue stress. Improper installation could result in excessive noise and vibration.