

HEATER & AIR CONDITIONER

SECTION HA

CONTENTS

PRECAUTIONS	2	Operational Check	66	GI
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2	A/C System	71	MA
Precautions for Working with HFC-134a (R-134a)	2	Mode Door Motor	75	EM
General Refrigerant Precautions	3	Air Mix Door Motor	82	LC
Precautions for Leak Detection Dye	3	Intake Door Motor	87	EC
Identification	4	Blower Motor	95	FE
Precautions for Refrigerant Connection	4	Magnet Clutch	104	AT
Precautions for Servicing Compressor	6	Insufficient Cooling	112	TF
Precautions for Service Equipment	7	Insufficient Heating	121	PD
Wiring Diagrams and Trouble Diagnoses	9	Noise	123	AX
PREPARATION	10	Self-diagnosis	124	SU
Special Service Tools	10	Memory Function	126	BR
HFC-134a (R-134a) Service Tools and Equipment	11	ECON (ECONOMY) Mode	128	ST
DESCRIPTION	14	Ambient Sensor Circuit	129	RS
Refrigeration System	14	In-vehicle Sensor Circuit	132	BT
V-6 Variable Displacement Compressor	15	Sunload Sensor Circuit	135	HA
Component Layout	19	Intake Sensor Circuit	139	SC
Introduction	20	Air Mix Door Motor PBR Circuit	141	EL
Features	20	Multiplex Communication Circuit	142	IDX
Overview of Control System	23	SERVICE PROCEDURE	144	
Control Operation	23	HFC-134a (R-134a) Service Procedure	144	
Discharge Air Flow	25	Maintenance of Lubricant Quantity in Compressor	146	
System Description	26	Compressor	149	
TROUBLE DIAGNOSES	27	Compressor Clutch	150	
Component Location	27	Refrigerant Lines	154	
Circuit Diagram (Without Navigation System)	30	Belt	159	
Wiring Diagram - A/C, A - (Without Navigation System)	31	Ventilation Air Filter	159	
Circuit Diagram (With Navigation System)	35	SERVICE DATA AND SPECIFICATIONS (SDS)	160	
Wiring Diagram - A/C, A - (With Navigation System)	36	Compressor	160	
Auto Amp. Terminals and Reference Value	40	Lubricant	160	
Self-diagnosis	44	Refrigerant	160	
How to Perform Trouble Diagnoses for Quick and Accurate Repair	65	Engine Idling Speed (When A/C is ON)	160	
		Belt Tension	160	

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NBHA0001

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to INFINITI QX4 is as follows:

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses covered with yellow insulation tape either just before the harness connectors or for the complete harness are related to the SRS.

Precautions for Working with HFC-134a (R-134a)

NBHA0002

WARNING:

- CFC-12 (R-12) refrigerant and HFC-134a (R-134a) refrigerant are not compatible. If the refrigerants are mixed and compressor failure is likely to occur, refer to "CONTAMINATED REFRIGERANT" below. To determine the purity of HFC-134a (R-134a) in the vehicle and recovery tank, use Refrigerant Recovery/Recycling Recharging equipment (ACR4) (J-39500-INF) and Refrigerant Identifier.
- Use only specified lubricant for the HFC-134a (R-134a) A/C system and HFC-134a (R-134a) components. If lubricant other than that specified is used, compressor failure is likely to occur.
- The specified HFC-134a (R-134a) lubricant rapidly absorbs moisture from the atmosphere. The following handling precautions must be observed:
 - a) When removing refrigerant components from a vehicle, immediately cap (seal) the component to minimize the entry of moisture from the atmosphere.
 - b) When installing refrigerant components to a vehicle, do not remove the caps (unseal) until just before connecting the components. Connect all refrigerant loop components as quickly as possible to minimize the entry of moisture into system.
 - c) Only use the specified lubricant from a sealed container. Immediately reseal containers of lubricant. Without proper sealing, lubricant will become moisture saturated and should not be used.
 - d) Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove R-134a from the A/C system, using certified service equipment meeting requirements of SAE J2210 (R-134a recycling equipment), or J2209 (R-134a recovery equipment). If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.
 - e) Do not allow lubricant (Nissan A/C System Oil Type S) to come in contact with styrofoam parts. Damage may result.

CONTAMINATED REFRIGERANT

NBHA0002S01

If a refrigerant other than pure R-134a is identified in a vehicle, your options are:

- Explain to the customer that environmental regulations prohibit the release of contaminated refrigerant into the atmosphere.
- Explain that recovery of the contaminated refrigerant could damage your service equipment and refrigerant supply.

PRECAUTIONS

Precautions for Working with HFC-134a (R-134a) (Cont'd)

- Suggest the customer return the vehicle to the location of previous service where the contamination may have occurred.
- If you choose to perform the repair, recover the refrigerant using only **dedicated equipment and containers. Do not recover contaminated refrigerant into your existing service equipment.** If your facility does not have dedicated recovery equipment, you may contact a local refrigerant product retailer for available service. This refrigerant must be disposed of in accordance with all federal and local regulations. In addition, replacement of all refrigerant system components on the vehicle is recommended.
- If the vehicle is within the warranty period, the air conditioner warranty is void. Please contact Nissan Customer Affairs for further assistance.

GI
MA
EM

General Refrigerant Precautions

NBHA0003

WARNING:

- **Do not release refrigerant into the air. Use approved recovery/recycling equipment to capture the refrigerant every time an air conditioning system is discharged.**
- **Always wear eye and hand protection (goggles and gloves) when working with any refrigerant or air conditioning system.**
- **Do not store or heat refrigerant containers above 52°C (125°F).**
- **Do not heat a refrigerant container with an open flame; if container warming is required, place the bottom of the container in a warm pail of water.**
- **Do not intentionally drop, puncture, or incinerate refrigerant containers.**
- **Keep refrigerant away from open flames: poisonous gas will be produced if refrigerant burns.**
- **Refrigerant will displace oxygen, therefore be certain to work in well ventilated areas to prevent suffocation.**
- **Do not pressure test or leak test HFC-134a (R-134a) service equipment and/or vehicle air conditioning systems with compressed air during repair. Some mixtures of air and R-134a have been shown to be combustible at elevated pressures. These mixtures, if ignited, may cause injury or property damage. Additional health and safety information may be obtained from refrigerant manufacturers.**

LC
EC
FE
AT
TF
PD
AX

Precautions for Leak Detection Dye

NBHA0111

- The A/C system contains a fluorescent leak detection dye used for locating refrigerant leaks. An ultraviolet (UV) lamp is required to illuminate the dye when inspecting for leaks.
- Always wear fluorescence enhancing UV safety glasses to protect your eyes and enhance the visibility of the fluorescent dye.
- The fluorescent dye leak detector is not a replacement for an electronic refrigerant leak detector. The fluorescent dye leak detector should be used in conjunction with an electronic refrigerant leak detector to (J-41995) pin-point refrigerant leaks.
- For your safety and your Customer's satisfaction, read and follow all manufacture's operating instructions and precautions prior to performing the work.
- A compressor shaft seal should not be repaired because of dye seepage. The compressor shaft seal should only be repaired after confirming the leak with an electronic refrigerant leak detector (J-41995).
- Always remove and dye from the leak area after repairs are complete to avoid a misdiagnosis during a future service.
- Do not allow dye to come into contact with painted body panels or interior components. If dye is spilled, clean immediately with the approved dye cleaner. Fluorescent dye left on a surface for an extended period of time cannot be removed.
- Do not spray the fluorescent dye cleaning agent on hot surfaces (engine exhaust manifold, etc.).
- Do not use more than one refrigerant dye bottle (1/4 ounce /7.4 cc) per A/C system.
- Leak detection dyes for R-134a and R12 A/C systems are different. Do not use R-134a leak detection dye in R-12 A/C system or R-12 leak detector dye in R-134a A/C systems or A/C system damage may result.
- The fluorescent properties of the dye will remain for over three (3) years unless a compressor failure occurs.

SU
BR
ST
RS
BT
HA
SC
EL
IDX

PRECAUTIONS

Identification

AIR CONDITIONER NISSAN		
	REFRIGERANT	COMPRESSOR LUBRICANT
TYPE (PART NO.)	HFC134a (R134a)	Nissan UV Luminous Oil Type S [KLHOO-PAGSO]
AMOUNT	0.7±0.025kg (1.54±0.055lbs)	
CAUTION PRECAUTION • REFRIGERANT UNDER HIGH PRESSURE. • SYSTEM TO BE SERVICED BY QUALIFIED PERSONNEL. • IMPROPER SERVICE METHODS MAY CAUSE PERSONAL INJURY. • CONSULT SERVICE MANUAL. • THIS AIR CONDITIONER SYSTEM COMPLIES WITH SAE J-639. Nissan Motor Co., Ltd., TOKYO, Japan 27090 6P102		
SHA436F		

Identification

IDENTIFICATION LABEL FOR VEHICLE

NBHA0112

NBHA0112S01

Vehicles with factory installed fluorescent dye have this identification label on the under side of hood.

NOTE:

Vehicles with factory installed fluorescent dye have a green label. Vehicles without factory installed fluorescent dye have a blue label.

Precautions for Refrigerant Connection

NBHA0004


A new type refrigerant connection has been introduced to all refrigerant lines except the following location.

- Expansion valve to cooling unit

FEATURES OF NEW TYPE REFRIGERANT CONNECTION

NBHA0004S01

- The O-ring has been relocated. It has also been provided with a groove for proper installation. This eliminates the chance of the O-ring being caught in, or damaged by, the mating part. The sealing direction of the O-ring is now set vertically in relation to the contacting surface of the mating part to improve sealing characteristics.
- The reaction force of the O-ring will not occur in the direction that causes the joint to pull out, thereby facilitating piping connections.




PRECAUTIONS

Precautions for Refrigerant Connection (Cont'd)

O-RING AND REFRIGERANT CONNECTION

NBHA0004S02

SEC. 271•274•276



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR

RHA816H

CAUTION:

The new and former refrigerant connections use different O-ring configurations. Do not confuse O-rings since they are not interchangeable. If a wrong O-ring is installed, refrigerant will leak at, or around, the connection.

O-Ring Part Numbers and Specifications

NBHA0004S0201

Connection type	O-ring size	Part number	D mm (in)		W mm (in)	
			mm	in	mm	in
New	8	92471 N8210	6.8	(0.268)	1.85	(0.0728)
Former		92470 N8200	6.07	(0.2390)	1.78	(0.0701)
New	12	92472 N8210	10.9	(0.429)	2.43	(0.0957)
Former		92475 71L00	11.0	(0.433)	2.4	(0.094)
New	16	92473 N8210	13.6	(0.535)	2.43	(0.0957)
Former		92475 72L00	14.3	(0.563)	2.3	(0.091)
New	19	92474 N8210	16.5	(0.650)	2.43	(0.0957)
Former		92477 N8200	17.12	(0.6740)	1.78	(0.0701)

RS
BT
HA
SC
EL
IDX

WARNING:

Make sure all refrigerant is discharged into the recycling equipment and the pressure in the system is less than atmospheric pressure. Then gradually loosen the discharge side hose fitting and remove it.


PRECAUTIONS

Precautions for Refrigerant Connection (Cont'd)

CAUTION:

When replacing or cleaning refrigerant cycle components, observe the following.

- When the compressor is removed, store it in the same position as it is when mounted on the car. Failure to do so will cause lubricant to enter the low pressure chamber.
- When connecting tubes, always use a torque wrench and a back-up wrench.
- After disconnecting tubes, immediately plug all openings to prevent entry of dirt and moisture.
- When installing an air conditioner in the vehicle, connect the pipes as the final stage of the operation. Do not remove the seal caps of pipes and other components until just before required for connection.
- Allow components stored in cool areas to warm to working area temperature before removing seal caps. This prevents condensation from forming inside A/C components.
- Thoroughly remove moisture from the refrigeration system before charging the refrigerant.
- Always replace used O-rings.
- When connecting tube, apply lubricant to circle of the O-rings shown in illustration. Be careful not to apply lubricant to threaded portion.
Lubricant name: Nissan A/C System Oil Type S
Part number: KLH00-PAGS0
- O-ring must be closely attached to dented portion of tube.
- When replacing the O-ring, be careful not to damage O-ring and tube.
- Connect tube until you hear it click, then tighten the nut or bolt by hand until snug. Make sure that the O-ring is installed to tube correctly.
- After connecting line, conduct leak test and make sure that there is no leakage from connections. When the gas leaking point is found, disconnect that line and replace the O-ring. Then tighten connections of seal seat to the specified torque.



Precautions for Servicing Compressor

NBHA0005

- Plug all openings to prevent moisture and foreign matter from entering.
- When the compressor is removed, store it in the same position as it is when mounted on the car.
- When replacing or repairing compressor, follow "Maintenance of Lubricant Quantity in Compressor" exactly. Refer to HA-146.
- Keep friction surfaces between clutch and pulley clean. If the surface is contaminated, with lubricant, wipe it off by using a clean waste cloth moistened with thinner.
- After compressor service operation, turn the compressor shaft by hand more than five turns in both directions. This will equally distribute lubricant inside the compressor. After the compressor is installed, let the engine idle and operate the compressor for one hour.
- After replacing the compressor magnet clutch, apply voltage to the new one and check for normal operation.

PRECAUTIONS

Precautions for Service Equipment

Precautions for Service Equipment

NBHA0006

RECOVERY/RECYCLING EQUIPMENT


NBHA0006S01

Be certain to follow the manufacturers instructions for machine operation and machine maintenance. Never introduce any refrigerant other than that specified into the machine.

ELECTRONIC LEAK DETECTOR

NBHA0006S02

Be certain to follow the manufacturer's instructions for tester operation and tester maintenance.



VACUUM PUMP


NBHA0006S03

The lubricant contained inside the vacuum pump is not compatible with the specified lubricant for HFC-134a (R-134a) A/C systems. The vent side of the vacuum pump is exposed to atmospheric pressure. So the vacuum pump lubricant may migrate out of the pump into the service hose. This is possible when the pump is switched off after evacuation (vacuuming) and hose is connected to it.

To prevent this migration, use a manual valve placed near the hose-to-pump connection, as follows.

- Usually vacuum pumps have a manual isolator valve as part of the pump. Close this valve to isolate the service hose from the pump.
- For pumps without an isolator, use a hose equipped with a manual shut-off valve near the pump end. Close the valve to isolate the hose from the pump.
- If the hose has an automatic shut off valve, disconnect the hose from the pump. As long as the hose is connected, the valve is open and lubricating oil may migrate.


Some one-way valves open when vacuum is applied and close under a no vacuum condition. Such valves may restrict the pump's ability to pull a deep vacuum and are not recommended.



MANIFOLD GAUGE SET

NBHA0006S04

Be certain that the gauge face indicates R-134a or 134a. Be sure the gauge set has 1/2"-16 ACME threaded connections for service hoses. Confirm the set has been used only with refrigerant HFC-134a (R-134a) and specified lubricants.



SERVICE HOSES



NBHA0006S05

Be certain that the service hoses display the markings described (colored hose with black stripe). All hoses must include positive shut off devices (either manual or automatic) near the end of the hoses opposite the manifold gauge.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

PRECAUTIONS

Precautions for Service Equipment (Cont'd)



SERVICE COUPLERS

NBHA0006S06

Never attempt to connect HFC-134a (R-134a) service couplers to an CFC-12 (R-12) A/C system. The HFC-134a (R-134a) couplers will not properly connect to the CFC-12 (R-12) system. However, if an improper connection is attempted, discharging and contamination may occur.

Shut-off valve rotation	A/C service valve
Clockwise	Open
Counterclockwise	Close

REFRIGERANT WEIGHT SCALE

NBHA0006S07

Verify that no refrigerant other than HFC-134a (R-134a) and specified lubricants have been used with the scale. If the scale controls refrigerant flow electronically, the hose fitting must be 1/2\"-16 ACME.

CALIBRATING ACR4 WEIGHT SCALE

NBHA0006S09

Calibrate the scale every three months.

To calibrate the weight scale on the ACR4 (J-39500-INF):

1. Press **Shift/Reset** and **Enter** at the same time.
2. Press **8787**. "A1" will be displayed.
3. Remove all weight from the scale.
4. Press **0**, then press **Enter**. "0.00" will be displayed and change to "A2".
5. Place a known weight (dumbbell or similar weight), between 4.5 and 8.6 kg (10 and 19 lb) on the center of the weight scale.
6. Enter the known weight using four digits. (Example 10 lb = 10.00, 10.5 lb = 10.50)
7. Press **Enter** — the display returns to the vacuum mode.
8. Press **Shift/Reset** and **Enter** at the same time.
9. Press **6** — the known weight on the scale is displayed.
10. Remove the known weight from the scale. "0.00" will be displayed.
11. Press **Shift/Reset** to return the ACR4 to the program mode.

CHARGING CYLINDER

NBHA0006S08

Using a charging cylinder is not recommended. Refrigerant may be vented into air from cylinder's top valve when filling the cylinder with refrigerant. Also, the accuracy of the cylinder is generally less than that of an electronic scale or of quality recycle/recharge equipment.

Wiring Diagrams and Trouble Diagnoses

NBHA0007

When you read wiring diagrams, refer to the following:

- GI-11, "HOW TO READ WIRING DIAGRAMS" GI
- EL-13, "Wiring Diagram — POWER —" for power distribution circuit MA

When you perform trouble diagnoses, refer to the following:

- GI-34, "HOW TO FOLLOW TROUBLE DIAGNOSES" EM
- GI-24, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT" LC

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX






PREPARATION

Special Service Tools

Special Service Tools

NBHA0008

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV99106100 (J-41260) Clutch disc wrench	<p data-bbox="950 331 1170 359">Removing center bolt</p>  <p data-bbox="415 527 477 548">NT232</p>  <p data-bbox="493 758 805 884">When replacing the magnet clutch in the above compressor, use a clutch disc wrench with the pin side on the clutch disc to remove it.</p>  <p data-bbox="623 894 678 915">Pin</p> <p data-bbox="704 982 889 1003">Clutch disc wrench</p> <p data-bbox="415 1041 477 1062">NT378</p>
KV99232340 (J-38874) or KV992T0001 (—) Clutch disc puller	<p data-bbox="950 1077 1170 1104">Removing clutch disc</p>  <p data-bbox="415 1304 477 1325">NT376</p>
KV99106200 (J-41261) Pulley installer	<p data-bbox="950 1344 1105 1371">Installing pulley</p>  <p data-bbox="415 1482 477 1503">NT235</p>

PREPARATION

HFC-134a (R-134a) Service Tools and Equipment

HFC-134a (R-134a) Service Tools and Equipment




^{=NBHA0009}

Never mix HFC-134a refrigerant and/or its specified lubricant with CFC-12 (R-12) refrigerant and/or its lubricant.

Separate and non-interchangeable service equipment must be used for handling each type of refrigerant/lubricant.

Refrigerant container fittings, service hose fittings and service equipment fittings (equipment which handles refrigerant and/or lubricant) are different between CFC-12 (R-12) and HFC-134a (R-134a). This is to avoid mixed use of the refrigerants/lubricant.





Adapters that convert one size fitting to another must never be used: refrigerant/lubricant contamination will occur and compressor failure will result.

Tool number (Kent-Moore No.) Tool name	Description
HFC-134a (R-134a) refrigerant	 <p>Container color: Light blue Container marking: HFC-134a (R-134a) Fitting size: Thread size</p> <ul style="list-style-type: none"> ● Large container 1/2"-16 ACME <p>NT196</p>
KLH00-PAGS0 (—) Nissan A/C System Oil Type S	 <p>Type: Poly alkylene glycol oil (PAG), type S Application: HFC-134a (R-134a) swash plate (piston) compressors (Nissan only) Lubricity: 40 mℓ (1.4 US fl oz, 1.4 Imp fl oz)</p> <p>NT197</p>
(J-39500-INF) Recovery/Recycling Recharging equipment (ACR4)	 <p>Function: Refrigerant Recovery and Recycling and Recharging</p> <p>NT195</p>
(J-41995) Electrical leak detector	 <p>Power supply:</p> <ul style="list-style-type: none"> ● DC 12V (Cigarette lighter) <p>AHA281A</p>

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



PREPARATION

HFC-134a (R-134a) Service Tools and Equipment (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description	
<p>(J-43926) Refrigerant dye leak detection kit Kit includes: (J-42220) UV lamp and UV safety glasses (J-41459) Refrigerant dye injector (J-41447) qty. 24 R-134a refrigerant dye (J-43872) Refrigerant dye cleaner</p>	 <p>UV lamp w/shield Carrying case Refrigerant dye cleaner UV goggles Refrigerant dye identification label (30 labels) Refrigerant dye (24 bottles) Refrigerant dye injector</p> <p>NOTICE This A/C or Refrigeration system contains a fluorescent leak detection tracer dye. (Must use UV black light to see dye). KENT-MOORE Wentz, MO 64094 1-800-345-2233</p>	<p>Power supply: DC 12V (Battery terminal)</p>
<p>(J-42220) Fluorescent dye leak detector</p>	 <p>UV lamp</p>	<p>Power supply: DC 12V (Battery terminal) For checking refrigerant leak when fluorescent dye is installed in A/C system. Includes: UV lamp and UV safety glasses UV safety glasses</p>
<p>(J-41447) R134a Fluorescent Leak Detection Dye (Box of 24, 1/4 ounce bottles)</p>	 <p>Dye Refrigerant dye (24 bottles)</p>	<p>Application: For R-134a PAG oil Container: 1/4 ounce (7.4 cc) bottle (Includes self-adhesive dye identification labels for affixing to vehicle after charging system with dye.)</p>
<p>(J-41459) R134a Dye Injector Use with J-41447, 1/4 ounce bottle</p>	 <p>Dye injector</p>	<p>For injecting 1/4 ounce of Fluorescent Leak Detection Dye into A/C system.</p>
<p>(J-43872) Dye cleaner</p>		<p>For cleaning dye spills.</p>
<p>(J-39183) Manifold gauge set (with hoses and couplers)</p>		<p>Identification: <ul style="list-style-type: none"> ● The gauge face indicates R-134a. Fitting size: Thread size <ul style="list-style-type: none"> ● 1/2"-16 ACME </p>


PREPARATION

HFC-134a (R-134a) Service Tools and Equipment (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description		GI
Service hoses <ul style="list-style-type: none"> ● High side hose (J-39501-72) ● Low side hose (J-39502-72) ● Utility hose (J-39476-72) 	 NT201	Hose color: <ul style="list-style-type: none"> ● Low hose: Blue with black stripe ● High hose: Red with black stripe ● Utility hose: Yellow with black stripe or green with black stripe Hose fitting to gauge: <ul style="list-style-type: none"> ● 1/2"-16 ACME 	MA
Service couplers <ul style="list-style-type: none"> ● High side coupler (J-39500-20) ● Low side coupler (J-39500-24) 	 NT202	Hose fitting to service hose: <ul style="list-style-type: none"> ● M14 x 1.5 fitting is optional or permanently attached. 	LC
(J-39650) Refrigerant weight scale	 NT200	For measuring of refrigerant Fitting size: Thread size <ul style="list-style-type: none"> ● 1/2"-16 ACME 	AT
(J-39649) Vacuum pump (Including the isolator valve)	 NT203	Capacity: <ul style="list-style-type: none"> ● Air displacement: 4 CFM ● Micron rating: 20 microns ● Oil capacity: 482 g (17 oz) Fitting size: Thread size <ul style="list-style-type: none"> ● 1/2"-16 ACME 	TF

COMMERCIAL SERVICE TOOL

NBHA0009S01

Tool name	Description		ST
Refrigerant identifier equipment	 NT765	For checking refrigerant purity and system contamination	RS

HA

SC

EL

IDX

DESCRIPTION

Refrigeration System

REFRIGERATION CYCLE

NBHA0010

Refrigerant Flow

NBHA0010S01

The refrigerant flows in the standard pattern, that is, through the compressor, the condenser, the liquid tank, through the evaporator, and back to the compressor. The refrigerant evaporation through the evaporator coil is controlled by an externally equalized expansion valve, located inside the evaporator case.

Freeze Protection

NBHA0010S02

Under normal operating conditions, when the A/C is switched on, the compressor runs continuously, and the evaporator pressure, and therefore temperature, is controlled by the V-6 variable displacement compressor to prevent freeze up.

Refrigerant System Protection

NBHA0010S03

Refrigerant Pressure Sensor


NBHA0010S0303

The refrigerant system is protected against excessively high or low pressures by the refrigerant pressure sensor, located on the liquid tank. If the system pressure rises above, or falls below the specifications, the refrigerant pressure sensor detects the pressure inside the refrigerant line and sends the voltage signal to the ECM. ECM makes the A/C relay go OFF and stops the compressor when pressure on the high pressure side detected by refrigerant pressure sensor is over about 2,746 kPa (28 kg/cm², 398 psi) or below about 177 kPa (1.8 kg/cm², 26 psi).

Pressure Relief Valve

NBHA0010S0302

The refrigerant system is also protected by a pressure relief valve, located in the rear head of the compressor. When the pressure of refrigerant in the system increases to an abnormal level [more than 3,727 kPa (38 kg/cm², 540 psi)], the release port on the pressure relief valve automatically opens and releases refrigerant into the atmosphere.



V-6 Variable Displacement Compressor

GENERAL INFORMATION

1. The V-6 variable compressor differs from previous units. The vent temperatures of the V-6 variable compressor do not drop too far below 5°C (41°F) when:

- evaporator intake air temperature is less than 20°C (68°F)
- engine is running at speeds less than 1,500 rpm.

This is because the V-6 compressor provides a means of “capacity” control.

2. The V-6 variable compressor provides refrigerant control under varying conditions. During cold winters, it may not produce high refrigerant pressure discharge (compared to previous units) when used with air conditioning systems.

3. A “clanking” sound may occasionally be heard during refrigerant charge. The sound indicates that the tilt angle of the swash plate has changed and is not a problem.

4. For air conditioning systems with the V-6 compressor, the clutch remains engaged unless: the system main switch, fan switch or ignition switch is turned OFF. When ambient (outside) temperatures are low or when the amount of refrigerant is insufficient, the clutch is disengaged to protect the compressor.

5. A constant range of suction pressure is maintained when engine speed is greater than a certain value. It normally ranges from 147 to 177 kPa (1.5 to 1.8 kg/cm², 21 to 26 psi) under varying conditions. In previous compressors, however, suction pressure was reduced with increases in engine speed.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DESCRIPTION

V-6 Variable Displacement Compressor (Cont'd)

=NBHA0087


NBHA0087S01

DESCRIPTION

General

The variable compressor is basically a swash plate type that changes piston stroke in response to the required cooling capacity.

The tilt of the swash plate allows the piston's stroke to change so that refrigerant discharge can be continuously changed from 14.5 to 184 cm³ (0.885 to 11.228 cu in).



RHA037DD

DESCRIPTION

V-6 Variable Displacement Compressor (Cont'd)

Operation

1. Operation Control Valve

=NBHA0087S02

Operation control valve is located in the suction port (low-pressure) side, and opens or closes in response to changes in refrigerant suction pressure.

NBHA0087S0201

Operation of the valve controls the internal pressure of the crankcase.

The angle of the swash plate is controlled between the crankcase's internal pressure and the piston cylinder pressure.

2. Maximum Cooling

NBHA0087S0202


Refrigerant pressure on the low-pressure side increases with an increase in heat loads.

When this occurs, the control valve's bellows compress to open the low-pressure side valve and close the high-pressure side valve.

This causes the following pressure changes:

- the crankcase's internal pressure to equal the pressure on the low-pressure side;
- the cylinder's internal pressure to be greater than the crankcase's internal pressure.

Under this condition, the swash plate is set to the maximum stroke position.



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DESCRIPTION

V-6 Variable Displacement Compressor (Cont'd)

3. Capacity Control

=NBHA0087S0203


- Refrigerant pressure on suction side is low during high speed driving or when ambient or interior temperature is low.
- The bellows expands when refrigerant pressure on the suction pressure side drops below approximately 177 kPa (1.8 kg/cm², 26 psi).
Since suction pressure is low, it makes the suction port close and the discharge port open. Thus, crankcase pressure becomes high as high pressure enters the crankcase.
- The force acts around the journal pin near the swash plate, and is generated by the pressure difference before and behind the piston.
The drive lug and journal pin are located where the piston generates the highest pressure. Piston pressure is between suction pressure P_s and discharge pressure P_d , which is near suction pressure P_s . If crankcase pressure P_c rises due to capacity control, the force around the journal pin makes the swash plate angle decrease and also the piston stroke decrease. In other words, crankcase pressure increase triggers pressure difference between the piston and the crankcase. The pressure difference changes the angle of the swash plate.



Component Layout

NBHA0012

SEC. 270•271•272•273



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

RHA451G

DESCRIPTION

Introduction


Introduction

AIR CONDITIONER LAN SYSTEM OVERVIEW CONTROL SYSTEM

NBHA0013

NBHA0013S01

The LAN system consists of auto amp., air mix door motor and mode door motor. A configuration of these components is shown in the diagram below.



Features

NBHA0014

SYSTEM CONSTRUCTION (LAN)


NBHA0014S08

A small network is constructed between the auto amplifier, air mix door motor and mode door motor. The auto amplifier and motors are connected by data transmission lines and motor power supply lines. The LAN network is built through the ground circuits of the two motors.

Addresses, motor opening angle signals, motor stop signals and error checking messages are all transmitted through the data transmission lines connecting the auto amplifier and two motors.

The following functions are contained in LCUs built into the air mix door motor and the mode door motor.

- Address
- Motor opening angle signals
- Data transmission
- Motor stop and drive decision
- Opening angle sensor (PBR function)
- Comparison
- Decision (Auto amplifier indicated value and motor opening angle comparison)




Operation

NBHA0014S0801

The auto amplifier receives data from each of the sensors. The amplifier sends air mix door and mode door opening angle data to the air mix door motor LCU and mode door motor LCU.

The air mix door motor and mode door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amplifier and each of the motor position sensors are compared by the LCUs in each motor with the existing decision and opening angles. Subsequently, HOT/ COLD or DEFROST/VENT operation is selected. The new selection data is returned to the auto amplifier.



Transmission Data and Transmission Order

NBHA0014S0802

Amplifier data is transmitted consecutively to each of the door motors following the form shown in figure below. Start: Initial compulsory signal sent to each of the door motors.

Address: Data sent from the auto amplifier is selected according to data-based decisions made by the air mix door motor and mode door motor.

If the addresses are identical, the opening angle data and error check signals are received by the door motor LCUs. The LCUs then make the appropriate error decision. If the opening angle data is normal, door control begins.

If an error exists, the received data is rejected and corrected data received. Finally, door control is based upon the corrected opening angle data.


Opening angle: Data that shows the indicated door opening angle of each door motor.

Error check: Procedure by which sent and received data is checked for errors. Error data is then compiled. The error check prevents corrupted data from being used by the air mix door motor and mode door motor.

Error data can be related to the following problems.

- Abnormal electrical frequency
- Poor electrical connections
- Signal leakage from transmission lines
- Signal level fluctuation

Stop signal: At the end of each transmission, a stop operation, in-operation, or internal problem message is delivered to the auto amplifier. This completes one data transmission and control cycle.



Air Mix Door Control (Automatic Temperature Control)

NBHA0014S0803

The air mix door is automatically controlled so that in-vehicle temperature is maintained at a predetermined value by: The temperature setting, ambient temperature, in-vehicle temperature and amount of sunload.

DESCRIPTION

Features (Cont'd)

Fan Speed Control

NBHA0014S0804

Blower speed is automatically controlled based on temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and air mix door position.

With FAN switch set to "AUTO", the blower motor starts to gradually increase air flow volume.

When engine coolant temperature is low, the blower motor operation is delayed to prevent cool air from flowing.

Intake Door Control

NBHA0014S0805

The intake doors are automatically controlled by: The temperature setting, ambient temperature, in-vehicle temperature, intake temperature, amount of sunload and ON-OFF operation of the compressor.

Outlet Door Control

NBHA0014S0806

The outlet door is automatically controlled by: The temperature setting, ambient temperature, in-vehicle temperature, intake temperature and amount of sunload.

Magnet Clutch Control

NBHA0014S0807

The ECM controls compressor operation using input signals from the throttle position sensor and auto amplifier.

Self-diagnostic System

NBHA0014S0808


The self-diagnostic system is built into the auto amplifier (LCU) to quickly locate the cause of problems.

DESCRIPTION

Overview of Control System


=NBHA0015

The control system consists of input sensors, switches, the automatic amplifier (microcomputer) and outputs. The relationship of these components is shown in the diagram below:




Control Operation

NBHA0016



DESCRIPTION

Control Operation (Cont'd)



DISPLAY SCREEN

Displays the operational status of the system.

NBHA0016S01

AUTO SWITCH

The compressor, intake doors, air mix door, outlet doors, and blower speed are automatically controlled so that the in-vehicle temperature will reach, and be maintained at the set temperature selected by the operator.

NBHA0016S02

ECON SWITCH

By pressing the ECON switch, the display should indicate ECON and the compressor always turns OFF. With the compressor OFF, the system will not remove heat (cool) or de-humidify. The system will maintain the in-vehicle temperature at the set temperature when the set temperature is above the ambient (outside) temperature. The system will set the intake doors to the outside air position.

NBHA0016S03

TEMPERATURE SWITCH (POTENTIAL TEMPERATURE CONTROL) WITHOUT NAVIGATION SYSTEM

Increases or decreases the set temperature.

NBHA0016S04

OFF SWITCH

The compressor and blower are OFF, the intake doors are set to the outside air position, and the air outlet doors are set to the foot (80% foot and 20% defrost) position.

NBHA0016S05

FAN SWITCH

Manually controls the blower speed. Four speeds are available for manual control (as shown on the display screen):

NBHA0016S06

low , medium low , medium high , high 

RECIRCULATION (REC) SWITCH

OFF position: Outside air is drawn into the passenger compartment.
ON position: Interior air is recirculated inside the vehicle.

NBHA0016S07

DEFROSTER (DEF) SWITCH

Positions the air outlet doors to the defrost position. Also positions the intake doors to the outside air position.

NBHA0016S08

MODE SWITCH

Controls the air discharge outlets.

NBHA0016S09

TEMPERATURE DIAL (POTENTIAL TEMPERATURE CONTROL) WITH NAVIGATION SYSTEM

Increases or decreases the set temperature.

NBHA0016S10

AMB (AMBIENT) SWITCH (WITH NAVIGATION SYSTEM)

Shows the ambient (outside) air temperature on the display screen for 5 seconds.







NBHA0016S11

DESCRIPTION

Discharge Air Flow

Discharge Air Flow

NBHA0017



- : Air passed through heater core
- : Mixed air (+)
- : Air not passed through heater core

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

RHA043G

DESCRIPTION


System Description

System Description

NBHA0110

SWITCHES AND THEIR CONTROL FUNCTIONS

NBHA0110S01



Position or switch	MODE SW				DEF SW		AUTO SW	ECON SW	REC SW		Temperature SW		
	VENT	B/L	FOOT	D/F	ON	OFF			ON	OFF	▼ TEMP ▲		
Door							AUTO	ECON			18.0°C (65°F)	—	32.0°C (85°F)
Ventila-tor door	A	B	C	C	C	—	AUTO	ECON	—	—	—		
Foot door	A	B	C	C	A	—			—	—	—		
Defroster door	A	A	B	C	C	—	AUTO	AUTO	—	—	—		
Air mix door	—				—	—	—	—	—	—	A	AUTO	B
Intake door	—				C	—	—	—	A	AUTO*1	—		

*1: Automatically controlled when REC switch is OFF.






TROUBLE DIAGNOSES

Component Location

Component Location ENGINE COMPARTMENT

NBHA0033

NBHA0033S01



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SHA281FA


TROUBLE DIAGNOSES

Component Location (Cont'd)

PASSENGER COMPARTMENT Without Navigation System

NBHA0033S02

NBHA0033S0201




RHA498G

TROUBLE DIAGNOSES

Component Location (Cont'd)

With Navigation System

NBHA0033S0202



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


RHA857H

TROUBLE DIAGNOSES

Circuit Diagram (Without Navigation System)

Circuit Diagram (Without Navigation System)

NBHA0034



© : For Canada

MHA973A

TROUBLE DIAGNOSES

Wiring Diagram — A/C, A — (Without Navigation System)

Wiring Diagram — A/C, A — (Without Navigation System)

NBHA0035

HA-A/C,A-01

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS







BT

HA

SC

EL

IDX



REFER TO THE FOLLOWING.


- (E1) -SUPER MULTIPLE JUNCTION (SMJ)
- (E3) -FUSE BLOCK-JUNCTION BOX (J/B)
- (F24) -ELECTRICAL UNITS

TROUBLE DIAGNOSES


Wiring Diagram — A/C, A — (Without Navigation System) (Cont'd)

HA-A/C,A-02

— — — — — : DATA LINE



(M38) W (M55) W




REFER TO THE FOLLOWING.

(M10) - FUSE BLOCK-
JUNCTION BOX (J/B)


TROUBLE DIAGNOSES

Wiring Diagram — A/C, A — (Without Navigation System) (Cont'd)

HA-A/C,A-03



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX





REFER TO THE FOLLOWING.
(E1) - SUPER MULTIPLE JUNCTION (SMJ)

MHA976A

TROUBLE DIAGNOSES

Wiring Diagram — A/C, A — (Without Navigation System) (Cont'd)

HA-A/C,A-04



REFER TO THE FOLLOWING.

(M10) - FUSE BLOCK-
JUNCTION BOX (J/B)

MHA977A



TROUBLE DIAGNOSES

Wiring Diagram — A/C, A — (With Navigation System)

Wiring Diagram — A/C, A — (With Navigation System)

NBHA0114

HA-A/C,A-05



REFER TO THE FOLLOWING.

- (E1) - SUPER MULTIPLE JUNCTION (SMJ)
- (E3) - FUSE BLOCK-JUNCTION BOX (J/B)
- (F24) - ELECTRICAL UNITS


MHA047B

TROUBLE DIAGNOSES

Wiring Diagram — A/C, A — (With Navigation System) (Cont'd)



HA-A/C,A-06

— — — — — : DATA LINE



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT

HA
SC
EL
IDX



REFER TO THE FOLLOWING.



(M10) - FUSE BLOCK-
JUNCTION BOX (J/B)

MHA048B

TROUBLE DIAGNOSES

Wiring Diagram — A/C, A — (With Navigation System) (Cont'd)

HA-A/C,A-07




REFER TO THE FOLLOWING.
 (E1) -SUPER MULTIPLE JUNCTION (SMJ)

MHA981A

TROUBLE DIAGNOSES

Wiring Diagram — A/C, A — (With Navigation System) (Cont'd)


HA-A/C,A-08



GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT

HA

SC
EL
IDX





REFER TO THE FOLLOWING.
 (M10) - FUSE BLOCK-
 JUNCTION BOX (J/B)

MHA982A

TROUBLE DIAGNOSES

Auto Amp. Terminals and Reference Value




Auto Amp. Terminals and Reference Value INSPECTION OF AUTO AMP.

NBHA0036

NBHA0036S01

- Measure voltage between each terminal and body ground by following "AUTO AMP. INSPECTION TABLE".

- Pin connector terminal layout



RHA839H

AUTO AMP. INSPECTION TABLE Without Navigation System

NBHA0036S02

NBHA0036S0201

TERMINAL NO.	ITEM	CONDITION	Voltage V	
1	Intake sensor	—	—	
2	Ambient sensor	—	—	
3	In-vehicle sensor	—	—	
6	ECM signal	Compressor: ON	Approximately 0	
		Compressor: OFF	Approximately 4.6	
8	Intake door position switch	Intake door position	FRESH	Approximately 0
			RECIRCULATION or 20% FRESH	Approximately 4.6
11	Sensor ground	—	Approximately 0	
12	Sunload sensor	—	—	

TROUBLE DIAGNOSES

Auto Amp. Terminals and Reference Value (Cont'd)

TERMINAL NO.	ITEM		CONDITION		Voltage V	
13	Thermal transmitter		Engine coolant temperature	Approximately 30°C (86°F)	Approximately 9.4	GI
				Approximately 55°C (131°F)	Approximately 6.5	MA
				Approximately 100°C (212°F)	Approximately 2.4	EM
14	Ground (for Canada)		—		Approximately 0	EM
16	A/C LAN signal		—		Approximately 5.5	LC
18	Intake door position switch		Intake door position	20% FRE or RECIRCULATION	Approximately 0	EC
				FRESH	Approximately 4.6	FE
19	Intake door position switch		Intake door position	RECIRCULATION or FRESH	Approximately 0	FE
				20% FRE	Approximately 4.6	AT
21	Power supply for mode door motor and air mix door motor		—		Approximately 12	AT
22	Compressor ON signal		Compressor	ON	Approximately 0	TF
				OFF	Approximately 4.6	PD
24	Power supply for illumination		Lighting switch	OFF	Approximately 0	PD
				1st	Approximately 12	AX
25	Illumination ground		—		Approximately 0	AX
26	Power supply for BAT		—		BATTERY VOLTAGE	SU
27	Power supply for IGN		—		Approximately 12	BR
28	Power supply for intake door motor		Intake door position	FRESH	Approximately 12	BR
				RECIRC	Approximately 0	ST
32	Ground		—		Approximately 0	ST
33	Power source for A/C		Ignition voltage feed back		Approximately 12	RS
34	Blower motor feed back		Fan speed: Low		Approximately 7 - 10	BT
35	Fan control AMP. control signal		Fan speed	Low, Middle low or Middle high	Approximately 2.5 - 3.0	BT
				High	Approximately 9 - 10	HA
36	Power supply for intake door motor		Intake door position	FRESH	Approximately 0	SC
				RECIRC	Approximately 12	EL

With Navigation System

NBHA0036S0202

TERMINAL NO.	ITEM		CONDITION		Voltage V	
1	Intake sensor		—		—	IDX
2	Ambient sensor		—		—	
3	In-vehicle sensor		—		—	

TROUBLE DIAGNOSES

Auto Amp. Terminals and Reference Value (Cont'd)

TERMINAL NO.	ITEM	CONDITION		Voltage V	
6	Intake door position switch		Intake door position	RECIRCULATION	Approximately 4.6
				FRESH or 20% FRESH	Approximately 0
7	Multiplex communication signal (AMP → NAVI)		—	—	
8	Multiplex communication signal (NAVI → AMP)		—	—	
9	Sensor ground		—	Approximately 0	
10	Sunload sensor		—	—	
11	Thermal transmitter		Engine coolant temperature	Approximately 30°C (86°F)	Approximately 9.4
				Approximately 55°C (131°F)	Approximately 6.5
				Approximately 100°C (212°F)	Approximately 2.4
				Approximately 110°C (230°F)	Approximately 1.9
14	A/C LAN signal		—	Approximately 5.5	
17	ECM signal		Compressor: ON	Approximately 0	
			Compressor: OFF	Approximately 4.6	
18	Intake door position switch		Intake door position	FRESH	Approximately 4.6
				RECIRCULATION or 20% FRESH	Approximately 0
19	Intake door position switch		Intake door position	20% FRESH	Approximately 4.6
				RECIRCULATION or FRESH	Approximately 0
20	Multiplex communication signal (CLK)		—	—	
21	Power supply for door motor		—	Approximately 12	
22	Compressor ON signal		Compressor: ON	Approximately 0	
			Compressor: OFF	Approximately 4.6	
24	Power supply for BAT		—	BATTERY VOLTAGE	

TROUBLE DIAGNOSES

Auto Amp. Terminals and Reference Value (Cont'd)

TERMINAL NO.	ITEM		CONDITION	Voltage V		
25	Power supply for IGN		—	Approximately 12	GI	
26	Power supply for intake door motor		Intake door position	FRE → REC	Approximately 12	MA
				REC → FRE	Approximately 0	
32	Ground			—	Approximately 0	EM
33	Power source for A/C			—	Approximately 12	
34	Blower motor feed back			Fan speed: Low	Approximately 7 - 10	LC
35	Fan control amp. control signal			Fan speed: Low, Middle low or Middle high	Approximately 2.5 - 3.0	EC
				Fan speed: High	Approximately 9 - 10	
36	Power supply for intake door motor		Intake door position	REC → FRE	Approximately 12	FE
				FRE → REC	Approximately 0	

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES

Self-diagnosis

Self-diagnosis

=NBHA0021

INTRODUCTION AND GENERAL DESCRIPTION


NBHA0021S01

The self-diagnostic system diagnoses sensors, door motors, blower motor, etc. by system line. Refer to applicable sections (items) for details. Shifting from normal control to the self-diagnostic system is accomplished by starting the engine (turning the ignition switch from “OFF” to “ON”) and pressing “OFF” switch for at least 5 seconds. The “OFF” switch must be pressed within 10 seconds after starting the engine (ignition switch is turned “ON”). This system will be canceled by either pressing (AUTO) (AUTO) switch or turning the ignition switch “OFF”. Shifting from one step to another is accomplished by means of pushing ▲ (HOT) or ▼ (COLD) switch, as required.

Additionally shifting from STEP 5 to AUXILIARY MECHANISM is accomplished by means of pushing ⚙️ (fan) UP switch.

Without Navigation System

NBHA0021S0101



RHA453GA

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)


STEP-BY-STEP PROCEDURE

Without Navigation System

=NBHA0021S02

NBHA0021S0201

1	SET IN SELF-DIAGNOSTIC MODE	
		<ol style="list-style-type: none"> 1. Turn ignition switch ON. 2. Set in self-diagnostic mode as follows. Within 10 seconds after starting engine (ignition switch is turned "ON"), press OFF switch for at least 5 seconds.
▶		GO TO 2.

2	STEP 1 - ALL LEDs AND SEGMENT ARE CHECKED	
		<p>Do all LEDs and segments illuminate?</p> <p style="text-align: center;">Display malfunction</p> <div style="text-align: center;">  </div> <p style="text-align: right;">RHA454G</p> <p style="text-align: center;">Yes or No</p>
Yes ▶		GO TO 3.
No ▶		Malfunctioning OFF switch, LED or fluorescent display tube. Replace A/C auto amp.

3	VERIFY ADVANCE TO SELF-DIAGNOSIS STEP 2	
		<ol style="list-style-type: none"> 1. Press ▲ (HOT) switch. 2. Does advance to self-diagnosis STEP 2? <p style="text-align: center;">Yes or No</p>
Yes ▶		GO TO 4.
No ▶		Malfunctioning ▲ (HOT) switch. Replace A/C auto amp.

4	VERIFY RETURN TO SELF-DIAGNOSIS STEP 1	
		<ol style="list-style-type: none"> 1. Press ▼ (COLD) switch. 2. Does return to self-diagnosis STEP 1? <p style="text-align: center;">Yes or No</p>
Yes ▶		GO TO 5.
No ▶		Malfunctioning ▼ (COLD) switch. Replace A/C auto amp.

TROUBLE DIAGNOSES


Self-diagnosis (Cont'd)

5	STEP 2 - SENSOR CIRCUITS ARE CHECKED FOR OPEN OR SHORT CIRCUIT	
Press  (HOT) switch. Does code No.  appear on the display?		
<p>Display (when all sensors are in good order)</p> <p>illuminates 25 seconds after "2" is illuminated.</p> <p>illuminates</p> 		
RHA970DB		
Yes or No		
Yes	▶	GO TO 6.
No	▶	GO TO 13.

6	STEP 3 - MODE DOOR AND INTAKE DOOR POSITIONS ARE CHECKED	
Press  (HOT) switch. Does code No.  appear on the display?		
<p>Display (when all doors are in good order)</p> <p>illuminates 50 seconds after "3" is shown on display.</p> <p>illuminates</p> 		
RHA869DD		
Yes or No		
Yes	▶	GO TO 7.
No	▶	GO TO 14.

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

7	STEP 4 - OPERATION OF EACH ACTUATOR IS CHECKED
<p>Press  (HOT) switch. Engine running. Press DEF switch, code No. of each actuator test is indicated on the display.</p> <p style="text-align: center;">Changes from "1" to "E".</p> <div style="text-align: center;"><p>Illuminates</p></div> <p style="text-align: right;">RHA495A</p>	
▶	GO TO 8.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


TROUBLE DIAGNOSES


Self-diagnosis (Cont'd)

8	CHECK ACTUATORS																																																
<p>Refer to the following chart and confirm discharge air flow, air temperature, blower motor voltage and compressor operation. Checks must be made visually, by listening to any noise, or by touching air outlets with your hand, etc. for improper operation.</p>																																																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 10%;">Code No.</th> <th colspan="5">Actuator test pattern</th> </tr> <tr> <th style="width: 15%;">Mode door</th> <th style="width: 15%;">Intake door</th> <th style="width: 15%;">Air mix door</th> <th style="width: 15%;">Blower motor</th> <th style="width: 15%;">Compressor</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">41</td> <td style="text-align: center;">VENT </td> <td style="text-align: center;">REC</td> <td style="text-align: center;">Full Cold</td> <td style="text-align: center;">4 - 5V</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">42</td> <td style="text-align: center;">B/L </td> <td style="text-align: center;">REC</td> <td style="text-align: center;">Full Cold</td> <td style="text-align: center;">9 - 11V</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">43</td> <td style="text-align: center;">B/L </td> <td style="text-align: center;">20% FRE</td> <td style="text-align: center;">Full Hot</td> <td style="text-align: center;">7 - 9V</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td style="text-align: center;">44</td> <td style="text-align: center;">FOOT </td> <td style="text-align: center;">FRE</td> <td style="text-align: center;">Full Hot</td> <td style="text-align: center;">7 - 9V</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td style="text-align: center;">45</td> <td style="text-align: center;">D/F </td> <td style="text-align: center;">FRE</td> <td style="text-align: center;">Full Hot</td> <td style="text-align: center;">7 - 9V</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">46</td> <td style="text-align: center;">DEF </td> <td style="text-align: center;">FRE</td> <td style="text-align: center;">Full Hot</td> <td style="text-align: center;">10 - 12V</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table>			Code No.	Actuator test pattern					Mode door	Intake door	Air mix door	Blower motor	Compressor	41	VENT 	REC	Full Cold	4 - 5V	ON	42	B/L 	REC	Full Cold	9 - 11V	ON	43	B/L 	20% FRE	Full Hot	7 - 9V	OFF	44	FOOT 	FRE	Full Hot	7 - 9V	OFF	45	D/F 	FRE	Full Hot	7 - 9V	ON	46	DEF 	FRE	Full Hot	10 - 12V	ON
Code No.	Actuator test pattern																																																
	Mode door	Intake door	Air mix door	Blower motor	Compressor																																												
41	VENT 	REC	Full Cold	4 - 5V	ON																																												
42	B/L 	REC	Full Cold	9 - 11V	ON																																												
43	B/L 	20% FRE	Full Hot	7 - 9V	OFF																																												
44	FOOT 	FRE	Full Hot	7 - 9V	OFF																																												
45	D/F 	FRE	Full Hot	7 - 9V	ON																																												
46	DEF 	FRE	Full Hot	10 - 12V	ON																																												
MTBL0200																																																	
<p>Discharge air flow</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 30%;">Mode control knob</th> <th colspan="3">Air outlet/distribution</th> </tr> <tr> <th style="width: 20%;">Face</th> <th style="width: 20%;">Foot</th> <th style="width: 20%;">Defroster</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;"></td> <td style="text-align: center;">100%</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;"></td> <td style="text-align: center;">60%</td> <td style="text-align: center;">40%</td> <td></td> </tr> <tr> <td style="text-align: center;"></td> <td></td> <td style="text-align: center;">80%</td> <td style="text-align: center;">20%</td> </tr> <tr> <td style="text-align: center;"></td> <td></td> <td style="text-align: center;">60%</td> <td style="text-align: center;">40%</td> </tr> <tr> <td style="text-align: center;"></td> <td></td> <td></td> <td style="text-align: center;">100%</td> </tr> </tbody> </table>			Mode control knob	Air outlet/distribution			Face	Foot	Defroster		100%				60%	40%				80%	20%			60%	40%				100%																				
Mode control knob	Air outlet/distribution																																																
	Face	Foot	Defroster																																														
	100%																																																
	60%	40%																																															
		80%	20%																																														
		60%	40%																																														
			100%																																														
MTBL0044																																																	
OK or NG																																																	
OK	▶	GO TO 9.																																															
NG	▶	<ul style="list-style-type: none"> ● Air outlet does not change. Go to "Mode Door Motor" (HA-75). ● Intake door does not change. Go to "Intake Door Motor" (HA-87). ● Blower motor operation is malfunctioning. Go to "Blower Motor" (HA-95). ● Magnet clutch does not engage. Go to "Magnet Clutch" (HA-104). ● Discharge air temperature does not change. Go to "Air Mix Door Motor" (HA-82). 																																															

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)


9	STEP 5 - TEMPERATURE OF EACH SENSOR IS CHECKED
<p>Press (HOT) switch. Code No. 5 appears on the display.</p> <div style="text-align: center; margin: 20px 0;">  </div> <p style="text-align: right;">RHA492A</p>	
▶	GO TO 10.


10	CHECK AMBIENT SENSOR
<p>Press (DEF) switch one time, temperature detected by ambient sensor is indicated on the display. ECON shown in display indicates negative temperature reading.</p> <p>NOTE: If temperature shown on display greatly differs from actual temperature, check sensor circuit first, then inspect sensor.</p> <div style="text-align: center; margin: 20px 0;">  </div> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 11.
NG	▶ Go to Ambient Sensor Circuit (HA-129).

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

11	CHECK IN-VEHICLE SENSOR
<p>Press  (DEF) switch the second time, temperature detected by in-vehicle sensor is indicated on the display screen. ECON shown in display indicates negative temperature reading.</p> <p>NOTE: If temperature shown on display greatly differs from actual temperature, check sensor circuit first, then inspect sensor.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">RHA500G</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 12.
NG	▶ Go to In-vehicle Sensor Circuit (HA-132).

12	CHECK INTAKE SENSOR
<p>Press  (DEF) switch the third time, temperature detected by intake sensor is indicated on the display.</p> <p>NOTE: If temperature shown on display greatly differs from actual temperature, check sensor circuit first, then inspect sensor.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">RHA500GB</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ <ol style="list-style-type: none"> 1. Press  (DEF) switch the fourth time. Display returns to original presentation 5. 2. Turn ignition switch OFF or  (AUTO) switch ON. 3. END
NG	▶ Go to Intake Sensor Circuit (HA-139).

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

13 CHECK MALFUNCTIONING SENSOR

Refer to the following chart for malfunctioning code No.
(If two or more sensors malfunction, corresponding code Nos. blink respectively two times.)

Code No.	Malfunctioning sensor (including circuits)	Reference page
21	Ambient sensor	*2
-21		
22	In-vehicle sensor	*3
-22		
24	Intake sensor	*4
-24		
25	Sunload sensor*1	*5
-25		
26	Air mix door motor (LCU) PBR	*6
-26		

MTBL0083

***1: Conduct self-diagnosis STEP 2 under sunshine.**

When conducting indoors, aim a light (more than 60W) at sunload sensor, otherwise Code No. 25 will indicate despite that sunload sensor is functioning properly.

*2: HA-129


*3: HA-132

*4: HA-139

*5: HA-135

*6: HA-141

Display (when sensor malfunctions)



RHA455G

RHA501A



INSPECTION END

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

14	CHECK MALFUNCTIONING DOOR MOTOR POSITION SWITCH		
<p>Mode or (and) intake door motor position switch(es) is (are) malfunctioning. (If two or more mode or intake doors are out of order, corresponding code numbers blink respectively two times.)</p>			
Code No. *1 *2	Mode or intake door position	Mode door motor	Reference page
31	VENT 	Mode door motor	*3
32	B/L 		
34	FOOT 		
35	D/F 		
36	DEF 		
37	FRE	Intake door motor	*4
38	20% FRE		
39	REC 		


MTBL0508

*1: If mode door motor harness connector is disconnected, the following display pattern will appear.
31 → 32 → 34 → 35 → 36 → Return to 31


*2: If intake door motor harness connector is disconnected, the following display pattern will appear.
37 → 38 → 39 → Return to 37

*3: HA-75
 *4: HA-87

Display (when a door is out of order) Code No. (blinks)



RHA168DA



RHA498A

▶ INSPECTION END

AUXILIARY MECHANISM: TEMPERATURE SETTING TRIMMER

=NBHA0021S03


Without Navigation System

NBHA0021S0301

The trimmer compensates for differences in range of $\pm 3^{\circ}\text{C}$ ($\pm 6^{\circ}\text{F}$) between temperature setting (displayed digitally) and temperature felt by driver.

Operating procedures for this trimmer are as follows:

- Begin Self-diagnosis STEP 5 mode.
- Press  (fan) UP switch to set system in auxiliary mode.
- Display shows "51" in auxiliary mechanism. It takes approximately 3 seconds.
- Press either  (HOT) or  (COLD) switch as desired. Temperature will change at a rate of 0.5°C (1°F) each time a switch is pressed.



SHA197E

When battery cable is disconnected, trimmer operation is canceled. Temperature set becomes that of initial condition, i.e. 0°C (0°F).

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)


INTRODUCTION AND GENERAL DESCRIPTION

NBHA0021S04

The self-diagnostic system diagnoses sensors, door motors, blower motor, etc. by system line. Refer to applicable sections (items) for details. Shifting from normal control to the self-diagnostic system is accomplished by starting the engine (turning the ignition switch from "OFF" to "ON") and pressing "OFF" switch for at least 5 seconds. The "OFF" switch must be pressed within 10 seconds after starting the engine (ignition switch is turned "ON"). This system will be canceled by either pressing "AUTO" (AUTO) switch or turning the ignition switch "OFF". Shifting from one step to another is accomplished by means of turning temperature dial, as required. Additionally shifting from STEP 5 to AUXILIARY MECHANISM is accomplished by means of pushing  (fan) UP switch.

With Navigation System

NBHA0021S0401



RHA859H


STEP-BY-STEP PROCEDURE

With Navigation System

NBHA0021S05

NBHA0021S0501

1	SET IN SELF-DIAGNOSTIC MODE
<ol style="list-style-type: none"> 1. Turn ignition switch ON. 2. Set in self-diagnostic mode as follows. Within 10 seconds after starting engine (ignition switch is turned "ON".), press OFF switch for at least 5 seconds. 	
▶	GO TO 2.

2	STEP 1 - ALL LEDs AND DISPLAY SCREEN ARE CHECKED
<p>When switch's LED and display are functioning properly in STEP-1, LED and display will come on.</p>	
	
RHA860H	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Malfunctioning OFF switch, LED or fluorescent display tube. Go to "Main Power Supply and Ground Circuit Check", HA-72.

3	VERIFY ADVANCE TO SELF-DIAGNOSIS STEP 2
<ol style="list-style-type: none"> 1. Turn temperature dial clockwise. 2. Does advance to self-diagnosis STEP 2? 	
Yes or No	
Yes	▶ GO TO 4.
No	▶ Malfunctioning temperature dial. Check Display & NAVI control unit.

4	VERIFY RETURN TO SELF-DIAGNOSIS STEP 1
<ol style="list-style-type: none"> 1. Turn temperature dial counterclockwise. 2. Does return to self-diagnosis STEP 1? 	
Yes or No	
Yes	▶ GO TO 5.
No	▶ Malfunctioning temperature dial. Check Display & NAVI control unit.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

5	STEP 2 - SENSOR CIRCUITS ARE CHECKED FOR OPEN OR SHORT CIRCUIT	
<p>Turn temperature dial clockwise. Does code No. 20 appear on the display?</p>		
<p>Display (when all sensors are in good order)</p> <p>illuminates 25 seconds after "2" is illuminated.</p> <p>illuminates</p> 		
RHA970DB		
Yes or No		
Yes	▶	GO TO 6.
No	▶	GO TO 14.

6	STEP 3 - MODE DOOR AND INTAKE DOOR POSITIONS ARE CHECKED	
<p>Turn temperature dial clockwise. Does code No. 30 appear on the display?</p>		
<p>Display (when all doors are in good order)</p> <p>illuminates 50 seconds after "3" is shown on display.</p> <p>illuminates</p> 		
RHA869DD		
Yes or No		
Yes	▶	GO TO 7.
No	▶	GO TO 15.

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

7	STEP 4 - OPERATION OF EACH ACTUATOR IS CHECKED
<p>Turn temperature dial clockwise. Engine running. Press DEF switch, code No. of each actuator test is indicated on the display.</p> <p style="text-align: center;">Changes from "I" to "E".</p> <div style="text-align: center;"></div> <p style="text-align: right;">RHA495A</p>	
▶	GO TO 8.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)


8	CHECK ACTUATORS																																																
<p>Refer to the following chart and confirm discharge air flow, air temperature, blower motor voltage and compressor operation. Checks must be made visually, by listening to any noise, or by touching air outlets with your hand, etc. for improper operation.</p>																																																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 10%;">Code No.</th> <th colspan="5">Actuator test pattern</th> </tr> <tr> <th style="width: 15%;">Mode door</th> <th style="width: 15%;">Intake door</th> <th style="width: 15%;">Air mix door</th> <th style="width: 15%;">Blower motor</th> <th style="width: 15%;">Compressor</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">41</td> <td style="text-align: center;">VENT </td> <td style="text-align: center;">REC</td> <td style="text-align: center;">Full Cold</td> <td style="text-align: center;">4 - 5V</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">42</td> <td style="text-align: center;">B/L </td> <td style="text-align: center;">REC</td> <td style="text-align: center;">Full Cold</td> <td style="text-align: center;">9 - 11V</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">43</td> <td style="text-align: center;">B/L </td> <td style="text-align: center;">20% FRE</td> <td style="text-align: center;">Full Hot</td> <td style="text-align: center;">7 - 9V</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td style="text-align: center;">44</td> <td style="text-align: center;">FOOT </td> <td style="text-align: center;">FRE</td> <td style="text-align: center;">Full Hot</td> <td style="text-align: center;">7 - 9V</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td style="text-align: center;">45</td> <td style="text-align: center;">D/F </td> <td style="text-align: center;">FRE</td> <td style="text-align: center;">Full Hot</td> <td style="text-align: center;">7 - 9V</td> <td style="text-align: center;">ON</td> </tr> <tr> <td style="text-align: center;">46</td> <td style="text-align: center;">DEF </td> <td style="text-align: center;">FRE</td> <td style="text-align: center;">Full Hot</td> <td style="text-align: center;">10 - 12V</td> <td style="text-align: center;">ON</td> </tr> </tbody> </table>			Code No.	Actuator test pattern					Mode door	Intake door	Air mix door	Blower motor	Compressor	41	VENT 	REC	Full Cold	4 - 5V	ON	42	B/L 	REC	Full Cold	9 - 11V	ON	43	B/L 	20% FRE	Full Hot	7 - 9V	OFF	44	FOOT 	FRE	Full Hot	7 - 9V	OFF	45	D/F 	FRE	Full Hot	7 - 9V	ON	46	DEF 	FRE	Full Hot	10 - 12V	ON
Code No.	Actuator test pattern																																																
	Mode door	Intake door	Air mix door	Blower motor	Compressor																																												
41	VENT 	REC	Full Cold	4 - 5V	ON																																												
42	B/L 	REC	Full Cold	9 - 11V	ON																																												
43	B/L 	20% FRE	Full Hot	7 - 9V	OFF																																												
44	FOOT 	FRE	Full Hot	7 - 9V	OFF																																												
45	D/F 	FRE	Full Hot	7 - 9V	ON																																												
46	DEF 	FRE	Full Hot	10 - 12V	ON																																												
MTBL0200																																																	
<p>Discharge air flow</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="width: 30%;">Mode control knob</th> <th colspan="3">Air outlet/distribution</th> </tr> <tr> <th style="width: 20%;">Face</th> <th style="width: 20%;">Foot</th> <th style="width: 20%;">Defroster</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;"></td> <td style="text-align: center;">100%</td> <td></td> <td></td> </tr> <tr> <td style="text-align: center;"></td> <td style="text-align: center;">60%</td> <td style="text-align: center;">40%</td> <td></td> </tr> <tr> <td style="text-align: center;"></td> <td></td> <td style="text-align: center;">80%</td> <td style="text-align: center;">20%</td> </tr> <tr> <td style="text-align: center;"></td> <td></td> <td style="text-align: center;">60%</td> <td style="text-align: center;">40%</td> </tr> <tr> <td style="text-align: center;"></td> <td></td> <td></td> <td style="text-align: center;">100%</td> </tr> </tbody> </table>			Mode control knob	Air outlet/distribution			Face	Foot	Defroster		100%				60%	40%				80%	20%			60%	40%				100%																				
Mode control knob	Air outlet/distribution																																																
	Face	Foot	Defroster																																														
	100%																																																
	60%	40%																																															
		80%	20%																																														
		60%	40%																																														
			100%																																														
MTBL0044																																																	
OK or NG																																																	
OK	▶	GO TO 9.																																															
NG	▶	<ul style="list-style-type: none"> ● Air outlet does not change. Go to "Mode Door Motor" (HA-75). ● Intake door does not change. Go to "Intake Door Motor" (HA-87). ● Blower motor operation is malfunctioning. Go to "Blower Motor" (HA-95). ● Magnet clutch does not engage. Go to "Magnet Clutch" (HA-104). ● Discharge air temperature does not change. Go to "Air Mix Door Motor" (HA-82). 																																															

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

9	STEP 5 - TEMPERATURE OF EACH SENSOR IS CHECKED		
<p>Turn temperature dial clockwise. Code No. 5 appears on the display.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">RHA492A</p>			
▶		GO TO 10.	

GI
MA
EM
LC
EC
FE

10	CHECK AMBIENT SENSOR		
<p>Press  (DEF) switch one time, temperature detected by ambient sensor is indicated on the display. ECON shown in display indicates negative temperature reading.</p> <p>NOTE: If temperature shown on display greatly differs from actual temperature, check sensor circuit first, then inspect sensor.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">RHA861H</p> <p style="text-align: center;">OK or NG</p>			
▶		GO TO 11.	
▶		Go to Ambient Sensor Circuit (HA-129).	


AT
TF
PD
AX
SU
BR
ST
RS


HA

SC
EL
IDX

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

11	CHECK IN-VEHICLE SENSOR
<p>Press  (DEF) switch the second time, temperature detected by in-vehicle sensor is indicated on the display screen. ECON shown in display indicates negative temperature reading.</p> <p>NOTE: If temperature shown on display greatly differs from actual temperature, check sensor circuit first, then inspect sensor.</p> <div style="text-align: center;"></div> <p style="text-align: right;">RHA862H</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 12.
NG	▶ Go to In-vehicle Sensor Circuit (HA-132).

12	CHECK INTAKE SENSOR
<p>Press  (DEF) switch the third time, temperature detected by intake sensor is indicated on the display.</p> <p>NOTE: If temperature shown on display greatly differs from actual temperature, check sensor circuit first, then inspect sensor.</p> <div style="text-align: center;"></div> <p style="text-align: right;">RHA862HA</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 13.
NG	▶ Go to Intake Sensor Circuit (HA-139).

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

13	DETECTS MULTIPLEX COMMUNICATION ERROR									
Press REC switch. Does code No. 52 appears on the display										
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 30%;">Display</th> <th>Signal direction</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">52</td> <td>In good order</td> </tr> <tr> <td style="text-align: center;">52 </td> <td>Display & NAVI control unit → Auto amp.</td> </tr> <tr> <td style="text-align: center;">52 </td> <td>Auto amp. → Display & NAVI control unit</td> </tr> </tbody> </table>			Display	Signal direction	52	In good order	52	Display & NAVI control unit → Auto amp.	52	Auto amp. → Display & NAVI control unit
Display	Signal direction									
52	In good order									
52	Display & NAVI control unit → Auto amp.									
52	Auto amp. → Display & NAVI control unit									
MTBL0509										
Yes or No										
Yes	▶	INSPECTION END								
No	▶	1. Go to "Multiplex Communication Circuit", HA-142. 2. Go to "OPERATIONAL CHECK", HA-66. Confirm that A/C system is in good order.								

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

14 CHECK MALFUNCTIONING SENSOR

Refer to the following chart for malfunctioning code No.
(If two or more sensors malfunction, corresponding code Nos. blink respectively two times.)

Code No.	Malfunctioning sensor (including circuits)	Reference page
21	Ambient sensor	*2
-21		
22	In-vehicle sensor	*3
-22		
24	Intake sensor	*4
-24		
25	Sunload sensor*1	*5
-25		
26	Air mix door motor (LCU) PBR	*6
-26		

MTBL0083

***1: Conduct self-diagnosis STEP 2 under sunshine.**

When conducting indoors, aim a light (more than 60W) at sunload sensor, otherwise Code No. 25 will indicate despite that sunload sensor is functioning properly.

*2: HA-129


*3: HA-132

*4: HA-139

*5: HA-135

*6: HA-141

Display (when sensor malfunctions)



RHA455G

RHA501A



INSPECTION END

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

15 CHECK MALFUNCTIONING DOOR MOTOR POSITION SWITCH

Mode or (and) intake door motor position switch(es) is (are) malfunctioning.
(If two or more mode or intake doors are out of order, corresponding code numbers blink respectively two times.)

Code No. *1 *2	Mode or intake door position	Reference page
31	VENT 	*3
32	B/L 	
34	FOOT 	
35	D/F 	
36	DEF 	
37	FRE	*4
38	20% FRE	
39	REC 	

MTBL0508

*1: If mode door motor harness connector is disconnected, the following display pattern will appear.

31 → 32 → 34 → 35 → 36 → Return to 31



*2: If intake door motor harness connector is disconnected, the following display pattern will appear.

37 → 38 → 39 → Return to 37

*3: HA-75

*4: HA-87

Display (when a door is out of order)



RHA168DA

RHA498A



INSPECTION END

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSES

Self-diagnosis (Cont'd)

AUXILIARY MECHANISM: TEMPERATURE SETTING TRIMMER

=NBHA0021S06


With Navigation System

NBHA0021S0601

The trimmer compensates for differences in range of $\pm 3^{\circ}\text{C}$ ($\pm 6^{\circ}\text{F}$) between temperature setting (displayed digitally) and temperature felt by driver.

Operating procedures for this trimmer are as follows:

- Begin Self-diagnosis STEP 5 mode.
- Press  (fan) UP switch to set system in auxiliary mode.
- Display shows "51" in auxiliary mechanism. It takes approximately 3 seconds.
- Turn the temperature dial clockwise or counterclockwise: Temperature will change at a rate of 0.5°C (1°F).



RHA863H

When battery cable is disconnected, trimmer operation is canceled. Temperature set becomes that of initial condition, i.e. 0°C (0°F).

TROUBLE DIAGNOSES


How to Perform Trouble Diagnoses for Quick and Accurate Repair

How to Perform Trouble Diagnoses for Quick and Accurate Repair

=NBHA0018

NBHA0018S01

WORK FLOW



SHA900E

*1: Operational Check (HA-66)

SYMPTOM TABLE

NBHA0018S02

Symptom	Reference Page
● A/C system does not come on.	● Go to Trouble Diagnosis Procedure for A/C system. HA-71
● Air outlet does not change.	● Go to Trouble Diagnosis Procedure for Mode Door Motor. (LAN) HA-75
● Mode door motor does not operate normally.	
● Discharge air temperature does not change.	● Go to Trouble Diagnosis Procedure for Air Mix Door Motor. (LAN) HA-82
● Air mix door motor does not operate normally.	
● Intake door does not change.	● Go to Trouble Diagnosis Procedure for Intake Door Motor. HA-87
● Intake door motor does not operate normally.	
● Blower motor operation is malfunctioning.	● Go to Trouble Diagnosis Procedure for Blower Motor. HA-95
● Blower motor operation is malfunctioning under out of starting fan speed control.	
● Magnet clutch does not engage.	● Go to Trouble Diagnosis Procedure for Magnet Clutch. HA-104
● Insufficient cooling.	● Go to Trouble Diagnosis Procedure for Insufficient Cooling. HA-112
● Insufficient heating.	● Go to Trouble Diagnosis Procedure for Insufficient Heating. HA-121
● Noise.	● Go to Trouble Diagnosis Procedure for Noise. HA-123
● Self-diagnosis can not be performed.	● Go to Trouble Diagnosis Procedure for Self-diagnosis. HA-124
● Memory function does not operate.	● Go to Trouble Diagnosis Procedure for Memory Function. HA-126
● ECON mode does not operate.	● Go to Trouble Diagnosis Procedure for ECON (ECONOMY) — mode. HA-128

TROUBLE DIAGNOSES

Operational Check

Operational Check





NBHA0019

The purpose of the operational check is to confirm that the system operates properly.

CONDITIONS:

NBHA0019S01

- Engine running and at normal operating temperature.



PROCEDURE:

NBHA0019S02

1. Check Memory Function

NBHA0019S0201

1. Set the temperature 85°F or 32°C.
2. Press OFF switch.
3. Turn the ignition off.
4. Turn the ignition on.
5. Press the AUTO switch.
6. Confirm that the set temperature remains at previous temperature.
7. Press OFF switch.

If NG, go to trouble diagnosis procedure for memory function (HA-126).

If OK, continue with next check.



2. Check Blower

NBHA0019S0202

1. Press fan switch (up side) one time.
Blower should operate on low speed.
The fan symbol should have one blade lit.
2. Press fan switch (up side) one more time, and continue checking blower speed and fan symbol until all speeds are checked.
3. Leave blower on MAX speed.

If NG, go to trouble diagnosis procedure for blower motor (HA-95).
If OK, continue with next check.

NBHA0019S0203



3. Check Discharge Air

1. Press MODE switch four times and D/F button.
2. Each position indicator should change shape.

3. Confirm that discharge air comes out according to the air distribution table at left.
Refer to "Discharge Air Flow" (HA-25).

NOTE:

Confirm that the compressor clutch is engaged (visual inspection) and intake door position is at FRESH when the DEF is selected.

Intake door position is checked in the next step.

If NG, go to trouble diagnosis procedure for mode door motor (HA-75).

If OK, continue with next check.

Discharge air flow

Mode control knob	Air outlet/distribution		
	Face	Foot	Defroster
	100%	-	-
	60%	40%	-
	-	80%	20%
	-	60%	40%
	-	-	100%

RHA654F

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

TROUBLE DIAGNOSES

Operational Check (Cont'd)





4. Check Recirculation

NBHA0019S0204

1. Press REC  switch.
Recirculation indicator should illuminate.
2. Listen for intake door position change (you should hear blower sound change slightly).

If NG, go to trouble diagnosis procedure for intake door (HA-87).
If OK, continue with next check.



5. Check Temperature Decrease

NBHA0019S0205

Without Navigation System

- 1) Press the temperature decrease button until 18°C (65°F) is displayed.
- 2) Check for cold air at discharge air outlets.

If NG, go to trouble diagnosis procedure for insufficient cooling (HA-112).


If OK, continue with next check.

With Navigation System





- Turn the temperature dial counterclockwise until 18°C (65°F) is displayed.
- Check for cold air at discharge air outlets.

If NG, go to trouble diagnosis procedure for insufficient cooling (HA-112).

If OK, continue with next check.



NBHA0019S0206



6. Check Temperature Increase

Without Navigation System

- Press the temperature increase button until 32°C (85°F) is displayed.
- Check for hot air at discharge air outlets.

If NG, go to trouble diagnosis procedure for insufficient heating (HA-121).

If OK, continue with next check.

With Navigation System

- Turn the temperature dial clockwise until 32°C (85°F) is displayed.
- Check for hot air at discharge air outlets.

If NG, go to trouble diagnosis procedure for insufficient heating (HA-121).

If OK, continue with next check.

7. Check ECON (Economy) Mode

NBHA0019S0207

1. Set the temperature 75°F or 25°C.
2. Press ECON switch.
3. Display should indicate ECON (no AUTO).
Confirm that the compressor clutch is not engaged (visual inspection).
(Discharge air and blower speed will depend on ambient, in-vehicle and set temperatures.)

If NG, go to trouble diagnosis procedure for ECON (Economy) mode (HA-128).

If OK, continue with next check.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA




SC

EL

IDX

TROUBLE DIAGNOSES

Operational Check (Cont'd)



8. Check AUTO Mode

NBHA0019S0208

1. Press AUTO switch.
2. Display should indicate AUTO (no ECON).
Confirm that the compressor clutch engages (audio or visual inspection).
(Discharge air and blower speed will depend on ambient, in-vehicle and set temperatures.)

If NG, go to trouble diagnosis procedure for A/C system (HA-71), then if necessary, trouble diagnosis procedure for magnet clutch (HA-104).

9. Check Ambient Display (With Navigation System)

NBHA0019S0209

1. Press AUTO switch.
2. Press AMB switch.
3. Display should show the outside (ambient) temperature for approximately 5 seconds.

If NG, go to trouble diagnosis procedure for multiplex communication circuit (HA-142).

If all operational check are OK (symptom can not be duplicated), go to "Incident Simulation Tests" (GI section) and perform tests as outlined to simulate driving conditions environment. If symptom appears, refer to "Symptom Table" (HA-65) and perform applicable trouble diagnosis procedures.

A/C System

TROUBLE DIAGNOSIS PROCEDURE FOR A/C SYSTEM

=NBHA0089


SYMPTOM:

- A/C system does not come on.

INSPECTION FLOW

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1. Confirm symptom by performing the following operational check.




OPERATIONAL CHECK – AUTO mode

- a. Press AUTO switch.
- b. Display should indicate AUTO (not ECON). Confirm that the compressor clutch engages (audio or visual inspection). (Discharge air and blower speed will depend on ambient, in-vehicle and set temperatures.)

If OK (symptom cannot be duplicated), perform complete operational check (*2).

If NG (symptom is confirmed), continue with STEP-2 following.



2. Check for any service bulletins.

3. Check Main Power Supply and Ground Circuit. (*1)

Without navigation system

With navigation system

4. Check Multiplex Communication Circuit (*3).

OK

5. Replace auto amp.

*1: HA-72





*2: HA-66

*3: HA-142

RHA866H

TROUBLE DIAGNOSES

A/C System (Cont'd)



MAIN POWER SUPPLY AND GROUND CIRCUIT CHECK

Component Description

NBHA0037

NBHA0037S01

Automatic Amplifier (Auto Amp.)

NBHA0037S0101

The auto amplifier has a built-in microcomputer which processes information sent from various sensors needed for air conditioner operation. The air mix door motor, mode door motor, intake door motor, blower motor and compressor are then controlled.

The auto amplifier is unitized with control mechanisms. Signals from various switches and Potentio Temperature Control (PTC) are directly entered into auto amplifier.


Self-diagnostic functions are also built into auto amplifier to provide quick check of malfunctions in the auto air conditioner system.

Potentio Temperature Control (PTC)

NBHA0037S0102

The PTC is built into the A/C auto amp. or Display & NAVI control unit. It can be set at an interval of 0.5°C (1.0°F) in the 18°C (65°F) to 32°C (85°F) temperature range by pushing the temperature button. The set temperature is digitally displayed.

NBHA0107



DIAGNOSTIC PROCEDURE

SYMPTOM:

- A/C system does not come on.

GI

MA

EM


LC

EC

FE

AT

TF



Auto Amp. Check

NBHA0107S01

Check power supply circuit for auto amp. with ignition switch ON. Measure voltage across terminal Nos. 26, 27, 33 (24, 25, 33) and body ground.

PD

AX

Voltmeter terminal		Voltage
(+)	(-)	
26 (24)	Body ground	Approx. 12V
27 (25)		
33 (33)		

SU

BR

ST

RS

BT

HA

SC

EL

IDX


TROUBLE DIAGNOSES

A/C System (Cont'd)

Without navigation system




Auto amp. connector (M102)



Auto amp. connector (M103)

Canada only



SHA967EE

Check body ground circuit for auto amp. with ignition switch OFF. Check for continuity between terminal Nos. 32, 14 and body ground.

Ohmmeter terminal		Continuity
(+)	(-)	
32	Body ground	Yes
14 (Canada only)		

If OK, check auto amp. ground circuit, see below.

- If NG, check 7.5A fuses (Nos. 11 and 24, located in the fuse block) and 15A fuses (Nos. 1 and 2, located in the fuse block).
- If fuses are OK, check for open circuit in wiring harness. Repair or replace as necessary.
- If fuses are NG, replace fuse and check wiring harness for short circuit. Repair or replace as necessary.

NOTE:


If OK, replace auto amp.

If NG, repair or replace harness.

With navigation system



Auto amp. connector (M105)



RHA868H

Mode Door Motor

TROUBLE DIAGNOSIS PROCEDURE FOR MODE DOOR MOTOR (LAN)

=NBHA0090

SYMPTOM:

- Air outlet does not change.
- Mode door motor does not operate normally.


Inspection Flow

Without Navigation System

NBHA0090S01

NBHA0090S0101

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Discharge air

- a. Press mode switch four times and DEF button.
- b. Each position indicator should change shape.


Discharge air flow

Mode control knob	Air outlet/distribution		
	Face	Foot	Defroster
	100%	-	-
	60%	40%	-
	-	80%	20%
	-	60%	40%
	-	-	100%

- c. Confirm that discharge air comes out according to the air distribution table at left.
Refer to "Discharge Air Flow" (*1).

NOTE:

- If OK (symptom cannot be duplicated), perform complete operational check (*2).
- If NG (symptom is confirmed), continue with STEP-2 following.
- Confirm that the compressor clutch is engaged (visual inspection) and intake door position is at FRESH when DEF is selected.
Intake door position is checked in the next step.



*1: HA-25
*2: HA-66
*3: HA-44
*4: HA-45
*5: HA-129

*6: HA-132
*7: HA-135
*8: HA-141
*9: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.
*10: HA-78
*11: HA-81
*12: HA-66
*13: HA-65
*14: HA-139

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


TROUBLE DIAGNOSES

Mode Door Motor (Cont'd)

With Navigation System

NBHA0090S0102

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Discharge air

- Press mode switch four times and DEF button.
- Each position indicator should change shape.

c. Confirm that discharge air comes out according to the air distribution table at left.


Refer to “Discharge Air Flow” (*1).

NOTE:

- If OK (symptom cannot be duplicated), perform complete operational check (*2).
- If NG (symptom is confirmed), continue with STEP-2 following.
- Confirm that the compressor clutch is engaged (visual inspection) and intake door position is at FRESH when DEF is selected. Intake door position is checked in the next step.

Discharge air flow

Mode control knob	Air outlet/distribution		
	Face	Foot	Defroster
	100%	–	–
	60%	40%	–
	–	80%	20%
	–	60%	40%
	–	–	100%



RHA869H

- *1: HA-25
- *2: HA-66
- *3: HA-44
- *4: HA-45
- *5: HA-129

- *6: HA-132
- *7: HA-135
- *8: HA-141
- *9: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.

- *10: HA-78
- *11: HA-81
- *12: HA-66
- *13: HA-65
- *14: HA-139

SYSTEM DESCRIPTION

Component Parts


Mode door control system components are:

- 1) Auto amp.
- 2) Mode door motor (LCU)
- 3) In-vehicle sensor
- 4) Ambient sensor
- 5) Sunload sensor
- 6) Intake sensor

System Operation

The auto amplifier receives data from each of the sensors. The amplifier sends air mix door and mode door opening angle data to the air mix door motor LCU and mode door motor LCU.

The air mix door motor and mode door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amplifier and each of the motor position sensors are compared by the LCUs in each motor with the existing decision and opening angles. Subsequently, HOT/COLD or DEFROST/VENT operation is selected. The new selection data is returned to the auto amplifier.



RHA870H

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

TROUBLE DIAGNOSES

Mode Door Motor (Cont'd)

Mode Door Control Specification


NBHA0052S03



COMPONENT DESCRIPTION

NBHA0053

The mode door motor is attached to the heater unit. It rotates so that air is discharged from the outlet set by the auto amplifier. Motor rotation is conveyed to a link which activates the mode door.





DIAGNOSTIC PROCEDURE FOR MODE DOOR MOTOR AND AIR MIX DOOR MOTOR CIRCUIT



NBHA0104

SYMPTOM: Mode door motor and/or air mix door motor does not operate normally.

TROUBLE DIAGNOSES

Mode Door Motor (Cont'd)


1	CHECK POWER SUPPLY FOR AUTO AMP. (LCU) SIDE		
Do approx. 12 volts exist between auto amp. (LCU) harness terminal No. 21 and body ground?			
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 20%;">  <p>CONNECT</p>    </div> <div style="width: 40%; text-align: center;"> <p>Auto amp. connector (M102)</p>  <p>Without navigation system</p> </div> <div style="width: 40%; text-align: center;"> <p>Auto amp. connector (M105)</p>  <p>With navigation system</p> </div> </div>			
RHA819H			
NOTE:			
If the result is NG or No after checking circuit continuity, repair harness or connector.			
Yes or No			
Yes	▶	GO TO 2.	
No	▶	Replace auto amp. (LCU).	



2	CHECK SIGNAL FOR AUTO AMP. (LCU) SIDE		
Do approx. 5.5 volts exist between auto amp. (LCU) terminals No. 16 or 14 and body ground?			
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="width: 20%;">  <p>CONNECT</p>    </div> <div style="width: 40%; text-align: center;"> <p>Auto amp. connector (M103)</p>  <p>Without navigation system</p> </div> <div style="width: 40%; text-align: center;"> <p>Auto amp. connector (M104)</p>  <p>With navigation system</p> </div> </div>			
RHA820H			
NOTE:			
If the result is NG or No after checking circuit continuity, repair harness or connector.			
Yes or No			
Yes	▶	GO TO 3.	
No	▶	Replace auto amp. (LCU).	


GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Mode Door Motor (Cont'd)

3	CHECK POWER SUPPLY FOR MOTOR SIDE
<p>Do approx. 12 volts exist between door motor (LCU) harness terminal No. 21 and body ground?</p> <div style="text-align: center;">  <p>Mode door motor connector (M38) or air mix door motor connector (M55)</p>  </div> <p style="text-align: right;">RHA489GC</p>	
Yes or No	
Yes	▶ GO TO 4.
No	▶ Repair harness or connector.

4	CHECK SIGNAL FOR MOTOR SIDE
<p>Do approx. 5.5 volts exist between door motor (LCU) terminal No. 16 and body ground?</p> <div style="text-align: center;">  <p>Mode door motor connector (M38) or air mix door motor connector (M55)</p>  </div> <p style="text-align: right;">RHA490G</p>	
Yes or No	
Yes	▶ GO TO 5.
No	▶ Repair harness or connector.

5	CHECK MOTOR GROUND CIRCUIT
<p>Does continuity exist between door motor (LCU) harness terminal No. 32 and body ground?</p> <div style="text-align: center;">  <p>Mode door motor connector (M38) or air mix door motor connector (M55)</p>  </div> <p style="text-align: right;">RHA491G</p>	
Yes or No	
Yes	▶ GO TO 6.
No	▶ Repair harness or connector.

TROUBLE DIAGNOSES

Mode Door Motor (Cont'd)

6	CHECK MOTOR OPERATION	
Disconnect and reconnect the motor connector and confirm the motor operation.		
OK or NG		
OK (Return to operate normally)	▶	Poor contacting the motor connector
NG (Does not operate normally)	▶	GO TO 7.


GI
MA
EM

7	CHECK MODE DOOR MOTOR OPERATION	
1. Disconnect the mode door motor and air mix door motor connector. 2. Reconnect the mode door motor and confirm the motor operation.		
OK or NG		
OK (Mode door motor operates normally)	▶	Replace the air mix door motor.
NG (Mode door motor does not operate normally)	▶	GO TO 8.

LC
EC
FE
AT

8	CHECK AIR MIX DOOR MOTOR OPERATION	
1. Disconnect the mode door motor connector. 2. Reconnect the air mix door motor and confirm the air mix door motor operation.		
OK or NG		
OK (Air mix door motor operates normally)	▶	Replace mode door motor.
NG (Air mix door motor does not operate normally)	▶	Replace auto amp.

TF
PD
AX
SU
BR



CONTROL LINKAGE ADJUSTMENT

Mode Door

1. Install mode door motor on heater unit and connect it to main harness.
2. Set up code No. in Self-diagnosis STEP 4. Refer to HA-45.
3. Move side link by hand and hold mode door in DEF mode.
4. Attach mode door motor rod to side link rod holder.
5. Make sure mode door operates properly when changing from code No. 41 to 46 by pushing DEF switch.

NBHA0091

NBHA0091S01

41	42	43	44	45	46
VENT	B/L	B/L	FOOT	D/F	DEF

ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Air Mix Door Motor

Air Mix Door Motor

TROUBLE DIAGNOSIS PROCEDURE FOR AIR MIX DOOR (LAN)

=NBHA0098

SYMPTOM:

- Discharge air temperature does not change.
- Air mix door motor does not operate.



Inspection Flow

NBHA0098S01

Without Navigation System

NBHA0098S0101

1. Confirm symptom by performing the following operational check.

OPERATIONAL CHECK

Temperature increase

a. Press the temperature increase button until 32°C (85°F) is displayed.

b. Check for hot air at discharge air outlets.


Temperature decrease

a. Press the temperature decrease button until 18°C (65°F) is displayed.

b. Check for cold air at discharge air outlets.

If OK (symptom cannot be duplicated), perform complete operational check (*10).

If NG (symptom is confirmed), continue with STEP-2 following.



- *1: HA-44
- *2: HA-129
- *3: HA-132
- *4: HA-135
- *5: HA-141

- *6: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.
- *7: HA-78
- *8: HA-85
- *9: HA-85

- *10: HA-66
- *12: HA-66
- *13: HA-65
- *14: HA-139
- *15: HA-45


SHA246F

TROUBLE DIAGNOSES

With Navigation System

NBHA0098S0102

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK


Temperature increase

- Turn temperature dial clockwise until 32°C (85°F) is displayed.
- Check for hot air at discharge air outlets.

Temperature decrease

- Turn temperature dial counterclockwise until 18°C (65°F) is displayed.
- Check for cold air at discharge air outlets.

If OK (symptom cannot be duplicated), perform complete operational check (*10).
If NG (symptom is confirmed), continue with STEP-2 following.



- *1: HA-44
- *2: HA-129
- *3: HA-132
- *4: HA-135
- *5: HA-141

- *6: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.
- *7: HA-78
- *8: HA-85
- *9: HA-85

- *10: HA-66
- *12: HA-66
- *13: HA-65
- *14: HA-139
- *15: HA-45

RHA871H

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Air Mix Door Motor (Cont'd)

SYSTEM DESCRIPTION

=NBHA0059

Component Parts

NBHA0059S01

Air mix door control system components are:


- 1) Auto amp.
- 2) Air mix door motor (LCU)
- 3) In-vehicle sensor
- 4) Ambient sensor
- 5) Sunload sensor
- 6) Intake sensor

System Operation

NBHA0059S02

The auto amplifier receives data from each of the sensors. The amplifier sends air mix door and mode door opening angle data to the air mix door motor LCU and mode door motor LCU.



The air mix door motor and mode door motor read their respective signals according to the address signal. Opening angle indication signals received from the auto amplifier and each of the motor position sensors are compared by the LCUs in each motor with the existing decision and opening angles. Subsequently, HOT/COLD or DEFROST/VENT operation is selected. The new selection data is returned to the auto amplifier.



RHA872H

Air Mix Door Control Specification


NBHA0059S03



COMPONENT DESCRIPTION

NBHA0060

The air mix door motor is attached to the heater unit. It rotates so that the air mix door is opened or closed to a position set by the auto amplifier. Motor rotation is then conveyed through a shaft and the air mix door position is then fed back to the auto amplifier by PBR built-in air mix door motor.




CONTROL LINKAGE ADJUSTMENT

NBHA0099

Air Mix Door (Water Cock)

NBHA0099S01

- Install air mix door motor on heater unit and connect it to main harness.
- Set up code No. 41 in Self-diagnosis STEP 4. Refer to HA-44.
- Move air mix door lever by hand and hold it in full cold position.
- Attach air mix door lever to rod holder.
- Make sure air mix door operates properly when changing from code No. 41 to 45 by pushing DEF switch.



41	42	43	44	45	46
Full cold			Full hot		

- Set up code No. 41 in Self-diagnosis STEP 4.
- Attach water cock rod to air mix door lever and secure with clip.
- Rotate air mix door lever (CLOCKWISE completely) and hold water cock rod and link lever in the full cold position.
- Attach water cock rod to link lever and secure with clip (white mark on cable housing should be centered under the retaining clip).

TROUBLE DIAGNOSES

Air Mix Door Motor (Cont'd)

10. Check that water cock operates properly when changing from code No. 41 to 45 by pushing DEF switch. (After several cycles, water cock lever should be midpoint of plate opening when code No. 41 is set.)

Intake Door Motor

TROUBLE DIAGNOSIS PROCEDURE FOR INTAKE DOOR

=NBHA0092

SYMPTOM:

- Intake door does not change.
- Intake door motor does not operate normally.


Inspection Flow

Without Navigation System

NBHA0092S01

NBHA0092S0101

1. Confirm symptom by performing the following operational check.




OPERATIONAL CHECK – Recirculation

a. Press REC switch.
Recirculation indicator should illuminate.

b. Listen for intake door position change (you should hear blower sound change slightly).

**If OK (symptom cannot be duplicated), perform complete operational check (*9).
If NG (symptom is confirmed), continue with STEP-2 following.**



*1: HA-44
 *2: HA-129
 *3: HA-132
 *4: HA-135
 *5: HA-141

*6: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.
 *7: HA-90
 *8: HA-94
 *9: HA-66

*10: HA-45
 *11: HA-66
 *12: HA-65
 *13: HA-139

SHA247F

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


TROUBLE DIAGNOSES

Intake Door Motor (Cont'd)

With Navigation System

NBHA0092S0102

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Recirculation

- a. Press REC switch. Recirculation indicator should illuminate.
- b. Listen for intake door position change (you should hear blower sound change slightly).

If OK (symptom cannot be duplicated), perform complete operational check (*9).
If NG (symptom is confirmed), continue with STEP-2 following.

2. Check for any service bulletins.

3. Perform self-diagnosis STEP-1. (*1)

OK

4. Perform self-diagnosis STEP-2. (*10)

NG

Go to appropriate malfunctioning sensor circuit. (*6)

OK

Go to Intake Door Motor Circuit. (*7)

5. Perform self-diagnosis STEP-4. (*10)

NG

Check intake door control linkage. (*8)

OK

Repair or adjust control linkage.

[Cause cannot be confirmed by self-diagnosis.]

6. Check ambient sensor circuit. (*2)

OK

7. Check in-vehicle sensor circuit. (*3)

OK

8. Check sunload sensor circuit. (*4)

OK

9. Check intake sensor circuit. (*13)

OK

10. Check air mix door motor PBR circuit. (*5)

OK

Replace auto amp.

If the symptom still exists, perform a complete operational check (*11) and check for other symptoms. [Refer to symptom table, (*12).] Does another symptom exist?

No

Yes

Follow the instruction in the "system table".

Another symptom exists.

INSPECTION END

RHA873H

- *1: HA-44
- *2: HA-129
- *3: HA-132
- *4: HA-135
- *5: HA-141

- *6: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.
- *7: HA-90
- *8: HA-94
- *9: HA-66

- *10: HA-45
- *11: HA-66
- *12: HA-65
- *13: HA-139

SYSTEM DESCRIPTION


Component Parts

Intake door control system components are:


- 1) Auto amp.
- 2) Intake door motor
- 3) A/C LAN system (PBR built-in mode motor and air mix door motor)
- 4) In-vehicle sensor
- 5) Ambient sensor
- 6) Sunload sensor
- 7) Intake sensor

System Operation

The intake door control determines intake door position based on the ambient temperature, the intake air temperature and the in-vehicle temperature. When the ECON, DEFROST, or OFF switches are pushed, the auto amplifier sets the intake door at the "Fresh" position.




Intake Door Control Specification




TROUBLE DIAGNOSES

Intake Door Motor (Cont'd)



COMPONENT DESCRIPTION

The intake door motor is attached to the intake unit. It rotates so that air is drawn from inlets set by the auto amplifier. Motor rotation is conveyed to a lever which activates the intake door. NBHA0057



DIAGNOSTIC PROCEDURE

SYMPTOM: Intake door motor does not operate normally. NBHA0058

- Perform Self-diagnosis STEP 1 before referring to the flow chart.


1	CHECK BODY GROUND CIRCUIT FOR INTAKE DOOR MOTOR	
Does continuity exist between intake door harness terminal No. 1 and body ground?		
RHA492G		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Repair harness or connector.

TROUBLE DIAGNOSES


Intake Door Motor (Cont'd)

2 CHECK FOR AUTO AMP. OUTPUT

Set up Self-diagnosis STEP 4.
Measure voltage across auto amp. harness terminals and body ground.



Without navigation system



With navigation system

RHA821H

Code No.	Terminals No.		Condition	Voltage V
	(+)	(-)		
41	8 (6)	Body ground	REC	5
42	18 or 19			0
43	19		20% FRE	5
	8 (6) or 18			0
44	18		FRE	5
45	8 (6) or 19			0
46				

0V: Approx. 0V () : With Navigation System
5V: Approx. 5V

MTBL0466

OK or NG

OK	▶	INSPECTION END
NG	▶	GO TO 3.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

TROUBLE DIAGNOSES

Intake Door Motor (Cont'd)

3 CHECK CIRCUIT CONTINUITY BETWEEN AUTO AMP. AND INTAKE DOOR MOTOR

Check circuit continuity between each terminal on auto amp. and on intake door motor.



RHA822H

Terminal No.		Continuity
Auto amp.	Intake door motor	
19	4	Yes
8 or 6	2	
18	3	
19	5	
28 or 26	6	
36	7	

MTBL0510

Continuity should exist.

If OK, check harness for short.

OK or NG


OK	▶	GO TO 4.
NG	▶	Repair harness or connector.

TROUBLE DIAGNOSES

Intake Door Motor (Cont'd)

4 CHECK FOR AUTO AMP. OUTPUT

Set up Self-diagnosis STEP 4.
Measure voltage across auto amp. harness terminals and body ground.



RHA823H

Code No.	Terminals No.		Condition	Voltage V
	(+)	(-)		
41	28 (26)	Body ground	REC	12
42	36			0
44	28 (26)	Body ground	FRE	0
45	36			12
46				12

0V: Approx. 0V () : With Navigation System
12V: Approx. 12V

MTBL0468


OK or NG

OK	▶	Replace intake door motor.
NG	▶	Replace auto amp.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Intake Door Motor (Cont'd)



CONTROL LINKAGE ADJUSTMENT

=NBHA0093

Intake Door

NBHA0093S01

1. Install intake door motor on intake unit and connect it to main harness.
2. Set up code No. 41 in Self-diagnosis STEP 4. Refer to HA-45.
3. Move intake door link by hand and hold it in REC position.
4. Attach intake door lever to rod holder.
5. Make sure intake door operates properly when changing from code No. 41 to 46 by pushing DEF switch.

41	42	43	44	45	46
REC		20% FRE	FRE		


TROUBLE DIAGNOSES

Blower Motor (Cont'd)

With Navigation System

NBHA0094S0102

1. Confirm symptom by performing the following operational check.




OPERATIONAL CHECK – Blower

- a. Press fan switch (up side) one time. Blower should operate on low speed. The fan symbol should have one blade lit.
- b. Press fan switch (up side) one more time, and continue checking blower speed and fan symbol until all speeds are checked.
- c. Leave blower on MAX speed.

If OK (symptom cannot be duplicated), perform complete operational check (*12).

If NG (symptom is confirmed), continue with STEP-2 following.



- *1: HA-44
- *2: HA-129
- *3: HA-132
- *4: HA-135
- *5: HA-141

- *6: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.
- *7: HA-98
- *8: HA-98
- *9: HA-45

- *10: HA-66
- *11: HA-65
- *12: HA-66
- *13: HA-139
- *14: EL-113

RHA875H


SYSTEM DESCRIPTION

Component parts

Fan speed control system components are:

- 1) Auto amp.
- 2) Fan control amp.
- 3) A/C LAN system (PBR built-in mode door motor and air mix door motor)
- 4) In-vehicle sensor
- 5) Ambient sensor
- 6) Sunload sensor
- 7) Intake sensor

System Operation



Automatic Mode

In the automatic mode, the blower motor speed is calculated by the automatic amplifier based on inputs from the PBR, in-vehicle sensor, sunload sensor, intake sensor and ambient sensor. The blower motor applied voltage ranges from approximately 5 volts (lowest speed) to 12 volts (highest speed).

The control blower speed (in the range of 5 to 12V), the automatic amplifier supplies a gate voltage to the fan control amplifier. Based on this voltage, the fan control amplifier controls the voltage supplied to the blower motor.

Starting Fan Speed Control

Start Up From "COLD SOAK" Condition (Automatic mode)

In a cold start up condition where the engine coolant temperature is below 50°C (122°F), the blower will not operate for a short period of time (up to 126 seconds). The exact start delay time varies depending on the ambient and engine coolant temperature.

In the most extreme case (very low ambient) the blower starting delay will be 126 seconds as described above. After this delay, the blower will operate at low speed until the engine coolant temperature rises above 55°C (131°F), at which time the blower speed will increase to the objective speed.

Start Up From Normal or "HOT SOAK" Condition (Automatic mode)

The blower will begin operation momentarily after the AUTO button is pushed. The blower speed will gradually rise to the objective speed over a time period of 3 seconds or less (actual time depends on the objective blower speed).

TROUBLE DIAGNOSES

Blower Motor (Cont'd)

Blower Speed Compensation

NBHA0062S05

Sunload

NBHA0062S0501

When the in-vehicle temperature and the set temperature are very close, the blower will be operating at low speed. The low speed will vary depending on the sunload. During conditions of high sunload, the blower low speed is "normal" low speed (approx. 6V). During low or no sunload conditions, the low speed will drop to "low" low speed (approx. 5V).


Ambient

NBHA0062S0502


When the ambient temperature is in the "moderate" range [10 - 15°C (50 - 59°F)], the computed blower voltage will be compensated (reduced) by up to 3.5V (depending on the blower speed). In the "extreme" ambient ranges [below 0°C (32°F) and above 20°C (68°F)] the computed objective blower voltage is not compensated at all. In the ambient temperature ranges between "moderate" and "extreme" [0 - 10°C (32 - 50°F) and 15 - 20°C (59 - 68°F)], the amount of compensation (for a given blower speed) varies depending on the ambient temperature.

Fan Speed Control Specification

NBHA0062S06



RHA138G




COMPONENT DESCRIPTION

NBHA0063

Fan Control Amplifier

NBHA0063S01

The fan control amplifier is located on the cooling unit. The fan control amp. receives a gate voltage from the auto amp. to steplessly maintain the blower fan motor voltage in the 5 to 12 volt range (approx.).



DIAGNOSTIC PROCEDURE

NBHA0064

SYMPTOM: Blower motor operation is malfunctioning under Starting Fan Speed Control.

TROUBLE DIAGNOSES

Blower Motor (Cont'd)

1		CHECK POWER SUPPLY FOR FAN CONTROL AMP.
Disconnect fan control amp. harness connector. Do approx. 12 volts exist between fan control amp. harness terminal No. 3 and body ground?		
RHA480G		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 8.

2		CHECK BODY GROUND CIRCUIT FOR FAN CONTROL AMP.
Does continuity exist between fan control amp. harness terminal No. 1 and body ground?		
RHA089G		
Yes or No		
Yes	▶	Reconnect fan control amp. harness connector. And GO TO 3.
No	▶	Repair harness or connector.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Blower Motor (Cont'd)

3	CHECK VOLTAGE FOR FAN CONTROL AMP.												
<p>Set up Self-diagnosis STEP 4. Measure voltage across fan control amp. harness terminal No. 2 and body ground.</p>													
RHA481GB													
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Code No.</th> <th colspan="2">Terminal No.</th> <th rowspan="2">Voltage</th> </tr> <tr> <th>(+)</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">41 - 45</td> <td style="text-align: center;">(2)</td> <td style="text-align: center;">Body ground</td> <td style="text-align: center;">Approx. 2.5 - 3V</td> </tr> </tbody> </table>				Code No.	Terminal No.		Voltage	(+)	(-)	41 - 45	(2)	Body ground	Approx. 2.5 - 3V
Code No.	Terminal No.		Voltage										
	(+)	(-)											
41 - 45	(2)	Body ground	Approx. 2.5 - 3V										
MTBL0465													
OK or NG													
OK	▶	GO TO 5.											
NG	▶	<ul style="list-style-type: none"> ● The result is less than 2.5V. Replace fan control amp. ● The result is more than 3.0V. GO TO 4. 											

4	CHECK FAN CONTROL AMP.		
Refer to HA-103.			
OK or NG			
OK	▶	GO TO 5.	
NG	▶	<ol style="list-style-type: none"> 1. Replace fan control amp. 2. Go to "STEP-BY-STEP PROCEDURE", HA-45 and perform self-diagnosis STEP 4. Confirm that blower motor operation is normal. 	

5	CHECK FAN CONTROL AMP. CIRCUIT BETWEEN FAN CONTROL AMP. AND AUTO AMP. (LCU)		
<ol style="list-style-type: none"> 1. Disconnect auto amp. (LCU) and fan control amp. harness connector. 2. Check circuit continuity between auto amp. (LCU) harness terminal No. 35 and fan control amp. harness terminal No. 2. 			
RHA824H			
Continuity should exist.			
If OK, check harness for short.			
OK or NG			
OK	▶	GO TO 6.	
NG	▶	Repair harness or connector.	

TROUBLE DIAGNOSES

Blower Motor (Cont'd)


6	CHECK FAN FEED BACK CIRCUIT	
Reconnect auto amp. (LCU) harness connector. Do approx. 12 volts exist between auto amp. (LCU) harness terminal No. 33 and body ground?		
RHA825H		
Yes or No		
Yes	▶	GO TO 7.
No	▶	Check power supply circuit and 15A fuses (Nos. 1 and 2, located in the fuse block). Refer to EL-17, "Wiring Diagram — POWER —". <ul style="list-style-type: none"> ● If OK, check for open circuit in wiring harness. Repair or replace as necessary. ● If NG, replace fuse and check wiring harness for short circuit. Repair or replace as necessary.


7	CHECK POWER SUPPLY FOR AUTO AMP.	
Do approx. 12 volts exist between auto amp. harness terminal No. 34 and body ground?		
RHA826H		
Yes or No		
Yes	▶	1. Replace auto amp. 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 4. Confirm that blower motor operation is normal.
No	▶	GO TO 10.

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES

Blower Motor (Cont'd)


8	CHECK POWER SUPPLY FOR BLOWER MOTOR	
<p>Disconnect blower motor harness connector. Do approx. 12 volts exist between blower motor harness terminal No. 1 and body ground?</p>		
		
RHA091G		
Yes or No		
Yes	▶	GO TO 9.
No	▶	<p>Check power supply circuit and 15A fuses (Nos. 1 and 2, located in the fuse block).</p> <ul style="list-style-type: none"> ● If OK, check for open circuit in wiring harness. Repair or replace as necessary. ● If NG, replace fuse and check wiring harness for short circuit. Repair or replace as necessary.

9	CHECK CIRCUIT CONTINUITY BETWEEN BLOWER MOTOR AND FAN CONTROL AMP.	
<p>Disconnect blower motor connector and auto amp. (LCU) connector. Check circuit continuity between blower motor harness terminal No. 2 and fan control amp. harness terminal No. 3.</p>		
		
RHA472G		
OK or NG		
OK	▶	<p>Check blower motor. (Refer to HA-103.)</p> <ol style="list-style-type: none"> 1. If NG, replace blower motor. 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 4. Confirm that blower motor operation is normal.
NG	▶	Repair harness or connector.

TROUBLE DIAGNOSES

Blower Motor (Cont'd)

10	CHECK BLOWER MOTOR CIRCUIT BETWEEN BLOWER MOTOR AND AUTO AMP. (LCU)
Check circuit continuity between blower motor harness terminal No. 2 and auto amp. (LCU) harness terminal No. 34.	
<p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ INSPECTION END
NG	▶ Repair harness or connector.



COMPONENT INSPECTION

Blower Motor

Confirm smooth rotation of the blower motor.

- Ensure that there are no foreign particles inside the intake unit.

NBHA0065

NBHA0065S01

Fan Control Amplifier

Check continuity between terminal Nos. 1 and 2.

NBHA0065S02

Terminal No.	Continuity
1 - 2	Yes

TROUBLE DIAGNOSES

Magnet Clutch

Magnet Clutch

TROUBLE DIAGNOSIS PROCEDURE FOR MAGNET CLUTCH

=NBHA0095

SYMPTOM:


- Magnet clutch does not engage.

Inspection Flow

Without Navigation System

NBHA0095S01

NBHA0095S0101



- *1: STEP-BY-STEP PROCEDURE (HA-44)
- *2: HA-129
- *3: HA-132
- *4: HA-135
- *5: HA-141

- *6: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.
- *7: HA-106
- *8: HA-150
- *9: HA-155
- *10: HA-66

- *11: HA-45
- *12: HA-66
- *13: HA-65
- *14: HA-139


SHA249F

With Navigation System

NBHA0095S0102

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1. Confirm symptom by performing operational check.




OPERATIONAL CHECK – AUTO mode

a. Press AUTO switch.

b. Display should indicate AUTO (not ECON). Confirm that the compressor clutch engages (audio or visual inspection). (Discharge air and blower speed will depend on ambient, in-vehicle and set temperatures.)

If OK (symptom cannot be duplicated), perform complete operational check (*10).

If NG (symptom is confirmed), continue with STEP-2 following.



*1: STEP-BY-STEP PROCEDURE (HA-44)
 *2: HA-129
 *3: HA-132
 *4: HA-135
 *5: HA-141


*6: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.
 *7: HA-106
 *8: HA-150
 *9: HA-155
 *10: HA-66

*11: HA-45
 *12: HA-66
 *13: HA-65
 *14: HA-139

RHA876H

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)




SYSTEM DESCRIPTION

Auto amplifier controls compressor operation by ambient temperature and signal from ECM. =NBHA0066

Low Temperature Protection Control

Auto amplifier will turn the compressor "ON" or "OFF" as determined by a signal detected by ambient sensor. NBHA0066S01
 When ambient temperatures are greater than -2°C (28°F), the compressor turns "ON". The compressor turns "OFF" when ambient temperatures are less than -5°C (23°F).



DIAGNOSTIC PROCEDURE

SYMPTOM: Magnet clutch does not engage when AUTO switch is ON. NBHA0067

1	CHECK POWER SUPPLY FOR COMPRESSOR	
Disconnect compressor harness connector. Do approx. 12 volts exist between compressor harness terminal No. 1 and body ground?		
<p style="text-align: center;">Yes or No</p>		
Yes	▶	Check magnet clutch coil. 1. If NG, replace magnet clutch. Refer to HA-150. 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 4. Confirm that magnet clutch operation is normal.
No	▶	Disconnect A/C relay. And GO TO 2.

RHA096G

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

2	CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY AND COMPRESSOR	
<p>Check circuit continuity between A/C relay harness terminal No. 5 and compressor harness terminal No. 1.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SHA472F</p>		
Continuity should exist.		
If OK, check harness for short.		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair harness or connector.

3	CHECK POWER SUPPLY FOR A/C RELAY	
<p>Disconnect A/C relay. Do approx. 12 volts exist between A/C relay harness terminal Nos. 1, 3 and body ground?</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SHA473F</p>		
Yes or No		
Yes	▶	GO TO 4.
No	▶	<p>Check power supply circuit and 7.5A (No. 6) fuse at fuse block. Refer to EL-17, "Wiring Diagram — POWER —".</p> <ul style="list-style-type: none"> ● If OK, check for open circuit in wiring harness. Repair or replace as necessary. ● If NG, replace fuse and check wiring harness for short circuit. Repair or replace as necessary.

4	CHECK A/C RELAY AFTER DISCONNECTING IT	
Refer to HA-110.		
OK or NG		
OK	▶	Reconnect A/C relay. And GO TO 5.
NG	▶	<ol style="list-style-type: none"> 1. Replace A/C relay. 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 4. <p>Confirm that magnet clutch operation is normal.</p>

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

5	CHECK COIL SIDE CIRCUIT OF A/C RELAY	
Do approx. 12 volts exist between ECM harness terminal No. 27 and body ground?		
RHA482GG		
Yes or No		
Yes	▶	GO TO 6.
No	▶	Disconnect A/C relay. Disconnect ECM harness connector. GO TO 11.

6	CHECK VOLTAGE FOR ECM	
Do approx. 12 volts exist between ECM harness terminal No. 45 and body ground?		
RHA701FJ		
Yes or No		
Yes	▶	Disconnect ECM harness connector. Disconnect dual-pressure switch harness connector. GO TO 7.
No	▶	Check ECM. Refer to EC-124, "ECM Terminals and Reference Value".

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

7	CHECK CIRCUIT CONTINUITY BETWEEN ECM AND AUTO AMP.	
Check circuit continuity between ECM harness terminal No. 45 and auto amp. harness terminal No. 22.		
<p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: right;">RHA878H</p>		
OK or NG		
OK	▶	GO TO 8.
NG	▶	<ol style="list-style-type: none"> 1. Repair harness or connector. 2. Go to "STEP-BY-STEP PROCEDURE", "Self-diagnosis", HA-45 and perform self-diagnosis STEP 4. <p style="text-align: center;">Confirm that magnet clutch operation is normal.</p>

8	CHECK REFRIGERANT PRESSURE SENSOR	
Refer to EC-630, "Diagnostic Procedure", HA-111.		
OK or NG		
OK	▶	GO TO 9.
NG	▶	Replace refrigerant pressure sensor.

9	CHECK VOLTAGE FOR ECM	
Check 4.6 volts exist between ECM harness terminal No. 51 and body ground?		
RHA482GG		
Yes or No		
Yes	▶	Check ECM. Refer to EC-124, "ECM Terminal and Reference Value".
No	▶	GO TO 10.


GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)

10	CHECK CIRCUIT CONTINUITY BETWEEN ECM AND AUTO AMP.	
<p>Check circuit continuity between ECM harness terminal No. 51 and auto amp. harness terminal No. 6 (17).</p>		
<p style="text-align: center;">Without navigation system With navigation system</p>		
RHA879H		
<p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	Replace auto amp.
NG	▶	<ol style="list-style-type: none"> 1. Repair harness or connector. 2. Go to "STEP-BY-STEP PROCEDURE", "Self-diagnosis", HA-45 and perform self-diagnosis STEP 4. <p style="text-align: center;">Confirm that magnet clutch operation is normal.</p>

11	CHECK CIRCUIT CONTINUITY BETWEEN A/C RELAY AND ECM	
<p>Check circuit continuity between A/C relay harness terminal No. 2 and ECM harness terminal No. 27.</p>		
SHA474F		
<p>Continuity should exist.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	Check harness for short.
NG	▶	Repair harness or connector.



COMPONENT INSPECTION

A/C Relay

NBHA0068

Check continuity between terminal Nos. 3 and 5.


NBHA0068S01

Conditions	Continuity
12V direct current supply between terminal Nos. 1 and 2	Yes
No current supply	No

If NG, replace relay.


TROUBLE DIAGNOSES

Magnet Clutch (Cont'd)



Refrigerant Pressure Sensor

Make sure that higher A/C refrigerant pressure results in higher refrigerant-pressure sensor output voltage. NBHA0068S02



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSES

Insufficient Cooling

Insufficient Cooling

TROUBLE DIAGNOSIS PROCEDURE FOR INSUFFICIENT COOLING

=NBHA0096

SYMPTOM:

- Insufficient cooling


Inspection Flow

Without Navigation System

NBHA0096S01

NBHA0096S0101


1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Temperature decrease

- Press the temperature decrease button until 18°C (65°F) is displayed.
- Check for cold air at discharge air outlets.

If OK (symptom cannot be duplicated), perform complete operational check (*11).
If NG (symptom is confirmed), continue with STEP-2 following.



SHA190FC

*1: HA-44

*2: HA-85

*3: HA-116

*4: HA-53

*5: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.

*6: HA-77

*7: HA-89

*8: HA-97

*9: HA-106

*10: HA-114

*11: HA-66

*12: HA-45

*13: HA-2

*14: MA-13

*15: LC-20


TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)

With Navigation System

NBHA0096S0102


1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Temperature decrease

- Press the temperature decrease button until 18°C (65°F) is displayed.
- Check for cold air at discharge air outlets.

If OK (symptom cannot be duplicated), perform complete operational check (*11).
If NG (symptom is confirmed), continue with STEP-2 following.



RHA881H

- | | | |
|---|-------------|------------|
| *1: HA-44 | *6: HA-77 | *11: HA-66 |
| *2: HA-85 | *7: HA-89 | *12: HA-45 |
| *3: HA-116 | *8: HA-97 | *13: HA-2 |
| *4: HA-53 | *9: HA-106 | *14: MA-13 |
| *5: STEP-BY-STEP PROCEDURE (HA-45), see No. 13. | *10: HA-114 | *15: LC-20 |


GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)

PERFORMANCE TEST DIAGNOSES

NBHA0030



SHA893E

*1: HA-116

*3: HA-116



*5: HA-85

*2: HA-116

*4: HA-85

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)



*1: HA-149

*2: HA-95

*3: MA-13

RHA576H

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)

PERFORMANCE CHART

NBHA0031

Test Condition

NBHA0031S01

Testing must be performed as follows:

Vehicle location	Indoors or in the shade (in a well-ventilated place)
Doors	Closed
Door window	Open
Hood	Open
TEMP.	Max. COLD
Mode switch	 (Ventilation) set
REC switch	 (Recirculation) set
 (blower) speed	Max. speed set
Engine speed	Idle speed

Operate the air conditioning system for 10 minutes before taking measurements.

Test Reading

NBHA0031S02

Recirculating-to-discharge Air Temperature Table

NBHA0031S0201

Inside air (Recirculating air) at blower assembly inlet		Discharge air temperature at center ventilator °C (°F)
Relative humidity %	Air temperature °C (°F)	
50 - 60	25 (77)	6.0 - 9.0 (43 - 48)
	30 (86)	10.0 - 13.6 (50 - 56)
	35 (95)	15.2 - 19.5 (59 - 67)
	40 (104)	22.5 - 27.1 (73 - 81)
60 - 70	25 (77)	9.0 - 12.2 (48 - 54)
	30 (86)	13.6 - 17.2 (56 - 63)
	35 (95)	19.5 - 23.7 (67 - 75)
	40 (104)	27.1 - 32.3 (81 - 90)

Ambient Air Temperature-to-operating Pressure Table

NBHA0031S0202

Ambient air		High-pressure (Discharge side) kPa (kg/cm ² , psi)	Low-pressure (Suction side) kPa (kg/cm ² , psi)
Relative humidity %	Air temperature °C (°F)		
50 - 70	25 (77)	1,226 - 1,638 (12.5 - 16.7, 178 - 237)	172 - 250 (1.75 - 2.55, 25 - 36)
	30 (86)	1,422 - 1,883 (14.5 - 19.2, 206 - 273)	196 - 275 (2.0 - 2.8, 28 - 40)
	35 (95)	1,657 - 2,187 (16.9 - 22.3, 240 - 317)	231 - 309 (2.35 - 3.15, 33 - 45)
	40 (104)	1,922 - 2,501 (19.6 - 25.5, 279 - 363)	280 - 373 (2.85 - 3.8, 41 - 54)

TROUBLE DIAGNOSES FOR ABNORMAL PRESSURE

NBHA0032


Whenever system's high and/or low side pressure is abnormal, diagnose using a manifold gauge. The marker above the gauge scale in the following tables indicates the standard (normal) pressure range. Since the standard (normal) pressure, however, differs from vehicle to vehicle, refer to HA-116 ("Ambient air temperature-to-operating pressure table").

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)


Both High- and Low-pressure Sides are Too High.

NBHA0032S01

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high- and low-pressure sides are too high.</p> <p>A</p>  <p>AC359A</p>	<ul style="list-style-type: none"> Pressure is reduced soon after water is splashed on condenser. 	<p>Excessive refrigerant charge in refrigeration cycle</p>	<p>Reduce refrigerant until specified pressure is obtained.</p>
	<p>Air suction by cooling fan is insufficient.</p>	<p>Insufficient condenser cooling performance</p> <p>↓</p> <ol style="list-style-type: none"> Condenser fins are clogged. Improper fan rotation of cooling fan 	<ul style="list-style-type: none"> Clean condenser. Check and repair cooling fan as necessary.
	<ul style="list-style-type: none"> Low-pressure pipe is not cold. When compressor is stopped high-pressure value quickly drops by approximately 196 kPa (2 kg/cm², 28 psi). It then decreases gradually thereafter. 	<p>Poor heat exchange in condenser (After compressor operation stops, high pressure decreases too slowly.)</p> <p>↓</p> <p>Air in refrigeration cycle</p>	<p>Evacuate repeatedly and recharge system.</p>
	<p>Engine tends to overheat.</p>	<p>Engine cooling systems malfunction.</p>	<p>Check and repair each engine cooling system.</p>
	<ul style="list-style-type: none"> An area of the low-pressure pipe is colder than areas near the evaporator outlet. Plates are sometimes covered with frost. 	<ul style="list-style-type: none"> Excessive liquid refrigerant on low-pressure side Excessive refrigerant discharge flow Expansion valve is open a little compared with the specification. <p>↓</p> <ol style="list-style-type: none"> Improper thermal valve installation Improper expansion valve adjustment 	<p>Replace expansion valve.</p>

High-pressure Side is Too High and Low-pressure Side is Too Low.

NBHA0032S02


Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>High-pressure side is too high and low-pressure side is too low.</p> <p>B</p>  <p>AC360A</p>	<p>Upper side of condenser and high-pressure side are hot, however, liquid tank is not so hot.</p>	<p>High-pressure tube or parts located between compressor and condenser are clogged or crushed.</p>	<ul style="list-style-type: none"> Check and repair or replace malfunctioning parts. Check lubricant for contamination.

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)

High-pressure Side is Too Low and Low-pressure Side is Too High.

NBHA0032S03


Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>High-pressure side is too low and low-pressure side is too high.</p> <p>C</p>  <p style="text-align: right; font-size: small;">AC356A</p>	<p>High and low-pressure sides become equal soon after compressor operation stops.</p>	<p>Compressor pressure operation is improper.</p> <p style="text-align: center;">↓</p> <p>Damaged inside compressor packings</p>	<p>Replace compressor.</p>
	<p>No temperature difference between high and low-pressure sides</p>	<p>Compressor pressure operation is improper.</p> <p style="text-align: center;">↓</p> <p>Damaged inside compressor packings.</p>	<p>Replace compressor.</p>

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)

Both High- and Low-pressure Sides are Too Low.

NBHA0032S04

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Both high- and low-pressure sides are too low.</p> <p>D</p>  <p style="text-align: right; margin-right: 20px;">AC353A</p>	<ul style="list-style-type: none"> There is a big temperature difference between receiver drier outlet and inlet. Outlet temperature is extremely low. Liquid tank inlet and expansion valve are frosted. 	<p>Compressor discharge capacity does not change. (Compressor stroke is set at maximum.)</p>	<ul style="list-style-type: none"> Replace liquid tank. Check lubricant for contamination.
	<ul style="list-style-type: none"> Temperature of expansion valve inlet is extremely low as compared with areas near liquid tank. Expansion valve inlet may be frosted. Temperature difference occurs somewhere in high-pressure side 	<p>High-pressure pipe located between receiver drier and expansion valve is clogged.</p>	<ul style="list-style-type: none"> Check and repair malfunctioning parts. Check lubricant for contamination.
	<ul style="list-style-type: none"> Expansion valve and liquid tank are warm or only cool when touched. 	<p>Low refrigerant charge</p> <p style="text-align: center;">↓</p> <p>Leaking fittings or components</p>	<p>Check refrigerant for leaks. Refer to "Checking Refrigerant Leaks", HA-155.</p>
	<p>There is a big temperature difference between expansion valve inlet and outlet while the valve itself is frosted.</p>	<p>Expansion valve closes a little compared with the specification.</p> <p style="text-align: center;">↓</p> <ol style="list-style-type: none"> Improper expansion valve adjustment Malfunctioning thermal valve Outlet and inlet may be clogged. 	<ul style="list-style-type: none"> Remove foreign particles by using compressed air. Check lubricant for contamination.
	<p>An area of the low-pressure pipe is colder than areas near the evaporator outlet.</p>	<p>Low-pressure pipe is clogged or crushed.</p>	<ul style="list-style-type: none"> Check and repair malfunctioning parts. Check lubricant for contamination.
	<p>Air flow volume is not enough or is too low.</p>	<p>Evaporator is frozen.</p> <p style="text-align: center;">↓</p> <p>Compressor discharge capacity does not change. (Compressor stroke is set at maximum length.)</p>	<p>Replace compressor.</p>


GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Insufficient Cooling (Cont'd)


Low-pressure Side Sometimes Becomes Negative.

NBHA0032S05

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side sometimes becomes negative.</p> <p>E</p>  <p style="text-align: right; font-size: small;">AC354A</p>	<ul style="list-style-type: none"> ● Air conditioning system does not function and does not cyclically cool the compartment air. ● The system constantly functions for a certain period of time after compressor is stopped and restarted. 	<p>Refrigerant does not discharge cyclically.</p> <p style="text-align: center;">↓</p> <p>Moisture is frozen at expansion valve outlet and inlet.</p> <p style="text-align: center;">↓</p> <p>Water is mixed with refrigerant.</p>	<ul style="list-style-type: none"> ● Drain water from refrigerant or replace refrigerant. ● Replace liquid tank.

Low-pressure Side Becomes Negative.

NBHA0032S06

Gauge indication	Refrigerant cycle	Probable cause	Corrective action
<p>Low-pressure side becomes negative.</p> <p>F</p>  <p style="text-align: right; font-size: small;">AC362A</p>	<p>Liquid tank or front/rear side of expansion valve's pipe is frosted or dewed.</p>	<p>High-pressure side is closed and refrigerant does not flow.</p> <p style="text-align: center;">↓</p> <p>Expansion valve or liquid tank is frosted.</p>	<p>Leave the system at rest until no frost is present. Start it again to check whether or not the problem is caused by water or foreign particles.</p> <ul style="list-style-type: none"> ● If water is the cause, initially cooling is okay. Then the water freezes causing a blockage. Drain water from refrigerant or replace refrigerant. ● If due to foreign particles, remove expansion valve and remove the particles with dry and compressed air (not shop air). ● If either of the above methods cannot correct the problem, replace expansion valve. ● Replace liquid tank. ● Check lubricant for contamination.

Insufficient Heating

TROUBLE DIAGNOSIS PROCEDURE FOR INSUFFICIENT HEATING

=NBHA0097

SYMPTOM:

- Insufficient heating


Inspection Flow

Without Navigation System

NBHA0097S01

NBHA0097S0101

1. Confirm symptom by performing the following operational check.




OPERATIONAL CHECK – Temperature increase

- a. Press the temperature increase button until 32°C (85°F) is displayed.
- b. Check for hot air at discharge air outlets.

If OK (symptom cannot be duplicated), perform complete operational check (*1).

If NG (symptom is confirmed), continue with STEP-2 following.



SHA894EA

- *1: HA-66
- *2: HA-44
- *3: HA-45
- *4: HA-45
- *5: HA-85

- *6: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.
- *7: HA-78
- *8: HA-90
- *9: HA-98

- *10: HA-82
- *11: MA-14
- *12: LC-11
- *13: LC-16


TROUBLE DIAGNOSES

Insufficient Heating (Cont'd)

With Navigation System

NBHA0097S0102


1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Temperature increase

- Press the temperature increase button until 32°C (85°F) is displayed.
- Check for hot air at discharge air outlets.

If OK (symptom cannot be duplicated), perform complete operational check (*1).
If NG (symptom is confirmed), continue with STEP-2 following.



RHA882H

- *1: HA-66
- *2: HA-44
- *3: HA-45
- *4: HA-45
- *5: HA-85

- *6: STEP-BY-STEP PROCEDURE (HA-45), see No. 13.
- *7: HA-78
- *8: HA-90
- *9: HA-98

- *10: HA-82
- *11: MA-14
- *12: LC-11
- *13: LC-16


Noise

TROUBLE DIAGNOSIS PROCEDURE FOR NOISE

SYMPTOM:

- Noise

=NBHA0100



*1: HA-150
*2: HA-152

*3: HA-146
*4: HA-66

*5: MA-13
*6: MA-14

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Self-diagnosis

Self-diagnosis

TROUBLE DIAGNOSIS PROCEDURE FOR SELF-DIAGNOSIS

=NBHA0101

SYMPTOM:


- Self-diagnosis cannot be performed.

Inspection Flow

Without Navigation System

NBHA0101S01

NBHA0101S0101



*1: HA-72

*2: HA-129

*3: HA-132

*4: HA-135

*5: HA-139

*6: HA-141

*7: HA-66

*8: HA-65


*9: HA-66

SHA250F

With Navigation System

NBHA0101S0102

1. Confirm symptom by performing the following operational check.




OPERATIONAL CHECK – AUTO mode

a. Press AUTO switch.

b. Display should indicate AUTO (not ECON). Confirm that the compressor clutch engages (audio or visual inspection). (Discharge air and blower speed will depend on ambient, in-vehicle and set temperatures.)

If OK (symptom cannot be duplicated), perform complete operational check (*7).

If NG (symptom is confirmed), continue with STEP-2 following.



- *1: HA-72
- *2: HA-129
- *3: HA-132
- *4: HA-135

- *5: HA-139
- *6: HA-141
- *7: HA-66

- *8: HA-65
- *9: HA-66
- *10: HA-142

RHA884H

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES

Memory Function

Memory Function

TROUBLE DIAGNOSIS PROCEDURE FOR MEMORY FUNCTION

=NBHA0102

SYMPTOM:

- Memory function does not operate.


Inspection Flow

NBHA0102S01

Without Navigation System

NBHA0102S0101

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Memory function

- a. Set the temperature 85°F or 32°C.
- b. Press OFF switch.
- c. Turn the ignition off.
- d. Turn the ignition on.
- e. Press the AUTO switch.
- f. Confirm that the set temperature remains at previous temperature.
- g. Press OFF switch.

If OK (symptom cannot be duplicated), perform complete operational check (*2).

If NG (symptom is confirmed), continue with STEP-2 following.

2. Check for any service bulletins.

3. Check Main Power Supply and Ground Circuit. (*1)

OK

4. Replace auto amp.

5. FINAL CHECK

Go to self-diagnosis step-by-step procedure (*3) and perform self-diagnosis STEP-2.

Confirm that code No. 20 is displayed.

RHA885H

*1: HA-72


*2: HA-66

*3: HA-45

With Navigation System

NBHA0102S0102

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – Memory function

- a. Set the temperature 85°F or 32°C.
- b. Press OFF switch.
- c. Turn the ignition off.
- d. Turn the ignition on.
- e. Press the AUTO switch.
- f. Confirm that the set temperature remains at previous temperature.
- g. Press OFF switch.

If OK (symptom cannot be duplicated), perform complete operational check (*2).

If NG (symptom is confirmed), continue with STEP-2 following.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

RHA886H

SU

BR

ST

RS

BT

HA

SC

EL

IDX

2. Check for any service bulletins.

3. Check Main Power Supply and Ground Circuit. (*1)

OK

4. Replace auto amp.

5. FINAL CHECK

Go to self-diagnosis step-by-step procedure (*3) and perform self-diagnosis STEP-2.
Confirm that code No. 20 is displayed.

*1: HA-72

*2: HA-66

*3: HA-45

TROUBLE DIAGNOSES

ECON (ECONOMY) Mode

ECON (ECONOMY) Mode

TROUBLE DIAGNOSIS PROCEDURE FOR ECON (ECONOMY) MODE

=NBHA0103

SYMPTOM:

- ECON mode does not operate.


Inspection Flow

NBHA0103S01

Without Navigation System

NBHA0103S0101

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – ECON (ECONOMY) mode

- a. Set the temperature 75°F or 25°C.
- b. Press ECON switch.
- c. Display should indicate ECON (not AUTO).

Confirm that the compressor clutch is not engaged (visual inspection).

(Discharge air and blower speed will depend on ambient, in-vehicle and set temperatures.)

If OK (symptom cannot be duplicated), perform complete operational check (*2).

If NG (symptom is confirmed), continue with STEP-2 following.

2. Check for any service bulletins.

3. Check Main Power Supply and Ground Circuit. (*1)

OK

4. Replace auto amp.

5. FINAL CHECK

Go to self-diagnosis step-by-step procedure (*3) and perform self-diagnosis STEP-2.
Confirm that code No. 20 is displayed.

SHA920EA

*1: HA-72


*2: HA-66

*3: HA-45

With Navigation System

NBHA0103S0102

1. Confirm symptom by performing the following operational check.



OPERATIONAL CHECK – ECON (ECONOMY) mode

- a. Set the temperature 75°F or 25°C.
 - b. Press ECON switch.
 - c. Display should indicate ECON (not AUTO).
- Confirm that the compressor clutch is not engaged (visual inspection).
(Discharge air and blower speed will depend on ambient, in-vehicle and set temperatures.)

If OK (symptom cannot be duplicated), perform complete operational check (*2).
If NG (symptom is confirmed), continue with STEP-2 following.

2. Check for any service bulletins.

3. Check Main Power Supply and Ground Circuit. (*1)

OK

4. Replace auto amp.


5. FINAL CHECK
Go to self-diagnosis step-by-step procedure (*3) and perform self-diagnosis STEP-2.
Confirm that code No. 20 is displayed.

*1: HA-72

*2: HA-66

*3: HA-45

RHA887H



Ambient Sensor Circuit COMPONENT DESCRIPTION

NBHA0039

The ambient sensor is attached in front of the driver's side condenser. It detects ambient temperature and converts it into a resistance value which is then input into the auto amplifier.

AMBIENT TEMPERATURE INPUT PROCESS


NBHA0040

The automatic amplifier includes a "processing circuit" for the ambient sensor input. However, when the temperature detected by the ambient sensor increases quickly, the processing circuit retards the auto amp. function. It only allows the auto amp. to recognize an ambient temperature increase of 0.33°C (0.6°F) per 100 seconds. As an example, consider stopping for a cup of coffee after high speed driving. Although the actual ambient temperature has not changed, the temperature detected by the ambient sensor will increase. This is because the heat from the engine compartment can radiate to the front grille area, location of the ambient sensor.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Ambient Sensor Circuit (Cont'd)



DIAGNOSTIC PROCEDURE

SYMPTOM: Ambient sensor circuit is open or shorted. ($\frac{2}{1}$ or $\frac{-2}{1}$ is indicated on the display as a result of conducting Self-diagnosis STEP 2.) NBHA0041

1	CHECK VOLTAGE BETWEEN AMBIENT SENSOR HARNESS CONNECTOR AND BODY GROUND
<p>Disconnect ambient sensor harness connector. Do approx. 5 volts exist between ambient sensor harness terminal No. 1 and body ground?</p>	
RHA052G	
Yes or No	
Yes	▶ GO TO 2.
No	▶ GO TO 4.


2	CHECK AMBIENT SENSOR CIRCUIT BETWEEN AMBIENT SENSOR AND AUTO AMP. (LCU)
<p>1. Disconnect auto amp. (LCU) harness connector. 2. Check circuit continuity between ambient sensor harness terminal No. 2 and auto amp. (LCU) harness terminal No. 11 or 9.</p>	
RHA829H	
Continuity should exist.	
If OK, check harness for short.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair harness or connector.

TROUBLE DIAGNOSES

Ambient Sensor Circuit (Cont'd)

3	CHECK AMBIENT SENSOR
Refer to HA-131.	
OK or NG	
OK	<ul style="list-style-type: none"> 1. Replace auto amp. (LCU). 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 2. Confirm that code No. 20 is displayed.
NG	Replace ambient sensor.

4	CHECK AMBIENT SENSOR CIRCUIT BETWEEN AMBIENT SENSOR AND AUTO AMP. (LCU)
<ul style="list-style-type: none"> 1. Disconnect auto amp. (LCU) harness connector. 2. Check circuit continuity between ambient sensor harness terminal No. 1 and auto amp. (LCU) harness terminal No. 2. 	
Continuity should exist.	
If OK, check harness for short.	
OK or NG	
OK	<ul style="list-style-type: none"> 1. Replace auto amp. (LCU). 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 2. Confirm that code No. 20 is displayed.
NG	Repair harness or connector.



COMPONENT INSPECTION

Ambient Sensor

NBHA0042

NBHA0042S01

After disconnecting ambient sensor harness connector, measure resistance between terminals 2 and 1 at sensor harness side, using the table below.


Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81

TROUBLE DIAGNOSES

Ambient Sensor Circuit (Cont'd)

Temperature °C (°F)	Resistance kΩ
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace ambient sensor.




In-vehicle Sensor Circuit COMPONENT DESCRIPTION In-vehicle sensor

NBHA0043

NBHA0043S01



The in-vehicle sensor is located on instrument lower panel. It converts variations in temperature of compartment air drawn from the aspirator into a resistance value. It is then input into the auto amplifier.



Aspirator

NBHA0043S02

The aspirator is located in front of heater unit. It produces vacuum pressure due to air discharged from the heater unit, continuously taking compartment air in the aspirator.



DIAGNOSTIC PROCEDURE

NBHA0044

SYMPTOM: In-vehicle sensor circuit is open or shorted. (⊘ or ⊘⊘ is indicated on the display as a result of conducting Self-diagnosis STEP 2.)

TROUBLE DIAGNOSES

In-vehicle Sensor Circuit (Cont'd)

1	CHECK IN-VEHICLE SENSOR CIRCUIT BETWEEN IN-VEHICLE SENSOR AND BODY GROUND
<p>Disconnect in-vehicle sensor harness connector. Do approx. 5 volts exist between in-vehicle sensor harness terminal No. 1 and body ground?</p>	
RHA477G	
Yes or No	
Yes	▶ GO TO 2.
No	▶ GO TO 4.

2	CHECK IN-VEHICLE SENSOR CIRCUIT BETWEEN IN-VEHICLE SENSOR AND AUTO AMP. (LCU)
<p>1. Disconnect auto amp. (LCU) harness connector. 2. Check circuit continuity between in-vehicle sensor harness terminal No. 2 and auto amp. (LCU) harness terminal No. 11 or 9.</p>	
RHA831H	
Continuity should exist.	
If OK, check harness for short.	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair harness or connector.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES


In-vehicle Sensor Circuit (Cont'd)

3	CHECK IN-VEHICLE SENSOR	
Refer to HA-135.		
OK or NG		
OK	▶	<ol style="list-style-type: none"> 1. Replace auto amp. 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 2. Confirm that code No. 20 is displayed.
NG	▶	<ol style="list-style-type: none"> 1. Replace in-vehicle sensor. 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 2. Confirm that code No. 20 is displayed.

4	CHECK IN-VEHICLE SENSOR CIRCUIT BETWEEN AMBIENT SENSOR AND AUTO AMP. (LCU)	
<ol style="list-style-type: none"> 1. Disconnect auto amp. (LCU) harness connector. 2. Check circuit continuity between in-vehicle sensor harness terminal No. 1 and auto amp. (LCU) harness terminal No. 3. 		
RHA832H		
Continuity should exist.		
If OK, check harness for short.		
OK or NG		
OK	▶	<ol style="list-style-type: none"> 1. Replace auto amp. (LCU). 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 2. Confirm that code No. 20 is displayed.
NG	▶	Repair harness or connector.

TROUBLE DIAGNOSES

In-vehicle Sensor Circuit (Cont'd)



COMPONENT INSPECTION

NBHA0045


In-vehicle Sensor

NBHA0045S01

After disconnecting in-vehicle sensor harness connector, measure resistance between terminals 1 and 2 at sensor harness side, using the table below.

Temperature °C (°F)	Resistance kΩ
-15 (5)	12.73
-10 (14)	9.92
-5 (23)	7.80
0 (32)	6.19
5 (41)	4.95
10 (50)	3.99
15 (59)	3.24
20 (68)	2.65
25 (77)	2.19
30 (86)	1.81
35 (95)	1.51
40 (104)	1.27
45 (113)	1.07

If NG, replace in-vehicle sensor.



Sunload Sensor Circuit

COMPONENT DESCRIPTION

NBHA0046

The sunload sensor is located on the right defroster grille. It detects sunload entering through windshield by means of a photo diode. The sensor converts the sunload into a current value which is then input into the auto amplifier.

SUNLOAD INPUT PROCESS

NBHA0047

The auto amp. also includes a processing circuit which "average" the variations in detected sunload over a period of time. This prevents drastic swings in the ATC system operation due to small or quick variations in detected sunload.


For example, consider driving along a road bordered by an occasional group of large trees. The sunload detected by the sunload sensor will vary whenever the trees obstruct the sunlight. The processing circuit averages the detected sunload over a period of time, so that the (insignificant) effect of the trees momentarily

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Sunload Sensor Circuit (Cont'd)

obstructing the sunlight does not cause any change in the ATC system operation. On the other hand, shortly after entering a long tunnel, the system will recognize the change in sunload, and the system will react accordingly.



DIAGNOSTIC PROCEDURE

SYMPTOM: Sunload sensor circuit is open or shorted. (25 or -25^{NBHA0048} is indicated on the display as a result of conducting Self-diagnosis STEP 2.)

1	CHECK SUNLOAD SENSOR CIRCUIT BETWEEN SUNLOAD SENSOR AND BODY GROUND
<p>Disconnect sunload sensor harness connector. Do approx. 5 volts exist between sunload sensor harness terminal No. 1 and body ground?</p> <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right;">RHA062G</p>	
Yes or No	
Yes	▶ GO TO 2.
No	▶ GO TO 4.

TROUBLE DIAGNOSES

Sunload Sensor Circuit (Cont'd)

2	CHECK SUNLOAD SENSOR CIRCUIT BETWEEN SUNLOAD SENSOR AND AUTO AMP. (LCU)	
<p>1. Disconnect auto amp. (LCU) harness connector. 2. Check circuit continuity between sunload sensor harness terminal No. 2 and auto amp. (LCU) harness terminal No. 11 or 9.</p>		
RHA833H		
<p>Continuity should exist. If OK, check harness for short.</p>		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair harness or connector.


3	CHECK SUNLOAD SENSOR.	
Refer to HA-138.		
OK or NG		
OK	▶	<ol style="list-style-type: none"> 1. Replace auto amp. (LCU). 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 2. Confirm that code No. 20 is displayed.
NG	▶	<ol style="list-style-type: none"> 1. Replace sunload sensor. 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 2. Confirm that code No. 20 is displayed.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES

Sunload Sensor Circuit (Cont'd)

4	CHECK SUNLOAD SENSOR CIRCUIT BETWEEN SUNLOAD SENSOR AND AUTO AMP. (LCU)
<p>1. Disconnect auto amp. (LCU) harness connector. 2. Check circuit continuity between sunload sensor harness terminal No. 1 and auto amp. (LCU) harness terminal No. 12 or 10.</p>	
RHA834H	
<p>Continuity should exist. If OK, check harness for short.</p>	
OK or NG	
OK	<p>▶ 1. Replace auto amp. 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 2. Confirm that code No. 20 is displayed.</p>
NG	<p>▶ Repair harness or connector.</p>



RHA835H

COMPONENT INSPECTION

Sunload Sensor

NBHA0049

NBHA0049S01


Measure voltage between auto amp. terminal 12 (10) and body ground.

If NG, replace sunload sensor.

- When checking sunload sensor, select a place where sun shines directly on it.

TROUBLE DIAGNOSES

Intake Sensor Circuit (Cont'd)



DIAGNOSTIC PROCEDURE

SYMPTOM: Intake sensor circuit is open or shorted. (24 or -24 is indicated on the display as a result of conducting Self-diagnosis STEP 2.) NBHA0106

1	CHECK INTAKE SENSOR CIRCUIT BETWEEN INTAKE SENSOR AND BODY GROUND						
<p>Disconnect intake sensor harness connector. Do approx. 5 volts exist between intake sensor harness terminal No. 2 and body ground?</p> <div style="text-align: center;"> <p>Intake sensor connector (M107)</p> </div> <p style="text-align: center;">Yes or No</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">Yes</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 2.</td> </tr> <tr> <td>No</td> <td style="text-align: center;">▶</td> <td>GO TO 4.</td> </tr> </table>		Yes	▶	GO TO 2.	No	▶	GO TO 4.
Yes	▶	GO TO 2.					
No	▶	GO TO 4.					

RHA495G

2	CHECK INTAKE SENSOR CIRCUIT BETWEEN INTAKE SENSOR AND AUTO AMP. (LCU)						
<p>1. Disconnect auto amp. (LCU) harness connector. 2. Check circuit continuity between intake sensor harness terminal No. 2 and auto amp. (LCU) harness terminal No. 11 or 9.</p> <div style="text-align: center;"> <p>Intake sensor connector (M107)</p> <p>Auto amp. connector (M103)</p> <p>Auto amp. connector (M104)</p> <p>Without navigation system</p> <p>With navigation system</p> </div> <p style="text-align: center;">Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 3.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>Repair harness or connector.</td> </tr> </table>		OK	▶	GO TO 3.	NG	▶	Repair harness or connector.
OK	▶	GO TO 3.					
NG	▶	Repair harness or connector.					

RHA836H

TROUBLE DIAGNOSES

Intake Sensor Circuit (Cont'd)

3	CHECK INTAKE SENSOR
Refer to HA-139.	
OK or NG	
OK	<ul style="list-style-type: none"> ▶ 1. Replace auto amp. 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 2. Confirm that code No. 20 is displayed.
NG	<ul style="list-style-type: none"> ▶ 1. Replace intake sensor. 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 2. Confirm that code No. 20 is displayed.

4	CHECK INTAKE SENSOR CIRCUIT BETWEEN AMBIENT SENSOR AND AUTO AMP. (LCU)
<ul style="list-style-type: none"> 1. Disconnect auto amp. (LCU) harness connector. 2. Check circuit continuity between intake sensor harness terminal No. 1 and auto amp. (LCU) harness terminal No. 1. 	
OK or NG	
OK	<ul style="list-style-type: none"> ▶ 1. Replace auto amp. 2. Go to self-diagnosis step-by-step procedure (HA-45) and perform self-diagnosis STEP 2. Confirm that code No. 20 is displayed.
NG	Repair harness or connector.

Continuity should exist.

If OK, check harness for short.

RHA837H

Air Mix Door Motor PBR Circuit DIAGNOSTIC PROCEDURE

For description of mode door motor and air mix door motor circuit, refer to HA-84.

SYMPTOM: If PBR circuit is open or shorted. (-25 or 25 is indicated on the display as a result of conducting Self-diagnosis STEP 2.)

Perform diagnostic procedure for mode door motor and air mix door motor. Refer to HA-78.


GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA

SC
EL
IDX

NBHA0050

TROUBLE DIAGNOSES

Multiplex Communication Circuit



Multiplex Communication Circuit DIAGNOSTIC PROCEDURE

NBHA0118

SYMPTOM:


- A/C system does not come on.
- A/C system can not controlled.

1	CHECK CIRCUIT CONTINUITY BETWEEN DISPLAY & NAVI CONTROL UNIT AND AUTO AMP.
<p>Check circuit continuity between each terminal on Display & Navigation control unit and on auto amp.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">RHA889H</p>	
<p>Continuity should exist. If OK, check harness for short.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 2.
NG	▶ <ol style="list-style-type: none"> 1. Repair harness or connector. 2. Go to "OPERATIONAL CHECK", HA-66. Confirm that A/C system is in good order.

2	CHECK MULTI-PLEX COMMUNICATION SIGNAL
<p>Do approx. 3.5 volts exist between Display & NAVI control unit harness terminal Nos. 37, 38 and body ground?</p> <div style="text-align: center;"> </div> <p style="text-align: right;">RHA890H</p>	
<p>Yes or No</p>	
Yes	▶ GO TO 3.
No	▶ <ol style="list-style-type: none"> 1. Replace auto amp. 2. Go to "OPERATIONAL CHECK", HA-66. Confirm that A/C system is in good order.

TROUBLE DIAGNOSES

Multiplex Communication Circuit (Cont'd)

3	CHECK MULTIPLEX COMMUNICATION SIGNAL	
<p>Do approx. 3.5 volts exist between auto amp. harness terminal No. 40 and body ground?</p> <div style="text-align: center; margin: 10px 0;">  <p>Display & NAVI control unit connector (M11B)</p>  </div> <p style="text-align: right; margin-right: 50px;">RHA891H</p> <p style="text-align: center; margin-top: 10px;">Yes or No</p>		
Yes	▶	INSPECTION END.
No	▶	<ol style="list-style-type: none"> 1. Replace Display & NAVI control unit. 2. Go to "OPERATIONAL CHECK", HA-66. Confirm that A/C system is in good order.

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
HA
 SC
 EL
 IDX

SERVICE PROCEDURE

HFC-134a (R-134a) Service Procedure

HFC-134a (R-134a) Service Procedure

NBHA0070


NBHA0070S01

NBHA0070S0101

SETTING OF SERVICE TOOLS AND EQUIPMENT DISCHARGING REFRIGERANT


WARNING:

Avoid breathing A/C refrigerant and lubricant vapor or mist. Exposure may irritate eyes, nose and throat. Remove HFC-134a (R-134a) from A/C system using certified service equipment meeting requirements of SAE J2210 (R-134a recycling equipment) or J2209 (R-134a recovery equipment). If accidental system discharge occurs, ventilate work area before resuming service. Additional health and safety information may be obtained from refrigerant and lubricant manufacturers.




Evacuating System and Charging Refrigerant

NBHA0070S0102



SERVICE PROCEDURE

HFC-134a (R-134a) Service Procedure (Cont'd)



SHA251FA

*1: HA-146
 *2: HA-155

*3: HA-157
 *4: HA-114

*5: HA-2

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
 BT
HA
 SC
 EL
 IDX

SERVICE PROCEDURE

Maintenance of Lubricant Quantity in Compressor

Maintenance of Lubricant Quantity in Compressor

NBHA0071

The lubricant in the compressor circulates through the system with the refrigerant. Add lubricant to compressor when replacing any component or after a large gas leakage occurred. It is important to maintain the specified amount.

If lubricant quantity is not maintained properly, the following malfunctions may result:

- Lack of lubricant: May lead to a seized compressor
- Excessive lubricant: Inadequate cooling (thermal exchange interference)

LUBRICANT

NBHA0071S01

Name: Nissan A/C System Oil Type S
Part number: KLH00-PAGS0

CHECKING AND ADJUSTING

NBHA0071S02

Adjust the lubricant quantity according to the test group shown below.

1	CHECK LUBRICANT RETURN OPERATION	
Can lubricant return operation be performed?		
<ul style="list-style-type: none"> ● A/C system works properly. ● There is no evidence of a large amount of lubricant leakage. 		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

2	PERFORM LUBRICANT RETURN OPERATION, PROCEEDING AS FOLLOWS:	
1. Start engine, and set the following conditions:		
<ul style="list-style-type: none"> ● Test condition 		
Engine speed: Idling to 1,200 rpm		
A/C or AUTO switch: ON		
Blower speed: Max. position		
Temp. control: Optional [Set so that intake air temperature is 25 to 30°C (77 to 86°F).]		
2. Next item is for V-5 or V-6 compressor. Connect the manifold gauge, and check that the high pressure side pressure is 588 kPa (6 kg/cm ² , 85 psi) or higher.		
If less than the reference level, attach a cover to the front face of the condenser to raise the pressure.		
3. Perform lubricant return operation for about 10 minutes.		
4. Stop engine.		
CAUTION:		
If excessive lubricant leakage is noted, do not perform the lubricant return operation.		
OK	▶	GO TO 3.

3	CHECK COMPRESSOR	
Should the compressor be replaced?		
Yes or No		
Yes	▶	Go to "Lubricant Adjustment Procedure for Compressor Replacement", (HA-148).
No	▶	GO TO 4.

SERVICE PROCEDURE

Maintenance of Lubricant Quantity in Compressor (Cont'd)

4	CHECK ANY PART	
Is there any part to be replaced? (Evaporator, condenser, liquid tank or in case there is evidence of a large amount of lubricant leakage.) <p style="text-align: center;">Yes or No</p>		
Yes	▶	Go to "Lubricant Adjusting Procedure for Components Replacement Except Compressor", (HA-148).
No	▶	Carry out the A/C performance test.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SERVICE PROCEDURE

Maintenance of Lubricant Quantity in Compressor (Cont'd)

Lubricant Adjusting Procedure for Components Replacement Except Compressor

=NBHA0071S0201

After replacing any of the following major components, add the correct amount of lubricant to the system.

Amount of lubricant to be added

Part replaced	Lubricant to be added to system	Remarks
	Amount of lubricant mℓ (US fl oz, Imp fl oz)	
Evaporator	75 (2.5, 2.6)	—
Condenser	75 (2.5, 2.6)	—
Liquid tank	5 (0.2, 0.2)	Add if compressor is not replaced. *1
In case of refrigerant leak	30 (1.0, 1.1)	Large leak
	—	Small leak *2

*1: If compressor is replaced, addition of lubricant is included in the table.

*2: If refrigerant leak is small, no addition of lubricant is needed.

Lubricant Adjusting Procedure for Compressor Replacement


NBHA0071S0202

1. Before connecting ACR4 to vehicle, check ACR4 gauges. No refrigerant pressure should be displayed. If NG, recover refrigerant from equipment lines.
2. Connect ACR4 to vehicle. Confirm refrigerant purity in supply tank using ACR4 and refrigerant identifier. If NG, refer to "CONTAMINATED REFRIGERANT", HA-2.
3. Confirm refrigerant purity in vehicle A/C system using ACR4 and refrigerant identifier. If NG, refer to "CONTAMINATED REFRIGERANT", HA-2.
4. Discharge refrigerant into the refrigerant recovery/recycling equipment. Measure lubricant discharged into the recovery/recycling equipment.
5. Remove the drain plug of the "old" (removed) compressor. Drain the lubricant into a graduated container and record the amount of drained lubricant.
6. Remove the drain plug and drain the lubricant from the "new" compressor into a separate, clean container.
7. Measure an amount of new lubricant installed equal to amount drained from "old" compressor. Add this lubricant to "new" compressor through the suction port opening.
8. Measure an amount of new lubricant equal to the amount recovered during discharging. Add this lubricant to "new" compressor through the suction port opening.
9. Torque the drain plug.
18 - 19 N·m (1.8 - 1.9 kg·m, 13 - 14 ft·lb)
10. If the liquid tank also needs to be replaced, add an additional 5 mℓ (0.2 US fl oz, 0.2 Imp fl oz) of lubricant at this time.
Do not add this 5 mℓ (0.2 US fl oz, 0.2 Imp fl oz) of lubricant if only replacing the compressor.

SERVICE PROCEDURE

Maintenance of Lubricant Quantity in Compressor (Cont'd)

Lubricant adjusting procedure for compressor replacement




RHA065DD

Compressor REMOVAL AND INSTALLATION

NBHA0072

SEC. 274-275





RHA892H

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SERVICE PROCEDURE

Compressor Clutch OVERHAUL


NBHA0073




REMOVAL


NBHA0074

- When removing center bolt, hold clutch disc with clutch disc wrench.




- Remove the clutch disc using the clutch disc puller. Insert the holder's three pins into the holes in the clutch disc. Rotate the holder clockwise to hook it onto the plate. Then, tighten the center bolt to remove the clutch disc. After removing the clutch disc, remove the shims from either the drive shaft or the clutch disc.







- Remove the snap ring using external snap ring pliers.




- Pulley removal
Position the center pulley puller on the end of the drive shaft, and remove the pulley assembly using any commercially available pulley puller.
To prevent the pulley groove from being deformed, the puller claws should be positioned onto the edge of the pulley assembly.



- Remove the field coil harness clip using a pair of pliers.



- Remove the snap ring using external snap ring pliers.



INSPECTION

Clutch Disc

If the contact surface shows signs of damage due to excessive heat, replace clutch disc and pulley.

Pulley

Check the appearance of the pulley assembly. If the contact surface of pulley shows signs of excessive grooving, replace clutch disc and pulley. The contact surfaces of the pulley assembly should be cleaned with a suitable solvent before reinstallation.

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


SERVICE PROCEDURE

Compressor Clutch (Cont'd)

Coil

Check coil for loose connection or cracked insulation.


NBHA0075S03




INSTALLATION

NBHA0076


- Install the field coil.
Be sure to align the coil's pin with the hole in the compressor's front head.
- Install the field coil harness clip using a screwdriver.




- Install the pulley assembly using the installer and a hand press, and then install the snap ring using snap ring pliers.



- Install the clutch disc on the drive shaft, together with the original shim(s). Press the clutch disc down by hand.



- Using the holder to prevent clutch disc rotation, tighten the bolt to 14 N·m (1.4 kg-m, 10 ft-lb) torque.
After tightening the bolt, check that the pulley rotates smoothly.



- Check clearance around the entire periphery of clutch disc.

Disc-to-pulley clearance:

0.3 - 0.6 mm (0.012 - 0.024 in)

If the specified clearance is not obtained, replace adjusting spacer and readjust.

Break-in Operation

When replacing compressor clutch assembly, always carry out the break-in operation. This is done by engaging and disengaging the clutch about thirty times. Break-in operation raises the level of transmitted torque.

NBHA0076S01

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SERVICE PROCEDURE

Refrigerant Lines




Refrigerant Lines

REMOVAL AND INSTALLATION

=NBHA0077

- Refer to page HA-4 regarding "Precautions for Refrigerant Connection".

SEC. 271•274•276



- : Refrigerant leak checking order
- : (Tightening torque)
- : (Wrench size)
- : (O-ring size)
- Ⓜ : N·m (kg-m, in-lb)
- Ⓐ : 8 - 20 (0.8 - 2.0, 69 - 174)
- Ⓑ : 3 - 5 (0.3 - 0.5, 26 - 43)
- Ⓜ : N·m (kg-m, ft-lb)
- Ⓒ : 20 - 29 (2 - 3, 14 - 22)
- Ⓓ : 14 - 18 (1.4 - 1.8, 10 - 13)

RHA838H

CHECKING FOR REFRIGERANT LEAKS

=NBHA0078

- Perform a visual inspection of all refrigeration parts, fittings, hoses and components for signs of A/C lubricant leakage, damage and corrosion. A/C lubricant leakage may indicate an area of refrigerant leakage. Allow extra inspection time in these areas when using either an electronic refrigerant leak detector or fluorescent dye leak detector. GI
MA
- If dye is observed, confirm the leak with an electronic refrigerant leak detector. It is possible a prior leak was repaired and not properly cleaned. EM
- When searching for leaks, do not stop when one leak is found but continue to check for additional leaks at all system components and connections. LC
- When searching for refrigerant leaks using an electronic leak detector, move the probe along the suspected leak area at 1 to 2 inches per second and no further than 1/4 inch from the component. EC
FE

NOTE:

Moving the electronic leak detector probe slower and closer to the suspected leak area will improve the chances of finding a leak. AT

CHECKING SYSTEM FOR LEAKS USING THE FLUORESCENT LEAK DETECTOR

NBHA0116

1. Check A/C system for leaks using the UV lamp and safety glasses (J-42220) in a low sunlight area (area without windows preferable). Illuminate all components, fittings and lines. The dye will appear as a bright green/yellow area at the point of leakage. Fluorescent dye observed at the evaporator drain opening indicates an evaporator core assembly (tubes, core or TXV) leak. TF
PD
AX
2. If the suspected area is difficult to see, use an adjustable mirror or wipe the area with a clean shop rag or cloth, then check the cloth with the UV lamp for dye residue. SU
3. After the leak is repaired, remove any residual dye using dye cleaner (J-43872) to prevent future misdiagnosis. BR
4. Perform a system performance check and verify the leak repair with an approved electronic refrigerant leak detector. ST

NOTE:

- **Other gases in the work area or substances on the A/C components, for example, anti-freeze, windshield washer fluid, solvents and lubricants, may falsely trigger the leak detector. Make sure the surfaces to be checked are clean. Clean with a dry cloth or blow off with shop air.** RS
BT
- **Do not allow the sensor tip of the detector to contact with any substance. This can also cause false readings and may damage the detector.** HA

DYE INJECTION

NBHA0117

(This procedure is only necessary when re-charging the system or when the compressor has seized and was replaced.) SC
EL

1. Check A/C system static (at rest) Pressure. Pressure must be at least 345 kPa (50 psi). IDX
2. Pour one bottle (1/4 ounce /7.4 cc) of the A/C refrigerant dye into the injector tool (J-41459).
3. Connect the injector tool to the A/C LOW PRESSURE side service fitting.
4. Start engine and switch A/C ON.

SERVICE PROCEDURE

Refrigerant Lines (Cont'd)

5. When the A/C operating (compressor running), inject one bottle (1/4 ounce /7.4 cc) of fluorescent dye through the low-pressure service valve using dye injector tool J-41459 (refer to the manufacture's operating instructions).
6. With the engine still running, disconnect the injector tool from the service fitting.


CAUTION:

Be careful not to allow dye to spray or drip when disconnecting the injector from the system.

NOTE:

If repairing the A/C system or replacing a component, pour the dye directly into the open system connection and proceed with the service procedures.

7. Operate the A/C system for a minimum of 20 minutes to mix the dye with the system oil. Depending on the leak size, operating conditions and location of the leak, it may take from minutes to days for the dye to penetrate a leak and become visible.



ELECTRONIC REFRIGERANT LEAK DETECTOR


NBHA0115

Precautions for Handling Leak Detector


NBHA0115S01

When performing a refrigerant leak check, use a J-41995 A/C leak detector or equivalent. Ensure that the instrument is calibrated and set properly per the operating instructions.


The leak detector is a delicate device. In order to use the leak detector properly, read the operating instructions and perform any specified maintenance.



1. Position probe approximately 5 mm (3/16 in) away from point to be checked.



2. When testing, circle each fitting completely with probe.



3. Move probe along component approximately 25 to 50 mm (1 to 2 in)/sec.

GI

MA

EM

LC

Checking Procedure

To prevent inaccurate or false readings, make sure there is no refrigerant vapor, shop chemicals, or cigarette smoke in the vicinity of the vehicle. Perform the leak test in calm area (low air/wind movement) so that the leaking refrigerant is not dispersed.

NBHA0115S02

EC

FE

1. Turn engine off.
2. Connect a suitable A/C manifold gauge set to the A/C service ports.
3. Check if the A/C refrigerant pressure is at least 345 kPa (3.52 kg/cm², 50 psi) above 16°C (61°F). If less than specification, recover/evacuate and recharge the system with the specified amount of refrigerant.

AT

TF

PD

NOTE:

At temperatures below 16°C (61°F), leaks may not be detected since the system may not reach 345 kPa (3.52 kg/cm², 50 psi).

AX

4. Conduct the leak test from the high side (compressor discharge **a** to evaporator inlet **f**) to the low side (evaporator drain hose **g** to shaft seal **k**). Refer to HA-154. Perform a leak check for the following areas carefully. Clean the component to be checked and move the leak detector probe completely around the connection/component.

SU

BR

- **Compressor**

Check the fitting of high and low pressure hoses, relief valve and shaft seal.

ST

- **Liquid tank**

Check the pressure switch, tube fitting, weld seams and the fusible plug mount.

RS

- **Service valves**

Check all around the service valves. Ensure service valve caps are secured on the service valves (to prevent leaks).

BT

NOTE:

After removing A/C manifold gauge set from service valves, wipe any residue from valves to prevent any false readings by leak detector.

HA

- **Cooling unit (Evaporator)**

With engine OFF, turn blower fan on "High" for at least 15 seconds to dissipate any refrigerant trace in the cooling unit. Wait a minimum of 10 minutes accumulation time (refer to the manufacturer's recommended procedure for actual wait time) before inserting the leak detector probe into the drain hose. Keep the probe inserted for at least ten seconds. Use caution not to contaminate the probe tip with water or dirt that may be in the drain hose.

SC


EL

IDX

SERVICE PROCEDURE

Refrigerant Lines (Cont'd)

5. If a leak detector detects a leak, verify at least once by blowing compressed air into area of suspected leak, then repeat check as outlined above.
6. Do not stop when one leak is found. Continue to check for additional leaks at all system components. If no leaks are found, perform steps 7 - 10.
7. Start engine.
8. Set the heater A/C control as follows:
 - 1) A/C switch ON.
 - 2) Face mode
 - 3) Recirculation switch ON
 - 4) Max cold temperature
 - 5) Fan speed high
9. Run engine at 1,500 rpm for at least 2 minutes.
10. Turn engine off and perform leak check again following steps 4 through 6 above.



Refrigerant leaks should be checked immediately after stopping the engine. Begin with the leak detector at the compressor. The pressure on the high pressure side will gradually drop after refrigerant circulation stops and pressure on the low pressure side will gradually rise, as shown in the graph. Some leaks are more easily detected when pressure is high.

11. Before connecting ACR4 to vehicle, check ACR4 gauges. No refrigerant pressure should be displayed. If pressure is displayed, recover refrigerant from equipment lines and then check refrigerant purity.
12. Confirm refrigerant purity in supply tank using ACR4 and refrigerant identifier.
13. Confirm refrigerant purity in vehicle A/C system using ACR4 and refrigerant identifier.
14. Discharge A/C system using approved refrigerant recovery equipment. Repair the leaking fitting or component as necessary.
15. Evacuate and recharge A/C system and perform the leak test to confirm no refrigerant leaks.
16. Conduct A/C performance test to ensure system works properly.

Belt

TENSION ADJUSTMENT

- Refer to MA-13, "Checking Drive Belts".

NBHA0079

GI

MA

EM

LC

EC

NBHA0108

Ventilation Air Filter

FUNCTION

Air inside passenger compartment is kept clean at either recirculation or fresh mode by installing ventilation air filter into cooling unit.

NOTE:


To replace ventilation air filter, refer to MA-6, "Periodic Maintenance".

Caution label is fixed inside the glove box.

FE

AT

TF



REPLACEMENT PROCEDURE

1. Remove glove box.
2. Remove instrument lower panel from instrument panel.
3. Remove ventilation air filter fixed clip.


NBHA0109

PD

AX

SU

BR



4. Take out the lower side ventilation air filter from cooling unit.
5. Then slide upper side filter to the bottom position and take off the ventilation air filter from the cooling unit.
6. Replace with new one and reinstall on cooling unit.
7. Reinstall clip, instrument lower panel and glove box.

ST

RS


BT

HA

SC

EL

IDX



SERVICE DATA AND SPECIFICATIONS (SDS)

Compressor

Compressor

NBHA0081

Model		CALSONIC make V-6
Type		V-6 variable displacement
Displacement cm ³ (cu in)/rev.	Max.	184 (11.228)
	Min.	14.5 (0.885)
Cylinder bore x stroke mm (in)		37 (1.46) x [2.3 - 28.6 (0.091 - 1.126)]
Direction of rotation		Clockwise (viewed from drive end)
Drive belt		Poly V

Lubricant

NBHA0082

Model		CALSONIC make V-6
Name		Nissan A/C System Oil Type S
Part number*		KLH00-PAGSO
Capacity mℓ (US fl oz, Imp fl oz)	Total in system	200 (6.8, 7.0)
	Compressor (Service part) charging amount	200 (6.8, 7.0)

*: Always check with the Parts Department for the latest parts information.

Refrigerant

NBHA0083

Type	HFC-134a (R-134a)
Capacity kg (lb)	0.60 - 0.70 (1.32 - 1.54)

Engine Idling Speed (When A/C is ON)

NBHA0084

- Refer to EC-639, "Idle Speed and Ignition Timing".

Belt Tension

NBHA0085

- Refer to MA-29, "Engine Maintenance".