

AUTOMATIC TRANSMISSION

SECTION AT

LC

EC

FE

MA

CONTENTS

TROUBLE DIAGNOSIS - INDEX	
Alphabetical & P No. Index for DTC	4
PRECAUTIONS	6
Precautions for Supplemental Restraint System	
(SRS) "AIR BAG" and "SEAT BELT	
PRE-TENSIONER"	6
Precautions for On Board Diagnostic (OBD)	
System of A/T and Engine	6
Precautions	6
Service Notice or Precautions	8
Wiring Diagrams and Trouble Diagnosis	9
PREPARATION	10
Special Service Tools	10
OVERALL SYSTEM	
A/T Electrical Parts Location	12
Circuit Diagram	13
Cross-sectional View	14
Hydraulic Control Circuit	15
Shift Mechanism	16
Control System	
Control Mechanism	26
Control Valve	31
ON BOARD DIAGNOSTIC SYSTEM	
DESCRIPTION	33
Introduction	33
OBD-II Function for A/T System	33
One or Two Trip Detection Logic of OBD-II	
OBD-II Diagnostic Trouble Code (DTC)	33
Malfunction Indicator Lamp (MIL)	
CONSULT	
Diagnostic Procedure Without CONSULT	
TROUBLE DIAGNOSIS - INTRODUCTION	
Introduction	
Work Flow	
TROUBLE DIAGNOSIS - BASIC INSPECTION	
A/T Fluid Check	
Stall Test	
Line Pressure Test	62

TROUBLE DIAGNOSIS - GENERAL	AT
DESCRIPTION81	
Symptom Chart81	TF
TCM Terminals and Reference Value92	IL
TROUBLE DIAGNOSIS FOR POWER SUPPLY96	
Wiring Diagram - AT - MAIN96	PD
DTC P0705 PARK/NEUTRAL POSITION SWITCH99	
Description99	
Wiring Diagram - AT - PNP/SW101	$\mathbb{A}\mathbb{X}$
Diagnostic Procedure102	
Component Inspection	@II II
DTC P0710 A/T FLUID TEMPERATURE SENSOR	SU
CIRCUIT105	
Description	BR
Wiring Diagram - AT - FTS	
Diagnostic Procedure	
Component Inspection	ST
DTC P0720 VEHICLE SPEED SENSOR.A/T	
(REVOLUTION SENSOR)110	
Description	RS
Wiring Diagram - AT - VSSA/T112	
Diagnostic Procedure113	BT
Component Inspection114	ا تا
DTC P0725 ENGINE SPEED SIGNAL	
Description	HA
Wiring Diagram - AT - ENGSS116	
Diagnostic Procedure117	88
DTC P0731 IMPROPER SHIFTING TO 1ST GEAR	SC
POSITION 119	
Description119	EL
Wiring Diagram - AT - 1ST122	
Diagnostic Procedure123	
Component Inspection124	
DTC P0732 IMPROPER SHIFTING TO 2ND GEAR	
POSITION 125	
Description125	
Wiring Diagram - AT - 2ND128	
Diagnostic Procedure129	
Component Inspection	



CONTENTS (Cont'd)

DTC P0733 IMPROPER SHIFTING TO 3RD GEAF	₹	Wiring Diagram - AT - BA/FTS	191
POSITION	131	Diagnostic Procedure	192
Description	131	Component Inspection	194
Wiring Diagram - AT - 3RD	134	VEHICLE SPEED SENSOR.MTR	
Diagnostic Procedure		Description	195
Component Inspection		Wiring Diagram - AT - VSSMTR	
DTC P0734 IMPROPER SHIFTING TO 4TH GEAR		Diagnostic Procedure	
POSITION		CONTROL UNIT (RAM), CONTROL UNIT (ROM)	
Description		Description	
Wiring Diagram - AT - 4TH		Diagnostic Procedure	
Diagnostic Procedure		CONTROL UNIT (EEP ROM)	
Component Inspection		Description	
DTC P0740 TORQUE CONVERTER CLUTCH		Diagnostic Procedure	
SOLENOID VALVE	147	TROUBLE DIAGNOSES FOR SYMPTOMS	
Description		Wiring Diagram - AT - NONDTC	
Wiring Diagram - AT - TCV		1. O/D OFF Indicator Lamp Does Not Come On	
Diagnostic Procedure		2. Engine Cannot Be Started In "P" and "N"	
Component Inspection		Position	.209
DTC P0744 IMPROPER LOCK-UP OPERATION		3. In "P" Position, Vehicle Moves Forward Or	00
Description		Backward When Pushed	210
Wiring Diagram - AT - TCCSIG		4. In "N" Position, Vehicle Moves	
Diagnostic Procedure		5. Large Shock. "N" -> "R" Position	
Component Inspection		6. Vehicle Does Not Creep Backward In "R"	10
DTC P0745 LINE PRESSURE SOLENOID VALVE		Position	215
Description		7. Vehicle Does Not Creep Forward In "D", "2"	210
Wiring Diagram - AT - LPSV		Or "1" Position	218
Diagnostic Procedure		8. Vehicle Cannot Be Started From D ₁	
Component Inspection		9. A/T Does Not Shift: D ₁ -> D ₂ Or Does Not	221
DTC P0750 SHIFT SOLENOID VALVE A		9. A 1 boes Not Gillit. D ₁ -> D ₂ Of boes Not Kickdown: D ₄ -> D ₂	22/
Description		10. A/T Does Not Shift: D ₂ -> D ₃	
Wiring Diagram - AT - SSV/A		11. A/T Does Not Shift: D ₃ -> D ₄	
Diagnostic Procedure		12. A/T Does Not Perform Lock-up	
Component Inspection		13. A/T Does Not Helloth Lock-up Condition	
DTC P0755 SHIFT SOLENOID VALVE B		14. Lock-up Is Not Released	
Description		15. Engine Speed Does Not Return To Idle (Light	
Wiring Diagram - AT - SSV/B		Braking D ₄ -> D ₃)	
Diagnostic Procedure		16. Vehicle Does Not Start From D ₁	
-		17. A/T Does Not Shift: $D_4 \rightarrow D_3$, When	240
Component Inspection DTC P1705 THROTTLE POSITION SENSOR			244
		Overdrive Control Switch "ON" -> "OFF"	241
Description		18. A/T Does Not Shift: D ₃ -> 2 ₂ , When Selector	242
Wiring Diagram - AT - TPS		Lever "D" -> "2" Position	242
Diagnostic Procedure		19. A/T Does Not Shift: 2 ₂ -> 1 ₁ , When Selector	0.40
Component Inspection	183	Lever "2" -> "1" Position	243
DTC P1760 OVERRUN CLUTCH SOLENOID	101	20. Vehicle Does Not Decelerate By Engine	244
VALVE		Brake	244
Description		21. TCM Self-diagnosis Does Not Activate (PNP,	
Wiring Diagram - AT - OVRCSV		Overdrive Control and Throttle Position Switches	0.4.4
Diagnostic Procedure		Circuit Checks)	
Component Inspection	188	A/T SHIFT LOCK SYSTEM	
DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP	400	Description	
SENSOR CIRCUIT AND TCM POWER SOURCE)		Wiring Diagram - SHIFT	
Description	189	Diagnostic Procedure	254



G[

 $\mathbb{M}\mathbb{A}$

EM

LC

EC

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC

EL

CONTENTS (Cont'd)

Component Check	256
KEY INTERLOCK CABLE	257
Components	257
Removal	257
Installation	258
ON-VEHICLE SERVICE	259
Control Valve Assembly and Accumulators	259
Revolution Sensor Replacement	260
Rear Oil Seal Replacement	260
Parking Components Inspection	260
Park/Neutral Position Switch Adjustment	260
Manual Control Linkage Adjustment	261
REMOVAL AND INSTALLATION	262
Removal	262
Installation	263
OVERHAUL	265
Components	265
Oil Channel	267
Locations of Needle Bearings, Thrust Washers	
and Snap Rings	268
DISASSEMBLY	269
REPAIR FOR COMPONENT PARTS	280
Oil Pump	280
Control Valve Assembly	284
Control Valve Upper Body	290
Control Valve Lower Body	
Reverse Clutch	
High Clutch	301

	Forward and Overrun Clutches	303
	Low & Reverse Brake	307
	Forward Clutch Drum Assembly	311
	Rear Internal Gear and Forward Clutch Hub	313
	Band Servo Piston Assembly	316
	Parking Pawl Components	320
A	SSEMBLY	322
	Assembly (1)	322
	Adjustment	
	Assembly (2)	332
SI	ERVICE DATA AND SPECIFICATIONS (SDS).	339
	General Specifications	339
	Shift Schedule	339
	Stall Revolution	339
	Line Pressure	339
	Return Springs	340
	Accumulator O-ring	341
	Clutches and Brakes	341
	Oil Pump and Low One-way Clutch	343
	Total End Play	343
	Reverse Clutch Drum End Play	344
	Removal and Installation	344
	Shift Solenoid Valves	344
	Solenoid Valves	344
	A/T Fluid Temperature Sensor	344
	Revolution Sensor	344
	Dropping Resistor	344



Alphabetical & P No. Index for DTC

ALPHABETICAL INDEX FOR DTC

NBAT0179 NBAT0179S01

		TC	NBAT0179S01
Items (CONSULT screen terms)	ECM*1	CONSULT GST*2	Reference page
A/T 1ST GR FNCTN	1103	P0731	AT-119
A/T 2ND GR FNCTN	1104	P0732	AT-125
A/T 3RD GR FNCTN	1105	P0733	AT-131
A/T 4TH GR FNCTN	1106	P0734	AT-137
A/T TCC S/V FNCTN	1107	P0744	AT-152
ATF TEMP SEN/CIRC	1208	P0710	AT-105
ENGINE SPEED SIG	1207	P0725	AT-115
L/PRESS SOL/CIRC	1205	P0745	AT-161
O/R CLTCH SOL/CIRC	1203	P1760	AT-184
PNP SW/CIRC	1101	P0705	AT-99
SFT SOL A/CIRC*3	1108	P0750	AT-167
SFT SOL B/CIRC*3	1201	P0755	AT-171
TCC SOLENOID/CIRC	1204	P0740	AT-147
TP SEN/CIRC A/T*3	1206	P1705	AT-175
VEH SPD SEN/CIR AT*4	1102	P0720	AT-110

^{*1:} In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

^{*2:} These numbers are prescribed by SAE J2012.

^{*3:} When the fail-safe operation occurs, the MIL illuminates.

^{*4:} The MIL illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

TROUBLE DIAGNOSIS — INDEX



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

BR

ST

RS

BT

HA

SC

EL

Alphabetical & P No. Index for DTC (Cont'd)

P NO. INDEX FOR DTC

=NBAT0179S02

DTC		Items	
CONSULT GST*2	ECM*1	(CONSULT screen terms)	Reference page
P0705	1101	PNP SW/CIRC	AT-99
P0710	1208	ATF TEMP SEN/CIRC	AT-105
P0720	1102	VEH SPD SEN/CIR AT*4	AT-110
P0725	1207	ENGINE SPEED SIG	AT-115
P0731	1103	A/T 1ST GR FNCTN	AT-119
P0732	1104	A/T 2ND GR FNCTN	AT-125
P0733	1105	A/T 3RD GR FNCTN	AT-131
P0734	1106	A/T 4TH GR FNCTN	AT-137
P0740	1204	TCC SOLENOID/CIRC	AT-147
P0744	1107	A/T TCC S/V FNCTN	AT-152
P0745	1205	L/PRESS SOL/CIRC	AT-161
P0750	1108	SFT SOL A/CIRC*3	AT-167
P0755	1201	SFT SOL B/CIRC*3	AT-171
P1705	1206	TP SEN/CIRC A/T*3	AT-175
P1760	1203	O/R CLTCH SOL/CIRC	AT-184

^{*1:} In Diagnostic Test Mode II (Self-diagnostic results), these numbers are controlled by NISSAN.

^{*2:} These numbers are prescribed by SAE J2012.

^{*3:} When the fail-safe operation occurs, the MIL illuminates.

^{*4:} The MIL illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

PRECAUTIONS



Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to INFINITI QX4 is as follows:

- For a frontal collision
 - The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
 - The Supplemental Restraint System consists of side air bag module (located in the outer side of front seat), satellite sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the RS section of this Service Manual.

WARNING:


- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses covered with yellow insulation tape either just before the harness connectors or for the complete harness are related to the SRS.

Precautions for On Board Diagnostic (OBD) System of A/T and Engine

The ECM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:


- Be sure to turn the ignition switch OFF and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will
 cause the MIL to light up due to an open circuit. (Be sure the connector is free from water, grease,
 dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. Interference of the harness with a bracket, etc. may cause the MIL to light up due to a short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube
 may cause the MIL to light up due to a malfunction of the EGR system or fuel injection system,
 etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the TCM and ECM before returning the vehicle to the customer.



Precautions

Before connecting or disconnecting the TCM harness connector, turn ignition switch "OFF" and disconnect negative battery terminal. Failure to do so may damage the TCM. Because battery voltage is applied to TCM even if ignition switch is turned off.





Perform TCM in-

put/output signal

inspection before replacement.

ENGINE SOON

DLD ONE

 When connecting or disconnecting pin connectors into or from TCM, take care not to damage pin terminals (bend or break).

Make sure that there are not any bends or breaks on TCM pin terminal, when connecting pin connectors.

MA

. .

LC

 Before replacing TCM, perform TCM input/output signal inspection and make sure whether TCM functions properly or not. (See page AT-92.)

EG

AT

ſF



SAT964I

MEF040DA

 After performing each TROUBLE DIAGNOSIS, perform "DTC (Diagnostic Trouble Code) CONFIRMATION PROCE-DURE".

TION PROCEDURE" if the repair is completed.

The DTC should not be displayed in the "DTC CONFIRMA-

NFIRIVIA-

BR

ST

Before proceeding with disassembly, thoroughly clean the outside of the transmission. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.

RS

Disassembly should be done in a clean work area.

IJ/@

 Use lint-free cloth or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the transmission.

BT

 Place disassembled parts in order for easier and proper assembly.

HA

 All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.

3C

 Gaskets, seals and O-rings should be replaced any time the transmission is disassembled.

It is very important to perform functional tests whenever they are indicated.

EL

The valve body contains precision parts and requires extreme care when parts are removed and serviced. Place disassembled valve body parts in order for easier and proper assembly. Care will also prevent springs and small parts from becoming scattered or lost.

 Properly installed valves, sleeves, plugs, etc. will slide along bores in valve body under their own weight.



PRECAUTIONS



- Before assembly, apply a coat of recommended ATF to all parts. Apply petroleum jelly to protect O-rings and seals, or hold bearings and washers in place during assembly. Do not use grease.
- Extreme care should be taken to avoid damage to O-rings, seals and gaskets when assembling.
- Replace ATF cooler if excessive foreign material is found in oil pan or clogging strainer. Refer to "ATF COOLER SERVICE" (Refer to AT-9).
- After overhaul, refill the transmission with new ATF.
- When the A/T drain plug is removed, only some of the fluid is drained. Old A/T fluid will remain in torque converter and ATF cooling system.

Always follow the procedures when changing A/T fluid. Refer to MA-21, "Changing A/T Fluid".

Service Notice or Precautions

NRAT0004

FAIL-SAFE

NBAT0004S01

The TCM has an electronic Fail-Safe (limp home mode). This allows the vehicle to be driven even if a major electrical input/output device circuit is damaged.

Under Fail-Safe, the vehicle always runs in third gear, even with a shift lever position of "1", "2" or "D". The customer may complain of sluggish or poor acceleration.

When the ignition key is turned "ON" following Fail-Safe operation, O/D OFF indicator lamp blinks for about 8 seconds. (For "TCM SELF-DIAGNOSTIC PROCEDURE (No Tools)", refer to AT-46.)

Fail-Safe may occur without electrical circuit damage if the vehicle is driven under extreme conditions (such as excessive wheel spin followed by sudden braking). To recover normal shift pattern, turn the ignition key "OFF" for 5 seconds, then "ON".

The blinking of the O/D OFF indicator lamp for about 8 seconds will appear only once and be cleared. The customer may resume normal driving conditions.

Always follow the "WORK FLOW" (Refer to AT-57).

The SELF-DIAGNOSIS results will be as follows:

The first SELF-DIAGNOSIS will indicate damage to the vehicle speed sensor or the revolution sensor. During the next SELF-DIAGNOSIS, performed after checking the sensor, no damages will be indicated.

TORQUE CONVERTER SERVICE

NBAT0004S04

The torque converter should be replaced under any of the following conditions:

- External leaks in the hub weld area.
- Converter hub is scored or damaged.
- Converter pilot is broken, damaged or fits poorly into crankshaft.
- Steel particles are found after flushing the cooler and cooler lines.
- Pump is damaged or steel particles are found in the converter.
- Vehicle has TCC shudder and/or no TCC apply. Replace only after all hydraulic and electrical diagnoses have been made. (Converter clutch material may be glazed.)
- Converter is contaminated with engine coolant containing antifreeze.
- Internal failure of stator roller clutch.
- Heavy clutch debris due to overheating (blue converter).
- Steel particles or clutch lining material found in fluid filter or on magnet when no internal parts in unit are worn or damaged indicates that lining material came from converter.

The torque converter should not be replaced if:

• The fluid has an odor, is discolored, and there is no evidence of metal or clutch facing particles.

PRECAUTIONS

\$\dagger

Service Notice or Precautions (Cont'd)

- The threads in one or more of the converter bolt holes are damaged.
- Transmission failure did not display evidence of damaged or worn internal parts, steel particles or clutch
 plate lining material in unit and inside the fluid filter.
 - GI
- Vehicle has been exposed to high mileage (only). The exception may be where the torque converter clutch dampener plate lining has seen excess wear by vehicles operated in heavy and/or constant traffic, such as taxi, delivery or police use.

MA

ATF COOLER SERVICE

Replace ATF cooler if excessive foreign material is found in oil pan or clogging strainer.

Replace radiator lower tank (which includes ATF cooler) with a new one and flush cooler line using cleaning solvent and compressed air.



OBD-II SELF-DIAGNOSIS

• A/T self-diagnosis is performed by the TCM in combination with the ECM. The results can be read through the blinking pattern of the O/D OFF indicator or the malfunction indicator lamp (MIL). Refer to the table on AT-38 for the indicator used to display each self-diagnostic result.



 The self-diagnostic results indicated by the MIL are automatically stored in both the ECM and TCM memories.



Always perform the procedure "HOW TO ERASE DTC" on AT-35 to complete the repair and avoid unnecessary blinking of the MIL.

AT

• The following self-diagnostic items can be detected using ECM self-diagnostic results mode* only when the O/D OFF indicator lamp does not indicate any malfunctions.



- PNP switch
- A/T 1st, 2nd, 3rd, or 4th gear function
- A/T TCC S/V function (lock-up)

*: For details of OBD-II, refer to EC-54, "Introduction".

PD

 Certain systems and components, especially those related to OBD, may use the new style slidelocking type harnesss connector. For description and how to disconnect, refer to EL-5, "Description".



Wiring Diagrams and Trouble Diagnosis

When you read wiring diagrams, refer to the following:



EL-9, "POWER SUPPLY ROUTING" for power distribution circuit

BF

When you perform trouble diagnosis, refer to the following:

- GI-34, "HOW TO FOLLOW TEST GROUP IN TROUBLE DIAGNOSIS"
- GI-23, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT"

51

BT

HA

SC

EL

PREPARATION



Special Service Tools

NBAT0006

The actual shapes of Kent-	Moore tools may differ from those of special service	tools illustrated here.
Tool number (Kent-Moore No.) Tool name	Description	
ST2505S001 (J34301-C) Oil pressure gauge set 1 ST25051001 (3 -3 -3 -3 -5 NT097	Measuring line pressure
ST07870000 (J37068) Transmission case stand	a c	Disassembling and assembling A/T a: 182 mm (7.17 in) b: 282 mm (11.10 in) c: 230 mm (9.06 in) d: 100 mm (3.94 in)
KV31102100 (J37065) Torque converter one- way clutch check tool	NT421	Checking one-way clutch in torque converter
ST25850000 (J25721-A) Sliding hammer	NT098	Removing oil pump assembly a: 179 mm (7.05 in) b: 70 mm (2.76 in) c: 40 mm (1.57 in) dia. d: M12 x 1.75P
KV31102400 (J34285 and J34285-87) Clutch spring compressor	NT423	Removing and installing clutch return springs a: 320 mm (12.60 in) b: 174 mm (6.85 in)

PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description		G I
ST33200000 (J26082) Drift		Installing oil pump housing oil seal Installing rear oil seal a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.	MA
	NT091		EM
(J34291) Shim setting gauge set		Selecting oil pump cover bearing race and oil pump thrust washer	LG
			EC
	NT101		FE

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC


EL

IDX




A/T Electrical Parts Location

NBAT0007








MAT725A



Cross-sectional View


NBAT0010





Hydraulic Control Circuit





SAT624GA

Shift Mechanism

OVERALL SYSTEM


JRATO012

The automatic transmission uses compact, dual planetary gear systems to improve power-transmission efficiency, simplify construction and reduce weight.

It also employs an optimum shift control and superwide gear ratios. They improve starting performance and acceleration during medium and high-speed operation.

Two one-way clutches are also employed: one is used for the forward clutch and the other for the low clutch. These one-way clutches, combined with four accumulators, reduce shifting shock to a minimum.

CONSTRUCTION



- 1. Torque converter clutch piston
- 2. Torque converter
- 3. Oil pump
- 4. Input shaft
- 5. Brake band
- 6. Reverse clutch
- 7. High clutch
- 8. Front pinion gear

- 9. Front sun gear
- 10. Front internal gear
- 11. Front planetary carrier
- 12. Rear sun gear
- 13. Rear pinion gear
- 14. Rear internal gear
- 15. Rear planetary carrier
- 16. Forward clutch

- 17. Forward one-way clutch
- 18. Overrun clutch
- 19. Low one-way clutch
- 20. Low & reverse brake
- 21. Parking pawl
- 22. Parking gear
- 23. Output shaft

FUNCTION OF CLUTCH AND BRAKE

NBAT0012S02

Clutch and brake components	Abbr.	Function
Oldforf and brake components	71001.	1 dilettori
Reverse clutch 6	R/C	To transmit input power to front sun gear 9.
High clutch 7	H/C	To transmit input power to front planetary carrier 11.
Forward clutch 16	F/C	To connect front planetary carrier 11 with forward one-way clutch 17.
Overrun clutch 18	O/C	To connect front planetary carrier 11 with rear internal gear 14.
Brake band 5	B/B	To lock front sun gear 9.
Forward one-way clutch 17	F/O.C	When forward clutch 16 is engaged, to stop rear internal gear 14 from rotating in opposite direction against engine revolution.
Low one-way clutch 19	L/O.C	To stop front planetary carrier 11 from rotating in opposite direction against engine revolution.
Low & reverse brake 20	L & R/B	To lock front planetary carrier 11.



MA

LC

CLUTCH AND BAND CHART

NBAT0012S03

Chift	nooi	Reverse	Lliab	For-	Over-	E	Band serv	0	For- ward	Low	Low &															
	posi- on	clutch	High clutch	ward clutch	run clutch	2nd apply	3rd release	4th apply	ı -wav ı	one way	one way	one way	one way	one w	-way	-way	one -way	-way	one way	one way	one way	one way way	one way	reverse brake	Lock-up	Remarks
ı	>												PARK POSITION													
ı	3	0									0		REVERSE POSITION													
1	N												NEUTRAL POSITION													
	1st			0	*1D				В	В																
D*4	2nd			0	*1A	0			В				Automatic shift													
D 4	3rd		0	0	*1A	*2C	С		В			*5〇	1 ⇔ 2 ⇔ 3 ⇔ 4													
	4th		0	С		*3C	С	0				0														
2	1st			0	0				В	В			Automatic shift													
2	2nd			0	0	0			В				1 ⇔ 2													
1	1st			0	0				В	В	0		Locks (held stationary) in 1st speed 1 ← 2													
	2nd			0	0	0			В																	

^{*1:} Operates when overdrive control switch is being set in "OFF" position.

○ : Operates.

A: Operates when throttle opening is less than 3/16, activating engine brake.

B: Operates during "progressive" acceleration.

C: Operates but does not affect power transmission.

D: Operates when throttle opening is less than 3/16, but does not affect engine brake.

FE

EC

AT































^{*2:} Oil pressure is applied to both 2nd "apply" side and 3rd "release" side of band servo piston. However, brake band does not contract because oil pressure area on the "release" side is greater than that on the "apply" side.

^{*3:} Oil pressure is applied to 4th "apply" side in condition *2 above, and brake band contracts.

^{*4:} A/T will not shift to 4th when overdrive control switch is set in "OFF" position.

^{*5:} Operates when overdrive control switch is "OFF".



POWER TRANSMISSION

"N" and "P" Positions

=NBAT0012S04


NBAT0012S0401

"N" position

No control members operate. Power from the input shaft is not transmitted to the output shaft since the clutch does not operate.

"P" position

Similar to the "N" position, no control members operate. The parking pawl interconnected with the select lever engages with the parking gear to mechanically hold the output shaft so that the power train is locked.






G[

MA


1 ₁ " Position	=NBAT0012S040
Forward clutch Forward one-way clutch Overrun clutch Low and reverse brake	As overrun clutch engages, rear internal gear is locked by the operation of low and reverse brake. This is different from that of D_1 and D_2 .
Engine brake	Overrun clutch always engages, therefore engine brake can be obtained when decelerating.



OVERALL SYSTEM




"D ₁ " and "2 ₁ " Positions	=NBAT0012S0402
Forward one-way clutch Forward clutch Low one-way clutch	Rear internal gear is locked to rotate counterclockwise because of the functioning of these three clutches. (Start-up at D ₁)
Overrun clutch engagement conditions (Engine brake)	D ₁ : Overdrive control switch in "OFF" Throttle opening less than 3/16 2 ₁ : Throttle opening less than 3/16 At D ₁ and 2 ₁ positions, engine brake is not activated due to free turning of low one-way clutch.





"D ₂ ", "2 ₂ " and "1 ₂ " Positions		!
Forward clutch Forward one-way clutch Brake band	Rear sun gear drives rear planetary carrier and combined front internal gear. Front internal gear now rotates around front sun gear accompanying front planetary carrier. As front planetary carrier transfers the power to rear internal gear through forward clutch and forward one-way clutch, this rotation of rear internal gear increases the speed of rear planetary carrier compared with that of the 1st speed.	GI MA
Overrun clutch engagement conditions	D ₂ : Overdrive control switch in "OFF" Throttle opening less than 3/16 2 ₂ : Throttle opening less than 3/16 1 ₂ : Always engaged	EM




OVERALL SYSTEM




"D₃" Position

	=NBAT0012S0404
High clutch Forward clutch Forward one-way clutch	Input power is transmitted to front planetary carrier through high clutch. And front planetary carrier is connected to rear internal gear by operation of forward clutch and forward one-way clutch. This rear internal gear rotation and another input (the rear sun gear) accompany rear planetary carrier to turn at the same speed.
Overrun clutch engagement conditions	D ₃ : Overdrive control switch in "OFF" Throttle opening less than 3/16





"D ₄ " (OD) Position	=NBAT0012S0405	
High clutch Brake band Forward clutch (Does not affect power transmission)	Input power is transmitted to front carrier through high clutch. This front planetary carrier turns around the sun gear which is fixed by brake band and makes front internal gear (output) turn faster.	GI MA
Engine brake	At D ₄ position, there is no one-way clutch in the power transmission line and engine brake can be obtained when decelerating.	




OVERALL SYSTEM



"R" Position

	=NBAT0012S0407
Reverse clutch Low and reverse brake	Front planetary carrier is stationary because of the operation of low and reverse brake. Input power is transmitted to front sun gear through reverse clutch, which drives front internal gear in the opposite direction.
Engine brake	As there is no one-way clutch in the power transmission line, engine brake can be obtained when decelerating.





Control System

OUTLINE

=NBAT0013

The automatic transmission senses vehicle operating conditions through various sensors. It always controls the optimum shift position and reduces shifting and lock-up shocks.

SENSORS		TCM		ACTUATORS	MA
PNP switch Throttle position sensor Closed throttle position switch Wide open throttle position switch Engine speed signal A/T fluid temperature sensor Revolution sensor	>	Shift control Line pressure control Lock-up control Overrun clutch control Timing control Fail-safe control	>	Shift solenoid valve A Shift solenoid valve B Overrun clutch solenoid valve Torque converter clutch solenoid valve	EM LC
Vehicle speed sensor Overdrive control switch ASCD control unit		Self-diagnosis CONSULT communication line Duet-EU control		Line pressure solenoid valve O/D OFF indicator lamp	EC


CONTROL SYSTEM

FE

ΑT

SC

EL





TCM FUNCTION

The function of the TCM is to:

=NBAT0013S03

- Receive input signals sent from various switches and sensors.
- Determine required line pressure, shifting point, lock-up operation, and engine brake operation.
- Send required output signals to the respective solenoids.

INPUT/OUTPUT SIGNAL OF TCM

NBAT0013S04

		NBAT0013S0-
	Sensors and solenoid valves	Function
	PNP switch	Detects select lever position and sends a signal to TCM.
	Throttle position sensor	Detects throttle valve position and sends a signal to TCM.
	Closed throttle position switch	Detects throttle valve's fully-closed position and sends a signal to TCM.
	Wide open throttle position switch	Detects a throttle valve position of greater than 1/2 of full throttle and sends a signal to TCM.
	Engine speed signal	From ECM.
Input	A/T fluid temperature sensor	Detects transmission fluid temperature and sends a signal to TCM.
	Revolution sensor	Detects output shaft rpm and sends a signal to TCM.
	Vehicle speed sensor	Used as an auxiliary vehicle speed sensor. Sends a signal when revolution sensor (installed on transmission) malfunctions.
	Overdrive control switch	Sends a signal, which prohibits a shift to " D_4 " (overdrive) position, to the TCM.
	ASCD control unit	Sends the cruise signal and "D ₄ " (overdrive) cancellation signal from ASCD control unit to TCM.
	Shift solenoid valve A/B	Selects shifting point suited to driving conditions in relation to a signal sent from TCM.
	Line pressure solenoid valve	Regulates (or decreases) line pressure suited to driving conditions in relation to a signal sent from TCM.
Output	Torque converter clutch solenoid valve	Regulates (or decreases) lock-up pressure suited to driving conditions in relation to a signal sent from TCM.
	Overrun clutch solenoid valve	Controls an "engine brake" effect suited to driving conditions in relation to a signal sent from TCM.
	O/D OFF indicator lamp	Shows TCM faults, when A/T control components malfunction.

Control Mechanism LINE PRESSURE CONTROL


NBAT0180

TCM has the various line pressure control characteristics to meet the driving conditions.

An ON-OFF duty signal is sent to the line pressure solenoid valve based on TCM characteristics.

Hydraulic pressure on the clutch and brake is electronically controlled through the line pressure solenoid valve to accommodate engine torque. This results in smooth shift operation.





or "1" position

Vehicle speed -

No shifting

When shifting (1→ 2 shift)

Throttle opening -

'2" or "1"

position

SAT004J

SAT005J

(kg/cm², psi)


pressure


Line kPa

(kg/cm², psi)

pressure

Line kPa (







MA

LC

Back-up Control (Engine brake)

If the selector lever is shifted to "2" position while driving in D_4 (OD) or D₃, great driving force is applied to the clutch inside the transmission. Clutch operating pressure (line pressure) must be increased to deal with this driving force.



FE

AT

TF

PD

During Shift Change

The line pressure is temporarily reduced corresponding to a change in engine torque when shifting gears (that is, when the shift solenoid valve is switched for clutch operation) to reduce shifting shock.



AX

At Low Fluid Temperature


Fluid viscosity and frictional characteristics of the clutch facing change with fluid temperature. Clutch engaging or band-contacting pressure is compensated for, according to fluid temperature, to stabilize shifting quality.



HA


SC

EL



The line pressure is reduced below 60°C (140°F) to prevent shifting shock due to low viscosity of automatic transmission fluid when temperature is low.






 Line pressure is increased to a maximum irrespective of the throttle opening when fluid temperature drops to -10°C (14°F). This pressure rise is adopted to prevent a delay in clutch and brake operation due to extreme drop of fluid viscosity at low temperature.

SHIFT CONTROL

NBATO180S02

The shift is regulated entirely by electronic control to accommodate vehicle speed and varying engine operations. This is accomplished by electrical signals transmitted by the revolution sensor and throttle position sensor. This results in improved acceleration performance and fuel economy.



Control of Shift Solenoid Valves A and B

The TCM activates shift solenoid valves A and B according to signals from the throttle position sensor and revolution sensor to select the optimum gear position on the basis of the shift schedule memorized in the TCM.


The shift solenoid valve performs simple ON-OFF operation. When set to "ON", the drain circuit closes and pilot pressure is applied to the shift valve.

[Relation between shift solenoid valves A and B and gear positions]

Shift solenoid valve			Gear position		
Shift soleriold valve	D ₁ , 2 ₁ , 1 ₁	D ₂ , 2 ₂ , 1 ₂	D_3	D ₄ (OD)	N-P
Α	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)	ON (Closed)
В	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)

Control of Shift Valves A and B

NBAT0180S0202





Pilot pressure generated by the operation of shift solenoid valves A and B is applied to the end face of shift valves A and B.

The drawing above shows the operation of shift valve B. When the shift solenoid valve is "ON", pilot pressure applied to the end face of the shift valve overcomes spring force, moving the valve upward.

LOCK-UP CONTROL

The torque converter clutch piston in the torque converter is locked to eliminate torque converter slip to increase power transmission efficiency. The solenoid valve is controlled by an ON-OFF duty signal sent from the TCM. The signal is converted to oil pressure signal which controls the torque converter clutch piston.



MA

Conditions for Lock-up Operation

When vehicle is driven in 4th gear position, vehicle speed and throttle opening are detected. If the detected values fall within the lock-up zone memorized in the TCM, lock-up is performed.



FE

LC


Overdrive control switch	ON	OFF
Selector lever	"D" po	osition
Gear position	D_4	D_3
Vehicle speed sensor	More than	set value
Throttle position sensor	Less than s	set opening
Closed throttle position switch	Ol	FF
A/T fluid temperature sensor	More than 4	·0°C (104°F)



TF



AX



TCM

Pilot pressure


converter clutch control valve

Torque Converter Clutch Solenoid Valve Control

The torque converter clutch solenoid valve is controlled by the TCM. The plunger closes the drain circuit during the "OFF" period, and opens the circuit during the "ON" period. If the percentage of OFF-time increases in one cycle, the pilot pressure drain time is reduced and pilot pressure remains high.

The torque converter clutch piston is designed to slip to adjust the ratio of ON-OFF, thereby reducing lock-up shock.

HA



Torque converter clutch solenoid valve off-time ratio (%)

SAT011J

OFF-time INCREASING Amount of drain DECREASING Pilot pressure HIGH Lock-up RELEASING

SC

OVERALL SYSTEM



Torque Converter Clutch Control Valve Operation

Lock-up applied Lock-up released Torque converter-Torque converterclutch piston clutch piston Oil pump Oil pump Torque converter Chamber B Chamber A ·Torque converter Converter Chamber B oil pressure oil pressure Pilot pressure Pilot pressure Torque converter clutch Torque converter clutch тсм TCM control plug control plug Torque converter Drain Torque converter To oil cooler To oil cooler clutch solenoid valve clutch solenoid Drain valve SAT048J Drain

Lock-up Released

The OFF-duration of the torque converter clutch solenoid valve is long, and pilot pressure is high. The pilot pressure pushes the end face of the torque converter clutch control valve in combination with spring force to move the valve to the left. As a result, converter pressure is applied to chamber A (torque converter clutch piston release side). Accordingly, the torque converter clutch piston remains unlocked.

Lock-up Applied

When the OFF-duration of the torque converter clutch solenoid valve is short, pilot pressure drains and becomes low. Accordingly, the control valve moves to the right by the pilot pressure of the other circuit and converter pressure. As a result, converter pressure is applied to chamber B, keeping the torque converter clutch piston applied.

Also smooth lock-up is provided by transient application and release of the lock-up.

OVERRUN CLUTCH CONTROL (ENGINE BRAKE CONTROL)


Forward one-way clutch is used to reduce shifting shocks in downshifting operations. This clutch transmits engine torque to the wheels. However, drive force from the wheels is not transmitted to the engine because the one-way clutch rotates idle. This means the engine brake is not effective.

The overrun clutch operates when the engine brake is needed.


Overrun Clutch Operating Conditions

NBAT0180S0401

	Gear position	Throttle opening
"D" position	D ₁ , D ₂ , D ₃ gear position	Less than 3/16
"2" position	2 ₁ , 2 ₂ gear position	Less than 3/16
"1" position	1 ₁ , 1 ₂ gear position	At any position







Pilot pressure A -Overrun Line pressure_ clutch (D2, 22 and 1 positions) solenoid Pilot pressure B valve Drain Throttle opening (narrow) Throttle opening (wide) Shuttle shift Overrun clutch Line pressure valve S (2 and 1 positions) Overrun clutch reducing valve Overrun clutch control valve * : First reducing pressure (1 position) **: Line pressure (D2 and 1 positions) SAT049J

Overrun Clutch Solenoid Valve Control

The overrun clutch solenoid valve is operated by an ON-OFF signal transmitted by the TCM to provide overrun clutch control (engine brake control).

When this solenoid valve is "ON", the pilot pressure drain port closes. When it is "OFF", the drain port opens.

During the solenoid valve "ON" pilot pressure is applied to the end face of the overrun clutch control valve.

Overrun Clutch Control Valve Operation

When the solenoid valve is "ON", pilot pressure A is applied to the overrun clutch control valve. This pushes up the overrun clutch control valve. The line pressure is then shut off so that the clutch does not engage.

When the solenoid valve is "OFF", pilot pressure A is not generated. At this point, the overrun clutch control valve moves downward by spring force. As a result, overrun clutch operation pressure is provided by the overrun clutch reducing valve. This causes the overrun clutch to engage.

In the "1" position, the overrun clutch control valve remains pushed down so that the overrun clutch is engaged at all times.

Control Valve

FUNCTION OF CONTROL VALVE

Valve name	Function	[
Pressure regulator valvePressure regulator plugPressure regulator sleeve plug	Regulate oil discharged from the oil pump to provide optimum line pressure for all driving conditions.	[
Pressure modifier valve	Used as a signal supplementary valve to the pressure regulator valve. Regulates pressure-modifier pressure (signal pressure) which controls optimum line pressure for all driving conditions.	
Modifier accumulator piston	Smooths hydraulic pressure regulated by the pressure modifier valve to prevent pulsations.	(
Pilot valve	Regulates line pressure to maintain a constant pilot pressure level which controls lock-up mechanism, overrun clutch, 3-2 timing required for shifting.	
Accumulator control valve Accumulator control sleeve	Regulate accumulator backpressure to pressure suited to driving conditions.	
Manual valve	Directs line pressure to oil circuits corresponding to select positions. Hydraulic pressure drains when the shift lever is in Neutral.	. [

LC

FE

AT

AX

NBAT0181

OVERALL SYSTEM



Valve name	Function
Shift valve A	Simultaneously switches three oil circuits using output pressure of shift solenoid valve A to meet driving conditions (vehicle speed, throttle opening, etc.). Provides automatic downshifting and up-shifting (1st \rightarrow 2nd \rightarrow 3rd \rightarrow 4th gears/4th \rightarrow 3rd \rightarrow 2nd \rightarrow 1st gears) in combination with shift valve B.
Shift valve B	Simultaneously switches three oil circuits using output pressure of shift solenoid valve B in relation to driving conditions (vehicle speed, throttle opening, etc.). Provides automatic downshifting and up-shifting (1st \rightarrow 2nd \rightarrow 3rd \rightarrow 4th gears/4th \rightarrow 3rd \rightarrow 2nd \rightarrow 1st gears) in combination with shift valve A.
Shuttle shift valve S	Switches hydraulic circuits to provide 3-2 timing control and overrun clutch control in relation to the throttle opening. Inactivates the overrun clutch to prevent interlocking in 4th gear when the throttle is wide open.
Overrun clutch control valve	Switches hydraulic circuits to prevent engagement of the overrun clutch simultaneously with application of the brake band in 4th gear. (Interlocking occurs if the overrun clutch engages during D_4 gear operation.)
4-2 relay valve	Memorizes that the transmission is in 4th gear. Prevents the transmission from down-shifting from 4th gear to 3rd and then to 2nd in combination with 4-2 sequence valve and shift valves A and B when downshifting from 4th to 2nd gear.
4-2 sequence valve	Prevents band servo pressure from draining before high clutch operating pressure and band servo releasing pressure drain (from the same circuit) during downshifting from 4th to 2nd gear.
Servo charger valve	An accumulator and a one-way orifice are used in the 2nd gear band servo oil circuit to dampen shifting shock when shifting from 1st to 2nd gear. To maintain adequate flowrate when downshifting from 4th or 3rd gear to 2nd gear, the servo charger valve directs 2nd gear band servo hydraulic pressure to the circuit without going through the one-way orifice when downshifting from 3rd or a higher gear.
3-2 timing valve	Prevents a late operation of the brake band when shifting selector lever from "D" to "1" or "2" position while driving in ${\rm D_3}$.
"1" reducing valve	Reduces low & reverse brake pressure to dampen engine-brake shock when down-shifting from the "1" position 2nd gear to 1st gear.
Overrun clutch reducing valve	Reduces oil pressure directed to the overrun clutch and prevents engine-brake shock. In "1" and "2" positions, line pressure acts on the overrun clutch reducing valve to increase the pressure-regulating point, with resultant engine brake capability.
Torque converter relief valve	Prevents an excessive rise in torque converter pressure.
Torque converter clutch control valve, torque converter clutch control plug and torque converter clutch control sleeve	Activate or inactivate the lock-up function. Also provide smooth lock-up through transient application and release of the lock-up system.
Shuttle shift valve D	Switches hydraulic circuits so that output pressure of the torque converter clutch solenoid valve acts on the lock-up valve in the "D" position of 2nd, 3rd and 4th gears. (In the "D" position 1st gear, lock-up is inhibited.) • Lock-up control is not affected in "D" position 2nd, 3rd or 4th gears, unless output pressure of the torque converter clutch solenoid valve is generated by a signal from the control unit.

Introduction

NBAT0014



Introduction

The A/T system has two self-diagnostic systems.

The first is the emission-related on board diagnostic system (OBD-II) performed by the TCM in combination with the ECM. The malfunction is indicated by the MIL (malfunction indicator lamp) and is stored as a DTC in the ECM memory but not the TCM memory.

The second is the TCM original self-diagnosis indicated by the O/D OFF indicator lamp. The malfunction is stored in the TCM memory. The detected items are overlapped with OBD-II self-diagnostic items. For detail, refer to AT-50.

OBD-II Function for A/T System

The ECM provides emission-related on board diagnostic (OBD-II) functions for the A/T system. One function is to receive a signal from the TCM used with OBD-related parts of the A/T system. The signal is sent to the ECM when a malfunction occurs in the corresponding OBD-related part. The other function is to indicate a diagnostic result by means of the MIL (malfunction indicator lamp) on the instrument panel, Sensors, switches and solenoid valves are used as sensing elements.

The MIL automatically illuminates in One or Two Trip Detection Logic when a malfunction is sensed in relation to A/T system parts.

One or Two Trip Detection Logic of OBD-II

ONE TRIP DETECTION LOGIC

AT NBAT0015S01

AX

If a malfunction is sensed during the first test drive, the MIL will illuminate and the malfunction will be stored in the ECM memory as a DTC. The TCM is not provided with such a memory function.

TWO TRIP DETECTION LOGIC

When a malfunction is sensed during the first test drive, it is stored in the ECM memory as a 1st trip DTC (diagnostic trouble code) or 1st trip freeze frame data. At this point, the MIL will not illuminate. — First Trip If the same malfunction as that experienced during the first test drive is sensed during the second test drive, the MIL will illuminate. — Second Trip

A/T-related parts for which the MIL illuminates during the first or second test drive are listed below.

Itoma	MIL	IIL
Items	One trip detection	Two trip detection
Shift solenoid valve A — DTC: P0750 (1108)	Х	
Shift solenoid valve B — DTC: P0755 (1201)	Х	
Throttle position sensor or switch — DTC: P1705 (1206)	X	
Except above		X

The "trip" in the "One or Two Trip Detection Logic" means a driving mode in which self-diagnosis is performed during vehicle operation.

OBD-II Diagnostic Trouble Code (DTC)

HOW TO READ DTC AND 1ST TRIP DTC

DTC and 1st trip DTC can be read by the following methods.

1. (No Tools) The number of blinks of the malfunction indicator lamp in the Diagnostic Test Mode II (Self-Diagnostic Results) Examples: 1101, 1102, 1103, 1104, etc. For details, refer to EC-70, "DESCRIP-

These DTCs are controlled by NISSAN.

2. (向 with CONSULT or 📾 GST) CONSULT or GST (Generic Scan Tool) Examples: P0705, P0710, P0720, P0725, etc.

These DTCs are prescribed by SAE J2012.

(CONSULT also displays the malfunctioning component or system.)

- 1st trip DTC No. is the same as DTC No.
- Output of the diagnostic trouble code indicates that the indicated circuit has a malfunction. However, in case of the Mode II and GST they do not indicate whether the malfunction is still occurring or occurred in the past and returned to normal. CONSULT can identify them as shown below. Therefore, using CONSULT (if available) is recom-

mended.

MA

BT


SC

EL




OBD-II Diagnostic Trouble Code (DTC) (Cont'd)


A sample of CONSULT display for DTC is shown at left. DTC or 1st trip DTC of a malfunction is displayed in SELF-DIAGNOSTIC RESULTS mode for "ENGINE" with CONSULT. Time data indicates how many times the vehicle was driven after the last detection of a DTC.



If the DTC is being detected currently, the time data will be "0".



If a 1st trip DTC is stored in the ECM, the time data will be "[1t]".



Freeze Frame Data and 1st Trip Freeze Frame Data

NBAT0016S010

The ECM has a memory function, which stores the driving condition such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed and vehicle speed at the moment the ECM detects a malfunction.

Data which are stored in the ECM memory, along with the 1st trip DTC, are called 1st trip freeze frame data, and the data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT or GST. The 1st trip freeze frame data can only be displayed on the CONSULT screen, not on the GST. For detail, refer to EC-80, "CONSULT".

Only one set of freeze frame data (either 1st trip freeze frame data of freeze frame data) can be stored in the ECM. 1st trip freeze frame data is stored in the ECM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM. The ECM has the following priorities to update the data.

OBD-II Diagnostic Trouble Code (DTC) (Cont'd)

Priority	Items		
1	Freeze frame data	Misfire — DTC: P0300 - P0306 (0701, 0603 - 0608) Fuel Injection System Function — DTC: P0171 (0115), P0172 (0114), P0174 (0209), P0175 (0210)	_ (
2		Except the above items (Includes A/T related items)	_
3	1st trip freeze frame of	data	

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM memory is erased.

HOW TO ERASE DTC

The diagnostic trouble code can be erased by CONSULT, GST or ECM DIAGNOSTIC TEST MODE as described following.

- If the battery terminal is disconnected, the diagnostic trouble code will be lost within 24 hours.
- When you erase the DTC, using CONSULT or GST is easier and quicker than switching the mode selector on the ECM.

The following emission-related diagnostic information is cleared from the ECM memory when erasing DTC related to OBD-II. For details, refer to EC-55, "Emission-related Diagnostic Information".

- Diagnostic trouble codes (DTC)
- 1st trip diagnostic trouble codes (1st trip DTC)
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values

(a) HOW TO ERASE DTC (WITH CONSULT)

- If a DTC is displayed for both ECM and TCM, it needs to be erased for both ECM and TCM.
- 1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
- 2. Turn CONSULT "ON" and touch "A/T".
- 3. Touch "SELF-DIAG RESULTS".
- 4. Touch "ERASE". (The DTC in the TCM will be erased.) Then touch "BACK" twice.
- 5. Touch "ENGINE".
- 6. Touch "SELF-DIAG RESULTS".
- 7. Touch "ERASE". (The DTC in the ECM will be erased.)

AT

LC

EC

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BK

ST

1 110


HA

SC

EL



OBD-II Diagnostic Trouble Code (DTC) (Cont'd)



HOW TO ERASE DTC (WITH GST)

NBAT0016S04


- 1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
- 2. Perform "OBD-II SELF-DIAGNOSTIC PROCEDURE (No Tools)". Refer to AT-46. (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
- 3. Select Mode 4 with Generic Scan Tool (GST). For details, refer to EC-93, "DESCRIPTION".

HOW TO ERASE DTC (NO TOOLS)

NBAT0016S05

- 1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
- 2. Perform "TCM SELF-DIAGNOSTIC PROCEDURE (No Tools)". Refer to AT-46. (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
- 3. Change the diagnostic test mode from Mode II to Mode I by turning the mode selector on the ECM. Refer to EC-72, "How to Switch Diagnostic Test Modes".

Malfunction Indicator Lamp (MIL.



Malfunction Indicator Lamp (MIL)

. The malfunction indicator lamp will light up when the ignition switch is turned ON without the engine running. This is for checking the blown lamp.

tion for GI

If the malfunction indicator lamp does not light up, refer to EL-100, "Schematic".

MA

(Or see MIL & Data Link Connectors in EC-582.)

2. When the engine is started, the malfunction indicator lamp should go off.

EM

If the lamp remains on, the on board diagnostic system has detected an emission-related (OBD-II) malfunction. For detail, refer to EC-54, "Introduction".

LC

EC

RE.

AT

CONSULT

After performing "SELF-DIAGNOSTIC PROCEDURE (WITH CONSULT)" (AT-38), place check marks for results on the "DIAGNOSTIC WORKSHEET", AT-55. Reference pages are provided following the items.

NOTICE:

1) The CONSULT electrically displays shift timing and lock-up timing (that is, operation timing of each solenoid). Check for time difference between actual shift timing and the CONSULT display. If the difference is noticeable, mechanical parts (except solenoids, sensors, etc.) may be malfunctioning. Check mechanical parts using applicable diagnostic proce-

dures.

2) Shift schedule (which implies gear position) displayed on CONSULT and that indicated in Service Manual may differ slightly. This occurs because of the following reasons:

и

Actual shift schedule has more or less tolerance or allowance.

RS

 Shift schedule indicated in Service Manual refers to the point where shifts start, and

3T

 Gear position displayed on CONSULT indicates the point where shifts are completed.

HA

 Shift solenoid valve "A" or "B" is displayed on CONSULT at the start of shifting. Gear position is displayed upon completion of shifting (which is computed by TCM).

SC

4) Additional CONSULT information can be found in the Operation Manual supplied with the CONSULT unit.

EL

 \mathbb{D}



CONSULT (Cont'd)

	. 1
SELECT SYSTEM	
ENGINE	
A/T	
	SAT038J

- SELF-DIAGNOSTIC PROCEDURE (WITH CONSULT)
- Turn on CONSULT and touch "ENGINE" for OBD-II detected items or touch "A/T" for TCM self-diagnosis.
 If A/T is not displayed, check TCM power supply and ground circuit. Refer to AT-92. If result is NG, refer to EL-9, "Schematic".
- FAILURE DETECTED
 THROTTLE POSI SEN

 ERASE PRINT FFdata
 SAT416J
- 2. Touch "SELF-DIAG RESULTS".

Display shows malfunction experienced since the last erasing operation.

CONSULT performs REAL-TIME SELF-DIAGNOSIS. Also, any malfunction detected while in this mode will be displayed at real time.

SELF-DIAGNOSTIC RESULT TEST MODE

NBAT0184S02

				NBAT0184S02	
Detected items			TCM self-diagnosis	OBD-II (DTC)	
(Screen terms for CONSULT, "SELF-DIAG RESULTS" test mode)		Malfunction is detected when	Available by	SERVICE ENGINE SOON. Available by malfunction	
"A/T"	"ENGINE"		O/D OFF indicator lamp or "A/T" on CONSULT	indicator lamp*2, "ENGINE" on CON- SULT or GST	
PNP switch circuit		TCM does not receive the cor-			
— PNP SW/CIRC		rect voltage signal (based on the gear position) from the switch.	_	P0705	
Revolution sensor		TCM does not receive the proper			
VHCL SPEED SEN-A/T	VEH SPD SEN/CIR AT	voltage signal from the sensor.	X	P0720	
Vehicle speed sensor	(Meter)	TCM does not receive the proper			
VHCL SPEED SEN-MTR	_	voltage signal from the sensor.	X	_	
A/T 1st gear function		A/T cannot be shifted to the 1st		D0704*4	
_	A/T 1ST GR FNCTN	gear position even if electrical circuit is good.	_	P0731*1	
A/T 2nd gear function	1	A/T cannot be shifted to the 2nd appropriate position even if electrical.		D0722*4	
_	A/T 2ND GR FNCTN	gear position even if electrical circuit is good.	_	P0732*1	
A/T 3rd gear function		A/T cannot be shifted to the 3rd appropriate power if electrical		P0733*1	
_	A/T 3RD GR FNCTN	gear position even if electrical circuit is good.	_	P0/33 1	
A/T 4th gear function		A/T cannot be shifted to the 4th gear position even if electrical		P0734*1	
	A/T 4TH GR FNCTN	circuit is good.		F0734 1	
					

CONSULT (Cont'd)

				CONSULT (Cont'd)	
Detected items			TCM self-diagnosis	OBD-II (DTC)	
(Screen terms for CONSULT, "SELF-DIAG RESULTS" test mode)		Malfunction is detected when	1,995	SERVICE ENGINE SOON	G[
"A/T"	"ENGINE"	walluffclioff is detected when	Available by O/D OFF indicator lamp or "A/T" on CONSULT	Available by malfunction indicator lamp*2, "ENGINE" on CON- SULT or GST	MA EM
A/T TCC S/V function	(lock-up)	A/T cannot perform lock-up even			
_	A/T TCC S/V FNCTN	if electrical circuit is good.	_	P0744*1	LG
Shift solenoid valve A		TCM detects an improper volt-			EC
SHIFT SOLENOID/V A	SFT SOL A/CIRC	age drop when it tries to operate the solenoid valve.	X	P0750	FE
Shift solenoid valve B	3	TCM detects an improper volt-			
SHIFT SOLENOID/V B	SFT SOL B/CIRC	age drop when it tries to operate the solenoid valve.	X	P0755	AT
Overrun clutch solend	oid valve	TCM detects an improper voltage drop when it tries to operate			
OVERRUN CLUTCH S/V	O/R CLUCH SOL/ CIRC	the solenoid valve.	X	P1760	TF
T/C clutch solenoid va	alve	TCM detects an improper volt-			PD
T/C CLUTCH SOL/V	TCC SOLENOID/ CIRC	age drop when it tries to operate the solenoid valve.	X	P0740	AX
Line pressure solenoid valve		TCM detects an improper volt-			
LINE PRESSURE S/V	L/PRESS SOL/CIRC	age drop when it tries to operate the solenoid valve.	X	P0745	SU
Throttle position sens Throttle position switch		TCM receives an excessively low or high voltage from the sen-	V	P1705	BR
THROTTLE POSI SEN	TP SEN/CIRC A/T	sor.	X	P1705	ST
Engine speed signal		TCM does not receive the proper TCM does not receive the proper	X	P0725	
ENGINE SPEED SIG	i	voltage signal from the ECM.	^	10723	RS
A/T fluid temperature	sensor	TCM receives an excessively low or high voltage from the sen-	V	D0740	
BATT/FLUID TEMP SEN	ATF TEMP SEN/ CIRC	sor.	X	P0710	BT
TCM (RAM)	1	TCM memory (RAM) is malfunctioning.			HA
CONTROL UNIT (RAM)	_	aoring.	_	_	
TCM (ROM)		TCM memory (ROM) is malfunctioning.			SC
CONTROL UNIT (ROM)	_	uoriirig.	_	_	
TCM (EEPROM)		TCM memory (EEROM) is mal- functioning.			
CONTROL UNIT (EEPROM)	_	ranouoning.	_	_	IDX



CONSULT (Cont'd)

		T	I		
Detected items (Screen terms for CONSULT, "SELF-DIAG RESULTS" test mode)			TCM self-diagnosis	OBD-II (DTC)	
		Malfunction is detected when	Available by	SERVICE ENGINE SOON. Available by malfunction	
"A/T"	"ENGINE"		O/D OFF indicator lamp or "A/T" on CONSULT	indicator lamp*2, "ENGINE" on CON- SULT or GST	
Initial start		This is not a malfunction message (Whenever shutting off a	x		
INITIAL START	_	power supply to the TCM, this message appears on the screen.)	^	_	
No failure (NO SELF DIAGNOSTIC FAILURE INDI- CATED FURTHER TESTING MAY BE REQUIRED**)		No failure has been detected.	X	Х	

X: Applicable

DATA MONITOR MODE (A/T)

NBAT0184S03

		Monito	or item			
Item	Display	ECU input signals	Main sig- nals	Description	Remarks	
Vehicle speed sensor 1 (A/T) (Revolution sensor)	VHCL/S SE·A/T [km/h] or [mph]	x	_	Vehicle speed computed from signal of revolution sensor is displayed.	When racing engine in "N" or "P" position with vehicle stationary, CONSULT data may not indicate 0 km/h (0 mph).	
Vehicle speed sensor 2 (Meter)	VHCL/S SE·MTR [km/h] or [mph]	Х	_	Vehicle speed computed from signal of vehicle speed sensor is dis- played.	Vehicle speed display may not be accurate under approx. 10 km/h (6 mph). It may not indicate 0 km/h (0 mph) when vehicle is stationary.	
Throttle position sensor	THRTL POS SEN [V]	Х	_	Throttle position sensor signal voltage is dis- played.		
A/T fluid temperature sensor	FLUID TEMP SE [V]	х	_	 A/T fluid temperature sensor signal voltage is displayed. Signal voltage lowers as fluid temperature rises. 		
Battery voltage	BATTERY VOLT [V]	Х	_	Source voltage of TCM is displayed.		
Engine speed	ENGINE SPEED [rpm]	×	X	Engine speed, computed from engine speed signal, is displayed.	Engine speed display may not be accurate under approx. 800 rpm. It may not indicate 0 rpm even when engine is not running.	
Overdrive control switch	OVERDRIVE SW [ON/OFF]	Х	_	ON/OFF state computed from signal of overdrive control SW is displayed.		

^{—:} Not applicable

^{*1:} These malfunctions cannot be displayed by MIL SCON. if another malfunction is assigned to MIL. *2: Refer to EC-70, "DESCRIPTION".

CONSULT (Cont'd)


		Monito	or item			
Item	Display	ECU input signals	Main sig- nals	Description	Remarks	(
P/N position switch	P/N POSI SW [ON/OFF]	Х	_	ON/OFF state computed from signal of P/N position SW is displayed.		-
R position switch	R POSITION SW [ON/OFF]	Х	_	ON/OFF state computed from signal of R position SW is displayed.		[
D position switch	D POSITION SW [ON/OFF]	Х	_	ON/OFF state computed from signal of D position SW is displayed.		- - [
2 position switch	2 POSITION SW [ON/OFF]	Х	_	ON/OFF status, computed from signal of 2 position SW, is displayed.		[
1 position switch	1 POSITION SW [ON/OFF]	Х	_	ON/OFF status, computed from signal of 1 position SW, is displayed.		
ASCD cruise signal	ASCD-CRUISE [ON/OFF]	Х	_	Status of ASCD cruise signal is displayed. ON Cruising state OFF Normal running state	This is displayed even when no ASCD is mounted.	_ [
ASCD OD cut signal	ASCD OD CUT [ON/OFF]	Х	_	Status of ASCD OD release signal is displayed. ON OD released OFF OD not released	This is displayed even when no ASCD is mounted.	
Kickdown switch	KICKDOWN SW [ON/OFF]	Х	_	ON/OFF status, computed from signal of kickdown SW, is displayed.	This is displayed even when no kickdown switch is equipped.	-
Closed throttle position switch	CLOSED THL/SW [ON/OFF]	Х	_	ON/OFF status, computed from signal of closed throttle position SW, is displayed.		- (
Wide open throttle position switch	W/O THRL/ P-SW [ON/OFF]	Х	_	ON/OFF status, computed from signal of wide open throttle position SW, is displayed.		- [
Gear position	GEAR	_	Х	Gear position data used for computation by TCM, is displayed.		-
Selector lever position	SLCT LVR POSI	_	Х	Selector lever position data, used for computa- tion by TCM, is dis- played.	A specific value used for control is displayed if fail-safe is activated due to error.	- (
Vehicle speed	VEHICLE SPEED [km/h] or [mph]	_	Х	Vehicle speed data, used for computation by TCM, is displayed.		- [
Throttle position	THROTTLE POSI [/8]	_	Х	Throttle position data, used for computation by TCM, is displayed.	A specific value used for control is displayed if fail-safe is activated due to error.	-




		Monito	or item		
ltem	Display	ECU input signals	Main sig- nals	Description	Remarks
Line pressure duty	LINE PRES DTY [%]	_	х	Control value of line pressure solenoid valve, computed by TCM from each input signal, is displayed.	
Torque converter clutch solenoid valve duty	TCC S/V DUTY [%]	_	X	Control value of torque converter clutch solenoid valve, computed by TCM from each input signal, is displayed.	
Shift solenoid valve A	SHIFT S/V A [ON/OFF]	_	X	Control value of shift solenoid valve A, com- puted by TCM from each input signal, is displayed.	Control value of solenoid is displayed even if solenoid circuit is disconnected. The "OFF" signal is dis-
Shift solenoid valve B	SHIFT S/V B [ON/OFF]	_	Х	Control value of shift solenoid valve B, com- puted by TCM from each input signal, is displayed.	played if solenoid circuit is shorted.
Overrun clutch solenoid valve	OVERRUN/C S/V [ON/OFF]	_	х	Control value of overrun clutch solenoid valve computed by TCM from each input signal is dis- played.	
Self-diagnosis display lamp (O/D OFF indicator lamp)	SELF-D DP LMP [ON/OFF]		Х	Control status of O/D OFF indicator lamp is displayed.	

X: Applicable

^{—:} Not applicable





DTC WORK SUPPORT MODE WITH CONSULT CONSULT Setting Procedure

NBAT0184S04

NBAT0184S0401

- 1. Turn ignition switch "OFF".
- 2. Connect CONSULT to Data link connector for CONSULT which is located in instrument lower panel on driver side.
- 3. Turn ignition switch "ON".
- 4. Touch "START".


\$\dagger

CONSULT (Cont'd)

	5.	Touch "A/T".	
■ SELECT SYSTEM ENGINE ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■	0.	TOUGH 7V I .	GI
A/T			MA
			EM
SAT974H	6.	Touch "DTC WORK SUPPORT".	LG
SELF-DIAG RESULTS	0.	TOUGH DIE WORK SOIT OKT.	EC
DATA MONITOR DTC WORK SUPPORT			FE
TCM PART NUMBER			AT
SAT384J			TF
SELECT ITEM 1ST GR FNCTN P0731	7.	Touch select item menu (1ST, 2ND, etc.).	PD
2ND GR FNCTN P0732 3RD GR FNCTN P0733			AX
4TH GR FNCTN P0734 TCC S/V FNCTN P0744			SU
SAT975I			BR
■2ND GR FNCTN P0732 ■	8.	Touch "START".	ST
THIS SUPPORT FUNCTION IS FOR DTC P0732. SEE THE SERVICE MANUAL			RS
ABOUT THE DRIVING CONDITION FOR THIS DIAGNOSIS.			BT
EXIT START SAT976I			HA
■ 2ND GR FNCTN P0732 ■ □	9.	Perform driving test according to "DTC CONFIRMATION PROCEDURE" in "TROUBLE DIAGNOSIS FOR DTC".	SC
OUT OF CONDITION MONITOR GEAR 1			EL
VEHICLE SPEED 0km/h THROTTLE POSI 0.0/8 TCC S/V DUTY 4%			IDX
SAT977I			




CONSULT (Cont'd)



SAT982I

CONSULT (Cont'd)



13. CONSULT procedure ended. If "NG" appears on the screen, a malfunction may exist. Go to "DIAGNOSTIC PROCEDURE".

GI

MA


LC

EG

FE

AT

TF



■ 2ND GR FNCTN P0732 ■ □

DTC WORK SUPPORT MODE

DIC WORK SUPPORT MODE	NBAT0184S05	P
Description	Check item	r
Following items for "A/T 1st gear function (P0731)" can be confirmed. • Self-diagnosis status (whether the diagnosis is being conducted or not) • Self-diagnosis result (OK or NG)	 Shift solenoid valve A Shift solenoid valve B Each clutch Hydraulic control circuit 	A
Following items for "A/T 2nd gear function (P0732)" can be confirmed. • Self-diagnosis status (whether the diagnosis is being conducted or not) • Self-diagnosis result (OK or NG)	 Shift solenoid valve B Each clutch Hydraulic control circuit 	60
Following items for "A/T 3rd gear function (P0733)" can be confirmed. • Self-diagnosis status (whether the diagnosis is being conducted or not) • Self-diagnosis result (OK or NG)	Shift solenoid valve A Each clutch Hydraulic control circuit	R
Following items for "A/T 4th gear function (P0734)" can be confirmed. • Self-diagnosis status (whether the diagnosis is being conducted or not) • Self-diagnosis result (OK or NG)	Shift solenoid valve A Shift solenoid valve B Overrun clutch solenoid valve Line pressure solenoid valve Each clutch Hydraulic control circuit	
Following items for "A/T TCC S/V function (lock-up) (P0744)" can be confirmed. • Self-diagnosis status (whether the diagnosis is being conducted or not) • Self-diagnosis result (OK or NG)	Torque converter clutch solenoid valve Each clutch Hydraulic control circuit	S
	Description Following items for "A/T 1st gear function (P0731)" can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not) Self-diagnosis result (OK or NG) Following items for "A/T 2nd gear function (P0732)" can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not) Self-diagnosis result (OK or NG) Following items for "A/T 3rd gear function (P0733)" can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not) Self-diagnosis result (OK or NG) Following items for "A/T 4th gear function (P0734)" can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not) Self-diagnosis result (OK or NG) Following items for "A/T TCC S/V function (lock-up) (P0744)" can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not)	Description Check item Following items for "A/T 1st gear function (P0731)" can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not) Self-diagnosis result (OK or NG) Following items for "A/T 2nd gear function (P0732)" can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not) Self-diagnosis result (OK or NG) Following items for "A/T 3rd gear function (P0733)" can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not) Self-diagnosis result (OK or NG) Following items for "A/T 3rd gear function (P0733)" can be confirmed. Self-diagnosis result (OK or NG) Following items for "A/T 4th gear function (P0734)" can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not) Self-diagnosis result (OK or NG) Following items for "A/T 4th gear function (P0734)" can be confirmed. Self-diagnosis result (OK or NG) Following items for "A/T 7th gear function (P0734)" can be confirmed. Self-diagnosis result (OK or NG) Following items for "A/T 7th gear function (P0734)" can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not) Self-diagnosis status (whether the diagnosis is being conducted or not) Following items for "A/T TCC S/V function (lock-up) (P0744)" Can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not) Following items for "A/T TCC S/V function (lock-up) (P0744)" Can be confirmed. Self-diagnosis status (whether the diagnosis is being conducted or not)




Diagnostic Procedure Without CONSULT


© OBD-II SELF-DIAGNOSTIC PROCEDURE (WITH GST)
Refer to EC-93, "DESCRIPTION".

© OBD-II SELF-DIAGNOSTIC PROCEDURE (NO TOOLS)

Refer to EC-70, "DESCRIPTION".

NBAT0206S02





TCM SELF-DIAGNOSTIC PROCEDURE (NO TOOLS) NBAT0206S030 NBAT0206S0301

1. Turn ignition switch to "OFF" position.

- 2. Connect the handy type vacuum pump to the throttle opener and apply vacuum –25.3 kPa (–190 mmHg, –7.48 inHg).
- 3. Disconnect the throttle position switch harness connector.
- 4. Turn ignition switch to "ON" position.
- Check continuity of the closed throttle position switch.
 Continuity should exist.
 (If continuity does not exist, check throttle opener and closed throttle position switch. Then increase vacuum until closed throttle position switch shows continuity.)
- 6. Go to "DIAGNOSIS START" on next page.



ST


BT

HA

SC

EL

Diagnostic Procedure Without CONSULT (Cont'd)






Diagnostic Procedure Without CONSULT (Cont'd)


JUDGEMENT PROCEDURE STEP 1

- 1. Turn ignition switch to "OFF" position.
- 2. Turn ignition switch to "ACC" position.
- 3. Move selector lever from "P" to "D" position.
- 4. Turn ignition switch to "ON" position. (Do not start engine.)
- 5. Depress and hold overdrive control switch in "OFF" position (the O/D OFF indicator lamp will be "ON") until directed to release the switch. (If O/D OFF indicator lamp does not come on, go to step 3 on AT-247).
- 6. Turn ignition switch to "OFF" position.



SAT968I

- 7. Turn ignition switch to "ON" position (Do not start engine.).
- 8. Release the overdrive control switch (the O/D OFF indicator lamp will be "OFF").
- 9. Wait 2 seconds.
- 10. Move selector lever to "2" position.
- 11. Depress and release the overdrive control switch (the O/D OFF indicator lamp will be "ON").
- 12. Depress and hold the overdrive control switch (the O/D OFF indicator lamp will be "OFF") until directed to release the switch.



SAT969I

GO TO 3.



Diagnostic Procedure Without CONSULT (Cont'd)


JUDGEMENT PROCEDURE STEP 2 1. Move selector lever to "1" position.

- 2. Release the overdrive control switch.
- 3. Depress and release the overdrive control switch (the O/D OFF indicator lamp will be "ON").
- 4. Depress and release the overdrive control switch (the O/D OFF indicator lamp will be "OFF").
- 5. Depress and hold the overdrive control switch (the O/D OFF indicator lamp will be "ON") until directed to release the switch.



6. Depress accelerator pedal fully and release it.


7. Release the overdrive control switch (the O/D OFF indicator lamp will begin to flash "ON" and "OFF").



Release

SAT981F

GO TO 4.



MA

GI

LC

EC

FE

SAT970I

AT

TF

AX

SC

[DX






JUDGEMENT OF SELF-DIAGNOSIS CODE


NBAT0206S04

O/D OFF indicator lamp:

All judgement flickers are same.



1st judgement flicker is longer than others.



SAT437F

SAT441F


SAT445F

SAT436F


All circuits that can be confirmed by self-diagnosis are OK.

Revolution sensor circuit is short-circuited or disconnected. ⇒ Go to VEHICLE SPEED SENSOR-A/T (REVOLUTION SENSOR), AT-110.

2nd judgement flicker is longer than others.




3rd judgement flicker is longer than others.




Vehicle speed sensor circuit is short-circuited or disconnected. ⇒ Go to VEHICLE SPEED SENSOR-MTR, AT-195.

Throttle position sensor circuit is short-circuited or disconnected. ⇒ Go to THROTTLE POSITION SENSOR, AT-175.

4th judgement flicker is longer than others.



5th judgement flicker is longer than others.




SAT443F

Shift solenoid valve A circuit is short-circuited or disconnected.

⇒ Go to SHIFT SOLENOID VALVE A, AT-167.


Shift solenoid valve B circuit is short-circuited or disconnected.

⇒ Go to SHIFT SOLENOID VALVE B, AT-171.






Diagnostic Procedure Without CONSULT (Cont'd)





 t_1 = 2.5 seconds t_2 = 2.0 seconds t_3 = 1.0 second t_4 = 1.0 second

Introduction









Introduction

The TCM receives a signal from the vehicle speed sensor, throttle position sensor or PNP switch and provides shift control or lock-up control via A/T solenoid valves.

The TCM also communicates with the ECM by means of a signal sent from sensing elements used with the OBD-related parts of the A/T system for malfunction-diagnostic purposes. The TCM is capable of diagnosing malfunctioning parts while the ECM can store malfunctions in its memory.

Input and output signals must always be correct and stable in the operation of the A/T system. The A/T system must be in good operating condition and be free of valve seizure, solenoid valve malfunction, etc.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems. A road test with CONSULT (or GST) or a circuit tester connected should be performed. Follow the "Work Flow". Refer to AT-57.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example (AT-55) should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

Also check related Service bulletins.



 $\mathbb{M}\mathbb{A}$

LC

FC.

FE

AT

TF

rw

 $\mathbb{A}\mathbb{X}$

SII

BR

ST

RS

BT

HA

SC

El

DW

Introduction (Cont'd)

TROUBLE DIAGNOSIS — INTRODUCTION



=NBAT0019S01

NBAT0019S0101

DIAGNOSTIC WORKSHEET Information From Customer

KEY POINTS

WHAT Vehicle & A/T model WHEN..... Date, Frequencies

WHERE..... Road conditions

	HOW Oper	rating conditions, Symptoms
Customer name MR/MS	Model & Year	VIN
Trans. model	Engine	Mileage
Incident Date	Manuf. Date	In Service Date
Frequency	□ Continuous □ Intermittent (times a day)
Symptoms	☐ Vehicle does not move. (☐ A	Any position □ Particular position)
	\square No up-shift (\square 1st \rightarrow 2nd	\square 2nd \rightarrow 3rd \square 3rd \rightarrow O/D)
	\square No down-shift (\square O/D \rightarrow 3rd	$\exists \Box 3rd \rightarrow 2nd \Box 2nd \rightarrow 1st)$
	☐ Lockup malfunction	
	☐ Shift point too high or too low.	
	\square Shift shock or slip (\square N \rightarrow D	D □ Lockup □ Any drive position)
	☐ Noise or vibration	
	☐ No kickdown	
	☐ No pattern select	
	□ Others)
O/D OFF indicator lamp	Blinks for about 8 seconds.	
	☐ Continuously lit	□ Not lit
Malfunction indicator lamp (MIL)	☐ Continuously lit	□ Not lit



SC

EL

Introduction (Cont'd)

		Diagnostic Worksheet	=NBAT0019S0102	
1.	□ Re	ead the Fail-safe Remarks and listen to customer complaints.	AT-8	GI
2.	□ Ch	HECK A/T FLUID	AT-59	
		□ Leakage (Follow specified procedure)□ Fluid condition□ Fluid level		MA
3.	Perfo	orm STALL TEST and LINE PRESSURE TEST.	AT-59, AT-62	EM
		□ Stall test — Mark possible damaged components/others.		ι ⊘
		□ Torque converter one-way clutch □ Low & reverse brake □ Reverse clutch □ Low one-way clutch □ Forward clutch □ Engine □ Overrun clutch □ Line pressure is low □ Forward one-way clutch □ Clutches and brakes except high clutch and brake band are OK		LC EC
		□ Pressure test — Suspected parts:		FE
4.	□ Pe	erform all ROAD TEST and mark required procedures.	AT-63	AT
	4-1.	Check before engine is started.	AT-64	• • • • • • • • • • • • • • • • • • • •
		SELF-DIAGNOSTIC PROCEDURE - Mark detected items.		TF
		 □ PNP switch, AT-99. □ A/T fluid temperature sensor, AT-105. □ Vehicle speed sensor·A/T (Revolution sensor), AT-110. □ Engine speed signal, AT-115. □ Torque converter clutch solenoid valve, AT-147. 		PD
		☐ Line pressure solenoid valve, AT-161. ☐ Shift solenoid valve A, AT-167. ☐ Shift solenoid valve B, AT-171.		AX
		☐ Throttle position sensor, AT-175. ☐ Overrun clutch solenoid valve, AT-184. ☐ A/T fluid temperature sensor and TCM power source, AT-189.		SU
		 □ Vehicle speed sensor·MTR, AT-195. □ Control unit (RAM), control unit (ROM), AT-199. □ Control unit (EEP ROM), AT-201. 		BR
		□ PNP, overdrive control and throttle position switches, AT-244.□ Battery□ Others		ST
	4-2.	Check at idle	AT-66	RS
		□ 1. O/D OFF Indicator Lamp Does Not Come On, AT-207. □ 2. Engine Cannot Be Started In "P" And "N" Position, AT-209. □ 3. In "P" Position, Vehicle Moves Forward Or Backward When Pushed, AT-210. □ 4. In "N" Position, Vehicle Moves, AT-211.		BT
		 □ 5. Large Shock. "N" → "R" Position, AT-213. □ 6. Vehicle Does Not Creep Backward In "R" Position, AT-215. □ 7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position, AT-218. 		HA



4.	4-3.	Cruise test	AT-67
		Part-1	AT-71
		□ 8. Vehicle Cannot Be Started From D_1 , AT-221. □ 9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$, AT-224. □ 10. A/T Does Not Shift: $D_2 \rightarrow D_3$, AT-227. □ 11. A/T Does Not Shift: $D_3 \rightarrow D_4$, AT-230. □ 12. A/T Does Not Perform Lock-up, AT-233. □ 13. A/T Does Not Hold Lock-up Condition, AT-235. □ 14. Lock-up Is Not Released, AT-237. □ 15. Engine Speed Does Not Return To Idle (Light Braking $D_4 \rightarrow D_3$), AT-238.	
		Part-2	AT-75
		□ 16. Vehicle Does Not Start From D_1 , AT-240. □ 9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$, AT-224. □ 10. A/T Does Not Shift: $D_2 \rightarrow D_3$, AT-227. □ 11. A/T Does Not Shift: $D_3 \rightarrow D_4$, AT-230.	
		Part-3	AT-77
		□ 17. A/T Does Not Shift: $D_4 \rightarrow D_3$ When Overdrive Control Switch "ON" \rightarrow "OFF", AT-241 □ 15. Engine Speed Does Not Return To Idle (Engine Brake In D_3), AT-238. □ 18. A/T Does Not Shift: $D_3 \rightarrow 2_2$, When Selector Lever "D" \rightarrow "2" Position, AT-242. □ 15. Engine Speed Does Not Return To Idle (Engine Brake In D_2), AT-238. □ 19. A/T Does Not Shift: $D_2 \rightarrow D_1$, When Selector Lever "2" $D_2 \rightarrow D_1$ "1" Position, AT-243. □ 20. Vehicle Does Not Decelerate By Engine Brake, AT-244. □ SELF-DIAGNOSTIC PROCEDURE — Mark detected items.	
		 □ PNP switch, AT-99. □ A/T fluid temperature sensor, AT-105. □ Vehicle speed sensor·A/T (Revolution sensor), AT-110. □ Engine speed signal, AT-115. □ Torque converter clutch solenoid valve, AT-147. □ Line pressure solenoid valve, AT-161. □ Shift solenoid valve A, AT-167. □ Shift solenoid valve B, AT-171. □ Throttle position sensor, AT-175. □ Overrun clutch solenoid valve, AT-184. □ A/T fluid temperature sensor and TCM power source, AT-189. □ Vehicle speed sensor·MTR, AT-195. □ Control unit (RAM), control unit (ROM), AT-199. □ Control unit (EEP ROM), AT-201. □ PNP, overdrive control and throttle position switches, AT-244. □ Battery □ Others 	
5.	□ Fo	or self-diagnosis NG items, inspect each component. Repair or replace the damaged parts.	AT-38
6.	□ Pe	erform all ROAD TEST and re-mark required procedures.	AT-63
7.		erform DTC CONFIRMATION PROCEDURE for following MIL indicating items and check out NG items. r to EC-55, "Emission-related Diagnostic Information".	EC-55
		□ DTC (P0731, 1103) A/T 1st gear function, AT-119. □ DTC (P0732, 1104) A/T 2nd gear function, AT-125. □ DTC (P0733, 1105) A/T 3rd gear function, AT-131. □ DTC (P0734, 1106) A/T 4th gear function, AT-137. □ DTC (P0744, 1107) A/T TCC S/V function (lock-up), AT-152.	
8.	parts Refe	perform the Diagnostic Procedures for all remaining items marked NG. Repair or replace the damaged is. To the Symptom Chart when you perform the procedures. (The chart also shows some other possible oftoms and the component inspection orders.)	AT-92 AT-81
9.	□ Er	ase DTC from TCM and ECM memories.	AT-35

Work Flow

Work Flow

HOW TO PERFORM TROUBLE DIAGNOSES FOR QUICK AND ACCURATE REPAIR

NBAT0020

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate. In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

MA

Make good use of the two sheets provided, "INFORMATION FROM CUSTOMER" (AT-54) and "DIAGNOSTIC WORKSHEET" (AT-55), to perform the best troubleshooting possible.

LC

EG

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC

EL


*6: AT-63

TROUBLE DIAGNOSIS — INTRODUCTION



WORK FLOW CHART

NBAT0020S02




*18: EC-55

*12: AT-203

A/T Fluid Check **FLUID LEAKAGE CHECK**

NBAT0021



- Start engine, apply foot brake, place selector lever in "D" position and wait a few minutes.
 - MA

- Stop engine.
- 4. Check for fresh leakage.





FLUID CONDITION CHECK

NBAT0021S02

Fluid color	Suspected problem	
Dark or black with burned odor	Wear of frictional material	
Milky pink	Water contamination — Road water entering through filler tube or breather	
Varnished fluid, light to dark brown and tacky	Oxidation — Over or under filling, — Overheating	

FLUID LEVEL CHECK


Refer to MA-21, "Checking A/T Fluid".

NBAT0021S03

TF

AT

AX



Stall Test

SAT647B

STALL TEST PROCEDURE


Check A/T fluid and engine oil levels. If necessary, add fluid

and oil. 2. Drive vehicle for approx. 10 minutes or until fluid and oil reach operating temperature.

ATF operating temperature:

50 - 80°C (122 - 176°F)


HA




SC


- Install a tachometer where it can be seen by driver during test.
- It is good practice to put a mark on point of specified engine rpm on indicator.

EL









- 5. Start engine, apply foot brake, and place selector lever in "D" position.
- Accelerate to wide open throttle gradually while applying foot brake.
- 7. Quickly note the engine stall revolution and immediately release throttle.
- During test, never hold throttle wide open for less than 5 seconds.

Stall revolution: 2,440 - 2,640 rpm

- 8. Move selector lever to "N" position.
- Cool off ATF.
- Run engine at idle for at least one minute.
- Repeat steps 5 through 9 with selector lever in "2", "1" and "R" positions.

JUDGEMENT OF STALL TEST

VBAT0022S02

The test result and possible damaged components relating to each result are shown in the illustration. In order to pinpoint the possible damaged components, follow the WORK FLOW shown in AT-57.

NOTE:

Stall revolution is too high in "D" or "2" position:

- Slippage occurs in 1st gear but not in 2nd and 3rd gears.
 Low one-way clutch slippage
- Slippage occurs at the following gears:
 - 1st through 3rd gears in "D" position and engine brake functions.

1st and 2nd gears in "2" position and engine brake functions with accelerator pedal released (fully closed throttle). Forward clutch or forward one-way clutch slippage

Stall revolution is too high in "R" position:

- Engine brake does not function in "1" position. Low & reverse brake slippage
- Engine brake functions in "1" position. Reverse clutch slippage

Stall revolution within specifications:

Vehicle does not achieve speed of more than 80 km/h (50 MPH).
 One-way clutch seizure in torque converter housing

CAUTION:


Be careful since automatic fluid temperature increases abnormally.

- Slippage occurs in 3rd and 4th gears in "D" position. High clutch slippage
- Slippage occurs in 2nd and 4th gear in "D" position. Brake band slippage

Stall revolution less than specifications:


 Poor acceleration during starts. One-way clutch seizure in torque converter





SAT392H






Line Pressure Test

NBAT0023

- Location of line pressure test ports.
- Always replace line pressure plugs as they are self-sealing bolts.




LINE PRESSURE TEST PROCEDURE


NBAT0023S0

- 1. Check A/T fluid and engine oil levels. If necessary, add fluid and oil
- 2. Drive vehicle for approx. 10 minutes or until fluid and oil reach operating temperature.


ATF operating temperature: 50 - 80°C (122 - 176°F)




3. Install pressure gauge to corresponding line pressure port.



- 4. Set parking brake and block wheels.
- Continue to depress brake pedal fully while line pressure test is being performed at stall speed.



Line Pressure Test (Cont'd)



- 5. Start engine and measure line pressure at idle and stall speed.
- When measuring line pressure at stall speed, follow the stall test procedure.

Line pressure:

Refer to SDS, AT-339.

GI

MA

EM

LC

JUDGEMENT OF LINE PRESSURE TEST

NBAT0023S02

	Judgement	Suspected parts	EG
	Line pressure is low in all positions.	 Oil pump wear Control piston damage Pressure regulator valve or plug sticking Spring for pressure regulator valve damaged Fluid pressure leakage between oil strainer and pressure regulator valve Clogged strainer 	FE
At idle	Line pressure is low in particular position.	Fluid pressure leakage between manual valve and particular clutch For example, line pressure is: — Low in "R" and "1" positions, but — Normal in "D" and "2" positions. Then, fluid leakage exists at or around low and reverse brake circuit. Refer to "CLUTCH AND BAND CHART", AT-17.	TF PD
	Line pressure is high.	 Mal-adjustment of throttle position sensor Fluid temperature sensor damaged Line pressure solenoid valve sticking Short circuit of line pressure solenoid valve circuit Pressure modifier valve sticking Pressure regulator valve or plug sticking Open in dropping resistor circuit 	- AX SU
At stall speed	Line pressure is low.	 Mal-adjustment of throttle position sensor Line pressure solenoid valve sticking Short circuit of line pressure solenoid valve circuit Pressure regulator valve or plug sticking Pressure modifier valve sticking Pilot valve sticking 	- BR ST

1. Check before engine is started. 2. Check at idle. 3. Cruise test.

Road Test DESCRIPTION

NEATOOS

NBAT0024

BT

HA

SC

IDX

- The purpose of the test is to determine overall performance of A/T and analyze causes of problems.
- The road test consists of the following three parts:
- 1. Check before engine is started
- 2. Check at idle
- 3. Cruise test




Road Test (Cont'd)



- Before road test, familiarize yourself with all test procedures and items to check.
- Conduct tests on all items until specified symptom is found. Troubleshoot items which check out No Good after road test. Refer to "ON BOARD DIAGNOSTIC SYSTEM DESCRIP-TION" and "TROUBLE DIAGNOSES FOR SYMPTOMS", AT-33 - AT-50 and AT-203 - AT-244.

1. CHECK BEFORE ENGINE IS STARTED



TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

Road Test (Cont'd)



3	3 CHECK NG ITEM				
2. Per	 Turn ignition switch to "OFF" position. Perform self-diagnosis and note NG items. Refer to TCM SELF-DIAGNOSIS PROCEDURE (No Tools), AT-46. 				
	>	Go to "2. Check at idle", AT-66.			



2. CHECK AT IDLE

=NBAT0024S03

1 CHECK ENGINE START

- 1. Park vehicle on flat surface.
- 2. Turn ignition switch to "OFF" position.
- 3. Move selector lever to "P" or "N" position.
- 4. Turn ignition switch to start position.
- 5. Is engine started?

Yes or No

100 01 110		
Yes	GO TO 2.	
No	Go to "2. Engine Cannot Be Started In "P" and "N" Position", AT-209.	

CHECK ENGINE START 1. Turn ignition switch to "OFF" position. 2. Make selector lever to "D" "1" "2" or "P" position.

- 2. Move selector lever to "D", "1", "2" or "R" position.
- 3. Turn ignition switch to start position.
- 4. Is engine started?

Yes or No

Yes	Go to "2. Engine Cannot Be Started In "P" and "N" Position", AT-209.
No •	GO TO 3.

3 CHECK VEHICLE MOVE

- 1. Turn ignition switch to "OFF" position.
- 2. Move selector lever to "P" position.
- 3. Release parking brake.
- 4. Push vehicle forward or backward.
- 5. Does vehicle move when it is pushed forward or backward?



SAT796A

Yes or No

Yes	•	Go to "3. In "P" Position, Vehicle Moves Forward Or Backward When Pushed", AT-210.
No	•	GO TO 4.


4 CHECK VEHICLE MOVE

- 1. Apply parking brake.
- 2. Move selector lever to "N" position.
- 3. Turn ignition switch to "START" position and start engine.
- 4. Release parking brake.
- 5. Does vehicle move forward or backward?

Yes or No


Yes	Go to "4. In "N" Position, Vehicle Moves", AT-211.
No	GO TO 5.

Road Test (Cont'd)



6	6 CHECK VEHICLE MOVE		
	lease foot brake for severa es vehicle creep backward	I seconds. when foot brake is released? Yes or No	
Yes	•	GO TO 7.	1
No	•	Go to "6. Vehicle Does Not Creep Backward In "R" Position", AT-215.	1

7	CHECK VEHICLE MOV	E		
	 Move selector lever to "D", "2" and "1" position and check if vehicle creeps forward. Does vehicle creep forward in all three positions? 			
	Yes or No			
Yes	•	Go to "3. Cruise test", AT-67.		
No	>	Go to "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position", AT-218.		



3. CRUISE TEST

Check all items listed in Parts 1 through 3.

With CONSULT

Using CONSULT, conduct a cruise test and record the result.

Print the result and ensure that shifts and lock-ups take place as per "Shift Schedule".

GI

MA

LC

EG

FE

AT

TF

PD

AX

SU

BR

ST

BT


HA

SC

NBAT0024S04








CONSULT Setting Procedure

NBAT0024S0402


- 1. Turn ignition switch "OFF".
- Connect "CONSULT" to Data link connector for CONSULT. Data link connector for CONSULT is located in instrument lower panel on driver side.




- 3. Turn ignition switch "ON".
- 4. Touch "START".

SELECT SYSTEM	
ENGINE	
A/T °	
	SAT974H


5. Touch "A/T".



6. Touch "DATA MONITOR".



7. Touch "SETTING" to set recording condition.



STORE

RECORD2


(RECORD1)

DISPLAY


SAT301C




Road Test (Cont'd)




14. Touch "PRINT".



15. Touch "PRINT" again.



- 16. Check the monitor data printed out.
- 17. Continue cruise test part 2 and 3.




N Without CONSULT

Throttle position sensor can be checked by voltage across terminals 41 and 42 of TCM.


, ,








Road Test (Cont'd)





GI


MA


LC

EC

FE

Road Test (Cont'd)





6	CHECK HOLD LOCK-UP				
Does A	A/T hold lock-up condition	for more than 30 seconds?			
	Yes or No				
Yes	S				
No	•	Go to "13. A/T Does Not Hold Lock-up Condition", AT-235.			

EL


BT


HA

SC



Road Test (Cont'd)





,

Road Test (Cont'd,



MA

LC

EC


FE


AT

TF

SC


[DX








Road Test (Cont'd)






FE


SC

EL

SAT812A

Road Test (Cont'd)







AT-77



Road Test (Cont'd)





GI

MA

LC

FE


BT


HA

SC


EL

Road Test (Cont'd)





AT-79





Road Test (Cont'd)

7	CHECK ENGINE BRAK	E
Does	s vehicle decelerate by engir	ne brake?
		22 1) 1) Engine brake
		Yes or No
Yes	>	 Stop vehicle. Perform self-diagnosis. Refer to TCM SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-46.
No	•	Go to "20. Vehicle Does Not Decelerate By Engine Brake", AT-244.

Symptom Chart



Symptom Chart

Numbers are arranged in the order of inspection.

Perform inspections starting with number one and work up.

IRΛ	TO	126	

Symptom	Condition	Diagnostic Item	Reference Page
Engine does not start in "N", "P" positions.	ON vehicle	Ignition switch and starter	EL-9, "Schematic" and SC-6, "System Description"
AT-209	ON VEHICLE	2. Control linkage	AT-261
		3. PNP switch	AT-260
Engine starts in position other than "N"	011	Control linkage	AT-261
and "P" positions. AT-209	ON vehicle	2. PNP switch	AT-260
		1. Fluid level	AT-59
		2. Line pressure	AT-62
	ON vehicle	3. Throttle position sensor (Adjustment)	EC-181, "Description"
Transmission noise in "P" and "N" positions.		Revolution sensor and vehicle speed sensor	AT-110, AT-195
		5. Engine speed signal	AT-115
	OFF vehicle	6. Oil pump	AT-280
		7. Torque converter	AT-269
Vehicle moves when changing into "P" position or parking gear does not disengage when shifted out of "P" posi-	ON vehicle	1. Control linkage	AT-261
tion. AT-209	OFF vehicle	2. Parking components	AT-320
	ON vehicle	1. Control linkage	AT-261
		2. Accumulator 3-4 (N-R)	AT-259
Vehicle runs in "N" position. AT-211		3. Forward clutch	AT-303
	OFF vehicle	4. Reverse clutch	AT-297
		5. Overrun clutch	AT-303
		1. Control linkage	AT-261
	ON vehicle	2. Line pressure	AT-62
	314 40111010	3. Line pressure solenoid valve	AT-161
Vehicle will not run in "R" position (but runs in "D", "2" and "1" positions).		4. Control valve assembly	AT-259
Clutch slips. /ery poor acceleration.		5. Reverse clutch	AT-297
AT-215		6. High clutch	AT-301
	OFF vehicle	7. Forward clutch	AT-303
		8. Overrun clutch	AT-303
		9. Low & reverse brake	AT-307

Symptom	Condition	Diagnostic Item	Reference Page
		1. Fluid level	AT-59
		2. Control linkage	AT-261
	ON vehicle	3. Line pressure	AT-62
		4. Line pressure solenoid valve	AT-161
Vehicle braked when shifting into "R" position.		5. Control valve assembly	AT-259
		6. High clutch	AT-301
	055 1111	7. Brake band	AT-316
	OFF vehicle	8. Forward clutch	AT-303
		9. Overrun clutch	AT-303
		1. Engine idling rpm	AT-62
		2. Throttle position sensor (Adjustment)	EC-181, "Description"
		3. Line pressure	AT-62
	ONhista	4. A/T fluid temperature sensor	AT-105
Sharp shock in shifting from "N" to "D" position.	ON vehicle	5. Engine speed signal	AT-115
		6. Line pressure solenoid valve	AT-161
		7. Control valve assembly	AT-259
		8. Accumulator N-D	AT-259
	OFF vehicle	9. Forward clutch	AT-303
Vehicle will not run in "D" and "2" posi-	ON vehicle	Control linkage	AT-261
ions (but runs in "1" and "R" posi- ions).	OFF vehicle	2. Low one-way clutch	AT-311
		1. Fluid level	AT-59
		2. Line pressure	AT-62
	ON vehicle	3. Line pressure solenoid valve	AT-161
		4. Control valve assembly	AT-259
Vehicle will not run in "D", "1", "2" positions (but runs in "R" position).		5. Accumulator N-D	AT-259
Clutch slips. Very poor acceleration.		6. Reverse clutch	AT-297
11 210		7. High clutch	AT-301
	OFF vehicle	8. Forward clutch	AT-303
		9. Forward one-way clutch	AT-303
		10. Low one-way clutch	AT-311



Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page
		1. Fluid level	AT-59
		2. Control linkage	AT-261
		3. Throttle position sensor (Adjustment)	EC-181, "Description"
		4. Line pressure	AT-62
	ON vehicle	5. Line pressure solenoid valve	AT-161
		6. Control valve assembly	AT-259
Clutches or brakes slip somewhat in tarting.		7. Accumulator N-D	AT-259
		8. Accumulator 3-4 (N-R)	AT-259
		9. Forward clutch	AT-303
		10. Reverse clutch	AT-297
	OFF vehicle	11. Low & reverse brake	AT-307
		12. Oil pump	AT-280
		13. Torque converter	AT-269
xcessive creep.	ON vehicle	1. Engine idling rpm	EC-181, "Description"
	ON vehicle	1. Fluid level	AT-59
		2. Line pressure	AT-62
o creep at all.		3. Control valve assembly	AT-259
T-215, AT-218	OFF vehicle	4. Forward clutch	AT-303
		5. Oil pump	AT-280
		6. Torque converter	AT-269
		1. PNP switch	AT-260
		2. Control linkage	AT-261
ailure to change gear from "D ₁ " to	ON vehicle	3. Shift solenoid valve A	AT-167
D ₂ ".		4. Control valve assembly	AT-259
		5. Revolution sensor and speed sensor	AT-110, AT-195
	OFF vehicle	6. Brake band	AT-316
		1. PNP switch	AT-260
		2. Control linkage	AT-261
	ON vehicle	3. Shift solenoid valve B	AT-171
ailure to change gear from " D_2 " to D_3 ".		4. Control valve assembly	AT-259
· 3 ·		5. Revolution sensor and speed sensor	AT-105, AT-195
	OFF	6. High clutch	AT-301
	OFF vehicle	7. Brake band	AT-316

Symptom	Condition	Diagnostic Item	Reference Page
		1. PNP switch	AT-260
		2. Control linkage	AT-261
Failure to change gear from "D ₃ " to	ON vehicle	3. Shift solenoid valve A	AT-167
"D ₄ ".		4. Revolution sensor and speed sensor	AT-110, AT-195
		5. A/T fluid temperature sensor	AT-105
	OFF vehicle	6. Brake band	AT-316
		Throttle position sensor (Adjustment)	EC-181, "Description"
Too high a gear change point from "D ₁ " to "D ₂ ", from "D ₂ " to "D ₃ ", from	ON ALCOHOL	2. Revolution sensor and speed sensor	AT-110, AT-195
"D ₃ " to "D ₄ ". AT-224, AT-227, AT-230	ON vehicle	3. Shift solenoid valve A	AT-167
A1-224, A1-221, A1-230		4. Shift solenoid valve B	AT-171
		1. Fluid level	AT-59
Gear change directly from "D ₁ " to "D ₃ " occurs.	ON vehicle	2. Accumulator 1-2	AT-259
oodio.	OFF vehicle	3. Brake band	AT-316
		1. Engine idling rpm	AT-62
Engine stops when shifting lever into	ON vehicle	2. Torque converter clutch solenoid valve	AT-147
"R", "D", "2" and "1".		3. Control valve assembly	AT-259
	OFF vehicle	4. Torque converter	AT-269
		Throttle position sensor (Adjustment)	EC-181, "Description"
		2. Line pressure	AT-62
Too sharp a shock in change from	ON vehicle	3. Accumulator 1-2	AT-259
"D ₁ " to "D ₂ ".		4. Control valve assembly	AT-259
		5. A/T fluid temperature sensor	AT-105
	OFF vehicle	6. Brake band	AT-316
		Throttle position sensor (Adjustment)	EC-181, "Description"
		2. Line pressure	AT-62
Too sharp a shock in change from	ON vehicle	3. Accumulator 2-3	AT-259
"D ₂ " to "D ₃ ".		4. Control valve assembly	AT-259
		5. High clutch	AT-301
	OFF vehicle	6. Brake band	AT-316
		Throttle position sensor (Adjustment)	EC-181, "Description"
	011	2. Line pressure	AT-62
Too sharp a shock in change from	ON vehicle	3. Accumulator 3-4 (N-R)	AT-259
" D_3 " to " D_4 ".		4. Control valve assembly	AT-259
	OFF vehicle	5. Brake band	AT-316
		6. Overrun clutch	AT-303



Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page	
		1. Fluid level	AT-59	_
		2. Throttle position sensor (Adjustment)	EC-181, "Description"	_
Almost no shock or clutches slipping	ON vehicle	3. Line pressure	AT-62	
n change from "D ₁ " to "D ₂ ".		4. Accumulator 1-2	AT-259	_
		5. Control valve assembly	AT-259	_
	OFF vehicle	6. Brake band	AT-316	
		1. Fluid level	AT-59	
		2. Throttle position sensor (Adjustment)	EC-181, "Description"	
	ON vehicle	3. Line pressure	AT-62	_
Almost no shock or slipping in change from "D ₂ " to "D ₃ ".		4. Accumulator 2-3	AT-259	_
2 0		5. Control valve assembly	AT-259	
	OFF vehicle	6. High clutch	AT-301	
	OFF Verlicie	7. Brake band	AT-316	
	ON vehicle	1. Fluid level	AT-59	
		2. Throttle position sensor (Adjustment)	EC-181, "Description"	
		3. Line pressure	AT-62	
Almost no shock or slipping in change from "D ₃ " to "D ₄ ".		4. Accumulator 3-4 (N-R)	AT-259	
.		5. Control valve assembly	AT-259	_
	OFF vehicle	6. High clutch	AT-301	
	Of F verticie	7. Brake band	AT-316	
	ON vehicle	1. Fluid level	AT-59	
		2. Reverse clutch	AT-297	
/ehicle braked by gear change from D ₁ " to "D ₂ ".	OFF vehicle	3. Low & reverse brake	AT-307	_
	Of 1 Verliere	4. High clutch	AT-301	
		5. Low one-way clutch	AT-311	
/ehicle braked by gear change from	ON vehicle	1. Fluid level	AT-59	_
'D ₂ " to "D ₃ ".	OFF vehicle	2. Brake band	AT-316	_
	ON vehicle	1. Fluid level	AT-59	_
Vehicle braked by gear change from		2. Overrun clutch	AT-303	
'D ₃ " to "D ₄ ".	OFF vehicle	3. Forward one-way clutch	AT-303	_
		4. Reverse clutch	AT-297	

EL

 $\mathbb{D}\mathbb{X}$

$\Diamond \Diamond$

Symptom	Condition	Diagnostic Item	Reference Page
		1. Fluid level	AT-59
		2. PNP switch	AT-260
	ON vehicle	3. Shift solenoid valve A	AT-167
		4. Shift solenoid valve B	AT-171
		5. Control valve assembly	AT-259
Maximum speed not attained. Acceleration poor.		6. Reverse clutch	AT-297
		7. High clutch	AT-301
	OFF vehicle	8. Brake band	AT-316
	OFF vehicle	9. Low & reverse brake	AT-307
		10. Oil pump	AT-280
		11. Torque converter	AT-269
		1. Fluid level	AT-59
		2. Throttle position sensor (Adjustment)	EC-181, "Description"
	ON vehicle	3. Overrun clutch solenoid valve	AT-184
Failure to change gear from "D ₄ " to	ON venicie	4. Shift solenoid valve A	AT-167
"D ₃ ".		5. Line pressure solenoid valve	AT-161
		6. Control valve assembly	AT-259
	OFF vehicle	7. Low & reverse brake	AT-307
		8. Overrun clutch	AT-303
		1. Fluid level	AT-59
		2. Throttle position sensor (Adjustment)	EC-181, "Description"
	ON vehicle	3. Shift solenoid valve A	AT-167
Failure to change gear from " D_3 " to " D_2 " or from " D_4 " to " D_2 ".		4. Shift solenoid valve B	AT-171
22 3: 24 13 22 .		5. Control valve assembly	AT-259
	OFF vehicle	6. High clutch	AT-301
		7. Brake band	AT-316
		1. Fluid level	AT-59
		2. Throttle position sensor (Adjustment)	EC-181, "Description"
	ON vehicle	3. Shift solenoid valve A	AT-167
Failure to change gear from "D ₂ " to		4. Shift solenoid valve B	AT-171
"D ₁ " or from "D ₃ " to "D ₁ ".		5. Control valve assembly	AT-259
		6. Low one-way clutch	AT-311
	OFF vehicle	7. High clutch	AT-301
		8. Brake band	AT-316
		Throttle position sensor (Adjustment)	EC-181, "Description"
Gear change shock felt during decel-		2. Line pressure	AT-62
eration by releasing accelerator pedal.		3. Overrun clutch solenoid valve	AT-184
		4. Control valve assembly	AT-259

			Symptom Chart (Cont'd	-
Symptom	Condition	Diagnostic Item	Reference Page	
Too high a change point from "D ₄ " to	ONhisla	Throttle position sensor (Adjustment)	EC-181, "Description"	_ (
$^{\circ}D_3$ ", from $^{\circ}D_3$ " to $^{\circ}D_2$ ", from $^{\circ}D_2$ " to $^{\circ}D_1$ ".	ON vehicle	2. Revolution sensor and speed sensor	AT-110, AT-195	_
		Throttle position sensor (Adjustment)	EC-181, "Description"	_ [
Kickdown does not operate when	ON ALLE	2. Revolution sensor and speed sensor	AT-110, AT-195	_
depressing pedal in "D ₄ " within kick-down vehicle speed.	ON vehicle	3. Shift solenoid valve A	AT-167	_ [
		4. Shift solenoid valve B	AT-171	_
		Revolution sensor and speed sensor	AT-110, AT-195	- !
Kickdown operates or engine overruns	ON ambiala	2. Throttle position sensor (Adjustment)	EC-181, "Description"	
when depressing pedal in "D ₄ " beyond ickdown vehicle speed limit.	ON vehicle	3. Shift solenoid valve A	AT-167	
		4. Shift solenoid valve B	AT-171	_
		1. Fluid level	AT-59	
		2. Throttle position sensor (Adjustment)	EC-181, "Description"	
aces extremely fast or slips in	ON vehicle	3. Line pressure	AT-62	
hanging from "D ₄ " to "D ₃ " when		4. Line pressure solenoid valve	AT-161	_
epressing pedal.		5. Control valve assembly	AT-259	_
	OFF vehicle	6. High clutch	AT-301	_
		7. Forward clutch	AT-303	
		1. Fluid level	AT-59	_
		2. Throttle position sensor (Adjustment)	EC-181, "Description"	
	ON vehicle	3. Line pressure	AT-62	_
aces extremely fast or slips in		4. Line pressure solenoid valve	AT-161	_
hanging from "D ₄ " to "D ₂ " when epressing pedal.		5. Shift solenoid valve A	AT-167	_
		6. Control valve assembly	AT-259	
	OFFhists	7. Brake band	AT-316	_
	OFF vehicle	8. Forward clutch	AT-303	_
		1. Fluid level	AT-59	
		2. Throttle position sensor (Adjustment)	EC-181, "Description"	_
		3. Line pressure	AT-62	
	ON vehicle	4. Line pressure solenoid valve	AT-161	_
aces extremely fast or slips in		5. Control valve assembly	AT-259	_
nanging from "D ₃ " to "D ₂ " when epressing pedal.		6. A/T fluid temperature sensor	AT-105	
		7. Accumulator 2-3	AT-259	_
		8. Brake band	AT-316	_
	OFF vehicle	9. Forward clutch	AT-303	_
		10. High clutch	AT-301	_



Symptom	Condition	Diagnostic Item	Reference Page
		1. Fluid level	AT-59
		2. Throttle position sensor (Adjustment)	EC-181, "Description"
	ON vehicle	3. Line pressure	AT-62
Races extremely fast or slips in		4. Line pressure solenoid valve	AT-161
changing from "D ₄ " or "D ₃ " to "D ₁ " when depressing pedal.		5. Control valve assembly	AT-259
		6. Forward clutch	AT-303
	OFF vehicle	7. Forward one-way clutch	AT-303
		8. Low one-way clutch	AT-311
		1. Fluid level	AT-59
	ON vehicle	2. Control linkage	AT-261
	ON venicie	3. Line pressure	AT-62
		4. Line pressure solenoid valve	AT-161
Vehicle will not run in any position.	OFF vehicle	5. Oil pump	AT-280
		6. High clutch	AT-301
		7. Brake band	AT-316
		8. Low & reverse brake	AT-307
		9. Torque converter	AT-269
Transmission noise in "D", "2", "1" and	ON vehicle	1. Fluid level	AT-59
"R" positions.	OFF vehicle	2. Torque converter	AT-269
		1. PNP switch	AT-260
		2. Throttle position sensor (Adjustment)	EC-181, "Description"
		3. Torque converter clutch solenoid valve	AT-147
Failure to change from "D ₃ " to "2"	ON vehicle	4. Shift solenoid valve B	AT-171
when changing lever into "2" position.		5. Shift solenoid valve A	AT-167
AT-238		6. Control valve assembly	AT-259
		7. Control linkage	AT-261
	OFF voltists	8. Brake band	AT-316
	OFF vehicle	9. Overrun clutch	AT-303
Gear change from "2 ₂ " to "2 ₃ " in "2" position.	ON vehicle	1. PNP switch	AT-260



Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page
		1. PNP switch	AT-260
		2. Control linkage	AT-261
		3. Throttle position sensor (Adjustment)	EC-181, "Description"
Engine brake does not operate in "1"	ON vehicle	4. Revolution sensor and speed sensor	AT-105, AT-195
position.		5. Shift solenoid valve A	AT-167
AT-240		6. Control valve assembly	AT-259
		7. Overrun clutch solenoid valve	AT-184
	OFF webiele	8. Overrun clutch	AT-303
	OFF vehicle	9. Low & reverse brake	AT-307
Gear change from "1 ₁ " to "1 ₂ " in "1"	ONLorabiala	1. PNP switch	AT-260
position.	ON vehicle	2. Control linkage	AT-261
		1. PNP switch	AT-260
		2. Revolution sensor and speed sensor	AT-110, AT-195
	ON vehicle	3. Shift solenoid valve A	AT-167
Does not change from "1 ₂ " to "1 ₁ " in "1" position.		4. Control valve assembly	AT-259
· poomoni		5. Overrun clutch solenoid valve	AT-184
	OFF vehicle	6. Overrun clutch	AT-303
		7. Low & reverse brake	AT-307
Large shock changing from "1 ₂ " to "1 ₁ "	ON vehicle	1. Control valve assembly	AT-259
in "1" position.	OFF vehicle	2. Low & reverse brake	AT-307
		1. Fluid level	AT-59
		2. Engine idling rpm	AT-62
		3. Throttle position sensor (Adjustment)	EC-181, "Description"
	ON vehicle	4. Line pressure	AT-62
		5. Line pressure solenoid valve	AT-161
		6. Control valve assembly	AT-259
		7. Oil pump	AT-280
Transmission overheats.		8. Reverse clutch	AT-297
		9. High clutch	AT-301
	055	10. Brake band	AT-316
	OFF vehicle	11. Forward clutch	AT-303
		12. Overrun clutch	AT-303
		13. Low & reverse brake	AT-307
		14. Torque converter	AT-269

 $\mathbb{D}\mathbb{X}$

Symptom	Condition	Diagnostic Item	Reference Page
	ON vehicle	1. Fluid level	AT-59
		2. Reverse clutch	AT-297
ATF shoots out during operation. White smoke emitted from exhaust pipe during operation.		3. High clutch	AT-301
	OFF webiele	4. Brake band	AT-316
	OFF vehicle	5. Forward clutch	AT-303
		6. Overrun clutch	AT-303
		7. Low & reverse brake	AT-307
	ON vehicle	1. Fluid level	AT-59
		2. Torque converter	AT-269
		3. Oil pump	AT-280
		4. Reverse clutch	AT-297
Offensive smell at fluid charging pipe.	OFF william	5. High clutch	AT-301
	OFF vehicle	6. Brake band	AT-316
		7. Forward clutch	AT-303
		8. Overrun clutch	AT-303
		9. Low & reverse brake	AT-307
		Throttle position sensor (Adjustment)	EC-181, "Description"
		2. Revolution sensor and speed sensor	AT-110, AT-195
		3. PNP switch	AT-260
	ONhista	4. Engine speed signal	AT-115
orque converter is not locked up.	ON vehicle	5. A/T fluid temperature sensor	AT-105
		6. Line pressure	AT-62
		7. Torque converter clutch solenoid valve	AT-147
		8. Control valve assembly	AT-259
	OFF vehicle	9. Torque converter	AT-269
		1. Fluid level	AT-59
		2. Line pressure	AT-62
	ONhista	3. Torque converter clutch solenoid valve	AT-147
Torque converter clutch piston slip.	ON vehicle	4. Line pressure solenoid valve	AT-161
		5. Line pressure solenoid valve	AT-161
		6. Control valve assembly	AT-259
	OFF vehicle	7. Torque converter	AT-269
		1. Throttle position sensor (Adjustment)	EC-181, "Description"
_ock-up point is extremely high or low.	ON	2. Revolution sensor and speed sensor	AT-110, AT-195
AT-233	ON vehicle	3. Torque converter clutch solenoid valve	AT-147
		4. Control valve assembly	AT-259

GI

MA

EM

LC

EC

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA


SC

EL

Symptom Condition		Diagnostic Item	Reference Page
		Throttle position sensor (Adjustment)	EC-181, "Description"
		2. PNP switch	AT-260
		3. Revolution sensor and speed sensor	AT-110, AT-195
	ON vehicle	4. Shift solenoid valve A	AT-167
A/T does not shift to "D ₄ " when driving	ON vehicle	5. Overrun clutch solenoid valve	AT-184
with overdrive control switch "ON".		6. Control valve assembly	AT-259
		7. A/T fluid temperature sensor	AT-105
		8. Line pressure	AT-62
	OFF vehicle	9. Brake band	AT-316
		10. Overrun clutch	AT-303
		1. Fluid level	AT-59
Engine is stopped at "R", "D", "2" and "1" positions.		2. Torque converter clutch solenoid valve	AT-147
	ON vehicle	3. Shift solenoid valve B	AT-171
		4. Shift solenoid valve A	AT-167
		5. Control valve assembly	AT-259








TCM Terminals and Reference Value PREPARATION

Measure voltage between each terminal and terminal 25 or 48 by following "TCM INSPECTION TABLE".



TCM HARNESS CONNECTOR TERMINAL LAYOUT **TCM INSPECTION TABLE**

NBAT0027S03

(Data are reference values.)

(Data are reference values.)					
Terminal No.	Wire color	Item		Condition	Judgement standard
	G/Y	Line pressure		When releasing accelerator pedal after warming up engine.	1.5 - 3.0V
1	G/ f	solenoid valve	Con	When depressing accelerator pedal fully after warming up engine.	0.5V or less
	BR/Y	Line pressure solenoid valve		When releasing accelerator pedal after warming up engine.	5 - 14V
2	BR/ I	(with dropping resistor)		When depressing accelerator pedal fully after warming up engine.	0.5V or less
2	C/OP	Torque converter		When A/T performs lock-up.	8 - 15V
3	G/OR	clutch solenoid valve		When A/T does not perform lock- up.	1V or less
4	_	_		_	_
5*1	PU/W	DT1		_	_
6*1	P/B	DT2		_	_
7*1	Р	DT3	Con	_	_
8	_	_		_	_
9	_	_		_	_
10	W/R	W/R Power source	When turning ignition switch to "ON".	Battery volt- age	
				When turning ignition switch to "OFF".	1V or less

TCM Terminals and Reference Value (Cont'd)

				ICM Terminals and Reference	(_
Terminal No.	Wire color	Item		Condition	Judgement standard	. - ((
		01:6		When shift solenoid valve A operates. (When driving in "D ₁ " or "D ₄ ".)	Battery volt- age	
11	L/W	Shift solenoid valve A		When shift solenoid valve A does not operate. (When driving in "D ₂ " or "D ₃ ".)	1V or less	- [
		01:6	EOMA !	When shift solenoid valve B operates. (When driving in "D ₁ " or "D ₂ ".)	Battery volt- age	- [
12	L/R	Shift solenoid valve B		When shift solenoid valve B does not operate. (When driving in "D ₃ " or "D ₄ ".)	1V or less	- [
13	GY	O/D OFF indicator		When setting overdrive control switch in "ON" position.	Battery volt- age	
13	Gi	lamp		When setting overdrive control switch in "OFF" position.	1V or less	
14	_	_			_	
15*1	Y/G	OBD-II output		_	_	
		Closed throttle		When releasing accelerator pedal after warming up engine. Refer to "Preparation", "TCM SELF-DIAG-NOSTIC PROCEDURE (No Tools)", AT-46.	Battery volt- age	- [
16	OR/W	(in throttle position switch)	8	When depressing accelerator pedal after warming up engine. Refer to "Preparation", "TCM SELF-DIAG-NOSTIC PROCEDURE (No Tools)", AT-46.	1V or less	
17	OR/B	Wide open throttle position switch		When depressing accelerator pedal more than half-way after warming up engine.	Battery volt- age	- (
17	OR/B	(in throttle position switch)		When releasing accelerator pedal after warming up engine.	1V or less	-
10	D.V.	ASCD cruise sig-		When ASCD cruise is being performed. ("CRUISE" light comes on.)	Battery volt- age	-
18	B/Y	nal		When ASCD cruise is not being performed. ("CRUISE" light does not comes on.)	1V or less	-
19	W/R	Power source		Same as No. 10		E
00		Overrun clutch		When overrun clutch solenoid valve operates.	Battery voltage	- [
20	L/B	solenoid valve		When overrun clutch solenoid valve does not operate.	1V or less	- (
21	_	_		_	_	-
_		Overdrive control	(CON)	When setting overdrive control switch in "ON" position	Battery volt- age	-
22	GY	switch		When setting overdrive control switch in "OFF" position	1V or less	- [
23	_	_		_	_	-

TCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item		Condition	Judgement standard
24	W/G	ASCD OD cut sig-		When "ACCEL" set switch on ASCD cruise is released.	More than 4.5V
24	W/G	nal		When "ACCEL" set switch on ASCD cruise is applied.	1V or less
25	В	Ground		_	_
26	G	PNP switch "1"		When setting selector lever to "1" position.	Battery voltage
	G	position		When setting selector lever to other positions.	1V or less
27	G/W	PNP switch "2"		When setting selector lever to "2" position.	Battery voltage
	G/VV	position		When setting selector lever to other positions.	1V or less
28	R/Y	Power source	CON	When turning ignition switch to "OFF".	Battery volt- age
20	N/T	(Memory back-up)	Or COFF	When turning ignition switch to "ON".	Battery voltage
29	W	Revolution sensor (Measure in AC range)		When vehicle cruises at 30 km/h (19 MPH).	1V or more Voltage rises gradually in response to vehicle speed.
				When vehicle parks.	0V
30*2	W	_		_	_
31*2	L	_	CON	_	_
32	P/B	Throttle position sensor (Power source)		_	4.5 - 5.5V
33	_	_		_	_
34	L	PNP switch "D"		When setting selector lever to "D" position.	Battery volt- age
	L	position		When setting selector lever to other positions.	1V or less
35	Y	PNP switch "R"		When setting selector lever to "R" position.	Battery voltage
	'	position		When setting selector lever to other positions.	1V or less
36	Р	PNP switch "N" or		When setting selector lever to "N" or "P" position.	Battery volt- age
	,	"P" position		When setting selector lever to other positions.	1V or less
37	_	_		_	_
38	_	_		_	_

TCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item		Condition	Judgement standard
39	W/B	Engine speed signal		When engine runs at idle speed.	0.5 - 2.5V
40	W/L	Vehicle speed sensor		When moving vehicle at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more.	Voltage varies between less than 1.0V and more than 4.5V.
41	Р	Throttle position sensor		When depressing accelerator pedal slowly after warming up engine. (Voltage rises gradually in response to throttle position.)	Fully-closed throttle: Approximately 0.5V Fully-open throttle: Approximately 4V
42	В	Throttle position sensor (Ground)	N.E.	_	_
45	_	_		_	_
		Vehicle speed signal		When vehicle is running.	Outputs approx. 1V or 5V alternately.
46	W	(For transfer control unit)		When vehicle is stopped.	Approximately 5V
	_	A/T fluid tempera-		When ATF temperature is 20°C (68°F).	Approximately 1.5V
47	R	ture sensor		When ATF temperature is 80°C (176°F).	Approximately 0.5V
48	В	Ground	N.	_	_

^{*1:} These terminals are connected to the ECM.

SC

HA


^{*2:} These terminals are connected to the Data link connector for CONSULT.




Wiring Diagram — AT — MAIN

NBAT0185

AT-MAIN-01





MAT726A

TROUBLE DIAGNOSIS FOR POWER SUPPLY

446

GI

MA

EM

LC

EC

FE

AT


Wiring Diagram — AT — MAIN (Cont'd)

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.


NBAT0185S01

Terminal No.	Wire color	Item	Condition Judgement standard		Judgement standard
10	W/R	Power source	Con	When turning ignition switch to "ON".	Battery voltage
			W 5 5	When turning ignition switch to "OFF".	1V or less
19	W/R	Power source		Same as No. 10	
25	В	Ground	COFF	_	_
20	DAY	Power source	Con	When turning ignition switch to "OFF".	Battery voltage
28	R/Y	(Memory back-up)	Or	When turning ignition switch to "ON".	Battery volt- age
48	В	Ground	COFF	_	_






Wiring Diagram — AT — MAIN (Cont'd)



Description



Description

The PNP switch assemble includes a transmission range switch.

The transmission range switch detects the selector position and sends a signal to the TCM.

MA

LC

EC

FE

ΑT

TF

PD

AX

SU

BR

ST

RS

TCM TERMINALS AND REFERENCE VALUE

NBAT0028S02

Remarks: Sp	Remarks: Specification data are reference values.				
Terminal No.	Wire color	Item		Condition	Judgement standard
26	G	PNP switch "1"		When setting selector lever to "1" position.	Battery volt- age
		position		When setting selector lever to other positions.	1V or less
27	G/W	PNP switch "2"		When setting selector lever to "2" position.	Battery volt- age
		position		When setting selector lever to other positions.	1V or less
34	L	PNP switch "D" position		When setting selector lever to "D" position.	Battery volt- age
		position		When setting selector lever to other positions.	1V or less
35	Y	PNP switch "R" position	V (3)	When setting selector lever to "R" position.	Battery volt- age
		position		When setting selector lever to other positions.	1V or less
36	PNP switch "N" or "P" position	When setting selector lever to "N" or "P" position.	Battery volt- age		
			When setting selector lever to other positions.	1V or less	

ON	BOARD	DIAGNOSIS	LOGIC

NBAT0028S03


Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)
E : PNP SW/CIRC	TCM does not receive the correct volt-	Harness or connectors (The PNP switch circuit is open or
⊚ : P0705	age signal from the switch based on the gear position.	shorted.) • PNP switch


BT HA

SC

EL

Description (Cont'd)





DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

CAUTION:

NBAT0028S01

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode for "ENGINE" with CONSULT.
- 3) Start engine and maintain the following conditions for at least 5 consecutive seconds.

VHCL SPEED SE: 10 km/h (6 MPH) or more


THRTL POS SEN: More than 1.3V

Selector lever: D position (OD "ON" or "OFF")

With GST

Follow the procedure "With CONSULT".

Wiring Diagram — AT — PNP/SW





Diagnostic Procedure


NBAT0029 CHECK PNP SWITCH CIRCUIT (With CONSULT) (P) With CONSULT 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT. 3. Read out "P", "R", "N", "D", "2" and "1" position switches moving selector lever to each position. Check the signal of the selector lever position is indicated properly. ☆ NO FAIL 🗘 ☆ MONITOR R POSITION SW OFF D POSITION SW OFF 2 POSITION SW OFF 1 POSITION SW OFF ASCD•CRUISE OFF ASCD•OD CUT OFF KICKDOWN SW OFF POWER SHIFT SW OFF CLOSED THL/SW OFF **RECORD** SAT761I OK or NG GO TO 3. OK NG Check the following items: PNP switch Refer to "Component Inspection", AT-104. • Harness for short or open between ignition switch and PNP switch (Main harness) • Harness for short or open between PNP switch and TCM (Main harness) • Diode (P, N position)

SC


EL


Diagnostic Procedure (Cont'd)

CHECK PNP SWITCH CIRCUIT (Without CONSULT) (R) Without CONSULT GI 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Check voltage between TCM terminals 26, 27, 34, 35, 36 and ground while moving selector lever through each posi-MA Terminals Lever position 36 27 35 34 26 P, N В 0 0 0 0 0 R В 0 0 0 LC D 0 0 В 0 0 2 0 0 В 0 0 1 0 0 0 0 В EC MTBL0205 FE OCONNECTOR TCM 26, 27, 34, 35, 36 ΑT TF SAT517J PD Does battery voltage exist (B) or non-existent (0)? Yes GO TO 3. No Check the following items: PNP switch Refer to "Component Inspection", AT-104. SU • Harness for short or open between ignition switch and PNP switch (Main harness) • Harness for short or open between PNP switch and TCM (Main harness) • Diode (P, N position) **CHECK DTC** ST Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-100. OK or NG OK **INSPECTION END** NG 1. Perform TCM input/output signal inspection. BT 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. HA










Component Inspection PARK/NEUTRAL POSITION SWITCH


NBAT0030

1. Check continuity between terminals 1 and 2 and between terminals 3 and 4, 5, 6, 7, 8, 9 while moving manual shaft through each position.

Lever position	Terminal No.		
Р	1 - 2 3 - 4		
R	3 - 5		
N	1 - 2	3 - 6	
D	3 - 7		
2	3 - 8		
1	3 - 9		




- 2. If NG, check again with manual control linkage disconnected from manual shaft of A/T assembly. Refer to step 1.
- 3. If OK on step 2, adjust manual control linkage. Refer to AT-261.



- 4. If NG on step 2, remove PNP switch from A/T and check continuity of PNP switch terminals. Refer to step 1.
- 5. If OK on step 4, adjust PNP switch. Refer to AT-260.
- 6. If NG on step 4, replace PNP switch.

446

Description



Description

The A/T fluid temperature sensor detects the A/T fluid temperature and sends a signal to the TCM.

G

MA

EM

LC

EG

FE

AT

TF

PD

AX

SU


ST

BT

HA

SC

EL



CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.

NBAT0031S04

Monitor item	Condition	Specification
A/T fluid temperature sensor	Cold [20°C (68°F)] ↓ Hot [80°C (176°F)]	Approximately 1.5V ↓ Approximately 0.5V

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.

NBAT0031S02


Terminal No.	Wire color	Item		Condition	Judgement standard
42	В	Throttle position sensor (Ground)	(Con)	_	_
47	R	A/T fluid tempera- ture sensor		When ATF temperature is 20°C (68°F).	Approximately 1.5V
				When ATF temperature is 80°C (176°F).	Approximately 0.5V


ON BOARD DIAGNOSIS LOGIC

NBAT0031S03

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	
(E): ATF TEMP SEN/CIRC	ICM receives an excessively low or high	 Harness or connectors (The sensor circuit is open or shorted.) A/T fluid temperature sensor 	
	voltage from the sensor.		

Description (Cont'd)





DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

CAUTION:

NBAT0031S01

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT.
- Start engine and maintain the following conditions for at least 10 minutes (Total). (It is not necessary to maintain continuously.)

CMPS-RPM (REF): 450 rpm or more


VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.2V Selector lever: D position (OD "ON")

With GST

Follow the procedure "With CONSULT".

Wiring Diagram — AT — FTS



MAT728A

Diagnostic Procedure




NBAT0032

Diagnostic Procedure

CHECK A/T FLUID TEMPERATURE SENSOR WITH TERMINAL CORD ASSEMBLY

- Turn ignition switch to "OFF" position.
- 2. Disconnect terminal cord assembly connector on the right side of transfer assmebly.
- 3. Check resistance between terminals 8 and 9 when A/T is cold [20°C (68°F)].



SAT697I

Is resistance approx. 2.5 k Ω ?

11		
Yes (With CONSULT)		GO TO 2.
Yes (Without CONSULT)	>	GO TO 3.
No		 Remove oil pan. Check the following items: A/T fluid temperature sensor Refer to "Component Inspection", AT-109. Harness of terminal cord assembly for short or open

2 CHECK INPUT SIGNAL OF A/T FLUID TEMPERATURE SENSOR (With CONSULT)

- (P) With CONSULT
- 1. Start engine.
- 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT.
- 3. Read out the value of "FLUID TEMP SE".

Voltage:

Cold [20°C (68°F)] \rightarrow Hot [80°C (176°F)]: Approximately 1.5V \rightarrow 0.5V

☆MONITOR ☆NO FAIL V 0km/h VHCL/S SE.A/T VHCL/S SE•MTR 5km/h THRTL POS SEN 0.4V FLUID TEMP SE 1.2V BATTERY VOLT 13.4V ENGINE SPEED 1024rpm OVERDRIVE SW 0 NP/N POSI SW 0 N R POSITION SW OFF RECORD

SAT076H

OK or NG

OK	GO TO 4.
NG	Check the following item:
	Harness for short or open between TCM and terminal cord assembly (Main harness)

DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

GI

MA

LC

EC

FE

ΑT


TF

PD


AX

SU

Diagnostic Procedure (Cont'd)



4	4 CHECK DTC			
Perfo	orm Diagnostic Trouble Code	e (DTC) confirmation procedure, AT-106.	1	
		OK or NG	l	
OK	•	INSPECTION END	1	
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 		



Component Inspection A/T FLUID TEMPERATURE SENSOR

NBAT0033 NBAT0033S01

For removal, refer to AT-259.

 Check resistance between terminals 8 and 9 while changing temperature as shown at left.

Temperature °C (°F)	Resistance
20 (68)	Approximately 2.5 kΩ
80 (176)	Approximately 0.3 kΩ


EL

BT

HA

SC

Description



Description

The revolution sensor detects the revolution of the out put shaft parking pawl lock gear and emits a pulse signal. The pulse signal is sent to the TCM which converts it into vehicle speed.

TCM TERMINALS AND REFERENCE VALUE

NBAT0034S02

Remarks: Specification data are reference values.


Terminal No.	Wire color	Item	Condition		
29	W	Revolution sensor (Measure in AC range)	When vehicle cruises at 30 km/h (19 MPH).	1V or more Voltage rises gradually in response to vehicle speed.	
			When vehicle parks.	0V	
42	В	Throttle position sensor (Ground)	_	_	

ON BOARD DIAGNOSIS LOGIC

NBAT0034S03

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	
(E): VEH SPD SEN/CIR AT	TCM does not receive the proper voltage	Harness or connectors (The sensor circuit is open or shorted.) Revolution sensor	
	signal from the sensor.		

Description (Cont'd)



SELECT DIAG MODE SELF-DIAG_SULTS DATA MONITOR DTC WORK SUPPORT TCM PART NUMBER SAT385J

[SELECT SYSTEM ENGINE	
[]]		
[[[
L		SEF895K

SELECT DIAG MODE	
WORK SUPPORT	
SELF-DIAG RESULTS	
DATA MONITOR	
ACTIVE TEST	
DTC CONFIRMATION	
ECM PART NUMBER	
	SAT911I

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

 Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT

- Turn ignition switch "ON" and select "DATA MONITOR" mode for "A/T" with CONSULT.
- Drive vehicle and check for an increase of "VHCL/S SE-MTR" value.

If the check result is NG, go to "DIAGNOSTIC PROCEDURE", AT-198.

If the check result is OK, go to following step.

- 3) Select "DATA MONITOR" mode for "ENGINE" with CONSULT.
- 4) Start engine and maintain the following conditions for at least 5 consecutive seconds.

VHCL SPEED SE: 30 km/h (19 MPH) or more THRTL POS SEN: More than 1.2V Selector lever: D position (OD "ON")

Driving pattern: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test

If the check result is NG, go to "DIAGNOSTIC PROCEDURE", AT-113.

If the check result is OK, go to following step.

5) Maintain the following conditions for at least 5 consecutive seconds.

CMPS-RPM (REF): 3,500 rpm or more THRTL POS SEN: More than 1.2V Selector lever: D position (OD "ON")

Driving pattern: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

With GST

Follow the procedure "With CONSULT".

EM

MA

LC

EC

FE

AT

TF

PD

AVA

90

BR

ST

0 0

e RS


65

HA

SC

 $\mathbb{D}\mathbb{X}$







HA

SC


Diagnostic Procedure

	Diagnostic Procedure				
1	CHECK REVOLUTION SENSOR				
Refer	to "Component Insp	pection"	, AT-114.		
			OK or NG	M	
OK (V	Vith CONSULT)	•	GO TO 2.	1	
OK (V	Vithout CONSULT)	•	GO TO 3.		
NG			Renair or replace revolution sensor	1	










4	CHECK DTC				
Perfori	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-111.				
	OK or NG				
OK	>	INSPECTION END			
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 			



Component Inspection REVOLUTION SENSOR

NBAT0036

NBAT0036S01

- For removal, refer to AT-259.
- Check resistance between terminals 1, 2 and 3.

Termir	Resistance	
1	2	500 - 650Ω
2	3	No continuity
1	3	No continuity

DTC P0725 ENGINE SPEED SIGNAL



NBAT0037

NBAT0037S02



Description

The engine speed signal is sent from the ECM to the TCM.

G

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.

						MA
Terminal No.	Wire color	Item		Condition Judger stand		
			(Con)			EM
39	W/B	Engine speed signal		When engine runs at idle speed.	0.5 - 2.5V	LC

ON BOARD DIAGNOSIS LOGIC


NBAT0037S03

NBAT0037501

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	
🖹 : ENGINE SPEED SIG	TCM does not receive the proper voltage	Harness or connectors	
	signal from ECM.	(The sensor circuit is open or shorted.)	

AT

AX



SELECT DIAG MODE

WORK SUPPORT

SELF-DIAG RESULTS

DATA MONITOR

ACTIVE TEST

DTC CONFIRMATION

ECM PART NUMBER

SAT9111

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT

- Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT.
- 2) Start engine and maintain the following conditions for at least 10 consecutive seconds.

VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.2V Selector lever: D position (OD "ON")

With GST

Follow the procedure "With CONSULT".

B1

RS

SC

HA


 $\mathbb{D}\mathbb{X}$




Wiring Diagram — AT — ENGSS

NBAT0189

AT-ENGSS-01





Refer to last page (Foldout page).

MAT730A

DTC P0725 ENGINE SPEED SIGNAL

Diagnostic Procedure



RS

BT

HA

SC

EL

Diagnostic Procedure


			2.09.100.1000.00	NBAT0038	
1	1 CHECK DTC WITH ECM				GI
Perforn	m diagnostic test mo	ode II (self-diagnostic results) for engine control. Check ignition signal circuit condition.		
			OK or NG		MA
OK (W	ith CONSULT)		GO TO 2.		
OK (W	ithout CONSULT)		GO TO 3.		EM
NG		•	Check ignition signal circuit for engine control. Refer to EC-451, "IGNITION COIL & POWER TRANSISTOR".		

		POWER TRANSISTOR.		п		
				LC.		
2 CHECK	INPUT SIGNAL	(WITH CONSULT)				
(P) With CONSU	(F) With CONSULT					
1. Start engine.						
	NPUT SIGNALS	in "DATA MONITOR" mode for "A/T" with CONSULT.		FE		
		according to throttle position.				
C .		☆MONITOR ☆NO FAIL		AT		
		VHCL/S SE•A/T 0km/h VHCL/S SE•MTR 5km/h				
		THRTL POS SEN 0.4V		TF		
		FLUID TEMP SE 1.2V BATTERY VOLT 13.4V		шш		
		ENGINE SPEED 1024rpm OVERDRIVE SW O N				
		P/N POSI SW O N		PD		
		RECORD				
		NECOND		AX		
			SAT076H			
		Does battery voltage (idle speed) 0.5 - 2.5V?		SU		
Yes	•	GO TO 4.				
No	•	Check the following items:		BR		
		Harness for short or open between TCM and ECM				
		ResistorIgnition coil				
		Refer to EC-451, "IGNITION COIL & POWER TRANSISTOR".		ST		

AT-117

DTC P0725 ENGINE SPEED SIGNAL

Diagnostic Procedure (Cont'd)



4	CHECK DTC					
Perfor	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-115.					
	OK or NG					
ОК	>	INSPECTION END				
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 				

Description

Description

This is an OBD-II self-diagnostic item and not available in TCM self-diagnosis.

This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.

This malfunction is detected when the A/T does not shift into first gear position as instructed by the TCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

MA

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

TCM TERMINALS AND REFERENCE VALUE

NBATO039S02

Judgement

standard Battery voltage

1V or less

Battery voltage

1V or less

Remarks: Specification data are reference values.

	Temane. Openioation data are reference values.								
	Terminal No.	Wire color	Item	Condition					
	44	L/W	./W Shift solenoid valve A		When shift solenoid valve A operates. (When driving in " D_1 " or " D_4 ".)				
11	11				When shift solenoid valve A does not operate (When driving in " D_2 " or " D_3 ".)				
	40	L/R	Shift solenoid valve		When shift solenoid valve B operates. (When driving in "D ₁ " or "D ₂ ".)				
1	12		В		When shift solenoid valve B does not operate (When driving in "D ₃ " or "D ₄ ".)				
		-	-						

AT

AX

ON BOARD DIAGNOSIS LOGIC

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by TCM as follows:

Torque converter slip ratio = $A \times C/B$

A: Output shaft revolution signal from revolution sensor

B: Engine speed signal from ECM

ST

C: Gear ratio determined as gear position which TCM supposes If the actual gear position is higher than the position (1st) supposed by TCM, the slip ratio will be more than normal. In case the ratio exceeds the specified value, TCM judges this diagnosis malfunc-

This malfunction will be caused when either shift solenoid valve A is stuck open or shift solenoid valve B is stuck open.

Gear position supposed by TCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve A stuck open	2*	2	3	3
In case of gear position with shift solenoid valve B stuck open	4*	3	3	4

HA

EL


Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)
(: A/T 1ST GR FNCTN	A/T cannot be shifted to the 1st gear posi-	Shift solenoid valve AShift solenoid valve B
⑤ : P0731	1	Each clutch Hydraulic control circuit


^{*:} P0731 is detected.


Description (Cont'd)



NBAT0039S01







DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

 Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITIONS:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT

- Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT.
- Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- 3) Select "1ST GR FNCTN P0731" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT and touch "START".
- Accelerate vehicle to 20 to 25 km/h (12 to 16 MPH) under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 1.0/8 (at all times during step 4)

Selector lever: D position (OD "ON")

- Check that "GEAR" shows "2" after releasing pedal.
- 5) Depress accelerator pedal to WOT (more than 7.0/8 of "THROTTLE POSI") quickly from a speed of 20 to 25 km/h (12 to 16 MPH) until "TESTING" changes to "STOP VEHICLE" or "COMPLETED". (It will take approximately 3 seconds.) If the check result NG appears on CONSULT screen, go to "DIAGNOSTIC PROCEDURE", AT-123. If "STOP VEHICLE" appears on CONSULT screen, go to the following step.
- Check that "GEAR" shows "1" when depressing accelerator pedal to WOT.
- If "TESTING" does not appear on CONSULT for a long time, select "SELF-DIAG RESULTS" for "ENGINE". In case a 1st trip DTC other than P0731 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
- Stop vehicle.
- 7) Follow the instruction displayed. (Check for normal shifting referring to the table below.)

Vehicle condition	Gear on actual transmission shift pattern when screen is changed to 1 \rightarrow 2 \rightarrow 3 \rightarrow 4	
No malfunction exists	$1 \rightarrow 2 \rightarrow 3 \rightarrow 4$	

Description (Cont'd)

Malfunction for P0731 exists.	$2 \rightarrow 2 \rightarrow 3 \rightarrow 3$
Manufiction for F0731 exists.	$4 \rightarrow 3 \rightarrow 3 \rightarrow 4$

er MA

8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "DIAGNOSTIC PROCEDURE".) Refer to "DIAGNOSTIC PROCEDURE", AT-123. Refer to shift schedule, AT-339.

DANY=7

GI

With GST

Follow the procedure "With CONSULT".

EM

LC

EG

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC


EL





Wiring Diagram — AT — 1ST

NBAT0190

AT-1STSIG-01












*: This connector is not shown in "HARNESS LAYOUT" in EL section.

TF

EL


Diagnostic Procedure



GO TO 2.


OK


NG



3	3 CHECK DTC					
Perfo	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-120.					
	OK or NG					
ОК	OK INSPECTION END					
NG	>	Check control valve again. Repair or replace control valve assembly.				

Component Inspection





Component Inspection SHIFT SOLENOID VALVE A AND B

=NBAT0041

NBAT0041S01

For removal, refer to AT-259.

Resistance Check

Check resistance between terminals (3 or 2) and ground.

Solenoid valve	Terminal No.		Resistance (Approx.)	
Shift solenoid valve A	3	Cround	20 400	
Shift solenoid valve B 2		Ground	20 - 40Ω	

Operation Check

NBAT0041S0102

Check solenoid valve by listening for its operating sound while applying battery voltage to the terminals (3 or 2) and ground.

Description

Description

This is an OBD-II self-diagnostic item and not available in TCM self-diagnosis.

This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.

This malfunction is detected when the A/T does not shift into second gear position as instructed by the TCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.



4 Gear position 1 ON (Closed) OFF (Open) OFF (Open) ON (Closed) Shift solenoid valve A Shift solenoid valve B ON (Closed) ON (Closed) OFF (Open) OFF (Open)



LC

AT

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.

IBAT0042S02	

Terminal No.	Wire color	Item		Judgement standard	
12	I I/R I	Shift solenoid		When shift solenoid valve B operates. (When driving in " D_1 " or " D_2 ".)	Battery volt- age
		valve B		When shift solenoid valve B does not operate. (When driving in "D ₃ " or "D ₄ ".)	1V or less

ON BOARD DIAGNOSIS LOGIC

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by TCM as follows: Torque converter slip ratio = A x C/B



A: Output shaft revolution signal from revolution sensor

B: Engine speed signal from ECM

AX

C: Gear ratio determined as gear position which TCM supposes If the actual gear position is higher than the position (2nd) supposed by TCM, the slip ratio will be more than normal. In case the ratio exceeds the specified value, TCM judges this diagnosis malfunction.



This malfunction will be caused when shift solenoid valve B is stuck open.

Gear position supposed by TCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve B stuck open	4	3*	3	4



*: P0732 is detected.

Ш	ПG	,


Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	• (
(E): A/T 2ND GR FNCTN	A/T cannot be shifted to the 2nd gear	Shift solenoid valve B Each clutch	
	position even if electrical circuit is good.	Hydraulic control circuit	


SC


EL

Description (Cont'd)









DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITIONS:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT

- Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT.
- Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- 3) Select "2ND GR FNCTN P0732" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT and touch "START".
- Accelerate vehicle to 52 to 57 km/h (32 to 35 MPH) under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 1.0/8 (at all times during step 4)

Selector lever: D position (OD "ON")

- Check that "GEAR" shows "3" or "4" after releasing pedal.
- 5) Depress accelerator pedal to WOT (more than 7.0/8 of "THROTTLE POSI") quickly from a speed of 52 to 57 km/h (32 to 35 MPH) until "TESTING" changes to "STOP VEHICLE" or "COMPLETED". (It will take approximately 3 seconds.) If the check result NG appears on CONSULT screen, go to "DIAGNOSTIC PROCEDURE", AT-129. If "STOP VEHICLE" appears on CONSULT screen, go to following step.
- Check that "GEAR" shows "2" when depressing accelerator pedal to WOT.
- If "TESTING" does not appear on CONSULT for a long time, select "SELF-DIAG RESULTS" for "ENGINE". In case a 1st trip DTC other than P0732 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
- Stop vehicle.
- 7) Follow the instruction displayed. (Check for normal shifting referring to the table below.)

Vehicle condition	Gear on actual transmission shift pattern when screen is changed to 1 \rightarrow 2 \rightarrow 3 \rightarrow 4	
No malfunction exists	$1 \rightarrow 2 \rightarrow 3 \rightarrow 4$	
Malfunction for P0732 exists.	$4 \rightarrow 3 \rightarrow 3 \rightarrow 4$	

Description (Cont'd)

8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "DIAGNOSTIC PROCEDURE".) Refer to "DIAGNOSTIC PROCEDURE", AT-129. Refer to shift schedule, AT-339.

GI

With GST

Follow the procedure "With CONSULT".

 $\mathbb{M}\mathbb{A}$

EM

LC

EC

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC


EL





Wiring Diagram — AT — 2ND

NBAT0191

AT-2NDSIG-01











 \bigstar : This connector is not shown in "HARNESS LAYOUT" in EL section.

ΑT

PD

AX


SU


ST

BT

HA


Diagnostic Procedure






<u> </u>	Repair control valve assembly.	
CHECK DTC		
m Diagnostic Trouble Co	de (DTC) confirmation procedure, AT-126.	
	OK or NG	
>	INSPECTION END	
•	Check control valve again. Repair or replace control valve assembly.	
	CHECK DTC n Diagnostic Trouble Co	CHECK DTC In Diagnostic Trouble Code (DTC) confirmation procedure, AT-126. OK or NG INSPECTION END

Component Inspection





Component Inspection SHIFT SOLENOID VALVE B

NBAT0044

NBAT0044S01

For removal, refer to AT-259.

Resistance Check

NBAT0044S0101

Check resistance between terminal 2 and ground.

Solenoid valve	Terminal No.		Resistance (Approx.)
Shift solenoid valve B	2	Ground	20 - 40Ω

Operation Check

Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal 2 and ground.

Description

Description

This is an OBD-II self-diagnostic item and not available in TCM self-diagnosis.

This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.

This malfunction is detected when the A/T does not shift into third gear position as instructed by the TCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, malfunctioning servo piston or brake band, etc.

MA

Gear position 4 Shift solenoid valve A ON (Closed) OFF (Open) OFF (Open) ON (Closed) Shift solenoid valve B ON (Closed) ON (Closed) OFF (Open) OFF (Open)

LC

EC

TCM TERMINALS AND REFERENCE VALUE

NBAT0045S02

Remarks: Specification data are reference values.

Terminal No.	Wire color	Item	Condition		Judgement standard
11	L/W	Shift solenoid		When shift solenoid valve A operates. (When driving in " D_1 " or " D_4 ".)	Battery volt- age
11	L/VV	valve A	E OPROZ	When shift solenoid valve A does not operate. (When driving in " D_2 " or " D_3 ".)	1V or less

ON BOARD DIAGNOSIS LOGIC

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by TCM as follows:

Torque converter slip ratio = A x C/B

A: Output shaft revolution signal from revolution sensor

B: Engine speed signal from ECM

C: Gear ratio determined as gear position which TCM supposes If the actual gear position is higher than the position (3rd) supposed by TCM, the slip ratio will be more than normal. In case the ratio exceeds the specified value, TCM judges this diagnosis malfunc-

This malfunction will be caused when shift solenoid valve A is stuck closed.

Gear position supposed by TCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve A stuck closed	1	1	4*	4


SC


^{*:} P0733 is detected.


Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	
🖹 : A/T 3RD GR FNCTN	A/I cannot be shifted to the 3rd gear	Shift solenoid valve AEach clutch	
		Hydraulic control circuit	

Description (Cont'd)









DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

 Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITIONS:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT

- Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT.
- Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- 3) Select "3RD GR FNCTN P0733" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT and touch "START".
- Accelerate vehicle to 75 to 90 km/h (47 to 56 MPH) under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 1.0/8 (at all times during step 4)

Selector lever: D position (OD "ON")

- Check that "GEAR" shows "4" after releasing pedal.
- 5) Depress accelerator pedal steadily with 3.5/8 4.5/8 of "THROTTLE POSI" from a speed of 75 to 90 km/h (47 to 56 MPH) until "TESTING" changes to "STOP VEHICLE" or "COM-PLETED". (It will take approximately 3 seconds.) If the check result NG appears on CONSULT screen, go to "DIAGNOSTIC PROCEDURE", AT-135. If "STOP VEHICLE" appears on CONSULT screen, go to following step.
- Check that "GEAR" shows "3" when depressing accelerator pedal with 3.5/8 - 4.5/8 of "THROTTLE POSI".
- If "TESTING" does not appear on CONSULT for a long time, select "SELF-DIAG RESULTS" for "ENGINE". In case a 1st trip DTC other than P0733 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
- Stop vehicle.
- 7) Follow the instruction displayed. (Check for normal shifting referring to the table below.)

Vehicle condition	Gear on actual transmission shift pattern when screen is changed to 1 \rightarrow 2 \rightarrow 3 \rightarrow 4
No malfunction exists.	$1 \rightarrow 2 \rightarrow 3 \rightarrow 4$
Malfunction for P0733 exists.	$1 \to 1 \to 4 \to 4$

Description (Cont'd)

8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "DIAGNOSTIC PROCEDURE".) Refer to "DIAGNOSTIC PROCEDURE", AT-135.

Refer to shift schedule, AT-339.

 \mathbb{G}

With GST

Follow the procedure "With CONSULT".

MA

LC

EC

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC


EL





Wiring Diagram — AT — 3RD

NBAT0192

AT-3RDSIG-01











*: This connector is not shown in "HARNESS LAYOUT" in EL section.

FE

TF

PD

AX

SU

ST


BT

HA

SC

SAT653I

Diagnostic Procedure



OK or NG

BAT

OK •	GO TO 2.
NG •	Repair or replace shift solenoid valve assembly.

CHECK CONTROL VALVE 1. Disassemble control valve assembly. Refer to "Control Valve Assembly", AT-284. 2. Check to ensure that: • Valve, sleeve and plug slide along valve bore under their own weight. • Valve, sleeve and plug are free from burrs, dents and scratches. • Control valve springs are free from damage, deformation and fatigue. • Hydraulic line is free from obstacles. SAT367H OK or NG


			_
3	CHECK DTC		
Perfo	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-132.		
	OK or NG		
OK	OK INSPECTION END		
NG	•	Check control valve again. Repair or replace control valve assembly.	


GO TO 3.

Repair control valve assembly.

OK NG

Component Inspection





Component Inspection SHIFT SOLENOID VALVE A

NBAT0047

NBAT0047S01

For removal, refer to AT-259.

Resistance Check

Check resistance between terminal 3 and ground.

 Solenoid valve
 Terminal No.
 Resistance (Approx.)

 Shift solenoid valve A
 3
 Ground
 20 - 40Ω

Operation Check

NRAT004750102

 Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal 3 and ground.





This is an OBD-II self-diagnostic item and not available in TCM self-diagnosis.



This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.

This malfunction is detected when the A/T does not shift into fourth gear position or the torque converter clutch does not lock up as instructed by the TCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, malfunctioning oil pump or torque converter clutch, etc.



CONSULT REFERENCE VALUE IN DATA MONITOR MODE

EC

FE

EM

Remarks: Specification data are reference values.

NBAT0048S04

Monitor item	C	Condition		ification
Torque converter clutch so noid valve duty	DIE-	Lock-up "OFF" ↓ Lock-up "ON"		mately 4% ↓ nately 94%
Line pressure solenoid va duty	ive	Small throttle opening (Low line pressure) Large throttle opening (High line pressure)		nately 24% ↓ nately 95%
Gear position	1	2	3	4
Shift solenoid valve A ON (Closed)		OFF (Open)	OFF (Open)	ON (Closed)

775	

AT

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)



TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.

NBAT0048S02

Terminal No.	Wire color	Item		Judgement standard	B	
4	0.00	Line pressure		When releasing accelerator pedal after warming up engine.	1.5 - 2.5V	- S
1	G/Y	solenoid valve	CON	When depressing accelerator pedal fully after warming up engine.	0.5V or less	R
0	DD W	Line pressure solenoid valve		When releasing accelerator pedal after warming up engine.	5 - 14V	- _ B'
2	2 BR/Y (with dropping resistor)	(with dropping When de	When depressing accelerator pedal fully after warming up engine.	0.5V or less		
44	1.00/	Shift solenoid		When shift solenoid valve A operates. (When driving in "D ₁ " or "D ₄ ".)	Battery volt- age	- 1
11	L/W	valve A		When shift solenoid valve A does not operate. (When driving in "D ₂ " or "D ₃ ".)	1V or less	- \$
40	1.75	Shift solenoid		When shift solenoid valve B operates. (When driving in "D ₁ " or "D ₂ ".)	Battery volt- age	- E
12	L/R	valve B		When shift solenoid valve B does not operate. (When driving in "D ₃ " or "D ₄ ".)	1V or less	

ON BOARD DIAGNOSIS LOGIC

=NBAT0048S03

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by TCM as follows:

Torque converter slip ratio = $A \times C/B$

A: Output shaft revolution signal from revolution sensor

B: Engine speed signal from ECM

C: Gear ratio determined as gear position which TCM supposes If the actual gear position is much lower than the position (4th) supposed by TCM, the slip ratio will be much less than normal. In case the ratio does not reach the specified value, TCM judges this diagnosis malfunction.


This malfunction will be caused when shift solenoid valve B is stuck closed.


Gear position supposed by TCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve B stuck closed	1	2	2	1*


^{*:} P0734 is detected.

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)
(E): A/T 4TH GR FNCTN	A/T cannot be shifted to the 4th gear position even if electrical circuit is good.	Shift solenoid valve A Shift solenoid valve B
		Line pressure solenoid valveEach clutchHydraulic control circuit

Description (Cont'd)







DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

CAUTION:

Always drive vehicle at a safe speed.

 Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITIONS:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT

 Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT.

2) Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

Select "4TH GR FNCTN P0734" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT and touch "START".

 Accelerate vehicle to 45 to 55 km/h (28 to 34 MPH) under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 5.5/8 (at all times during step 4)

Selector lever: D position (OD "ON")

- Check that "GEAR" shows "3" after releasing pedal.
- 5) Depress accelerator pedal steadily with 1.0/8 2.0/8 of "THROTTLE POSI" from a speed of 45 to 55 km/h (28 to 34 MPH) until "TESTING" has turned to "STOP VEHICLE" or "COMPLETED". (It will take approximately 3 seconds.)

 If the check result NG appears on CONSULT screen, go to "DIAGNOSTIC PROCEDURE", AT-142.

 If "STOP VEHICLE" appears on CONSULT screen, go to fol-

Check that "GEAR" shows "4" when depressing accelerator pedal with 1.0/8 - 2.0/8 of "THROTTLE POSI".

• If "TESTING" does not appear on CONSULT for a long time, select "SELF-DIAG RESULTS" for "ENGINE". In case a 1st trip DTC other than P0734 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".

Stop vehicle.

lowing step.

7) Follow the instruction displayed. (Check for normal shifting referring to the table below.)

Vehicle condition	Gear on actual transmission shift pattern when screen is changed to 1 \rightarrow 2 \rightarrow 3 \rightarrow 4
No malfunction exists	$1 \rightarrow 2 \rightarrow 3 \rightarrow 4$
Malfunction for P0734 exists.	$1 \to 2 \to 2 \to 1$



MA

LC



































Description (Cont'd)

- 8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "DIAGNOSTIC PROCEDURE".) Refer to "DIAGNOSTIC PROCEDURE", AT-142. Refer to shift schedule, AT-339.
- **With GST**


Follow the procedure "With CONSULT".

Wiring Diagram — AT — 4TH

Wiring Diagram — AT — 4TH

NBAT0193

MAT734A





Diagnostic Procedure

No

Diagnostic Procedure NBAT0049 CHECK SHIFT UP (D₃ TO D₄) During "Cruise test – Part 1", AT-71. Does A/T shift from D₃ to D₄ at the specified speed? Accelerator pedal Halfway SAT988H Yes or No Yes GO TO 9. GO TO 2.

2	CHECK LINE PRESSURE				
Perfor	Perform line pressure test. Refer to AT-62.				
	OK or NG				
ОК	OK ▶ GO TO 3.				
NG	•	GO TO 6.			

GI

MA

LC

EC

FE


ΑT


TF

PD

AX

Diagnostic Procedure (Cont'd)








Diagnostic Procedure (Cont'd)

5	CHECK SHIFT UP (D ₃ TO D ₄)				
Does	Does A/T shift from D ₃ to D ₄ at the specified speed?				
	Yes or No				
Yes	Yes ▶ GO TO 9.				
No	No Check control valve again. Repair or replace control valve assembly.				



DTC P0734 IMPROPER SHIFTING TO 4TH GEAR POSITION



PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

Diagnostic Procedure (Cont'd)



8	CHECK SHIFT UP (D ₃ TO D ₄)			
Does	Does A/T shift from D ₃ to D ₄ at the specified speed?			
	OK or NG			
ОК	OK ▶ GO TO 9.			
NG	NG Check control valve again. Repair or replace control valve assembly.			


9	CHECK DTC			
Perfor	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-139.			
	OK or NG			
OK	OK INSPECTION END			
NG	NG Perform "Cruise test — Part 1" again and return to the start point of this flow chart.			

AT-145

DTC P0734 IMPROPER SHIFTING TO 4TH GEAR POSITION

Component Inspection





Component Inspection SOLENOID VALVES

NBAT0050

NBAT0050S01

For removal, refer to AT-259.

Resistance Check

NBAT0050S0101


• Check resistance between terminals (3, 2 or 6) and ground.

Solenoid valve	Solenoid valve Term		Resistance (Approx.)
Shift solenoid valve A	3		20 - 40Ω
Shift solenoid valve B	2	Ground	20 - 4002
Line pressure solenoid valve	6		2.5 - 5Ω

Operation Check


VBAT0050S0102

 Check solenoid valve by listening for its operating sound while applying battery voltage to the terminals (3, 2 or 6) and ground.



DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

Description



Description

The torque converter clutch solenoid valve is activated, with the gear in "D4", by the TCM in response to signals sent from the vehicle speed and throttle position sensors. Lock-up piston operation will then be controlled.

Lock-up operation, however, is prohibited when A/T fluid temperature is too low.

MA

When the accelerator pedal is depressed (less than 2/8) in lock-up condition, the engine speed should not change abruptly. If there is a big jump in engine speed, there is no lock-up.

EM

LC

EC

FE

AT

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.

NBAT0051S02

Monitor item	Condition	Specification
Torque converter clutch solenoid valve duty	Lock-up "OFF" ↓ Lock-up "ON"	Approximately 4% ↓ Approximately 94%

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.

NBAT0051S03

TF

AX

Terminal No.	Wire color	Item	Condition		Judgement standard
3	G/OR	Torque converter clutch solenoid		When A/T performs lock-up.	8 - 15V
3	G/OR	valve		When A/T does not perform lock-up.	1V or less

ON BOARD DIAGNOSIS LOGIC

NBAT0051S04

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)
(E): TCC SOLENOID/CIRC	TCM detects an improper voltage drop when it tires to operate the solenoid	Harness or connectors (The solenoid circuit is open or shorted.)
	valve.	Torque converter clutch solenoid valve

ST


HA SC

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE



Description (Cont'd)

SELECT SYSTEM ENGINE	
	SEF895K



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NOTE:

NBAT0051S0

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

- (P) With CONSULT
- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode for "ENGINE" with CONSULT and wait at least 1 second.

With GST

Follow the procedure "With CONSULT".

Wiring Diagram — AT — TCV

NBAT0194

AT-TCV-01

GI

MA

EM

LC

EC

FE

ΑT

TF

PD

AX

SU

BR

ST


RS


BT


HA

SC

EL








7 B91

TORQUE CONVERTER CLUTCH SOLENOID VALVE





*: This connector is not shown in "HARNESS LAYOUT" in EL section.

MAT735A

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

Diagnostic Procedure



NBAT0052

SAT156J


Diagnostic Procedure

Turn ignition switch to "OFF" position.

CHECK GROUND CIRCUIT

2. Disconnect terminal cord assembly connector on the right side of transfer assembly.

3. Check resistance between terminal 7 and ground.




Is resistance approx. 10 - 20 Ω ?

Yes	GO TO 2.
No	 Remove oil pan. Refer to AT-259. Check the following items: Torque converter clutch solenoid valve Refer to "Component Inspection", AT-151. Harness of terminal cord assembly for short or open

2 CHECK RESISTANCE

- 1. Turn ignition switch to "OFF" position.
- 2. Disconnect TCM harness connector.
- 3. Check resistance between terminal 7 and TCM harness connector terminal 3.



SAT521J

If OK, check harness for short to ground and short to power.

Is resistance approx. 0Ω ?

Yes	GO TO 3.
No •	Repair open circuit or short to ground or short to power in harness or connectors.

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

GI


MA


LC

NBAT0053S0101

Diagnostic Procedure (Cont'd)

3	CHECK DTC		
Perfor	m Diagnostic Trouble Code	e (DTC) confirmation procedure, AT-148.]
OK or NG			l
OK	•	INSPECTION END]
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 	





Component Inspection

TORQUE CONVERTER CLUTCH SOLENOID VALVE

• For removal, refer to AT-259.

Resistance Check

• Check resistance between terminal 7 and ground.

Solenoid valve	Terminal No.		Resistance (Approx.)
Torque converter clutch solenoid valve	7	Ground	10 - 20Ω

Operation Check

 Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal 7 and ground.

0.5/7

PD

TF

 $\mathbb{A}\mathbb{X}$

SU

ST

ചര

BT

HA

SC

EL



Description

- This is an OBD-II self-diagnostic item and not available in TCM self-diagnosis.
- This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into fourth gear position or the torque converter clutch does not lock up as instructed by the TCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, malfunctioning oil pump or torque converter clutch, etc.

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.

NBAT0054S02

Monitor item	Condition	Specification
Torque converter clutch solenoid valve duty	Lock-up "OFF" ↓ Lock-up "ON"	Approximately 4% ↓ Approximately 94%

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.

NBAT0054S03

Terminal No.	Wire color	Item		Condition	Judgement standard
1	0.04	Line pressure solenoid valve		When releasing accelerator pedal after warming up engine.	1.5 - 2.5V
ı	G/Y			When depressing accelerator pedal fully after warming up engine.	0.5V or less
2	2 BR/Y solenoid val	Line pressure solenoid valve		When releasing accelerator pedal after warming up engine.	5 - 14V
2		(with dropping resistor)		When depressing accelerator pedal fully after warming up engine.	0.5V or less
2	C/OB	Torque converter		When A/T performs lock-up.	8 - 15V
3	G/OR	G/OR clutch solenoid valve	EOPROL	When A/T does not perform lock- up.	1V or less

ON BOARD DIAGNOSIS LOGIC

NBAT0054S04

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by TCM as follows:

Torque converter slip ratio = $A \times C/B$

A: Output shaft revolution signal from revolution sensor

B: Engine speed signal from ECM

C: Gear ratio determined as gear position which TCM supposes If the actual gear position is much lower than the position (4th) supposed by TCM, the slip ratio will be much less than normal. In case the ratio does not reach the specified value, TCM judges this diagnosis malfunction.

This malfunction will be caused when shift solenoid valve B is stuck closed.


Description (Cont'd


Gear position supposed by TCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve B stuck closed	1	2	2	1*

*: P0744 is detected.

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	E
(E): A/T TCC S/V FNCTN		Line pressure solenoid valve Torque converter clutch solenoid valve	_
	1	Each clutchHydraulic control circuit	L(

SELECT SYSTEM **ENGINE** A/T SAT974H





DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION **PROCEDURE** NRAT0054S01

CAUTION:

Always drive vehicle at a safe speed.

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT

- Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT.
- Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- Select "TCC S/V FNCTN P0744" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT and touch "START".
- Accelerate vehicle to more than 80 km/h (50 MPH) and maintain the following condition continuously until "TESTING" has turned to "COMPLETED". (It will take approximately 30 seconds after "TESTING" shows.)

THROTTLE POSI: 1.0/8 - 2.0/8 (at all times during step 4) Selector lever: D position (OD "ON")

TCC S/V DUTY: More than 94%

VHCL/S SE-A/T: Constant speed of more than 80 km/h (50 MPH)

- Check that "GEAR" shows "4".
- For shift schedule, refer to SDS, AT-339.

MA

AT

PD

AX

HA

SC

EL

AT-153



- If "TESTING" does not appear on CONSULT for a long time, select "SELF-DIAG RESULTS". In case a 1st trip DTC other than P0744 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
- 5) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "DIAGNOSTIC PROCEDURE".) Refer to "DIAGNOSTIC PROCEDURE", AT-156. Refer to shift schedule, AT-339.
- **With GST**

Follow the procedure "With CONSULT".

Wiring Diagram — AT — TCCSIG

Wiring Diagram — AT — TCCSIG

NBAT0195

GI

MA

EM

LC


EC

FE


ΑT




: Detectable line for DTC



TF PD AXSU BR ST BT Refer to last page (Foldout page). HA







TORQUE

CONVERTER CLUTCH SOLENOID VALVE

M1), E1

SC

EL

7 B91 6 2 B93 B64)

*: This connector is not shown in "HARNESS LAYOUT" in EL section.

MAT736A

PRESSURE SOLENOID VALVE




Diagnostic Procedure

The composition of the compositi

2	CHECK LINE PRESSURE			
Perfor	Perform line pressure test. Refer to AT-62.			
	OK or NG			
ОК	OK ▶ GO TO 3.			
NG	•	GO TO 6.		

3 CHECK CONTROL VALVE

- 1. Disassemble control valve assembly. Refer to AT-284.
- 2. Check to ensure that:
- Valve, sleeve and plug slide along valve bore under their own weight.
- Valve, sleeve and plug are free from burrs, dents and scratches.
- Control valve springs are free from damage, deformation and fatigue.
- Hydraulic line is free from obstacles.



SAT367H

OK or NG

OK •	>	GO TO 4.
NG •	>	Repair control valve.



GI

MA

EM

LC

EC

FE

ΑT

TF

PD

AX

SU

BR

ST

BT

HA


SC

EL

Diagnostic Procedure (Cont'd)

4	4 CHECK SHIFT UP (D ₃ TO D ₄)			
Does A/T shift from D ₃ to D ₄ at the specified speed?				
	Yes or No			
Yes	Yes DO TO 5.			
No	•	Check control valve again. Repair or replace control valve assembly.		

5	CHECK DTC		
Perfor	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-153.		
	OK or NG		
OK	>	INSPECTION END	
NG	>	GO TO 10. And check for proper lock-up.	



IDX



Diagnostic Procedure (Cont'd)

OK NG

7 CHECK CONTROL VALVE 1. Disassemble control valve assembly. Refer to AT-284. 2. Check line pressure circuit valves for sticking. • Pressure regulator valve • Pilot valve • Pressure modifier valve SAT367H OK or NG

8	CHECK SHIFT UP (D ₃ TO D ₄)		
Does /	Does A/T shift from D ₃ to D ₄ at the specified speed?		
	Yes or No		
Yes	>	GO TO 9.	
No	>	Check control valve again. Repair or replace control valve assembly.	

GO TO 8.

Repair control valve.

9	CHECK DTC				
Perfor	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-153.				
	OK or NG				
OK	>	INSPECTION END			
NG	>	GO TO 10.And check for proper lock-up.			

10	CHECK LOCK-UP CONDITION			
	During "Cruise test – Part 1", AT-71, Does A/T perform lock-up at the specified speed?			
	Yes or No			
Yes	Yes Perform "Cruise test – Part 1" again and return to the start point of this flow chart.			
No	>	GO TO 11.		

11	1 CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE		
2. Che	 Remove control valve assembly. Refer to AT-259. Check torque converter clutch solenoid valve operation. Refer to AT-160. 		
	OK or NG		
OK	>	GO TO 12.	
NG	>	Replace solenoid valve assembly.	



G[

MA

EM

LC

EC

FE

ΑT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL

Diagnostic Procedure (Cont'd)




13	3 CHECK LOCK-UP CONDITION			
Does	Does A/T perform lock-up at the specified speed?			
	Yes or No			
Yes	es ► GO TO 14.			
No	>	Check control valve again. Repair or replace control valve assembly.		

14	CHECK DTC					
Perfori	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-153.					
	OK or NG					
OK	OK INSPECTION END					
NG	NG Perform "Cruise test — Part 1" again and return to the start point of this flow chart.					

AT-159





Component Inspection SOLENOID VALVES

NBAT0056

NBAT0056S01

For removal, refer to AT-259.

Resistance Check

Check resistance between terminals (6 or 7) and ground.

Solenoid valve	Terminal No.		Resistance (Approx.)
Line pressure solenoid valve	6		2.5 - 5Ω
Torque converter clutch solenoid valve	7	Ground	10 - 20Ω


-Overrun clutch solenoid valve Shift solenoid valve A Shift solenoid valve B Line pressure solenoid valve Torque converter clutch solenoid valve FUSE (FUSE) BAT SAT158J

Operation Check

Check solenoid valve by listening for its operating sound while applying battery voltage to the terminals (6 or 7) and ground.

Description





Description

The line pressure solenoid valve regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM.

The line pressure duty cycle value is not consistent when the closed throttle position switch is "ON". To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position switch is "OFF".



MA

EM

LC

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.

NBAT0057S02

EC

Monitor item	Condition	Specification	
Line pressure solenoid valve duty	Small throttle opening (Low line pressure) Large throttle opening (High line pressure)	Approximately 24% ↓ Approximately 95%	

NOTE:

The line pressure duty cycle value is not consistent when the closed throttle position switch is "ON". To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position switch is "OFF".

TF

PD

AX

AT

Remarks: S _l	pecification da	ata are reference va	lues.		NBA10057503
Terminal No.	Wire color	Item		Condition	Judgement standard
		Line proceure		When releasing accelerator pedal after warming up engine.	1.5 - 2.5V

Line pressure G/Y solenoid valve When depressing accelerator pedal fully after 0.5V or less warming up engine. When releasing accelerator pedal after warm-Line pressure 5 - 14V ing up engine. solenoid valve 2 BR/Y (with dropping When depressing accelerator pedal fully after resistor) 0.5V or less warming up engine.

ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)
: L/PRESS SOL/CIRC	TCM detects an improper voltage drop when it tries to operate the solenoid	Harness or connectors (The solenoid circuit is open or shorted.)
圖: P0745	valve.	Line pressure solenoid valve

NBAT0057S04







Description (Cont'd)

SELECT SYSTEM ENGINE	
	SEF895K

SELECT DIAG MODE	▼	
WORK SUPPORT		
SELF-DIAG RESULTS		
DATA MONITOR		
ACTIVE TEST		
DTC CONFIRMATION		
ECM PART NUMBER		
		SAT911I

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NOTE:

NBAT0057S0

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.


(II) With CONSULT

- Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT.
- Depress accelerator pedal completely and wait at least 1 second.

With GST

Follow the procedure "With CONSULT".

Wiring Diagram — AT — LPSV






NBAT0058

Diagnostic Procedure

CHECK GROUND CIRCUIT

- 1. Turn ignition switch to "OFF" position.
- 2. Disconnect terminal cord assembly connector on the right side of transfer assembly.
- 3. Check resistance between terminal 6 and ground.




SAT162J

Is resistance approx. 2.5 - 5Ω ?

Yes	GO TO 2.
No	 Remove control valve assembly. Refer to AT-259. Check the following items: Line pressure solenoid valve Refer to "Component Inspection", AT-165. Harness of terminal cord assembly for short or open

2 CHECK POWER SOURCE CIRCUIT

- 1. Turn ignition switch to "OFF" position.
- 2. Disconnect TCM harness connector.
- 3. Check resistance between terminal 6 and TCM harness connector terminal 2.



SAT522J

Is resistance approx. 11.2 - 12.8 Ω ?

Yes	GO TO 3.
No •	Check the following items: Dropping resistor Refer to "Component Inspection", AT-165. Harness for short or open between TCM terminal 2 and terminal cord assembly (Main harness)

GI

MA

LC

EC

FE

TF

PD

AX

SU

ST


BT

HA


SC

EL

Diagnostic Procedure (Cont'd)



4	CHECK DTC					
Perfor	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-162.					
	OK or NG					
ОК	>	INSPECTION END				
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 				



Component Inspection LINE PRESSURE SOLENOID VALVE

NBAT0059

NBAT0059S0101

NBAT0059S01

For removal, refer to AT-259.


Resistance Check

Check resistance between terminal 6 and ground.

 Solenoid valve
 Terminal No.
 Resistance (Approx.)


 Line pressure solenoid valve
 6
 Ground
 2.5 - 5Ω

Component Inspection (Cont'd)



Operation Check

Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal 6 and ground.



DROPPING RESISTOR


NBAT0059S02

Check resistance between two terminals.

Resistance: 11.2 - 12.8 Ω

DTC P0750 SHIFT SOLENOID VALVE A

Description



Description

Shift solenoid valves A and B are turned "ON" or "OFF" by the TCM in response to signals sent from the PNP switch, vehicle speed and throttle position sensors. Gears will then be shifted to the optimum position.

MA

LC

AT

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

Remarks: Specification data are reference values.

TCM TERMINALS AND REFERENCE VALUE NBAT0060S02

Terminal No.	Wire color	Item	Condition		Judgement standard
11	L/W Shift solenoid valve A	Shift solenoid		When shift solenoid valve A operates. (When driving in " D_1 " or " D_4 ".)	Battery voltage
		When shift solenoid valve A does not operate. (When driving in " D_2 " or " D_3 ".)	1V or less		

ON BOARD DIAGNOSIS LOGIC

NBAT0060S03

NBAT0060S01

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	
	TCM detects an improper voltage drop when it tires to operate the solenoid	Harness or connectors (The planting in particular and partic	
	valve.	(The solenoid circuit is open or shorted.)Shift solenoid valve A	

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION **PROCEDURE CAUTION:** Always drive vehicle at a safe speed. NOTE:

SC

EL

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.


After the repair, perform the following procedure to confirm the malfunction is eliminated.


(P) With CONSULT

- Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT.
- Start engine.
- Drive vehicle in "D" position and allow the transmission to shift "1" \rightarrow "2" ("GEAR").

With GST

Follow the procedure "With CONSULT".










Wiring Diagram — AT — SSV/A

NBAT0197

AT-SSV/A-01











★: This connector is not shown in "HARNESS LAYOUT" in EL section.



GI

MA

LC

EC

FE

TF

PD

SU

ST


BT

HA

SC


SAT524J

Diagnostic Procedure





- 1. Turn ignition switch to "OFF" position.
- 2. Disconnect TCM harness connector.
- 3. Check resistance between terminal 3 and TCM harness connector terminal 11.



If OK, check harness for short to ground and short to power.

Is resistance approx. 0Ω ?


Yes	GO TO 3.
No •	Repair open circuit or short to ground or short to power in harness or connectors.


DTC P0750 SHIFT SOLENOID VALVE A



Diagnostic Procedure (Cont'd)

3	CHECK DTC				
Perfor	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-167.				
	OK or NG				
OK	•	INSPECTION END			
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 			





Component Inspection SHIFT SOLENOID VALVE A

NBAT0062

NBAT0062S01

For removal, refer to AT-259.

Resistance Check

Check resistance between terminal 3 and ground.

NBAT0062S0101

Solenoid valve	Terminal No.		Resistance (Approx.)
Shift solenoid valve A	3	Ground	20 - 40Ω


Operation Check

Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal 3 and ground.

DTC P0755 SHIFT SOLENOID VALVE B

•

Description



Description

Shift solenoid valves A and B are turned "ON" or "OFF" by the TCM in response to signals sent from the PNP switch, vehicle speed and throttle position sensors. Gears will then be shifted to the optimum position.

G

©III

MA

PD/I

LC

3	4	r@
(Open)	ON (Closed)	EG

OFF (Open)

FE

AT

TCM TERMINALS AND REFERENCE VALUE

OFF

OFF (Open)

Remarks: Specification data are reference values.

1

ON (Closed)

ON (Closed)

Gear position

Shift solenoid valve A

Shift solenoid valve B

NBAT0063S02

Terminal No.	Wire color	Item	Condition		Judgement standard
40	L/D	Shift solenoid		When shift solenoid valve B operates. (When driving in " D_1 " or " D_2 ".)	Battery voltage
12	L/R	valve B		When shift solenoid valve B does not operate. (When driving in " D_3 " or " D_4 ".)	1V or less

2

OFF (Open)

ON (Closed)

		NBAT0063S03
	Malfunction is detected when	Check item (Possible cause)
ı	TCM detects an improper voltage drop when it tires to operate the solenoid	Harness or connectors (The solenoid circuit is open or shorted.)

SU

(The solenoid circuit is open or shorted.)

Shift solenoid valve B

BR

ENGINE

Diagnostic trouble code

🗐 : SFT SOL B/CIRC

🗃 : P0755

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NBAT0063S01

CAUTION:

Always drive vehicle at a safe speed.

ON BOARD DIAGNOSIS LOGIC

NOTE:

valve.

SEF895K

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

HA

After the repair, perform the following procedure to confirm the malfunction is eliminated.

SC

(P) With CONSULT

 Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT.

t EL

2) Drive vehicle in "D" position and allow the transmission to shift $1 \rightarrow 2 \rightarrow 3$ ("GEAR").

nift 🖳

With GST

Follow the procedure "With CONSULT".

SELECT DIAG MODE

WORK SUPPORT

SELF-DIAG RESULTS

DATA MONITOR

ACTIVE TEST

DTC CONFIRMATION

ECM PART NUMBER


SAT9111





Wiring Diagram — AT — SSV/B

NBAT0198

AT-SSV/B-01











★: This connector is not shown in "HARNESS LAYOUT" in EL section.




ST


BT

HA

SC









DTC P0755 SHIFT SOLENOID VALVE B



Diagnostic Procedure (Cont'd)

3	CHECK DTC			
Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-171.				
	OK or NG			
OK	•	INSPECTION END		
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 		





Component Inspection SHIFT SOLENOID VALVE B

NBAT0065

NBAT0065S01

For removal, refer to AT-259.

Resistance Check

NBAT0065S0101

Check resistance between terminal 2 and ground.


Solenoid valve	Terminal No.		Resistance (Approx.)
Shift solenoid valve B	2	Ground	20 - 40Ω

Operation Check

Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal 2 and ground.

Description





Description

NBAT0066

Throttle position sensor The throttle position sensor detects the throttle valve position and sends a signal to the TCM.

Throttle position switch

MA

Consists of a wide open throttle position switch and a closed throttle position switch. The wide open position switch sends a signal to the TCM when the throttle valve is open at least 1/2 of the full throttle position. The closed throttle position switch sends a signal to the TCM when the throttle valve is fully closed.

LC

CONSULT REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.

NBAT0066S02

AT

TF

Monitor item	Condition	Specification	
Throttle position sensor	Fully-closed throttle	Approximately 0.5V	
Throttle position sensor	Fully-open throttle	Approximately 4V	

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values.

sensor (Ground)


42


NBAT0066S03


Judgement **Terminal** Wire color Condition Item No. standard When releasing accelerator pedal after warming up engine. Battery volt-[Refer to "Preparation", "TCM SELF-DIAGage Closed throttle AX NOSTIC PROCEDURE (No Tools)", AT-46.] position switch OR/W 16 (in throttle When depressing accelerator pedal after position switch) warming up engine. 1V or less [Refer to "Preparation", "TCM SELF-DIAG-NOSTIC PROCEDURE (No Tools)", AT-46.] Wide open When depressing accelerator pedal more than Battery voltthrottle position half-way after warming up engine. age 17 OR/B switch (in throttle When releasing accelerator pedal after warm-1V or less ing up engine. position switch) Throttle position P/B 4.5 - 5.5V 32 sensor (Power source) Fully-closed throttle: Approximately When depressing accelerator pedal slowly after warming up engine. 0.5V Throttle position HA 41 (Voltage rises gradually in response to throttle Fully-open sensor position.) throttle: Approximately SC 4V Throttle position EL В




ON BOARD DIAGNOSIS LOGIC			
Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	
: TP SEN/CIRC A/T	TCM receives an excessively low or high voltage from the sensor.	Harness or connectors (The solenoid circuit is open or shorted.)	
		Throttle position sensor Throttle position switch	









DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NBAT0066S01

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT

- Turn ignition switch "ON" and select "DATA MONITOR" mode for "A/T" with CONSULT.
- Apply vacuum to the throttle opener, then check the following. Refer to steps 1 and 2 of "Preparation", "TCM SELF-DIAG-NOSTIC PROCEDURE (No Tools)", AT-46.

	· · ·	, ,	
Accelerator pedal condition	THRTL POS SEN	CLOSED THL/SW	W/O THRL/P-SW
Fully released	Less than 4.7V	ON	OFF
Partially depressed	0.1 - 4.6V	OFF	OFF
Fully depressed	More than 1.9 - 4.6V	OFF	ON

If the check result is NG, go to "DIAGNOSTIC PROCEDURE", AT-179.

If the check result is OK, go to following step.

- 3) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT.
- Start engine and maintain the following conditions for at least 3 consecutive seconds. Then release accelerator pedal completely.

VHCL SPEED SE: 10 km/h (6 MPH) or more THRTL POS SEN: Approximately 3V or less Selector lever: D position (OD "ON")

Selector level. D position (OD ON)

If the check result is NG, go to "DIAGNOSTIC PROCEDURE", AT-179.

If the check result is OK, go to following step.

5) Maintain the following conditions for at least 3 consecutive seconds. Then release accelerator pedal completely.

VHCL SPEED SE: 10 km/h (6 MPH) or more Accelerator pedal: Wide open throttle Selector lever: D position (OD "ON")

Description (Cont'd)

With GST

Follow the procedure "With CONSULT".

G[

MA

EM

LG

EG

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS


BT

HA

SC

EL







Diagnostic Procedure

Diagnostic Procedure

			NBAT0067	
1	1 CHECK DTC WITH ECM			
Perform diagnostic test mode II (self-diagnostic results) for engine control. Refer to EC-70, "DESCRIPTION".				
OK or NG				
OK	>	GO TO 2.		
NG	•	Check throttle position sensor circuit for engine control. Refer to EC-181, "Description	n".	

LC

EC

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC

EL



Diagnostic Procedure (Cont'd)

2 CHECK INPUT SIGNAL

(I) With CONSULT

- 1. Turn ignition switch to "ON" position. (Do not start engine.)
- 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT.
- 3. Read out the value of "THRTL POS SEN".


Voltage:

Fully-closed throttle:

Approximately 0.5V

Fully-open throttle:

Approximately 4V



SAT076H

Without CONSULT

1. Turn ignition switch to "ON" position. (Do not start engine.)

Check voltage between TCM terminals 41 and 42 while accelerator pedal is depressed slowly. Voltage:


Fully-closed throttle valve:

Approximately 0.5V

Fully-open throttle valve:

Approximately 4V

(Voltage rises gradually in response to throttle position.)



SAT513J

OK or NG

OK (With CONSULT)		GO TO 3.
OK (Without CONSULT)	•	GO TO 4.
NG	•	Check harness for short or open between ECM and TCM regarding throttle position sensor circuit. (Main harness)


DTC P1705 THROTTLE POSITION SENSOR

Diagnostic Procedure (Cont'd)

3 CHECK THROTTLE POSITION SWITCH CIRCUIT (With CONSULT)

(I) With CONSULT

1. Turn ignition switch to "ON" position. (Do not start engine.)



3. Apply vacuum to the throttle opener, then check the following. Refer to steps 1 and 2 of "Preparation", "TCM SELF-DIAGNOSTIC PROCEDURE (No Tools)", AT-46.

4. Read out "CLOSED THL/SW" and "W/O THRL/P-SW" depressing and releasing accelerator pedal. Check the signal of throttle position switch is indicated properly.

Accelerator	Data monitor		
pedal condition	CLOSED THL/SW	W/O THRL/P-SW	
Released	ON	OFF	
Fully depressed	OFF	ON	

MTBL0011



☆ MONITOR	公	NO FAIL		
',	, ,			
POWERSHIFT S	W	OFF		
CLOSED THL/SV	V	ON		
W/O THRL/P-SW	1	OFF		
HOLD SW		OFF		
l REC	RECORD			

SAT052I

			OK or NG
•	-	GO TO 5.	

OK	GO TO 5.
NG ►	Check the following items: Throttle position switch Refer to "Component Inspection", AT-183. Harness for short or open between ignition switch and throttle position switch (Main harness) Harness for short or open between throttle position switch and TCM (Main harness)

GI

MA

LC

EG

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

ST

RS

HA

SC

EL

DTC P1705 THROTTLE POSITION SENSOR



Diagnostic Procedure (Cont'd)

CHECK THROTTLE POSITION SWITCH CIRCUIT (Without CONSULT)

Without CONSULT


- 1. Turn ignition switch to "ON" position. (Do not start engine.)
- 2. Check voltage between TCM terminals 16, 17 and ground while depressing, and releasing accelerator pedal slowly. (after warming up engine)

[Refer to "Preparation", "TCM SELF-DIAGNOSTIC PROCEDURE (No Tools)", AT-46.]

Accelerator	Voltage		
pedal condition	Terminal No. 16	Terminal No. 17	
Released	Battery voltage	1V or less	
Fully depressed	1V or less	Battery voltage	

MTBL0206





SAT526J


OK •	GO TO 5.
NG ▶	 Check the following items: Throttle position switch Refer to "Component Inspection", AT-183. Harness for short or open between ignition switch and throttle position switch (Main harness) Harness for short or open between throttle position switch and TCM (Main harness)

OK or NG

5	CHECK DTC				
Perfor	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-176.				
	OK or NG				
ОК	>	INSPECTION END			
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 			

DTC P1705 THROTTLE POSITION SENSOR

Component Inspection



Component Inspection THROTTLE POSITION SWITCH

Closed Throttle Position Switch (Idle position)

NBAT0205 NBAT0205S01

NBAT0205S0101

Check continuity between terminals 1 and 2. [Refer to "Preparation", "TCM SELF-DIAGNOSTIC PROCE-DURE (No Tools)", AT-46.]

MA	

Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

LC


To adjust closed throttle position switch, refer to EC-99, "Basic Inspection".

EG

FE

AT

TF



Wide Open Throttle Position Switch

Accelerator pedal condition

Released

Depressed

Check continuity between terminals 2 and 3.

NBAT0205S0102

Continuity

No Yes

AX

SU

ST

BT

HA


SC

EL

DTC P1760 OVERRUN CLUTCH SOLENOID VALVE

Description





Description

The overrun clutch solenoid valve is activated by the TCM in response to signals sent from the inhibitor switch, overdrive control switch, vehicle speed and throttle position sensors. The overrun clutch operation will then be controlled.

TCM TERMINALS AND REFERENCE VALUE

NBAT0068S02

Remarks: Specification data are reference values.

Terminal No.	Wire color	Item	Condition		Judgement standard
20 L/B	I /D	Overrun clutch		When overrun clutch solenoid valve operates.	Battery voltage
	solenoid valve		When overrun clutch solenoid valve does not operate.	1V or less	

ON BOARD DIAGNOSIS LOGIC

NBAT0068S03

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)
(E): O/R CLTCH SOL/CIRC	TCM detects an improper voltage drop when it tries to operate the solenoid	Harness or connectors (The solenoid circuit is open or shorted.)
	valve.	Overrun clutch solenoid valve

SELECT_SYSTEM	
ENGINE	
]]
	I SEF895K

SELECT DIAG MODE ▼	
WORK SUPPORT	
SELF-DIAG RESULTS	
DATA MONITOR	
ACTIVE TEST	
DTC CONFIRMATION	
ECM PART NUMBER	
<u> </u>	SAT911I

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NBAT0068S01

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always drive vehicle on a level road to improve accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT.
- Start engine.
- 3) Accelerate vehicle to a speed of more than 10 km/h (6MPH) in "D" position (OD "ON").
- Release accelerator pedal completely in "D" position (OD "OFF").

DTC P1760 OVERRUN CLUTCH SOLENOID VALVE

Description (Cont'd)



Follow the procedure "With CONSULT".

G[

MA

EM

LC

EC

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC


EL





Wiring Diagram — AT — OVRCSV

NBAT0200

AT-OVRCSV-01











*: This connector is not shown in "HARNESS LAYOUT" in EL section.

DTC P1760 OVERRUN CLUTCH SOLENOID VALVE

,

GI

MA

LC


EC


FE

TF

Diagnostic Procedure









DTC P1760 OVERRUN CLUTCH SOLENOID VALVE



Diagnostic Procedure (Cont'd)

3	CHECK DTC			
Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-184.				
OK or NG				
OK	•	INSPECTION END		
NG	•	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 		





Component Inspection OVERRUN CLUTCH SOLENOID VALVE

NBAT0070

NBAT0070S01

For removal, refer to AT-259.

Resistance Check

NBAT0070S0101

Check resistance between terminal 4 and ground.


Solenoid valve	Terminal No.		Resistance (Approx.)
Overrun clutch solenoid valve	4	Ground	20 - 40Ω

Operation Check

Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal 4 and ground.

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE)

Description



2.0 1.5

1.0

0.5

Description

The A/T fluid temperature sensor detects the A/T fluid temperature and sends a signal to the TCM.



MA

EM

LC

EC

FE

AT

TF

PD

AX

SU



Remarks: Specification data are reference values.

SAT021J

-40 -20 0 20 40 60 80 100 120 140 160 (-40) (-4) (32)(68)(104)(140)(176)(212)(248)(284)(320)

NBAT0172S02

Monitor item	Condition	Specification
A/T fluid temperature sensor	Cold [20°C (68°F)] Hot [80°C (176°F)]	Approximately 1.5V ↓ Approximately 0.5V

TCM TERMINALS AND REFERENCE VALUE

Remarks: Specification data are reference values


NBAT0172S03

Remarks: 5	Remarks: Specification data are reference values.					
Terminal No.	Wire color	Item	Condition Judgement standard		ST	
10	W/R	Power source	(Con)	When turning ignition switch to "ON".	Battery volt- age	RS
			\$55	When turning ignition switch to "OFF".	1V or less	
19	W/R	Power source		Same as No. 10	·	BT
20	D/V	Power source	Or	When turning ignition switch to "OFF".	Battery voltage	HA
28 R/Y (Memory back-up	(Memory back-up)	(Memory back-up)	When turning ignition switch to "ON".	Battery volt- age	SC	
42	В	Throttle position sensor (Ground)	Con	_	_	EL
47	Ь	A/T fluid tempera-		When ATF temperature is 20°C (68°F).	Approximately 1.5V	IDX
47 R	ture sensor	M=	When ATF temperature is 80°C (176°F).	Approximately 0.5V		


DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE)

Description (Cont'd)

	ON BOARD DIAGNOSIS	LOGIC NBAT0172S04	
Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	
: BATT/FLUID TEMP SEN	TCM receives an excessively low or high	Harness or connectors (The sensor circuit is open or shorted.)	
8th judgement flicker	voltage from the sensor.	A/T fluid temperature sensor	



SELF-DIAG SULTS DATA MONITOR DTC WORK SUPPORT TCM PART NUMBER SAT385J



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NBAT0172S01

After the repair, perform the following procedure to confirm the malfunction is eliminated.


(P) With CONSULT

- 1) Start engine.
- 2) Select "DATA MONITOR" mode for "A/T" with CONSULT.
- Drive vehicle under the following conditions: Selector lever in "D" position, vehicle speed higher than 20 km/h (12 MPH).

No Tools

- 1) Start engine.
- Drive vehicle under the following conditions:
 Selector lever in "D" position, vehicle speed higher than 20 km/h (12 MPH).
- Perform self-diagnosis.
 Refer to TCM SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-46.


Wiring Diagram — AT — BA/FTS




Diagnostic Procedure

Diagnostic Procedure 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Check voltage between TCM terminals 10, 19, 28 and ground. Voltage: Battery voltage TCM OCONNECTOR 10, 19, 28 SAT514J 3. Turn ignition switch to "OFF" position. 4. Check voltage between TCM terminal 42 and ground. Voltage: Battery voltage

OK or NG		
ОК	>	GO TO 2.
NG	>	Check the following items: Harness for short or open between ignition switch and TCM terminals 10, 19 and 28 (Main harness) Ignition switch and fuse Refer to EL-9, "Schematic".




Diagnostic Procedure (Cont'd)



 \mathbb{Z}

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE)

Component Inspection



Component Inspection A/T FLUID TEMPERATURE SENSOR

NBAT0174

NBAT0174S01


- For removal, refer to AT-259.
- Check resistance between terminals 8 and 9 while changing temperature as shown at left.

Temperature °C (°F)	Resistance
20 (68)	Approximately 2.5 kΩ
80 (176)	Approximately 0.3 kΩ

VEHICLE SPEED SENSOR-MTR

Description





Remarks: Specification data are reference values.

Description

The vehicle speed sensor MTR is built into the speedometer assembly. The sensor functions as an auxiliary device to the revolution sensor when it is malfunctioning. The TCM will then use a signal sent from the vehicle speed sensor MTR.

MA

FE

AT

TF

TCM TERMINALS AND REFERENCE VALUE

NBAT0071S02

Terminal No.	Wire color	Item	Condition		Judgement standard
40	W/L	Vehicle speed sensor		When moving vehicle at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more.	Voltage varies between less than 1V and more than 4.5V

ON BOARD DIAGNOSIS LOGIC

NBAT0071S03

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	
: VHCL SPEED SEN-MTR	TCM does not receive the proper voltage	 Harness or connectors (The sensor circuit is open or shorted.) Vehicle speed sensor 	
2nd judgement flicker	signal from the sensor.		

AX

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION

CAUTION:

PROCEDURE

- Always drive vehicle at a safe speed.
- If conducting this "DTC CONFIRMATION PROCEDURE" again, always turn ignition switch "OFF" and wait at least 5 seconds before continuing.

After the repair, perform the following procedure to confirm the malfunction is eliminated.


(P) With CONSULT


- Turn ignition switch "ON" and select "DATA MONITOR" mode for "A/T" with CONSULT.
- Start engine and accelerate vehicle from 0 to 25 km/h (0 to 6 MPH).

HA



EL






VEHICLE SPEED SENSOR-MTR



Description (Cont'd)




- No Tools
- 1) Start engine.
- Drive vehicle under the following conditions: Selector lever in "D" position and vehicle speed higher than 25 km/h (16 MPH).
- Perform self-diagnosis.
 Refer to TCM SELF-DIAGNOSTIC PROCEDURE (No Tools), AT-46.



Wiring Diagram — AT — VSSMTR



MAT743A



VEHICLE SPEED SENSOR-MTR



Diagnostic Procedure

NBAT0072

1 CHECK INPUT SIGNAL.

(P) With CONSULT


- 1. Start engine.
- 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT.
- Read out the value of "VHCL/S SE-MTR" while driving. Check the value changes according to driving speed.

☆MONITOR ☆NO FAIL ∇ VHCL/S SE•A/T 0km/h VHCL/S SE•MTR 5km/h 0.4V THRTL POS SEN FLUID TEMP SE 1.2V BATTERY VOLT 13.4V ENGINE SPEED 1024rpm OVERDRIVE SW 0 N O N P/N POSI SW OFF R POSITION SW RECORD

SAT076H

Without CONSULT

- 1. Start engine.
- 2. Check voltage between TCM terminal 40 and ground while driving at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more.



SAT528J


Does battery voltage vary between less than 1V and more than 4.5V?

Yes	GO TO 2.
,	 Check the following items: Vehicle speed sensor and ground circuit for vehicle speed sensor Refer to EL-80, "Components Parts and Harness Connector Location". Harness for short or open between TCM and vehicle speed sensor (Main harness)

2	CHECK DTC				
Perfo	Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-195.				
	OK or NG				
ОК	•	INSPECTION END			
NG	•	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 			

CONTROL UNIT (RAM), CONTROL UNIT (ROM)

Description



Description

The TCM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the A/T.

MA

GI

EM

LC

EG

FE

ON BOARD DIAGNOSIS LOGIC


NBAT0207S01

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	[
(E): CONTROL UNIT (RAM) (E): CONTROL UNIT (ROM)	TCM memory (RAM) or (ROM) is mal- functioning.	тсм	[

ΑT

TF

PD



SELF-DIAG MODE

SELF-DIAG SULTS

DATA MONITOR

DTC WORK SUPPORT

TCM PART NUMBER

SAT385J

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

(II) With CONSULT

- Turn ignition switch "ON" and select "DATA MONITOR" mode for A/T with CONSULT.
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.

ST

SU

RS

BT

HA

SC

CONTROL UNIT (RAM), CONTROL UNIT (ROM)




Diagnostic Procedure

Diagnostic Procedure

	=NBATO2		
1	CHECK DTC		
1. Tui 2. Toi PERF	 With CONSULT 1. Turn ignition switch "ON" and select "SELF DIAG RESULTS" mode for A/T with CONSULT. 2. Touch "ERASE". PERFORM DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE. See previous page. 		
	Is the "CONTROL UNIT (RAM) or CONTROL UNIT (ROM)" displayed again?		
Yes	>	Replace TCM.	
No	•	INSPECTION END	

CONTROL UNIT (EEP ROM)

Description



Description

The TCM consists of a microcomputer and connectors for signal input and output and for power supply. The unit controls the A/T.

T. 🧐

MA

EM

LC


ON BOARD DIAGNOSIS LOGIC

NBAT0210S01

Diagnostic trouble code	Malfunction is detected when	Check item (Possible cause)	EG
(EEP ROM)	TCM memory (EEP ROM) is malfunctioning.	тсм	FE

ΑT

TF



SELECT DIAG MODE	
SELF-DIAG SULTS	
DATA MONITOR]
DTC WORK SUPPORT	
TCM PART NUMBER	
	SAT385J

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NOTE:

SAT574J

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCE-DURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

(I) With CONSULT

- Turn ignition switch "ON" and select "DATA MONITOR" mode for A/T with CONSULT.
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.

MW

PD

SU

ST

RS

BT

HA

SC

en

No

CONTROL UNIT (EEP ROM)




Diagnostic Procedure


		Diagnostic Procedure	=NBAT0211
1	CHECK DTC		
1. Tur 2. Mo 3. De 4. Tou 5. Tur PERF	ve selector lever to "R" po press accelerator pedal (F uch "ERASE". 'n ignition switch "OFF" po	ull throttle position).	
	Is the "CONTROL UNIT (EEP ROM)" displayed again?		
Yes	•	Replace TCM.	

INSPECTION END


Wiring Diagram — AT — NONDTC









Wiring Diagram — AT — NONDTC (Cont'd)






AT-NONDTC-04











BT

HA


SC


EL

1. O/D OFF Indicator Lamp Does Not Come On

1. O/D OFF Indicator Lamp Does Not Come On SYMPTOM:

O/D OFF indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".










1. O/D OFF Indicator Lamp Does Not Come On (Cont'd)



4	СНЕСК ЅҮМРТОМ		
Check	Check again.		
	OK or NG		
ОК	OK INSPECTION END		
NG	NG 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.		

2. Engine Cannot Be Started In "P" and "N" Position

2. Engine Cannot Be Started In "P" and "N" Position

SYMPTOM:

Self diagnosis Start

Yes or No
Check PNP switch circuit. Refer to "DTC P0705", AT-99.

Does "ECU INPUT SIGNALS" in Data Monitor show damage to PNP switch circuit?

GO TO 2.

=NBAT0074

Engine cannot be started with selector lever in "P" or "N" position.

MA

EM

Engine cannot be started with selector lever in "P"Engine can be started with selector lever in "D", "2", "1" or "R" position.

АТ
FE
EG
LC

All

PD


SAT367J

SU

ST

BT

SC



Light

--- Shade

338BB | | HA

OK		GO TO 3.
NG	•	Repair or replace PNP switch.

CHECK PNP SWITCH CIRCUIT

Does self-diagnosis show damage to PNP switch circuit?

(P) With CONSULT

Yes

No

Without CONSULT

3	CHECK STARTING SYSTEM		
Check starting system. Refer to SC-6, "System Description".			
	OK or NG		
OK INSPECTION END			
NG Repair or replace damaged parts.			

OK or NG




3. In "P" Position, Vehicle Moves Forward Or Backward When Pushed

3. In "P" Position, Vehicle Moves Forward Or Backward When Pushed

SYMPTOM:

Vehicle moves when it is pushed forward or backward with selector lever in "P" position.



4. In "N" Position, Vehicle Moves



MA

EM

LC

EC

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC

EL

4. In "N" Position, Vehicle Moves SYMPTOM:

=NBAT0076


Vehicle moves forward or backward when selecting "N" position.


1 CHECK PNP SWITCH	CIRCUIT	
© With CONSULT Does "ECU INPUT SIGNALS"	With CONSULT Does "ECU INPUT SIGNALS" in Data Monitor show damage to PNP switch circuit?	
Without CONSULT Does self-diagnosis show dam	age to PNP switch circuit?	
	Self diagnosis Start Light	
	Shade Yes or No	367J
Yes	Check PNP switch circuit. Refer to "DTC P0705", AT-99.	\dashv
No •	GO TO 2.	

2	CHECK CONTROL LINKAGE	
Che	ck control linkage. Refer to AT-261.	
	"P" position	
	Do not push Turn buckle	SAT032G
	OK NO	0A10020
	OK or NG	
OK	GO TO 3.	
NG	Adjust control linkage. Refer to AT-261.	

AT-211

4. In "N" Position, Vehicle Moves (Cont'd)





5	CHECK SYMPTOM		
Check again.			
	OK or NG		
OK	OK INSPECTION END		
NG	NG 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.		

5. Large Shock. "N" → "R" Position

5. Large Shock. "N" \rightarrow "R" Position SYMPTOM:

=NBAT0077

MA

EM

LC

EC


FE

AT

TF

There is large shock when changing from "N" to "R" position.

1	CHECK SELF-DIAGNO	STIC RESULTS	
	Does self-diagnosis show damage to A/T fluid temperature sensor, line pressure solenoid valve or throttle position sensor circuit?		
		Throttle position sensor circuit A/T fluid temperature sensor circuit Line pressure solenoid valve circuit Light Shade	
		SAT345HA	
		Yes or No	
Yes	•	Check damaged circuit. Refer to "DTC P0710, DTC P0745 or DTC P1705", AT-108, 164 or 179.	
No	>	GO TO 2.	



IDX

SC

EL




5. Large Shock. "N" → "R" Position (Cont'd)

Check line pressure at idle with selector lever in "D" position. Refer to "LINE PRESSURE TEST", AT-62. SAT494G OK or NG OK I. Remove control valve assembly. Refer to AT-259. 2. Check the following items: Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) Line pressure solenoid valve

4	CHECK SYMPTOM			
Check	Check again.			
	OK or NG			
OK	>	INSPECTION END		
NG		 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 		

6. Vehicle Does Not Creep Backward In "R" Position



6. Vehicle Does Not Creep Backward In "R" **Position**

SYMPTOM:

MA

LC

EC

FE

AT

TF

	Vehicle does not creep backward when selecting "R" position.
CHECK A/T FLUID LEVEL	


1	CHECK A/T FLUID LEVEL	
Che	eck A/T fluid level again.	
		THE STATE OF THE S
		SAT638A
		OK or NG
OK	▶ GC) TO 2.
	▶ Re	fill ATF.

2 C	HECK STALL TES	Т	PC
Check stall revolution with selector lever in "1" and "R" positions. Refer to AT-339.			
			S
			B
		SAT493G	\$1
		OK or NG	R
OK	•	GO TO 3.	1
OK in "1' "R" posit	" position, NG in b ion	 Remove control valve assembly. Refer to "ON-VEHICLE SERVICE", AT-259. Check the following items: 	
		 Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) Line pressure solenoid valve 	H
		3. Disassemble A/T.4. Check the following items:Oil pump assembly	\$(
		Torque converterReverse clutch assemblyHigh clutch assembly	
NG in bo	oth "1" and "R"	GO TO 6.	



6. Vehicle Does Not Creep Backward In "R" Position (Cont'd)

3 CHECK LINE PRESSURE Check line pressure at idle with selector lever in "R" position. Refer to "LINE PRESSURE TEST", AT-62. SAT494G OK or NG OK GO TO 4. NG 1. Remove control valve assembly. Refer to "ON-VEHICLE SERVICE", AT-259. 2. Check the following items: • Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) • Line pressure solenoid valve 3. Disassemble A/T. 4. Check the following items: • Oil pump assembly



5	CHECK SYMPTOM			
Check	Check again.			
	OK or NG			
ОК	•	INSPECTION END		
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 		



EL

	6. Vehicle Does Not Creep Backward In "R" Position (Cont'd)	
6 DETECT MALFUNCTIONIN	G ITEM	
Check the following items:	essure regulator valve, pressure modifier valve, pilot valve and pilot filter)	GI MA
4. Check the following items: Oil pump assembly Torque converter Reverse clutch assembly		EM
High clutch assemblyLow & reverse brake assemblyLow one-way clutch		LG
► Rep	pair or replace damaged parts.	EC
		FE
		AT
	5	TF
		PD
		AX
		SU
		BR
		ST
		RS
		BT
		HA
		SC




7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position


7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position

SYMPTOM:

=NBAT0079

Vehicle does not creep forward when selecting "D", "2" or "1" position.





G[

MA

EM

LC

EG

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC

EL

7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position (Cont'd)

3	CHECK LINE PRESSURI	=
	line pressure at idle with se to "LINE PRESSURE TEST"	
		SAT494G
		OK or NG
OK	> (GO TO 4.
NG	2	Remove control valve assembly. Refer to AT-259. Check the following items: Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) Line pressure solenoid valve Disassemble A/T. Check the following items:

4	CHECK A/T FLUID CO	NDITION	٦
1. Re	move oil pan.		П
2. Ch	eck A/T fluid condition.		
		SAT171	R
		OK or NG	۱
OK		GO TO 5.	\dashv
			\dashv
NG		GO TO 6.	- 1

5	CHECK SYMPTOM		
Check	Check again.		
		OK or NG	
OK	•	INSPECTION END	
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 	



7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position (Cont'd)

DETECT MALFUNCTIONING ITEM

- 1. Remove control valve assembly. Refer to "ON-VEHICLE SERVICE", AT-259.
- 2. Check the following items:
- Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter)
- Line pressure solenoid valve
- 3. Disassemble A/T.
- 4. Check the following items:
- Oil pump assembly
- Forward clutch assembly
- Forward one-way clutch
- Low one-way clutch
- Low & reverse brake assembly
- Torque converter

Repair or replace damaged parts.

8. Vehicle Cannot Be Started From D₁



G[

MA

LC

EC

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC

EL

8. Vehicle Cannot Be Started From D_1 SYMPTOM:

=NBAT0080

Vehicle cannot be started from D_1 on Cruise test — Part 1.


1	CHECK SYMPTOM			
Is "6. \	Is "6. Vehicle Does Not Creep Backward In "R" Position" OK?			
	Yes or No			
Yes	•	GO TO 2.		
No	>	Go to "6. Vehicle Does Not Creep Backward In "R" Position", AT-215.		

2	CHECK SELF-DIAGNO	STIC RESULTS
	s self-diagnosis show damaged sensor MTR after cruise to	e to vehicle speed sensor·A/T (revolution sensor), shift solenoid valve A, B or vehicle est?
		Vehicle speed sensor·A/T (revolution sensor) Vehicle speed sensor·MTR Shift solenoid valve A Shift solenoid valve B Light Shade
		Yes or No
Yes	>	Check damaged circuit. Refer to "DTC P0720, DTC P0750, DTC P0755 or VEHICLE SPEED SENSOR. MTR", AT-113, 169, 173 or 198.
No	•	GO TO 3.

3	CHECK THROTTLE PO	DSITION SENSOR	
Checl	k throttle position sensor. R	Refer to EC-181, "Description".	
		Throttle position switch harness connector Air duct Throttle position sensor harness connector SAT3:	3291
		OK or NG	
OK	•	GO TO 4.	
NG	•	Repair or replace throttle position sensor.	



8. Vehicle Cannot Be Started From D₁ (Cont'd)



6	DETECT MALFUN	ICTIONING	G ITEM	
Re 2. Ch Shifl Shifl Shifl Shifl Pilo	1. Remove control valve assembly. Refer to AT-259. 2. Check the following items: Shift valve A Shift valve B Shift solenoid valve A Shift solenoid valve B Pilot valve Pilot filter			
	OK or NG			
OK		▶ GO	TO 7.	
NG		Rep	air or replace damaged parts.	



G[

 $\mathbb{M}\mathbb{A}$

EM

BR

ST

RS

BT

HA

SC

EL

8. Vehicle Cannot Be Started From D₁ (Cont'd)

7	CHECK SYMPTOM]
Check again.			1
		OK or NG	
OK	•	INSPECTION END]
NG	•	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 	

		1			
8 DETECT	MALFUNCTIO	DNING ITEM			
 Remove cont Refer to AT-2 		DIY.			
	Check the following items:				
Shift valve A					
Shift valve B					
 Shift solenoid 	valve A		FE		
 Shift solenoid 	valve B				
 Pilot valve 					
 Pilot filter 					
3. Disassemble					
4. Check the fol					
Forward clutch			TF		
Forward one-wayLow one-way					
 High clutch as 			PD		
 Torque conve 					
Oil pump asset					
		21/ 112			
		OK or NG			
OK	>	GO TO 7.			
NG	•	Repair or replace damaged parts.	SU		



9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$


9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$

SYMPTOM:

=NBAT0081

A/T does not shift from D_1 to D_2 at the specified speed. A/T does not shift from D_4 to D_2 when depressing accelerator pedal fully at the specified speed.

1	CHECK SYMPTOM			
Are "7	Are "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position" and "8. Vehicle Cannot Be Started From D ₁ " OK?			
	Yes or No			
Yes	>	GO TO 2.		
No	>	Go to "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position" and "8. Vehicle Cannot Be Started From D ₁ ", AT-218, 221.		



3	CHECK VEHICLE SPE	ED SENSOR-A/T AND VEHICLE SPEED SENSOR-MTR CIRCUIT		
	Check vehicle speed sensor-A/T (revolution sensor) and vehicle speed sensor-MTR circuit. Refer to "DTC P0720 and VEHICLE SPEED SENSOR-MTR", AT-113, 198.			
	OK or NG			
OK	DK ▶ GO TO 4.			
NG	•	Repair or replace vehicle speed sensor·A/T (revolution sensor) and vehicle speed sensor·MTR circuits.		



TF


PD


AX

SU

ST

9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$ (Cont'd)





6	DETECT MALFUNCTIONING ITEM				
2. Ch	 Remove control valve. Refer to AT-259. Check the following items: Shift valve A 				
Shi	ft solenoid valve A t valve				HA
			OK or NG		SC
OK		•	GO TO 7.		
NG	G Repair or replace damaged parts.				



9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$ (Cont'd)

7	CHECK SYMPTOM				
Check	Check again.				
	OK or NG				
OK	OK INSPECTION END				
NG	•	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 			

8	DETECT MALFUNCTIO	NING ITEM	
2. Che Shif Shif Pilo Pilo Pilo 3. Dis 4. Che Ser Bral	1. Remove control valve. Refer to AT-259. 2. Check the following items: Shift valve A Shift solenoid valve A Pilot valve Pilot filter 3. Disassemble A/T. 4. Check the following items: Servo piston assembly Brake band Oil pump assembly		
		OK or NG	
OK	•	GO TO 7.	
NG	•	Repair or replace damaged parts.	

=NBAT0082

GI

MA

LC


EC

FE

AT

TF

AX





10. A/T Does Not Shift: $D_2 \rightarrow D_3$

SYMPTOM:

A/T does not shift from D_2 to D_3 at the specified speed.


1	CHECK SYMPTOM]		
Are "7.	Are "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position" and "8. Vehicle Cannot Be Started From D ₁ " OK?				
	Yes or No				
Yes	•	GO TO 2.	1		
No					







10. A/T Does Not Shift: $D_2 \rightarrow D_3$ (Cont'd)



5	DETECT MALFUNCTIO	NING ITEM			
 2. Che Shif Shif Pilot 	 Remove control valve Assembly. Refer to AT-259. Check the following items: Shift valve B Shift solenoid valve B Pilot valve Pilot filter 				
	OK or NG				
OK	>	GO TO 6.			
NG	NG Repair or replace damaged parts.				

6	CHECK SYMPTOM					
Check	Check again.					
	OK or NG					
OK	OK INSPECTION END					
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 				



10. A/T Does Not Shift: $D_2 \rightarrow D_3$ (Cont'd)

7 DETEC	T MALFUNCTION	DNING ITEM				
		bly. Refer to AT-259.		GI		
2. Check the foShift valve B	•					
 Shift solenoid 				MA		
 Pilot valve 				UV/U <i>L</i> =		
Pilot filter Discourable	. A /T					
3. Disassemble4. Check the formula				EM		
 Servo piston 						
High clutch a				LC		
 Oil pump ass 	sembly					
		OK or NG				
OK	>	GO TO 6.		EC		
NG	G Repair or replace damaged parts.					

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC

EL




11. A/T Does Not Shift: $D_3 \rightarrow D_4$ SYMPTOM:

=NBAT0083

- A/T does not shift from D₃ to D₄ at the specified speed.
- A/T must be warm before D₃ to D₄ shift will occur.

		<u> </u>			
1	CHECK SYMPTOM				
Are "7	Are "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position" and "8. Vehicle Cannot Be Started From D ₁ " OK?				
	Yes or No				
Yes	Yes ▶ GO TO 2.				
No	No Go to "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position" and "8. Vehicle Cannot Be Started From D ₁ ", AT-218, 221.				



TF

PD

AX

SU

BR

ST


BT


HA

SC

EL

11. A/T Does Not Shift: $D_3 \rightarrow D_4$ (Cont'd)





- ILCI WALFU	NCTIC	NING ITEM		
the following ite		bly. Refer to AT-259.		
n clutch control vollenoid valve B	/alve			
er				
		OK or NG		
	•	GO TO 6.		
G Repair or replace damaged parts.				
r	ve control valve the following ite	ve control valve Asseml the following items: alve B n clutch control valve blenoid valve B alve	ve control valve Assembly. Refer to AT-259. the following items: alve B n clutch control valve blenoid valve B alve ter OK or NG GO TO 6.	



11. A/T Does Not Shift: $D_3 \rightarrow D_4$ (Cont'd)

6	CHECK SYMPTOM	CHECK SYMPTOM			
Check	Check again.				
	OK or NG				
OK	•	INSPECTION END			
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 			

	1				
7	DETECT MALFUNCTIO	NING ITEM			
 2. Che Shiff Ove Shiff Pilo Pilo Dis Che Ser Bral Toro 	1. Remove control valve Assembly. Refer to AT-259. 2. Check the following items: Shift valve B Overrun clutch control valve Shift solenoid valve B Pilot valve Pilot filter 3. Disassemble A/T. 4. Check the following items: Servo piston assembly Brake band Torque converter Oil pump assembly				
	OK or NG				
OK	>	GO TO 6.			
NG	•	Repair or replace damaged parts.			

12. A/T Does Not Perform Lock-up

12. A/T Does Not Perform Lock-up

=NBAT0084

MA

LC

EC

FE


AT


TF


AX

SYMPTOM:

A/T does not perform lock-up at the specified speed.











12. A/T Does Not Perform Lock-up (Cont'd)

4	CHECK SYMPTOM	CHECK SYMPTOM			
Check	Check again.				
	OK or NG				
OK	OK INSPECTION END				
NG					

13. A/T Does Not Hold Lock-up Condition

AX

ST


BT


HA

SC

13. A/T Does Not Hold Lock-up Condition

SYMPTOM:





3	DETECT MALFUNCTIO	NING ITEM		
1. Remove control valve assembly. Refer to AT-259. 2. Check the following items: • Torque converter clutch control valve • Pilot valve • Pilot filter				
	OK or NG			
OK	>	GO TO 4.		
NG		Repair or replace damaged parts.		



13. A/T Does Not Hold Lock-up Condition (Cont'd)

4	CHECK SYMPTOM			
Check	Check again.			
	OK or NG			
OK	•	INSPECTION END		
NG	>	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 		

5	DETECT MALFUNCTIO	NING ITEM		
2. Che Tord Pilot Pilot Dis	1. Remove control valve assembly. Refer to AT-259. 2. Check the following items: • Torque converter clutch control valve • Pilot valve • Pilot filter 3. Disassemble A/T. 4. Check torque converter and oil pump assembly.			
	OK or NG			
OK	>	GO TO 4.		
NG	•	Repair or replace damaged parts.		



GI

MA

LC

FE

AT

TF

AX

SU

ST

BT

HA


SC

=NBAT0086

14. Lock-up Is Not Released

SYMPTOM:

Lock-up is not released when accelerator pedal is released.



2	CHECK SYMPTOM			
Check	Check again.			
	OK or NG			
OK	•	INSPECTION END		
NG	•	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 		

IDX





15. Engine Speed Does Not Return To Idle (Light Braking $D_4 \rightarrow D_3$)

15. Engine Speed Does Not Return To Idle (Light Braking $D_4 \rightarrow D_3$) SYMPTOM:


=NBAT0087

- Engine speed does not smoothly return to idle when A/T shifts from D₄ to D₃.
- Vehicle does not decelerate by engine brake when turning overdrive control switch OFF.
- Vehicle does not decelerate by engine brake when shifting A/T from "D" to "2" position.





15. Engine Speed Does Not Return To Idle (Light Braking $D_4 \rightarrow D_3$) (Cont'd)



Repair or replace damaged parts.


NG



16. Vehicle Does Not Start From D₁ SYMPTOM:

NBAT0088

Vehicle does not start from D_1 on Cruise test — Part 2.



2	CHECK SYMPTOM				
Check	Check again.				
	OK or NG				
OK	>	Go to "8. Vehicle Cannot Be Started From D ₁ ", AT-221.			
NG	•	 Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 			



17. A/T Does Not Shift: $D_4 \rightarrow D_3$, When Overdrive Control Switch "ON" \rightarrow "OFF"

17. A/T Does Not Shift: $D_4 \rightarrow D_3$, When Overdrive Control Switch "ON" \rightarrow "OFF" SYMPTOM:

IBAT0089

A/T does not shift from $\mathrm{D_4}$ to $\mathrm{D_3}$ when changing overdrive control switch to "OFF" position.

ive

MA

LC

EC

FE

AT

TF

PD

 $\mathbb{A}\mathbb{X}$

SU

BR

ST

RS

BT

HA

SC

EL

1 CHECK OVERDRIVE	CONTROL SWITCH CIRCUIT				
With CONSULT Does "ECU INPUT SIGNALS" i	With CONSULT Does "ECU INPUT SIGNALS" in Data Monitor show damage to overdrive control switch circuit?				
Without CONSULT Does self-diagnosis show dama	Without CONSULT Does self-diagnosis show damage to overdrive control switch circuit?				
	O/D OFF				
	Self-diagnosis start				
	Light				
		SAT344H			
Yes or No					
Yes	Check overdrive control switch circuit. Refer to AT-245.				
No •	Go to "10. A/T Does Not Shift: $D_2 \rightarrow D_3$ ", AT-227.				

AT-241



18. A/T Does Not Shift: $D_3 \rightarrow 2_2$, When Selector Lever "D" \rightarrow "2" Position

18. A/T Does Not Shift: $D_3 \rightarrow 2_2$, When Selector Lever "D" \rightarrow "2" Position SYMPTOM:

A/T does not shift from D_3 to $\mathrm{2}_2$ when changing selector lever from "D" to "2" position.

1 CHECK PNP SWITCH	CIRCUIT	
With CONSULT Does "ECU INPUT SIGNALS" in	n Data Monitor show damage to PNP switch circuit?	
Without CONSULT Does self-diagnosis show dama	ge to PNP switch circuit?	
	Self diagnosis Start	
	Shade	T367J
	Yes or No	
Yes	Check PNP switch circuit. Refer to "DTC P0705", AT-102.	
No >	Go to "9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$ ", AT-224.	



19. A/T Does Not Shift: $2_2 \rightarrow 1_1$, When Selector Lever "2" \rightarrow "1" Position

19. A/T Does Not Shift: $\mathbf{2_2} \to \mathbf{1_1}$, When Selector Lever "2" \to "1" Position

SYMPTOM:

A/T does not shift from $\mathbf{2}_2$ to $\mathbf{1}_1$ when changing selector lever from "2" to "1" position.

$\mathbb{M}\mathbb{A}$

LC

EC

FE

AT

TF

PD

1	CHECK PNP SWITCH	CIRCUIT	
	th CONSULT "ECU INPUT SIGNALS" in	Data Monitor show damage to PNP switch circuit?	
	thout CONSULT self-diagnosis show damag	ge to PNP switch circuit?	
		Self diagnosis Start	
		Yes or No	SAT367J
Yes	•	Check PNP switch circuit. Refer to "DTC P0705", AT-102.	
No	•	GO TO 2.	

2	CHECK SYMPTOM		- 1
Che	ck again.	,	S
		22	
			S
		1 ₁ Engine brake	R
		SAT778B	B
		OK or NG	
OK	•	INSPECTION END	
NG	>	Perform TCM input/output signal inspection. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.] S(

EL





20. Vehicle Does Not Decelerate By Engine **Brake**


SYMPTOM:


Vehicle does not decelerate by engine brake when shifting from 2_2 (1_2) to 1_1 .

1	CHECK SYMPTOM		
Is "6. Vehicle Does Not Creep Backward In "R" Position" OK?			
Yes or No			
Yes	•	Go to "15. Engine Speed Does Not Return To Idle (Light Braking $D_4 \rightarrow D_3$)", AT-238.	
No	•	Go to "6. Vehicle Does Not Creep Backward In "R" Position", AT-215.	









21. TCM Self-diagnosis Does Not Activate (PNP, **Overdrive Control and Throttle Position Switches Circuit Checks)**

SYMPTOM:

NBAT0204

O/D OFF indicator lamp does not come on in TCM self-diagnostic procedure even the lamp circuit is good.

DESCRIPTION

NBAT0204S01

PNP switch

The PNP switch assemble includes a transmission range switch. The transmission range switch detects the selector position and sends a signal to the TCM.

- Overdrive control switch
 - Detects the overdrive control switch position (ON or OFF) and sends a signal to the TCM.
- Throttle position switch

Consists of a wide open throttle position switch and a closed throttle position switch.

The wide open throttle position switch sends a signal to the TCM when the throttle valve is open at least 1/2 of the full throttle position. The closed throttle position switch sends a signal to the TCM when the throttle valve is fully closed.



21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

DIAGNOSTIC PROCEDURE

NOTE:

=NBAT0204S03

The diagnostic procedure includes inspections for the overdrive control and throttle position switch circuits.

ve G

BR

ST

RS

BT

HA

SC

1	CHECK PNP SWITCH	CIRCUIT (With CONSULT)	MA
1. Tur (Do	th CONSULT n ignition switch to "ON" po not start engine.)		EM
3. Rea		in "DATA MONITOR" mode for "A/T" with CONSULT. In and "1" position switches moving selector lever to each position. Check the signal of the ated properly.	LC
		☆ MONITOR ☆ NO FAIL □ R POSITION SW OFF D POSITION SW OFF 2 POSITION SW OFF	EC
		1 POSITION SW OFF ASCD•CRUISE OFF ASCD•OD CUT OFF KICKDOWN SW OFF	FE
		POWER SHIFT SW OFF CLOSED THL/SW OFF	AT
		RECORD SAT7611	TF
		OK or NG	
OK	•	GO TO 3.	PD
NG	>	Check the following items: PNP switch Refer to "Component Inspection", AT-250.	AX
		 Harness for short or open between ignition switch and PNP switch (Main harness) Harness for short or open between PNP switch and TCM (Main harness) 	SU





21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)


CHECK PNP SWITCH CIRCUIT (Without CONSULT)

Without CONSULT

- 1. Turn ignition switch to "ON" position. (Do not start engine.)
- 2. Check voltage between TCM terminals 26, 27, 34, 35, 36 and ground while moving selector lever through each position.

Lever position	Terminals				
	36	35	34	27	26
P, N	В	0	0	0	0
R	0	В	0	0	0
D	0	0	В	0	0
2	0	0	0	В	0
1	0	0	0	0	В

MTBL0205



SAT517J


Does battery voltage exist (B) or non-existent (0)?

Yes ▶	GO TO 3.
No •	Check the following items: PNP switch Refer to "Component Inspection", AT-250. Harness for short or open between ignition switch and PNP switch (Main harness) Harness for short or open between PNP switch and TCM (Main harness)



EL

21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)





21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

CHECK THROTTLE POSITION SWITCH CIRCUIT (With CONSULT)

With CONSULT

- 1. Turn ignition switch to "ON" position. (Do not start engine.)
- 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT.
- 3. Apply vacuum to the throttle opener, then check the following. Refer to steps 1 and 2 of "Preparation", "TCM SELF-DIAGNOSTIC PROCEDURE (No Tools)", AT-46.
- 4. Read out "CLOSED THL/SW" and "W/O THRL/P-SW" depressing and releasing accelerator pedal. Check the signal of throttle position switch is indicated properly.

Accelerator	Data monitor	
pedal condition	CLOSED THL/SW	W/O THRL/P-SW
Released	ON	OFF
Fully depressed	OFF	ON

MTBL0011



☆ MONITOR	☆N	O FAIL	-
POWERSHIFT S CLOSED THL/SV W/O THRL/P-SW HOLD SW		OFF ON OFF OFF	
RECORD			

SAT052I

OK or NG

OK •	GO TO 6.
NG ►	 Check the following items: Throttle position switch Refer to "Component Inspection", AT-251. Harness for short or open between ignition switch and throttle position switch (Main harness) Harness for short or open between throttle position switch and TCM (Main harness)




21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

CHECK THROTTLE POSITION SWITCH CIRCUIT (Without CONSULT) Without CONSULT GI 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Check voltage between TCM terminals 16, 17 and ground while depressing, and releasing accelerator pedal slowly. MA (after warming up engine) [Refer to "Preparation", "TCM SELF-DIAGNOSTIC PROCEDURE (No Tools)", AT-46.] Accelerator Voltage pedal condition Terminal No. 16 Terminal No. 17 Released Battery voltage 1V or less LC Fully depressed 1V or less Battery voltage MTBL0206 FE AΤ TF TCM O CONNECTOR 16 PD OR/W OR/B AX SU SAT526J OK or NG OK GO TO 6. NG Check the following items: ST • Throttle position switch Refer to "Component Inspection", AT-251. • Harness for short or open between ignition switch and throttle position switch (Main harness) • Harness for short or open between throttle position switch and TCM (Main harness) BT **CHECK DTC** Perform Diagnostic procedure, AT-245. HA OK or NG OK **INSPECTION END** SC NG 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. EL

l ₪ W



21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)




COMPONENT INSPECTION Overdrive Control Switch

NBAT0204S04

NBAT0204S0401

Check continuity between two terminals.

Continuity:
Switch position "ON":
No
Switch position "OFF":
Yes




PNP switch SAT843BG

Park/Neutral Position Switch


NBAT0204S0402

1. Check continuity between terminals 1 and 2 and between terminals 3 and 4, 5, 6, 7, 8, 9 while moving manual shaft through each position.

Lever position	Termir	nal No.
Р	1 - 2	3 - 4
R	3 - 5	
N	1 - 2	3 - 6
D	3 - 7	
2	3 - 8	
1	3 - 9	




- 2. If NG, check again with manual control linkage disconnected from manual shaft of A/T assembly. Refer to step 1.
- 3. If OK on step 2, adjust manual control linkage. Refer to AT-261.



- If NG on step 2, remove PNP switch from A/T and check continuity of PNP switch terminals. Refer to step 1.
- 5. If OK on step 4, adjust PNP switch. Refer to AT-260.
- 6. If NG on step 4, replace PNP switch.



21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd,



Throttle Position Switch

Closed Throttle Position Switch (Idle Position)

NBAT0204S0403

Check continuity between terminals 1 and 2. [Refer to "Preparation", "TCM SELF-DIAGNOSTIC PROCE-DURE (No Tools)", AT-46.1

		- IN//I/A\
Accelerator pedal condition	Continuity	
Released	Yes	EM
Depressed	No	

MA


To adjust closed throttle position switch, refer to EC-99, "Basic Inspection".


EC


LC

AT

TF







Wide Open Throttle Position Switch

Check continuity between terminals 2 and 3.

Accelerator pedal condition	Continuity
Released	No
Depressed	Yes

AX

A/T Fluid Temperature Switch

Make sure the A/T fluid warning lamp lights when the key is inserted and turned to "ON".

Make sure the A/T fluid warning lamp goes off when turning the ignition switch to "ON".

Check resistance between terminal 10 and ground while changing temperature as shown at left.

HA

Temperature °C (°F)	Resistance
140 (284) or more	Yes
140 (284) or less	No

SC EL

A/T SHIFT LOCK SYSTEM



Description

NBAT0093


 The mechanical key interlock mechanism also operates as a shift lock:

With the key switch turned to "ON", the selector lever cannot be shifted from "P" (parking) to any other position unless the brake pedal is depressed.


With the key removed, the selector lever cannot be shifted from "P" to any other position.

The key cannot be removed unless the selector lever is placed in "P".

 The shift lock and key interlock mechanisms are controlled by the ON-OFF operation of the shift lock solenoid and by the operation of the rotator and slider located inside the key cylinder, respectively.







A/T SHIFT LOCK SYSTEM



NBAT0095

Diagnostic Procedure

SYMPTOM 1:

 Selector lever cannot be moved from "P" position with key in "ON" position and brake pedal applied.

- Selector lever can be moved from "P" position with key in "ON" position and brake pedal released.
- Selector lever can be moved from "P" position when key is removed from key cylinder.

SYMPTOM 2:

Ignition key cannot be removed when selector lever is set to "P" position. It can be removed when selector lever is set to any position except "P".

1	1 CHECK KEY INTERLOCK CABLE						
Check	Check key interlock cable for damage.						
	OK or NG						
OK	•	GO TO 2.					
NG	•	Repair key interlock cable. Refer to "Key Interlock Cable", AT-257.					

2	CHECK SELECTOR LEVER POSITION						
Check	Check selector lever position for damage.						
	OK or NG						
OK	•	GO TO 3.					
NG		Check selector lever. Refer to "ON-VEHICLE SERVICE — Inhibitor Switch and Manual Control Linkage Adjustment", AT-260 and AT-261.					

3 **CHECK POWER SOURCE** 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Check voltage between ASCD brake switch harness terminal 1 and ground. ASCD brake switch OR/L SAT917HJ Does battery voltage exist? GO TO 4. Yes No Check the following items: • Harness for short or open between battery and ASCD brake switch harness terminal 1 Fuse • Ignition switch (Refer to EL section.)




HA

SC

EL

[DX

SAT347I



OK	•	GO TO 6.					
NG	•	Repair harness or connector.					
6	CHECK PARK POSITIO	CHECK PARK POSITION SWITCH					
(Refe	(Refer to "Component Check", AT-256.)						
OK or NG							
OK	•	GO TO 7.					

OK or NG


Replace park position switch.

NG



7	CHECK SHIFT LOCK SOLENOID						
(Refe	(Refer to "Component Check", AT-256.)						
	OK or NG						
OK	•	GO TO 8.					
NG	•	Replace shift lock solenoid.					

8	CHECK SHIFT LOCK O	PERATION					
2. Tur	 Reconnect shift lock harness connector. Turn ignition switch from "OFF" to "ON" position. (Do not start engine.) Recheck shift lock operation. 						
	OK or NG						
OK	>	INSPECTION END					
NG	>	 Perform A/T device input/output signal inspection test. If NG, recheck harness connector connection. 					




Component Check SHIFT LOCK SOLENOID

NBAT0096

.

 Check operation by applying battery voltage between shift lock solenoid harness connector terminal 2 and A/T device harness connector terminal 5.



PARK POSITION SWITCH

NBAT0096S02

heck continuity between park position switch harness connector terminal 2 and A/T device harness connector terminal 6.

Condition	Continuity
When selector lever is set in "P" position and selector lever button is released	Yes
Except above	No


ASCD BRAKE SWITCH

NBAT0096S03


 Check continuity between ASCD brake switch harness connector terminals 1 and 2.

Condition	Continuity
When brake pedal is depressed	No
When brake pedal is released	Yes

Check ASCD brake switch after adjusting brake pedal — refer to BR-13, "Removal and Installation".








CAUTION:

- Install key interlock cable in such a way that it will not be damaged by sharp bends, twists or interference with adjacent parts.
- After installing key interlock cable to control device, make sure that casing cap and bracket are firmly secured in their positions. If casing cap can be removed with an external load of less than 39.2 N (4.0 kg, 8.8 lb), replace key interlock cable with new one.





Removal

Unlock slider from adjuster holder and remove rod from cable.

EL

SU

BR

ST


RS


BT


HA

SC









Installation


- Set key interlock cable to steering lock assembly and install lock plate.
- Clamp cable to steering column and fix to control cable with band.
- 3. Set selector lever to P position.
- Insert interlock rod into adjuster holder.

- 5. Install casing cap to bracket.
- 6. Move slider in order to fix adjuster holder to interlock rod.

ON-VEHICLE SERVICE

Control Valve Assembly and Accumulators





A/T fluid temperature

Front

(B) (B)

sensor

Tube bracket -

(B)

A

Control Valve Assembly and Accumulators REMOVAL

NBA10100

NBAT0100S01

- 1. Remove exhaust front tube.
 - Remove oil pan and gasket and drain ATF.

MA

LC

- . Remove A/T fluid temperature sensor if necessary.
- 4. Remove oil strainer.



===

AT

TF

 Remove control valve assembly by removing fixing bolts and disconnecting harness connector.



Bolt length and location

SAT073BA

SAT353B

SAT074BA

Tube bracket

Bolt symbol	ℓ mm (in) $\stackrel{\square}{\biguplus}$ ℓ
A	33 (1.30)
В	45 (1.77)



AX

- . Remove solenoids and valves from valve body if necessary.
- 7. Remove terminal cord assembly if necessary.



HA

- 8. Remove accumulator **A**, **B**, **C** and **D** by applying compressed air if necessary.
- Hold each piston with rag.
- 9. Reinstall any part removed.
- Always use new sealing parts.





EL





B B B A














Revolution Sensor Replacement

- Remove rear engine mounting member from side member while supporting A/T with transfer case with jack. Tighten rear engine mounting member to the specified torque. Refer to EM-44, "Rear Engine Mounting".
- Lower A/T with transfer case as much as possible.
- Remove revolution sensor from A/T.
- Reinstall any part removed.
- Always use new sealing parts.

Rear Oil Seal Replacement

- Remove transfer case from vehicle. Refer to TF-117, "Removal".
- Remove rear oil seal.
- Install rear oil seal.
- Apply ATF before installing.
- Reinstall any part removed.

Parking Components Inspection

NBAT0103

- Remove propeller shaft. Refer to PD-4, "Components".
- Remove transfer case from vehicle. Refer to TF-117, "Removal".
- Remove A/T control cable bracket from transmission case.

- Support A/T assembly with a jack.
- Remove adapter case from transmission case.
- Replace parking components if necessary.
- Reinstall any part removed.
- Always use new sealing parts.


Park/Neutral Position Switch Adjustment


- Remove manual control linkage from manual shaft of A/T assembly.
- Set manual shaft of A/T assembly in "N" position.
- Loosen PNP switch fixing bolts.
- Insert pin into adjustment holes in both PNP switch and manual shaft of A/T assembly as near vertical as possible.
- Reinstall any part removed.
- Check continuity of PNP switch. Refer to "Components Inspection", AT-104.

ON-VEHICLE SERVICE

Manual Control Linkage Adjustment







Manual Control Linkage Adjustment

Move selector lever from "P" position to "1" position. You should be able to feel the detents in each position.

If the detents cannot be felt or the pointer indicating the position is improperly aligned, the linkage needs adjustment.

- 1. Place selector lever in "P" position.
- Loosen lock nuts.

Tighten turn buckle until aligns with inner cable, pulling selector lever toward "R" position side without pushing button.

Back off turn buckle 1 turn and tighten lock nuts to the specified torque.

Lock nut:

(0.45 - 0.60 kg-m, 39.1 - 52.1 in-lb)

Move selector lever from "P" position to "1" position. Make sure that selector lever can move smoothly.

MA

LC

EG

FE

AT

TF


AX


HA


SC

[DX









CAUTION:

When removing the A/T assembly from engine, first remove the crankshaft position sensor (OBD) from the A/T assembly upper side.


Be careful not to damage sensor edge.

- 1. Remove battery negative terminal.
- 2. Remove exhaust front and rear tubes.
- 3. Remove fluid charging pipe from A/T assembly.
- 4. Remove fluid cooler pipe from A/T assembly.
- 5. Plug up openings such as the fluid charging pipe hole, etc.
- Remove front and rear propeller shaft. Refer to PD-4, "Components".
- 7. Remove transfer control linkage from transfer. Refer to TF-117, "Removal".
- Insert plug into rear oil seal after removing rear propeller shaft.
- Be careful not to damage spline, sleeve yoke and rear oil seal.
- 8. Remove A/T control cable from A/T assembly.
- 9. Disconnect A/T and speedometer sensor harness connectors.
- Remove starter motor. Refer to SC-8, "Removal and Installation".
- Remove gusset and rear plate cover securing engine to A/T assembly.
- 12. Remove bolts securing torque converter to drive plate.
- Remove the bolts by turning crankshaft.

REMOVAL AND INSTALLATION

Removal (Cont'd,





13. Support A/T and transfer assembly with a jack.

14. Remove rear engine mounting member from body and A/T assembly. Tighten rear engine mounting member to the specified torque. Refer to EM-44, "Rear Engine Mounting".


15. Remove bolts securing A/T assembly to engine.

16. Lower A/T assembly with transfer.



LC

NBAT0107



Installation

Drive plate runout

Maximum allowable runout:

Refer to EM-54, "DRIVE PLATE RUNOUT".

If this runout is out of specification, replace drive plate with ring gear.



AT

TF

When connecting torque converter to transmission, measure distance "A" to be certain that they are correctly assembled. Distance "A":

26.0 mm (1.024 in) or more

AX

Install converter to drive plate.

ST

After converter is installed to drive plate, rotate crankshaft several turns and check to be sure that transmission rotates freely without binding.

Tightening torque

N·m (kg-m, ft-lb)

39 - 49 (4.0 - 5.0, 29 - 36)

39 - 49 (4.0 - 5.0, 29 - 36)

29 - 39 (3.0 - 4.0, 22 - 29)

29 - 39 (3.0 - 4.0, 22 - 29)

HA

SC

Bolt length "ℓ"

mm (in)

47.5 (1.870)

58.0 (2.283)


25.0 (0.984)


20.0 (0.787)


EL

Reinstall any part removed.

Tighten bolts securing transmission.







Bolt No.

1

2

3


Gusset to engine







- Check fluid level in transmission.
- Move selector lever through all positions to be sure that transmission operates correctly.
 - With parking brake applied, rotate engine at idling. Move selector lever through "N" to "D", to "2", to "1" and to "R" positions. A slight shock should be felt by hand gripping selector each time transmission is shifted.
- Perform road test. Refer to "ROAD TEST", AT-63.

AIR BREATHER HOSE










SAT752IA



Oil Channel





SAT185B



Locations of Needle Bearings, Thrust Washers and Snap Rings


gs								ı
ap rin	Outer diameter	<u>ج</u>	.34)	(5.52)	(6.16)	(2.59)	.27)	
sné	ä	Ξ	9)	(5			9	
o Jo	ter	mm (in)	161.0 (6.34)	140.1	156.4	142.0	159.2 (6.27)	
eter	0		F	Ť	Ŧ.	-	=	
uter diameter of snap rings	Ē	number		(9		
uter	Item	nuu	9	9	(A)	۳		

Thrust washers	Color	Black	White
Thrus	ltem number	Θ	©


Outer diameter of needle bearings	Outer diameter	mm (in)	47 (1.85)	53 (2.09)	78 (3.07)	53 (2.09)	78 (3.07)	59 (2.32)	78 (3.07)	64 (2.52)	53 (2.09)
	Item	number	⊚	6	((2)	9	(1)	9	9	<u>(1)</u>

Ses				
Inner diameter of bearing races	Outer diameter	mm (in)	58.8 (2.315)	58.8 (2.315)
ner diame	Item	number	⊕	(EJ)
⊑ .				

Bearing race (black) location	Front	Front	Rear side	Rear side
Item	9	(2)	(29)	9







- Drain ATF through drain plug.
- Remove torque converter by holding it firmly and turning while pulling straight out.




MA

EM

LC

EC

FE



- Check torque converter one-way clutch.
- Insert Tool into spline of one-way clutch inner race.
- Hook bearing support unitized with one-way clutch outer race with suitable wire.
- Check that one-way clutch inner race rotates only clockwise with Tool while holding bearing support with wire.



ΑT

TF

Remove PNP switch from transmission case.



AX



SU

ST

Remove oil pan. Always place oil pan straight down so that foreign particles inside will not move.













Place transmission into Tool with the control valve facing up.



















- 7. Check foreign materials in oil pan to help determine cause of malfunction. If the fluid is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and may inhibit pump pressure.
- If frictional material is detected, replace radiator after repair of A/T. Refer to LC-12, "REMOVAL AND INSTALLA-TION".




- 8. Remove torque converter clutch solenoid valve and A/T fluid temperature sensor connectors.
- Be careful not to damage connector.



- Remove oil strainer.
- Remove oil strainer from control valve assembly.
 Then remove O-ring from oil strainer.




b. Check oil strainer screen for damage.



- 10. Remove control valve assembly.
- a. Straighten terminal clips to free terminal cords then remove terminal clips.





b. Remove bolts A and B, and remove control valve assembly from transmission.

Bolt symbol	Length mm (in)		
A	33 (1.30)		
В	45 (1.77)		

GI

MA

EM

LC

EC

FE

AT

TF

Remove solenoid connector.

Be careful not to damage connector.

d. Remove manual valve from control valve assembly.

PD

AX

SU

BR

ST

RS

BT


HA


11. Remove terminal cord assembly from transmission case while SC


Be careful not to damage cord.


pushing on stopper.

Do not remove terminal cord assembly unless it is damaged.

















- 12. Remove converter housing from transmission case.
- Be careful not to scratch converter housing.




13. Remove O-ring from input shaft.



- 14. Remove oil pump assembly.
- a. Attach Tool to oil pump assembly and extract it evenly from transmission case.




- b. Remove O-ring from oil pump assembly.
- c. Remove traces of sealant from oil pump housing.
- Be careful not to scratch pump housing.



 Remove needle bearing and thrust washer from oil pump assembly.





15. Remove input shaft and oil pump gasket.

GI

MA

EM

LC

16. Remove brake band and band strut.

transmission case.

a. Loosen lock nut and remove band servo anchor end pin from EC

FE

AT

TF

Remove brake band and band strut from transmission case.

PD

AX

SU

BR

ST

RS


BT

HA

SC


Remove clutch pack (reverse clutch, high clutch and front sun gear) from transmission case.


EL



SAT986A

SAT655







Clip

17. Remove front side clutch and gear components.







- b. Remove front bearing race from clutch pack.
- c. Remove rear bearing race from clutch pack.




d. Remove front planetary carrier from transmission case.



- e. Remove front needle bearing from front planetary carrier.
- f. Remove rear bearing from front planetary carrier.




g. Remove rear sun gear from transmission case.



- 18. Remove adapter case.
- a. Remove adapter case from transmission case.
- b. Remove adapter case gasket from transmission case.





- c. Remove oil seal from adapter case.
- Do not remove oil seal unless it is to be replaced.



MA

EM

- LC
- d. Remove revolution sensor from adapter case.
- e. Remove O-ring from revolution sensor.



FE

AT

TF

- 19. Remove output shaft and parking gear.
 - Remove rear snap ring from output shaft.



SU



- Slowly push output shaft all the way forward. **Do not use excessive force.**



c. Remove snap ring from output shaft.

Remove parking gear from output shaft.












- Remove output shaft and parking gear as a unit from transmission case.
 - mis- SC




EL

















f. Remove needle bearing from transmission case.




- 20. Remove rear side clutch and gear components.
- a. Remove front internal gear.



b. Remove bearing race from front internal gear.




c. Remove needle bearing from rear internal gear.



d. Remove rear internal gear, forward clutch hub and overrun clutch hub as a set from transmission case.





Remove needle bearing from overrun clutch hub. e.

f. Remove overrun clutch hub from rear internal gear and forward clutch hub.

GI

MA

LC

Remove thrust washer from overrun clutch hub.

EG

FE

AT

TF

Remove forward clutch assembly from transmission case.

PD

AX

SU


BR

ST

BT


HA

SC





Hold piston with a rag and gradually direct air to oil hole. Remove return springs.

EL



SAT037B






21. Remove band servo and accumulator components.


Remove band servo retainer from transmission case.






- d. Remove springs from accumulator pistons B, C and D.
- e. Apply compressed air to each oil hole until piston comes out.
- Hold piston with a rag and gradually direct air to oil hole.


Identification of accumulator pistons	А	В	С	D
Identification of oil holes	а	b	С	d




f. Remove O-ring from each piston.



- 22. Remove manual shaft components, if necessary.
- a. Hold width across flats of manual shaft (outside the transmission case) and remove lock nut from shaft.




b. Remove retaining pin from transmission case.



c. While pushing detent spring down, remove manual plate and parking rod from transmission case.





Spacer

d. Remove manual shaft from transmission case.

G[

MA

EM

LG

Remove spacer and detent spring from transmission case.

EC

FE

AT

TF

Remove oil seal from transmission case.

PD

SU

BR

ST


RS

BT

HA

SC


EL






Oil Pump COMPONENTS

NBAT0112







DISASSEMBLY

NBAT011

1. Loosen bolts in numerical order and remove oil pump cover.



- 2. Remove rotor, vane rings and vanes.
- Inscribe a mark on back of rotor for identification of foreaft direction when reassembling rotor. Then remove rotor.




- 3. While pushing on cam ring remove pivot pin.
- Be careful not to scratch oil pump housing.

REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)





While holding cam ring and spring lift out cam ring spring.

Be careful not to damage oil pump housing.

Hold cam ring spring to prevent it from jumping.

GI

MA

LC

Remove cam ring and cam ring spring from oil pump housing.

EC

FE

AT

TF

AX

SU


ST


BT


HA

SC


NRAT0114S01 EL







- Remove oil seal from oil pump housing.
- Be careful not to scratch oil pump housing.





INSPECTION


Oil Pump Cover, Rotor, Vanes, Control Piston, Side Seals, Cam Ring and Friction Ring


Check for wear or damage.














Side Clearances

Measure side clearances between end of oil pump housing and cam ring, rotor, vanes and control piston. Measure in at least four places along their circumferences. Maximum measured values should be within specified positions.

 Before measurement, check that friction rings, O-ring, control piston side seals and cam ring spring are removed.

Standard clearance (Cam ring, rotor, vanes and control piston):

Refer to SDS, AT-343.

 If not within standard clearance, replace oil pump assembly except oil pump cover assembly.

Seal Ring Clearance

NBAT0114S03

Measure clearance between seal ring and ring groove.

Standard clearance:

0.10 - 0.25 mm (0.0039 - 0.0098 in)

Wear limit:

0.25 mm (0.0098 in)

If not within wear limit, replace oil pump cover assembly.

ASSEMBLY

NBAT0115

- 1. Drive oil seal into oil pump housing.
- Apply ATF to outer periphery and lip surface.


- 2. Install cam ring in oil pump housing by the following
- a. Install side seal on control piston.
- Pay attention to its direction Black surface goes toward control piston.
- Apply petroleum jelly to side seal.
- b. Install control piston on oil pump.
- Install O-ring and friction ring on cam ring.
- Apply petroleum jelly to O-ring.



REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd,





Assemble cam ring, cam ring spring and spring seat. Install spring by pushing it against pump housing.

GI

MA

LC

While pushing on cam ring install pivot pin.

Install rotor, vanes and vane rings. Pay attention to direction of rotor.

Install oil pump housing and oil pump cover.

Tighten bolts in a criss-cross pattern.

Wrap masking tape around splines of oil pump cover assembly to protect seal. Position oil pump cover assembly in oil

Install new seal rings carefully after packing ring grooves with

petroleum jelly. Press rings down into jelly to a close fit.

pump housing assembly, then remove masking tape.

EC

AT

AX

ST

HA

SC

Seal rings come in two different diameters. Check fit care-

EL


Small dia. seal ring: No mark


fully in each groove.


Large dia. seal ring:


Yellow mark in area shown by arrow

Do not spread gap of seal ring excessively while installing. It may deform ring.












Control Valve Assembly COMPONENTS


NBAT0116



REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd





DISASSEMBLY

Remove solenoids.

Remove torque converter clutch solenoid valve and side plate from lower body.

Remove O-ring from solenoid.

MA

LC

Remove line pressure solenoid valve from upper body.

Remove O-ring from solenoid.

EC

AT

Remove 3-unit solenoid assembly from upper body.

f. Remove O-rings from solenoids.

Disassemble upper and lower bodies.

TF

AX

Place upper body facedown, and remove bolts, reamer bolts and support plates.

Remove lower body, separator plate as a unit from upper body.

RS

Be careful not to drop pilot filter, orifice check valve, spring and steel balls.

BT

HA


Place lower body facedown, and remove separator plate. C.


SC


Remove pilot filter, orifice check valve and orifice check spring.


EL

[DX















Check to see that steel balls are properly positioned in upper body. Then remove them from upper body.




INSPECTION


NBAT0118

Lower and Upper Bodies


Check to see that there are pins and retainer plates in lower body.



- Check to see that there are pins and retainer plates in upper
- Be careful not to lose these parts.



- Check to make sure that oil circuits are clean and free from damage.
- Check tube brackets and tube connectors for damage.



Separator Plate

Make sure that separator plate is free of damage and not deformed and oil holes are clean.

REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd,



Pilot Filter

Check to make sure that filter is not clogged or damaged.



MA

LC

Torque Converter Clutch Solenoid Valve Check that filter is not clogged or damaged.

NBAT0118S04

Measure resistance. Refer to "Component Inspection", AT-146.

Check that filter is not clogged or damaged.

Line Pressure Solenoid Valve

FE

Measure resistance. Refer to "Component Inspection", AT-146.

TF

AT

3-Unit Solenoid Assembly (Overrun Clutch Solenoid Valve and Shift Solenoid Valves A and B)

Measure resistance of each solenoid. Refer to "Component Inspection", AT-146.



ST

A/T Fluid Temperature Sensor and Switch

Measure resistance. Refer to "Component Inspection", AT-109 and AT-251.


HA


SC


ASSEMBLY


Install upper and lower bodies.


Place oil circuit of upper body face up. Install steel balls in their













proper positions.







o. Install reamer bolts from bottom of upper body.



 Place oil circuit of lower body face up. Install orifice check spring, orifice check valve and pilot filter.




- d. Install lower separator plate on lower body.
- e. Install and temporarily tighten support plates, A/T fluid temperature sensor and tube brackets.



- f. Temporarily assemble lower and upper bodies, using reamer bolt as a guide.
- Be careful not to dislocate or drop steel balls, orifice check spring, orifice check valve and pilot filter.

Control Valve Assembly (Cont'd)



Side plate

Install and temporarily tighten bolts and tube brackets in their proper locations.

Bolt length and location:

Bolt symbol	а	b	С	d
Bolt length mm (in)	70 (2.76)	50 (1.97)	33 (1.30)	27 (1.06)







MA

LC

2. Install solenoids.

Attach O-ring and install torque converter clutch solenoid valve and side plates onto lower body.





AT

TF

Attach O-rings and install 3-unit solenoids assembly onto upper body.



Attach O-ring and install line pressure solenoid valve onto upper body.



Tighten all bolts.



SU

BR


ST

RS

BT

HA


SC






Control Valve Upper Body

COMPONENTS



Apply ATF to all components before their installation. Numbers preceding valve springs correspond with those shown in SDS on page AT-340.

Control Valve Upper Body (Cont'd,



Wire paper clip

SAT822A

DISASSEMBLY

Remove valves at parallel pins.

Do not use a magnetic hand.



GI

MA

LC

Use a wire paper clip to push out parallel pins.

EC

FE

AT

TF

Remove parallel pins while pressing their corresponding plugs and sleeves.

PD

Remove plug slowly to prevent internal parts from jumping out.

AX

SU

ST

parts. If a valve is hard to remove, place valve body facedown

Place mating surface of valve facedown, and remove internal


RS

BT


HA

SC

EL




Parallel pin




- and lightly tap it with a soft hammer.
- Be careful not to drop or damage valves and sleeves.
- Remove valves at retainer plates. 2.
- Pry out retainer plate with wire paper clip.

Control Valve Upper Body (Cont'd)







b. Remove retainer plates while holding spring.



- Place mating surface of valve facedown, and remove internal parts.
- If a valve is hard to remove, lightly tap valve body with a soft hammer.
- Be careful not to drop or damage valves, sleeves, etc.



- 4-2 sequence valve and relay valve are located far back in upper body. If they are hard to remove, carefully push them out using stiff wire.
- Be careful not to scratch sliding surface of valve with wire.



INSPECTION

Valve Springs

Measure free length and outer diameter of each valve spring.
Also check for damage or deformation.

Inspection standard:

Refer to SDS, AT-340.

Replace valve springs if deformed or fatigued.


Control Valves

Check sliding surfaces of valves, sleeves and plugs.


NBAT0122S02



- Lubricate the control valve body and all valves with ATF. Install
 control valves by sliding them carefully into their bores.
- Be careful not to scratch or damage valve body.



Control Valve Upper Body (Cont'd)



Sleeve

Screwdriver :

Lightly push sleeve

in while turning it.

Center plug in spool bore

SAT832A


Wrap a small screwdriver with vinyl tape and use it to insert the valves into proper position.

GI

MA

LC

Pressure regulator valve




FE

EC

Turn sleeve slightly while installing.

TF





Vinyl tape

Accumulator control plug

Align protrusion of accumulator control sleeve with notch in plug.

PD

Align parallel pin groove in plug with parallel pin, and install accumulator control valve.

AX

SU

Install parallel pins and retainer plates.


ST

BT

HA

SC

EL




Parallel pin

While pushing plug, install parallel pin.




Control Valve Upper Body (Cont'd)



4-2 sequence valve and relay valve


 Push 4-2 sequence valve and relay valve with wire wrapped in vinyl tape to prevent scratching valve body. Install parallel pins.



• Insert retainer plate while pushing spring.




Control Valve Lower Body



Apply ATF to all components before their installation. Numbers preceding valve springs correspond with those shown in SDS on page AT-340.

Control Valve Lower Body (Cont'd)






DISASSEMBLY

Remove valves at parallel pins.

Remove valves at retainer plates. For removal procedures, refer to "DISASSEMBLY" of Control Valve Upper Body.



INSPECTION Valve Springs

NBAT0126

NBAT0125

Check each valve spring for damage or deformation. Also measure free length and outer diameter.

Inspection standard:

Refer to SDS, AT-340.

Replace valve springs if deformed or fatigued.


Control Valves

Check sliding surfaces of control valves, sleeves and plugs for damage.

ASSEMBLY


NBAT0127


Install control valves. For installation procedures, refer to "ASSEMBLY" of Control Valve Upper Body, AT-292.






Reverse Clutch COMPONENTS







DISASSEMBLY

Check operation of reverse clutch.

Install seal ring onto oil pump cover and install reverse clutch. Apply compressed air to oil hole.

Check to see that retaining plate moves to snap ring. b.

If retaining plate does not contact snap ring, C.

D-ring might be damaged.

Oil seal might be damaged.

Fluid might be leaking past piston check ball.

Remove drive plates, driven plates, retaining plate, dish plate and snap ring.

MA

LC

EC

FE

AT

TF

AX

SU

ST

BT


HA

SC


EL

[DX





- Remove snap ring from clutch drum while compressing clutch springs.
- Do not expand snap ring excessively.
- Remove spring retainer and return spring.



- Install seal ring onto oil pump cover and install reverse clutch drum. While holding piston, gradually apply compressed air to oil hole until piston is removed.
- Do not apply compressed air abruptly.
- 6. Remove D-ring and oil seal from piston.


INSPECTION

Reverse Clutch Snap Ring and Spring Retainer

Check for deformation, fatigue or damage.

NRAT0130

NBAT0130S01



Facing

Core plate

SAT845A

Thickness

Reverse Clutch Return Springs

Check for deformation or damage. Also measure free length and outside diameter.

Inspection standard:

Refer to SDS, AT-340.

Reverse Clutch Drive Plates

NBAT0130S03

Check facing for burns, cracks or damage.

Measure thickness of facing.

Thickness of drive plate:

Standard value: 1.90 - 2.05 mm (0.0748 - 0.0807 in)

Wear limit: 1.80 mm (0.0709 in)

If not within wear limit, replace.


Reverse Clutch Dish Plate

Check for deformation or damage.

NBAT0130S04

Reverse Clutch (Cont'd,






Oil seal ATF

D-ring ATF

Reverse Clutch Piston

Shake piston to assure that balls are not seized.



Also apply compressed air to oil hole on return spring side to assure that air leaks past ball.

NBAT0130S05

MA

LC

ASSEMBLY

Install D-ring and oil seal on piston.

Apply ATF to both parts.

EC

NBAT0131

FE

AT

Install piston assembly by turning it slowly and evenly.

Install snap ring while compressing clutch springs.

Apply ATF to inner surface of drum.

TF

AX

SU


ST

BT

HA

SC

EL




3. Install return springs and spring retainer.

SAT849A


SAT524G

KV31102400 (J34285 and J34285-87)






Do not align snap ring gap with spring retainer stopper.



- 5. Install drive plates, driven plates, retaining plate and dish plate.
- 6. Install snap ring.



7. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard


0.5 - 0.8 mm (0.020 - 0.031 in)

Allowable limit

1.2 mm (0.047 in)

Retaining plate:

Refer to SDS, AT-341.



8. Check operation of reverse clutch. Refer to "DISASSEMBLY" of Reverse Clutch, AT-297.

MA

LC

EC

FE

AT

TF

PD

AX

SU

BR


ST


BT


HA

EL

High Clutch COMPONENTS








DISASSEMBLY AND ASSEMBLY

Service procedures for high clutch are essentially the same as those for reverse clutch, with the following exception:


Check of high clutch operation

SC







Removal and installation of return spring



Inspection of high clutch return springs
 Inspection standard:
 Refer to SDS, AT-340.



Inspection of high clutch drive plate
 Thickness of drive plate:
 Standard
 1.52 - 1.67 mm (0.0598 - 0.0657 in)
 Wear limit
 1.40 mm (0.0551 in)



Measurement of clearance between retaining plate and snap ring

Specified clearance:


Standard
1.8 - 2.2 mm (0.071 - 0.087 in)
Allowable limit
2.8 mm (0.110 in)
Retaining plate:
Refer to SDS, AT-341.



Forward and Overrun Clutches COMPONENTS


NBAT0134 G





ATF : Apply ATF.


★ : Select with proper thickness.




DISASSEMBLY AND ASSEMBLY

Forward and overrun clutches are serviced essentially the same way as reverse clutch is serviced. However, note the following exceptions.


• Check of forward clutch operation




Check of overrun clutch operation



Removal of forward clutch drum
 Remove forward clutch drum from transmission case by holding snap ring.




- Removal of forward clutch and overrun clutch pistons
- a) While holding overrun clutch piston, gradually apply compressed air to oil hole.



b) Remove overrun clutch from forward clutch.

Forward and Overrun Clutches (Cont'd)



Removal and installation of return springs

GI

MA

LC

Inspection of forward clutch and overrun clutch return springs Inspection standard:

EC

FE

AT

TF

Inspection of forward clutch drive plates

Refer to SDS, AT-340.

Thickness of drive plate: **Standard**

1.52 - 1.67 mm (0.0598 - 0.0657 in)

Wear limit

1.40 mm (0.0551 in)

AX

SU

ST


BT

HA

SC

EL

[DX




Facing

Core plate

Core plate


Thickness

Thickness



SAT845A

SAT845A



Inspection of overrun clutch drive plates Thickness of drive plate:

Standard

1.90 - 2.05 mm (0.0748 - 0.0807 in)

Wear limit

1.80 mm (0.0709 in)


Installation of forward clutch piston and overrun clutch piston

Install forward clutch piston by turning it slowly and evenly.


Apply ATF to inner surface of clutch drum.




Forward and Overrun Clutches (Cont'd)



Align notch in forward clutch piston with groove in forward clutch drum.



- b) Install overrun clutch by turning it slowly and evenly.
- Apply ATF to inner surface of forward clutch piston.



 Measurement of clearance between retaining plate and snap ring of overrun clutch

Specified clearance:

Standard


1.0 - 1.4 mm (0.039 - 0.055 in)

Allowable limit

2.0 mm (0.079 in)

Retaining plate:

Refer to SDS, AT-342.



 Measurement of clearance between retaining plate and snap ring of forward clutch

Specified clearance:

Standard

0.35 - 0.75 mm (0.0138 - 0.0295 in)

Allowable limit

1.85 mm (0.0728 in)

Retaining plate:

Refer to SDS, AT-342.



GI

MA

LC

EC

FE

ΑT

TF

PD

AX

SU

ST


BT


HA


SC

EL

Low & Reverse Brake COMPONENTS







DISASSEMBLY

Check operation of low and reverse brake.

Install seal ring onto oil pump cover and install reverse clutch. Apply compressed air to oil hole.

b. Check to see that retaining plate moves to snap ring.

If retaining plate does not contact snap ring, C.

D-ring might be damaged.

Oil seal might be damaged.


Fluid might be leaking past piston check ball.

Remove snap ring, low and reverse brake drive plates, driven


plates and dish plate.

Low & Reverse Brake (Cont'd)





- 3. Remove low one-way clutch inner race, spring retainer and return spring from transmission case.
- Remove seal rings from low one-way clutch inner race.
- Remove needle bearing from low one-way clutch inner race.




- Remove low and reverse brake piston using compressed air.
- Remove oil seal and D-ring from piston.

INSPECTION

Low and Reverse Brake Snap Ring and Spring Retainer

Check for deformation, or damage.



Low and Reverse Brake Return Springs

Check for deformation or damage. Also measure free length and outside diameter.

> **Inspection standard:** Refer to SDS, AT-340.

Low and Reverse Brake Drive Plates

NBAT0138S03

- Check facing for burns, cracks or damage.
- Measure thickness of facing.

Thickness of drive plate:


Standard value

1.52 - 1.67 mm (0.0598 - 0.0657 in)

Wear limit


1.40 mm (0.0551 in)

If not within wear limit, replace.



Low & Reverse Brake (Cont'd,





L Clearance

Seal ring

Low One-way Clutch Inner Race

Check frictional surface of inner race for wear or damage.

GI

MA

LC

EC

FE

Install a new seal rings onto low one-way clutch inner race.

Be careful not to expand seal ring gap excessively.

Measure seal ring-to-groove clearance.

Inspection standard:

Standard value: 0.10 - 0.25 mm (0.0039 - 0.0098 in) Allowable limit: 0.25 mm (0.0098 in)

If not within allowable limit, replace low one-way clutch inner race.

AT

TF

ASSEMBLY

SAT878A

Install needle bearing onto one-way clutch inner race.

Pay attention to its direction — Black surface goes to rear

AX

Apply petroleum jelly to needle bearing.


SU


ST


HA

SC

EL








- Install oil seal and D-ring onto piston.
- Apply ATF to oil seal and D-ring.


- Install piston by rotating it slowly and evenly. 3.
- Apply ATF to inner surface of transmission case.




Low & Reverse Brake (Cont'd)



- 4. Install return springs, spring retainer and low one-way clutch inner race onto transmission case.
- 5. Install dish plate, low and reverse brake drive plates, driven plates and retaining plate.
- 6. Install snap ring on transmission case.



7. Check operation of low and reverse brake clutch piston. Refer to "DISASSEMBLY", AT-307.



8. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard


0.8 - 1.1 mm (0.031 - 0.043 in)

Allowable limit

2.3 mm (0.091 in)

Retaining plate:


Refer to SDS, AT-343.



- 9. Install low one-way clutch inner race seal ring.
- Apply petroleum jelly to seal ring.
- Make sure seal rings are pressed firmly into place and held by petroleum jelly.

Forward Clutch Drum Assembly

Forward Clutch Drum Assembly COMPONENTS



AT

TF

PD

AX

SU

BR

ST

BT

HA


NBAT0141

MA

LC


EG

FE




DISASSEMBLY

- 1. Remove snap ring from forward clutch drum.
- 2. Remove side plate from forward clutch drum.




- 3. Remove low one-way clutch from forward clutch drum.
- 4. Remove snap ring from forward clutch drum.

5. Remove needle bearing from forward clutch drum.




SC

EL








INSPECTION

Forward Clutch Drum

NBAT014

NBAT0142S01


- Check spline portion for wear or damage.
- Check frictional surfaces of low one-way clutch and needle bearing for wear or damage.



Needle Bearing and Low One-way Clutch

NBAT0142S02


Check frictional surface for wear or damage.




ASSEMBLY

NBAT0143

- 1. Install needle bearing in forward clutch drum.
- 2. Install snap ring onto forward clutch drum.




3. Install low one-way clutch onto forward clutch drum by pushing the roller in evenly.



Install low one-way clutch with flange facing rearward.



Forward Clutch Drum Assembly (Cont'd)



- Install side plate onto forward clutch drum.
- Install snap ring onto forward clutch drum.

GI

MA


EM

LC

EG

FE

Rear Internal Gear and Forward Clutch Hub **COMPONENTS**



AT

TF

PD

AX

SU

SAT897A

DISASSEMBLY

Remove rear internal gear by pushing forward clutch hub forward.

RS

ST


BT

HA

Remove thrust washer from rear internal gear.


EL

SC







Rear Internal Gear and Forward Clutch Hub (Cont'd)




3. Remove snap ring from forward clutch hub.




4. Remove end bearing.



5. Remove forward one-way clutch and end bearing as a unit from forward clutch hub.



6. Remove snap ring from forward clutch hub.



INSPECTION


Rear Internal Gear and Forward Clutch Hub

NBAT0146

NBAT0146S01

- Check gear for excessive wear, chips or cracks.
- Check frictional surfaces of forward one-way clutch and thrust washer for wear or damage.
- Check spline for wear or damage.

Rear Internal Gear and Forward Clutch Hub (Cont'd)



Snap Ring and End Bearing

Check for deformation or damage.

GI

MA

EM

LC

ASSEMBLY

SAT901A

1. Install snap ring onto forward clutch hub.


NBAT0147

Install end bearing.

FE

AT

TF



AX

SU

ST

Install thrust washer onto rear internal gear. Apply petroleum jelly to thrust washer.

Securely insert pawls of thrust washer into holes in rear

internal gear.


HA

BT


Position forward clutch hub in rear internal gear.

EL

SC




Face arrow toward the front.







Rear Internal Gear and Forward Clutch Hub (Cont'd)




After installing, check to assure that forward clutch hub rotates clockwise.

Band Servo Piston Assembly COMPONENTS








DISASSEMBLY

- Block one oil hole in OD servo piston retainer and the center hole in OD band servo piston.
- Apply compressed air to the other oil hole in piston retainer to remove OD band servo piston from retainer.
- Remove D-ring from OD band servo piston.

Remove band servo piston assembly from servo piston retainer by pushing it forward.

Band Servo Piston Assembly (Cont'd)



SAT912A

SAT913A

E-ring

Place piston stem end on a wooden block. While pushing servo piston spring retainer down, remove E-ring.



MA

LC

Remove servo piston spring retainer, return spring C and piston stem from band servo piston.



FE

AT

TF

Remove E-ring from band servo piston.



AX

SU

BR

- 8. Remove servo cushion spring retainer from band servo piston. ST
- Remove D-rings from band servo piston. 10. Remove O-rings from servo piston retainer.












SC



Pistons, Retainers and Piston Stem


Check frictional surfaces for abnormal wear or damage.





Band Servo Piston Assembly (Cont'd)






Return Springs

Check for deformation or damage. Measure free length and outer diameter.


Inspection standard: Refer to SDS, AT-340.




ASSEMBLY

NBAT0151


- 1. Install O-rings onto servo piston retainer.
- Apply ATF to O-rings.
- Pay attention to position of each O-ring.



2. Install servo cushion spring retainer onto band servo piston.




3. Install E-ring onto servo cushion spring retainer.



- 4. Install D-rings onto band servo piston.
- Apply ATF to D-rings.

Band Servo Piston Assembly (Cont'd)



Install servo piston spring retainer, return spring C and piston stem onto band servo piston.

GI

MA

EM

LC



E-ring


Place piston stem end on a wooden block. While pushing servo piston spring retainer down, install E-ring.

EC

FE

AT

TF



7. Install band servo piston assembly onto servo piston retainer by pushing it inward.

PD

AX

SU

BR

ST

Install D-ring on OD band servo piston. Apply ATF to D-ring.


RS

BT

HA

SC

EL




Install OD band servo piston onto servo piston retainer by pushing it inward.




SAT924A



Parking Pawl Components COMPONENTS







DISASSEMBLY

NBAT0153

- 1. Slide return spring to the front of adapter case flange.
- Remove return spring, parking pawl spacer and parking pawl from adapter case.
- 3. Remove parking pawl shaft from adapter case.



4. Remove parking actuator support from adapter case.



INSPECTION


Parking Pawl and Parking Actuator Support


Check contact surface of parking rod for wear.


NBAT0209 NBAT0209S01

Parking Pawl Components (Cont'd)









ASSEMBLY

Install parking actuator support onto adapter case.

Insert parking pawl shaft into adapter case.

Install return spring, pawl spacer and parking pawl onto parking pawl shaft.



MA

LC

Bend return spring upward and install it onto adapter case.

EC

FE

AT

TF

PD

AX

SU

BR

ST


RS

BT


HA

SC

EL









Assembly (1)

NBAT015


- 1. Install manual shaft components.
- a. Install oil seal onto manual shaft.
- Apply ATF to oil seal.
- Wrap threads of manual shaft with masking tape.
- b. Insert manual shaft and oil seal as a unit into transmission case.
- c. Remove masking tape.




d. Push oil seal evenly and install it onto transmission case.



e. Align groove in shaft with retaining pin hole, then retaining pin into position as shown in figure at left.



- f. Install detent spring and spacer.
- g. While pushing detent spring down, install manual plate onto manual shaft.




n. Install lock nuts onto manual shaft.



GI

MA



2.	Install	accumulator	piston.
----	---------	-------------	---------

a. Install O-rings onto accumulator piston.

Apply ATF to O-rings.

Accumulator piston O-rings

 Accumulator
 A
 B
 C
 D

 Small diameter end
 29 (1.14)
 32 (1.26)
 45 (1.77)
 29 (1.14)

 Large diameter end
 45 (1.77)
 50 (1.97)
 50 (1.97)
 45 (1.77)

LC

Install return spring for accumulator A onto transmission case.
 Free length of return spring:

Refer to SDS, AT-340.

EC

FE

AT

TE

c. Install accumulator pistons A, B, C and D.

Install return springs onto servo piston.

Apply ATF to transmission case.

Install band servo piston.

PD

AX

SU

BK


ST


HA


SC


EL

- . Install band servo piston onto transmission case.
- Apply ATF to O-ring of band servo piston and transmission case.
- c. Install gasket for band servo onto transmission case.

















d. Install band servo retainer onto transmission case.




- 4. Install rear side clutch and gear components.
- a. Place transmission case in vertical position.



 Slightly lift forward clutch drum assembly. Then slowly rotate it clockwise until its hub passes fully over clutch inner race inside transmission case.




c. Check to be sure that rotation direction of forward clutch assembly is correct.



- d. Install thrust washer onto front of overrun clutch hub.
- Apply petroleum jelly to the thrust washer.
- Insert pawls of thrust washer securely into holes in overrun clutch hub.





Install overrun clutch hub onto rear internal gear assembly.

GI

MA

EM

LC

Install needle bearing onto rear of overrun clutch hub.

Apply petroleum jelly to needle bearing.





AT

TF













RS






















Check that overrun clutch hub rotates as shown while holding forward clutch hub.




h. Place transmission case into horizontal position.




Install rear internal gear, forward clutch hub and overrun clutch hub as a unit onto transmission case.







- j. Install needle bearing onto rear internal gear.
- Apply petroleum jelly to needle bearing.




- k. Install bearing race onto rear of front internal gear.
- Apply petroleum jelly to bearing race.
- Securely engage pawls of bearing race with holes in front internal gear.



I. Install front internal gear on transmission case.




- 5. Install output shaft and parking gear.
- Insert output shaft from rear of transmission case while slightly lifting front internal gear.
- Do not force output shaft against front of transmission case.



- b. Carefully push output shaft against front of transmission case. Install snap ring on front of output shaft.
- Check to be sure output shaft cannot be removed in rear direction.





c. Install needle bearing on transmission case.

Pay attention to its direction — Black side goes to rear.

Apply petroleum jelly to needle bearing.

GI

MA

EM

LC


Install parking gear on transmission case.

EG

FE

AT

TF



PD Check to be sure output shaft cannot be removed in forward direction.

AX

SU


BR

ST

HA

SC

EL



Install adapter case.

Install oil seal on adapter case.

Apply ATF to oil seal.

BT



SAT757I

Install O-ring on revolution sensor. b.


Apply ATF to O-ring.

Install revolution sensor on adapter case.




ST33200000-(J26082)







d. Install adapter case gasket on transmission case.




e. Install parking rod on transmission case.



f. Install adapter case on transmission case.




- 7. Install front side clutch and gear components.
- a. Install rear sun gear on transmission case.
- Pay attention to its direction.



- b. Make sure needle bearing is on front of front planetary carrier.
- Apply petroleum jelly to needle bearing.
- c. Make sure needle bearing is on rear of front planetary carrier.
- Apply petroleum jelly to bearing.
- Pay attention to its direction Black side goes to front.





Front planetary carrier

Forward clutch drum

SAT970A

d. While rotating forward clutch drum clockwise, install front planetary carrier on forward clutch drum.

 \mathbb{G}

MA

EM

LC

 Check that portion A of front planetary carrier protrudes approximately 2 mm (0.08 in) beyond portion B of forward clutch assembly.

EC FE

AT

TF

- e. Make sure bearing races are on front and rear of clutch pack.
- Apply petroleum jelly to bearing races.
- Securely engage pawls of bearing races with holes in clutch pack.

 $\mathbb{A}\mathbb{X}$

PD

SU

BR

ST


RS


BT

HA

SC

EL





f. Install clutch pack into transmission case.


ASSEMBLY



Adjustment


When any parts listed in the following table are replaced, total end play or reverse clutch end play must be adjusted.

·	-	
Part name	Total end play	Reverse clutch end play
Transmission case	•	•
Low one-way clutch inner race	•	•
Overrun clutch hub	•	•
Rear internal gear	•	•
Rear planetary carrier	•	•
Rear sun gear	•	•
Front planetary carrier	•	•
Front sun gear	•	•
High clutch hub	•	•
High clutch drum	•	•
Oil pump cover	•	•
Reverse clutch drum	_	•




Adjust total end play.

Total end play "T₁": 0.25 - 0.55 mm (0.0098 - 0.0217 in)




a. With needle bearing installed, place J34291-1 (bridge), J34291-2 (legs) and the J34291-5 (gauging cylinder) onto oil pump. The long ends of legs should be placed firmly on machined surface of oil pump assembly. The gauging cylinder should rest on top of the needle bearing. Lock gauging cylinder in place with set screw.



b. Install J34291-23 (gauging plunger) into gauging cylinder.





Install original bearing race inside reverse clutch drum. Place shim selecting gauge with its legs on machined surface of transmission case (no gasket). Allow gauging plunger to rest on bearing race. Lock gauging plunger in place with set screw.



MA

LC

Remove Tool and use feeler gauge to measure gap between gauging cylinder and gauging plunger. This measurement should give exact total end play. Total end play "T₁":



0.25 - 0.55 mm (0.0098 - 0.0217 in)



If end play is out of specification, decrease or increase thickness of oil pump cover bearing race as necessary.



Available oil pump cover bearing race: Refer to SDS, AT-343.



Adjust reverse clutch drum end play.

Reverse clutch drum end play "T2": 0.55 - 0.90 mm (0.0217 - 0.0354 in)



AX











HA









Feeler gauge







Place J34291-1 (bridge), J34291-2 (legs) and J34291-5 (gauging cylinder) on machined surface of transmission case (no gasket). Allow gauging cylinder to rest on front thrust surface of reverse clutch drum. Lock cylinder in place with set screw.







c. Install original thrust washer on oil pump. Place shim setting gauge legs onto machined surface of oil pump assembly. Allow gauging plunger to rest on thrust washer. Lock plunger in place with set screw.




d. Use feeler gauge to measure gap between gauging plunger and gauging cylinder. This measurement should give you exact reverse clutch drum end play.

Reverse clutch drum end play "T₂": 0.55 - 0.90 mm (0.0217 - 0.0354 in)

 If end play is out of specification, decrease or increase thickness of oil pump thrust washer as necessary.


Available oil pump thrust washer: Refer to SDS, AT-344.




Assembly (2)

NBAT0157

- 1. Install brake band and band strut.
- a. Install band strut on brake band.
- Apply petroleum jelly to band strut.




b. Place brake band on periphery of reverse clutch drum, and insert band strut into end of band servo piston stem.



c. Install anchor end bolt on transmission case. Then, tighten anchor end bolt just enough so that reverse clutch drum (clutch pack) will not tilt forward.





2. Install input shaft on transmission case.

• Pay attention to its direction — O-ring groove side is front.


3. Install gasket on transmission case.

MA

GI

LC

EC



4. Install oil pump assembly.

a. Install needle bearing on oil pump assembly.

Apply petroleum jelly to the needle bearing.

b. Install selected thrust washer on oil pump assembly.

Apply petroleum jelly to thrust washer.

FE

AT

TF e PD

ing (ing)

 Carefully install seal rings into grooves and press them into the petroleum jelly so that they are a tight fit.

AX

5L/\L

SU

BK

ST


RS

BT

HA


e SC

EL



d. Install O-ring on oil pump assembly.

• Apply petroleum jelly to O-ring.




O-ring 🚮 (P)


SAT991A

e. Apply petroleum jelly to mating surface of transmission case and oil pump assembly.







- f. Install oil pump assembly.
- Install two converter housing securing bolts in bolt holes in oil pump assembly as guides.




 Insert oil pump assembly to the specified position in transmission, as shown at left.



- 5. Install O-ring on input shaft.
- Apply ATF to O-rings.




- 6. Install converter housing.
- Apply recommended sealant (Genuine anaerobic liquid gasket, Three Bond TB1215, Locktite Part No. 51813 or equivalent) to outer periphery of bolt holes in converter housing
- Do not apply too much sealant.



- b. Apply recommended sealant (Genuine anaerobic liquid gasket, Three Bond TB1215, Locktite Part No. 51813 or equivalent) to seating surfaces of bolts that secure front of converter housing.
- c. Install converter housing on transmission case.





7. Adjust brake band.

a. Tighten anchor end bolt to specified torque.

Anchor end bolt:

(0.4 - 0.6 kg-m, 35 - 52 in-lb)

b. Back off anchor end bolt two and a half turns.

GI

MA

LC

L

While holding anchor end bolt, tighten lock nut.

EG

FE

AT

TF

. Install terminal cord assembly.

SAT002B

SAT115B

41 P 9

a. Install O-ring on terminal cord assembly.

PD

Apply petroleum jelly to O-ring.

b. Compress terminal cord assembly stopper and install terminal cord assembly on transmission case.

AX

SU

BK

ST

Install control valve assembly.Install accumulator piston return springs B, C and D.


Free length of return springs: Refer to SDS, AT-340.


BT

HA

SC

EL







o. Install manual valve on control valve.

Apply ATF to manual valve.






- c. Place control valve assembly on transmission case. Connect solenoid connector for upper body.
- d. Install connector clip.




- e. Install control valve assembly on transmission case.
- f. Install connector tube brackets and tighten bolts A and B.
- Check that terminal assembly does not catch.

Bolt symbol	ℓ mm (in) 🖳 ℓ
A	33 (1.30)
В	45 (1.77)




- g. Install O-ring on oil strainer.
- Apply petroleum jelly to O-ring.
- h. Install oil strainer on control valve.



i. Securely fasten terminal harness with clips.





j. Install torque converter clutch solenoid valve and A/T fluid temperature sensor connectors.

GI

MA

LC

10. Install oil pan.

SAT011B

SAT365I

Attach a magnet to oil pan.



FE

AT

TF

Install new oil pan gasket on transmission case.

Install oil pan and bracket on transmission case. C.



Always replace oil pan bolts as they are self-sealing bolts.

Before installing bolts, remove traces of sealant and oil from mating surface and thread holes.




Tighten four bolts in a criss-cross pattern to prevent dislocation of gasket.



Tighten drain plug.



11. Install PNP switch.





Temporarily install PNP switch on manual shaft.




Move manual shaft to "N".




HA

SC









Tighten bolts while inserting 4.0 mm (0.157 in) dia. pin vertically into locating holes in PNP switch and manual shaft.

ASSEMBLY






- 12. Install torque converter.
- a. Pour ATF into torque converter.
- Approximately 2 liters (2-1/8 US qt, 1-3/4 Imp qt) of fluid are required for a new torque converter.
- When reusing old torque converter, add the same amount of fluid as was drained.



b. Install torque converter while aligning notches and oil pump.



 Measure distance A to check that torque converter is in proper position.

Distance "A": 26.0 mm (1.024 in) or more

General Specification

		General Specifications	1
		VG33E engine	. (
Applied model		4WD	
Automatic transmission mo	del	RE4R01A	. [
Transmission model code r	number	43X78	
Stall torque ratio		2.0 : 1	
	1st	2.785	
	2nd	1.545	. [
Transmission gear ratio	Тор	1.000	
	OD	0.694	[
	Reverse	2.272	
Recommended fluid		Nissan Matic "D" (Continental U.S. and Alaska) or Genuine Nissan Automatic Transmission Fluid (Canada)*1	. [
Fluid capacity		8.5ℓ (9 US qt, 7-1/2 Imp qt)	

Shift Schedule VEHICLE SPEED WHEN SHIFTING GEARS THROTTLE POSITION

NBAT0178

TF

NBAT0178S01

Throttle meeties	Vehicle speed km/h (MPH)					PD		
Throttle position	$D_1 \rightarrow D_2$	$D_2 \rightarrow D_3$	$D_3 \rightarrow D_4$	$D_4 \rightarrow D_3$	$D_3 \rightarrow D_2$	$D_2 \rightarrow D_1$	1 ₂ → 1 ₁	_
Full throttle	48 - 52 (30 - 32)	93 - 101 (58 - 63)	148 - 158 (92 - 98)	143 - 153 (89 - 95)	88 - 96 (55 - 60)	43 - 47 (27 - 29)	44 - 48 (27 - 30)	AX
Half throttle	35 - 39 (22 - 24)	69 - 75 (43 - 47)	134 - 142 (83 - 88)	59 - 67 (37 - 42)	32 - 38 (20 - 24)	10 - 14 (6 - 9)	44 - 48 (27 - 30)	SU

VEHICLE SPEED WHEN PERFORMING AND RELEASING LOCK-UP

4WD (Final gear ratio: 4.363) and 4WD (Final gear ratio: 4.636)

NBAT0178S02

BR

ST

RS

BT

HA

SC

EL

Throttle position	Overdrive control switch [Shift posi-	Vehicle speed km/h (MPH)		
Throttle position	tion]	Lock-up "ON"	Lock-up "OFF"	
Full throttle	ON [D ₄]	149 - 157 (93 - 98)	144 - 152 (89 - 94)	
	OFF [D ₃]	74 - 82 (46 - 51)	71 - 79 (44 - 49)	
Half throttle	ON [D ₄]	141 - 149 (88 - 93)	85 - 93 (53 - 58)	
Hall throttle	OFF [D ₃]	74 - 82 (46 - 51)	71 - 79 (44 - 49)	

Stall Revolution

NBAT0163

Stall revolution rpm 2,440 - 2,640

Line Pressure

NBAT0164

Engine speed	Line pressure kPa (kg/cm², psi)			
rpm	D, 2 and 1 positions	R position		
Idle	422 - 461 (4.3 - 4.7, 61 - 67)	667 - 706 (6.8 - 7.2, 97 - 102)		
Stall	1,020 - 1,098 (10.4 - 11.2, 148 - 159)	1,422 - 1,500 (14.5 - 15.3, 206 - 218)		





Return Springs

Unit: mm (in)

						Unit: mm (i
					Item	
Parts —			Part No.*	Free length	Outer diameter	
		Torque converter relief valve spring		31742-41X23	38.0 (1.496)	9.0 (0.354)
		Pressure regulator valve spring		31742-41X24	44.02 (1.7331)	14.0 (0.551)
		Pressure modifier valve spring		31742-41X19	31.95 (1.2579)	6.8 (0.268)
		Accumulator control valve spring		_	_	_
		Shuttle shift valve D spring		31762-41X01	25.0 (0.984)	7.0 (0.276)
		4-2 sequence valve spring		31756-41X00	29.1 (1.146)	6.95 (0.2736)
		Shift valve B spring		31762-41X01	25.0 (0.984)	7.0 (0.276)
	Upper body	4-2 relay valve spring		31756-41X00	29.1 (1.146)	6.95 (0.2736)
		Shift valve A spring		31762-41X01	25.0 (0.984)	7.0 (0.276)
Control valve		Overrun clutch control valve spring		31762-41X03	23.6 (0.929)	7.0 (0.276)
		Overrun clutch reducing valve spring		31742-41X20	32.5 (1.280)	7.0 (0.276)
		Shuttle shift valve S spring		31762-41X04	51.0 (2.008)	5.65 (0.2224)
		Pilot valve spring		31742-41X13	25.7 (1.012)	9.0 (0.354)
		Torque converter clutch control valve spring		31742-41X22	18.5 (0.728)	13.0 (0.512)
		Modifier accumulator valve spring		31742-27X70	31.4 (1.236)	9.8 (0.386)
		1st reducing valve spring		31756-41X05	25.4 (1.000)	6.75 (0.2657)
	Lower body	3-2 timing valve spring		31742-41X06	23.0 (0.906)	6.7 (0.264)
		Servo charger valve spring		31742-41X06	23.0 (0.906)	6.7 (0.264)
Reverse clutch	1		16 pcs	31521-41X02 (Assembly)	19.7 (0.7756)	11.6 (0.457)
High clutch			10 pcs	31521-41X03 (Assembly)	24.2 (0.9528)	11.6 (0.457)
Forward clutch clutch)	(Overrun		20 pcs	31521-41X00 (Assembly)	35.77 (1.4083)	9.7 (0.382)
Low & reverse	brake		18 pcs	31655-41X00 (Assembly)	22.3 (0.878)	11.2 (0.441)
		Spring A		31605-41X05	45.6 (1.795)	34.3 (1.350)
Band servo		Spring B		31605-41X00	53.8 (2.118)	40.3 (1.587)
		Spring C		31605-41X01	29.7 (1.169)	27.6 (1.087)
		Accumulator A		31605-41X02	43.0 (1.693)	18.0 (0.709)
A course data :		Accumulator B		31605-41X10	66.0 (2.598)	20.0 (0.787)
Accumulator		Accumulator C		31605-41X09	45.0 (1.772)	29.3 (1.154)
		Accumulator D		31605-41X06	58.4 (2.299)	17.3 (0.681)

^{*:} Always check with the Parts Department for the latest parts information.



Accumulator O-ring

Accumulator O-ring					166
Accounting		Diamete	er mm (in)		_
Accumulator	А	В	С	D	_
Small diameter end	29 (1.14)	32 (1.26)	45 (1.77)	29 (1.14)	_
Large diameter end	45 (1.77)	50 (1.97)	50 (1.97)	45 (1.77)	_

MA

GI

Clutches and Brakes

NBAT0167

	CDCC	\boldsymbol{c}	IITCU
REV	ERSE	C-L	итьп

			NBAT0167S01	
Code number		43X78		
Number of drive plates		2	2	
Number of driven plates	es 2		2	
Standard		1.90 - 2.05 (0.	0748 - 0.0807)	
Thickness of drive plate mm (in)	Wear limit	1.80 (0	0.0709)	
Classes may (in)	Standard	0.5 - 0.8 (0.020 - 0.031)		
Clearance mm (in)	Allowable limit	1.2 (0.047)		
		Thickness mm (in)	Part number*	
Thickness of retaining plate		4.8 (0.189) 5.0 (0.197) 5.2 (0.205) 5.4 (0.213)	31537-42X02 31537-42X03 31537-42X04 31537-42X05	

5.6 (0.220)

4.0 (0.157)

4.2 (0.165)

4.4 (0.173)

4.6 (0.181)

4.8 (0.189)

AT

EC

FE

TF PD 31537-42X05 31537-42X06



AX

HI	GH	CL	UΙ	CH

Thickness of retaining plate

NBAT0167S02	
	SU

Code number		43X78	
Number of drive plates		5	
Number of driven plates		5	
Thickness of drive plate mm (in)	Standard	1.52 - 1.67 (0.0	598 - 0.0657)
	Wear limit	1.40 (0.0551)	
Clearance mm (in) Standard Allowable limit		1.8 - 2.2 (0.071 - 0.087)	
		2.8 (0.110)	
		Thickness mm (in)	Part number*
Third and a factorist and a		3.4 (0.134) 3.6 (0.142)	31537-41X71 31537-41X61
		3.8 (0.150)	31537-41X62

ST	

BR









31537-41X63

31537-41X64

31537-41X65

31537-41X66

31537-41X67

SC	



^{*:} Always check with the Parts Department for the latest parts information.

^{*:} Always check with the Parts Department for the latest parts information.



Clutches and Brakes (Cont'd)

FORWARD CLUTCH			NBAT0167S03	
Code number		43X78		
Number of drive plates		7		
Number of driven plates		7		
Thickness of drive plate mm (in)	Standard	1.52 - 1.67 (0.0598 - 0.0657)		
	Wear limit	1.40 (0.0551)		
01 (1)	Standard	0.35 - 0.75 (0.0138 - 0.0295)		
Clearance mm (in)	Clearance mm (in) Allowable limit		1.85 (0.0728)	
		Thickness mm (in)	Part number*	
Thickness of retaining plate		4.6 (0.181) 4.8 (0.189) 5.0 (0.197) 5.2 (0.205) 5.4 (0.213) 5.6 (0.220)	31537-42X13 31537-42X14 31537-42X15 31537-4AX00 31537-4AX01 31537-4AX02	

^{*:} Always check with the Parts Department for the latest parts information.

OVERRUN CLUTCH

NBAT0167S04 43X78 Code number Number of drive plates 3 5 Number of driven plates Standard 1.90 - 2.05 (0.0748 - 0.0807) Thickness of drive plate mm (in) Wear limit 1.80 (0.0709) Standard 1.0 - 1.4 (0.039 - 0.055) Clearance mm (in) 2.0 (0.079) Allowable limit Thickness mm (in) Part number* 4.2 (0.165) 31537-41X80 4.4 (0.173) 31537-41X81 Thickness of retaining plate 4.6 (0.181) 31537-41X82 4.8 (0.189) 31537-41X83 5.0 (0.197) 31537-41X84

^{*:} Always check with the Parts Department for the latest parts information.



Clutches and Brakes (Cont'd)

				NBAT0167S05
Code number			43X78	
Number of drive plates				7
Number of driven plates				7
Thickness of drive plate mm (in)	Standard		1.52 - 1.6	67 (0.0598 - 0.0657)
Trickless of drive plate filli (iii)	Wear limit		1	.40 (0.0551)
Clearance mm (in)	Standard		0.8 - 1	.1 (0.031 - 0.043)
Clearance min (iii)	Allowable limit		2.3 (0.091)	
			Thickness mm (in)	Part number*
Thickness of retaining plate			6.6 (0.260) 6.8 (0.268) 7.0 (0.276) 7.2 (0.283) 7.4 (0.291) 7.6 (0.299) 7.8 (0.307) 8.0 (0.315) 8.2 (0.323) 8.4 (0.331) 8.6 (0.339) 8.8 (0.346) 9.0 (0.354)	31667-41X17 31667-41X11 31667-41X12 31667-41X13 31667-41X07 31667-41X07 31667-41X08 31667-41X00 31667-41X01 31667-41X01 31667-41X02 31667-41X03 31667-41X04 31667-41X05
-	epartment for the late	est parts informati	ion.	
Anchor end bolt nut tightening torqu		est parts informati	40 - 51 N·m (4.	NBAT0167506 1 - 5.2 kg-m, 30 - 38 ft-lb) - 0.6 kg-m, 35 - 52 in-lb)
Anchor end bolt nut tightening torque	ue	est parts informati	40 - 51 N·m (4.	1 - 5.2 kg-m, 30 - 38 ft-lb)
Anchor end bolt nut tightening torque	ue anchor end bolt		40 - 51 N·m (4.	1 - 5.2 kg-m, 30 - 38 ft-lb) - 0.6 kg-m, 35 - 52 in-lb) 2.5
Anchor end bolt nut tightening torque	ue anchor end bolt	Oil Pump a	40 - 51 N·m (4. 4 - 6 N·m (0.4	1 - 5.2 kg-m, 30 - 38 ft-lb) - 0.6 kg-m, 35 - 52 in-lb) 2.5 Vay Clutch
Anchor end bolt nut tightening torque Anchor end bolt tightening torque Number of returning revolution for a	ue anchor end bolt	Oil Pump a	40 - 51 N·m (4. 4 - 6 N·m (0.4 and Low One-w	1 - 5.2 kg-m, 30 - 38 ft-lb) - 0.6 kg-m, 35 - 52 in-lb) 2.5 vay Clutch NBATO168 Unit: mm (in)
Anchor end bolt nut tightening torque Anchor end bolt tightening torque Number of returning revolution for a	cam ring — oil pump	Oil Pump a	40 - 51 N·m (4. 4 - 6 N·m (0.4	1 - 5.2 kg-m, 30 - 38 ft-lb) - 0.6 kg-m, 35 - 52 in-lb) 2.5 Vay Clutch Unit: mm (in) 0.01 - 0.024 (0.0004 - 0.0009)
Anchor end bolt nut tightening torque Anchor end bolt tightening torque Number of returning revolution for a	cam ring — oil pump	Oil Pump a	40 - 51 N·m (4. 4 - 6 N·m (0.4) and Low One-w Standard Standard	1 - 5.2 kg-m, 30 - 38 ft-lb) - 0.6 kg-m, 35 - 52 in-lb) 2.5 Vay Clutch Unit: mm (in) 0.01 - 0.024 (0.0004 - 0.0009) 0.03 - 0.044 (0.0012 - 0.0017)
Anchor end bolt nut tightening torque Anchor end bolt tightening torque Number of returning revolution for a	Cam ring — oil pump Rotor, vanes and con pump housing	Oil Pump a	40 - 51 N·m (4. 4 - 6 N·m (0.4 and Low One-w Standard Standard Standard Allowable limit	1 - 5.2 kg-m, 30 - 38 ft-lb) - 0.6 kg-m, 35 - 52 in-lb) 2.5 Vay Clutch Unit: mm (in) 0.01 - 0.024 (0.0004 - 0.0009) 0.03 - 0.044 (0.0012 - 0.0017) 0.10 - 0.25 (0.0039 - 0.0098)
Anchor end bolt nut tightening torque Anchor end bolt tightening torque Number of returning revolution for a Oil pump clearance Seal ring clearance	Cam ring — oil pump Rotor, vanes and con pump housing	Oil Pump a phousing strol piston — oil	40 - 51 N·m (4. 4 - 6 N·m (0.4 and Low One-w Standard Standard Standard Allowable limit	.1 - 5.2 kg-m, 30 - 38 ft-lb) - 0.6 kg-m, 35 - 52 in-lb) 2.5 Vay Clutch Unit: mm (in) 0.01 - 0.024 (0.0004 - 0.0009) 0.03 - 0.044 (0.0012 - 0.0017) 0.10 - 0.25 (0.0039 - 0.0098) 0.25 (0.0098)
Always check with the Parts D BRAKE BAND Anchor end bolt nut tightening torque Anchor end bolt tightening torque Number of returning revolution for a Oil pump clearance Seal ring clearance	Cam ring — oil pump Rotor, vanes and con pump housing	Oil Pump a bhousing strol piston — oil	40 - 51 N·m (4. 4 - 6 N·m (0.4) and Low One-w Standard Standard Standard Allowable limit	.1 - 5.2 kg-m, 30 - 38 ft-lb) - 0.6 kg-m, 35 - 52 in-lb) 2.5 Vay Clutch Unit: mm (in) 0.01 - 0.024 (0.0004 - 0.0009) 0.03 - 0.044 (0.0012 - 0.0017) 0.10 - 0.25 (0.0039 - 0.0098) 0.25 (0.0098)

^{*:} Always check with the Parts Department for the latest parts information.





Reverse Clutch Drum End Play		
	Reverse Clutch Drum Er	nd Play
Reverse clutch drum end play "T ₂ "	0.55 - 0.90 mm (0.	0217 - 0.0354 in)
	Thickness mm (in)	Part number*
	0.9 (0.035)	31528-21X01
	1.1 (0.043)	31528-21X02
Thickness of oil pump thrust washer	1.3 (0.051)	31528-21X03
	1.5 (0.059)	31528-21X04
	1.7 (0.067)	31528-21X05
	1.9 (0.075)	31528-21X06
	1.9 (0.075)	31528-21X06

^{*:} Always check with the Parts Department for the latest parts information.

Removal and Installation

NBAT0171

	Number of returning revolutions for lock nut	2
Manual control linkage	Lock nut tightening torque	4.4 - 5.9 N·m (0.45 - 0.60 kg-m, 39.1 - 52.1 in-lb)
Distance between end of converter housing and torque converter		26.0 mm (1.024 in) or more

Shift Solenoid Valves

NBAT0212

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

Solenoid Valves

NBAT0213

Solenoid valves	Resistance (Approx.) Ω	Terminal No.
Shift solenoid valve A	20 - 40	3
Shift solenoid valve B	20 - 40	2
Overrun clutch solenoid valve	20 - 40	4
Line pressure solenoid valve	2.5 - 5	6
Torque converter clutch solenoid valve	10 - 20	7

A/T Fluid Temperature Sensor

Remarks: Specification data are reference values.

NBAT0214

Monitor item	Condition	Specification
A/T fluid temperature sensor	Cold [20°C (68°F)] +	Approximately 1.5V ↓ Approximately 0.5V

Revolution Sensor

Terminal No.		Resistance
1	2	500 - 650Ω
2	3	No continuity
1	3	No continuity

Dropping Resistor

NBAT0216

Resistance	11.2 - 12.8Ω