

EXL

SECTION EXTERIOR LIGHTING SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

CONTENTS

XENON TYPE

PRECAUTION	4
PRECAUTIONS	4
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4
General precautions for service operations	4
Precaution for Work	5
PREPARATION	6
PREPARATION	6
Special Service Tool	6
SYSTEM DESCRIPTION	7
COMPONENT PARTS	7
Component Parts Location	7
Component Description	8
SYSTEM	9
HEADLAMP SYSTEM	9
HEADLAMP SYSTEM : System Diagram	9
HEADLAMP SYSTEM : System Description	9
AUTO LIGHT SYSTEM	9
AUTO LIGHT SYSTEM : System Diagram	10
AUTO LIGHT SYSTEM : System Description	10
DAYTIME RUNNING LIGHT SYSTEM	10
DAYTIME RUNNING LIGHT SYSTEM : System Diagram	10
DAYTIME RUNNING LIGHT SYSTEM : System Description	10
HEADLAMP AIMING CONTROL (MANUAL)	11
HEADLAMP AIMING CONTROL (MANUAL) : System Diagram	11
HEADLAMP AIMING CONTROL (MANUAL) : System Description	11

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Diagram	11
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description	11

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Diagram	12
PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description	12

FRONT FOG LAMP SYSTEM

FRONT FOG LAMP SYSTEM : System Diagram	12
FRONT FOG LAMP SYSTEM : System Description	12

TRAILER TOW SYSTEM

TRAILER TOW SYSTEM : System Diagram	13
TRAILER TOW SYSTEM : System Description	13

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM	14
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	14

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEADLAMP)	15
--	----

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)	16
--	----

DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description	17
CONSULT Function (IPDM E/R)	18

ECU DIAGNOSIS INFORMATION

.....21

EXL

BCM, IPDM E/R	21	Component Function Check	128
List of ECU Reference	21	Diagnosis Procedure	128
WIRING DIAGRAM	22	XENON HEADLAMP	130
HEADLAMP	22	Description	130
Wiring Diagram	22	Diagnosis Procedure	130
DAYTIME RUNNING LIGHT SYSTEM	31	DAYTIME RUNNING LIGHT RELAY CIRCUIT	131
Wiring Diagram	31	Description	131
AUTO LIGHT SYSTEM	43	Diagnosis Procedure	131
Wiring Diagram	43	Component Inspection	132
FRONT FOG LAMP SYSTEM	53	HEADLAMP AIMING SYSTEM (MANUAL)	134
Wiring Diagram	53	Description	134
TURN SIGNAL AND HAZARD WARNING		Component Inspection	134
LAMP SYSTEM	61	Diagnosis Procedure	134
Wiring Diagram	61	FRONT FOG LAMP CIRCUIT	136
PARKING, LICENSE PLATE AND TAIL		Description	136
LAMPS SYSTEM	70	Component Function Check	136
Wiring Diagram	70	Diagnosis Procedure	136
STOP LAMP	83	PARKING LAMP CIRCUIT	138
Wiring Diagram	83	Description	138
BACK-UP LAMP	87	Component Function Check	138
Wiring Diagram	87	Diagnosis Procedure	138
TRAILER TOW	97	TURN SIGNAL LAMP CIRCUIT	141
Wiring Diagram	97	Description	141
HEADLAMP AIMING SYSTEM (MANUAL) ...	111	Component Function Check	141
Wiring Diagram	111	Diagnosis Procedure	141
BASIC INSPECTION	121	OPTICAL SENSOR	144
DIAGNOSIS AND REPAIR WORKFLOW ..	121	Description	144
Work Flow	121	Component Function Check	144
DTC/CIRCUIT DIAGNOSIS	124	Diagnosis Procedure	144
POWER SUPPLY AND GROUND CIRCUIT ..	124	HAZARD SWITCH	146
BCM (BODY CONTROL MODULE)	124	Component Function Check	146
BCM (BODY CONTROL MODULE) : Diagnosis		Diagnosis Procedure	146
Procedure	124	SYMPTOM DIAGNOSIS	148
IPDM E/R (INTELLIGENT POWER DISTRIBU-		EXTERIOR LIGHTING SYSTEM SYMPTOMS.	148
TION MODULE ENGINE ROOM)	124	Symptom Table	148
IPDM E/R (INTELLIGENT POWER DISTRIBU-		NORMAL OPERATING CONDITION	151
TION MODULE ENGINE ROOM) : Diagnosis Pro-		Description	151
cedure	124	BOTH SIDE HEADLAMPS DO NOT SWITCH	
HEADLAMP (HI) CIRCUIT	126	TO HIGH BEAM	152
Description	126	Description	152
Component Function Check	126	Diagnosis Procedure	152
Diagnosis Procedure	126	BOTH SIDE HEADLAMPS (LO) ARE NOT	
HEADLAMP (LO) CIRCUIT	128	TURNED ON	153
Description	128	Description	153
PARKING, LICENSE PLATE, SIDE MARKER		Diagnosis Procedure	153
AND TAIL LAMPS ARE NOT TURNED ON ...		PARKING, LICENSE PLATE, SIDE MARKER	
		AND TAIL LAMPS ARE NOT TURNED ON ...	154

Description	154	HAZARD SWITCH	169
Diagnosis Procedure	154	Removal and Installation	169
BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON	155	HEADLAMP AIMING SWITCH	170
Description	155	Exploded View	170
Diagnosis Procedure	155	Removal and Installation	170
DAYTIME LIGHT SYSTEM INOPERATIVE	156	REAR COMBINATION LAMP	171
Description	156	Exploded View	171
Diagnosis Procedure	156	Removal and Installation	171
PERIODIC MAINTENANCE	157	HIGH-MOUNTED STOP LAMP	172
HEADLAMP AIMING ADJUSTMENT	157	Removal and Installation	172
Inspection	157	BACK-UP LAMP	173
Aiming Adjustment Procedure	159	Exploded View	173
FRONT FOG LAMP AIMING ADJUSTMENT ..	161	Removal and Installation	173
Aiming Adjustment	161	LICENSE PLATE LAMP	174
REMOVAL AND INSTALLATION	162	Exploded View	174
FRONT COMBINATION LAMP	162	Removal and Installation	174
Exploded View	162	UNIT DISASSEMBLY AND ASSEMBLY .	176
Removal and Installation	162	FRONT COMBINATION LAMP	176
FRONT FOG LAMP	165	Exploded View	176
Exploded View	165	Disassembly and Assembly	176
Removal and Installation	165	REAR COMBINATION LAMP	178
OPTICAL SENSOR	167	Exploded View	178
Exploded View	167	Disassembly and Assembly	178
Removal and Installation	167	SERVICE DATA AND SPECIFICATIONS (SDS)	179
LIGHTING & TURN SIGNAL SWITCH	168	SERVICE DATA AND SPECIFICATIONS (SDS)	179
Exploded View	168	Bulb Specifications	179
Removal and Installation	168		

A

B

C

D

E

F

G

H

I

J

K

M

N

O

P

EXL

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000011134615

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes dual stage front air bag modules. The SRS system may only deploy one front air bag, depending on the severity of a collision and whether the front passenger seat is occupied. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

General precautions for service operations

INFOID:0000000011134616

- Do not work with wet hands.
- The xenon headlamp system includes a high voltage generating part. Be sure to disconnect battery negative cable (negative terminal) or power fuse before removing, installing, or touching the xenon headlamp (including lamp bulb).
- Turn the lighting switch OFF before disconnecting and connecting the connector.
- When turning the xenon headlamp on and while it is illuminated, do not touch the harness, bulb, and socket of the headlamp.
- When checking the headlamp on/off operation, check it on vehicle and with the power connected to the vehicle-side connector.
- Do not touch the headlamp bulb glass surface with bare hands or allow oil or grease to get on it. Do not touch the headlamp bulb just after the headlamp is turned off, because it is very hot.
- Install the xenon headlamp bulb socket correctly. If it is installed improperly, high-voltage leak or corona discharge may occur that can melt the bulb, connector or housing. Do not illuminate the xenon headlamp bulb out of the headlamp housing. Doing so can cause fire and harm your eyes.
- When the bulb has burned out, wrap it in a thick vinyl bag and discard. Do not break the bulb.
- Leaving the bulb removed from the headlamp housing for a long period of time can deteriorate the performance of the lens and reflector (dirt, clouding). Always prepare a new bulb and have it on hand when replacing the bulb.
- When adjusting the headlamp aiming, turn the aiming adjustment screw only in the tightening direction. If it is necessary to loosen the screw, first fully loosen the screw, and then turn it in the tightening direction.
- Do not use organic solvent (paint thinner or gasoline) to clean lamps and to remove old sealant.



PKIA0183E

PRECAUTIONS

[XENON TYPE]

< PRECAUTION >

Precaution for Work

INFOID:000000011134617

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000011134618

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.)	Description
— (J-46534) Trim Tool Set	Removing trim components


ANJIA0483ZZ


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000011134619



AWLIA1955ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[XENON TYPE]

- | | | |
|--|--|---|
| 1. BCM
(view with combination meter removed) | 2. Combination switch
(lighting and turn signal switch) | 3. Headlamp aiming switch |
| 4. Combination meter | 5. A/C and AV switch assembly
(hazard switch) | 6. Parking brake switch |
| 7. Stop lamp switch | 8. Optical sensor | 9. IPDM E/R, (Front fog lamp relay, Headlamp high relay, Headlamp low relay, Tail lamp relay) |
| 10. Daytime running light relay
(if equipped) | 11. Front door switch LH
(RH similar) | 12. Rear door switch LH
(RH similar) |
| 13. Front combination lamp RH
(headlamp aiming motor)
(LH similar) | | |

Component Description


INFOID:000000011134620

Part	Description
BCM	Controls the exterior lighting system.
Combination switch (Lighting & turn signal switch)	Refer to BCS-7, "COMBINATION SWITCH READING SYSTEM : System Description" .
IPDM E/R	Controls the integrated relays and supplies voltage to the load according to the request from the BCM via CAN communication.
Stop lamp switch	Transmits stop lamp switch signal to BCM when the brake pedal is pressed to operate stop lamps.
Combination meter	Refer to MWI-9, "METER SYSTEM : System Description" .
Daytime running light relay (if equipped)	Sends power to the daytime running lamp when operated by the IPDM E/R.
Front combination lamp RH (headlamp aiming motor)	Moves the headlamp up/down based on input from the headlamp aiming switch.
Front door switch LH/RH	Transmits the door open signal to the BCM to operate the autolight system.
Rear door switch LH/RH	
Optical sensor	Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM to operate the autolight system.
Parking brake switch	Transmits the parking brake switch signal to the combination meter to operate the autolight system.
Headlamp aiming switch	Controls variable ground to the headlamp aiming motor signal to move the headlamp aiming motor up/down.
A/C and AV switch assembly (hazard switch)	Inputs the hazard switch signal to BCM.

< SYSTEM DESCRIPTION >

SYSTEM**HEADLAMP SYSTEM****HEADLAMP SYSTEM : System Diagram**

INFOID:0000000011134621

**HEADLAMP SYSTEM : System Description**

INFOID:0000000011134622

LOW BEAM OPERATION

When the lighting switch is in 2nd position, the BCM receives input requesting the headlamps to illuminate. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU of the IPDM E/R controls the headlamp low relay coil which supplies power to the low beam headlamps.

HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

With the lighting switch in the 2nd position and placed in HIGH position, the BCM receives input requesting the headlamp high beams to illuminate. The flash to pass feature can be used any time and also sends a signal to the BCM. This input is communicated to the IPDM E/R across the CAN communication lines. The CPU of the combination meter controls the ON/OFF status off the HIGH BEAM indicator. The CPU of the IPDM E/R controls the headlamp high relay coil which supplies power to the high beam headlamps.

The combination meter receives a high beam request signal (ON) through the CAN communication lines and turns the high beam indicator lamp ON.

EXTERIOR LAMP BATTERY SAVER CONTROL

With the combination switch (lighting and turn signal switch) in the 2nd position and the ignition switch is turned from ON or ACC to OFF, the battery saver feature is activated.

Under this condition, the headlamps remain illuminated for a period of time, unless the lighting switch position is changed. If the lighting switch position is changed, then the headlamps are turned off.

AUTO LIGHT SYSTEM

A

B

C

D

E

F

G

H

I

J

EXL

M

N

O

P


SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

AUTO LIGHT SYSTEM : System Diagram

INFOID:000000011134623



ANLIA1957GB

AUTO LIGHT SYSTEM : System Description

INFOID:000000011134624

- BCM (Body Control Module) controls auto light operation according to signals from optical sensor, lighting switch and ignition switch.
- IPDM E/R (Intelligent Power Distribution Module Engine Room) operates parking, license plate, tail, front fog lamps and headlamps according to CAN communication signals from BCM.
- Optical sensor detects ambient brightness of 800 to 2,500 lux. And optical sensor converts light (lux) to voltage, then sends the optical sensor signal to BCM.

OUTLINE


The auto light control system has an optical sensor that detects outside brightness.

When the lighting switch is in AUTO position, it automatically turns ON/OFF the parking, license plate, tail, front fog lamps and headlamps in accordance with the ambient light. Sensitivity can be adjusted in four steps. For the details of the setting, Refer to [BCS-17, "HEADLAMP : CONSULT Function \(BCM - HEADLAMP\)".](#)

DAYTIME RUNNING LIGHT SYSTEM

DAYTIME RUNNING LIGHT SYSTEM : System Diagram

INFOID:000000011134625



ANLIA2532GB

DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:000000011134626

System Description

SYSTEM

[XENON TYPE]

< SYSTEM DESCRIPTION >

The daytime running light system is equipped with a daytime running light control that activates the daytime running lights within the front fog lamp assembly when the engine is operating. If the parking brake is applied, the daytime running lights will turn OFF. The daytime running lights will turn ON when the parking brake is released.


OPERATION

The BCM monitors inputs from the parking brake switch and the combination switch (lighting and turn signal switch) to determine when to operate the daytime running light system. The BCM sends a daytime running light request to the IPDM E/R via the CAN communication lines. The IPDM E/R grounds the daytime running light relay which in turn, provides power to the daytime running lights.

HEADLAMP AIMING CONTROL (MANUAL)

HEADLAMP AIMING CONTROL (MANUAL) : System Diagram

INFOID:0000000011134627



HEADLAMP AIMING CONTROL (MANUAL) : System Description


INFOID:0000000011134628

The headlamp aiming system (manual) controls the headlamp light axis height according to input from the headlamp aiming switch. The variable internal resistance of the headlamp aiming switch controls the signal ground of the headlamp aiming motors located on the front combination lamp LH and RH. The headlamp aiming system operates when the combination switch (lighting and turn signal switch) is in the 2nd position.

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Diagram

INFOID:0000000011134629



TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description

INFOID:0000000011134630

TURN SIGNAL OPERATION

When the combination switch (lighting and turn signal switch) is in LH or RH turn position with the ignition switch in the ON position, the BCM receives input requesting the turn RH or turn LH lamps to illuminate. The BCM controls the turn signal power to the respective turn signal lamp. The BCM also sends a turn indicator signal ON request via the CAN communication lines to the combination meter. The combination meter then activates the appropriate turn signal indicator and audible buzzer.

HAZARD LAMP OPERATION


When the hazard switch is in the ON position, the BCM receives input requesting the hazard lamps illuminate. The BCM controls the turn signal power to both the LH and RH turn signal lamps. The BCM sends a hazard indicator signal ON request via the CAN communication lines to the combination meter. The combination meter then activates both the LH and RH turn signal indicators and audible buzzer.

< SYSTEM DESCRIPTION >

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Diagram

INFOID:0000000011134631



AWLIA1723GB

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description

INFOID:0000000011134632

PARKING, LICENSE PLATE AND TAIL LAMPS OPERATION

When the lighting switch is in 1st position, BCM detects the LIGHTING SWITCH 1st POSITION ON. The BCM sends a parking light ON request via the CAN communication lines to the IPDM E/R. The IPDM E/R then activates the tail lamp relay which sends power to the parking and instrument illumination circuits.

EXTERIOR LAMP BATTERY SAVER CONTROL


With the combination switch (lighting and turn signal switch) in the 2nd position and the ignition switch is turned from ON or ACC to OFF, the battery saver feature is activated.

Under this condition, the exterior lamps remain illuminated for a period of time unless the lighting switch position is changed. If the lighting switch position is changed, then the exterior lamps are turned off.

FRONT FOG LAMP SYSTEM

FRONT FOG LAMP SYSTEM : System Diagram

INFOID:0000000011134633



AWLIA1719GB

FRONT FOG LAMP SYSTEM : System Description

INFOID:0000000011134634

The front fog lamps are activated with the combination switch (lighting and turn signal switch). The lighting switch signal to the BCM is monitored with the BCM combination switch reading function. When the fog lamps are turned ON with the lighting switch, the BCM sends a front fog lamp request signal via CAN communication lines to the IPDM E/R. The IPDM E/R grounds the front fog lamp relay coil to activate the front fog lamps.

FRONT FOG LAMP OPERATION

When the lighting switch is in front fog lamp ON position and also in 1st or 2nd position or AUTO position (headlamp is ON), the BCM detects FR FOG ON and the HEAD LAMP 1, 2 ON or the AUTO LIGHT ON. The BCM sends a front fog lamp request ON signal via the CAN communication lines to the IPDM E/R. The IPDM E/R then turns ON the front fog lamp relay sending power to the front fog lamps.

TRAILER TOW SYSTEM


SYSTEM

< SYSTEM DESCRIPTION >

[XENON TYPE]

TRAILER TOW SYSTEM : System Diagram

INFOID:000000011134635



TRAILER TOW SYSTEM : System Description

INFOID:000000011134636

TRAILER TAIL LAMP OPERATION

The trailer tail lamps are controlled by the trailer tow relay 1. With the combination switch (lighting and turn signal switch) in the 1st position, the BCM detects the LIGHTING SWITCH 1st POSITION ON. The BCM sends a parking light ON request via the CAN communication lines to the IPDM E/R. The IPDM E/R then activates the tail lamp relay which activates the trailer tow relay 1 and sends power to the trailer connector.

TRAILER TURN SIGNAL LAMP OPERATION

The trailer turn signal lamps are controlled by the BCM. When the turn signal switch is in the LH or RH position with the ignition switch ON, the combination switch (lighting and turn signal switch) sends a signal to the BCM. The BCM detects the TURN RH or TURN LH ON request. The BCM sends a control signal to the respective trailer turn relay which sends power to the trailer connector.

TRAILER HAZARD LAMP OPERATION

The trailer hazard lamps are controlled by the BCM. When the hazard switch is pressed, the BCM detects the hazard ON request. The BCM then sends a control signal to both trailer turn relays which sends power to the trailer connector.

TRAILER BRAKE LAMP OPERATION

The trailer brake lamps operate when the brake pedal is pressed sending the stop lamp switch signal to the trailer connector.

EXL

M

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000011544281

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> • The vehicle specification can be read and saved. • The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Back door open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

System	Sub System	Direct Diagnostic Mode					
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration
Signal buffer system	SIGNAL BUFFER			x			
TPMS	AIR PRESSURE MONITOR		x	x	x	x	

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEADLAMP)

INFOID:0000000011544282

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

DATA MONITOR

Monitor Item [Unit]	Description
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
ENGINE STATE [Stop/Stall/Crank/Run]	Indicates engine status received from ECM on CAN communication line.
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.
TURN SIGNAL R [On/Off]	Indicates condition of combination switch.
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW 1 [On/Off]	
HEAD LAMP SW 2 [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW [On/Off]	
FR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of back door switch.
OPTI SEN (DTCT) [V]	Indicates outside brightness voltage signal from optical sensor.
OPTI SEN (FILT) [V]	Indicates outside brightness voltage signal from optical sensor filtered by BCM.

ACTIVE TEST

Test Item	Description
FR FOG LAMP	This test is able to check front fog lamp operation [On/Off].
DAYTIME RUNNING LIGHT	This test is able to check daytime running lamp operation [On/Off].
ILL DIM SIGNAL	This test is able to check head lamp illumination dimming operation [On/Off].

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Support Item	Setting	Description
TWILIGHT ON	MODE2*	Autolamp function ON.
	MODE1	Autolamp function OFF.
WIPER LINK	MODE4	This mode is not used.
	MODE3*	Wiper link function operates in INT, LOW and HI.
	MODE2	Wiper link function operates in LOW and HI.
	MODE1	Wiper link function OFF.
CUSTOM A/LIGHT SETTING	MODE4	Less sensitive than normal setting (turns ON later).
	MODE3	More sensitive than MODE2.
	MODE2	More sensitive than normal setting (turns ON earlier).
	MODE1*	Normal setting.
ILL DELAY SET	MODE 8	Autolamp delay timer.
	MODE 7	
	MODE 6	
	MODE 4	
	MODE 5	
	MODE 3	
	MODE 2	
	MODE 1*	

* : Initial setting

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000011544283

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
TURN SIGNAL R [On/Off]	Indicates condition of turn signal function of combination switch.
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	Indicates condition of hazard switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]	Indicates condition of panic alarm signal from Intelligent Key.

ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [Off/LH/RH].

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (IPDM E/R)**Diagnosis Description**

INFOID:0000000011544284

AUTO ACTIVE TEST**Description**

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Front wiper (LO, HI)
- Front fog lamps
- Parking lamps
- Side marker lamps
- Tail lamps
- License plate lamps
- Daytime running lamps
- Headlamps (LO, HI)
- A/C compressor
- Cooling fans (LO, HI)

Operation Procedure**CAUTION:**

Do not start the engine.

NOTE:

When auto active test is performed with hood opened, sprinkle water on windshield before hand.

NOTE:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-171, "Component Function Check".](#)
 - When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.
1. Close the hood and lift the wiper arms from the windshield. (Prevent windshield damage due to wiper operation)
 2. Turn ignition switch OFF.
 3. Turn the ignition switch ON, and within 20 seconds, press the front door switch LH 10 times. Then turn the ignition switch OFF.
 4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once, and the auto active test starts.
 5. After a series of the following operations is repeated 3 times, auto active test is completed.

Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following operation sequence is repeated 3 times.

EXL

Operation sequence	Inspection Location	Operation
1	Front wiper	LO for 3 seconds → HI for 3 seconds
2	<ul style="list-style-type: none"> • Front fog lamps • Parking lamps • Side marker lamps • Tail lamps • License plate lamps 	10 seconds
3	Daytime running lamps	10 seconds
4	Headlamps	LO ⇄ HI 5 times
5	A/C compressor	ON ⇄ OFF 5 times
6*	Cooling fans	LO for 5 seconds → HI for 5 seconds

*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.

M

N

O


P

DIAGNOSIS SYSTEM (IPDM E/R)

[XENON TYPE]

< SYSTEM DESCRIPTION >

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Any of the following components do not operate • Front fog lamps • Parking lamps • Side marker lamps • License plate lamps • Tail lamps • Daytime running lamps • Headlamp (HI, LO) • Front wiper	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R
Cooling fans do not operate	Perform auto active test. Do the cooling fans operate?	YES • ECM signal input circuit • CAN communication signal between ECM and IPDM E/R
		NO • Cooling fans • Harness or connectors between cooling fans and cooling fan control module • Cooling fan control module • Harness or connectors between cooling fan relay and cooling fan control module • Cooling fan relay • Harness or connectors between IPDM E/R and cooling fan relay • IPDM E/R

CONSULT Function (IPDM E/R)

INFOID:000000011544285

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

DIAGNOSIS SYSTEM (IPDM E/R)

[XENON TYPE]

< SYSTEM DESCRIPTION >

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
Ecu Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

ECU IDENTIFICATION

The IPDM E/R part number is displayed.

SELF DIAGNOSTIC RESULT

Refer to [PCS-20, "DTC Index"](#).

DATA MONITOR

Monitor Item [Unit]	Main Signals	Description
RAD FAN REQ [%]	×	Indicates cooling fan speed signal received from ECM on CAN communication line
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates ignition switch ON signal received from BCM on CAN communication line
IGN RLY [On/Off]	×	Indicates condition of ignition relay
PUSH SW [On/Off]		Indicates condition of push-button ignition switch
INTER/NP SW [On/Off]		Indicates condition of CVT shift position
ST RLY CONT [On/Off]		Indicates starter relay status signal received from BCM on CAN communication line
IHBT RLY -REQ [On/Off]		Indicates starter control relay signal received from BCM on CAN communication line
ST/INHI RLY [Off/ ST /INHI]		Indicates condition of starter relay and starter control relay
DETENT SW [On/Off]		Indicates condition of CVT shift selector (park position switch)
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
HOOD SW [On/Off]		Indicates condition of hood switch
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[XENON TYPE]

Monitor Item [Unit]	Main Signals	Description
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line
HOOD SW 2 [On/Off]		Indicates condition of hood switch 2

ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [On].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].
MOTOR FAN	This test is able to check cooling fan operation [4/3/2/1].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/Tail/Off].

CAN DIAG SUPPORT MNTR

Refer to [LAN-25, "CAN Diagnostic Support Monitor".](#)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM, IPDM E/R

List of ECU Reference

INFOID:000000011134642

ECU	Reference
BCM	BCS-29, "Reference Value"
	BCS-49, "Fail_Safe"
	BCS-49, "DTC Inspection Priority Chart"
	BCS-51, "DTC Index"
IPDM E/R	PCS-12, "Reference Value"
	PCS-19, "Fail_Safe"
	PCS-20, "DTC Index"

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

HEADLAMP

< WIRING DIAGRAM >


[XENON TYPE]

WIRING DIAGRAM

HEADLAMP

Wiring Diagram

INFOID:0000000011134643




ABLWA2898GB

HEADLAMP

[XENON TYPE]

< WIRING DIAGRAM >

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	P	-
5	V	-
7	P	-
8	P	-
9	W	-
10	P	-
11	W	-
12	P	-
13	BG	-
14	W	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-

Terminal No.	Color of Wire	Signal Name
71A	72A	73A
72A	73A	74A
73A	74A	75A
74A	75A	76A
75A	76A	77A
76A	77A	78A
77A	78A	79A
78A	79A	80A
79A	80A	81A
80A	81A	82A
81A	82A	83A
82A	83A	84A
83A	84A	85A
84A	85A	86A
85A	86A	87A
86A	87A	88A
87A	88A	89A
88A	89A	90A
89A	90A	91A
90A	91A	92A
91A	92A	93A
92A	93A	94A
93A	94A	95A
94A	95A	96A
95A	96A	97A
96A	97A	98A
97A	98A	99A
98A	99A	100A


ABLIA4969GB

HEADLAMP

[XENON TYPE]

< WIRING DIAGRAM >

Connector No.	M43
Connector Name	JOINT CONNECTOR M17
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	M41
Connector Name	JOINT CONNECTOR M18
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND2
139	W	BAT POWER F/L
143	B	GND1




Terminal No.	Color of Wire	Signal Name
12	11	-
10	10	-
9	9	-
8	8	-
7	7	-
6	6	-
5	5	-
4	4	-
3	3	-
2	2	-
1	1	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE



Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-

Terminal No.	Color of Wire	Signal Name
1	L	-
4	L	-
7	P	-
10	P	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL

HEADLAMP

< WIRING DIAGRAM >


[XENON TYPE]

Connector No.	E70
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H
41	B	GND (SIGNAL)
43	L	IGN SIGNAL

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




HEADLAMP


< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	E217
Connector Name	IPDM ECR (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	E217
Connector Name	IPDM ECR (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
75	R	HEADLAMP LO RH
76	L	HEADLAMP LO LH
80	W	HEADLAMP HI RH
81	G	HEADLAMP HI LH

Terminal No.	Color of Wire	Signal Name
75	R	HEADLAMP LO RH
76	L	HEADLAMP LO LH
80	W	HEADLAMP HI RH
81	G	HEADLAMP HI LH

Terminal No.	Color of Wire	Signal Name
3	B	-
4	B	-
6	G	-
8	L	-

Terminal No.	Color of Wire	Signal Name
3	B	-
4	B	-
6	G	-
8	L	-

Terminal No.	Color of Wire	Signal Name
3	G	-
4	B	-

Terminal No.	Color of Wire	Signal Name
3	G	-
4	B	-

A

B

C

D

E

F

G

H

K

EXL

M

Z

O

P

ABLIA4970GB

HEADLAMP

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	E331
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	W	-
4	B	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-



Connector No.	E328
Connector Name	FRONT COMBINATION LAMP LH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

Terminal No.	Color of Wire	Signal Name
3	W	-
4	B	-



Connector No.	E332
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
4	3	-
3	2	-
2	1	-



HEADLAMP


< WIRING DIAGRAM >

[XENON TYPE]

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	Color	Wire to Wire
B17	JOINT CONNECTOR B12	WHITE



HEADLAMP


< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	B102
Connector Name	JOINT CONNECTOR-B14
Connector Color	WHITE



Connector No.	B103
Connector Name	JOINT CONNECTOR-B15
Connector Color	WHITE



Connector No.	B124
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
18	P	-
19	P	-

Terminal No.	Color of Wire	Signal Name
1	6	7
2	5	8
3	4	9
4	3	10
5	2	11
6	1	12
7	-	13
8	-	14
9	-	15
10	-	16
11	-	17
12	-	18
13	-	19
14	-	20
15	-	21
16	-	22
17	-	23
18	-	24
19	-	25
20	-	26
21	-	27
22	-	28
23	-	29
24	-	30
25	-	31
26	-	32

AALIA0626GB

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >


[XENON TYPE]

DAYTIME RUNNING LIGHT SYSTEM

Wiring Diagram

INFOID:0000000011134644

DAYTIME RUNNING LIGHT SYSTEM




ABLWA2899GB

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]



ABLWA2900GB


DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

DAYTIME RUNNING LIGHT SYSTEM CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6N	W	-
6N	W	-

Terminal No.	Color of Wire	Signal Name
8P	BG	-
13P	W	-

Terminal No.	Color of Wire	Signal Name
10	P	COMBI SW IN 5
11	P	COMBI SW IN 4
12	V	COMBI SW IN 3
13	W	COMBI SW IN 2
14	P	COMBI SW IN 1



Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
20	P	IGN USM OUT 1
21	BG	IGN
22	W	BAT
38	P	CAN-L
39	L	CAN-H

Terminal No.	Color of Wire	Signal Name
59	P	CAN-L
60	L	CAN-H
70	P	IGN USM OUT 1
75	BG	COMBI SW OUT 5
76	P	COMBI SW OUT 4
77	P	COMBI SW OUT 3
78	W	COMBI SW OUT 2
79	W	COMBI SW OUT 1


ABLIA7049GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]



ABLIA4972GB

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND2
139	W	BAT POWER F/L
143	B	GND1



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	LG	-
3	BR	-
5	V	-
6	SB	-
7	V	-



Connector No.	M184
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
16	15	14
17	14	13
18	13	12
19	10	9
20	8	7
21	6	5
22	4	3
23	2	2
24	1	1
25	26	27
26	28	29
27	30	31
28	32	33
29	34	35
30	36	37
31	38	39
32	40	41



Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-

A B C D E F G H I J K L M N O P EXL

ABLIA7050GB

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >


[XENON TYPE]

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
30	V	-
31	LG	-
32	V	-
33	V	-
1	Y	-
2	SB	-
3	BR	-

Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
30	V	-
31	LG	-
32	V	-
33	V	-
1	Y	-
2	SB	-
3	BR	-

Connector No.	E52
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	P	-

Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE



Connector No.	E70
Connector Name	JOINT CONNECTOR-E14
Connector Color	BLACK



Connector No.	E71
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-


Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H
41	B	GND (SIGNAL)
43	L	IGN SIGNAL

Terminal No.	Color of Wire	Signal Name
10G	P	—
33G	LG	—
35G	P	—
36G	L	—
63G	L	—



Terminal No.	Color of Wire	Signal Name
1	P	—
2	P	—
3	R	—



ABLIA4670GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	E211
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Connector No.	E212
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	E211
Connector Name	WIRE TO WIRE
Connector Color	GRAY


Connector No.	E212
Connector Name	WIRE TO WIRE
Connector Color	GRAY

Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	P	-
7	B	-


Terminal No.	Color of Wire	Signal Name
75	R	HEADLAMP LO RH
76	L	HEADLAMP LO LH
80	W	HEADLAMP HI RH
81	G	HEADLAMP HI LH



Connector No.	E232
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
85	P	DTRL RLY
8	L	-

Terminal No.	Color of Wire	Signal Name
3	B	-
4	B	-
6	G	-
8	R	-

Terminal No.	Color of Wire	Signal Name
82	83	84
83	85	86
85	87	88
86	89	90
87	91	92
88	93	94
89	95	96
90	97	-

ABLIA4975GB

DAYTIME RUNNING LIGHT SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	E302
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	E301
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	LG	-
7	B	-

Terminal No.	Color of Wire	Signal Name
3	LG	-
7	B	-

Terminal No.	Color of Wire	Signal Name
3	LG	-
4	B	-



Terminal No.	Color of Wire	Signal Name
3	LG	-
4	B	-

Terminal No.	Color of Wire	Signal Name
3	LG	-
4	B	-

Connector No.	E304
Connector Name	FRONT FOG LAMP RH
Connector Color	GRAY



Connector No.	E325
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
3	LG	-
4	B	-
6	G	-
8	L	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
O

ABLIA4976GB

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	E328
Connector Name	FRONT COMBINATION
Connector Color	BLACK



Connector No.	E327
Connector Name	FRONT COMBINATION
Connector Color	BLACK




Connector No.	E332
Connector Name	FRONT COMBINATION
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-


Terminal No.	Color of Wire	Signal Name
3	W	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-



ABLIA3555GB

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE



H.S.

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY

Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-

5A 4A	3A 2A 1A	10A 9A 8A 7A 6A
21A 20A 19A 18A 17A 16A 15A 14A 13A 12A 11A		
30A 29A 28A 27A 26A 25A 24A 23A 22A		
41A 40A 39A 38A 37A 36A 35A 34A 33A 32A 31A		
50A 49A 48A 47A 46A 45A 44A 43A 42A		
61A 60A 59A 58A 57A 56A 55A 54A 53A 52A 51A		
70A 69A 68A 67A 66A 65A 64A 63A 62A		
81A 80A 79A 78A 77A 76A 75A 74A 73A 72A 71A		
90A 89A 88A 87A 86A 85A 84A 83A 82A		
95A 94A 93A 92A 91A		
100A 99A 98A 97A 96A		

ABLIA4977GB

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

DAYTIME RUNNING LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	B102
Connector Name	JOINT CONNECTOR-B15
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	B103
Connector Name	JOINT CONNECTOR-B15
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-



AALIA0627GB

AUTO LIGHT SYSTEM


[XENON TYPE]

< WIRING DIAGRAM >

AUTO LIGHT SYSTEM

Wiring Diagram

INFOID:0000000011134645



ABLWA2901GB


AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

AUTO LIGHT SYSTEM CONNECTORS


Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M15
Connector Name	OPTICAL SENSOR
Connector Color	WHITE




Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	G	-
3	R	-

Terminal No.	Color of Wire	Signal Name
3	W	A/L POWER SUPPLY 5V
4	G	A/L SIGNAL
10	P	COMBI SW IN 5
11	P	COMBI SW IN 4
12	V	COMBI SW IN 3
13	W	COMBI SW IN 2
14	P	COMBI SW IN 1
17	R	GND RF A/L




Terminal No.	Color of Wire	Signal Name
82	W	RL DOOR SW
93	R	RR DOOR SW
94	G	AS DOOR SW
96	BG	DR DOOR SW
97	W	BACK DOOR SW

ABLIA7150GB

AUTO LIGHT SYSTEM

[XENON TYPE]

< WIRING DIAGRAM >



ABLIA4979GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	M41
Connector Name	JOINT CONNECTOR-M18
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

EXL-46

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	W	-
1	W	-


2015 QX60 NAM

Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	W	-
1	W	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
16	L	-
2	W	-

Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-
21	G	-
22	R	-

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	E70
Connector Name	JOINT CONNECTOR-E14
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	L	-
4	L	-
7	P	-
10	P	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE



Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H
41	B	GND (SIGNAL)
43	L	IGN SIGNAL

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)
9	G	TAIL RH
10	L	TAIL LH

Terminal No.	Color of Wire	Signal Name
19	P	CAN-L
20	L	CAN-H
21	B	GND (SIGNAL)
22	L	IGN SIGNAL





A B C D E F G H I J K L M O P EXL Z M Z O

ABLIA7152GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]




ABLIA7153GB

AUTO LIGHT SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-




Connector No.	B12
Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-



Terminal No.	Color of Wire	Signal Name
12	G	-
13	-	-



Terminal No.	Color of Wire	Signal Name
1	2	-
2	3	-



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P


ABLIA7154GB

AUTO LIGHT SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	G	-
23	GR	-



Terminal No.	Color of Wire	Signal Name
65A	SB	-
66A	L	-
89A	L	-
90A	P	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
21	LG	-
22	LG	-

Connector No.	Joint Connector-B15
B103	



Connector No.	Joint Connector-B14
B102	



Connector No.	Color of Wire	Signal Name
1	P	-
2	P	-

ABLIA7155GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


[XENON TYPE]

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	LG	—

Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	L	—
19	P	—

Terminal No.	Color of Wire	Signal Name
18	L	—
19	P	—




Terminal No.	Color of Wire	Signal Name
6	B	—
12	G	—

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	Y	—
12	P	—

Connector No.	D507
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	Y	—
12	P	—

Terminal No.	Color of Wire	Signal Name
18	L	—
19	P	—




A B C D E F G H I J K L M N O P EXL

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	D557
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	G	-
8	B	-

ABLIA7157GB

FRONT FOG LAMP SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

FRONT FOG LAMP SYSTEM

Wiring Diagram

INFOID:0000000011134646



ABLWA2902GB


FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

FRONT FOG LAMP CONNECTORS


Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
8P	BG	—
13P	W	—

Terminal No.	Color of Wire	Signal Name
10	P	COMBI SW IN 5
11	P	COMBI SW IN 4
12	V	COMBI SW IN 3
13	W	COMBI SW IN 2
14	P	COMBI SW IN 1

Terminal No.	Color of Wire	Signal Name
59	P	CAN-L
60	L	CAN-H
70	P	IGN USM OUT 1
75	BG	COMBI SW OUT 5
76	P	COMBI SW OUT 4
77	P	COMBI SW OUT 3
78	W	COMBI SW OUT 2
79	W	COMBI SW OUT 1

Terminal No.	Color of Wire	Signal Name
20	19	18
39	38	37
40	39	38
36	35	34
33	32	31
30	29	28
27	26	25
24	23	22
21	20	19
16	15	14
12	11	10
9	8	7
5	4	3
1	2	1

Terminal No.	Color of Wire	Signal Name
1	B	GND1
2	B	GND2
21	BG	IGN
22	W	BAT
38	P	CAN-L
39	L	CAN-H


ABLIA4635GB

FRONT FOG LAMP SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-

Terminal No.	Color of Wire	Signal Name
10G	W	-
35G	P	-
36G	L	-
63G	P	-

ABLIA4981GB

EXL

M

N

O

P

Q

R

S

T

U

A

B

C

D

F

G

J


K

FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-


Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND2
139	W	BAT POWER F/L
143	B	GND1




Terminal No.	Color of Wire	Signal Name
1	L	-
4	L	-
7	P	-
10	P	-



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-



Terminal No.	Color of Wire	Signal Name
16	15	14
17	14	13
18	13	12
19	10	9
20	8	7
21	6	5
22	4	3
23	2	1
24	26	25
25	26	27
26	27	28
27	28	29
28	29	30
29	30	31
30	31	32







Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-

FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

<table border="1"> <tr><td>Connector No.</td><td>E70</td></tr> <tr><td>Connector Name</td><td>JOINT CONNECTOR E14</td></tr> <tr><td>Connector Color</td><td>BLACK</td></tr> </table>  H.S.	Connector No.	E70	Connector Name	JOINT CONNECTOR E14	Connector Color	BLACK	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>P</td><td>—</td></tr> <tr><td>2</td><td>P</td><td>—</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	P	—	2	P	—	<table border="1"> <tr><td>Connector No.</td><td>E71</td></tr> <tr><td>Connector Name</td><td>JOINT CONNECTOR E15</td></tr> <tr><td>Connector Color</td><td>BLACK</td></tr> </table>  H.S.	Connector No.	E71	Connector Name	JOINT CONNECTOR E15	Connector Color	BLACK	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>L</td><td>—</td></tr> <tr><td>2</td><td>L</td><td>—</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	L	—	2	L	—												
Connector No.	E70																																												
Connector Name	JOINT CONNECTOR E14																																												
Connector Color	BLACK																																												
Terminal No.	Color of Wire	Signal Name																																											
1	P	—																																											
2	P	—																																											
Connector No.	E71																																												
Connector Name	JOINT CONNECTOR E15																																												
Connector Color	BLACK																																												
Terminal No.	Color of Wire	Signal Name																																											
1	L	—																																											
2	L	—																																											
<table border="1"> <tr><td>Connector No.</td><td>E119</td></tr> <tr><td>Connector Name</td><td>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  H.S.	Connector No.	E119	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>28</td><td>P</td><td>CAN-L</td></tr> <tr><td>29</td><td>L</td><td>CAN-H</td></tr> <tr><td>41</td><td>B</td><td>GND (SIGNAL)</td></tr> <tr><td>43</td><td>L</td><td>IGN SIGNAL</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	28	P	CAN-L	29	L	CAN-H	41	B	GND (SIGNAL)	43	L	IGN SIGNAL	<table border="1"> <tr><td>Connector No.</td><td>E152</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  H.S.	Connector No.	E152	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>10G</td><td>P</td><td>—</td></tr> <tr><td>35G</td><td>P</td><td>—</td></tr> <tr><td>36G</td><td>L</td><td>—</td></tr> <tr><td>63G</td><td>L</td><td>—</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	10G	P	—	35G	P	—	36G	L	—	63G	L	—
Connector No.	E119																																												
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																																												
Connector Color	WHITE																																												
Terminal No.	Color of Wire	Signal Name																																											
28	P	CAN-L																																											
29	L	CAN-H																																											
41	B	GND (SIGNAL)																																											
43	L	IGN SIGNAL																																											
Connector No.	E152																																												
Connector Name	WIRE TO WIRE																																												
Connector Color	WHITE																																												
Terminal No.	Color of Wire	Signal Name																																											
10G	P	—																																											
35G	P	—																																											
36G	L	—																																											
63G	L	—																																											
<table border="1"> <tr><td>Connector No.</td><td>E121</td></tr> <tr><td>Connector Name</td><td>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  H.S.	Connector No.	E121	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>7</td><td>B</td><td>GND (POWER)</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	7	B	GND (POWER)	<table border="1"> <tr><td>Connector No.</td><td>E152</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  H.S.	Connector No.	E152	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>41G</td><td>9G</td><td>3G</td></tr> <tr><td>50G</td><td>4G</td><td>4G</td></tr> <tr><td>61G</td><td>6G</td><td>5G</td></tr> <tr><td>70G</td><td>6G</td><td>6G</td></tr> <tr><td>81G</td><td>7G</td><td>7G</td></tr> <tr><td>90G</td><td>8G</td><td>8G</td></tr> <tr><td>100G</td><td>9G</td><td>9G</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	41G	9G	3G	50G	4G	4G	61G	6G	5G	70G	6G	6G	81G	7G	7G	90G	8G	8G	100G	9G	9G
Connector No.	E121																																												
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																																												
Connector Color	WHITE																																												
Terminal No.	Color of Wire	Signal Name																																											
7	B	GND (POWER)																																											
Connector No.	E152																																												
Connector Name	WIRE TO WIRE																																												
Connector Color	WHITE																																												
Terminal No.	Color of Wire	Signal Name																																											
41G	9G	3G																																											
50G	4G	4G																																											
61G	6G	5G																																											
70G	6G	6G																																											
81G	7G	7G																																											
90G	8G	8G																																											
100G	9G	9G																																											

ABLIA4637GB

FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	E211
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	W	-
8	B	-

Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
74	W	FR FOG LAMP RH
79	L	FR FOG LAMP LH

Terminal No.	Color of Wire	Signal Name
78	W	FR FOG LAMP RH
79	L	FR FOG LAMP LH



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	E302
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	E301
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	W	-
8	B	-

Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-


ABLIA3570GB

FRONT FOG LAMP SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	B11
Connector Name	JOINT CONNECTOR-B09
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-




Connector No.	E306
Connector Name	FRONT FOG LAMP RH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-




Connector No.	B17
Connector Name	JOINT CONNECTOR-B12
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-



Connector No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-



A B C D E F G H I J K L M N O P EXL

ABLIA3571GB

FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]



TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

Wiring Diagram

INFOID:0000000011134647




TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

TURN SIGNAL AND HAZARD WARNING LAMPS CONNECTORS

Connector No.	M3	Connector No.	M4
Connector Name	FUSE BLOCK (J/B)	Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE	Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Signal Name
6N	W	—	—
13P	W	—	—

Terminal No.	Color of Wire	Signal Name	Signal Name
8P	BG	—	—
13P	W	—	—
20	GP	SP	3P
39	GP	1P	2P
38	GP	1P	1P
37	GP	1P	GP
36	GP	1P	GP
35	GP	1P	GP
34	GP	1P	GP
33	GP	1P	GP
32	GP	1P	GP
31	GP	1P	GP
30	GP	1P	GP
29	GP	1P	GP
28	GP	1P	GP
27	GP	1P	GP
26	GP	1P	GP
25	GP	1P	GP
24	GP	1P	GP
23	GP	1P	GP
22	GP	1P	GP
21	GP	1P	GP

Terminal No.	Color of Wire	Signal Name	Signal Name
10	P	COMBI SW IN 5	—
11	P	COMBI SW IN 4	—
12	V	COMBI SW IN 3	—
13	W	COMBI SW IN 2	—
14	P	COMBI SW IN 1	—
36	LG	HAZARD SW	—

Connector No.	M19	Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)	Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK	Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name	Signal Name
92	R	RR FLASHER	—
103	BG	RL FLASHER	—
60	59	58	57
59	58	57	56
58	57	56	55
57	56	55	54
56	55	54	53
55	54	53	52
54	53	52	51
53	52	51	50
52	51	50	49
51	50	49	48
50	49	48	47
49	48	47	46
48	47	46	45
47	46	45	44
46	45	44	43
45	44	43	42
44	43	42	41
43	42	41	40
42	41	40	39
41	40	39	38
40	39	38	37
39	38	37	36
38	37	36	35
37	36	35	34
36	35	34	33
35	34	33	32
34	33	32	31
33	32	31	30
32	31	30	29
31	30	29	28
30	29	28	27
29	28	27	26
28	27	26	25
27	26	25	24
26	25	24	23
25	24	23	22
24	23	22	21

Terminal No.	Color of Wire	Signal Name	Signal Name
1	B	GND1	—
2	B	GND2	—
21	BG	IGN	—
22	W	BAT	—
38	P	CAN-L	—
39	L	CAN-H	—

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]



ABLIA4983GB

A B C D E F G H I J K M O P EXL

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE




Connector No.	M41
Connector Name	JOINT CONNECTOR-M18
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
105	LG	FR FLASHER
117	SB	FL FLASHER



Terminal No.	Color of Wire	Signal Name
2	4	6
3	3	8
5	5	10
7	7	12
9	9	14
11	11	16
13	13	1
15	15	2
17	17	3
19	19	4
21	21	5
23	23	6
25	25	7
27	27	8
29	29	9
30	30	10
31	31	11
32	32	12
33	33	13
34	34	14
35	35	15
36	36	16

Terminal No.	Color of Wire	Signal Name
2	4	6
3	3	8
5	5	10
7	7	12
9	9	14
11	11	16
13	13	1
15	15	2
17	17	3
19	19	4
21	21	5
23	23	6
25	25	7
27	27	8
29	29	9
30	30	10
31	31	11
32	32	12
33	33	13
34	34	14
35	35	15
36	36	16

Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND 2

Terminal No.	Color of Wire	Signal Name
139	W	BAT POWER F/L

Terminal No.	Color of Wire	Signal Name
143	B	GND 1

ABLIA4984GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


A B C D E F G H I J K M N O P EXL

Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	G	-
12	W	-

Connector No.	E209
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10G	P	-
19G	W	-
20G	G	-

Connector No.	E209
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	SB	-
12	Y	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABLIA3577GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	E239
Connector Name	FRONT COMBINATION
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
5	Y	-
6	B	-



Connector No.	E234
Connector Name	FRONT COMBINATION
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Terminal No.	Color of Wire	Signal Name
5	SB	-
6	B	-



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-


ABLIA3578GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


[XENON TYPE]

Connector No.	B32
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
11A	W	-
12A	G	-
89A	L	-
90A	P	-

Connector No.	B77
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	G	-
5	W	-

ABLIA4985GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B102
Connector Name	JOINT CONNECTOR-B14
Connector Color	WHITE



Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-

Terminal No.	Color of Wire	Signal Name
1	L	-
18	P	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

A

B

C

D

E

F

G

H

J

K

EXL

M

N

O

P

Connector No.	B409
Connector Name	REAR COMBINATION LAMP
RH	



Terminal No.	Color of Wire	Signal Name
4	G	-
5	B	-

Terminal No.	Color of Wire	Signal Name
4	G	-
5	B	-



Connector No.	B408
Connector Name	REAR COMBINATION LAMP
LH	



ABLIA3644GB


PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

PARKING, LICENSE PLATE AND TAIL LAMPS CONNECTORS


Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
6N	W	—

Terminal No.	Color of Wire	Signal Name
10	P	COMBI SW IN 5
11	P	COMBI SW IN 4
12	V	COMBI SW IN 3
13	W	COMBI SW IN 2
14	P	COMBI SW IN 1

Terminal No.	Color of Wire	Signal Name
59	P	CAN-L
60	L	CAN-H
70	P	IGN USM OUT 1
75	BG	COMBI SW OUT 5
76	P	COMBI SW OUT 4
77	P	COMBI SW OUT 3
78	W	COMBI SW OUT 2
79	W	COMBI SW OUT 1

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P


ABLIA4986GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M41
Connector Name	JOINT CONNECTOR M18
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Terminal No.	Color of Wire	Signal Name
10G	W	-
35G	P	-
36G	L	-
63G	P	-

ABLIA4987GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	M43
Connector Name	JOINT CONNECTOR M17
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND 2
139	W	BAT POWER F/L
143	B	GND 1

Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
16	L	-
17	P	-

Terminal No.	Color of Wire	Signal Name
16	L	-
17	P	-
18	L	-
19	P	-
20	L	-
21	P	-
22	L	-
23	P	-
24	L	-
25	P	-
26	L	-
27	P	-
28	L	-
29	P	-
30	L	-
31	P	-
32	L	-
33	P	-
34	L	-
35	P	-
36	L	-
37	P	-
38	L	-
39	P	-
40	L	-
41	P	-
42	L	-
43	P	-

A B C D E F G H I J K L M N O P EXL


ABLIA3584GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[XENON TYPE]

Connector No.	E70
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-

Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
4	L	-
7	P	-
10	P	-

Connector No.	E119
Connector Name	IPDM ER (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-

Connector No.	E121
Connector Name	IPDM ER (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H
41	B	GND (SIGNAL)
43	L	IGN SIGNAL

Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)
9	G	TAIL RH
10	L	TAIL LH


ABLIA4649GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	P	-
35G	P	-
36G	L	-
63G	L	-



Terminal No.	Color of Wire	Signal Name
5G	4G	3G
10G	8G	8G
		7G
		6G



Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
90	LG	CLEARANCE



Terminal No.	Color of Wire	Signal Name
90	LG	E235
		FRONT COMBINATION LAMP LH



Terminal No.	Color of Wire	Signal Name
7	LG	-
8	B	-



Terminal No.	Color of Wire	Signal Name
4	B	-
7	LG	-



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P

ABLIA4988GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	E240
Connector Name	FRONT COMBINATION
Connector Color	GRAY



Connector No.	E325
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
7	LG	-
8	B	-

Connector No.	E240
Connector Name	FRONT COMBINATION
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
9	LG	-
10	B	-


Connector No.	E326
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	2	3
2	3	4
3	5	6
4	6	7
5	7	8




Connector No.	E333
Connector Name	FRONT COMBINATION
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
4	B	-
7	LG	-




Connector No.	E329
Connector Name	FRONT COMBINATION
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
9	LG	-
10	B	-



Connector No.	E333
Connector Name	FRONT COMBINATION
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-




PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	B16
Connector Name	JOINT CONNECTOR B11
Connector Color	WHITE



Connector No.	B12
Connector Name	JOINT CONNECTOR B10
Connector Color	WHITE



Connector No.	B29
Connector Name	FUSE BLOCK (J1B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-


Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P


ABLIA358GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	B34
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	W	-




Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
22	W	-

Connector No.	B47
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	W	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
31	W	-
32	W	-
33	W	-


ABLIA4990GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-



Connector No.	B77
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
31	W	-




Terminal No.	Color of Wire	Signal Name
31	W	-



Terminal No.	Color of Wire	Signal Name
31	W	-

Terminal No.	Color of Wire	Signal Name
31	W	-



Terminal No.	Color of Wire	Signal Name
31	W	-

Terminal No.	Color of Wire	Signal Name
31	W	-



Terminal No.	Color of Wire	Signal Name
31	W	-

Terminal No.	Color of Wire	Signal Name
1	P	-

Terminal No.	Color of Wire	Signal Name
2	P	-

Terminal No.	Color of Wire	Signal Name
1	P	-

Terminal No.	Color of Wire	Signal Name
2	P	-

EXL M Z O P K M Z O P A B C D E F G H I J K L

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	B124
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B400
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B405
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

Terminal No.	Color of Wire	Signal Name
31	W	-

Terminal No.	Color of Wire	Signal Name
2	W	-
3	B	-

Terminal No.	Color of Wire	Signal Name
1	B	-



Terminal No.	Color of Wire	Signal Name
1	B	-



Terminal No.	Color of Wire	Signal Name
2	W	-
3	GR	-



PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D502
Connector Name	WIRE TO WIRE
Connector Color	GRAY





Terminal No.	Color of Wire	Signal Name
2	B	-

Terminal No.	Color of Wire	Signal Name
12	Y	-


Terminal No.	Color of Wire	Signal Name
1	B	-

Terminal No.	Color of Wire	Signal Name
7	BR	-

Terminal No.	Color of Wire	Signal Name
7	BR	-



Connector No.	D507
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-

Terminal No.	Color of Wire	Signal Name
7	Y	-

A B C D E F G H I J K L M N O P EXL

ABLIA4992GB

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	D562
Connector Name	LICENSE PLATE LAMP RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	-
2	BR	-

Connector No.	D561
Connector Name	LICENSE PLATE LAMP LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	-
2	BR	-

ABLIA4993GB

STOP LAMP

[XENON TYPE]

< WIRING DIAGRAM >

STOP LAMP

Wiring Diagram

INFOID:0000000011134649

A

B

C

D

E

F

G

H

I

K

EXL


M

N

O

P

STOP LAMP



ABLWA2200GB


STOP LAMP

< WIRING DIAGRAM >

[XENON TYPE]

STOP LAMP CONNECTORS

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	E38
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE



Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	Y	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
10	10	10
11	11	11
12	12	12
13	13	13
14	14	14
15	15	15
16	16	16
17	17	17
18	18	18
19	19	19
20	20	20
21	21	21
22	22	22
23	23	23
24	24	24
25	25	25
26	26	26
27	27	27
28	28	28
29	29	29
30	30	30
31	31	31
32	32	32
33	33	33

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
10	10	10
11	11	11
12	12	12
13	13	13
14	14	14
15	15	15
16	16	16
17	17	17
18	18	18
19	19	19
20	20	20
21	21	21
22	22	22
23	23	23
24	24	24
25	25	25
26	26	26
27	27	27
28	28	28
29	29	29
30	30	30
31	31	31
32	32	32
33	33	33

Terminal No.	Color of Wire	Signal Name
12	P	-
13	P	-
19	Y	-
20	Y	-



Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2

Terminal No.	Color of Wire	Signal Name
1	B	-
5Q	G	-

STOP LAMP

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	B47
Connector Name	WIRE TO WIRE
Connector Color	GRAY



1	2	3	4
5	6	7	8



Connector No.	B77
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32



Terminal No.	Color of Wire	Signal Name
15	G	-

Terminal No.	Color of Wire	Signal Name
15	G	-

Terminal No.	Color of Wire	Signal Name
15	G	-



Terminal No.	Color of Wire	Signal Name
1	G	-
3	GR	-

Terminal No.	Color of Wire	Signal Name
1	G	-
3	GR	-

Connector No.	B406
Connector Name	REAR COMBINATION LAMP
Connector Color	GRAY



Connector No.	B404
Connector Name	WIRE TO WIRE
Connector Color	BLACK



ABLIA4995GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P

STOP LAMP


< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	D503
Connector Name	HIGH-MOUNTED STOP LAMP
Connector Color	BROWN



Connector No.	D502
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	B	-

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	LG	-

Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-



ABLIA4996GB

BACK-UP LAMP


[XENON TYPE]

< WIRING DIAGRAM >

BACK-UP LAMP

Wiring Diagram

INFOID:0000000011134650



ABLWA2906GB


BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]

BACK-UP LAMP CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20	W	SHIFT P
27	G	BRAKE SW LAMP

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
20	W	SHIFT P
27	G	BRAKE SW LAMP

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
59	P	CAN-L
60	L	CAN-H

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
104	LG	REVERSE LAMP OUT

Terminal No.	Color of Wire	Signal Name
69	G	AT DEVICE OUT

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	W	-
35G	P	-

Terminal No.	Color of Wire	Signal Name
69	L	-

1G	2G	3G	4G	5G
6G	7G	8G	9G	10G

1G	2G	3G	4G	5G
6G	7G	8G	9G	10G

9G	10G
----	-----


Terminal No.	Color of Wire	Signal Name
104	LG	REVERSE LAMP OUT

BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY





Terminal No.	Color of Wire	Signal Name
79A	LG	-
89A	L	-
90A	P	-



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Connector No.	M43
Connector Name	JOINT CONNECTOR M17
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-




Terminal No.	Color of Wire	Signal Name
1	1	1
2	2	2
3	3	3
4	4	4
5	5	5
6	6	6
7	7	7
8	8	8
9	9	9
10	10	10
11	11	11
12	12	12



Terminal No.	Color of Wire	Signal Name
9R	G	-
1	L	-
2	L	-



Terminal No.	Color of Wire	Signal Name
3	G	-
4	GR	-
5	G	-
6	W	-




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P

BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]



Connector No.	M80
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
108	G	SHIFT LOCK SOLENOID OUT



Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND2
139	W	BAT POWER F/L
143	B	GND1

Terminal No.	Color of Wire	Signal Name
16	14	13
17	14	11
18	14	9
19	14	8
20	14	7
21	14	6
22	14	5
23	14	4
24	14	3
25	14	2
26	14	1
27	14	12
28	14	10
29	14	9
30	14	8
31	14	7
32	14	6
33	14	5
34	14	4
35	14	3
36	14	2
37	14	1
38	14	12
39	14	10
40	14	9
41	14	8
42	14	7
43	14	6
44	14	5
45	14	4
46	14	3
47	14	2
48	14	1



Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-



Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-


Terminal No.	Color of Wire	Signal Name
9	P	-
10	L	-

ABLIA3599GB

BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]



Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE

H.S.

Terminal No.	Color of Wire	Signal Name
1	Y	-
2	P	-

Terminal No.	Color of Wire	Signal Name
12	P	-
13	P	-
19	Y	-
20	Y	-

Terminal No.	Color of Wire	Signal Name
12	P	-
13	P	-
19	Y	-
20	Y	-

Terminal No.	Color of Wire	Signal Name
12	P	-
13	P	-
19	Y	-
20	Y	-

Terminal No.	Color of Wire	Signal Name
12	P	-
13	P	-
19	Y	-
20	Y	-

Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE

H.S.

Terminal No.	Color of Wire	Signal Name
1	L	-
3	L	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
7	P	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
7	P	-

ABLIA4998GB

A

B
C
D
E
F
G

K
EXL


M
Z
O

P

BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]




ABLIA7059GB

BACK-UP LAMP


< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	B11
Connector Name	JOINT CONNECTOR-B09
Connector Color	WHITE




Connector No.	F89
Connector Name	TCM (TRANSMISSION CONTROL MODULE) (EXCEPT FOR MEXICO)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
3	P	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
3	P	-


Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-



Connector No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
3	P	-



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

A B C D E F G H I J K M O P EXL


ABLIA7060GB

BACK-UP LAMP


< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-





Terminal No.	Color of Wire	Signal Name
22	BR	-
		-

Terminal No.	Color of Wire	Signal Name
2	B	-

Terminal No.	Color of Wire	Signal Name
78A	BR	-
88A	L	-
90A	P	-

Terminal No.	Color of Wire	Signal Name
2	B	-

Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-



ABLIA7061GB

BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	B103
Connector Name	JOINT CONNECTOR-B15
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-


Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	B124
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	6	9
2	7	10
3	5	11
4	4	12
5	3	13
6	2	14
7	1	15
8	—	16
9	—	17
10	—	18
11	—	19
12	—	20
13	—	21
14	—	22
15	—	23
16	—	24
17	—	25
18	—	26
19	—	27
20	—	28
21	—	29
22	—	30
23	—	31
24	—	32


Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	D502
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	3	1
3	2	2
2	1	3
1	—	4
8	7	5
7	6	6
6	5	7
5	4	8



Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
22	LG	-

A B C D E F G H I J K M N O P EXL


ABLIA5002GB

BACK-UP LAMP

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	D507
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	D550
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	LG	-

Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	D563
Connector Name	BACK-UP LAMP RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-

Connector No.	D564
Connector Name	BACK-UP LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-

ABLIA5003GB

TRAILER TOW


[XENON TYPE]

< WIRING DIAGRAM >

TRAILER TOW

Wiring Diagram

INFOID:0000000011134651




ABLWA2907GB

TRAILER TOW

< WIRING DIAGRAM >

[XENON TYPE]



ABLWA2908GB


TRAILER TOW

[XENON TYPE]

< WIRING DIAGRAM >

TRAILER TOW CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
6N	W	-

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
10	P	COMBI SW IN 5
11	P	COMBI SW IN 4
12	V	COMBI SW IN 3
13	W	COMBI SW IN 2
14	P	COMBI SW IN 1
59	P	CAN-L
60	L	CAN-H
70	P	IGN USM CUT 1
75	BG	COMBI SW OUT 5
76	P	COMBI SW OUT 4
77	P	COMBI SW OUT 3
78	W	COMBI SW OUT 2
79	W	COMBI SW OUT 1

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	P	-
5	V	-
7	P	-
8	P	-
9	W	-
10	P	-
11	W	-
12	P	-
13	BG	-
14	W	-

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
86	R	TRAILER FLASHER RL
87	P	TRAILER FLASHER RR
104	LG	REVERSE LAMP OUT


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL

TRAILER TOW

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M41
Connector Name	JOINT CONNECTOR-M18
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

1A 2A 3A 4A 5A 6A 7A 8A 9A 10A	1A 2A 3A 4A 5A 6A 7A 8A 19A 20A 21A
22A 23A 24A 25A 26A 27A 28A 29A 30A	22A 23A 24A 25A 26A 27A 28A 29A 30A
31A 32A 33A 34A 35A 36A 37A 38A 39A 40A 41A	31A 32A 33A 34A 35A 36A 37A 38A 39A 40A 41A
42A 43A 44A 45A 46A 47A 48A 49A 50A	42A 43A 44A 45A 46A 47A 48A 49A 50A
51A 52A 53A 54A 55A 56A 57A 58A 59A 60A 61A	51A 52A 53A 54A 55A 56A 57A 58A 59A 60A 61A
62A 63A 64A 65A 66A 67A 68A 69A 70A	62A 63A 64A 65A 66A 67A 68A 69A 70A
71A 72A 73A 74A 75A 76A 77A 78A 79A 80A 81A	71A 72A 73A 74A 75A 76A 77A 78A 79A 80A 81A
82A 83A 84A 85A 86A 87A 88A 89A 90A	82A 83A 84A 85A 86A 87A 88A 89A 90A
91A 92A 93A 94A 95A 96A 97A 98A 99A 100A	91A 92A 93A 94A 95A 96A 97A 98A 99A 100A

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1G 2G 3G 4G 5G 6G 7G 8G 9G 10G	1G 2G 3G 4G 5G 6G 7G 8G 9G 20G 21G
22G 23G 24G 25G 26G 27G 28G 29G 30G	22G 23G 24G 25G 26G 27G 28G 29G 30G
31G 32G 33G 34G 35G 36G 37G 38G 39G 40G 41G	31G 32G 33G 34G 35G 36G 37G 38G 39G 40G 41G
42G 43G 44G 45G 46G 47G 48G 49G 50G	42G 43G 44G 45G 46G 47G 48G 49G 50G
51G 52G 53G 54G 55G 56G 57G 58G 59G 60G 61G	51G 52G 53G 54G 55G 56G 57G 58G 59G 60G 61G
62G 63G 64G 65G 66G 67G 68G 69G 70G	62G 63G 64G 65G 66G 67G 68G 69G 70G
71G 72G 73G 74G 75G 76G 77G 78G 79G 80G 81G	71G 72G 73G 74G 75G 76G 77G 78G 79G 80G 81G
82G 83G 84G 85G 86G 87G 88G 89G 90G	82G 83G 84G 85G 86G 87G 88G 89G 90G
91G 92G 93G 94G 95G 96G 97G 98G 99G 100G	91G 92G 93G 94G 95G 96G 97G 98G 99G 100G

Terminal No.	Color of Wire	Signal Name
8A	W	-
68A	LG	-
79A	LG	-
89A	L	-
90A	P	-

Terminal No.	Color of Wire	Signal Name
4G	G	-
10G	W	-
35G	P	-
36G	L	-
43G	W	-
63G	P	-
89G	R	-
90G	P	-

ABLIA5004GB

TRAILER TOW

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE



Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	L	-	2R	LG	-
2	L	-			

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	L	-	2R	LG	-
2	L	-			

Connector No.	M76
Connector Name	ELECTRIC BRAKE (PRE-WIRING)
Connector Color	WHITE




Connector No.	M120
Connector Name	JOINT CONNECTOR-M21
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-
3	W	-
5	G	-

Terminal No.	Color of Wire	Signal Name
1	4	3 2 1

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
16	15	14 13 12 11 10 9 8 7 6 5 4 3 2 1
32	31	29 28 27 26 25 24 23 22 21 20 19 18 17

Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-

ABLIA7062GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
EXL

TRAILER TOW

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5M	Y	-
6M	L	-
7M	P	-
8M	R	-

Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-

Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	R	-
6	L	-
11	G	-
12	W	-



Connector No.	E38
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	P	-



Terminal No.	Color of Wire	Signal Name
5	R	-
6	R	-
12	P	-
13	P	-
19	Y	-
20	Y	-

Terminal No.	Color of Wire	Signal Name
1	Y	-
2	P	-


ABLIA5006GB

TRAILER TOW


[XENON TYPE]

< WIRING DIAGRAM >


Connector No.	E70
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	—
4	L	—
7	P	—
10	P	—




Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLACK



Connector No.	E71
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	—
2	L	—



Connector No.	E78
Connector Name	TRAILER TURN RELAY RH
Connector Color	BLUE



Connector No.	E77
Connector Name	TRAILER TURN RELAY LH
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
19	20	21
35	36	37
20	21	22
37	38	39
21	22	23
38	39	40
22	23	24
39	40	41
23	24	25
40	41	42
24	25	26
41	42	43
25	26	27
42	43	44
26	27	28
43	44	45
27	28	29
44	45	46
28	29	30
45	46	47
29	30	31
46	47	48
30	31	32
47	48	49
31	32	33
48	49	50
32	33	34
49	50	35

Terminal No.	Color of Wire	Signal Name
1	P	—
2	L	—
3	P	—
5	G	—

Terminal No.	Color of Wire	Signal Name
1	P	—
2	R	—
3	P	—
5	W	—

P

Z

M

EXL

A

B

C

D

F

G

H

I

K

L

ABLIA5007GB


TRAILER TOW

< WIRING DIAGRAM >


[XENON TYPE]

Terminal No.	Color of Wire	Signal Name
4G	R	-
10G	P	-
35G	P	-
36G	L	-
43G	R	-
63G	L	-
89G	R	-
90G	L	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)
10	L	TAIL LH



Terminal No.	Color of Wire	Signal Name
4G	R	-
10G	P	-
35G	P	-
36G	L	-
43G	R	-
63G	L	-
89G	R	-
90G	L	-



Connector No.	B12
Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-


Connector No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE

TRAILER TOW


< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	B21
Connector Name	JOINT CONNECTOR-B20
Connector Color	WHITE



Connector No.	B22
Connector Name	JOINT CONNECTOR-B20
Connector Color	WHITE



Connector No.	B17
Connector Name	JOINT CONNECTOR-B12
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	BR	-
3	BR	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-


Terminal No.	Color of Wire	Signal Name
1T	W	-

Terminal No.	Color of Wire	Signal Name
1	BR	-
3	BR	-



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	W	-
3	G	-
6	G	-
7	W	-

Terminal No.	Color of Wire	Signal Name
1	BR	-
3	BR	-



Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

A B C D E F G H I J K L M N O P EXL


ABLIA7063GB

TRAILER TOW

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	B43
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B44
Connector Name	WIRE TO WIRE
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-

Terminal No.	Color of Wire	Signal Name
5	R	-
6	L	-
11	G	-
12	W	-


Terminal No.	Color of Wire	Signal Name
1	W	-

Terminal No.	Color of Wire	Signal Name
2	BR	-
5	P	-
6	L	-
9	GR	-
10	W	-
11	W	-
13	Y	-
16	R	-

Connector No.	B48
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
29	W	-
33	W	-



Terminal No.	Color of Wire	Signal Name
1	W	-

Terminal No.	Color of Wire	Signal Name
29	W	-
33	W	-


ABLIA7064GB

TRAILER TOW

< WIRING DIAGRAM >

[XENON TYPE]

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL



ABLIA7065GB

TRAILER TOW


< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	B404
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Connector No.	B405
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	B	-	1	Y	-
2	W	-	2	W	-
			3	G	-
			6	G	-
			7	W	-

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	B	-	1	Y	-
2	W	-	2	W	-
			3	Y	-
			5	G	-
			6	W	-

Connector No.	B411
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Connector No.	B410
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	G	-	1	V	-
2	W	-	2	L	-

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1	B	-	1	B	-
2	W	-	2	W	-


ABLIA7066GB

TRAILER TOW

< WIRING DIAGRAM >


[XENON TYPE]

Connector No.	B426
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	G	-
5	W	-
6	Y	-
9	B	-
10	W	-
11	G	-
13	LG	-
16	R	-

Connector No.	B428
Connector Name	TRAILER TOW RELAY 1
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-
3	R	-
5	W	-

Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-
3	L	-
5	V	-
6	L	-
7	V	-

Connector No.	B451
Connector Name	WIRE TO WIRE
Connector Color	BLACK



1	W	-
2	B	-
3	L	-
5	V	-
6	L	-
7	V	-

Connector No.	B450
Connector Name	WIRE TO WIRE
Connector Color	GRAY



1	W	-
2	B	-
3	L	-
5	V	-
6	L	-
7	V	-

Connector No.	B431
Connector Name	TRAILER BACK-UP RELAY
Connector Color	BLUE



1	G	-
2	B	-
3	Y	-
5	LG	-
6	W	-


A B C D E F G H I J K L M N O P EXL

TRAILER TOW

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	B454
Connector Name	TRAILER RECEPTACLE
Connector Color	BLACK



Connector No.	B453
Connector Name	TRAILER
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-
3	G	-
4	G	-
5	W	-
6	W	-
7	Y	-

Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-
3	G	-
4	G	-
5	W	-
6	W	-
7	Y	-

ABLIA7067GB

HEADLAMP AIMING SYSTEM (MANUAL)


< WIRING DIAGRAM >

HEADLAMP AIMING SYSTEM (MANUAL)

Wiring Diagram

[XENON TYPE]

INFOID:0000000011134652



ABLWA2909GB


HEADLAMP AIMING SYSTEM (MANUAL)

< WIRING DIAGRAM >

[XENON TYPE]

HEADLAMP AIMING SYSTEM CONNECTORS


Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
10	P	COMBI SW IN 5	59	P	CAN-L
11	P	COMBI SW IN 4	60	L	CAN-H
12	V	COMBI SW IN 3	70	P	IGN USM OUT 1
13	W	COMBI SW IN 2	75	BG	COMBI SW OUT 5
14	P	COMBI SW IN 1	76	P	COMBI SW OUT 4
			77	P	COMBI SW OUT 3
			78	W	COMBI SW OUT 2
			79	W	COMBI SW OUT 1

Terminal No.	Color of Wire	Signal Name
6N	W	-

Terminal No.	Color of Wire	Signal Name
6N	W	-

Terminal No.	Color of Wire	Signal Name
2	P	-
5	V	-
7	P	-
8	P	-
9	W	-
10	P	-
11	W	-
12	P	-
13	BG	-
14	W	-

Terminal No.	Color of Wire	Signal Name
2	P	-
5	V	-
7	P	-
8	P	-
9	W	-
10	P	-
11	W	-
12	P	-
13	BG	-
14	W	-




ABLIA5015GB

HEADLAMP AIMING SYSTEM (MANUAL)

< WIRING DIAGRAM >

[XENON TYPE]



ABLIA5016GB

HEADLAMP AIMING SYSTEM (MANUAL)

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE




Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1R	R	-	131	W	BAT BCM FUSE
1L	L	-	134	B	GND 2
2R	R	-	139	W	BAT POWER F/L
2L	L	-	143	B	GND 1

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-

Terminal No.	Color of Wire	Signal Name
1	V	-
2	B	-
3	R	-
4	B	-

Terminal No.	Color of Wire	Signal Name
12	R	-
14	R	-

Terminal No.	Color of Wire	Signal Name
11	9	8
10	8	7
9	7	6
8	6	5
7	5	4
6	4	3
5	2	1

Terminal No.	Color of Wire	Signal Name
16	15	14
15	14	13
14	13	12
13	12	11
12	11	10
11	10	9
10	9	8
9	8	7
8	7	6
7	6	5
6	5	4
5	4	3
4	3	2
3	2	1

Terminal No.	Color of Wire	Signal Name
22	21	20
21	20	19
20	19	18
19	18	17
18	17	16
17	16	15
16	15	14
15	14	13
14	13	12

Terminal No.	Color of Wire	Signal Name
33	32	31
32	31	30
31	30	29
30	29	28
29	28	27
28	27	26
27	26	25
26	25	24
25	24	23

Terminal No.	Color of Wire	Signal Name
12	R	-
14	R	-


ABLIA5017GB

HEADLAMP AIMING SYSTEM (MANUAL)


< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M181
Connector Name	JOINT CONNECTOR M36
Connector Color	WHITE



Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
20	BG	-

Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-

Terminal No.	Color of Wire	Signal Name
12	11	-
10	9	-
9	8	-
8	7	-
7	6	-
6	5	-
5	4	-
4	3	-
3	2	-
2	1	-

Terminal No.	Color of Wire	Signal Name
6M	L	-



Connector No.	E70
Connector Name	JOINT CONNECTOR-E14
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
7	P	-
10	P	-



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
12	11	-
10	9	-
9	8	-
8	7	-
7	6	-
6	5	-
5	4	-
4	3	-
3	2	-
2	1	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P


ABLIA3605GB

HEADLAMP AIMING SYSTEM (MANUAL)

< WIRING DIAGRAM >


[XENON TYPE]

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H
41	B	GND (SIGNAL)
43	L	IGN SIGNAL



Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)
10	L	TAIL LH

Terminal No.	Color of Wire	Signal Name
10G	P	-
14G	BG	-
35G	P	-
36G	L	-
63G	L	-

Terminal No.	Color of Wire	Signal Name
10G	P	-
14G	BG	-



Terminal No.	Color of Wire	Signal Name
20	V	-




ABLIA4643GB

HEADLAMP AIMING SYSTEM (MANUAL)


< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
75	R	HEADLAMP LO RH
76	L	HEADLAMP LO LH




Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
75	R	HEADLAMP LO RH
76	L	HEADLAMP LO LH


Connector No.	E232
Connector Name	WIRE TO WIRE
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	V	-
2	B	-
5	SB	-



Connector No.	E233
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	V	-
2	B	-
5	SB	-



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P


ABLIA5018GB

HEADLAMP AIMING SYSTEM (MANUAL)

< WIRING DIAGRAM >

[XENON TYPE]


Connector No.	E334
Connector Name	FRONT COMBINATION LAMP RH (HEADLAMP AIMING MOTOR)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
13	V	-
14	L	-
15	B	-




Connector No.	E330
Connector Name	FRONT COMBINATION LAMP LH (HEADLAMP AIMING MOTOR)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
13	V	-
14	L	-
15	B	-


Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

ABLIA5019GB


HEADLAMP AIMING SYSTEM (MANUAL)

< WIRING DIAGRAM >


[XENON TYPE]

Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-

Connector No.	B32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-

Connector No.	B102
Connector Name	JOINT CONNECTOR-B14
Connector Color	WHITE



Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-

Connector No.	B103
Connector Name	JOINT CONNECTOR-B15
Connector Color	WHITE




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL

HEADLAMP AIMING SYSTEM (MANUAL)

< WIRING DIAGRAM >

[XENON TYPE]

Connector No.	B124	
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	

Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

ABLIA5021GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000011134653

OVERALL SEQUENCE



AWLIA1823GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[XENON TYPE]

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

>> GO TO 2.

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3.

3. BASIC INSPECTION

Check the operation of each part. Check any concerns that occur other than those mentioned in the customer interview.

>> GO TO 4.

4. SELF-DIAGNOSIS WITH CONSULT

Perform the self-diagnosis with CONSULT. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Refer to [EXL-148, "Symptom Table"](#).

>> GO TO 9.

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10.

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform the self-diagnosis with CONSULT. Verify that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[XENON TYPE]

YES >> GO TO 5.

NO >> GO TO 11.

A

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

B

Does it operate normally?

YES >> Inspection End.

C

NO >> GO TO 3.

D

E

F

G

H

I

J

K

EXL

M

N

O

P

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:0000000011544367

Regarding Wiring Diagram information, refer to [BCS-54, "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	O (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
 NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M81.
2. Check voltage between BCM connector M81 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M81	131	—	Battery voltage
	139		

Is the inspection result normal?

- YES >> GO TO 3
 NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M81 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	134	—	Yes
	143		

Is the inspection result normal?

- YES >> Inspection End.
 NO >> Repair or replace harness or connectors.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:0000000011544368

Regarding Wiring Diagram information, refer to [PCS-21, "Wiring Diagram"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

1. CHECK FUSIBLE LINKS

Check that the following fusible links are not blown.

Terminal No.	Signal name	Fusible link No.
1	Fusible link main	E (80A)
2	Fusible link IPDM E/R	A (250A), C (80A)
3	Fusible link ignition switch	A (250A), B (100A), K (40A)

Is the fusible link blown?

- YES >> Replace the blown fusible link after repairing the affected circuit.
NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R connectors E118 and E120.
2. Check voltage between IPDM E/R connectors and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E118	1	—	Battery voltage
	2		
E120	3	—	—

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R connectors E119 and E121.
2. Check continuity between IPDM E/R connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E121	7	—	Yes
	41		

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

HEADLAMP (HI) CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

HEADLAMP (HI) CIRCUIT

Description

INFOID:0000000011134656

The IPDM E/R (intelligent power distribution module engine room) controls the headlamp high relay based on inputs from the BCM over the CAN communication lines. When the headlamp high relay is energized, power flows through fuses 34 and 35, located in the IPDM E/R. Power then flows to the front combination lamps to the headlamp high beam.

Component Function Check

INFOID:0000000011134657

1. CHECK HEADLAMP (HI) OPERATION

WITHOUT CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the headlamp switches to the high beam.

WITH CONSULT

1. Select EXTERNAL LAMP of IPDM E/R active test item.
2. While operating the test items, check that the headlamp switches to the high beam.

HI : Headlamp switches to the high beam.

OFF : Headlamp OFF

Does the headlamp switch to the high beam?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-126, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011134658

Regarding Wiring Diagram - Refer to [EXL-22, "Wiring Diagram"](#).

1. CHECK HEADLAMP (HI) FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	35	10A
Headlamp HI (RH)	IPDM E/R	34	10A

Is the fuse open?

YES >> Replace the fuse after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

CONSULT ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp harness connector E331 or E327.
3. Turn the ignition switch ON.
4. Select EXTERNAL LAMP of IPDM E/R active test item.
5. With EXTERNAL LAMP ON, check the voltage between the combination lamp harness connector and ground.

Connector	(+)	Terminal	(-)	Voltage
RH	E331	3	Ground	Battery voltage
LH	E327			

HEADLAMP (HI) CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

Is battery voltage present?

- YES >> GO TO 4.
NO >> GO TO 3.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

3. CHECK HEADLAMP (HI) CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R harness connector E217.
3. Check continuity between the IPDM E/R harness connector E217 and the front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E217	80	E331	3
LH		81	E327	

Does continuity exist?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).
NO >> Repair the harnesses or connectors.

4. CHECK FRONT COMBINATION LAMP (HI) GROUND CIRCUIT

Check continuity between the front combination lamp harness connector terminal 4 and ground.

Connector		Terminal	—	Continuity
RH	E331	4	Ground	Yes
LH	E327			

Does continuity exist?

- YES >> Replace the headlamp bulb.
NO >> Repair or replace the harness or connector.

< DTC/CIRCUIT DIAGNOSIS >

HEADLAMP (LO) CIRCUIT**Description**

INFOID:0000000011134659

The IPDM E/R (intelligent power distribution module engine room) controls the headlamp low relay based on inputs from the BCM over the CAN communication lines. When the headlamp low relay is energized, power flows through fuses 36 and 37, located in the IPDM E/R. Power then flows to the front combination lamps to the headlamp low beam.

Component Function Check

INFOID:0000000011134660

1. CHECK HEADLAMP (LO) OPERATION **WITHOUT CONSULT**

1. Start IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the headlamp is turned ON.

NOTE:

H/L is repeated 1 second each when using the IPDM E/R auto active test.

 CONSULT

1. Select EXTERNAL LAMP of IPDM E/R active test item.
2. While operating the test item, check that the headlamp is turned ON.

LO : Headlamp ON**OFF : Headlamp OFF****Is the headlamp turned ON?**

YES >> Headlamp (LO) is normal.

NO >> Refer to [EXL-128, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011134661

Regarding Wiring Diagram information - Refer to [EXL-22, "Wiring Diagram"](#).

1. CHECK HEADLAMP (LO) FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

Unit	Location	Fuse No.	Capacity
Headlamp LO (LH)	IPDM E/R	37	15A
Headlamp LO (RH)	IPDM E/R	36	15A

Is the fuse open?

YES >> Replace the fuse after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK HEADLAMP (LO) OUTPUT VOLTAGE **CONSULT**

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp harness connector E332 or E328.
3. Turn the ignition switch ON.
4. Select EXTERNAL LAMP of IPDM E/R active test item.
5. With EXTERNAL LAMP ON, check the voltage between the front combination lamp harness connector E332 or E328 terminal 1 and ground.

(+)	(-)	Voltage
Connector	Terminal	

HEADLAMP (LO) CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

RH	E332	1	Ground	Battery voltage
LH	E328			

Is battery voltage present?

- YES >> GO TO 4.
NO >> GO TO 3.

3. CHECK HEADLAMP (LO) CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector E217.
3. Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector E332 or E328.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E217	75	E332	1
		76	E328	

Does continuity exist?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).
NO >> Repair the harness or connector.

4. CHECK FRONT COMBINATION LAMP (LO) GROUND CIRCUIT

Check continuity between the front combination lamp harness connector E332 or E328 terminal 2 and ground.

Connector	Terminal	—	Continuity
RH	E332	2	Yes
	E328		

Does continuity exist?

- YES >> Perform xenon headlamp diagnosis. Refer to [EXL-130, "Diagnosis Procedure"](#).
NO >> Repair the harness or connector.

A

B

C

D

E

F

G

H

J

K

EXL

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

XENON HEADLAMP

Description

INFOID:0000000011134662

OPERATION

Refer to [EXL-130, "Description"](#).

PRECAUTIONS FOR TROUBLE DIAGNOSIS

- Installation or removal of the connector must be done with the lighting switch OFF.
- When the lamp is illuminated (when the lighting switch is ON), do not touch the harness, HID control unit, inside of the lamp or the lamp metal parts.
- To check illumination, temporarily install lamp in the vehicle. Be sure to connect power at the vehicle-side connector.
- If the malfunction can be traced directly to the electrical system, first check for items such as blown fuses and fusible links, broken wires or loose connectors, pulled-out terminals and improper connections.
- Do not work with wet hands.
- Using a tester for HID control unit circuit trouble diagnosis is prohibited.
- Disassembling the HID control unit or harnesses (bulb socket harness, ballast harness) is prohibited.
- Immediately after illumination, the light intensity and color will fluctuate this is normal.
- When the bulb has reached the end of its lifetime, the brightness may drop significantly, it may flash repeatedly or the light may turn a reddish color.

Diagnosis Procedure

INFOID:0000000011134663

1.CHECK XENON BULB

Install a known good bulb to the applicable headlamp. Check that the headlamp operates.

Is the inspection result normal?

- YES >> Replace the xenon bulb.
NO >> GO TO 2.

2.CHECK HID CONTROL UNIT

Install a known good HID control unit to the applicable headlamp. Check that the headlamp operates.

Is the inspection result normal?

- YES >> Replace HID control unit.
NO >> Inspection End.

DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

DAYTIME RUNNING LIGHT RELAY CIRCUIT

Description

INFOID:0000000011134664

The BCM sends a daytime running light request to the IPDM E/R via the CAN communication lines. The power flows through fuse 43 located in IPDM E/R to the daytime running light relay coil. When the IPDM E/R operates the daytime running light relay, power is sent to the daytime running lamps.

Diagnosis Procedure

INFOID:0000000011134665

Regarding Wiring Diagram information, refer to [EXL-31, "Wiring Diagram"](#).

1. CHECK DAYTIME RUNNING LIGHT RELAY VOLTAGE SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect the daytime running light relay harness connector E4.
3. Turn the ignition switch ON.
4. Check the voltage between the following daytime running light relay harness connector E4 terminals and ground.

Connector	(+)	(-)	Voltage
E4	Terminal	Ground	Battery voltage
	2		
	5		
	7		

Is the inspection results normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK DAYTIME RUNNING LIGHT RELAY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R harness connector E121.
3. Check continuity between the IPDM E/R harness connector E121 and the daytime running light relay harness connector E4.

Daytime running light relay	IPDM E/R			Continuity
Connector	Terminal	Connector	Terminal	
E4	2	E121	14	Yes
	5			
	7			

4. Check continuity between the IPDM E/R harness connector E121 and ground.

Connector	Terminal	(-)	Continuity
E121	14	Ground	No

Is the inspection results normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).
NO >> Repair or replace the harnesses or connectors.

3. CHECK DAYTIME RUNNING LAMP RELAY COIL CIRCUIT

1. Check continuity between the IPDM E/R harness connector E218 and daytime running light relay harness connector E4.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL

DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

IPDM E/R		Daytime running light relay		Continuity
Connector	Terminal	Connector	Terminal	
E218	85	E4	1	Yes

2. Check continuity between the IPDM E/R harness connector E218 and ground.

Connector	Terminal	Ground	Continuity
E218	85		No

Does continuity exist?

- YES >> GO TO 4.
NO >> Repair or replace the harnesses or connectors.

4. CHECK DAYTIME RUNNING LIGHT RELAY

Check the daytime running light relay. Refer to [EXL-132, "Component Inspection"](#).

Is the inspection results normal?

- YES >> GO TO 5.
NO >> Replace relay.

5. CHECK DAYTIME RUNNING LAMP CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect the front fog lamp harness connector E303 or E304 in question.
3. Check continuity between the daytime running light relay harness connector E4 and the front fog lamp harness connector E303 or E304.

Front fog lamp		Daytime running light relay		Continuity
Connector	Terminal	Connector	Terminal	
LH E303	3	E4	6	Yes
RH E304			3	

Is the inspection results normal?

- YES >> GO TO 6.
NO >> Repair or replace the harnesses or connectors.

6. CHECK DAYTIME RUNNING LAMP GOUND CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect front fog lamp harness connector E303 or E304 in question.
3. Check continuity between the front fog lamp harness connector E303 or E304 terminal 4 and ground.

Connector	Terminal	(-)	Continuity
LH E303	4	Ground	Yes
RH E304			

Does continuity exist?

- YES >> Inspection End.
NO >> Repair or replace the harnesses or connectors.

Component Inspection

INFOID:000000011134666

1. CHECK DAYTIME RUNNING LIGHT RELAY

1. Turn ignition switch OFF.
2. Remove daytime running light relay.
3. Check the continuity between daytime running light relay terminals 3 and 5 and 6 and 7 when voltage is supplied between terminals 1 and 2.

DAYTIME RUNNING LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

Terminals	Voltage	Continuity
3 and 5	ON	Yes
	OFF	No
6 and 7	ON	Yes
	OFF	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace daytime running light relay.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

HEADLAMP AIMING SYSTEM (MANUAL)

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

HEADLAMP AIMING SYSTEM (MANUAL)

Description

INFOID:0000000011134667

The manual headlamp aiming system uses a headlamp aiming switch to adjust the axis of the headlamp aiming motor. The headlamp aiming switch has four settings, each with a different resistance value. The headlamp aiming motor adjusts to the proper axis based off the position of the headlamp aiming switch.

Component Inspection

INFOID:0000000011134668

1. CHECK HEADLAMP AIMING SWITCH

1. Disconnect headlamp aiming switch.
2. Check resistance between terminal 1 and terminal 2.

Headlamp aiming switch		Condition	Resistance (Approx.)
Terminal		Switch position	
1	2	0	160 Ω
		1	402 Ω
		2	620 Ω
		3	1100 Ω

Is the inspection result normal?

YES >> Headlamp aiming switch is normal.

NO >> Replace the headlamp aiming switch. Refer to [EXL-170, "Removal and Installation"](#).

Diagnosis Procedure

INFOID:0000000011134669

Regarding Wiring Diagram information, refer to [EXL-111, "Wiring Diagram"](#).

1. CHECK HEADLAMP AIMING MOTOR FUSES

1. Turn the ignition switch OFF.
2. Check that the fuse is not open.

Unit	Location	Fuse No.	Capacity
Headlamp aiming motor	IPDM E/R	48	10A

Is the inspection result normal?

YES >> GO TO 2

NO >> Replace the fuse after repairing the affected circuit.

2. CHECK HEADLAMP AIMING MOTOR POWER SUPPLY CIRCUIT FOR OPEN OR SHORT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector E218, headlamp aiming motor LH harness connector E330 or headlamp aiming motor RH harness connector E334.
3. Check continuity between IPDM E/R harness connector E218 and headlamp aiming motor LH harness connector E330 or headlamp aiming motor RH harness connector E334.

IPDM E/R		Headlamp aiming motor			Continuity
Connector	Terminal	Connector		Terminal	
E218	92	LH	E330	14	Yes
	84	RH	E334		

4. Check continuity between the IPDM E/R harness connector and ground.

HEADLAMP AIMING SYSTEM (MANUAL)

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

IPDM E/R		—	Continuity
Connector	Terminal		
E218	92	Ground	No
	84		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace the harness or connector.

3.CHECK HEADLAMP AIMING SWITCH SIGNAL FOR OPEN OR SHORT CIRCUIT

1. Disconnect headlamp aiming switch harness connector M121.
2. Check continuity between the headlamp aiming switch harness connector M121 and headlamp aiming motor LH harness connector E330 or headlamp aiming motor RH harness connector E334.

Headlamp aiming switch		Headlamp aiming motor			Continuity
Connector	Terminal	Connector		Terminal	
M121	1	LH	E330	13	Yes
		RH	E334		

3. Check continuity between the headlamp aiming switch harness connector M121 and ground.

Headlamp aiming switch		(-)	Continuity
Connector	Terminal		
M121	1	Ground	No

Is the inspection result normal?

YES >> GO TO 4

NO >> Repair or replace the harness or connector.

4.CHECK HEADLAMP AIMING MOTOR GROUND CIRCUIT

Check continuity between headlamp aiming motor LH harness connector E330 or headlamp aiming motor RH harness connector E334 and ground.

Headlamp aiming motor		(-)	Continuity
Connector	Terminal		
LH	E330	15	Ground
	E334		

Is the inspection result normal?

YES >> Inspect the headlamp aiming motors.

NO >> Repair or replace the harness or connector.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

FRONT FOG LAMP CIRCUIT

Description

INFOID:0000000011134670

The IPDM E/R (intelligent power distribution module engine room) controls the front fog lamp relay based on inputs from the BCM via the CAN communication lines. When the front fog lamp relay is energized, power flows from the front fog lamp relay in the IPDM E/R to the front fog lamps.

Component Function Check

INFOID:0000000011134671

1.CHECK FRONT FOG LAMP OPERATION

WITHOUT CONSULT

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the front fog lamp is turned ON.

WITH CONSULT

1. Select EXTERNAL LAMPS of IPDM E/R active test item.
2. While operating the test items, Check that the front fog lamp is turned ON.

Fog : Front fog lamp ON

Off : Front fog lamp OFF

Is the front fog lamp turned ON?

YES >> Front fog lamp circuit is normal.

NO >> Refer to [EXL-136, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011134672

Regarding Wiring Diagram information, refer to [EXL-53, "Wiring Diagram"](#).

1.CHECK FRONT FOG LAMP FUSE

1. Turn the ignition switch OFF.
2. Check if the following fuse is blown.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	42	15A

Is the fuse open?

YES >> Replace the blow fuse after repairing the affected circuit.

NO >> GO TO 2

2.CHECK FRONT FOG LAMP OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the front fog lamp harness connector E305 or E306.
3. Turn the ignition switch ON.
4. Turn the front fog lamps ON.
5. Check the voltage between the fog lamp harness connector E305 or E306 terminal 1 and ground.

(+) Connector		Terminal	(-)	Voltage (Approx.)
LH				
LH	E305	1	Ground	Battery voltage
RH	E306			

Is battery voltage present?

YES >> GO TO 4

NO >> GO TO 3

FRONT FOG LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK FRONT FOG LAMP OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R harness connector E217.
3. Check continuity between the IPDM E/R harness connector E217 and the front fog lamp harness connector E305 or E306.

IPDM E/R		Front fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	E217	79	E305	1
RH		78	E306	

Does continuity exist?

YES >> Replace IDPM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> Repair or replace the harnesses or connectors.

4. CHECK FRONT FOG LAMP GROUND CIRCUIT

1. Disconnect the front fog lamp connector.
2. Check continuity between the front fog lamp harness connector E305 or E306 terminal 2 and ground.

Connector	Terminal	—	Continuity
LH	E305	2	Yes
RH	E306		

Does continuity exist?

YES >> Inspect the fog lamp bulb.

NO >> Repair or replace the harnesses or connectors.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

PARKING LAMP CIRCUIT

Description

INFOID:0000000011134673

The IPDM E/R (intelligent power distribution module engine room) controls the tail lamp relay based on inputs from the BCM via the CAN communication lines. When the tail lamp relay is energized, power flows through fuse 51 and 52, located in the IPDM E/R. Power then flows to the front and rear combination lamps, license plate lamps.

Component Function Check

INFOID:0000000011134674

1. CHECK PARKING LAMP OPERATION

WITHOUT CONSULT

1. Activate IPDM E/R auto active test. Refer to [PCS-8, "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

WITH CONSULT

1. Select EXTERNAL LAMPS of IPDM E/R active test item.
2. While operating the test items, check that the parking lamp is turned ON.

TAIL : Parking lamp ON

Off : Parking lamp OFF

Is the parking lamp turned ON?

YES >> Parking lamp circuit is normal.

NO >> Refer to [EXL-141, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011134675

Regarding Wiring Diagram information, refer to [EXL-70, "Wiring Diagram"](#).

1. CHECK PARKING LAMP FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not blown.

Unit	Location	Fuse No.	Capacity
Parking lamps	IPDM E/R	51	10A
		52	10A

Is the fuse blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK TAIL LAMP RELAY OUTPUT (VOLTAGE)

1. Disconnect the front combination lamp connectors, front side marker lamp connectors, rear combination lamp connectors and license plate lamp connectors.
2. Turn the ignition switch ON.
3. Turn the parking lamps ON.
4. With the parking lamps ON, check voltage between the front combination lamp connector and ground.

(+) Connector		Terminal	(-)	Voltage (Approx.)
LH	E235		7	Ground
RH	E240			Battery voltage

PARKING LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

- With the parking lamps ON, check voltage between the front side marker lamp connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Connector				
LH	E329	9	Ground	Battery voltage
RH	E333			

- With the parking lamps ON, check voltage between the rear combination lamp connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Connector				
LH	B406	2	Ground	Battery voltage
RH	B407			

- With the parking lamps ON, check voltage between the license plate lamp connector and ground

(+)		Terminal	(-)	Voltage (Approx.)
Connector				
LH	D561	2	Ground	Battery voltage
RH	D562			

Are the inspection results normal?

YES >> GO TO 4

NO >> GO TO 3

3.CHECK PARKING LAMP CIRCUIT (OPEN)

- Turn the ignition switch OFF.
- Disconnect IPDM E/R connector.
- Check continuity between the IPDM E/R harness connector and the front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	E218	90	E235	Yes
RH			E240	

- Check continuity between the IPDM E/R harness connector and the front side marker lamp harness connector.

IPDM E/R		Front side marker lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	E218	90	E329	Yes
RH			E333	

- Check continuity between the IPDM E/R harness connector and the rear combination lamp harness connector.

IPDM E/R		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	E121	10	B406	Yes
RH		9	B407	

PARKING LAMP CIRCUIT

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

- Check continuity between the IPDM E/R harness connector and license plate lamp connector.

IPDM E/R		License plate lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	E121	10	D561	Yes
RH			D562	

Are the inspection results normal?

YES >> Replace IPDM E/R. Refer to PCS-32, "Removal and Installation".

NO >> Repair or replace the harness or connector.

4. CHECK PARKING LAMP GROUND CIRCUITS

- Check continuity between the front combination lamp harness connector and ground.

(+) Connector		Terminal	(-)	Continuity
LH	E235		8	
RH	E240		Ground	Yes

- Check continuity between the front side marker lamp harness connector and ground.

(+) Connector		Terminal	(-)	Continuity
LH	E329		10	
RH	E333		Ground	Yes

- Check continuity between the rear combination lamp harness connector and ground.

(+) Connector		Terminal	(-)	Continuity
LH	B406		3	
RH	B407		Ground	Yes

- Check continuity between the license plate lamp harness connector and ground.

(+) Connector		Terminal	(-)	Continuity
LH	D561		1	
RH	D562		Ground	Yes

Are the inspection results normal?

YES >> Inspect the parking lamp bulb.

NO >> Repair or replace the harness or connector.

< DTC/CIRCUIT DIAGNOSIS >

TURN SIGNAL LAMP CIRCUIT

Description

INFOID:0000000011134676

The BCM monitors inputs from the combination switch (lighting and turn signal switch) to determine when to activate the turn signals. The BCM outputs voltage direction to the left and right turn signals during turn signal operation or both during hazard warning operation. The BCM sends a turn signal indicator request to the combination meter via the CAN communication lines.

The BCM performs the fast flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

NOTE:

Turn signal lamp blinks at normal speed when using the hazard warning lamp.

Component Function Check

INFOID:0000000011134677

1.CHECK TURN SIGNAL LAMP

CONSULT

1. Select FLASHER of BCM (FLASHER) active test item.
2. While operating the test items, check that the turn signal lamp blinks.

- | | |
|------------|-----------------------------|
| LH | : Turn signal lamps (LH) ON |
| RH | : Turn signal lamps (RH) ON |
| Off | : Turn signal lamps OFF |

Is the inspection result normal?

- YES >> Turn signal lamp circuit is normal.
 NO >> Refer to [EXL-141, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011134678

Regarding Wiring Diagram information, refer to [EXL-61, "Wiring Diagram"](#).

1.CHECK TURN SIGNAL LAMP BULB

Check the applicable lamp bulb to be sure the proper bulb standard is in use and the bulb is not open.

Is the bulb OK?

- YES >> GO TO 2.
 NO >> Replace the bulb.

2.CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE


1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp harness connector or the rear combination lamp harness connector in question.
3. Turn the ignition switch ON.
4. Operate the turn signal switch.
5. While the turn signal is operating, check the voltage between the front combination lamp harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		

TURN SIGNAL LAMP CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

RH	E239			
LH	E234	5	Ground	 PKID0926E

6. While the turn signal is operating, check the voltage between the rear combination lamp harness connector and ground.

(+) Connector		(-) Terminal	Voltage (Approx.)
RH	B409		
LH	B408	4	Ground


 PKID0926E

Is voltage reading as specified?

YES >> GO TO 5.
NO >> GO TO 3.

3.CHECK TURN SIGNAL LAMP CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector M20 or M80.
3. Check continuity between the BCM harness connector M80 and the front combination lamp harness connector.

BCM		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	M80	117	E234	Yes
RH		105	E239	

4. Check continuity between the BCM harness connector M20 and the rear combination lamp harness connector.

BCM		Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
LH	M20	103	B408	Yes
RH		92	B409	

Is the inspection results normal?

YES >> GO TO 4.
NO >> Repair or replace the harness or connectors.

4.CHECK TURN SIGNAL LAMP SHORT CIRCUIT

1. Check continuity between the BCM harness connector M80 and ground.

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[XENON TYPE]

A

BCM			Ground	Continuity
Connector		Terminal		
LH	M80	117		
RH		105		

B

2. Check continuity between the BCM harness connector M20 and ground.

C

BCM			Ground	Continuity
Connector		Terminal		
LH	M20	103		
RH		92		

D

Are the inspection results normal?

E

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

F

NO >> Repair or replace the harness or connectors.

G

5.CHECK TURN SIGNAL LAMP GROUND CIRCUIT

H

1. Check continuity between the front combination lamp harness connector or the rear combination lamp harness connector in question and ground.

I

Front combination lamp			(-)	Continuity
Connector		Terminal		
LH	E234	6		
RH		E239		

J

2. Check continuity between the rear combination lamp harness connector and ground.

K

Rear combination lamp			(-)	Continuity
Connector		Terminal		
LH	B408	5		
RH		B409		

EXL

Are continuity results as specified?

M

YES >> Replace the malfunctioning lamp.

N

NO >> Repair or replace the harness or connectors.

O

P

< DTC/CIRCUIT DIAGNOSIS >

OPTICAL SENSOR**Description**

INFOID:0000000011134679

The optical sensor measures ambient light and transmits the optical sensor signal to the BCM.

Component Function Check

INFOID:0000000011134680

1.CHECK OPTICAL SENSOR SIGNAL TO BCM**CONSULT**

1. Turn the ignition switch ON.
2. Select OPTI SEN (DTCT) of BCM (HEAD LAMP) DATA MONITOR item.
3. Turn the lighting switch to AUTO.

Monitor item	Condition	Voltage (Approx.)
OPTI SEN (DTCT)	When outside of vehicle is bright	3.1 V or more * *
	When outside of vehicle is dark	0.6 V or less

*:Outside light varies. The value may be less than the standard value if brightness is weak.

Is the inspection result normal?

- YES >> Optical sensor is normal.
 NO >> Refer to [EXL-144, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011134681

Regarding Wiring Diagram information, refer to [EXL-43, "Wiring Diagram"](#).

1.CHECK OPTICAL SENSOR POWER SUPPLY INPUT

1. Turn the ignition switch OFF.
2. Disconnect the optical sensor harness connector M15.
3. Turn the ignition switch ON.
4. Turn the lighting switch to AUTO.
5. Check the voltage between the optical sensor harness connector M15 and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		
M15	1	Ground	5 V

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 3.

2.CHECK OPTICAL SENSOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check continuity between the optical sensor harness connector M15 and ground.

(+)		(-)	Continuity
Connector	Terminal		
M15	3	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 6
 NO >> GO TO 5

3.CHECK OPTICAL SENSOR POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.

OPTICAL SENSOR

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect the BCM harness connector M18.
3. Check continuity between optical sensor harness connector M15 and BCM harness connector M18.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M15	1	M18	3	Yes

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the harness or connectors.

4.CHECK OPTICAL SENSOR POWER SUPPLY FOR SHORT CIRCUIT

Check continuity between optical sensor harness connector M15 terminal 1 and ground.

(+) Connector		(-) Terminal	Continuity
Connector	Terminal	Ground	
M15	1	Ground	No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
NO >> Repair or replace harness or connector.

5.CHECK OPTICAL SENSOR GROUND FOR OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the BCM harness connector M18.
3. Check continuity between optical sensor harness connector M15 terminal 3 and BCM harness connector M18 terminal 17.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M15	3	M18	17	Yes

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
NO >> Repair or replace harness or connector.

6.CHECK OPTICAL SENSOR SIGNAL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M15	2	M18	4	Yes

4. Check continuity between optical sensor harness connector and ground.

Connector	Terminal	(-)	Continuity
M15	2	Ground	No

Is the inspection result normal?

- YES >> Replace the optical sensor. Refer to [EXL-167, "Removal and Installation"](#).
NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

< DTC/CIRCUIT DIAGNOSIS >

HAZARD SWITCH**Component Function Check**

INFOID:0000000011134682

1.CHECK HAZARD SWITCH SIGNAL BY CONSULT**(B)CONSULT DATA MONITOR**

1. Turn ignition switch ON.
2. Select HAZARD SW of BCM (FLASHER) DATA MONITOR item.
3. While operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the inspection result normal?


- YES >> Hazard switch circuit is normal.
 NO >> Refer to [EXL-146, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011134683

Regarding Wiring Diagram information, refer to [EXL-61, "Wiring Diagram"](#).**1.CHECK HAZARD SWITCH SIGNAL INPUT**

1. Turn ignition switch OFF.
2. Disconnect A/C and AV switch assembly harness connector M98.
3. Turn ignition switch ON.
4. Check voltage between A/C and AV switch assembly harness connector M98 and ground.

(+) A/C and AV switch assembly (hazard switch)		(-)	Voltage (Approx.)
Connector	Terminal		
M98	16	Ground	 JPMIA0154GB

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 2.

2.CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector M18.
3. Check continuity between A/C and AV switch assembly harness connector and BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M98	16	M18	36	Yes

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace the harness or connectors.

HAZARD SWITCH

[XENON TYPE]

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between A/C and AV switch assembly harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M98	16		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace the harness or connectors.

4.CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between A/C and AV switch assembly harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M98	1		Yes

Is the inspection result normal?

YES >> Replace A/C and AV switch assembly. Refer to [EXL-169, "Removal and Installation"](#).

NO >> Repair or replace the harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

SYMPTOM DIAGNOSIS**EXTERIOR LIGHTING SYSTEM SYMPTOMS****Symptom Table**

INFOID:000000011134684

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp does not switch to the high beam.	One side	<ul style="list-style-type: none"> Fuse Harness between IPDM E/R and the front combination lamp Front combination lamp (High beam relay) IPDM E/R Harness between the front combination lamp and ground 	Headlamp (HI) circuit Refer to EXL-126 .
	Both sides	—	Symptom diagnosis BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM Refer to EXL-152 .
High beam indicator lamp is not turned ON (Headlamp switched to the high beam).		<ul style="list-style-type: none"> BCM Combination meter 	<ul style="list-style-type: none"> Combination meter Data monitor HI-BEAM IND BCM (HEAD LAMP) Active test "HEADLAMP"
Headlamp does not switch to the low beam.	One side	Front combination lamp (High beam relay)	—
	Both sides	<ul style="list-style-type: none"> Combination switch (lighting and turn signal switch) Harness between the combination switch and BCM BCM 	Combination switch (lighting and turn signal switch) Refer to BCS-78 .
		High beam request signal	IPDM E/R Data monitorHL HI REQ
		IPDM E/R	—
Headlamp does not turn ON.	One side	<ul style="list-style-type: none"> Fuse Xenon bulb Harness between IPDM E/R and the front combination lamp Front combination lamp (xenon headlamp) IPDM E/R Harness between the front combination lamp and ground 	Headlamp (LO) circuit Refer to EXL-128 .
	Both sides	—	Symptom diagnosis BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON Refer to EXL-153 .
Headlamp does not turn OFF.	When the ignition switch is turned ON	<ul style="list-style-type: none"> BCM Combination switch (lighting and turn signal switch) 	Combination switch (lighting and turn signal switch) Refer to BCS-78 .
	The ignition switch is turned OFF (After activating the battery saver).	IPDM E/R	—

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item
Headlamp is not turned ON/OFF with lighting switch AUTO.	<ul style="list-style-type: none"> Combination switch (lighting and turn signal switch) Harness between combination switch and BCM BCM 	Combination switch Refer to BCS-78 .
	<ul style="list-style-type: none"> Optical sensor Harness between optical sensor and BCM BCM 	Optical sensor Refer to EXL-144 .
Daytime running light system does not activate. (if equipped)	<ul style="list-style-type: none"> Fuse Harness between IPDM E/R and the daytime running light relay Harness between daytime running light relay and the front fog lamp Harness between the front fog lamp and ground Daytime running light bulb IPDM E/R Daytime running light relay BCM 	Symptom diagnosis Daytime running light system inoperative. Refer to EXL-156 .
Headlamp aiming motor does not operate.	One side	<ul style="list-style-type: none"> Fuse Harness between IPDM E/R and headlamp aiming motor Headlamp aiming motor IPDM E/R
	Both sides	<ul style="list-style-type: none"> Headlamp aiming switch Harness between aiming switch and headlamp aiming motor IPDM E/R
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> Front fog lamp bulb Harness between IPDM E/R and front fog lamp Front fog lamp IPDM E/R
	Both sides	Symptom diagnosis BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON Refer to EXL-136 .
Parking lamp is not turned ON.	One side	<ul style="list-style-type: none"> Parking lamp bulb Harness between IPDM E/R and front/rear combination lamp Harness between front/rear combination lamp and ground Front/rear combination lamp IPDM E/R
	Both sides	Symptom diagnosis PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON Refer to EXL-154 .
Turn signal lamp does not blink. (The applicable side performs the high flasher activation).	Indicator lamp is normal.	<ul style="list-style-type: none"> Hazard BCM and each turn signal lamp Turn signal lamp bulb
		Turn signal lamp circuit Refer to EXL-141 .

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

Symptom	Possible cause	Inspection item
Turn signal indicator lamp does not blink.	One side	Combination meter
	Both sides (Always)	<ul style="list-style-type: none"> • Turn signal indicator lamp signal - BCM • Combination meter
	Both sides (Does blink when activating hazard warning lamp with the ignition switch OFF)	<ul style="list-style-type: none"> • Combination meter power supply and ground circuit • Combination meter
• Hazard warning lamp does not activate. • Hazard warning lamp continues activating (Turn signal is normal).	<ul style="list-style-type: none"> • Hazard switch • Harness between the hazard switch and BCM • BCM 	Combination meter Power supply and ground circuit Refer to MWI-76 . Hazard switch Refer to EXL-146 .

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:0000000011134685

XENON HEADLAMP

- Brightness and the color of light may change slightly immediately after turning the headlamp ON until the xenon bulb becomes stable. This is normal.
- Illumination time lag may occur between right and left. This is normal.

AUTO LIGHT SYSTEM

The headlamp may not be turned ON/OFF immediately after passing dark area or bright area (short tunnel, sky bridge, shadowed area etc.) while using the auto light system. This causes for the control difference. This is normal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

Description

INFOID:0000000011134686

The headlamps (both sides) do not switch to high beam when the lighting switch is in the HI or PASS setting.

Diagnosis Procedure

INFOID:0000000011134687

1. COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-7, "COMBINATION SWITCH READING SYSTEM : System Description"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning part.

2. CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select HL HI REQ of IPDM E/R DATA MONITOR item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2nd)	HI or PASS	ON
		Except for HI or PASS	OFF

Is the item status normal?

YES >> GO TO 3

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

3. HEADLAMP (HI) CIRCUIT INSPECTION

Check the headlamp (HI) circuit. Refer to [EXL-126, "Diagnosis Procedure"](#).

Is the headlamp (HI) circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

Description

INFOID:0000000011134688

The headlamps (both sides) do not turn ON in any lighting switch setting.

Diagnosis Procedure

INFOID:0000000011134689

1. CHECK COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH)

Check the combination switch (lighting and turn signal switch). Refer to [BCS-7, "COMBINATION SWITCH READING SYSTEM : System Description"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select HL LO REQ of IPDM E/R DATA MONITOR item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status
HL LO REQ	Lighting switch	2nd
		OFF

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

3. HEADLAMP (LO) CIRCUIT INSPECTION

Check the headlamp (LO) circuit. Refer to [EXL-128, "Diagnosis Procedure"](#).

Is the headlamp (LO) circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

Description

INFOID:000000011134690

The parking, license plate, tail lamps and side marker lamps do not turn ON with the combination switch in any setting.

Diagnosis Procedure

INFOID:000000011134691

1. COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-78, "Symptom Table"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning part.

2. CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

CONSULT DATA MONITOR

1. Select TAIL & CLR REQ of IPDM E/R DATA MONITOR item.

2. While operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
TAIL & CLR REQ	Lighting switch	1st	ON
		OFF	OFF

Is the item status normal?

YES >> GO TO 3

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

3. PARK LAMP CIRCUIT INSPECTION

Check the parking lamp circuit. Refer to [EXL-138, "Diagnosis Procedure"](#).

Is the tail lamp circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[XENON TYPE]

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

Description

INFOID:0000000011134692

The front fog lamps do not turn ON in any setting.

Diagnosis Procedure

INFOID:0000000011134693

1. COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-78, "Symptom Table"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning part.

2. CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

 WITH CONSULT DATA MONITOR

1. Select FR FOG REQ of IPDM E/R DATA MONITOR item.
2. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status	
FR FOG REQ	Front fog lamp switch (Lighting switch 2nd)	ON	ON
		OFF	OFF

Is the monitor item status normal?

YES >> GO TO 3

NO >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

3. FRONT FOG LAMP CIRCUIT INSPECTION

Check the front fog lamp circuit. Refer to [EXL-136, "Diagnosis Procedure"](#).

Is the front fog lamp circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

DAYTIME LIGHT SYSTEM INOPERATIVE**Description**

INFOID:0000000011134694

The daytime running light system is inoperative even though the combination switch (lighting and turn signal switch) and parking brake switch are in the normal setting, also whenever the engine is operating.

Diagnosis Procedure

INFOID:0000000011134695

1.CHECK DAYTIME RUNNING LIGHT OPERATION

1. Perform BCM(HEADLAMP) DAYTIME RUNNING LIGHT active test. Refer to [BCS-17, "HEADLAMP : CONSULT Function \(BCM - HEADLAMP\)"](#).
2. Check that the daytime running lights turn on.

Is the inspection results normal?

- YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).
 NO >> GO TO 2.

2.CHECK DAYTIME RUNNING LIGHT RELAY FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown.

Unit	Fuse No.	Capacity
Daytime running light	43	10 A

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Replace the blown fuse after repairing the affected circuit.

3.CHECK DAYTIME RUNNING LIGHT BULBS

Check the daytime running light bulbs are not open.

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Replace the bulbs.

4.PERFORM DAYTIME RUNNING LIGHT CIRCUIT INSPECTION

Check the daytime running light circuit. Refer to [EXL-131, "Diagnosis Procedure"](#).

Is the inspection results normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).
 NO >> Repair or replace the malfunctioning part.

< PERIODIC MAINTENANCE >

PERIODIC MAINTENANCE

HEADLAMP AIMING ADJUSTMENT

Inspection

INFOID:0000000011134696

PREPARATION BEFORE ADJUSTING

Before performing aiming adjustment, check the following:

- Ensure all tires are inflated to correct pressure.
- Place vehicle and screen on level surface.
- Ensure there is no load in vehicle other than the driver (or equivalent weight placed in driver's position).
- Coolant and engine oil filled to correct level, and fuel tank full.
- Remove cargo and/or luggage to maintain an unloaded vehicle condition.
- Confirm spare tire, jack and tools are properly stowed.
- Carefully wipe off any dirt from headlamp lens.

CAUTION:

Do not use organic solvent (thinner, gasoline etc.)

- Place a driver or equivalent weight of 68.5 kg (150 lb) on the driver seat.
- By hand, bounce the front and rear of the vehicle to settle the suspension and eliminate any static load.
- Place the front tires in the straight ahead position.
- Confirm headlamp aiming switch is set to "0" (zero) position.
- Aim each headlamp individually and ensure other headlamp beam pattern is blocked from screen.

NOTE:

- For headlamp aiming details, refer to regulations in your area.
- By regulation, no means for horizontal aim adjustment is provided from the factory; only vertical aim is adjustable.
- Use adjusting screw to perform aiming adjustment.
- Perform headlamp aiming if:
 - The vehicle front body has been repaired;
 - The front combination lamp has been removed or replaced;
 - Any outfitting has been installed;
 - The vehicle's standard load condition has been substantially increased.

AIMING ADJUSTMENT SCREW

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N


O

P

HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]



AWLIA25202Z

- A. Headlamp RH HI/LO (UP/DOWN)
adjustment screw B. Headlamp LH HI/LO (UP/DOWN) ad- ◀ : Center
justment screw


HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

Aiming Adjustment Procedure

INFOID:000000011134697



AWLIA1960ZZ

- | | | |
|---|---|---|
| 1. Adjustment screen | A. Highest cutoff line height | B. Lowest cutoff line height |
| C. Headlamp bulb center (H-V point) | D. Distance of headlamp aiming screen from vehicle 7.62 m (25 ft) | E. Maximum aim evaluation distance from vertical center on aiming screen 399 mm (3°R) |
| F. Minimum aim evaluation distance from vertical center on aiming screen 133 mm (1°R) | G. Aim evaluation area | H. Horizontal aiming evaluation line |
| V. Vertical aiming evaluation line | Right | |

A (Highest cutoff line height)

-13.3 mm (0.5 in)

0.1° up

B (Lowest cutoff line height)

53.2 mm (2.1 in)

0.4° down

LOW BEAM AND HIGH BEAM

NOTE:

- Basic illuminating area for evaluation and/or adjustment should be within range shown on aiming chart.

- Use adjustment screw to perform aiming adjustment.
 - Ensure fog lamps (if equipped) are turned off.**
- Block the opposite headlamp from projecting a beam pattern onto the adjustment screen, using a suitable object. Aim each headlamp individually.

CAUTION:

Do not cover the lens surface with a tape etc. The lens is made of resin.

- Place the screen on the same level and flat surface as the vehicle.

NOTE:

- Surface should be free of any debris that would cause a difference between the headlamp center and the adjustment screen.

- Face the front of the vehicle to the screen and measure distance between the headlamp center and the screen surface.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

Distance between the headlamp center and the screen (D) : 7.62 m (25 ft)

5. Start the engine. Turn the headlamp on.
6. Determine the preferred vertical aim range dimensions, using the aiming chart.
7. Measure the projected beam within the aim evaluation segment on the screen.
8. Adjust the beam pattern of each headlamp until the aim evaluation segment (the area relative to both the highest and lowest cutoff line height) is positioned within the vertical aim range dimensions shown on the aiming chart.

FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[XENON TYPE]

FRONT FOG LAMP AIMING ADJUSTMENT

Aiming Adjustment

INFOID:0000000011134698


NOTE:

Check the following conditions before performing the aiming adjustment.

- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.
- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.

1. Set the distance between the screen and the center of the fog lamp lens as shown.


- (1) Aiming screen or a matte white surface
- (2) 7.62 m (25 ft)
- (3) Floor to center of fog lamp lens
- (4) Floor



ALLIA10582Z


2. Turn front fog lamps ON.

3. Access adjustment screw from underneath front bumper. Use a suitable tool to adjust. Turn screw clockwise to raise pattern and counterclockwise to lower pattern. Adjust front fog lamps using adjusting screw so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown.



LKIA0572E

- (1) Vertical center line of left fog lamp.
- (2) Lamp center above ground.
- (3) 100 mm (4 in) (0.76 deg) below lamp center above ground.
- (4) Left fog lamp high intensity area.
- (5) Vehicle center axis.
- (6) Vertical center line of right fog lamp.
- (7) Right fog lamp high intensity area.




AWLIA21992Z

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION**FRONT COMBINATION LAMP****Exploded View**

INFOID:0000000011134699



1. Front combination lamp

A. Bolt

Removal and Installation

INFOID:0000000011134700

FRONT COMBINATION LAMP**Removal****CAUTION:****Disconnect the battery negative terminal or remove the fuse.**

1. Remove front bumper fascia. Refer to [EXT-17, "Removal and Installation"](#).
2. Release the clips and pawls using a suitable tool and remove hood ledge finisher.
3. Remove front combination lamp bolts.
4. Pull front combination lamp forward.
5. Disconnect the harness connectors from the front combination lamp and remove.

Installation

Installation is in the reverse order of removal.

NOTE:After installation, perform headlamp aiming adjustment. Refer to [EXL-159, "Aiming Adjustment Procedure"](#).**XENON BULB****Removal****WARNING:**

To prevent burns, never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF.

CAUTION:


- After installing the bulb, install the plastic cover and the bulb socket securely for watertightness.
- Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.
- Disconnect the battery negative terminal or remove the fuse.

FRONT COMBINATION LAMP

[XENON TYPE]

< REMOVAL AND INSTALLATION >

1. Release the clips and pawls using a suitable tool and remove hood ledge finisher.
2. Remove the washer tank inlet tube clip (A) from the coolant reservoir and pull the washer tank inlet tube (1) from the washer tank (RH only).




ALLIA1096ZZ

3. Rotate plastic cover counterclockwise and unlock from the front combination lamp.
4. Rotate xenon bulb socket counterclockwise and unlock from the front combination lamp.
5. Remove retaining spring and then remove xenon bulb from the front combination lamp.

CAUTION:

Do not break the xenon bulb ceramic tube when replacing the bulb.



JPLIA0919ZZ

Installation

Installation is in the reverse order of removal.


NOTE:

After installation, perform headlamp aiming adjustment. Refer to [EXL-159, "Aiming Adjustment Procedure".](#)

PARKING LAMP BULB

Removal

1. Release the clips and pawls using a suitable tool and remove hood ledge finisher.
2. Remove the washer tank inlet tube clip (A) from the coolant reservoir and pull the washer tank inlet tube (1) from the washer tank (RH only).



ALLIA1096ZZ

3. Rotate parking lamp socket counterclockwise and unlock from the front combination lamp.
4. Remove parking lamp bulb from bulb socket.

Installation

Installation is in the reverse order of removal.

FRONT TURN SIGNAL LAMP BULB

Removal

1. Release the clips and pawls using a suitable tool and remove hood ledge finisher.
2. Rotate front turn signal lamp socket counterclockwise and unlock from the front combination lamp.
3. Remove front turn signal lamp bulb from bulb socket.

Installation

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]

Installation is in the reverse order of removal.

FRONT SIDE MARKER LAMP BULB

Removal

1. Release the clips and pawls using a suitable tool and remove hood ledge finisher.
2. Rotate the front side marker lamp socket counterclockwise and unlock from the front combination lamp.
3. Remove the front side marker lamp bulb from the bulb socket.

Installation

Installation is in the reverse order of removal.

FRONT FOG LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

FRONT FOG LAMP

Exploded View

INFOID:0000000011134701



1. Front bumper fascia

2. Front fog lamp

A. Bolt

AWLIA2185Z2

Removal and Installation

INFOID:0000000011134702

FRONT FOG LAMP

Removal

1. Remove bumper fascia. Refer to [EXT-17, "Removal and Installation"](#).
2. Disconnect the harness connector from the front fog lamp and daytime running lamp (if equipped).
3. Remove front fog lamp bolts.
4. Remove front fog lamp.

Installation

Installation in the reverse order of removal.

NOTE:

After installation, perform fog lamp aiming adjustment. Refer to [EXL-161, "Aiming Adjustment"](#).

FRONT FOG LAMP BULB

EXL

Removal

WARNING:

Do not touch bulb by hand while it is lit or right after being turned OFF. Burning may result.

CAUTION:

- Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.


1. Partially remove front fender protector. Refer to [EXT-28, "FENDER PROTECTOR : Removal and Installation"](#).

FRONT FOG LAMP

[XENON TYPE]

< REMOVAL AND INSTALLATION >

2. Disconnect the harness connector from the front fog lamp (A).
3. Rotate bulb (1) counterclockwise and remove.



Installation

Installation is in the reverse order of removal.

DAYTIME LAMP BULB (CANADA ONLY)

Removal


WARNING:

Do not touch bulb by hand while it is lit or right after being turned OFF. Burning may result.

CAUTION:

- **Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.**
- **Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

1. Partially remove front fender protector. Refer to [EXT-28, "FENDER PROTECTOR : Removal and Installation"](#).
2. Disconnect the harness connector from the front fog lamp (A).
3. Rotate bulb (1) counterclockwise and remove.



Installation

Installation is in the reverse order of removal.

OPTICAL SENSOR


< REMOVAL AND INSTALLATION >

[XENON TYPE]

OPTICAL SENSOR

Exploded View

INFOID:0000000011134703



1. Optical sensor
2. Instrument panel tweeter grille (RH)
3. Optical sensor harness connector
4. Instrument panel tweeter (RH)
5. Instrument panel

Removal and Installation

INFOID:0000000011134704

REMOVAL

1. Release the instrument panel tweeter grille (RH) using a suitable tool.
2. Insert a suitable tool between the optical sensor and the instrument panel tweeter grille (RH). Release the optical sensor and lift upward.
3. Disconnect the harness connector from the optical sensor and remove.

INSTALLATION

Installation is in the reverse order of removal.

EXL

M

N

O

P

LIGHTING & TURN SIGNAL SWITCH


< REMOVAL AND INSTALLATION >

[XENON TYPE]

LIGHTING & TURN SIGNAL SWITCH

Exploded View

INFOID:0000000011134705



1. Combination switch

2. Combination switch harness connector

◀ Front

Removal and Installation

INFOID:0000000011134706

REMOVAL

1. Remove the steering wheel. Refer to [ST-47, "Removal and Installation"](#).
2. Remove the steering column covers. Refer to [IP-17, "Removal and Installation"](#).
3. Remove the combination switch screws.
4. Disconnect the harness connector from the combination switch.
5. Remove the combination switch.

INSTALLATION

Installation is in the reverse order of removal.

< REMOVAL AND INSTALLATION >

HAZARD SWITCH

Removal and Installation

INFOID:0000000011134707

The hazard switch is integrated in the multifunction switch. Refer to [AV-137, "Removal and Installation - A/C and AV Switch Assembly"](#) (BASE AUDIO), [AV-303, "Removal and Installation - A/C and AV Switch Assembly"](#) (BOSE AUDIO W/O NAVIGATION), [AV-586, "Removal and Installation - A/C and AV Switch Assembly"](#) (BOSE AUDIO WITH NAVIGATION W/O SURROUND), [AV-884, "Removal and Installation - A/C and AV Switch Assembly"](#) (BOSE AUDIO WITH NAVIGATION WITH SURROUND) or [AV-1057, "Removal and Installation - A/C and AV Switch Assembly"](#) (TELEMATICS SYSTEM).

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

HEADLAMP AIMING SWITCH


< REMOVAL AND INSTALLATION >

[XENON TYPE]

HEADLAMP AIMING SWITCH

Exploded View

INFOID:0000000011134708



1. Instrument lower panel LH

2. Headlamp aiming switch

 Pawl

INFOID:0000000011134709

Removal and Installation

REMOVAL

1. Remove instrument lower panel LH. Refer to [IP-25, "Removal and Installation"](#).
2. While pressing pawls, push the headlamp aiming switch to remove.

INSTALLATION

Installation is in the reverse order of removal.

REAR COMBINATION LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

REAR COMBINATION LAMP

Exploded View

INFOID:0000000011134710



1. Rear combination lamp

△ Clip

2. Rear combination lamp bolt cover

A. Bolt

Removal and Installation

INFOID:0000000011134711

REAR COMBINATION LAMP

Removal

1. Release metal clip and pawls using a suitable tool and remove rear combination lamp bolt cover.
2. Remove rear combination lamp bolts.
3. Pull rear combination lamp rearward.
4. Disconnect the harness connector from the rear combination lamp and remove rear combination lamp.

Installation

Installation is in the reverse order of removal.

REAR TURN SIGNAL LAMP BULB

EXL

WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

Removal

1. Remove rear combination lamp. Refer to [EXL-171, "Removal and Installation"](#)
2. Rotate the rear turn signal lamp socket counterclockwise and remove.
3. Remove the bulb from rear turn signal lamp socket.

Installation

Installation is in the reverse order of removal.

CAUTION:

After installing, be sure to install the bulb sockets securely to ensure watertightness.

HIGH-MOUNTED STOP LAMP

Removal and Installation

INFOID:0000000011134712

REMOVAL

1. Remove rear spoiler. Refer to [EXT-42, "Removal and Installation"](#).

INSTALLATION

Installation is in the reverse order of removal.

HIGH-MOUNTED STOP LAMP BULB

The high-mounted stop lamp bulb is LED and is serviced as part of the high-mounted stop lamp. Refer to [EXL-172, "Removal and Installation"](#)

BACK-UP LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

BACK-UP LAMP

Exploded View

INFOID:0000000011134713



1. Back-up lamp

A. Nut

Stud

Removal and Installation

INFOID:0000000011134714

BACK-UP LAMP

Removal

1. Remove back door lower finisher. Refer to [INT-35, "BACK DOOR LOWER FINISHER : Removal and Installation"](#).
2. Disconnect the harness connector from the back-up lamp.
3. Remove back-up lamp nuts, and then remove back-up lamp.

Installation

Installation is in the reverse order of removal.

BACK-UP LAMP BULB

WARNING:

Do not touch bulb by hand while it is lit or right after being turned OFF. Burning may result.

CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.

EXL

Removal

1. Release pawls using a suitable tool and remove back door trim access panel.
2. Rotate back-up lamp socket counterclockwise and remove.
3. Remove back-up lamp bulb from bulb socket.

Installation

Installation is in the reverse order of removal.

M

N

O

P

LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[XENON TYPE]

LICENSE PLATE LAMP

Exploded View

INFOID:0000000011134715



1. License plate lamp harness
2. License plate lamp socket
3. License plate lamp bulb
4. License plate lamp gasket
5. License plate lamp

Removal and Installation

INFOID:0000000011134716

LICENSE PLATE LAMP

Removal

1. Remove back door outer finisher. Refer to [EXT-44, "Removal and Installation"](#).
2. Release pawls using a suitable tool and remove license plate lamp.

Installation

Installation is in the reverse order of removal.

LICENSE PLATE LAMP BULB

WARNING:


Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.

Removal

1. Remove back door lower finisher. Refer to [INT-35, "BACK DOOR LOWER FINISHER : Removal and Installation"](#).
2. Rotate license plate lamp socket (1) counterclockwise and remove.
3. Remove license plate lamp bulb (2) from bulb socket.



Installation

LICENSE PLATE LAMP

< REMOVAL AND INSTALLATION >

[XENON TYPE]

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M


N

O

P

UNIT DISASSEMBLY AND ASSEMBLY**FRONT COMBINATION LAMP****Exploded View**

INFOID:000000011134717



- | | | |
|--------------------------------|------------------------|----------------------------------|
| 1. Front combination lamp | 2. Retaining spring | 3. Side marker lamp bulb |
| 4. Side marker lamp socket | 5. Xenon bulb | 6. Front turn signal lamp socket |
| 7. Front turn signal lamp bulb | 8. Parking lamp socket | 9. Parking lamp bulb |
| A. Seal packing | B. Plastic cover | |

Disassembly and Assembly

INFOID:000000011134718

DISASSEMBLY**WARNING:**

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

CAUTION:

- Disconnect the negative battery terminal or remove the fuse.
- Do not touch glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to bulb.
- Do not leave the bulb out of the lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of the lamp.

CAUTION:

HID control unit and xenon bulb socket cannot be disassembled.

1. Remove front combination lamp. Refer to [EXL-162, "Removal and Installation"](#)
2. Rotate plastic cover counterclockwise and remove.
3. Rotate xenon bulb socket counterclockwise and remove.
4. Unlock retaining spring and remove xenon bulb.
5. Rotate parking lamp socket counterclockwise and remove.
6. Remove parking lamp bulb from parking lamp socket.
7. Rotate front turn signal lamp socket counterclockwise and remove.
8. Remove front turn signal lamp bulb from front turn signal lamp socket.
9. Rotate side marker lamp socket counterclockwise and remove.
10. Remove side marker lamp bulb from side marker lamp socket.

ASSEMBLY

Assembly is in the reverse order of disassembly.

CAUTION:

After installing the bulb, install the plastic cover and the bulb socket securely for watertightness.

NOTE:

FRONT COMBINATION LAMP

< UNIT DISASSEMBLY AND ASSEMBLY >

[XENON TYPE]

After installation, perform headlamp aiming adjustment. Refer to [EXL-159, "Aiming Adjustment Procedure"](#)

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

REAR COMBINATION LAMP


< UNIT DISASSEMBLY AND ASSEMBLY >

[XENON TYPE]

REAR COMBINATION LAMP

Exploded View

INFOID:0000000011134719



- | | | |
|------------------------------------|--------------------------|--------------------------|
| 1. Rear combination lamp | 2. Rear turn signal bulb | 3. Rear turn bulb socket |
| 4. Rear LED lamp harness connector | A. Grommet | (○) Locating pin |

Disassembly and Assembly

INFOID:0000000011134720

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

DISASSEMBLY

1. Remove rear combination lamp. Refer to [EXL-171, "Removal and Installation"](#).
2. Rotate the rear turn signal lamp socket counterclockwise and remove.
3. Remove the bulb from rear turn signal lamp socket.

ASSEMBLY

Assembly is in the reverse order of disassembly.

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[XENON TYPE]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:000000011134721

Item	Wattage (W)*
Front combination lamp	Headlamp (HI/LO)
	Front turn signal lamp
	Parking lamp
	Side marker lamp
Front fog lamp	55
Day time running lamp (Canada only)	19
Rear combination lamp	Stop lamp/Tail lamp
	Rear turn signal lamp
	Side marker lamp
Back-up lamp	18
License plate lamp	5
High-mounted stop lamp	LED

*: Always check with the Parts Department for the latest parts info.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P