

# SECTION PG

## POWER SUPPLY, GROUND & CIRCUIT ELEMENTS

### CONTENTS

<b>PRECAUTION</b>	3	<b>FUSE BLOCK - JUNCTION BOX (J/B)</b>	83
<b>PRECAUTIONS</b>	3	Terminal Arrangement	83
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	3	<b>FUSE, FUSIBLE LINK AND RELAY BOX</b>	84
		Terminal Arrangement	84
<b>PREPARATION</b>	4	<b>IPDM E/R (INTELLIGENT POWER DISTRI- BUTION MODULE ENGINE ROOM)</b>	88
<b>PREPARATION</b>	4	IPDM E/R Terminal Arrangement	88
Special Service Tools	4	<b>BASIC INSPECTION</b>	89
Commercial Service Tool	4	<b>BATTERY</b>	89
<b>SYSTEM DESCRIPTION</b>	5	How to Handle Battery	89
<b>COMPONENT PARTS</b>	5	Work Flow	89
Circuit Breaker	5	<b>INSPECTION AND ADJUSTMENT</b>	92
Battery	5	<b>ADDITIONAL SERVICE WHEN REMOVING BAT- TERY NEGATIVE TERMINAL</b>	92
Harness Connector	5	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Re- pair Requirement	92
Standardized Relay	8	<b>REMOVAL AND INSTALLATION</b>	93
<b>WIRING DIAGRAM</b>	11	<b>BATTERY</b>	93
<b>POWER SUPPLY ROUTING CIRCUIT</b>	11	Exploded View	93
Wiring Diagram - BATTERY POWER SUPPLY	11	Removal and Installation	93
Wiring Diagram - ACCESSORY POWER SUP- PLY	19	<b>BATTERY TRAY</b>	95
Wiring Diagram - IGNITION POWER SUPPLY	23	Removal and Installation	95
<b>GROUND</b>	35	<b>BATTERY TERMINAL WITH FUSIBLE LINK</b>	96
Ground Distribution	35	Exploded View	96
<b>HARNESS</b>	50	Removal and Installation	96
Harness Layout	50	<b>BATTERY CURRENT SENSOR</b>	97
<b>ELECTRICAL UNITS LOCATION</b>	75	Exploded View	97
Electrical Units Location	75	Removal and Installation	97
<b>HARNESS CONNECTOR</b>	78	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b>	98
Description	78		
<b>STANDARDIZED RELAY</b>	81		
Description	81		

A  
B  
C  
D  
E

F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

PG

---

<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	Battery .....	98
--	---------------	----

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000009131079

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes dual stage front air bag modules. The SRS system may only deploy one front air bag, depending on the severity of a collision and whether the front passenger seat is occupied. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

A

B

C

D

E

F

G

H

I

J

K

L

PG

N

O

P

## PREPARATION

< PREPARATION >



# PREPARATION

## PREPARATION

### Special Service Tools

INFOID:000000009131080

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.)	Description
— — Model GR8-1200 NI Multitasking battery and electrical diagnostic station	 Tests batteries, starting and charging systems and charges batteries. For operating instructions, refer to diagnostic station instruction manual. AWIIA1239ZZ
— — Model EXP-800 NI Battery and electrical diagnostic analyzer	 Tests batteries and charging systems. For operating instructions, refer to diagnostic analyzer instruction manual. JSMIA0806ZZ

### Commercial Service Tool

INFOID:000000009754969

Tool name	Description
Power tool	 Loosening nuts, screws and bolts PIIB1407E

## COMPONENT PARTS

< SYSTEM DESCRIPTION >


# SYSTEM DESCRIPTION

## COMPONENT PARTS

### Circuit Breaker

INFOID:000000009131081

The PTC thermistor generates heat in response to current flow. The temperature (and resistance) of the thermistor element varies with current flow. Excessive current flow will cause the element's temperature to rise. When the temperature reaches a specified level, the electrical resistance will rise sharply to control the circuit current. Reduced current flow will cause the element to cool. Resistance falls accordingly and normal circuit current flow is allowed to resume.



SEL109W

### Battery

INFOID:000000009131082

Type	115D31R
20 hour rate capacity [V – Ah]	12 – 82
Cold cranking current (For reference value) [A]	782

### Harness Connector

INFOID:000000009131083

#### HARNESS CONNECTOR (TAB-LOCKING TYPE)

- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the figure below.

#### CAUTION:

Never pull the harness or wires when disconnecting the connector.

A

B

C

D

E

F

G

H

I

J

K

L

PG

N


O

P

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

[Example]



SEL769DA

### HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.
- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.

#### **CAUTION:**


- Never pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

[Example]

### Waterproof type




① Firmly grasp shell of connector housing at A.

② Push slider until connector pops or snaps apart.

③ Disconnect harness connector.

### Non-waterproof type



① Firmly grasp shell of connector housing at A.

② Pull back on the slider while pulling apart male and female halves of connector.

③ Disconnect harness connector.

SEL769V

## HARNESS CONNECTOR (LEVER LOCKING TYPE)

- Lever locking type harness connectors are used on certain control units and control modules such as ECM, ABS actuator and electric unit (control unit), etc.
- Lever locking type harness connectors are also used on super multiple junction (SMJ) connectors.
- Always confirm the lever is fully locked in place by moving the lever as far as it will go to ensure full connection.

**CAUTION:**


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

PG

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

**Always confirm the lever is fully released (loosened) before attempting to disconnect or connect these connectors to avoid damage to the connector housing or terminals.**



LKIA0670E

- |   |   |  |
|---|---|--|
| 1. Control unit with single lever<br>A. Fasten<br>B. Loosen<br>C. Lever | 2. Control unit with dual levers<br>A. Levers<br>B. Fasten<br>C. Loosen | 3. SMJ connector<br>A. Lever<br>B. Fasten<br>C. Loosen |
|---|---|--|

## Standardized Relay

INFOID:0000000009131084

### NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS

Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.

	NORMAL OPEN RELAY	NORMAL CLOSED RELAY	MIXED TYPE RELAY
SW 1 "OFF"			
SW 1 "ON"			

SEL881H


## TYPE OF STANDARDIZED RELAYS

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

1M ..... 1 Make  
1T ..... 1 Transfer

2M ..... 2 Make  
1M·1B ..... 1 Make 1 Break
















SEL882H

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
PG  
N  
O  
P

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M	 			BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W

# POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

## WIRING DIAGRAM

### POWER SUPPLY ROUTING CIRCUIT


#### Wiring Diagram - BATTERY POWER SUPPLY -

INFOID:0000000009131085



# POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >



ABMWA2095GB

# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >




ABMWAA2096GB

A B C D E F G H I J K L M N O P Q R Z PG

# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

N : FOR CANADA




# POWER SUPPLY ROUTING CIRCUIT

**< WIRING DIAGRAM >**

## BATTERY POWER SUPPLY CONNECTORS


Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	W	-

Connector No.	E7
Connector Name	FUSIBLE LINK BOX (BATTERIY)
Connector Color	GRAY



Connector No.	M82
Connector Name	CIRCUIT BREAKER-2
Connector Color	WHITE




Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3	W	-
4	R	-

Connector No.	E7
Connector Name	FUSIBLE LINK BOX (BATTERIY)
Connector Color	GRAY




# POWER SUPPLY ROUTING CIRCUIT

**< WIRING DIAGRAM >**

Connector No.	E27
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	BROWN



Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5M	Y	-
5	W	-

Terminal No.	Color of Wire	Signal Name
1	W	-
2	L	-

Connector No.	E63
Connector Name	POWER STEERING CONTROL MODULE
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
5	W	-



Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H
41	B	GND (SIGNAL)

Terminal No.	Color of Wire	Signal Name
1	R	F/L MAIN
2	L	F/L USM



Terminal No.	Color of Wire	Signal Name
19	20	21
23	24	25
26	27	28
29	30	31
32	33	34
35	36	37
38	39	40
41	42	43
44	45	46
47	48	49
49	50	


ABMIA4822GB

# POWER SUPPLY ROUTING CIRCUIT


< WIRING DIAGRAM >

Connector No.	Color of Wire	Terminal No.	Color of Wire	Signal Name
E152	WHITE	10G	P	-

Connector No.	Color of Wire	Terminal No.	Color of Wire	Signal Name
E121	WHITE	G	9	10 11




Terminal No.	Color of Wire	Signal Name
9	G	TAIL RH
10	L	TAIL LH
13	LG	ECM VB
14	V	DTRL



Connector No.	Color of Wire	Terminal No.	Color of Wire	Signal Name
F6	WHITE	1	B/R	-



Connector No.	Color of Wire	Terminal No.	Color of Wire	Signal Name
E218	WHITE	1	B/R	-



Connector No.	Color of Wire	Terminal No.	Color of Wire	Signal Name
E217	WHITE	74	75 76	77 78 79 80 81



Connector No.	Color of Wire	Terminal No.	Color of Wire	Signal Name
90	LG	90	LG	CLEARANCE

ABMIA4823GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
PG


# POWER SUPPLY ROUTING CIRCUIT

**< WIRING DIAGRAM >**

Connector No.	F19
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	F24
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	F19
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
52	W	O2SENS #2
53	W	O2SENS #1

Terminal No.	Color of Wire	Signal Name
57	R	ETC
58	GR	ECM BAT
59	L	ENG SOL

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
B	B/R	-	B	B/R	-



Terminal No.	Color of Wire	Signal Name
6Q	P	-


Terminal No.	Color of Wire	Signal Name
6	B/R	-



Connector No.	B29
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	F39
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	-



Terminal No.	Color of Wire	Signal Name
6T	L	-

ABMIA4824GB


# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

## Wiring Diagram - ACCESSORY POWER SUPPLY -

INFOID:0000000009131086

### ACCESSORY POWER SUPPLY



ABMWA2098GB

# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

## ACCESSORY POWER SUPPLY CONNECTORS


Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1N	LG	—
7N	L	—

Terminal No.	Color of Wire	Signal Name
1N	LG	—
7N	L	—


Terminal No.	Color of Wire	Signal Name
3G	P	—
10G	W	—
50G	L	—




Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Connector No.	M80
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
113	L	ACC RELAY OUT
139	W	BAT POWER F/L

# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

Connector No.	E13	Connector No.	E22
Connector Name	FUSE BLOCK (J/B)	Connector Name	ACCESSORY RELAY-2
Connector Color	WHITE	Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1S	W	-	1	G	-
			2	B	-
			3	R	-
			5	P	-



Connector No.	E30	Connector No.	E44
Connector Name	FUSIBLE LINK BOX (BATTERY)	Connector Name	JOINT CONNECTOR-E01
Connector Color	BLACK	Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
5	W	-	11	9	-



Terminal No.	Color of Wire	Signal Name
15	GR	-
17	B	-

PG

N

O


P

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

ABMIA4825GB

# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >



ABMIA4826GB


# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

## Wiring Diagram - IGNITION POWER SUPPLY -


INFO ID: 000000009131087

### IGNITION POWER SUPPLY



# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >




ABMWA2100GB

# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

W4 : WITH ALL WHEEL DRIVE



ABMWAA2101GB

PG


# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >


---

## IGNITION POWER SUPPLY CONNECTORS


Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3N	L	—
8N	L	—




Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



ABMIA3726GB

# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >



ABMIA4827GB








# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >

Connector No.	E152	Connector No.	E217																
Connector Name	WIRE TO WIRE	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																
Connector Color	WHITE	Connector Color	WHITE																
																			
<table border="1"><thead><tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name</th><th></th></tr></thead><tbody><tr><td>10G</td><td>P</td><td>-</td><td></td></tr><tr><td>35G</td><td>P</td><td>-</td><td></td></tr><tr><td>36G</td><td>L</td><td>-</td><td></td></tr></tbody></table>				Terminal No.	Color of Wire	Signal Name		10G	P	-		35G	P	-		36G	L	-	
Terminal No.	Color of Wire	Signal Name																	
10G	P	-																	
35G	P	-																	
36G	L	-																	
<table border="1"><thead><tr><th>Terminal No.</th><th>Color of Wire</th><th>Signal Name</th><th></th></tr></thead><tbody><tr><td>74</td><td>R</td><td>WASH MTR</td><td></td></tr></tbody></table>				Terminal No.	Color of Wire	Signal Name		74	R	WASH MTR									
Terminal No.	Color of Wire	Signal Name																	
74	R	WASH MTR																	
																			


ABMIA4502GB





# POWER SUPPLY ROUTING CIRCUIT

< WIRING DIAGRAM >



ABMIA3740GB

# GROUND



< WIRING DIAGRAM >

## GROUND

### Ground Distribution

INFOID:0000000009131088

### MAIN HARNESS



CONNECTOR NUMBER	CONNECT TO
(M16)	ADP steering switch
(M22)	Data link connector (Terminal No. 4)
(M22)	Data link connector (Terminal No. 5)
(M24)	Combination meter (Terminal No. 1)
(M24)	Combination meter (Terminal No. 2)
(M28)	Combination switch
(M48)	Heated steering wheel switch (Terminal No. 2)
(M48)	Heated steering wheel switch (Terminal No. 6)
(M54)	Steering angle sensor
(M68)	Fuse block (J/B)
(M70)	Sonar control unit (Terminal No. 15)
(M70)	Sonar control unit shield
(E307)	Front sonar sensor LH outer shield
(E308)	Front sonar sensor RH outer shield
(B455)	Rear sonar sensor LH outer shield
(B456)	Rear sonar sensor RH outer shield
(B457)	Rear sonar sensor LH inner shield
(B458)	Rear sonar sensor RH inner shield
(M71)	VDC OFF switch
(M81)	BCM (body control module) (Terminal No. 134)
(M81)	BCM (body control module) (Terminal No. 143)
(M88)	A/C 120V outlet main switch
(M98)	A/C and AV switch assembly
(M117)	PTC heater (Terminal No. 2)
(M121)	Headlamp aiming switch
(M135)	Automatic back door main switch
(M186)	Automatic back door switch
(B82)	Inverter unit shield
(B82)	Inverter unit (Terminal No. 8)
(B205)	Climate controlled seat control unit (driver seat) (Terminal No. 30) (with rear entertainment system)
(R4)	Moonroof motor assembly

Next page

Next page

A

B

C

D

E

F

G

H

I

J

K

L

PG

N



O

P

ABMIA4837GB

# GROUND


< WIRING DIAGRAM >




ABMIA4838GB

# GROUND

< WIRING DIAGRAM >



Preceding page







CONNECTOR NUMBER	CONNECT TO
(M93)	Display unit (Terminal No. 1) (without NAVI)
(M117)	PTC heater (Terminal No. 4)
(M122)	AV control unit (Terminal No. 20) (with BOSE audio system - with NAVI without surround sound system)
(M126)	Twin switch (warning system switch)
(M160)	Yaw rate/side/decel G sensor
(M161)	AV control unit (Terminal No. 20) (with BOSE audio system - with NAVI and surround sound system)
(M193)	AV control unit (Terminal No. 52) (with BOSE audio system without NAVI)
(M46)	AV control unit (shield wire) (Terminal No. 90) (with base audio system)
(M125)	AV control unit (shield wire) (Terminal No. 94) (with BOSE audio system - with NAVI without surround sound system)
(M164)	AV control unit (Terminal No. 94) (with BOSE audio system - with NAVI and surround sound system)
(M195)	AV control unit (shield wire) (Terminal No. 90) (with BOSE audio system without NAVI)
(M123)	AV control unit (shield wire) (Terminal No. 37) (with rear entertainment system) (with BOSE audio system with NAVI without surround sound system)
(M182)	AV control unit (shield wire) (Terminal No. 37) (with rear entertainment system) (with BOSE audio system - with NAVI and surround sound system)
(B110)	Front seat RH shield (pre-wiring) (without rear entertainment system)
(M203)	Climate controlled seat switch (driver seat)
(M206)	Climate controlled seat switch (passenger seat)
(M207)	Front console power socket
(M211)	Drive mode select switch
(M220)	Front heated seat switch LH
(M221)	Front heated seat switch RH
(M228)	Front power socket (for cigarette lighter)
(M252)	2nd row heated seat switch LH
(M253)	2nd row heated seat switch RH
(M258)	Rear console power socket
(M254)	Rear auxiliary input jacks
(M258)	Rear air control (Terminal No. 1)
(B25)	Video distributor (shield wire)
(B202)	Headrest display unit (driver seat) (Terminal No. 12)
(B302)	Headrest display unit (passenger seat) (Terminal No. 12)

ABMIA4839GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
PG  
N  
O  
P

# GROUND

< WIRING DIAGRAM >






ABMIA4840GB

# GROUND

< WIRING DIAGRAM >

ENGINE ROOM HARNESS







A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
PG  
N  
O  
P

ABMIA4841GB

# GROUND

< WIRING DIAGRAM >




ABMIA3777GB

# GROUND

< WIRING DIAGRAM >

## FRONT END MODULE HARNESS



A

B

C

D

E

F

G

H

I

K

L


PG

N


O

P


CONNECTOR NUMBER	CONNECT TO
(E204)	Generator (Terminal No. 5)
(E204)	Generator (Terminal No. 6)



CONNECTOR NUMBER	CONNECT TO
(E205)	Hood switch
(E208)	Washer fluid level switch
(E221)	Horn (high)
(E223)	Horn (low)
(E227)	Exhaust gas/outside odor detecting sensor
(E240)	Front combination lamp RH
(E304)	Front fog lamp RH (with daytime light system)
(E306)	Front fog lamp RH (without daytime light system)
(E331)	Front combination lamp RH
(E332)	Front combination lamp RH
(E333)	Front combination lamp RH
(E334)	Front combination lamp RH (headlamp aiming motor)




CONNECTOR NUMBER	CONNECT TO
(E219)	ICC sensor
(E234)	Front combination lamp LH
(E327)	Front combination lamp LH
(E328)	Front combination lamp LH
(E329)	Front combination lamp LH
(E330)	Front combination lamp LH (headlamp aiming motor)
(E303)	Front fog lamp LH (with daytime light system)
(E305)	Front fog lamp LH (without daytime light system)




ABMIA4842GB

# GROUND

< WIRING DIAGRAM >



(NX) : EXCEPT MEXICO  
(XX) : FOR MEXICO





ABMIA4843GB

# GROUND

< WIRING DIAGRAM >

ENGINE CONTROL HARNESS



CONNECTOR NUMBER	CONNECT TO
(F8)	Ignition coil No. 2 (with power transistor)
(F9)	Ignition coil No. 4 (with power transistor)
(F10)	Ignition coil No. 6 (with power transistor)
(F21)	Condenser-1
(F47)	Ignition coil No. 1 (with power transistor)
(F48)	Ignition coil No. 3 (with power transistor)
(F49)	Ignition coil No. 5 (with power transistor)

A

B

C

D

E

F

G

H

I

J

K

L

PG

N

O



ABMIA4844GB

P

# GROUND

< WIRING DIAGRAM >

## BODY HARNESS




Next page


ABMIA4845GB

# GROUND

< WIRING DIAGRAM >



Preceding page



CONNECTOR NUMBER	CONNECT TO
(B2)	Satellite radio tuner
(B3)	Bluetooth® control unit (Terminal No. 4)
(B3)	Bluetooth® control unit (Terminal No. 20)
(B3)	Bluetooth® control unit (Terminal No. 23)
(B3)	Bluetooth® control unit (Terminal No. 24)
(B3)	Bluetooth® control unit (Terminal No. 27)
(B24)	Video distributor (Terminal No. 1)
(B24)	Video distributor (Terminal No. 3)
(B56)	Automatic back door control module shield
(B56)	Automatic back door control module (Terminal No. 32)
(B416)	Side radar LH
(D21)	Blind spot warning/blind spot intervention indicator LH
(D21)	Blind spot warning/blind spot intervention indicator LH shield
(B70)	Spindle unit LH (shield wire)
(B162)	Spindle unit RH (shield wire)
(B81)	Rear cargo power socket
(B85)	Sunshade motor assembly
(B90)	Third row power folding seat switch driver side
(B412)	Third row power folding seat control unit (Terminal No. 12)
(B412)	Third row power folding seat control unit (Terminal No. 25)
(B427)	Trailer tow relay 1
(B428)	Trailer tow relay 2
(B431)	Trailer back-up relay
(D557)	Back door lock assembly
(D559)	Back door opener switch (Terminal No. 2)
(D559)	Back door opener switch (Terminal No. 3)
(B56)	Automatic back door control module (shield wire) (Terminal No. 28)
(D560)	Automatic back door close switch
(D503)	High-mounted stop lamp
(D553)	Rear wiper motor
(D561)	License plate lamp LH
(D562)	License plate lamp RH
(D563)	Back-up lamp RH
(D564)	Back-up lamp LH

A

B

C

D

E

F

G

H

I

J

K

L

PG

N




O

P

ABMIA4846GB

# GROUND

## < WIRING DIAGRAM >






ABMIA4847GB


# GROUND

< WIRING DIAGRAM >

BODY NO. 2 HARNESS



CONNECTOR NUMBER	CONNECT TO
(B105)	2nd row seat heater RH
(B110)	Front seat RH (pre-wiring)
(B138)	Third row power folding seat switch passenger side
(B303)	Seat belt buckle switch (passenger seat)
(B304)	Climate controlled seat control unit (passenger seat) (Terminal No. 30) (without rear entertainment system)
(B313)	Power seat switch RH (without rear entertainment system)
(B315)	Front seat heater (passenger seat)
(B356)	Occupant classification system control unit (Terminal No. 9)
(B160)	Pre-crash seat belt control unit (passenger side) (Terminal No. 20)
(D356)	Rear power window switch RH (Terminal No. 11)



CONNECTOR NUMBER	CONNECT TO
(B104)	ADAS control unit shield
(B104)	ADAS control unit (Terminal No. 6)
(B109)	Side radar RH (Terminal No. 1)
(B109)	Side radar RH (Terminal No. 2)
(D111)	Blind spot warning/blind spot intervention indicator RH
(D111)	Blind spot warning/blind spot intervention indicator RH shield
(B121)	BOSE speaker AMP. (Terminal No. 47) (with surround sound)
(B121)	BOSE speaker AMP. (Terminal No. 52) (with surround sound)
(B129)	BOSE speaker AMP. (terminal No. 47) (without surround sound)
(B129)	BOSE speaker AMP. (terminal No. 52) (without surround sound)
(B133)	Rear blower motor resistor 2
(B160)	Pre-crash seat belt control unit (passenger side) (Terminal No. 18)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L



PG

N  
O  
P


ABMIA4848GB

# GROUND

< WIRING DIAGRAM >



Body ground






Body ground

ABMIA4849GB

# GROUND

< WIRING DIAGRAM >

BACK DOOR HARNESS



A  
B  
C  
D

E  
F  
G  
H  
I

J  
K

PG

N

O

ABMIA3784GB

P

# HARNESS

< WIRING DIAGRAM >

## HARNESS

### Harness Layout


INFOID:0000000009131089

#### BOSEHOW TO READ HARNESS LAYOUT

The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness 1, Main Harness 2, Console Sub-harness and Console Switch Sub-harness
- Engine Room Harness
- Engine Room Harness (Passenger Compartment)
- Front End Module Harness, Front Fog Lamp Sub-harness and Front Combination Lamp Sub-harness
- Engine Control Harness and Knock Sensor Sub-harness
- Body Harness, Front Seat LH Harness, Body No.3 Harness, Body No.3 Sub-harness, Trailer Relay Sub Harness and Chassis Harness
- Body No. 2 Harness, Front Seat RH Harness and ODS Sub Harness
- Room Lamp Harness and Room Lamp Sub-harness
- Back Door LH Harness and Back Door RH Harness

Example:




SEL252V

#### To use the grid reference

1. Find the desired connector number on the connector list.
2. Find the grid reference.
3. On the drawing, find the crossing of the grid reference letter column and number row.
4. Find the connector number in the crossing zone.
5. Follow the line (if used) to the connector.

#### OUTLINE




ABMIA4855GB

# HARNESS

< WIRING DIAGRAM >

MAIN HARNESS 1



ABMIA4829ZZ

A2	M1	W/24	: To R1	E1	M59	—	: Glove box lamp
A2	M2	W/6	: To R2	B3	M60	BR/4	: Warning buzzer
B4	M3	W/8	: Fuse block (J/B)	C2	M61	—	: Body ground
B4	M4	W/16	: Fuse block (J/B)	B1	M62	BR/2	: Instrument panel tweeter LH
E2	M5	W/12	: CAN gateway	E3	M63	W/24	: To M215




# HARNESS

## < WIRING DIAGRAM >

C3	M53	Y/6	: Combination switch (Spiral cable)	E3	M115	GR/7	: To M210
C3	M54	W/8	: Steering angle sensor	E5	M117	W/2	: PTC heater
E3	M55	L/5	: AV control unit	E5	M118	W/3	: PTC heater
E3	M56	W/10	: To M214	F2	M119	W/4	: Ionizer
B2	M57	—	: Body ground	F1	M120	W/4	: Joint connector-M21
G2	M58	BR/	: Climate controlled seat relay				

## MAIN HARNESS 2



ABMIA4830ZZ



# HARNESS

## < WIRING DIAGRAM >

F1	M170	W/33	: Joint connector-M09	D3	M228	GR/3	: Front console power socket (For cigarette lighter)		
D1	M171	W/4	: Joint connector-M10	E4	M230	GR/6	: Joint connector-M01		
D2	M172	W/4	: Joint connector-M11	Console switch sub harness					
D2	M173	W/4	: Joint connector-M12	E5	M251	W/16	: To M201		
D2	M174	W/4	: Joint connector-M13	E5	M252	W/6	: 2nd row heated seat switch LH		
E2	M175	W/33	: Joint connector-M22	F5	M253	BR/6	: 2nd row heated seat switch RH		
C1	M176	W/4	: Joint connector-M56	E5	M254	W/40	: Rear auxiliary input jacks		
C2	M177	W/4	: Joint connector-M57	E5	M255	GR/2	: Inside key antenna (Console)		
E2	M178	W/4	: Joint connector-M58	F5	M256	W/4	: A/C 120V outlet		
D1	M179	W/4	: Joint connector-M59	F5	M257	W/24	: To M202		
G2	M180	BR/7	: Heated seat relay	E4	M258	W/12	: Rear air control		
C2	M181	W/4	: Joint connector-M36	E5	M268	GR/3	: Rear console power socket		
A2	M183	W/4	: Joint connector-M44						

A

B

C

D

E

F

G

H

I

J

K

L

PG

N


O

P

# HARNESS

< WIRING DIAGRAM >

ENGINE ROOM HARNESS



ABMIA4831ZZ

E1	E1	BR/3	: Intelligent Key warning buzzer	F3	E30	B/1	: Fusible link box (Battery)
F3	E2	W/16	: To F32	G2	E40	B/2	: To E201
F2	E3	B/2	: Anti theft diode	B3	E43	B/2	: Front wheel sensor RH
C3	E4	BR/6	: Daytime light relay	F1	E45	L/12	: Joint connector-E12
G2	E5	W/16	: To E207	G2	E55	W/4	: Joint connector-E10

# HARNESS

## < WIRING DIAGRAM >

E3	E7	GR/2	: Fusible link box (Battery)	B2	E61	—	: Body ground
F3	E8	W/3	: Anti theft horn relay	B3	E62	B/6	: Power steering control module
E2	E9	—	: Ground	C3	E63	B/2	: Power steering control module
C3	E11	L/5	: PTC relay-1	B1	E70	B/6	: Joint connector-E14
D2	E12	L/5	: PTC relay-2	C1	E71	B/6	: Joint connector-E15
F1	E14	B/12	: Joint connector-E05	D3	E75	L/4	: ICC brake hold relay
E2	E15	—	: Engine ground	E2	E77	L/4	: Trailer turn relay LH
E3	E16	GR/32	: ECM	E2	E78	L/4	: Trailer turn relay RH
E2	E18	B/2	: Front wheel sensor LH	G2	E82	BR/4	: Cooling fan relay
F3	E19	W/10	: To F33	F1	E118	B/2	: IPDM E/R (Intelligent power distribution module engine room)
D2	E21	GR/2	: Brake fluid level switch	F1	E119	W/32	: IPDM E/R (Intelligent power distribution module engine room)
C3	E22	L/4	: Accessory relay-2	E1	E120	W/4	: IPDM E/R (Intelligent power distribution module engine room)
E1	E23	GR/5	: Front wiper motor	F1	E121	W/12	: IPDM E/R (Intelligent power distribution module engine room)
F2	E26	W/24	: To E209	B2	E125	B/34	: ABS actuator and electric unit (Control unit)
F2	E27	BR/2	: Fusible link box (Battery)	E2	E167	B/3	: Vacuum sensor
F2	E29	Y/4	: To E210				

A

B

C

D

E

F

G

H

I

J

K

L

PG

N


O

P

# HARNESS

< WIRING DIAGRAM >

ENGINE ROOM HARNESS (PASSENGER VIEW)



AAMIA0128ZZ


B4	E13	W/1	: Fuse block (J/B)	D4	E52	B/1	: Parking brake switch
B4	E17	W/1	: Fuse block (J/B)	D2	E56	BR/2	: VDC resistor
C5	E28	W/10	: Fuse block (J/B)	D5	E72	BR/2	: ICC brake switch
F5	E31	B/6	: Accelerator pedal position sensor (Without intelligent cruise control)	G5	E73	B/6	: Accelerator pedal position sensor (With intelligent cruise control)
B3	E33	W/12	: To B43	G4	E74	GR/6	: Accelerator pedal actuator

# HARNESS

## < WIRING DIAGRAM >

C2	E34	W/24	: To B40	E5	E76	BR/2	: Brake pedal position switch
B3	E35	GR/1	: To B48	E4	E106	W/4	: Joint connector-E06
A4	E36	W/3	: To M75	F4	E108	W/4	: Joint connector-E07
E4	E38	W/4	: Stop lamp switch	C2	E126	—	: Body ground
C1	E44	W/33	: Joint connector-E01	C4	E152	SMJ	: To M31
E3	E51	B/4	: Brake pedal stroke sensor				

## FRONT END MODULE HARNESS



A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

AAMIA0129ZZ

PG

# HARNESS

## < WIRING DIAGRAM >

F3	E201	B/2	: To E40	E3	E232	B/8	: To E325
C2	E203	—	: Body ground	B3	E233	GR/8	: To E326
C2	E204	—	: Generator	E3	E234	GR/2	: Front combination lamp LH
C2	E205	BR/3	: Hood switch	E4	E235	GR/2	: Front combination lamp LH
C5	E206	B/2	: Ambient sensor	A2	E239	GR/2	: Front combination lamp RH
F3	E207	W/16	: To E5	A2	E240	GR/2	: Front combination lamp RH
B3	E208	B/2	: Washer fluid level switch	D4	E244	B/3	: Refrigerant pressure sensor
F3	E209	W/24	: To E26	D4	E245	BR/2	: Cooling fan control module (cooling fan motor-1)
E3	E210	Y/4	: To E29	D4	E246	GR/2	: Cooling fan control module (cooling fan motor-2)
B3	E211	GR/8	: To E301	Front fog lamp sub harness			
E5	E212	GR/8	: To E302	B4	E301	GR/8	: To E211
F4	E213	—	: Body ground	E5	E302	GR/8	: To E212
C2	E214	—	: Body ground	F5	E303	GR/2	: Front fog lamp LH
B3	E215	—	: Body ground	A3	E304	GR/2	: Front fog lamp RH
E4	E216	—	: Body ground	F5	E305	B/2	: Front fog lamp LH
F2	E217	W/8	: IPDM E/R (intelligent power distribution module engine room)	A4	E306	B/2	: Front fog lamp RH
F2	E218	W/16	: IPDM E/R (intelligent power distribution module engine room)	F4	E307	B/3	: Front sonar sensor LH outer
B4	E219	B/8	: ICC sensor	A3	E308	B/3	: Front sonar sensor RH outer
C3	E220	B/1	: Horn (high)	Front combination lamp sub harness			
C3	E221	B/1	: Horn (high)	E3	E325	B/8	: To E232
D4	E222	B/1	: Horn (low)	B2	E326	GR/8	: To E233
D3	E223	B/1	: Horn (low)	F4	E327	B/2	: Front combination lamp LH
B4	E224	B/2	: Front and rear washer motor	F3	E328	GR/2	: Front combination lamp LH
C3	E225	GR/3	: Cooling fan control module	G3	E329	GR/2	: Front combination lamp LH
C3	E226	B/6	: Front camera	F3	E330	GR/3	: Front combination lamp LH (headlamp aiming motor)
D4	E227	B/3	: Exhaust gas/outside odor detecting sensor	A2	E331	B/2	: Front combination lamp RH
D3	E228	Y/2	: Crash zone sensor	A2	E332	GR/2	: Front combination lamp RH
E4	E229	—	: Body ground	A1	E333	GR/2	: Front combination lamp RH
B2	E231	B/1	: Anti theft horn	B2	E334	GR/3	: Front combination lamp RH (headlamp aiming motor)

# HARNESS

< WIRING DIAGRAM >

ENGINE CONTROL HARNESS



ABMIA4832ZZ

B5	F3	B/2	: A/C compressor	F3	F39	—	: Fusible link box (Battery)
C5	F5	GR/4	: Air fuel ratio (A/F) sensor 1 (Bank 2)	C3	F41	GR/2	: Fuel injector No. 3
C5	F6	—	: Generator	D3	F42	GR/2	: Fuel injector No. 5
C4	F7	B/3	: Generator	F4	F43	GR/22	: CVT unit
C4	F8	GR/3	: Ignition coil No. 2 (With power transistor)	D2	F44	B/3	: Camshaft position sensor (PHASE) (Bank 1)

# HARNESS


## < WIRING DIAGRAM >

C4	F9	GR/3	: Ignition coil No. 4 (With power transistor)	D4	F45	B/3	: Camshaft position sensor (PHASE) (Bank 2)	
D4	F10	GR/3	: Ignition coil No. 6 (With power transistor)	C2	F47	GR/3	: Ignition coil No. 1 (With power transistor)	
D4	F11	B/3	: Crankshaft position sensor (POS)	C2	F48	GR/3	: Ignition coil No. 3 (With power transistor)	
E4	F12	B/4	: Heated oxygen sensor 2 (Bank 2)	D2	F49	GR/3	: Ignition coil No. 5 (With power transistor)	
B2	F13	B/4	: Heated oxygen sensor 2 (Bank 1)	E2	F50	B/6	: Electric throttle control actuator	
E5	F14	B/10	: Joint connector-F01	E5	F51	B/48	: ECM	
D4	F16	GR/2	: Evap canister purge volume control solenoid valve	F4	F52	BR/48	: ECM	
F3	F17	B/1	: IPDM E/R (Intelligent power distribution module engine room)	E5	F53	B/10	: Joint connector-F03	
C3	F18	GR/2	: Fuel injector No. 2	B3	F54	B/3	: Engine oil pressure sensor	
G3	F19	W/10	: IPDM E/R (Intelligent power distribution module engine room)	F5	F55	B/10	: Joint connector-F04	
C3	F20	GR/2	: Fuel injector No. 4	G4	F56	W/4	: Joint connector-F07	
D3	F21	W/2	: Condenser-1	G4	F57	W/4	: Joint connector-F08	
D3	F22	GR/2	: Fuel injector No. 6	C2	F58	GR/6	: Joint connector-F09	
G2	F24	W/12	: IPDM E/R (Intelligent power distribution module engine room)	B4	F59	—	: Ground	
E5	F25	B/48	: TCM (Transmission control module)	B3	F60	—	: Ground	
D3	F26	B/4	: To F201	E3	F61	GR/2	: Engine coolant temperature sensor	
F4	F27	—	: Starter motor	B2	F62	GR/2	: Intake valve timing control solenoid valve (Bank 1)	
E4	F28	GR/1	: Starter motor	B3	F63	GR/2	: Intake valve timing control solenoid valve (Bank 2)	
E5	F29	B/10	: Transmission range switch	B3	F64	BR/2	: Electronic controlled engine mount control solenoid valve	
B3	F30	GR/2	: Fuel injector No. 1	D2	F65	BR/4	: Air fuel ratio (A/F) sensor 1 (Bank 1)	
E3	F31	B/5	: Mass air flow sensor	C3	F66	B/2	: VIAS control solenoid valve 1	
G3	F32	W/16	: To E2	C3	F67	B/2	: VIAS control solenoid valve 2	
F4	F33	W/10	: To E19	C2	F68	GR/2	: Engine oil temperature sensor	
F5	F34	GR/4	: Battery current sensor	Knock sensor sub harness				
F4	F35	B/3	: Primary speed sensor	D3	F201	L/4	: To F26	
F4	F36	B/3	: Output speed sensor	D3	F202	GR/2	: Knock sensor (Bank 1)	
E5	F37	B/3	: Input speed sensor	C3	F204	GR/2	: Knock sensor (Bank 2)	
F5	F38	B/10	: Joint connector-f02					

# HARNESS

< WIRING DIAGRAM >

BODY HARNESS



PG

ABMIA4833ZZ

B2	B1	BR/2	: Rear side speaker LH	C4	B76	GR/2	: Inside key antenna (Luggage room)
A2	B2	W/16	: Satellite radio tuner	A2	B77	W/32	: To B400
B3	B3	W/32	: Bluetooth® control unit	E3	B79	W/3	: 2nd row seat heater LH
B3	B4	W/8	: Bluetooth® control unit	G1	B80	W/4	: Joint connector-B17
G3	B5	W/16	: Front seat LH (Pre-wiring)	B1	B81	GR/3	: Rear cargo power socket

# HARNESS

## < WIRING DIAGRAM >

G2	B6	W/24	: To M66	B3	B82	B/8	: Inverter unit
C2	B7	—	: Body ground	C2	B85	W/10	: Sunshade motor assembly
E1	B8	W/4	: Front door switch LH	B2	B87	W/4	: Joint connector-B16
G3	B9	Y/15	: Air bag diagnosis sensor unit	Front seat LH harness			
G3	B10	Y/2	: Front LH side air bag module	G2	B200	BR/12	: To B54
E3	B11	W/4	: Joint connector-B09	G3	B201	W/24	: To B23
E3	B12	W/4	: Joint connector-B10	E2	B202	W/32	: Headrest display unit (Driver seat)
D4	B13	B/14	: To C13	E3	B203	B/16	: Climate controlled seat control unit (Driver seat)
E2	B14	Y/2	: Front LH seat belt pre-tensioner	F3	B204	B/8	: Climate controlled seat control unit (Driver seat)
E2	B15	Y/2	: Front side air bag satellite sensor LH	F3	B205	B/6	: Climate controlled seat control unit (Driver seat)
B4	B16	W/4	: Joint connector-B11	F3	B206	W/4	: Seat cushion thermal electric device (Driver seat)
B4	B17	W/4	: Joint connector-B12	F1	B207	W/6	: Lifting motor LH (Rear)
D2	B18	W/4	: Rear door switch LH	F1	B208	W/10	: Power seat switch LH
A4	B19	—	: Body ground	F2	B209	W/32	: Driver seat control unit
B1	B20	W/4	: Fuel lid door lock actuator	F3	B210	W/12	: Driver seat control unit
C3	B21	W/4	: Joint connector-B20	G2	B211	GR/5	: Sliding motor LH
E2	B22	O/2	: Front LH seat belt pre-tensioner	E3	B212	W/4	: Seat back thermal electric device (Driver seat)
G2	B23	W/24	: To B201	F4	B213	W/5	: Climate controlled seat blower motor (Driver seat)
A2	B24	W/32	: Video distributor	E1	B214	BR/4	: Lumbar support switch
A1	B25	W/24	: Video distributor	F1	B215	B/2	: Lumbar support motor
C2	B27	—	: Body ground	F1	B216	W/3	: Front seat heater (Driver seat)
C2	B28	—	: Body ground	F1	B217	W/6	: Reclining motor LH
G1	B29	W/6	: Fuse block (J/B)	G2	B218	W/6	: Lifting motor LH (Front)
G1	B30	W/8	: Fuse block (J/B)	G3	B220	W/12	: To B74
B4	B31	B/2	: Evap canister vent control valve	F4	B221	W/4	: Seat belt buckle switch (Driver seat)
G3	B32	W/32	: To B124	G2	B224	P/20	: Joint connector-B22
A2	B33	B/2	: To B404	Body no.3 harness			
A3	B34	W/8	: To B405	A2	B400	W/32	: To B77
C2	B35	W/4	: Sonar buzzer	A4	B401	B/12	: To B452
B4	B36	GR/3	: Evap control system pressure sensor	B4	B402	BR/2	: Back door warning chime
C1	B38	Y/2	: LH side curtain air bag module	A4	B403	GR/2	: Outside key antenna (Rear bumper)
E3	B39	W/4	: Joint connector-B05	A2	B404	B/2	: To B33
G1	B40	W/24	: To E34	A3	B405	W/8	: To B34
G2	B41	W/32	: To M69	A2	B406	GR/3	: Rear combination lamp LH
G2	B42	BR/12	: To M74	C4	B407	GR/3	: Rear combination lamp RH
G1	B43	W/12	: To E33	A2	B408	GR/2	: Rear combination lamp LH
A4	B44	B/2	: To B425	C4	B409	GR/2	: Rear combination lamp RH
A3	B45	W/16	: To B426	C4	B410	GR/6	: To B450
B2	B46	W/24	: To D501	B4	B411	B/2	: To B451
B1	B47	W/8	: To D502	A4	B416	B/6	: Side radar LH
G1	B48	W/1	: To E35	Trailer relay sub harness			

# HARNESS

## < WIRING DIAGRAM >

B4	B49	W/16	: To B140	A3	B425	B/2	: To B44
E2	B51	W/12	: To D201	A3	B426	W/16	: To B45
D2	B52	W/2	: Condenser-2	B3	B427	L/4	: Trailer tow relay 1
F2	B54	BR/12	: To B200	A3	B428	BR/6	: Trailer tow relay 2
B3	B55	B/24	: Automatic back door control module	B4	B431	L/4	: Trailer back-up relay
C3	B56	GR/14	: Automatic back door control module	Body no.3 sub harness			
D2	B58	W/20	: Pre-crash seat belt control unit (Driver side)	C5	B450	GR/6	: To B410
D3	B60	W/4	: Joint connector-B06	B5	B451	B/2	: To B411
B2	B61	W/4	: Joint connector-B18	A4	B452	B/12	: To B401
B2	B62	W/4	: Joint connector-B19	B5	B453	B/7	: Trailer
B2	B63	W/33	: Joint connector-B01	B5	B454	B/7	: Trailer receptacle
C3	B65	W/4	: Joint connector-B07	A4	B455	B/3	: Rear sonar sensor LH outer
B4	B67	W/16	: Awd control unit	C5	B456	B/3	: Rear sonar sensor RH outer
G2	B69	W/99	: To M40	A4	B457	B/3	: Rear sonar sensor LH inner
B1	B70	B/10	: Spindle unit LH	A5	B458	B/3	: Rear sonar sensor RH inner
C3	B71	Y/2	: Rear side air bag satellite sensor LH	Chassis harness			
E3	B72	GR/6	: Fuel level sensor and fuel pump	C4	C10	B/2	: Rear wheel sensor LH
C4	B73	GR/6	: Subwoofer	D4	C11	GR/2	: Rear wheel sensor RH
G3	B74	W/12	: To B220	D4	C12	GR/2	: AWD solenoid
D3	B75	W/16	: To B145	D4	C13	B/14	: To B13

A

B

C

D

E

F

G

H

I

J

K

L

PG

N


O

P

# HARNESS

< WIRING DIAGRAM >

BODY NO. 2 HARNESS



ABMIA4834ZZ

D1	B101	W/32	: To M84	D4	B145	W/16	: To B75
E4	B102	W/4	: Joint connector-B14	G3	B146	W/4	: Joint connector-B12
F4	B103	W/4	: Joint connector-B15	G4	B147	W/4	: Joint connector-B13
F4	B104	W/16	: ADAS control unit	F3	B152	—	: Body ground
E3	B105	W/6	: 2nd row seat heater RH	F2	B153	BR/2	: Rear side speaker RH

# HARNESS


## < WIRING DIAGRAM >

D1	B106	GR/1	: To M8	C2	B157	W/12	: To B300	
C1	B107	W/24	: To M9	G3	B158	—	: Body ground	A
E2	B108	W/4	: Front door switch RH	D2	B159	W/4	: Joint connector-B21	
G4	B109	B/6	: Side radar RH	E3	B160	W/20	: Pre-crash seat belt control unit (Passenger side)	B
B3	B110	W/24	: Front seat RH (Pre-wiring)	C1	B161	W/16	: To M157	
C1	B111	BR/16	: To M10	F2	B162	B/10	: Spindle unit RH	C
E3	B112	O/2	: Front RH seat belt pre-tensioner	F3	B169	W/4	: Joint connector-B04	D
B2	B113	Y/14	: Air bag diagnosis sensor unit	F3	B170	Y/2	: Rear side air bag satellite sensor RH	
E3	B114	Y/2	: Front side air bag satellite sensor RH	Front seat RH harness				
G3	B115	W/33	: Joint connector-B08	C2	B300	W/12	: To B157	
F3	B116	W/4	: Rear door switch RH	C2	B301	W/24	: To B137	E
F2	B117	—	: Body ground	D2	B302	—	: Headrest display unit (Passenger seat)	F
E4	B120	W/40	: BOSE speaker amp. (With surround sound system)	C3	B303	W/4	: Seat belt buckle switch (Passenger seat)	
D4	B121	BR/14	: BOSE speaker amp. (With surround sound system)	C3	B304	B/6	: Climate controlled seat control unit (Passenger seat)	G
E4	B122	BR/23	: BOSE speaker amp. (With surround sound system)	C3	B305	B/8	: Climate controlled seat control unit (Passenger seat)	H
D2	B123	W/4	: To B350	D3	B306	B/16	: Climate controlled seat control unit (Passenger seat)	I
B3	B124	W/32	: To B32	D3	B307	W/5	: Climate controlled seat blower motor (Passenger seat)	J
C2	B126	Y/2	: Front RH side air bag module	E2	B308	W/4	: Seat cushion thermal electric device (Passenger seat)	K
E2	B127	Y/2	: Front RH seat belt pre-tensioner	D3	B309	W/4	: Seat back thermal electric device (Passenger seat)	L
F1	B128	Y/2	: RH side curtain air bag module	D3	B310	W/6	: Lifting motor RH (Rear)	
D4	B129	BR/14	: BOSE speaker amp. (Without surround sound system)	D2	B311	W/6	: Reclining motor RH	PG
D4	B130	BR/23	: BOSE speaker amp. (Without surround sound system)	D2	B313	W/10	: Power seat switch RH	N
F4	B132	—	: Body ground	D3	B314	W/5	: Sliding motor RH	O
F3	B133	W/4	: Rear blower motor resistor 2	C2	B315	W/3	: Front seat heater (Passenger seat)	P
G4	B134	W/2	: Rear blower motor 2	ODS sub harness				
C1	B136	W/40	: To M36	D2	B350	W/4	: To B123	
C3	B137	W/24	: To B301	C3	B351	B/3	: Occupant classification system sensor (FL)	
E2	B139	W/12	: To D301	D2	B352	P/3	: Occupant classification system sensor (FR)	
E5	B140	W/16	: To B49	D3	B356	P/20	: Occupant classification system control unit	
D4	B144	W/4	: Joint connector-B11					

# HARNESS

< WIRING DIAGRAM >

ROOM LAMP HARNESS



AAMIA0130ZZ


B5	R1	W/24	: To M1	A3	R102	W/2	: Vanity lamp RH
C5	R2	W/6	: To M2	C4	R103	W/2	: Vanity lamp LH
B4	R4	GR/10	: Moonroof motor assembly	F1	R104	W/3	: Cargo lamp
B4	R5	W/8	: Lane camera unit	C3	R105	W/8	: Telematics switch
B4	R10	B/10	: Auto anti-dazzling inside mirror	E3	R106	W/4	: Personal lamps 2nd row

# HARNESS

## < WIRING DIAGRAM >

C4	R11	W/24	: To R101	B3	R107	GR/8	: Front room/map lamp assembly
A4	R12	B/3	: Rain sensor	B4	R108	W/8	: Moonroof switch
Room lamp sub harness				B3	R109	W/4	: Microphone
C4	R101	W/24	: To R11	C3	R110	W/4	: Sunshade switch

## FRONT DOOR LH HARNESS




ABMIA4835ZZ

D2	W/16	: To M167	D19	W/24	: To D52
D3	W/40	: To M168	D20	W/24	: Door mirror LH (Side camera)
D4	W/12	: Door mirror LH (Without around view monitor)	D21	W/4	: Blind spot warning/blind spot intervention indicator LH
D5	GR/2	: Outside key antenna (Driver side)	D26	Y/2	: Front door satellite sensor LH
D6	W/24	: Door mirror LH (With around view monitor)	Front door LH sub harness		
D9	W/6	: Front power window motor LH	D51	W/16	: To D18
D11	W/2	: Front step lamp LH	D52	W/24	: To D19
D12	W/2	: Front door speaker LH	D53	W/8	: To D17
D13	Y/4	: To M169	D55	W/12	: Main power window and door lock/unlock switch (Power mirror remote control switch) (Without automatic drive positioner)
D14	GR/6	: Front door lock assembly LH	D56	W/16	: Main power window and door lock/unlock switch
D15	W/6	: Front outside handle assembly LH	D57	W/12	: Main power window and door lock/unlock switch (Power mirror remote control switch) (With automatic drive positioner)
D17	W/8	: To D53	D60	W/16	: Seat memory switch
D18	W/16	: To D51			

# HARNESS

< WIRING DIAGRAM >

FRONT DOOR RH HARNESS



ABMIA4852ZZ


D101	W/32	: To M91	D113	W/24	: Door mirror RH (Side camera)
D102	W/10	: To M158	D114	GR/6	: Front door lock actuator RH
D103	Y/4	: To M159	D115	W/6	: Front outside handle assembly RH
D104	W/6	: Front power window motor RH	D116	W/24	: Door mirror RH (With around view monitor)
D107	W/12	: Door mirror RH (Without around view monitor)	D118	GR/2	: Outside key antenna (Passenger side)
D109	W/2	: Front step lamp RH	D126	Y/2	: Front door satellite sensor RH
D110	W/10	: To D151	Front door RH sub harness		
D111	W/4	: Blind spot warning/blind spot intervention indicator RH	D151	W/10	: To D110
D112	W/2	: Front door speaker RH	D157	W/16	: Power window and door lock/unlock switch RH

# HARNESS

< WIRING DIAGRAM >

REAR DOOR LH HARNESS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L



AAMIA0133ZZ

D201	W/12	: To B51	D207	BR/2	: Rear door speaker LH (With BOSE audio system)
D202	W/12	: To D251			Rear door LH sub harness
D204	W/6	: Rear power window motor LH	D251	W/12	: To D202
D205	GR/6	: Rear door lock actuator LH	D252	BR/2	: Rear door tweeter LH
D206	W/2	: Rear door speaker LH (With base audio system)	D256	W/16	: Rear power window switch LH

PG

N


O

P

# HARNESS

< WIRING DIAGRAM >

REAR DOOR RH HARNESS




AAMIA0134ZZ

D301	W/12	: To B139	D307	BR/2	: Rear door speaker RH (With BOSE audio system)		
D302	W/12	: To D351	Rear door RH sub harness				
D304	W/6	: Rear power window motor RH	D351	W/12	: To D302		
D305	GR/6	: Rear door lock actuator RH	D352	BR/2	: Rear door tweeter RH		
D306	W/2	: Rear door speaker RH (With base audio system)	D356	W/16	: Rear power window switch RH		

# HARNESS

< WIRING DIAGRAM >

BACK DOOR



AAMIA0135ZZ

A2	D501	W/24	: To B46	D4	D550	W/6	: To D505
A1	D502	GR/8	: To B47	D4	D551	W/6	: To D506
C1	D503	BR/2	: High-mounted stop lamp	D4	D552	W/16	: To D507
D3	D504	W/4	: Rear view camera (Without NAVI)	E3	D553	W/3	: Rear wiper motor
C5	D505	W/6	: To D550	D3	D554	W/4	: Joint connector-D01

# HARNESS

## < WIRING DIAGRAM >

C5	D506	W/6	: To D551	G4	D555	GR/2	: Touch sensor RH
B4	D507	W/16	: To D552	B5	D556	W/2	: Touch sensor LH
B4	D508	B/1	: Rear window defogger condenser	D5	D557	W/8	: Back door lock assembly
A4	D509	B/1	: Rear window defogger condenser	F4	D558	B/2	: Diode-2
B3	D510	B/1	: Rear window defogger	E4	D559	W/4	: Back door opener switch
D3	D511	W/8	: Rear view camera (With NAVI)	D5	D560	B/8	: Automatic back door close switch
F3	D513	—	: Body ground	D4	D561	BR/2	: License plate lamp LH
C3	D514	—	: Body ground	E4	D562	BR/2	: License plate lamp RH
F2	D525	B/1	: Rear window defogger	B5	D563	W/2	: Back-up lamp RH
Back door RH harness				G3	D564	W/2	: Back-up lamp LH

# ELECTRICAL UNITS LOCATION



< WIRING DIAGRAM >

## ELECTRICAL UNITS LOCATION

### Electrical Units Location

INFOID:0000000009131090

### ENGINE COMPARTMENT



A

B

C

D

E

F

G

H

I

J

K


L

PG

N

O

P







ABMIA4814GB

# ELECTRICAL UNITS LOCATION

< WIRING DIAGRAM >








PASSENGER COMPARTMENT



AAMIA1069GB

# ELECTRICAL UNITS LOCATION

< WIRING DIAGRAM >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

PG

N  
O  
P

AAMIA1070GB

# HARNESS CONNECTOR

< WIRING DIAGRAM >

## HARNESS CONNECTOR

### Description

INFOID:0000000009131091

#### HARNESS CONNECTOR (TAB-LOCKING TYPE)


- The tab-locking type connectors help prevent accidental looseness or disconnection.
- The tab-locking type connectors are disconnected by pushing or lifting the locking tab(s). Refer to the figure below.

Refer to the next page for description of the slide-locking type connector.

#### CAUTION:

Do not pull the harness or wires when disconnecting the connector.

[Example]



SEL769DA

#### HARNESS CONNECTOR (SLIDE-LOCKING TYPE)

- A new style slide-locking type connector is used on certain systems and components, especially those related to OBD.
- The slide-locking type connectors help prevent incomplete locking and accidental looseness or disconnection.

# HARNESS CONNECTOR


## < WIRING DIAGRAM >

- The slide-locking type connectors are disconnected by pushing or pulling the slider. Refer to the figure below.

### CAUTION:

- Do not pull the harness or wires when disconnecting the connector.
- Be careful not to damage the connector support bracket when disconnecting the connector.

[Example]



## HARNESS CONNECTOR (LEVER LOCKING TYPE)

- Lever locking type harness connectors are used on certain control units and control modules such as ECM, ABS actuator and electric unit (control unit), etc.
- Lever locking type harness connectors are also used on super multiple junction (SMJ) connectors.
- Always confirm the lever is fully locked in place by moving the lever as far as it will go to ensure full connection.


### CAUTION:

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
PG  
N  
O  
P

## HARNESS CONNECTOR

### < WIRING DIAGRAM >

- Always confirm the lever is fully released (loosened) before attempting to disconnect or connect these connectors to avoid damage to the connector housing or terminals.




- |                                   |                                 |                  |
|-----------------------------------|---------------------------------|------------------|
| 1. Control unit with single lever | 2. Control unit with dual lever | 3. SMJ connector |
| A. Fasten                         | A. Lever                        | A. Lever         |
| B. Loosen                         | B. Fasten                       | B. Fasten        |
| C. Lever                          | C. Loosen                       | C. Loosen        |

### HARNESS CONNECTOR (DIRECT-CONNECT SRS COMPONENT TYPE)

- SRS direct-connect type harness connectors are used on certain SRS components such as air bag modules and seat belt pre-tensioners.
- Always pull up to release black locking tab prior to removing connector from SRS components.
- Always push down to lock black locking tab after installing connector to SRS components. When locked, the black locking tab is level with the connector housing.

#### CAUTION:

- Do not pull the harness or wires when removing connectors from SRS components.



# STANDARDIZED RELAY

< WIRING DIAGRAM >


## STANDARDIZED RELAY

### Description

INFOID:0000000009131092

### NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

### TYPE OF STANDARDIZED RELAYS















1M ..... 1 Make  
1T ..... 1 Transfer      2M ..... 2 Make  
              1M-1B ..... 1 Make 1 Break



SEL882H

# STANDARDIZED RELAY

< WIRING DIAGRAM >

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M•1B				GRAY
1M				BLUE
				

The arrangement of terminal numbers on the actual relays may differ from those shown above.

SEL188W



# FUSE BLOCK - JUNCTION BOX (J/B)

< WIRING DIAGRAM >

## FUSE BLOCK - JUNCTION BOX (J/B)

### Terminal Arrangement

INFOID:0000000009131093



ABMIA4815GB

# FUSE, FUSIBLE LINK AND RELAY BOX


< WIRING DIAGRAM >

## FUSE, FUSIBLE LINK AND RELAY BOX


### Terminal Arrangement

INFOID:0000000009131094

### FUSE AND FUSIBLE LINK BOX



FUSIBLE LINK BOX (BATTERY)




ABMIA4816GB

# FUSE, FUSIBLE LINK AND RELAY BOX

< WIRING DIAGRAM >

## FUSE AND RELAY BOX 1



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

PG


N  
O  
P

ABMIA4817GB

## FUSE, FUSIBLE LINK AND RELAY BOX

< WIRING DIAGRAM >

FUSE AND RELAY BOX 2




ABMIA4818GB

# FUSE, FUSIBLE LINK AND RELAY BOX

< WIRING DIAGRAM >

## RELAY BOX



PG

ABMIA4819GB


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< WIRING DIAGRAM >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

### IPDM E/R Terminal Arrangement

INFOID:0000000009131095



#### NOTE:

Numbers preceded by an "F" represent the fuse numbers imprinted on the IPDM E/R. The other numbers represent the fuse numbers as they appear in the wiring diagrams.

ABMIA4820ZZ

&lt; BASIC INSPECTION &gt;

## BASIC INSPECTION

### BATTERY

#### How to Handle Battery

INFOID:000000009131096


**CAUTION:**

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.


#### METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level. This also applies to batteries designated as "low maintenance" and "maintenance-free".



- When the vehicle is not going to be used over a long period of time, disconnect the battery cable from the negative terminal. (If the vehicle has an extended storage switch, turn it off.)



#### Work Flow

INFOID:000000009131097

PG

##### BATTERY DIAGNOSIS WITH EXP-800 NI OR GR8-1200 NI

To diagnose and confirm the condition of the battery, use the following special service tools:

- EXP-800 NI Battery and electrical diagnostic analyzer
- GR8-1200 NI Multitasking battery and electrical diagnostic station

**NOTE:**

Refer to the applicable Instruction Manual for proper battery diagnosis procedures.

##### BATTERY DIAGNOSIS WITHOUT EXP-800 NI OR GR8-1200 NI

###### Checking Electrolyte Level


**WARNING:**

Never allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, never touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention. Failure to do this may cause personal injury or damage to clothing or the painted surfaces.

# BATTERY


## < BASIC INSPECTION >

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.



## SULFATION

- A battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulfation on the cell plates.
- To determine if a battery has been "sulfated", note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulfated batteries.
- A sulfated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.




## Specific Gravity Check

### NOTE:

Check the charge condition of the battery.

Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

1. Read hydrometer and thermometer indications at eye level.
2. Use the chart below to correct your hydrometer reading according to electrolyte temperature.



## Hydrometer Temperature Correction

Battery electrolyte temperature [°C (°F)]	Add to specific gravity reading
71 (160)	0.032
66 (150)	0.028
60 (140)	0.024
54 (130)	0.020
49 (120)	0.016
43 (110)	0.012
38 (100)	0.008
32 (90)	0.004
27 (80)	0
21 (70)	-0.004
16 (60)	-0.008
10 (50)	-0.012

# BATTERY

## < BASIC INSPECTION >

Battery electrolyte temperature [°C (°F)]	Add to specific gravity reading
4 (40)	-0.016
-1 (30)	-0.020
-7 (20)	-0.024
-12 (10)	-0.028
-18 (0)	-0.032

Corrected specific gravity	Approximate charge condition
1.260 - 1.280	Fully charged
1.230 - 1.250	3/4 charged
1.200 - 1.220	1/2 charged
1.170 - 1.190	1/4 charged
1.140 - 1.160	Almost discharged
1.110 - 1.130	Completely discharged

## Charging The Battery

### CAUTION:

- Never “quick charge” a fully discharged battery.
- Keep the battery away from open flame while it is being charged.
- When connecting the charger, connect the leads first, then turn on the charger. Never turn on the charger first, as this may cause a spark.
- If battery electrolyte temperature rises above 55 °C (131 °F), stop charging. Always charge battery at a temperature below 55 °C (131 °F).

## Charging Rates (Standard Charge)

Approximate charge condition	Charge current (A)	Charge time (h)
Fully charged	7	2
3/4 charged		2.5
1/2 charged		5
1/4 charged		7.5
Almost discharged		9
Completely discharged		10

## Charging Rates (Quick Charge)

Approximate charge condition	Charge current (A)	Charge time (h)
Fully charged	—	—
3/4 charged	16	0.5
1/2 charged		
1/4 charged		
Almost discharged		
Completely discharged	—	—

### NOTE:

The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than 0.050, the battery should be replaced.

A

B

C

D

E

F

G

H

I

J

K

L

PG

N

O

P

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

### ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000009131098

Required Procedure After Battery Disconnection

System	Item	Reference
Engine Control System	Idle Air Volume Learning	<a href="#">EC-153</a>
Brake Control System	Steering Angle Sensor Neutral Position	<a href="#">BRC-60</a>
Power Window Control System	Power Window System Initialization	<a href="#">PWC-35</a>
Roof	Moonroof Memory Reset/Initialization Sunshade Memory Reset/Initialization	<a href="#">RF-24</a>
Automatic Drive Positioner	Automatic Drive Positioner System Initialization	Refer to Owner's Manual.
Heater & Air Conditioning Control System	Temperature Setting Trimmer (front)	<a href="#">HAC-83</a>
	Temperature Setting Trimmer (rear)	<a href="#">HAC-84</a>
	Foot Position Setting Trimmer	<a href="#">HAC-83</a>
	Inlet Port Memory Function (FRE)	<a href="#">HAC-84</a>
	Inlet Port Memory Function (REC)	<a href="#">HAC-84</a>
	Exhaust Gas/Outside Odor Detecting Sensor Sensitivity Adjustment Function	<a href="#">HAC-85</a>
	Auto Intake Switch Interlocking Movement Change Function	<a href="#">HAC-85</a>
Audio, Visual & Navigation System	Audio (Radio Preset)	Refer to Owner's Manual.
	Navigation System	Refer to Owner's Manual.


# BATTERY

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION BATTERY

### Exploded View

INFOID:000000009131099



- |                      |                         |                       |
|----------------------|-------------------------|-----------------------|
| 1. Upper ECM bracket | 2. Battery frame        | 3. Battery            |
| 4. Battery rods      | 5. Battery cover        | 6. Battery tray liner |
| 7. Battery tray      | 8. Battery tray support | Front                 |

### Removal and Installation

INFOID:000000009131100

PG

#### REMOVAL

1. Remove cover of battery positive terminal.
2. Loosen battery terminal nuts and disconnect both negative and positive terminals from the battery.  
**CAUTION:**  
**To prevent damage to the parts, disconnect the battery negative terminal first.**
3. Remove battery frame nuts, battery frame and battery rods.
4. Remove battery cover.
5. Remove battery.

#### INSTALLATION

Installation is in the reverse order of removal.

##### **CAUTION:**

**Replace the battery if it has been dropped or sustained and impact.**

**To install the battery, carefully read the following instructions:**

- **To prevent damage to the parts, connect the battery cable to the positive terminal first.**

## BATTERY

### < REMOVAL AND INSTALLATION >

- After connecting battery cables, to securely supply battery voltage, ensure that they are tightly clamped to battery terminals for good contact.
- To securely supply battery voltage, check battery terminal for poor connection caused by corrosion. Reset electronic systems as necessary. Refer to [PG-92, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

## BATTERY TRAY

< REMOVAL AND INSTALLATION >

### BATTERY TRAY

#### Removal and Installation

INFOID:000000009131101

##### REMOVAL

1. Remove battery and battery tray liner. Refer to [PG-93, "Removal and Installation"](#).
2. Remove air cleaner assembly. Refer to [EM-24, "Removal and Installation"](#).
3. Disconnect harness connector and then remove ECM.
4. Disconnect the harness connector from the transmission control module (TCM). Refer to [TM-193, "Exploded View"](#).
5. Remove the ECM bracket.
6. Remove the battery tray bolts and battery tray.
7. Remove the battery tray support bolts and battery tray support.

##### INSTALLATION

Installation is in the reverse order of removal.

Reset electronic systems as necessary. Refer to [PG-92, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

A

B

C

D

E

F

G

H

I

J

K

L

PG

M

N

O

P


# BATTERY TERMINAL WITH FUSIBLE LINK

< REMOVAL AND INSTALLATION >

## BATTERY TERMINAL WITH FUSIBLE LINK

### Exploded View

INFOID:0000000009729275



1. Fusible link box (battery)
2. Positive Terminal
3. Battery
4. Harness connectors
5. Positive cable
6. Cover
- A. Fusible link box (battery) nut
- B. Positive cable nut

Front

### Removal and Installation

INFOID:0000000009729276

#### REMOVAL

1. Loosen battery terminal nuts and disconnect both negative and positive terminals from the battery.  
**CAUTION:**  
**To prevent damage to the parts, disconnect the battery negative terminal first.**
2. Disconnect positive cable from fusible link box (battery).
3. Disconnect harness connectors and separate positive terminal from fusible link box (battery).

#### INSTALLATION

Installation is in the reverse order of removal.

##### CAUTION:

Replace the fusible link box battery if it has been dropped or sustained and impact.

To install the battery, carefully read the following instructions:

- To prevent damage to the parts, connect the battery cable to the positive terminal first.
  - After connecting battery cables, to securely supply battery voltage, ensure that they are tightly clamped to battery terminals for good contact.
  - To securely supply battery voltage, check battery terminal for poor connection caused by corrosion.
- Reset electronic systems as necessary. Refer to [PG-92, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).


# BATTERY CURRENT SENSOR

< REMOVAL AND INSTALLATION >

## BATTERY CURRENT SENSOR

### Exploded View

INFOID:000000009729277



1. Negative terminal
2. Current sensor
3. Harness connector
4. Negative cable

Front

### Removal and Installation

INFOID:000000009729278

#### REMOVAL

1. Disconnect negative terminal from the battery.
2. Disconnect harness connector from current sensor.
3. Remove nut and separate current sensor from the negative terminal.
4. Remove nut and separate negative cable from the current sensor and remove the current sensor.

#### INSTALLATION

Installation is in the reverse order of removal.

#### CAUTION:

Replace the battery current sensor if it has been dropped or sustained and impact.

To install the battery, carefully read the following instructions:

- To prevent damage to the parts, connect the battery cable to the positive terminal first.
- After connecting battery cables, to securely supply battery voltage, ensure that they are tightly clamped to battery terminals for good contact.
- To securely supply battery voltage, check battery terminal for poor connection caused by corrosion. Reset electronic systems as necessary. Refer to [PG-92, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

PG

## **SERVICE DATA AND SPECIFICATIONS (SDS)**

< SERVICE DATA AND SPECIFICATIONS (SDS)

# **SERVICE DATA AND SPECIFICATIONS (SDS)**

## **SERVICE DATA AND SPECIFICATIONS (SDS)**

### **Battery**

INFOID:000000009131102

Type*	GR35
Capacity (20HR) minimum V-AH	12 - 60
Cold cranking current A @ -18°C (0°F)	550

\*: Always check with the Parts Department for the latest parts information.