

Contents A-Z

# **OWNER'S MANUAL.**

MINI.



#### MINI Owner's Manual for Vehicle

Thank you for choosing a MINI.

The more familiar you are with your vehicle, the better control you will have on the road. We therefore strongly suggest:

Read this Owner's Manual before starting off in your new MINI. Also use the Integrated Owner's Manual in your vehicle. It contains important information on vehicle operation that will help you make full use of the technical features available in your MINI. The manual also contains information designed to enhance operating reliability and road safety, and to contribute to maintaining the value of your MINI.

Any updates made after the editorial deadline can be found in the appendix of the printed Owner's Handbook for the Vehicle.

Get started now. We wish you driving fun and inspiration with your MINI

The MINI team of BMW AG

© 2015 Bayerische Motoren Werke Aktiengesellschaft Munich, Germany Reprinting, including excerpts, only with the written consent of BMW AG, Munich. US English II/15, 03 15 490 Printed on environmentally friendly paper, bleached without chlorine, suitable for recycling.

#### ADDENDUM TO OWNER'S MANUAL

We wanted to provide you with some updates and clarifications with respect to the printed MINI Owner's Manual. These updates and clarifications will supersede the materials contained in that document.

- Where the terms "service center," "the service center," "your service center," "service specialist," or "service" are used in the Owner's Manual, we wanted to clarify that the terms refer to a MINI dealer's service center or another service center or repair shop that employs trained personnel that can perform maintenance and repair work on your vehicle in accordance with MINI specifications.
- 2. Where the text of the Owner's Manual contains an affirmative instruction to contact a "service center" or "your service center," we wanted to clarify that MINI recommends that, if you are faced with one of the situations addressed by that text, you contact or seek the assistance of a MINI dealer's service center or another service center or repair shop that employs trained personnel that can perform maintenance and repair work on your vehicle in accordance with MINI specifications.
  - While MINI, at no cost to you, will pay for repairs required by the limited warranties provided with respect to your vehicle and for maintenance under the Maintenance Program during the applicable warranty and maintenance coverage periods, you are free to elect, both during those periods and thereafter, to have maintenance and repair work provided by other service centers or repair shops.
- Where the Owner's Manual makes reference to parts and accessories having been approved by MINI, those references are intended to reflect that those parts and accessories are recommended by MINI. You may elect to use other parts and accessories, but, if you do, we recommend that you make sure

- that any such parts and/or accessories are appropriate for use on your vehicle.
- 4. At page 7, under the warranty section's discussion of homologation, where it states that you "cannot lodge warranty claims for your vehicle there," the text should read that you "may not be able to lodge warranty claims for your vehicle there."
- 5. At page 7, in the "Parts and Accessories" section, the sentence beginning "For your own safety, use ...," should be disregarded and the following the text should be read in lieu thereof: "The manufacturer of your vehicle recommends using genuine MINI parts and accessories."
  - In the fifth sentence of that paragraph, the word "cannot" should read "does not."
- 6. At page 51, in the "Check and replace safety belts" section, the text beginning, "This should only be done by your service center ..." should be disregarded and the following text should be read in lieu thereof: "MINI recommends having this work performed by a service center as it is important that this safety feature functions properly."
- 7. At page 155 under the heading: "Objects in the area around the pedals" and at page 217 under the heading: "Carpets and floor mats," the paragraph that begins: "Only use floor mats ..." should be disregarded and the following language should be read in lieu thereof: "The manufacturer of your vehicle recommends that you use floor mats that have been identified by it as appropriate for use in your vehicle and that can be properly fixed in place."
- 8. At page 162, under the heading: "Have maintenance carried out," the sentence beginning, "Have the maintenance carried out ..." should be disregarded and the following text should be read in lieu thereof: "MINI recommends that you have the maintenance carried out by your service center."

- At page 174, under the heading "Pressure specifications," the sentence beginning, "Pressure specifications apply to approved tire sizes ..." should be disregarded.
- 10. At page 181, under the heading: "Mounting," the paragraph beginning, "Have mounting and balancing ..." should be disregarded and the following text should be read in lieu thereof: "BMW recommends that you have mounting and balancing performed by your service center or a tire mounting specialist."
- 11. At page 181, under the heading: "Approved wheels and tires," the term "Approved" should be disregarded and in lieu thereof, the term "Recommended" should be read in its place. In addition, the text of that section should be disregarded and the following text should be read in lieu thereof:

The manufacturer of your vehicle strongly suggests that you use wheels and tires that have been recommended by the vehicle manufacturer for your vehicle type; otherwise, for example, despite having the same official size ratings, variations can lead to body contact and with it, the risk of severe accidents.

The manufacturer of your vehicle does not evaluate non-recommended wheels and tires to determine if they are suitable for use on your vehicle.

12. At page 186, under the heading: "Snow Chains," the paragraph beginning, "Only certain fine-link snow chains ..." should be disregarded and the following text should be read in lieu thereof:

Only certain types of fine-link snow chains have been tested by the manufacturer of your vehicle and are determined by the manufacturer of your vehicle to be road safe and are recommended by the manufacturer of your vehicle.

Information about recommended snow chains is available from a service center.

13. At page 188, under the heading "Hood," the sentence beginning, "If you are unfamiliar" should be disregarded.

14. At page 192, under the heading: "Engine oil

- change," the text should be disregarded and in lieu thereof should be read as follows:

  MINI recommends that you have the oil changed at your MINI dealer's service center or at another service center that has trained personnel that can perform the work in ac-
- 15. At page 195, under the heading: "Service and Warranty Information Booklet for US Models and Warranty and Service Guide Booklet for Canadian Models," the second paragraph should be disregarded and the following text read in lieu thereof:

cordance with MINI specifications.

The manufacturer of your vehicle recommends that you have maintenance and repair performed by your MINI dealer's service center or another service center or repair shop that employs trained personnel that can perform maintenance and repair work on your vehicle in accordance with MINI specifications. The manufacturer of your vehicle recommends that you maintain records of all maintenance and repair work performed on your vehicle.

16. At page 207, under the "Battery replacement" section, the text should be disregarded and in lieu thereof the following text should be read:

Use of recommended vehicle batteries

The manufacturer of your vehicle recommends that you use vehicle batteries that it has tested and recommends for use in your vehicle; otherwise the vehicle could be damaged and systems or functions may not be fully available.

After a battery replacement, the manufacturer of your vehicle recommends that you have the battery registered on your vehicle by a service center to ensure that all comfort functions are fully available, and that any

"check control" messages of these comfort functions are no longer displayed.

# **CONTENTS**

The fastest way to find information on a particular topic or item is by using the index, refer to page 230.

6 Notes

#### **AT A GLANCE**

- 14 Cockpit
- 18 Onboard monitor
- 27 Voice activation system
- 30 Integrated Owner's Manual in the vehicle

#### **CONTROLS**

- 34 Opening and closing
- 48 Adjusting
- 56 Transporting children safely
- 60 Driving
- 72 Displays
- 90 Lights
- 95 Safety
- 111 Driving stability control systems
- 115 Driving comfort
- 132 Climate control
- 139 Interior equipment
- 141 Digital compass
- 147 Storage compartments

#### **DRIVING TIPS**

- 154 Things to remember when driving
- 157 Loading
- 161 Saving fuel

#### **MOBILITY**

- 170 Refueling
- **172** Fuel
- 174 Wheels and tires
- 188 Engine compartment
- 190 Engine oil
- 193 Coolant
- 195 Maintenance
- 197 Replacing components
- 209 Breakdown assistance
- 214 Care

#### REFERENCE

- 220 Technical data
- 225 Appendix
- 230 Everything from A to Z

# **NOTES**

# USING THIS OWNER'S MANUAL

The fastest way to find information on a particular topic is by using the index.

An initial overview of the vehicle is provided in the first chapter.

# Updates made after the editorial deadline

Any updates made after the editorial deadline can be found in the appendix of the printed Owner's Handbook for Vehicle.

# User's manual for Navigation, Entertainment, Communication

The topics Navigation, Entertainment, Communication and the short commands of the voice activation system can be retrieved on the Control Display via the Integrated Owner's Handbook.

#### Additional sources of information

Should you have any questions, your service center will be glad to advise you at any time.

Information about MINI, e.g., on technology, is available on the Internet: www.miniusa.com

### **SYMBOLS**

- ⚠ Indicates precautions that must be followed precisely in order to avoid the possibility of personal injury and serious damage to the vehicle.
- → Marks the end of a specific item of information.
- "..." Identifies Control Display texts used to select individual functions.

- >.... Verbal instructions to use with the voice activation system..
- »...« Identifies the answers generated by the voice activation system.
- Refers to measures that can be taken to help protect the environment.

#### Symbols on vehicle components

Il Indicates that you should consult the relevant section of this Owner's Manual for information on a particular part or assembly.

# VEHICLE FEATURES AND OP-TIONS

This Owner's Manual describes all models and all standard, country-specific and optional equipment that is offered in the model series. Therefore, in this Owner's Manual, we also describe and illustrate features that are not available in your vehicle, e.g., because of the selected optional features or the country-specific version.

This also applies to safety-related functions and systems.

The respectively applicable country provisions must be observed when using the respective features and systems.

For any options and equipment not described in this Owner's Handbook, refer to the Supplementary Owner's Handbooks.

On right-hand drive vehicles, some controls are arranged differently from what is shown in the illustrations.

# STATUS OF THE OWNER'S MANUAL

#### **Basic information**

The manufacturer of your vehicle pursues a policy of constant development that is conceived to ensure that our vehicles continue to embody the highest quality and safety standards. In rare cases, therefore, the features described in this Owner's Manual may differ from those in your vehicle.

# Updates made after the editorial deadline

Any updates made after the editorial deadline can be found in the appendix of the printed Owner's Handbook for Vehicle.

#### **OWN SAFETY**

#### Manufacturer

The manufacturer of this MINI is Bayerische Motoren Werke Aktionengesellschaft, BMW AG.

#### Warranty

Your vehicle is technically configured for the operating conditions and registration requirements applying in the country of first delivery homologation. If your vehicle is to be operated in a different country it might be necessary to adapt your vehicle to potentially differing operating conditions and permit requirements. If your vehicle does not comply with the homologation requirements in a certain country you cannot lodge warranty claims for your vehicle there. Further information can be obtained from your Service Centre.

# Maintenance and repairs

Advanced technology, e.g., the use of modern materials and high-performance electronics, requires suitable maintenance and repair work.

Therefore, have this work performed only by a MINI service center or a workshop that works according to the manufacturer's repair procedures for the MINI with respectively trained personnel.

If work is not carried out properly, there is a danger of subsequent damage and related safety hazards.

#### **Parts and Accessories**

For your own safety, it is recommended that you use genuine parts and accessories approved by MINI. When you purchase accessories tested and approved by MINI and Genuine MINI Parts, you simultaneously acquire the assurance that they have been thoroughly tested by MINI to ensure optimum performance when installed on your vehicle. MINI warrants these parts to be free from defects in material and workmanship. MINI will not accept any liability for damage resulting from installation of parts and accessories not approved by MINI. MINI cannot test every product made by other manufacturers to verify if it can be used on a MINI safely and without risk to either the vehicle, its operation, or its occupants. Genuine MINI Parts, MINI Accessories and other products approved by MINI, together with professional advice on using these items, are available from all MINI centers. Installation and operation of non-MINI approved accessories such as alarms, radios. amplifiers, radar detectors, wheels, suspension components, brake dust shields, telephones, including operation of any mobile phone from within the vehicle without using an externally mounted antenna, or transceiver equipment, for instance, CBs, walkie-talkies, ham radios or similar accessories, may cause extensive damage to the vehicle, compromise its safety, interfere with the vehicle's electrical system or affect the validity of the MINI Limited Warranty. See your MINI center for additional information. Maintenance, replacement, or repair of the emission control devices and systems may be performed by any automotive repair establishment or individual using any certified automotive part.

#### **California Proposition 65 Warning**

California laws require us to state the following warning:

Engine exhaust and a wide variety of automobile components and parts, including components found in the interior furnishings in a vehicle, contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Battery posts, terminals and related accessories contain lead and lead compounds. Wash your hands after handling. Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water.

### Service and warranty

We recommend that you read this publication thoroughly. Your vehicle is covered by the following warranties:

- New Vehicle Limited Warranty.
- Rust Perforation Limited Warranty.
- ▶ Federal Emissions System Defect Warranty.
- Federal Emissions Performance Warranty.
- California Emission Control System Limited Warrantv.

Detailed information about these warranties is listed in the Service and Warranty Information Booklet for US models or in the Warranty and Service Guide Booklet for Canadian models.

Your vehicle has been specifically adapted and designed to meet the particular operating conditions and homologation requirements in your country and continental region in order to deliver the full driving pleasure while the vehicle is

operated under those conditions. If you wish to operate your vehicle in another country or region, you may be required to adapt your vehicle to meet different prevailing operating conditions and homologation requirements. You should also be aware of any applicable warranty limitations or exclusions for such country or region. In such case, please contact Customer Relations for further information.

#### Maintenance

Maintain the vehicle regularly to sustain the road safety, operational reliability and the New Vehicle Limited Warranty.

Specifications for required maintenance measures:

- MINI Maintenance system
- Service and Warranty Information Booklet for US models
- Warranty and Service Guide Booklet for Canadian models

If the vehicle is not maintained according to these specifications, this could result in serious damage to the vehicle. Such damage is not covered by the MINI New Vehicle Limited Warranty.

# **DATA MEMORY**

Many electronic components on your vehicle are equipped with data memories that temporarily or permanently store technical information about the condition of the vehicle, events and faults. This technical information generally records the state of a component, a module, a system or the environment:

- Operating mode of system components, fill levels for instance.
- Status messages for the vehicle and from its individual components, e.g., wheel rotation speed/vehicle speed, deceleration, transverse acceleration.

- Malfunctions and faults in important system components, e.g., lights and brakes.
- Responses by the vehicle to special situations such as airbag deployment or engaging the stability control system.
- ▶ Ambient conditions, such as temperature.

This data is purely technical in nature and is used to detect and correct faults and to optimize vehicle functions. Motion profiles over routes traveled cannot be created from this data. When service offerings are used, e.g., repair services, service processes, warranty claims, quality assurance, this technical information can be read out from the event and fault memories by the service personnel, including the manufacturer, using special diagnostic tools. You can obtain further information there if you need it. After an error is corrected, the information in the fault memory is deleted or overwritten on a continuous basis.

With the vehicle in use there are situations where you can associate these technical data with individuals if combined with other information, e.g., an accident report, damage to the vehicle, eye witness accounts — possibly with the assistance of an expert.

Additional functions that are contractually agreed with the customer - such as vehicle emergency locating - you can transmit certain vehicle data from the vehicle.

# **EVENT DATA RECORDER EDR**

This vehicle is equipped with an event data recorder EDR. The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating.
- ▶ Whether or not the driver and passenger safety belts were fastened.
- → How far, if at all, the driver was depressing the accelerator and/or brake pedal.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

EDR data are recorded by your vehicle only if a nontrivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data, e.g., name, gender, age, and crash location, are recorded.

However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

# VEHICLE IDENTIFICATION NUMBER



The vehicle identification number can be found in the engine compartment.

The vehicle identification number can also be found behind the windshield.

#### REPORTING SAFETY DEFECTS

#### For US customers

The following only applies to vehicles owned and operated in the US.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration NHTSA, in addition to notifying MINI of North America, LLC, P.O. Box 1227, Westwood, New Jersey 07675-1227, Telephone 1-800-831-1117.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign.

However, NHTSA cannot become involved in individual problems between you, your dealer, or MINI of North America, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov

#### For Canadian customers

Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls, may call the toll-free hotline 1-800-333-0510. You can also obtain other information about motor vehicle safety from http://www.tc.gc.ca/roadsafety.



# WATCH ME.

**AT A GLANCE** 

**CONTROLS** 

**DRIVING TIPS** 

**MOBILITY** 

**REFERENCE** 


# COCKPIT

# VEHICLE FEATURES AND OP-**TIONS**

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not

necessarily available in your car, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### ALL AROUND THE STEERING WHEEL



- Power windows 45
- Exterior mirror operation 53
- Central locking system 40 3
- 4 Lights



Front fog lights 93



Parking lights 90



Low beams 90



Automatic headlight control 91 Daytime running lights 91

Corner-illuminating lights 92

High-beam Assistant 92



Instrument lighting 93

Steering wheel buttons, left



Cruise control on/off, interrupt 115



Cruise control on/off, interrupt 121



Store speed 115, 121



Resume speed 117, 122



Set speed 117, 121



Reduce distance 121



Increase distance 115

6 Steering column stalk, left



Turn signal 65



High beams, headlight flasher 65



High-beam Assistant 92



Roadside parking lights 90



Computer 81

- 7 Instrument cluster 72
- 8 Steering column stalk, right



Windshield wipers 65



Rain sensor 66



Cleaning windows 67



Rear window wiper 67



Cleaning rear window 67

**9** Steering wheel buttons, right



Voice activation 27



Telephone



Confirm the selection 81



Move selection up 81



Move selection down 81




Increase volume



Reduce volume

- 10 Horn
- 11 Adjust the steering wheel 55
- 12 Unlock hood 188

### ALL AROUND THE CENTER CONSOLE



1



Hazard warning system 209



Intelligent Safety 103

- 2 Control Display 18
- 3 Radio/Multimedia
- 4 Glove compartment 147
- 5 Climate control 132



PDC Park Distance Control 123

Rearview camera 125

Parking assistant 127



Auto Start/Stop function 62



Start/stop the engine and switch the ignition on/off 63



DSC Dynamic Stability Control 111



Head-up Display 86

- Steptronic transmission selector lever 68
   Manual transmission selector lever 68
- 8 Controller with buttons 19
- 9 Parking brake 64
- 10 Driving Dynamics Control 113

# **ALL AROUND THE ROOFLINER**



1 808

**Emergency Request** 

4 💢

Ambient light 94

PASS AIR BAG OFF Indicator lamp, front-seat passenger airbag 97



Glass sunroof 46

<sup>3</sup> □⟨

Reading lights 94



Interior lights 93

# ONBOARD MONITOR

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### THE CONCEPT

The onboard monitor combines the functions of a multitude of switches. Thus, these functions can be operated from a central location.

Using the onboard monitor during a trip
To avoid becoming distracted and posing
an unnecessary hazard to your vehicle's occupants and to other traffic, never attempt to use
the controls or enter information unless traffic
and road conditions allow it.

# CONTROL ELEMENTS AT A GLANCE

#### **Control elements**



- Control Display
- 2 Controller with buttons and, depending on the equipment version, with touchpad

### **Control Display**

#### Hints

- To clean the Control Display, follow the care instructions.
- Do not place objects close to the Control Display; otherwise, the Control Display can be damaged.
- In the case of very high temperatures on the Control Display, e.g. due to intense solar radiation, the brightness may be reduced down to complete deactivation.
   Once the temperature is reduced, e.g. through shadow or climate control system, the normal functions are re-established.

## Switching on

- 1. Switch on the ignition.
- 2. Press the controller.

#### Switch off

- 1. OPTION Press
  - Press button.
- 2. "Turn off control display"



### Controller with navigation system

The buttons can be used to open the menus directly. The controller can be used to select menu items and enter the settings.

Some functions of the onboard monitor can be operated using the touchpad on the controller:

1. Turn.



#### Press.



#### 3. Move in four directions.



#### **Buttons on controller**

Press button	Function
MENU	Open the main menu.
RADIO	Opens the Radio menu.
MEDIA	Opens the Multimedia menu.
NAV	Opens the Navigation menu.
TEL	Opens the phone menu.
BACK	Displays the previous panel.
OPTION	Opens the Options menu.

### **Controller without navigation system**

The buttons can be used to open the menus directly. The controller can be used to select menu items and enter the settings.

1. Turn.



#### 2. Press.



Move in two directions.



#### **Buttons on controller**

Press button	Function
MENU	Open the main menu.
Audio	Open audio menu last listened to, switch between audio menus.
TEL	Opens the phone menu.
BACK	Open previous panel.
OPTION	Opens the Options menu.

## **OPERATING CONCEPT**

## Opening the main menu



Press button.




The main menu is displayed.

All onboard monitor functions can be called up via the main menu.

### Selecting menu items

Highlighted menu items can be selected.

1. Turn the controller until the desired menu item is highlighted.



2. Press the controller.

#### Menu items in the Owner's Manual

In the Owner's Manual, menu items that can be selected are set in quotation marks, e.g., "Settings".

### Changing between panels

After a menu item is selected, e.g., "Radio", a new panel is displayed. Panels can overlap.

Closes current display and shows previous display.

Reopens previous display by pressing BACK button. In this case, the current panel is not closed.

Move the controller to the right.
 Opens new display on top of previous screen.



Arrows pointing to the left or right indicate that additional panels can be opened.

#### Display of an opened menu

When selecting a menu, it generally opens with the panel that was last selected in that menu. To display the first panel of a menu:

- Move the controller to the left repeatedly until the first panel is displayed.
- Press the menu button on the controller twice.

### **Opening the Options menu**



Press button.

The "Options" menu is displayed.



Additional options: move the controller to the right repeatedly until the "Options" menu is displayed.


#### **Options menu**

The "Options" menu consists of various areas:

- Screen settings, e.g., "Split screen".This area remains unchanged.
- ▷ Control options for the selected main menu, e.g., for "Radio".
- ▶ If applicable, further operating options for the selected menu, e.g., "Store station".

#### **Changing settings**

- 1. Select a field.
- 2. Turn the controller until the desired setting is displayed.



Press the controller.

## Activating/deactivating the functions

Several menu items are preceded by a checkbox. It indicates whether the function is activated or deactivated. Selecting the menu item activates or deactivates the function.

Function is activated.

Function is deactivated.

# **TOUCHPAD**

Some functions of the onboard monitor can be operated using the touchpad on the controller:

## **Selecting functions**

On the Control Display:

1. Ø "Settings"

- 2. "Touchpad"
- Select the desired function.
  - "Speller": enter letters and numbers.
  - "Interactive map": viewing the interactive map.
  - "Audio feedback": pronounces entered letters and numbers.

#### **Entering letters and numbers**

Entering letters requires some practice at the beginning. When entering, pay attention to the following:

- For the input of upper/lower case letters and numbers, it may be necessary to switch via the controller to the corresponding Input mode, refer to page 25, e.g. when the spelling of upper and lower case letters is identical.
- ▷ Enter characters as they are displayed on the Control Display.
- ▷ Always enter associated characters, such as accents or periods so that the letter can be clearly recognized. Possible input depends on the set language. Where necessary, enter special characters via the controller.
- ➤ To delete a character, slide to the left on the touchpad.
- ▶ To enter a blank space, slide to the right in the center of the touchpad.
- ➤ To enter a hyphen, slide to the right in the upper area of the touchpad.
- ➤ To enter an underscore, swipe to the right in the lower area of the touchpad.

# Operating the interactive map

The interactive map in the navigation system can be moved via the touchpad.

Function	Controls
Interactive map.	Swipe into respective direction.
Enlarge/shrink in- teractive map.	Drag in or out on the touchpad with fingers.
teractive map.	touchpad with hingers.
Display menu.	Tap once.

#### **Changing settings**

You may change control display settings via touchpad. Swipe left or right accordingly.

# **EXAMPLE: SETTING THE CLOCK**

### Setting the clock


On the Control Display:

- 1. MENU Press button. The main menu is displayed.
- 2. Turn the controller until "Settings" is highlighted, and then press the controller.



- 3. If necessary, move the controller to the left to display "Time/Date".
- 4. Turn the controller until "Time/Date" is highlighted, and then press the controller.

5. Turn the controller until "Time:" is highlighted, and then press the controller.



- 6. Turn the controller to set the hours and press the controller.
- 7. Turn the controller to set the minutes and press the controller.

### **STATUS INFORMATION**

#### Status field

The following information is displayed in the status field at the top right:

- Time.
- Current entertainment source.
- ⊳ Sound output, on/off.
- ▶ Wireless network reception strength.
- Phone status.
- ▶ Traffic bulletin reception.

## Status field symbols

The symbols are grouped as follows.

# Radio symbols

Symbol	Meaning
H))	HD Radio station is being received.
1	Satellite radio is switched on.

#### **Telephone symbols**

Symbol	Meaning	
8	Incoming or outgoing call.	
<b>%</b>	Missed call.	
all	Wireless network reception strength.  Symbol flashes: network search.	
atl	Wireless network is not available.	
3	Bluetooth is switched on.	
	Roaming is active.	
$\boxtimes$	Text message was received.	
<b></b> ©	Check the SIM card.	
<b>■</b>	SIM card is blocked.	
<b>/</b>	SIM card is missing.	
( iii	Enter PIN.	

# **Entertainment symbols**

Symbol	Meaning
<b>€1</b> €6	DVD changer.
2	Music collection.
gracenote	Gracenote® database.
P	AUX-IN port.
ψ	USB audio interface.
Ø.	Mobile phone audio interface.

## **Additional symbols**

Symbol	Meaning
Ø	Spoken instructions are turned off.

#### SPLIT SCREEN

#### **General information**

Additional information can be displayed on the right side of the split screen, e.g., information from the on-board comupter.

In the divided screen view, the so-called split screen, this information remains visible even when you change to another menu.

# Switching the split screen on and off


On the Control Display:

- 1. Press button.
- 2. "Split screen"

### Selecting the display

On the Control Display:

- 1. Press button.
- 2. "Split screen"
- Move the controller until the split screen is selected.
- Press the controller or select "Split screen content".
- 5. Select the desired menu item.



# PROGRAMMABLE MEMORY BUTTONS

#### **General information**

The onboard monitor functions can be stored on the programmable memory buttons and called up directly, e.g., radio stations, navigation destinations, phone numbers and menu entries.

Settings are stored for the profile currently in use.

#### Saving a function

- 1. Highlight function via the onboard monitor.
- 2. Press and hold the desired button, until a signal sounds.

### **Running a function**

Press button.

The function will work immediately.

This means, e.g., that the number is dialed when a phone number is selected.

## Displaying the button assignment

Touch buttons with bare fingers. Do not wear gloves or use objects.

The key assignment is displayed at top edge of screen.



# **Deleting the button assignments**

1. Press buttons 1 and 6 simultaneously for approx. five seconds.

2. "OK"

# **DELETING PERSONAL IN THE VEHICLE**

#### The concept

Depending on the usage, the vehicle saves personal data, such as stored radio stations. These personal data can be permanently deleted via the onboard monitor

#### General information

Depending on the equipment package, the following data can be deleted:

- Personal Profile settings.
- Stored radio stations.
- Stored Favorites buttons.
- Travel and computer information.
- Music collection.
- **>** Navigation, e.g. stored destinations.
- Phone book.
- Online data, e.g. Favorites, cookies.
- Voice notes.
- Login accounts.

Altogether, the deletion of the data can take up to 30 minutes.

## **Functional requirement**

Data can only be deleted while stationary.

# **Deleting data**

Heed and follow the instructions on the Control Display.

- 1. Switch on the ignition.
- 2. 🐼 "Settings"
- 3. Open "Options".
- 4. "Delete all personal data"

- 5. "Continue"
- 6 "OK"

# **ENTERING LETTERS AND NUMBERS**

#### General information

On the Control Display:

- 1. Turn the controller: select letters or numhers
- 2. Select additional letters or numbers if needed
- 3. "OK": confirm the entry.

	Symbol	Function		
		Press the controller: delete the letter or number.		
	l←	Press the controller for an extended		

period: delete all letters or numbers.

# Switching between cases, letters and

Depending on the menu, you can switch between entering upper and lower case, letters and numbers:

Symbol	Function
A <sup>B</sup> C	Enter the letters.
1@+	Enter the numbers.
abc or ABC	Tip controller up.

# Without navigation system

## **Entry comparison**

numbers

Entering names and addresses: choice is narrowed down with every letter entered and letters may be added automatically.

Entries are continuously compared with data stored in the vehicle.

- Only those letters are offered during input for which data is available.
- Target search: names of locations may be entered in languages available through Control Display.

# **VOICE ACTIVATION SYSTEM**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

### THE CONCEPT

- Most functions displayed on the Control Display can be operated by voice commands via the voice activation system. The system supports you with announcements during input.
- Functions that can only be used when the vehicle is stationary cannot be used via the voice activation system.
- The system uses a special microphone on the driver's side.
- .... Verbal instructions in the Owner's Manual to use with the voice activation system.

# **REQUIREMENTS**

Via the Control Display, set a language that is also supported by the voice activation system so that the spoken commands can be identified.

Set the language, refer to page 85.

### **USING VOICE ACTIVATION**

#### Activating the voice activation system



- Press button on the steering wheel.
- 2. Wait for the signal.
- 3. Say the command.

A command that is recognized by the voice activation system is announced and displayed in the instrument cluster.

which the instrument cluster indicates that the voice activation system is active.

If no other commands are available, operate the function via the onboard monitor.

# Terminating the voice activation system



Briefly press the button on the steering wheel or >Cancel.

# **POSSIBLE COMMANDS**

Most menu items on the Control Display can be voiced as commands.

The available commands depend on the menu that is currently displayed on the Control Display.

There are short commands for many functions.

You may select lists such as phone lists via voice activation. Read these lists out loud exactly as they show in the respective list.

# Having possible commands read aloud

You can have available commands read out loud for you: >Voice commands<

E. g. if the "Settings" menu is displayed, the commands for the settings are read out loud.

# Executing functions using short commands

Execute functions on the main menu via short commands. It almost doesn't matter which menu item is selected, e.g., >Vehicle status<.

# Help dialog for the voice activation system

Calling up help dialog: >Help<

Additional commands for the help dialog:

- Help with examples: announces information about the current operating options and the most important commands for them
- > Help with voice activation: information about the principle of operation for the voice activation system is announced.

# ONE EXAMPLE: OPEN THE TONE SETTINGS

#### Via the main menu

The commands of the menu items are spoken just as they are selected via the controller.

 Turn on the Entertainment sound output if needed.

Press button on the steering wheel.

- needed.
- 3. →Radioc
- 4. →Tone«

#### Via short command

The desired tone settings can also be started via a short command.

- Turn on the Entertainment sound output if needed.
- 2. Press button on the steering wheel.
- 3. →Tone«

### SETTING THE VOICE DIALOG

Set system to standard dialog or use a short version.

The short version of the voice dialog plays back short messages in abbreviated form.

On the Control Display:

- 1. 🐼 "Settings"
- 2. "Language/Units"
- 3. "Speech type:"
- 4. Select setting.

### ADJUSTING THE VOLUME

Turn the volume button while giving an instruction until the desired volume is set.

- The volume remains constant even if the volume of other audio sources is changed.
- The volume is stored for the profile currently in use.

# HINTS ON EMERGENCY RE-QUESTS

Do not use the voice activation system to initiate an Emergency Request. In stressful situations, the voice and vocal pitch can change. This can unnecessarily delay the establishment of a phone connection.

# ENVIRONMENTAL CONDITIONS

- Say the commands, numbers, and letters smoothly and with normal volume, emphasis, and speed.
- Always say commands in the language of the voice activation system.
- Keep the doors, windows, and glass sunroof closed to prevent noise interference.

Avoid making other noise in the vehicle while speaking.

# INTEGRATED OWNER'S MANUAL IN THE VEHICLE

# VEHICLE FEATURES AND OPTIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# INTEGRATED OWNER'S MANUAL IN THE VEHICLE

The Integrated Owner's Manual can be displayed on the Control Display. It specifically describes features and functions found in the vehicle.

# Components of the Integrated Owner's Manual

The Integrated Owner's Manual consists of three parts, which offer various levels of information or possible access.

#### **Ouick Reference Guide**

The Quick Reference Guide provides information how to operate the car, how to use basic vehicle functions or what to do in case of a breakdown. This information can also be displayed while driving.

#### Search by images


Image search provides information and descriptions. This is helpful when the terminology for a feature is not at hand.

#### Owner's Manual

Search for information and descriptions by entering terms selected from the index.

#### **Select components**

- MENU
  - Press button.
- 2. Turn the controller: open "Vehicle info".
- 3. Press the controller.
- 4. Selecting desired range:
  - ▶ "Quick reference"
  - ▷ "Search by pictures"
  - ▷ "Owner's Manual"



# Leafing through the Owner's Manual

# Page by page with link access

Turn the controller until the next or previous page is displayed.

## Page by page without link access

Scroll through the pages directly while skipping the links.

Highlight the symbol once. Now simply press the controller to browse from page to page.



Scroll back.



Scroll forward.

# Context help - Owner's Manual to the temporarily selected function

You may open the relevant information directly.

#### Opening via the onboard monitor

To move directly from the application on the Control Display to the options menu:

- Press button or move the controller to the right repeatedly until the "Options" menu is displayed.
- 2. "Display Owner's Manual"

# Opening when a Check Control message is displayed

Directly from the Check Control message on the Control Display:

"Display Owner's Manual"

# Changing between a function and the Owner's Manual

To switch from a function, e. g., radio, to the Owner's Manual on the Control Display and to alternate between the two displays:

- Press button or move the controller to the right repeatedly until the "Options" menu is displayed.
- 2. "Display Owner's Manual"
- Select the desired page in the Owner's Manual.
- 4. Press button again to return to last displayed function.
- Press button to return to the page of the Owner's Manual displayed last.

To alternate permanently between the last displayed function and the Owner's Manual repeat steps 4 & 5. Opens a new display every time.

### **Programmable memory buttons**

#### **General information**

The Owner's Manual can be stored on the programmable memory buttons and called up directly.

#### Storing

- Select "Owner's Manual" via the onboard monitor.
- 2. Press and hold the desired button, until a signal sounds.

### **Executing**

Press button.
The Owner's Man

The Owner's Manual is displayed immediately.



# HANDLE ME.

**AT A GLANCE** 

**CONTROLS** 

**DRIVING TIPS** 

**MOBILITY** 

**REFERENCE** 

# OPENING AND CLOSING

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# REMOTE CONTROL/KEY

#### **General information**

The vehicle is supplied with two remote controls with integrated key.

Every remote control holds a replaceable battery.

You may set the key functions depending on the optional features and country-specific version. For Settings, refer to page 42.

The vehicle stores personal settings for every remote control. Personal Profile, refer to page 35.

The remote controls hold information on required maintenance. For service data, refer to page 195.

#### Overview



- Unlocking
- 2 Locking
- 3 Unlock the tailgate
- 4 Panic mode

# **Integrated key**




Press button, arrow 1, and remove the key, arrow 2.

The integrated key fits the driver's door lock.

# Replacing the battery

- Remove integrated key from remote control.
- Slide the key into the opening and raise the cover, arrow.

The battery compartment is accessible.



3. Slide the key in the cover of the battery compartment and raise the cover, arrow.



- 4. Insert a battery of the same type with the positive side facing up.
- 5. Insert lid and cover.



Take the used battery to a recycling center or to your service center.

#### **New remote controls**

New remote controls are available from the service center.

#### Loss of the remote controls

Lost remote controls can be disabled by your service center.

# **Emergency detection of remote control**

It is possible to switch on the ignition or start the engine in situations such as the following:

- Interference of radio transmission to remote control by external sources e.g., by radio masts.
- ▷ Empty battery in remote control.

- Interference from radio transmissions through mobile devices in close proximity to remote control.
- Interference of radio transmission by charger while charging items such as mobile devices in the vehicle.

A Check Control message is displayed if an attempt is made to switch on the ignition or start the engine.

Starting the engine via emergency detection of the remote control



Steptronic transmission: if a corresponding Check Control message appears, hold the remote control, as shown, against the marked area on the steering column and press the Start/Stop button within 10 seconds while pressing the brake.

Manual transmission: if a corresponding Check Control message appears, hold the remote control, as shown, against the marked area on the steering column and press the Start/Stop button within 10 seconds while pressing the clutch.

# **PERSONAL PROFILE**

# The concept

Personal Profile provides three profiles, using which personal vehicle settings can be stored. Every remote control has one of these profiles assigned.

If the vehicle is unlocked using a remote control, the assigned personal profile will be activated. All settings stored in the profile are automatically applied.

If several drivers use their own remote control, the vehicle will adjust the personal settings during unlocking. These settings are also restored, if the vehicle has been used in the meantime by a person with a different remote control.

Changes to the settings are automatically saved in the personal profile.

Three personal profiles and a guest profile can be created.

# Adjusting

The settings for the following systems and functions are saved in the active profile. The scope of storable settings is country- and equipmentdependable.

- Unlocking and locking.
- ▶ Lights.
- Radio.
- Instrument cluster.
- Programmable memory buttons.
- ▶ Volumes, tone.
- ▷ Control Display.
- ▷ Climate control.
- Navigation.
- ▶ Park Distance Control PDC.
- Rearview camera
- Driving Dynamics Control.
- Cruise control.
- ▶ Intelligent Safety.

#### **Profile management**

# **Opening profiles**

Regardless of the remote control in use a different profile may be activated.

- 1. 🕸 "Settings"
- 2. "Profiles"
- 3. Select a profile.
- ▷ All settings stored in the called-up profile are automatically applied.
- The called-up profile is assigned to the remote control being used at the time.
- If the profile is already assigned to a different remote control, this profile will apply to both remote controls. It cannot be differentiated anymore between the settings for the two remote controls.

# **Renaming profiles**

A personal name can be assigned to every profile to avoid confusion between the profiles.

- Settings"
- 2. "Profiles"

The current profile is selected.

- 3. "Options"
- 4. "Rename current profile"

# **Resetting profiles**

The settings of the active profile are reset to their default values.

- 1. 🕸 "Settings"
- 2. "Profiles"

The current profile is selected.

- 3. Open "Options".
- 4. "Reset current profile"

# **Exporting profiles**

Most settings of the active profile can be exported.

This can be helpful for securing and retrieving personal settings, before delivering the vehicle to a workshop, e.g. Profiles can be taken to another vehicle equipped with the Personal Profile function.

Export is made via the USB port to a USB device.

Popular file systems for USB devices are supported. FAT32 and exFAT are the recommended formats for profile export. Other formats may not support the export.

- 1. 🗭 "Settings"
- 2. "Profiles"
- 3. "Export profile"
- 4. "USB device"

# **Importing profiles**

Profiles stored on a USB device can be imported via the USB interface.

Existing settings are overwritten with the imported profile.

- 1. 🕸 "Settings"
- 2 "Profiles"
- 3. "Import profile"
- 4. "USB device"

# Using the guest profile

The guest profile is for individual settings that are saved in none of the three personal profiles.

This can be useful for drivers who are using the vehicle temporarily and do not have their own profile.

- 1. 🕸 "Settings"
- 2. "Profiles"
- 3. "Guest"
- 4. Adjust the settings.

The guest profile cannot be renamed. It is not assigned to the current remote control.

# Display profile list during start

The profile list can be displayed during each start to select the desired profile.

- 1. 🕸 "Settings"
- 2. "Profiles"
- 3. Open "Options".
- 4. "Display user list at startup"

# USING THE REMOTE CONTROL

#### Note

Take the remote control with you People or animals left unattended in a parked vehicle can lock the doors from the inside. Always take the remote control with you when leaving the vehicle so that the vehicle can then be opened from the outside. ◄

# Unlocking



Press button on the remote control.

- ▶ The vehicle is unlocked.
- Interior lamps and courtesy lamps are activated. This function is not available, if the interior lamps were switched off manually.
- ▶ The welcome lamps are switched on, if this function was activated.
- Exterior mirrors folded through convenient closing are folded open.

On 3-door models:
Press button on the remote control
twice in direct succession.

When the door is opened, the window is low-

You can set how the vehicle is to be unlocked. Create the settings, refer to page 42.

cle.

The alarm system, refer to page 43, is disarmed.

# **Convenient opening**



Press and hold this button on the remote control after unlocking.

The windows and the glass sunroof are opened, as long as the button on the remote control is pressed.

### Locking

Locking from the outside
Do not lock the vehicle from the outside
with people inside the car, as the vehicle cannot be unlocked from inside without special
knowledge.

The driver's door must be closed.



Press button on the remote control.

The alarm system, refer to page 43, is armed. If the vehicle horn honks twice when you lock the car, this means that the engine or ignition is still switched on. In this case, the engine or ignition must be switched off by means of the Start/Stop button.

# Switching on interior lights and courtesy lights



Press button on the remote control with the vehicle locked.

This function is not available, if the interior lamps were switched off manually.

If the button is pressed within 10 seconds of when the vehicle was locked Interior motion sensor and tilt alarm sensor of the anti-theft warning system, refer to page 44, are turned off. After locking, wait 10 seconds before pressing the button again.

#### Panic mode

You can trigger the alarm system if you find yourself in a dangerous situation.



Press button on the remote control for at least 3 seconds.

To switch off the alarm: press any button.

# Unlock the tailgate



Press button on the remote control for approx. 1 second.

The tailgate opens slightly, regardless of whether the vehicle was previously locked or unlocked.

Depending on the features and the country version, it is also possible to have door unlocked. Create the settings, refer to page 42.

If the doors were not unlocked, the tailgate is locked again as soon as it closes.



Do not place the remote control in the cargo area

Take the remote control with you and do not leave it in the cargo area; otherwise, the remote control is locked inside the vehicle when the tailqate is closed. ◀

Provide edge protection
Sharp objects or those with edges can hit the rear window while driving and damage the

the rear window while driving and damage the heat conductors of the rear window. Provide edge protection. ◄

#### Malfunction

Remote control detection by the vehicle can among others be malfunctioning under the following circumstances:

- The battery of the remote control is discharged. Replace the battery, refer to page 34.
- ▷ Interference of the radio connection from transmission towers or other equipment with high transmit power.

- Shielding of the remote control due to metal objects.
- Interference of the radio connection from mobile phones or other electronic devices in direct proximity.

Do not transport the remote control together with metal objects or electronic devices.

In the case of a malfunction, unlock and lock the vehicle using the integrated key, refer to page 39.

#### For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

#### FCC ID:

- LX8766S.
- ▶ LX8766E.
- LX8CAS.
- ▶ LX8CAS2.
- ▶ MYTCAS4.

#### Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference. and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment.

# WITHOUT REMOTE CONTROL

#### From the outside

A


Locking from the outside

Do not lock the vehicle from the outside with people inside the car, as the vehicle cannot be unlocked from inside without special knowledge.



Remove the key before pulling the door handle

Before pulling the outside door handle, remove the key to avoid damaging the paintwork and the key. ◀



Unlock or lock the driver's door via the door lock using the integrated key, refer to page 34. The other doors must be unlocked or locked from the inside.

To do this, unlock the lid from below with the integrated key, arrow, and remove.

# Alarm system

The alarm system is not armed if the vehicle is locked with the integrated key.

The alarm system is triggered when the door is opened, if the vehicle was unlocked via the door lock. In order to terminate this alarm, unlock vehicle with the remote control or switch on the ignition, if needed, through emergency detection of the remote control.

#### From the inside

### Locking and unlocking





Press button.
Vehicle is locked.



Press button.

The vehicle is unlocked.

Pressing the buttons for the central locking system locks and unlocks the doors and the tailgate when the front doors are closed, but they are not secured against theft.

The fuel filler flap remains unlocked.

In the event of a severe accident, the vehicle is automatically unlocked. The hazard warning system and interior lights come on.

# **Unlocking and opening**

Either unlock the doors together using the central locking system buttons and then pull the door handle above the armrest or pull the door handle on the door to open the door. The other doors remain locked.

# **TAILGATE**

#### Hints

Keep the closing path clear

Make sure that the closing path of the tailgate is clear; otherwise, injuries may result.



Do not place the remote control in the cargo area

Take the remote control with you and do not leave it in the cargo area; otherwise, the remote control is locked inside the vehicle when the tailgate is closed. ◀

Provide edge protection

Sharp objects or those with edges can hit the rear window while driving and damage the heat conductors of the rear window. Provide edge protection.

# **Opening**

When the tailgate is opened, make sure there is sufficient clearance to prevent damage.



Unlock the vehicle and press the button on the tailgate.



Press button on the remote control for approx. 1 second.

As the case may be, the doors are also unlocked. Unlocking with the remote control, refer to page 38.

The tailgate is unlocked and can be swung upward.

# Opening from the inside



With the vehicle is stationary, press the button in the driver's footwell.

# Closing



Recessed grips on the inside trim of the tailgate can be used to conveniently pull down the tailgate.

# **COMFORT ACCESS**

# The concept

The vehicle can be accessed without activating the remote control.

All you need to do is to have the remote control with you, such as in your pants pocket.

The vehicle automatically detects the remote control when it is in close proximity or in the car's interior.


Comfort Access supports the following functions:

- Unlocking/locking of the vehicle.
- Convenient closing.
- Separate unlocking of the tailgate.
- Start the engine.

# **Functional requirements**

- There are no sources of interference nearby.
- ▷ To lock the vehicle, the remote control must be located outside of the vehicle.
- The next unlocking and locking cycle is not possible until after approx. 2 seconds.
- The engine can only be started if the remote control is in the vehicle.


## **Unlocking**



On the driver's or front passenger's door handle, press the button, arrow.

This corresponds to pressing the remote control button:  $\Box$ 

## Locking



On the driver's or front passenger's door handle, press the button, arrow.


This corresponds to pressing the remote control button:

To save battery power, ensure that all power consumers are turned off, before locking the vehicle.

# **Convenient closing**

Monitor closing

Monitor closing to ensure that no one becomes trapped. ◄



Press and hold down the handle of the driver or the front seat passenger.

This corresponds to pressing the remote control button:

In addition to locking, the windows and glass suproof will be closed.

# Unlock the tailgate

Press button on tailgate's exterior.

This corresponds to pressing the remote control button:

The situation of the doors does not change.



Do not place the remote control in the cargo area

Take the remote control with you and do not leave it in the cargo area; otherwise, the remote control is locked inside the vehicle when the tailgate is closed. ◀

#### Malfunction

Remote control detection by the vehicle can among others be malfunctioning under the following circumstances:

- The battery of the remote control is discharged. Replace the battery, refer to page 34.
- Interference of the radio connection from transmission towers or other equipment with high transmit power.
- Shielding of the remote control due to metal objects.

 Interference of the radio connection from mobile phones or other electronic devices in direct proximity.

Do not transport the remote control together with metal objects or electronic devices.

In the case of a malfunction, unlock and lock the vehicle using the buttons of the remote control or using the integrated key, refer to page 39.

#### **ADJUSTING**

# Unlocking

The settings are saved in the active profile. Personal Profile, refer to page 35.

#### **Doors**

- 1. 
  Settings"
- 2. "Doors/key"
- 3. 🔓 Select the symbol.
- 4. Select the desired function.
  - "Driver's door only"
     Only the driver's door and the fuel filler flap are unlocked. Pressing again unlocks the entire vehicle.
  - ▷ "All doors"

The entire vehicle is unlocked.

▷ On 3-door models:

"Comfort access"

The entire vehicle is unlocked.

If the remote control button is pressed twice directly consecutively, the window is lowered more when the door is opened next.

#### **Tailgate**

Depending on optional features and country version, this setting is not offered in some cases.

- 1. 🕸 "Settings"
- 2. "Doors/key"
- 3. Select the symbol.
- 4. Select the desired function.
  - ⊳ "Tailgate"

Only the tailgate is unlocked.

"Tailgate + door(s)"
The tailgate and the doors are unlocked.

# Locking

The settings are saved in the active profile. Personal Profile, refer to page 35.

- 1. 🐼 "Settings"
- 2. "Doors/key"
- 3. Select desired setting.
  - "Lock if no door is opened"
    The vehicle locks automatically after a short period of time if no door is opened.
  - "Lock after start driving"
     The vehicle locks automatically after you drive off.

# Confirmation signals from the vehicle

- 1. 🕸 "Settings"
- 2. "Doors/key"
- 3. Select desired setting.
  - "Acoustic sig. lock/unlock"Unlocking is signaled by one honk of the horn.
  - "Flash when lock/unlock"Unlocking is signaled by two flashes, locking by one.

### ALARM SYSTEM

# The concept

When the vehicle is locked, the vehicle alarm system responds to:

- ▷ Opening a door, the hood or the tailgate.
- Movements in the vehicle interior
- Changes in the vehicle tilt, e. g., during attempts at stealing a wheel or when towing the car.
- Disconnected battery voltage.

The alarm system briefly signals tampering:

- Acoustic alarm.
- ▷ By switching on the hazard warning system.
- By flashing the daytime running lights.

# Arming and disarming the alarm system

When you lock or unlock the vehicle, either with the remote control or via the Comfort Access, the alarm system is armed or disarmed at the same time.

# Door lock and armed alarm system

The alarm system is triggered when the door is opened, when the vehicle is unlocked via the door lock.

Switch off the alarm, refer to page 44.

# Tailgate and armed alarm system

The tailgate can be opened even when the alarm system is armed.

After the tailgate is closed, it is locked and monitored again when the doors are locked. The hazard warning system flashes once.

#### Panic mode


You can trigger the alarm system if you find yourself in a dangerous situation.



Press button on the remote control for at least 3 seconds.

To reel off the alarm: press any button.

# Indicator lamp on the interior rearview mirror



The indicator lamp flashes briefly every 2 seconds:

The system is armed.

The indicator lamp flashes after locking: The doors, hood or tailgate is not closed properly, but the rest of the vehicle is secured.

After 10 seconds, the indicator lamp flashes continuously. Interior motion sensor and tilt alarm sensor are not active.

When the still open access is closed, interior motion sensor and tilt alarm sensor will be switched on.

The indicator lamp goes out after unlocking:

The vehicle has not been tampered with.

The indicator lamp flashes after unlocking until the engine ignition is switched on, but no longer than approx. 5 minutes:

An alarm has been triggered.

#### Tilt alarm sensor

The tilt of the vehicle is monitored.

The alarm system responds in situations such as attempts to steal a wheel or when the car is towed.

#### Interior motion sensor

The windows and glass sunroof must be closed for the system to function properly.

#### **Avoiding unintentional alarms**

The tilt alarm sensor and interior motion sensor can be switched off together, such as in the following situations:

- ▷ In automatic car washes.
- In duplex garages.
- During transport on trains carrying vehicles, at sea or on a trailer.
- With animals in the vehicle.

# Switching off the tilt alarm sensor and interior motion sensor



Press the remote control button again within 10 seconds as soon as the vehi-

cle is locked.

The indicator lamp lights up for approx. 2 seconds and then continues to flash.

The tilt alarm sensor and interior motion sensor are turned off, until the vehicle is locked again.

# Switching off the alarm

- Unlock vehicle with the remote control or switch on the ignition, if needed through emergency detection of remote control, refer to page 35.
- With Comfort Access: If you are carrying the remote control on your person, grasp the driver side or front passenger side door handle completely.

Unlock vehicle with the remote control or switch on the ignition, if needed through emergency detection of remote control, refer to page 35.

# **POWER WINDOWS**

#### Note

Take the remote control with you Take the remote control with you when leaving the vehicle so that children, e.g., cannot operate the power windows and injure themselves.

#### On 5-door models



#### On 3-door models



# **Opening**

Press the button to the resistance point.

The window opens while the switch is held.

Press the switch beyond the resistance point.

The window opens automatically. Pressing again stops the motion.

See also: Convenient opening, refer to page 38, via remote control.

### Closing

Keep the closing path clear

Monitor closing and make sure that the closing path of the window is clear; otherwise, injuries may result.



Pull switch up.

The window closes while the reel is held.

See also: closing by means of Comfort Access, refer to page 41.

#### **Pinch protection system**



Danger of jamming even with pinch protection

Even with the pinch protection system, check that the window's closing path is clear; otherwise, the closing action may not stop in certain situations, e.g., if thin objects are present. ◀

No window accessories

Do not install any accessories in the window's range of movement; otherwise, the pinch protection system will be impaired.

If closing force exceeds a specific margin as a window closes, closing is interrupted.

The window reopens slightly.

# Closing without the pinch protection system

Keep the closing path clear

Monitor closing and make sure that the closing path of the window is clear; otherwise, injuries may result.

E. g. danger from the outside or ice might prevent window from closing properly - proceed as follows:

1. Pull the switch past the resistance point and hold it there.

The pinch protection is limited and the window reopens slightly if the closing force exceeds a certain margin.

Pull the switch past the resistance point again within approx. 4 seconds and hold it there.

The window closes without jam protection.

# On 5-door models: safety switch

The safety switch in the driver's door can be used to prevent children, e.g., from opening and closing the rear windows using the switches in the rear.

# Switching on and off

Press button.

The LED lights up if the safety function is switched on.

Safety switch for rear operation
Press the safety switch when transporting
children in the rear; otherwise, injury may result
if the windows are closed without supervision.

# PANORAMIC GLASS SUN-ROOF

#### Hints

Keep the closing path clear

Monitor closing and make sure that the
closing path of the glass sunroof is clear; otherwise, injuries may result.

✓

Take the remote control with you Take the remote control with you when leaving the vehicle so that children, e.g., cannot operate the glass sunroof and injure themselves.

#### At a glance



# Tilting the glass sunroof



Press back the reel up to or beyond the resistance point and release it.

The glass sunroof is raised.

# **Opening glass sunroof**

# When the glass sunroof is closed



Press the reel back beyond the resistance point and release it twice.

The glass sunroof is opened.

Pressing the reel again stops the

motion.

# With the glass sunroof completely raised



- Slide reel back to the resistance point and hold.
  - The glass sunroof is opened as long as the reel is pressed.
- Press the reel back beyond the resistance point and release it.

The glass sunroof is opened. Pressing the reel again stops the motion.

### **Comfort position**

If the glass sunroof stops before it is completely opened, it is in the Comfort position. In this position the wind noises in the interior are the least.

If desired, continue the movement by pressing the reel.

### Closing glass sunroof

# With the glass sunroof open



- Slide reel forward to the resistance point and hold.
   The glass sunroof is closed as long as the reel is pressed and stops in the raised position.
- Press the reel forward beyond the resistance point and release it.
  - The glass sunroof is closed and stops in the raised position.
  - Pressing the reel toward the back stops the motion.
- Press the reel forward beyond the resistance point and release it twice.
  - The glass sunroof is closed.
  - Pressing the reel again stops the motion.

# With the glass sunroof completely raised



Press the reel forward beyond the resistance point and release it.

The glass sunroof is closed.

# **Pinch protection system**

If the closing force exceeds a specific value as a glass sunroof closes, the closing action is interrupted.

The glass sunroof reopens slightly.



Danger of jamming even with pinch protection

Despite the pinch protection system, check that the glass sunroof's closing path is clear; otherwise, the closing action may not be interrupted in certain extreme situations, such as when thin objects are present.

# Closing without the pinch protection system

E. g. if there is an external danger, proceed as follows:

- 1. Press the reel forward beyond the resistance point and hold it.
  - The pinch protection is limited and the glass sunroof reopens slightly if the closing force exceeds a certain margin.
- Press the reel forward again beyond the resistance point and hold until the glass sunroof closes without jam protection. Make sure that the closing area is clear.

# Initializing after a power failure

After a power failure, it can happen that the glass sunroof can only be raised. The system must be initialized in this case. MINI recommends having this work performed by your service center.

# **ADJUSTING**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# SITTING SAFELY

The ideal seating position can make a vital contribution to relaxed, fatigue-free driving.

The seating position plays an important role in an accident in combination with:

- ▷ Safety belts, refer to page 50.
- ▶ Head restraints, refer to page 51.
- Airbags, refer to page 95.

# **SEATS**

#### Hints

Do not adjust the seat while driving
Do not adjust the driver's seat while driving, or the seat could respond with unexpected
movement and the ensuing loss of vehicle control could lead to an accident.



Do not incline the backrest too far to the rear

Do not incline the backrest too far to the rear while driving, or there is a risk of slipping under the safety belt in the event of an accident. This would eliminate the protection normally provided by the belt.◀

Keep the movement area unobstructed When changing the seat position, keep the seat's area of movement unobstructed; otherwise, people might get injured or objects damaged.

# **Adjusting seats**

#### **Overview**



- 1 Forward/backward
- 2 Thigh support
- 3 Height
- 4 Backrest tilt

### Forward/backward



Pull the lever and slide the seat in the desired direction.

After releasing the lever, move the seat forward or back slightly making sure it engages properly.

# Height



Pull the lever up or press it down as often as needed to reach the desired height.

#### **Backrest tilt**



Pull the lever and apply your weight to the backrest or lift it off, as necessary.

# **Lumbar support**

The curvature of the seat backrest can be adjusted in a way that it supports the lumbar region of the spine. The lower back and the spine are supported for upright posture.



Turn the wheel in order to increase or decrease the curvature.

# Thigh support



Pull the lever at the front of the seat and adjust the thigh support.

# In 3-door models: entering the rear

#### Hints

Folding back and locking the backrest
Before driving off, fold back and lock the
backrests; otherwise, an unexpected seat
movement may cause an accident.

Keep the movement area unobstructed When changing the seat position, keep the seat's area of movement unobstructed; otherwise, people might get injured or objects damaged.

#### Fold down seat back

1. Pull lever up to the stop.



- Fold backrest forward.
- 3. Push the seat forward.

# **Original position**

The driver's seat features a mechanical memory function for forward/back and backrest adjustment.

- 1. Push the seat back into the original position.
- Fold back the backrest to lock the seat.

If the backrest is folded back when the seat is not yet in the original position, the seat latches in the current position. In this case, manually adjust longitudinal direction, refer to page 48.

# Front seat heating



# Switching on



Press button once for each temperature level.

The maximum temperature is reached when three LEDs are lit.

If the journey is continued within approx. 15 minutes, the seat heating is activated automatically with the temperature selected last.

When Green mode, refer to page 162, is activated, the heater output is reduced.

#### Switch off



Press button longer.

The LEDs go out.

# **SAFETY BELTS**

### Seats with safety belt

The vehicle has four or five seating positions, each of which is equipped with a safety belt.

# **Number of safety belts**

Your vehicle has been fitted with four or five safety belts for your and your passengers' safety. However, they can only offer protection when adjusted correctly.

#### **General information**

Always make sure that safety belts are being worn by all occupants before driving off.

For the occupants' safety the belt locking mechanism triggers early. Slowly guide the belt out of the holder when applying it.

If needed, disengage the belt in the rear from the belt buckle on the side.

Although airbags enhance safety by providing added protection, they are not a substitute for safety belts.

The two outer safety belt buckles, integrated into the rear seat, are for passengers sitting on the left and right.

The center rear safety belt buckle is solely intended for the center passenger.

#### Hints

One person per safety belt

Never allow more than one person to
wear a single safety belt. Never allow infants or
small children to ride on a passenger's lap.

Putting on the belt
Lay the belt, without twisting, snugly
across the lap and shoulders, as close to the
body as possible. Make sure that the belt lies
low around the hips in the lap area and does
not press on the abdomen. Otherwise, the belt
can slip over the hips in a frontal impact and injure the abdomen.

The safety belt must not lie across the neck, rub on sharp edges, be routed over breakable objects, or be pinched. ◀

What reduces the restraining effect
Avoid wearing bulky clothing, and pull
the shoulder belt periodically to readjust the
tension. Make sure that the belt is not jammed;
otherwise, the belt can be damaged and the
restraining effect is reduced.

Using the middle safety belt
If the middle safety belt in the rear is
used, the larger side of the backrest must be
locked. Otherwise, the safety belt will not have
a restraining effect.

# **Buckling the belt**



Make sure you hear the latch plate engage in the belt buckle.

### Unbuckling the belt

- 1. Hold the belt firmly.
- 2. Press the red button in the belt buckle.
- Guide the belt back into its roll-up mechanism.

# Safety belt reminder for driver's seat and front passenger seat



The indicator lamp lights up and a signal sounds. Make sure that the safety belts are positioned correctly. The

safety belt reminder is active at speeds above approx. 6 mph/10 km/h. It can also be activated if objects are placed on the front passenger seat.

# Damage to safety belts

Wear and tear after accidents or when damaged otherwise:

Have the safety belts, including the safety belt tensioners, replaced and have the belt anchors checked.

Check and replace safety belts
This should only be done by your service center; otherwise, this safety feature might not work properly. ◀

# FRONT HEAD RESTRAINTS

# Correctly adjusted head restraint

A correctly adjusted head restraint reduces the risk of injury to cervical vertebrae in the event of an accident.

Adjust the headrest via the backrest tilt as needed.

Adjusting the head restraint
Adjust the head restraints of all occupied seats properly; otherwise, there is an increased risk of injury in an accident.

### Height

Adjust the head restraint so that its center is approximately at ear level.

#### **Distance**

Adjust the distance so that the head restraint is as close as possible to the back of the head.

If necessary, adjust the distance by adjusting the tilt of the backrest.

# Adjusting the height



- ▷ To raise: pull.
- ▶ To lower: press button, arrow 1, and push headrest down.

# Removing

Only remove the head restraint if no one will be sitting in the seat in question.



- 1. Pull head restraint up as far as possible.
- 2. Press button, arrow 1, and pull the head restraint out completely.

To remove the headrest, fold the backrest rearward if it is in the upright position.

Before transporting passengers
Reinstall the head restraint before transporting anyone in the seat; otherwise, the protective function of the head restraint is unavailable.

# **REAR HEAD RESTRAINTS**

# Correctly adjusted head restraint


A correctly adjusted head restraint reduces the risk of injury to cervical vertebrae in the event of an accident.

Adjusting the head restraint
Adjust the head restraints of all occupied seats properly; otherwise, there is an increased risk of injury in an accident.

#### Height

Adjust the head restraint so that its center is approximately at ear level.

# Adjusting the height



- ▶ To raise: push.
- ▷ To lower: press button, arrow 1, and push headrest down.

# Folding down head restraints

Extending/retracting head restraint
Only fold down head restraint if no passengers are in the rear. Fold out retracted headrests again if passengers are being carried

in the rear; otherwise, there is increased risk of injury in the event of an accident. ◀




- To lower flaps: press the button, arrow 1, and press down the head restraint.
- Fold back up: pull up head restraints.

# Removing

Only remove the head restraint if no one will be sitting in the seat in question.

Fold the seat down, refer to page 145, before removing the head restraint, otherwise the head restraint cannot be removed.



- Pull head restraint up against the resistance.
- Press button, arrow 1, and pull the head restraint out completely.

Before transporting passengers
Reinstall the head restraint before transporting anyone in the seat; otherwise, the protective function of the head restraint is unavailable.

#### **MIRRORS**

#### **Exterior mirrors**

#### General information

The mirror on the passenger side is more curved than the driver's side mirror.

Depending on the vehicle equipment, the mirror setting is stored for the profile currently in use. When the vehicle is unlocked via the remote control, the position is automatically retrieved if this function is active.

#### Note

Estimating distances correctly
Objects reflected in the mirror are closer
than they appear. Do not estimate the distance
to the traffic behind you based on what you see
in the mirror, as this will increase your risk of an
accident.

# **Overview**



- 1 Adjusting 54
- 2 Left/right, Automatic Curb Monitor
- 3 Fold in and out 54

### Selecting a mirror



To change over to the other mirror: Slide the switch.

# Adjusting electrically



The setting corresponds to the direction in which the button is pressed.

#### Adjusting manually

In case of electrical malfunction press edges of mirror.

#### **Automatic Curb Monitor**

#### The concept

If reverse gear is engaged, the mirror glass on the front passenger side is tilted downward. This improves your view of the curb and other low-lying obstacles when parking, e.g.

#### **Activating**

- 1. Slide the switch to the driver's side mirror position.
- 2. Engage selector lever position R.

#### **Deactivating**

Slide the switch to the passenger side mirror position.

#### Fold in and out



Press button.

Possible at speeds up to approx. 15 mph/20 km/h.

E. g. this is advantageous

- In car washes.
- In narrow streets.
- For folding mirrors back out that were folded away manually.

Mirrors that were folded in are folded out automatically at a speed of approx.

25 mph/40 km/h.

Fold in the mirror in a car wash

Before washing the car in an automatic
car wash, fold in the exterior mirrors by hand or
with the button; otherwise, the mirrors could
be damaged, depending on the width of the

# **Automatic heating**

vehicle.◀


Both exterior mirrors are automatically heated whenever the engine is running.

# **Automatic dimming feature**

Both exterior mirrors are automatically dimmed. Photocells are used to control the Interior rearview mirror, refer to page 55.

# Interior rearview mirror, manually dimmable

# Flip lever



To reduce the blinding effect of the interior rear view mirror, flip the lever forward.


#### **Turn knob**



Turn the knob to reduce the blinding effect by the interior mirror.

# Interior rearview mirror, automatic dimming feature

# The concept



Photocells are used for control:

- In the mirror glass.
- On the back of the mirror.

#### **Functional requirement**

For proper operation:

- Keep the photocells clean.
- Do not cover the area between the inside rearview mirror and the windshield.

# STEERING WHEEL

#### Note

Do not adjust while driving
Do not adjust the steering wheel while
driving; otherwise, an unexpected movement
could result in an accident.

# Adjusting



- 1. Switch on the ignition.
- 2. Fold the lever down.
- Move the steering wheel to the preferred height and angle to suit your seating position.
- Fold the lever back.
- 5. Switch off the ignition again if needed.

# TRANSPORTING CHILDREN SAFELY

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# THE RIGHT PLACE FOR CHILDREN

#### Note

Children in the vehicle
Do not leave children unattended in the vehicle; otherwise, they could endanger themselves and other persons, e.g., by opening the doors.

## Children should always be in the rear

Accident research shows that the safest place for children is in the back seat.

Transporting children in the rear
Only transport children younger than
13 years of age or shorter than 5 ft/150 cm in
the rear in child restraint systems provided in
accordance with the age, weight and size of
the child; otherwise, there is an increased risk
of injury in an accident.

Children 13 years of age or older must wear a safety belt as soon as a suitable child restraint system can no longer be used due to their age, weight and size. ◀

# Children on the front passenger seat

Should it ever be necessary to use a child restraint system in the front passenger seat, make sure that the front, knee and side airbags on the front passenger side are deactivated. Automatic deactivation of front-seat passenger airbags, refer to page 97.

#### Note



Deactivating the front-seat passenger airbags

If a child restraint system is used in the front passenger seat, deactivate the front-seat passenger airbags; otherwise, there is an increased risk of injury to the child when the airbags are activated, even with a child restraint system.

# INSTALLING CHILD RE-STRAINT SYSTEMS

#### Hints



Manufacturer's information for child restraint systems

To select, mount and use child restraint systems, observe the information provided by the system manufacturer; otherwise, the protective effect can be lost. ◀

Ensuring the stability of the child seat When installing child restraint systems, make sure that the child seat is securely fastened to the backrest of the seat. Angle and headrest of the backrest might need to be adjusted or possibly be removed. Make sure that all backrests are securely locked. Otherwise the stability of the child seat can be affected, and

there is an increased risk of injury because of unexpected movement of the seat backrest.

In order to faciliate the installation of a backfacing child restraint system in the rear: move the front passenger's seat as far up as possible before folding down the backrest.

# On the front passenger seat

# **Deactivating airbags**

After installing a child restraint system in the front passenger seat, make sure that the front, knee and side airbags on the front passenger side are deactivated.

Deactivate the front-seat passenger airbags automatically, refer to page 97.



Deactivating the front-seat passenger airbags

If a child restraint system is used in the front passenger seat, deactivate the front-seat passenger airbags; otherwise, there is an increased risk of injury to the child when the airbags are activated, even with a child restraint system.

# Seat position and height

Before installing a child restraint system, move the front passenger seat as far back as possible and adjust its height to the highest and thus best possible position for the belt and to offer optimal protection in the event of an accident.

If the upper anchorage of the safety belt is located in front of the belt guide of the child seat,

move the passenger seat carefully forward until the best possible belt guide position is reached.

# Child seat security



The rear safety belts and the front passenger safety belt can be permanently locked to fasten child restraint systems.

# Locking the safety belt

- 1. Pull out the strap completely.
- 2. Secure the child restraint system with the belt.
- Allow the strap to be pulled in and pull it tight against the child restraint system. The safety belt is locked.

# Unlocking the safety belt

- Unbuckle the belt buckle.
- 2. Remove the child restraint system.
- 3. Allow the strap to be pulled in completely.

# LATCH CHILD RESTRAINT SYSTEM

LATCH: Lower Anchors and Tether for Children.

#### Note



Follow manufacturer's information for LATCH child restraint systems

To mount and use the LATCH child restraint systems, observe the operating and safety infor-

mation from the system manufacturer; otherwise, the level of protection may be reduced. ◀

#### Mounts for the lower LATCH anchors

The lower anchors may be used to attach the CRS to the vehicle seat up to a combined child

and CRS weight of 65 lb when the child is restrained by the internal harnesses.



Properly engage the lower LATCH anchors

Make sure that the lower LATCH anchors have properly engaged and that the child restraint system is resting snugly against the backrest; otherwise, the degree of protection may be reduced. ◀


Before mounting the LATCH child restraint system, pull the belt away from the child restraint system.

#### **Position**



E

The corresponding symbol shows the mounts for the lower LATCH anchors. Seats equipped with lower anchors are marked with a pair, 2, of LATCH sym-



# Assembly of LATCH child restraint systems

- 1. Mount the child restraint system; refer to the user's manual of the system.
- Ensure that both LATCH anchors are properly connected.

# Child restraint fixing system with a tether strap

#### Note

Mounting eyelets

Use the mounting eyes only for the upper retaining strap to secure child restraint systems; otherwise, the mounting eyes could be damaged.

#### **Mounting points**




The respective symbol shows the anchor for the upper retaining strap. Seats with an upper Top Tether are marked

with this symbol. It can be found on the rear seat backrest or the rear window shelf.

# Retaining strap guide

Retaining strap

Make sure that the upper retaining strap is not passed over the head restraints or sharp edges and is not twisted up to the upper mounting points; otherwise, the belt cannot properly secure the child restraint system in an accident.



- Direction of travel
- 2 Head restraint
- 3 Hook for upper retaining strap
- 4 Mounting point/eye
- 5 Seat backrest
- **6** Upper retaining strap

# Attaching the upper retaining strap to the mounting point

- 1. Raise the head restraint if needed.
- 2. Guide the upper retaining strap between the supports of the head restraint.
- 3. Attach the hook of the retaining strap to the mounting eye on the rear seat.
- Tighten the retaining strap by pulling it down.

No persons on the back seat when there is a child restraint system with an upper retaining strap on the front passenger seat.

When there is a child restraint system with an upper retaining strap on the front passenger seat, no one should sit in the back seat directly behind it, otherwise there is an increased risk of injury due to the upper retaining strap.



Upper retaining strap when the backrest is folded down

When the backrest is folded down, do not guide the belt through the head restraint supports on the backrest; otherwise the belt may not secure the child restraint system properly in case of an accident.

This locks various functions so that they cannot be operated from the rear: safety switch, refer to page 46.

# ON 5-DOOR MODELS: LOCK-ING THE DOORS AND WIN-DOWS

#### Rear doors



Push the locking lever on the rear doors up. The door can now be opened from the outside only.

# Safety switch for the rear



Press button on the driver's door if children are being transported in the

rear.

# **DRIVING**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# START/STOP BUTTON

# The concept



Pressing the Start/Stop button switches the ignition on or off and starts the engine.

Steptronic transmission: the engine starts in selector lever posi-

tion P or N with the brake pedal pressed when you press the Start/Stop button.

Manual transmission: the engine starts with the clutch pedal pressed when the Start/Stop button is pressed.

# Ignition on

Steptronic transmission: press the Start/Stop button, and do not press on the brake pedal at the same time.

Manual transmission: press the Start/Stop button without stepping on the clutch pedal.

All vehicle systems are ready for operation.

Most of the indicator and warning lights in the instrument cluster light up for a varied length of time.

To save battery power when the engine is off, switch off the ignition and any unnecessary electronic systems/power consumers.

# **Ignition off**

Manual transmission: press the Start/Stop button again without stepping on the clutch pedal.

Steptronic transmission: shift to selector lever position P, press the Start/Stop button again without stepping on the brake.

All indicator lights in the instrument cluster go out.

To save battery power when the engine is off, switch off the ignition and any unnecessary electronic systems/power consumers.

Ignition automatically cuts off while the vehicle is stationary and the engine is stopped:

- During locking, also with the low beams activated.
- Shortly before the battery is discharged completely, so that the engine can still be started. This function is only available when the low beams are turned off.
- When opening and closing the driver door, if the driver's safety belt is unbuckled and the low beams are turned off.
- ▶ While the driver's safety belt is unbuckled with driver's door open and low beams off.
- ▶ The low beams switch to parking lights after approx. 15 minutes of no use.

# Radio ready state

Activate radio-ready state:

When the engine is running: press the Start/ Stop button.

Some electronic systems/power consumers remain ready for operation.

Radio ready state switches off automatically:

- ▶ After approx. 8 minutes.
- When the vehicle is locked using the central locking system.
- Shortly before the battery is discharged completely, so that the engine can still be started.

The radio-ready state remains active if, e.g., the ignition is automatically switched off for the following reasons:

- Opening or closing the driver's door.
- Unfastening of the driver's safety belt.
- When automatically switching from low beams to parking lights.

If the engine is switched off and the ignition is switched on, the system automatically switches to the radio-ready state if the lights are turned off or, if correspondingly equipped, the day-time running lights are activated.

# STARTING THE ENGINE

#### Hints

Enclosed areas

Do not let the engine run in enclosed areas, since breathing in exhaust fumes may lead to loss of consciousness and death. The exhaust gases contain carbon monoxide, an odorless and colorless but highly toxic gas.

Unattended vehicle

Do not leave the vehicle unattended with the engine running; doing so poses a risk of danger.

Before leaving the vehicle with the engine running, set the parking brake and place the transmission in selector lever position P or N to prevent the vehicle from moving. ◀

Repeated starting in quick succession Avoid trying to start the vehicle repeatedly and in quick succession. Otherwise, the fuel is not burned or is inadequately burned, posing a risk of overheating and damage to the catalytic converter. ◀

Do not wait for the engine to warm-up while the vehicle remains stationary. Start driving at moderate engine speeds.

# Steptronic transmission

# Starting the engine

- 1. Depress the brake pedal.
- 2. Engage selector lever position P or N.
- 3. Press the Start/Stop button.

The ignition is activated automatically for a certain time and is stopped as soon as the engine starts.

### **Manual transmission**

# Starting the engine

- 1. Depress the brake pedal.
- Press on the clutch pedal and shift to neutral.
- Press the Start/Stop button.

The ignition is activated automatically for a certain time and is stopped as soon as the engine starts.

# **ENGINE STOP**

#### Hints

Take the remote control with you

Take the remote control with you when
leaving the vehicle so that children, e.g., cannot start the engine.

✓

A

Apply parking brake and further secure the vehicle if needed.

Set the parking brake firmly when parking; otherwise, the vehicle could roll. On steep upward and downward inclines, further secure the ve-

hicle, e.g., by turning the steering wheel in the direction of the curb. ◀

# Before driving into a car wash

So that the vehicle can roll into a car wash observe instructions for going into an automatic car wash, refer to page 214.

#### Steptronic transmission

### Switching off the engine

- 1. Engage selector lever position P with the vehicle stopped.
- Press the Start/Stop button.
   The engine is switched off.
   The radio-ready state is switched on.
- 3. Set the parking brake.

#### **Manual transmission**

# Switching off the engine

- 1. With the vehicle at a standstill, press the Start/Stop button.
  - The engine is switched off.
  - The radio-ready state is switched on.
- 2. Shift into first gear or reverse.
- 3. Set the parking brake.

# **AUTO START/STOP FUNCTION**

# The concept

The Auto Start/Stop function helps save fuel. The system switches off the engine during a stop, e.g., in traffic congestion or at traffic lights. The ignition remains switched on. The engine starts again automatically for driving off.

# **Automatic operation**

After every start of the engine using the Start/ Stop button, the Auto Start/Stop function is in the last selected state, refer to page 63. When the Auto Start/Stop function is active, it is available when the vehicle is traveling faster than about 3 mph, approx. 5 km/h.

#### **Engine stop**

The engine is switched off automatically during a stop under the following conditions:

#### Manual transmission:

- Neutral is engaged and the clutch pedal is not pressed.
- ➤ The driver's safety belt is buckled or the driver's door is closed.

#### Steptronic transmission:

- The selector lever is in selector lever position D.
- Brake pedal remains depressed while the vehicle is stopped.
- ➤ The driver's safety belt is buckled or the driver's door is closed.

In order to be able to release the brake pedal, engage lever in position P. The engine remains off.

To continue driving depress the brake pedal. When a gear is engaged, the engine starts automatically.

The air flow from the air conditioner is reduced when the engine is switched off.

# Displays in the instrument cluster



The display indicates that the Auto Start/Stop function is ready for an Automatic engine start.



The display indicates that the conditions for an automatic engine stop have not been met.

#### **Functional limitations**

The engine is not switched off automatically in the following situations:

- External temperature too low.
- ➤ The external temperature is high and automatic climate control is running.
- The car's interior has not yet been heated or cooled to the required level.
- The engine is not yet at operating temperature.
- The wheels are at a sharp angle or the steering wheel is being turned.
- After driving in reverse.
- Fogging of the windows when the automatic climate control is switched on.
- ▷ The vehicle battery charge is very low.
- At higher elevations.
- ▷ The engine compartment lid is unlocked.
- ▶ The parking assistant is activated.
- Stop-and-go traffic.
- Selector lever in selector lever position R, N or M/S.

# Starting the engine

The engine starts automatically under the following conditions:

- Manual transmission:The clutch pedal is pressed.
- Steptronic transmission:
   By releasing the brake pedal.

After the engine starts, accelerate as usual.

# Safety mode

After the engine switches off automatically, it will not start again automatically if any one of the following conditions are met.

- ▶ The driver's safety belt is unbuckled and the driver's door is open.
- The hood was unlocked.

Some indicator lights light up for a varied length of time.

The engine can only be started via the Start/ Stop button.

#### **Functional limitations**

Even if driving off was not intended, the deactivated engine starts up automatically in the following situations:

- Excessive warming of the car's interior when the cooling function is switched on.
- ▶ The steering wheel is turned.
- Steptronic transmission: change from selector lever position D to R, N or M/S.
- Steptronic transmission: change from selector lever position P to R, N, D or M/S.
- ▶ The vehicle begins rolling.
- ▶ Fogging of the windows when the automatic climate control is switched on.
- Excessive cooling of the car's interior when the heating is switched on.
- Manual transmission: low brake vacuum pressure; this can occur, e.g., if the brake pedal is depressed a number of times in succession.

# Switching the system on/off

# Using the button





Press button.

 LED comes on: Auto Start/Stop function is deactivated.

The engine is started during an automatic engine stop.

The engine can only be stopped or started via the Start/Stop button.

▶ LED goes out: Auto Start/Stop function is activated.

# Switching off the vehicle during an automatic engine stop

During an automatic engine stop, the vehicle can be switched off permanently, e. g., when leaving it.

- Steptronic transmission: engage selector lever position P.
- Press the Start/Stop button. The ignition is switched off. The Auto Start/Stop function is deactivated.
- Manual transmission: shift into first gear or reverse.
- 4. Set the parking brake.

Engine start as usual via Start/Stop button.

#### **Automatic deactivation**

In certain situations, Auto Start/Stop function is deactivated automatically for safety reasons as if the driver were absent.

#### Malfunction

The Auto Start/Stop function no longer switches off the engine automatically. A Check Control message is displayed. It is possible to continue driving. Have the system checked.

# BRAKE

The indicator lamp lights up red. The parking brake is set.



Lower lamp: indicator lamp in Canadian models

# Releasing



Raise lever slightly, press the button and guide the lever down.

#### Hints

Use while driving

On rare occasions if it is necessary to use the parking brake while driving, do not use excessive force when applying it. When using it, keep the button on the lever depressed.

Otherwise, using excessive force when applying the parking brake may cause the rear wheels to lock, resulting in fishtailing.

To prevent corrosion and one-sided brake action, lightly apply the parking brake periodically while coasting, if traffic conditions permit.

The brake lights will not light up if the parking brake is set.

# **PARKING BRAKE**

# **Applying**

The lever automatically engages after being pulled up.

# TURN SIGNAL, HIGH BEAMS, **HEADLIGHT FLASHER**

# Turn signal

# Using turn signals



Press the lever beyond the resistance point. To switch off manually, press the lever to the resistance point.

Unusually rapid flashing of the indicator lamp indicates that a turn signal bulb has failed.

# Triple turn signal activation

Press the lever to the resistance point.

The turn signal flashes three times.

The function can be activated or deactivated. On the Control Display:

- 1. 🚳 "Settings"
- 2. "Lighting"
- 3. "Triple turn signal"

Settings are stored for the profile currently in use.

# Signaling briefly

Press the lever to the resistance point and hold it there for as long as you want the turn signal to flash.

# High beams, headlight flasher



- High beams, arrow 1.
- Headlight flasher, arrow 2.

# WASHER/WIPER SYSTEM

Switching the wipers on/off and brief wipe

#### Hints



Do not activate wipers if frozen to windshield

Do not switch on the wipers if they are frozen to the windshield; otherwise, the wiper blades and the wiper motor may be damaged. ◀

Do not activate wipers on dry windshield Do not use the wipers if the windshield is dry, as this may damage the wiper blades or cause them to become worn more quickly.



Do not activate wipers with wipers folded away

Do not switch on the wipers if they are folded away, otherwise the hood or the wipers may be damaged.◀

#### Switching on



Push wiper lever up.

The lever automatically returns to its initial position when released.

- Normal wiper speed: push up once.
   The wipers switch to intermittent operation when the vehicle is stationary.
- Fast wiper speed: press up twice or press once beyond the resistance point.
   Wipers change to normal speed when vehi-

# Switch off and brief wipe

cle comes to standstill.



Push wiper lever down.

The lever automatically returns to its initial position when released.

- ▷ Single wipe: press down once.
- To switch off normal wipe: press down once.
- To switch off fast wipe: press down twice.

#### Interval mode or rain sensor

# The concept

Without the rain sensor, the frequency of the wiper operation is preset.

The rain sensor automatically controls the time between wipes depending on the intensity of the rainfall. The sensor is located on the windshield, directly behind the interior rearview mirror.

# **Activating/deactivating**



Press button on the wiper lever.

The LED in the wiper lever lights up and wiping starts. When wipers are frozen to windshield, wiper operation is deactivated.

Deactivate the rain sensor in car washes
Deactivate the rain sensor when passing
through an automatic car wash; otherwise, unintentional wiping can cause damages.

# Setting the frequency or sensitivity of the rain sensor



Turn the thumbwheel.

# Washing the windshield



Pull the wiper lever towards you.

The system sprays washer fluid on the windshield and activates the wipers briefly.



Do not use the washer system at freezing temperatures

Do not use the washers if fluid could freeze onto the windshield which might impede your viewing field. Therefore use antifreeze fluid.

Avoid using the washer when the reservoir is empty; operation might damage pump. ◀

#### Windshield washer nozzles

The windshield washer nozzles are automatically heated while the ignition is switched on.

# Rear window wiper

Switching on the rear window wiper



Turn the switch from idle position 0 upward, arrow 1: interval mode. When reverse gear is engaged, the system switches to continuous operation.

## Cleaning rear window

In interval mode: turn the switch further, arrow 2. The switch automatically returns to its interval position when released.


In idle position: turn switch downward, arrow 3. The switch automatically returns to its idle position when released.

### Fold-out position of the wipers

Helpful when changing the wiper blades or under frosty conditions, e.g.

- 1. Switch the ignition on and off again.
- 2. With icy conditions make sure that blades are not frozen to the windshield.
- Press the wiper lever up beyond the point of resistance and hold it for approx. 3 seconds, until the wiper remains in a nearly vertical position.

After the wipers are folded back down, the wiper system must be reactivated.



1. Switch on the ignition.

are activated.◀

2. Push wiper lever down. Wipers move to their resting position and are ready again for operation.

# **WASHER FLUID**

#### Hints

Antifreeze for washer fluid

Antifreeze is flammable and can cause injury if it is used incorrectly.

Therefore, keep it away from possible sources of ignition.

Only keep it in the closed original container and inaccessible to children.

Follow the notes and instructions on the container.

United States: The washer fluid mixture ratio is regulated by the U.S. EPA and many individual states; do not exceed the allowable washer fluid dilution ratios limits that apply. Follow the usage instructions on the washer fluid container. Use BMW's Windshield Washer Concentrate or the equivalent. ◀

Adding washer fluid

Only add washer fluid when the engine is cool, and then close the cover completely to avoid contact between the washer fluid and hot engine parts.

Otherwise, there is a danger of fire and a risk to personal safety if the fluid is spilled. ◀

#### Washer fluid reservoir



All washer nozzles are supplied from one reservoir

Fill with a mixture of windshield washer concentrate and tap water and – if required – with a washer antifreeze, according to the manufacturer's recommendations.

Mix the washer fluid before adding to find the right mixture.

Do not add windshield washer concentrate and antifreeze undiluted and do not fill with pure water; this could damage the wiper system.

Do not mix window washer concentrates of different manufacturers because they can clog the windshield washer nozzles. Recommended minimum fill quantity: 0.2 US gal/1 liter.

# **MANUAL TRANSMISSION**

# Shifting

Shifting into 5th or 6th gear
When shifting into 5th or 6th gear, push
the gearshift lever to the right; otherwise, inadvertent shifting into 3rd or 4th gear could lead
to engine damage.

# Reverse gear

Select only when the vehicle is stationary.

To overcome the resistance push the selector lever dynamically to the left and engage the reverse gear.

# STEPTRONIC TRANSMISSION

# Selector lever positions

#### **D** Drive

Selector lever position for normal vehicle operation. All gears for forward travel are activated automatically.

#### R is Reverse

Select only when the vehicle is stationary.

#### N Neutral:

The vehicle may roll. Use in automatic car washes, e.g.

#### P Park

Select only when the vehicle is stationary. The drive wheels are blocked.

Before exiting the vehicle, make sure that selector lever position P is set. Otherwise, the vehicle may begin to move.

#### **Kickdown**

Kickdown is used to achieve maximum driving performance. Step on the accelerator pedal beyond the resistance point at the full throttle position.

#### **Engaging a selector lever position**



Press on the brake pedal until you start driving

To prevent the vehicle from creeping after you select a gear, maintain pressure on the brake pedal until you are ready to start. ◀

The selector lever can only be taken out of selector lever position P if the ignition is on or the engine is running.

With the vehicle is stationary, press on the brake pedal before shifting out of selector lever position P or N; otherwise, the selector lever is blocked: shift lock.

A lock prevents inadvertent shifting into selector lever position P or R.

# **Canceling the lock**



Press button on the front of the selector lever, arrow.

#### Sport program and manual mode M/S

#### **Activating the sport program**



Press the selector lever to the left out of selector lever position D.

The engaged selector lever position, such as S1, is displayed in the instrument cluster.

The sport program of the transmission is activated.

### Activating the M/S manual mode

- Press the selector lever to the left out of selector lever position D.
- Push the selector lever forward or backward.

Manual mode becomes active and the selector lever position is changed.

The engaged selector lever position is displayed in the instrument cluster, for instance M1.

Once maximum engine speed is attained, M/S manual mode is automatically upshifted as needed.

# Switching to manual mode

- To shift down: press the selector lever forward.
- ➤ To shift up: pull the selector lever rearwards.

Gears will only be shifted at appropriate engine and road speeds, for example downshifting is not possible if the engine speed is too high. The selected gear is briefly displayed in the instrument cluster, followed by the currently selected gear.

# Manual mode M/S: prevent automatic upshifting

Once maximum engine speed is attained, M/S manual mode is automatically upshifted as needed.

For vehicles with Steptronic Sport transmission, automatic shift operations are not performed if one of the following conditions is met:

- DSC is deactivated.
- TRACTION is activated.

In addition, the kickdown is deactivated.

With the respective transmission version, the lowest possible gear can be selected by simultaneously operating the kickdown and the left shift paddle. However, this effect is not produced via the shift paddles when switching briefly from D to manual mode.

# Ending the sport program/manual mode

Push the selector lever to the right.

D is displayed in the instrument cluster.

# Shift paddles for Steptronic Sport transmission



The shift paddles on the steering wheel allow you to shift gears quickly while keeping both hands on the steering wheel.

> Shift up: briefly pull right shift paddle.

- Shift down: briefly pull left shift paddle.
- With the respective transmission version, the lowest possible gear can be selected by pulling and holding the left shift paddle.

Gears will only be shifted at appropriate engine and road speeds, for example downshifting is not possible if the engine speed is too high.

The selected gear is briefly displayed in the instrument cluster, followed by the current gear.

If the shift paddles on the steering wheel are used to shift gears in automatic mode, the transmission temporarily switches to manual mode.

If the selector lever is still in selector lever position D with the respective transmission version, it is possible to switch back into the automatic mode:

- Pull and hold right shift paddle.
   Or
- ▷ In addition to the briefly pulled right shift paddle, briefly pull the left shift paddle.

In the manual mode, after conservative driving for a certain amount of time or if there has been no acceleration or shifting of the shift paddles within a certain amount of time, the transmission switches back to automatic mode.

# Displays in the instrument cluster




The selector lever position is displayed, e.g.: P.

# Manually release the transmission lock

Should the selector lever be blocked in selector lever position P despite the ignition being turned on, the brake being depressed and the unlock button being pressed, the transmission lock can be manually canceled:

Before unlocking the transmission lock manually, engage the parking brake forcefully to prevent the vehicle from rolling away.

- 1. Loosen the sleeve of the selector lever.
- 2. Pull the sleeve over the selector lever. Unplug the cable connector if needed.
- Using the screwdriver from the onboard vehicle tool kit, refer to page 197, press the yellow release lever downward, arrow.



- Move the selector lever slightly toward the rear; to do this press the unlock button on the front of the selector lever.
  - Release the release lever.
- Bring the selector lever into the desired position.

# Steptronic Sport transmission: Launch Control

#### The concept

Component wear

Launch Control enables optimum acceleration on surfaces with good traction.

#### Hints

Do not use Launch Control too often; otherwise, this may result in premature wear of components due to the high stress placed on the vehicle.

Do not use Launch Control during the break-in, refer to page 154, period.

To increase vehicle stability, activate DSC again as soon as possible.

An experienced driver may be able to achieve better acceleration values in DSC OFF mode, refer to page 111.

### Requirements

Launch Control is available when the engine is warmed up, that is, after uninterrupted driving of at least 6 miles/10 km.

To start with Launch Control do not steer the steering wheel.

#### Start with launch control

While the engine is running:

- 1. Press button and select SPORT with Driving Dynamics Control, refer to page 113.
  - The instrument cluster displays TRACTION in combination with SPORT. The DSC OFF indicator lamp lights up.
- 2. Engage selector lever position S.
- 3. With the left foot, forcefully press down on the brake.
- Step on the accelerator pedal beyond the resistance point at the full throttle position.
   A flag symbol is displayed in the instrument cluster.
- The starting engine speed adjusts. Within
   seconds, release the brake.

Before using Launch Control, allow the transmission to cool down for approx. 5 minutes.


# **DISPLAYS**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **INSTRUMENT CLUSTER**


#### Overview, instrument cluster



- 1 Tachometer 77
- 2 Messages, e.g. Check Control
- 3 Speedometer

- 4 Fuel gauge 77
- 5 Display/reset miles 77
- 6 Electronic displays 73

#### **Electronic displays**



1 Driver assistance systems
Messages, e.g. Check Control
Time 77
External temperature 77
Selection lists 81
Total miles/trip odometer 77

- On-board computer 81
- 2 Selector lever position display 68 Gear shift indicator 79
- 3 Driving Dynamics Control 113 Status

### **CHECK CONTROL**

# The concept

The Check Control system monitors functions in the vehicle and notifies you of malfunctions in the monitored systems.

A Check Control message is displayed as a combination of indicator or warning lights and text messages in the instrument cluster and in the Head-up Display.

In addition, an acoustic signal may be output and a text message may appear on the Control Display.

### Indicator/warning lights

#### General information

The indicator and warning lights can light up in a variety of combinations and colors.

Several of the lights are checked for proper functioning and light up temporarily when the engine is started or the ignition is switched on.

# **Red lights**

#### Safety belt reminder



Flashing or illuminated: safety belt on the driver or passenger side is not buckled. The safety belt reminder can also be activated if objects are placed on the front passenger seat.

Make sure that the safety belts are positioned correctly.

#### Airbag system



Airbag system and belt tensioner are defective.

Have the vehicle checked by the service center immediately.

#### Parking brake, brake system



The parking brake is set.

For additional information, refer to Release parking brake, refer to page 64.



#### Front-end collision warning



Illuminated: advance warning is issued, e.g., when there is the impending danger of a collision or the distance to the

vehicle ahead is too small.

Increase distance.

Flashing: acute warning of the imminent danger of a collision when the vehicle approaches another vehicle at a relatively high differential speed.

Intervention by braking or make an evasive maneuver.

#### **Pedestrian warning**



If a collision with a person detected in this way is imminent, the symbol lights up and a signal sounds.

#### **Orange lights**

#### **Active Cruise Control**



The number bars shows the selected distance from the vehicle driving ahead.

For more information, see Camera-based cruise control, ACC, refer to page 115.

#### **Vehicle detection, Active Cruise Control**



Illuminated: vehicle driving ahead detected.

Flashing: the conditions are not adequate for operating the system.

The system was deactivated but applies the brakes until you actively resume control by pressing on the brake pedal or accelerator pedal.

#### Yellow lights

#### **Anti-lock Braking System ABS**



ABS

Avoid abrupt braking if possible. Braking force boost in some cases defective. Stop carefully. Take into account longer brake travel. Have this checked by the service center immediately.

#### **DSC Dynamic Stability Control**



Flashing: DSC controls the drive and braking forces. The vehicle is stabilized. Reduce speed and adapt driving profile

to the driving circumstances.

Illuminated: DSC failed. Have the system checked by the service center.

For additional information, refer to Dynamic Stability Control DSC, refer to page 111.

# DSC Dynamic Stability Control is deactivated or DTC Dynamic Traction Control is activated



Dynamic Stability Control DSC is switched off or Dynamic Traction Control DTC is switched on.

For additional information, refer to Dynamic Stability Control, refer to page 111, and Dynamic Traction Control, refer to page 112.

#### **Flat Tire Monitor FTM**



The Flat Tire Monitor signals a loss of tire inflation pressure in a tire.

Reduce your speed and stop cautiously.

Avoid sudden braking and steering maneuvers.

For additional information, refer to Flat Tire Monitor, refer to page 102.

#### **Tire Pressure Monitor TPM**



Illuminated: the Tire Pressure Monitor signals a loss of tire inflation pressure in a tire

Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.

Flashing and then continuously illuminated: no flat tire or loss of tire inflation pressure can be detected.

- Interference through systems or devices with the same radio frequency: after leaving the area of the interference, the system automatically becomes active again.
- ▶ TPM could not conclude the reset: perform the reset of the system again.
- ▷ A wheel without TPM electronics is fitted: have the service center check it if needed.
- Malfunction: have the system checked by your service center.

For additional information, refer to Tire Pressure Monitor, refer to page 98.

#### Steering system



Steering system in some cases defective.

Have the steering system checked by the service center.

#### **Engine functions**



Illuminated: vehicle generates increased exhaust emissions. It is possible to continue driving. Exhaust system in

some cases defective.

Flashing: increased engine load damages the catalytic converter. Continue driving with a lower engine load. Possible engine problem.

Have the vehicle checked by the service center.

For additional information, refer to On-board Diagnostics socket, refer to page 196.

# **Green lights**

#### **Turn signal**



Turn signal on.

Unusually rapid flashing of the indicator lamp indicates that a turn signal bulb

has failed.

For additional information, refer to Turn signal, refer to page 65.

#### Parking lights, headlight control



Parking lights or headlights are activated.

For additional information, refer to Parking lights/low beams, headlight control, refer to page 90.

#### Front fog lights



Front fog lights are activated.

For additional information, refer to Front fog lights, refer to page 93.

#### **High-beam Assistant**



High-beam Assistant is switched on. High beams are activated and off automatically as a function of the traffic sit-

uation.

For additional information, refer to High-beam Assistant, refer to page 92.

#### **Cruise control**



The system is switched on. It maintains the speed that was set using the control elements on the steering wheel.

#### **Blue lights**

#### **High beams**



High beams are activated.

For additional information, refer to High beams, refer to page 65.

### **General lamps**



At least one Check Control message is displayed or is stored. The symbol is shown in the display of the instrument

cluster.

#### **Text messages**

Text messages in combination with a symbol in the instrument cluster explain a Check Control message and the meaning of the indicator and warning lights.

# Supplementary text messages

Additional information, such as on the cause of an error or the required action, can be called up via Check Control.

With urgent messages the added text will be automatically displayed on the Control Display.

#### **Symbols**

Within the supplementary text, the following functions can be selected independent of the check control message.

- Display additional information about the Check Control message in the Integrated Owner's Manual.
- ▷ Service request"

  Contact the service partner.
- ▷ S "Roadside Assistance"
  Contact Roadside Assistance.

# **Hiding Check Control messages**



Press the onboard computer button on the turn signal lever.

- Some Check Control messages are displayed continuously and are not cleared until the malfunction is eliminated. If several malfunctions occur at once, the messages are displayed consecutively.
  - These messages can be faded for approx. 8 seconds. After this time, they are displayed again automatically.
- Other Check Control messages are faded automatically after approx. 20 seconds.
   They are stored and can be displayed again later.

# Displaying stored Check Control messages

On the Control Display:

- Wehicle info"
- 2. "Vehicle status"
- 3. A "Check Control"
- 4. Select the text message.

#### Messages after trip completion

Special messages displayed while driving are displayed again after the ignition is switched off.

#### **FUEL GAUGE**



Vehicle tilt position may cause the display to vary.

The arrow beside the fuel pump symbol shows which side of the vehicle the fuel filler flap is on.

Notes on refueling, refer to page 170.

# **TACHOMETER**

Always avoid engine speeds in the red warning field. In this range, the fuel supply is interrupted to protect the engine.

# ODOMETER AND TRIP ODOM-ETER

# The concept

Odometer and trip odometer are displayed in the instrument cluster.

#### Resetting the trip odometer



Press the knob.

- The odometer is displayed when the ignition is switched off.
- When the ignition is switched on, the trip odometer is reset.

### **EXTERNAL TEMPERATURE**



If the indicator drops to  $+37 \,^{\circ}\text{F/}+3 \,^{\circ}\text{C}$ , a signal sounds.

A Check Control message is displayed.

There is an increased risk of ice

on roads.



Ice on roads

Even at temperatures above +37 °F/+3 °C, roads might be icy.

Therefore, drive carefully on bridges and shaded roads, e.g., to avoid the increased risk of an accident. ◀

# TIME



The time is displayed in the instrument cluster.

Setting the time on the Control Display, refer to page 84.

# **DATE**



The date is displayed in the instrument cluster.

Set the date on the Control Display, refer to page 84.

#### **RANGE**

# **Display**



With a low remaining range:

- A Check Control message is displayed briefly.
- With a dynamic driving style e.g., taking curves aggressively - engine operation might vary.

The Check Control message appears continuously below a range of approx. 30 miles/50 km.

A

Refuel promptly

Refuel no later than at a range of 30 miles/50 km or engine operation might fail and damage might occur.

# Displaying the cruising range

- 1. 🚱 "Settings"
- 2. "Instrument cluster"
- 3. "Range"

# CURRENT FUEL CONSUMP-TION

# The concept

Displays the current fuel consumption. Check whether you are currently driving in an efficient and environmentally-friendly manner.

# Displaying the current fuel consumption

- 1. 🕸 "Settings"
- 2. "Instrument cluster"
- 3. "Current consumption"

# **SERVICE REQUIREMENTS**

#### The concept

After the ignition is turned on the instrument cluster briefly displays available driving distance or time to the next scheduled maintenance.

Your service specialist can read the current service requirements from your remote control.

#### **Display**

# **Detailed information on service requirements**

More information on the scope of service required can be displayed on the Control Display. On the Control Display:

- 2. "Vehicle status"
- ≤ "Service required"

Required maintenance procedures and legally mandated inspections are displayed.

Select an entry to call up detailed information.

# **Symbols**

Symbols	Description	
OK	No service is currently required.	
Δ	The deadline for scheduled maintenance or a legally mandated inspection is approaching.	
	The service deadline has already passed.	

# **Entering appointment dates**

Enter the dates for the required inspections.

Make sure that the vehicle's date and time are set correctly.

#### On the Control Display:

- 2. "Vehicle status"
- Service required"
- 4. "§ Vehicle inspection"
- 5. "Date:"
- 6. Adjust the settings.
- 7. Confirm.

The entered date is stored.

### **GEAR SHIFT INDICATOR**

#### The concept

The system recommends the most fuel efficient gear for the current driving situation.

Depending on the vehicle's features and country version of the vehicle, the gear shift indicator is active in the manual mode of the Steptronic transmission and with manual transmission.

Suggestions to shift gear up or down are displayed in the instrument cluster.

# Manual transmission: displaying

Example	Description
3	Fuel efficient gear is set.
3)4	Shift into fuel efficient gear.

#### Steptronic transmission: Displaying

Example	Description
<b>M3</b>	Fuel efficient gear is set.
314	Shift into fuel efficient gear.

## SPEED LIMIT DETECTION

#### The concept

#### **Speed limit detection**

Speed limit detection uses a symbol in the shape of a traffic sign to display the currently detected speed limit. The camera at the base of the interior rearview mirror detects traffic signs at the edge of the road as well as variable overhead sign posts. Traffic signs with extra symbols for wet road conditions, etc. are also detected and compared with the vehicle's onboard data, such as for the rain sensor, and will be displayed depending on the situation.

With the navigation system, the system takes into account the information stored in the navigation data and also displays speed limits present on routes without signs.

Without a navigation system, the system is subject to limitations imposed by technology. Speed limits with extra text characters are always displayed.

#### Hints

Speed limits when towing a trailer are not shown.

Personal judgment
The system cannot serve as a substitute
for the driver's personal judgment of the traffic
situation.

The system assists the driver and does not replace the human eye. ◀

#### At a glance

#### Camera



The camera is found near the interior rearview mirror.

Keep the windshield in the area behind the interior rearriew mirror clean and clear.

#### Switching on/off

- 1. "Settings"
- 2. "Instrument cluster"
- 3. "Speed limit information"

If speed limit detection is switched on, it can be displayed on the info display in the instrument cluster via the computer.

### Display

The following is displayed in the instrument cluster:

### **Speed limit detection**



The last speed limit detected. Without a navigation system the traffic signals are grayed out after curves or longer stretches of roadway.



With navigation system: speed limit detection is not available.



Without navigation system: speed limit detection switched on but no speed limit or cancellation is detected.

Speed limit detection can also be displayed in the Head-up Display.

#### System limits

The system may not be fully functional and may provide incorrect information in the following situations:

- ▷ In heavy fog, rain or snowfall.
- ▶ When signs are concealed by objects.
- When driving very close to the vehicle in front of you.
- ▶ When driving toward bright lights.
- When the windshield behind the interior rearview mirror is fogged over, dirty or covered by a sticker, etc.
- ▷ In the event of incorrect detection by the camera.
- ▶ If the speed limits stored in the navigation system are incorrect.
- ▷ In areas not covered by the navigation system.
- When roads differ from the navigation, such as due to changes in road routing.
- When passing buses or trucks with a speed sticker.
- ▶ If the traffic signs are non-conforming.
- During calibration of the camera immediately after vehicle shipment.

# SELECTION LISTS IN THE IN-STRUMENT CLUSTER

#### The concept

With the buttons on the steering wheel and the display in the instrument cluster the following can be displayed or operated:

- ▷ Current audio source.
- ▷ Redial phone feature.
- > Turn on voice activation system.

It also displays programs of the Driving Dynamics Control.

#### **Display**



# Activating a list and adjusting the setting

Button the steering wheel	Function
❖	Activate the respective list and select the desired settings.
ОК	Confirm the selection.

#### ON-BOARD COMPUTER

# Calling up information on the info display



Press the onboard computer button on the turn signal lever.

Information is displayed in the info display of the instrument cluster.

#### Information at a glance

#### Info display



Repeatedly pressing the button on the turn signal lever calls up the following information in the info display:

- ▶ Range.
- ▶ GREEN Info.
  - When GREEN Mode is activated.
- Average fuel consumption.
- ▷ Current fuel consumption.
- Average speed.
- Date.
- Distance to destination.
   When destination guidance is activated in
- the navigation system.

  > Time of arrival.
- When destination guidance is activated in the navigation system.
- ▷ Speed limit detection.

▷ Speed.

### Adjusting the info display

You can select what information from the computer is to be displayed on the info display of the instrument cluster.

On the Control Display:

- 1. 🗳 "Settings"
- 2. "Instrument cluster"
- 3. Select the desired displays.

#### Information in detail

#### Range

Displays the estimated cruising range available with the remaining fuel.

It is calculated based on your driving style over the last 20 miles/30 km.

#### **GREEN** info

Description of GREEN info, refer to page 164.

### **Average fuel consumption**

This is calculated for the period while the engine is running.

The average fuel consumption is calculated for the distance traveled since the last reset by the on-board comupter.

# Average speed

Periods in which the vehicle is parked with the engine manually stopped are not included in the calculation of the average speed.

# Resetting average values

Press and hold the onboard computer button on the turn signal lever.

# **Engine temperature display**

Displays the current engine temperature, based on a combination of coolant and motor oil temperature. As soon as the optimum operating temperature has been attained, the indicator is in the center position.

If the engine oil or coolant, thus the engine, become too hot, a Check Control message is displayed.

Check the coolant level, refer to page 193.

#### Distance to destination

The distance remaining to the destination is displayed if a destination is entered in the navigation system before the trip is started.

The distance to the destination is adopted automatically.

#### Time of arrival

The estimated time of arrival is displayed if a destination is entered in the navigation system before the trip is started.

The time must be correctly set.

#### **Speed limit detection**

Description of the speed limit detection, refer to page 79, function.

#### **Trip computer**

The vehicle features two types of board computers.

- "Onboard info": the values can be reset as often as necessary.
- "Trip computer": the values provide an overview of the current trip.

# Resetting the trip computer

On the Control Display:

- 2. "Trip computer"
- 3. "Reset": all values are reset.

"Automatically reset": all values are reset approx. 4 hours after the vehicle came to a standstill.

### Display on the Control Display

Display the computer or trip computer on the Control Display.

On the Control Display:

- 2. "Onboard info" or "Trip computer"

# Resetting the fuel consumption and speed

On the Control Display:

- Wehicle info"
- 2. "Onboard info"
- 3. "Consumpt." or "Speed"
- 4. "Yes"

#### **DRIVING EXCITEMENT**

#### The concept

On the Control Display, sport instruments can be displayed, and the vehicle condition can be checked before the use of the SPORT program.

# **Sport instruments**

On the Control Display, values for power and torque are displayed.

# **Displaying sport instruments**

Via onboard monitor:

- 2. "Driving Excitement"
- 3. ( "Sports instruments"

Via the Driving Dynamics Control

- 1. Activating SPORT.
- 2. (Ci "Driving Excitement"
- 3. ( "Sports instruments"

#### Vehicle state

The following vehicle and surrounding area data are automatically checked and evaluated in succession:

- Range.
- Engine temperature.
- ▷ SPORT program state.

Finally, a total evaluation of the vehicle state is displayed.

#### **Checking vehicle state**

Via onboard monitor:

- Wehicle info"
- 2. "Driving Excitement"
- ∠ "Vehicle and surroundings"

Via the Driving Dynamics Control

- 1. Activating SPORT.
- Driving Excitement"
- 3. ∠ok "Vehicle and surroundings"

# **SPEED WARNING**

# The concept

Displays speed limit which, when reached, should cause a warning to be issued.

The warning is repeated if the vehicle speed drops below the set speed limit once by at least 3 mph/5 km/h.

# Displaying, setting or changing the limit

On the Control Display:

- 1. 🕸 "Settings"
- 2. "Speed"
- 3. "Warning at:"

- 4. Turn the controller until the desired limit is displayed.
- 5. Press the controller.

The speed limit is stored.

### Activating/deactivating the limit

On the Control Display:

- 1. 
  Settings"
- 2. "Speed"
- 3. "Warning"
- 4. Press the controller.

### Setting your current speed as the limit

On the Control Display:

- 1. 🕸 "Settings"
- 2. "Speed"
- "Select current speed"
- 4. Press the controller.

The current vehicle speed is stored as the limit.

# SETTINGS ON THE CONTROL DISPLAY

#### **Time**

#### Setting the time zone

- 1. 🦃 "Settings"
- 2. "Time/Date"
- 3. "Time zone:"
- 4. Select the desired time zone.

The time zone is stored.

### Setting the time

- 1. 🕸 "Settings"
- 2. "Time/Date"
- 3. "Time:"

- Turn the controller until the desired hours are displayed.
- 5. Press the controller.
- Turn the controller until the desired minutes are displayed.
- 7. Press the controller.

The time is stored.

### Setting the time format

- 1. 🕸 "Settings"
- 2. "Time/Date"
- 3. "Format:"
- 4. Select the desired format.

The time format is stored.

#### **Date**

#### Setting the date

- 1. Ø "Settings"
- 2. "Time/Date"
- 3. "Date:"
- Turn the controller until the desired day is displayed.
- 5. Press the controller.
- 6. Make the necessary settings for the month and year.

The date is stored.

# Setting the date format

- Settings"
- 2. "Time/Date"
- 3. "Format:"
- 4. Select the desired format.

The date format is stored.

#### Language

#### Setting the language

To set the language on the Control Display:

- 1. 🕸 "Settings"
- 2. "Language/Units"
- 3. "Language:"
- 4. Select the desired language.

Settings are stored for the profile currently in use.

#### Setting the voice dialog

Voice dialog for the voice activation system, refer to page 28.

#### Units of measure

#### Setting the units of measure

To set the units for fuel consumption, route/ distance and temperature:

- 1. 🕸 "Settings"
- 2. "Language/Units"
- 3. Select the desired menu item.
- 4. Select the desired unit.

Settings are stored for the profile currently in use.

# **Brightness**

# **Setting the brightness**

To set the brightness of the Control Display:

- 1. 🕸 "Settings"
- 2. "Control display"
- 3. "Brightness"
- Turn the controller until the desired brightness is set.
- 5. Press the controller.

Settings are stored for the profile currently in use.

Depending on the light conditions, the brightness settings may not be clearly visible.

# LED RING ON THE CENTRAL INSTRUMENT CLUSTER

#### The concept

The LED ring displays light animations to represent specific functions.

#### **Basic displays**

Basic functions, for example the tachometer, can be set to be displayed continually if so desired.

#### **Event displays**

Functions that are only displayed temporarily, for example the volume or temperature settings, can be set as event displays.

Several vehicle assistance functions can also be displayed on the LED ring. This display corresponds with the displays of the function in the respective display.

# **Example: tachometer**

Like the tachometer in the instrument cluster, the light animations of the tachometer's basic display show the current RPMs and the respective RPM warning margins.

# **Display**



- Arrow 1: current RPM.
- Arrow 2: prewarning field.

Arrow 3: warning field.

### Switching on/off LED ring

- 1. 🕸 "Settings"
- "Center Instrument"
- "Center Instrument"

### Adjusting the LED ring

- 1. 
  Settings"
- 2. "Center Instrument"
- 3. "Basic display" or "Event display"
- 4. Select desired setting.

#### Setting the brightness

The brightness can be adjusted when night lighting is active in the instrument cluster.

- 1. 🐉 "Settings"
- "Center Instrument"
- 3. "Brightness"
- 4. Turn the controller.

Settings are stored for the profile currently in use.

# **HEAD-UP DISPLAY**

# The concept



This system projects important information into the driver's field of vision, e.g., the speed.

The driver can quickly absorb information and concentrate on the traffic situation.

#### Hints

Do not move the moving parts manually
Do not move the moving parts manually,
and keep the area of movement of these parts
clear; otherwise, the system is damaged.

✓



Do not place objects on the Head-up Display

Do not place any objects on the Head-up Display, attach them to components of the system or insert them in the system, or else the system can be damaged. ◀

A

Keep the closing path clear

Monitor retraction of the projection lens of the Head-up Display and make sure that the closing path is clear; otherwise, injuries may result. ◄

Follow the instructions for cleaning the Headup Display, refer to page 217.

# **Display visibility**

The visibility of the displays in the Head-up Display is influenced by the following factors:

- ▷ Certain sitting positions.
- Objects on the cover of the Head-up Display.
- Sunglasses with certain polarization filters.
- Wet roads.
- Unfavorable light conditions.

# Switching on/off

When switching on, the projection lens of the Head-up Display is extended. When switching off, the projection lens of the Head-up Display is retracted again.





Press button.

#### **Display**

#### Overview

- ▷ Speed.
- Navigation system.
- Check Control messages.
- ▷ Selection list from the instrument cluster.
- Driver assistance systems.

Some of this information is only displayed briefly as needed.

# Selecting displays in the Head-up Display

On the Control Display:

- 1. 🕸 "Settings"
- 2. "Head-Up Display"
- 3. "Displayed information"
- Select the desired displays in the Head-up Display.

Settings are stored for the profile currently in use.

#### Setting the brightness

The brightness is automatically adjusted to the ambient brightness.

The basic setting can be adjusted manually.

On the Control Display:

- 1. 🕸 "Settings"
- 2. "Head-Up Display"
- 3. "Brightness"
- 4. Turn the controller.

When the low beams are activated, the brightness of the Head-up Display can be additionally influenced using the instrument lighting, refer to page 93.

Settings are stored for the profile currently in use.

# Adjusting the height

On the Control Display:

- 1. 🕸 "Settings"
- 2. "Head-Up Display"
- 3. "Height"
- 4. Turn the controller.

Settings are stored for the profile currently in use.

### Setting the rotation

On the Control Display:

- 1. 🕸 "Settings"
- 2. "Head-Up Display"
- 3. "Rotation"
- 4. Turn the controller.

Settings are stored for the profile currently in use.

# CHRONO PACKAGE IN THE COCKPIT

#### The concept

The Chrono package consists of three display instruments in the cockpit, where the engine oil pressure, the turbocharger boost, and the time are displayed. In addition, intermediate and to-

tal times can be measured using the stop watch.

The display elements of the Chrono package mainly support a sporty driving style, e,g, on racetracks.

#### **Overview**



- Engine oil pressure display
- 2 Turbocharger boost display
- 3 Time/stop watch

#### **Engine oil pressure**

The current engine oil pressure is displayed.

#### **Turbocharger boost**

The current boost of the turbocharger is displayed.


### Stop watch

#### **General information**

The stop watch contains the following features:

- Measuring the total time.
- Measuring and storing of up to nine lap times.
- Displaying the time.
- The red indicator light indicates that the stop watch is active.

#### Overview, buttons



- ▶ MODE button, arrow 1.
- START/STOP button, arrow 2.

#### Displaying the measured times

The times measured using the stop watch are shown in minutes and seconds on the display. For times greater than 60 minutes, the numbers of hours and the minutes with seconds are alternatively displayed.

If the stop watch is running, the seconds are also shown using a seconds pointer in the scale of the display element.

# Measuring the total time

- 1. Press button, arrow 2, to start the stop watch.
- 2. Press button, arrow 2, again to stop the stop watch.

# Lap times

#### **General information**

It is possible to measure and store up to nine lap times. Older lap times are overwritten.

#### Measuring and storing a lap time

- 1. Press button, arrow 2, to start the stop watch.
- 2. Press button, arrow 3, to measure and store a lap time.

The lap time is briefly shown in the display and via the seconds pointer of the stop

watch, e.g., LAP 1 with the measured time. The stop watch continues running in the background.

3. If needed, press button, arrow 3, again to measure a further lap time.

### Calling up lap times

- 1. Press button, arrow 1, repeatedly until LAP 1 is shown on the display.
- 2. Press button, arrow 2, to call up the individual lap times.

#### **Deleting lap times**

- 1. Press button, arrow 1, repeatedly until LAP 1 is shown on the display.
- 2. Press button, arrow 3, to delete all stored lap times.

### Displaying the time

The time is copied from the instrument cluster.

Press button, arrow 1, repeatedly until the time is displayed.

# **LIGHTS**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **OVERVIEW**



- Rear fog lights
- 2 Front fog lights
- 3 Depending on the equipment: automatic headlight control, cornering lights, Highbeam Assistant, welcome lights, daytime running lights
- 4 Lights off, daytime running lights
- 5 Parking lights / daytime running lights
- **6** Depending on the equipment: low beams, welcome lights, High-beam Assistant
- 7 Instrument lighting

# PARKING LIGHTS, CORNER-ING LIGHTS AND ROADSIDE PARKING LIGHTS

#### General information

If the driver door is opened with the ignition switched off, the exterior lighting is automatically switched off at these switch settings.

#### **Parking lights**

Position of switch **ED QE**: the vehicle's lights light up on all sides, e.g., for parking.

Do not use the parking lights for extended periods; otherwise, the battery may become discharged and it would then be impossible to start the engine.

When parking you better turn on just the roadside parking light.

#### Low beams

Position of switch **D** with the ignition switched on: the low beams light up.

# Roadside parking lights



The vehicle can be illuminated on one side.

#### Switching on

With the ignition switched off, press the lever either up or down past the resistance point for approx. 2 seconds.

#### Switch off

Briefly press the lever to the resistance point in the opposite direction.

# WELCOME LIGHTS AND HEADLIGHT COURTESY DE-LAY FEATURE

#### **Welcome lights**

When the vehicle is parked, leave the switch in position D or D: parking and interior lights come on briefly when the vehicle is unlocked depending on the ambient brightness.

#### Activating/deactivating

- 1. 🐼 "Settings"
- 2. "Lighting"
- 3. "Welcome lights"

Settings are stored for the profile currently in use.

# Headlight courtesy delay feature

The low beams stay lit for a short while after the radio-ready state is switched off if the lights are turned off and the headlight flasher is switched on.

# **Setting the duration**

- 1. 🕸 "Settings"
- 2. "Lighting"
- 3. "Pathway lighting:"
- 4. Set length of time.

Settings are stored for the profile currently in use.

# AUTOMATIC HEADLIGHT CONTROL

Position of switch  $\mathbb{S}^{\bullet}$ : the low beams are activated and off automatically, e.g., in tunnels, in twilight or if there is precipitation. The indicator lamp in the instrument cluster lights up.

A blue sky with the sun low on the horizon can cause the lights to be switched on.

The low beams always stay on when the fog lights are activated.

Personal responsibility

The automatic headlight control cannot serve as a substitute for your personal judgment in determining when to turn the lights on in response to ambient lighting conditions.

E. g. the sensors are unable to detect fog or hazy weather. To avoid safety risks under these conditions, you should always switch on the lights manually. ◀

# **DAYTIME RUNNING LIGHTS**

With the ignition switched on, the daytime running lights light up in position 0, 0 or 0. After the ignition is switched off, the parking lights light up in position 0.

# Activating/deactivating

In some countries, daytime running lights are mandatory, so it may not be possible to deactivate the daytime running lights.

On the Control Display:

- 1. Settings"
- 2. "Lighting"
- 3. "Daytime running lamps"

Settings are stored for the remote control currently in use.

## **CORNERING LAMP**

Position of switch ∰: going around corners, the cornering lamp also lights the interior area of the curve. Below a speed of approx.

25 mph/40 km/h when the flasher is switched

25 mph/40 km/h when the flasher is switched on and the steering angle is detected, there is automatic activation.

#### Malfunction

A Check Control message is displayed.

Cornering light is disrupted or failed. Have the system checked as soon as possible.

#### **HIGH-BEAM ASSISTANT**

#### The concept

When the low beams are activated, this system automatically switches the high beams on and off. The procedure is controlled by a camera on the front of the interior rearview mirror. The assistant ensures that the high beams are activated whenever the traffic situation allows. The driver can intervene at any time and switch the high beams on and off as usual.

#### Note

Personal responsibility
The High-beam Assistant cannot serve as a substitute for the driver's personal judgment of when to use the high beams. Therefore,

manually reel off the high beams in situations where required to avoid a safety risk.◀

#### **Activating**



The High-beam Assistant can be activated when the low beams are activated.

- 2. Press button on the turn signal lever, arrow.



The indicator lamp in the instrument cluster lights up.

When the low beams are on, the lights are automatically brightened or dimmed.

The system responds to light from oncoming traffic and traffic driving ahead of you, and to adequate illumination, e.g., in towns and cities.



The blue indicator lamp in the instrument cluster lights up when the system switches on the high beams.

# Switching the high beams on and off manually



- High beams on, arrow 1.

The High-beam Assistant can be switched off when manually adjusting the light. To reactivate the High-beam Assistant, press the button on the turn signal lever.

#### **System limits**

The system is not fully functional in situations such as the following, and driver intervention may be necessary:

- ▷ In very unfavorable weather conditions, such as fog or heavy precipitation.
- When detecting poorly-lit road users such as pedestrians, cyclists, horseback riders and wagons; when driving close to train or ship traffic; and at animal crossings.
- In tight curves, on hilltops or in depressions, in cross traffic or half-obscured oncoming traffic on freeways.
- ▷ In poorly-lit towns and cities and in the presence of highly reflective signs.
- ▶ At low speeds.
- When the windshield behind the interior rearview mirror is fogged over, dirty or covered with stickers, etc.

# **FOG LIGHTS**

# **Front fog lights**

The low beams must be switched on.



Press button. The green indicator lamp lights up.

If the automatic headlight control, refer to page 91, is activated, the low beams will come on automatically when you switch on the front fog lights.

When the high beams or headlight flasher are activated, the front fog lights are not switched on.

#### **Rear fog lights**

The low beams or front fog lights must be switched on.



Press button. The yellow indicator lamp lights up.

If the automatic headlight control, refer to page 91, is activated, the low beams will come on automatically when you switch on the rear fog lights.

#### INSTRUMENT LIGHTING

#### **Adjusting**



The parking lights or low beams must be switched on to adjust the brightness.

Adjust the brightness with the thumbwheel.

# **INTERIOR LIGHTS**

#### **General information**

The interior lights, footwell lights, access lights and courtesy lights are controlled automatically.

Thumb wheel for the instrument lighting controls brightness of some of these features.

#### **Overview**



- Interior lights
- 2 Reading lamp
- 3 Ambient light

### Switching the interior lights on and off



Press button.

To reel off permanently: press the button for approx. 3 seconds.

Switch back on: press button.

### **Reading lights**



Press button.

Reading lights are located in the front next to the interior light.

### **Ambient light**

Depending on your optional features lighting can be adjusted for some lights in the interior.

# Activating/deactivating

On the Control Display:

- 1. 🥨 "Settings"
- "Lighting"
- 3. "Ambient:"

Settings are stored for the profile currently in use.

### **Changing color**



Push the switch forward or back: manual color change.



Push and hold the switch forward or back: automatic color change. Push

the switch again to end color changes.

#### Setting the brightness

The brightness of the ambient light can be adjusted via the thumbwheel for the instrument lighting or on the Control Display.

On the Control Display:


- 1. 🐼 "Settings"
- 2. "Lighting"
- 3. "Brightness:"
- 4. Adjust the brightness.

# **SAFETY**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **AIRBAGS**



- 1 Front airbag, driver
- 2 Front airbag, front passenger
- 3 Head airbag
- Front airbags
- Front airbags help protect the driver and front passenger by responding to frontal impacts in which safety belts alone would not provide adequate restraint.

- 4 Side airbag
- 5 Knee airbags

#### Side airbags

In a lateral impact, the side airbag supports the side of the body in the chest and lap area.

### **Head airbags**

In a lateral impact, the head airbag supports the head.

#### Knee airbag

The knee airbag supports the legs in a frontal impact.

#### **Protective action**

Airbags are not triggered in every impact situation, e.g., in less severe accidents or rear-end collisions.



Information on how to ensure the optimal protective effect of the airbags

- ▶ Keep at a distance from the airbags.
- ▷ Always grasp the steering wheel on the steering wheel rim, holding your hands at the 3 o'clock and 9 o'clock positions, to keep the risk of injury to your hands or arms as low as possible when the airbag is triggered.
- ▶ There should be no person, animals, or objects between an airbag and a person.
- Do not use the cover of the front airbag on the front passenger side as a storage area.
- Dashboard and windshield on the front passenger side must stay clear - do not attach adhesive labels or coverings and do not attach brackets or cables, e. g., for GPS devices or' mobile phones.
- correctly, i.e., keeps his or her feet and legs in the footwell; otherwise, leg injuries might occur when front airbag is activated.
- ▷ Do not place slip covers, seat cushions or other objects on the front passenger seat that are not approved specifically for seats with integrated side airbags.
- ▷ Do not hang pieces of clothing, such as jackets, over the backrests.
- Make sure that occupants keep their heads away from the side airbag and do not rest against the head airbag; otherwise, injuries might occur when airbag is activated.
- Do not remove the airbag system.
- Do not remove the steering wheel.

- Do not apply adhesive materials to the airbag cover panels, do not cover them or modify them in any way.
- Never modify either the individual components or the wiring in the airbag system. This also applies to steering wheel covers, the dashboard, the seats, the roof pillars and the sides of the roofliner. ◀

Even when you follow all instructions very closely, injury from contact with the airbags cannot be ruled out in certain situations.

The ignition and inflation noise may lead to short-term and, in most cases, temporary hearing impairment in sensitive individuals.



Malfunction, deactivation and after deploying the airbags

Do not touch the individual components immediately after the system has been triggered; otherwise, you may risk burns.

Only have the airbags checked, repaired or dismantled and the airbag generator scrapped by the service center or an authorized repair shop for handling explosives.

Non-professional attempts to service the system could lead to failure in an emergency or unintentional activation of the airbag - both may lead to injury.◀

Warnings and information on the airbags are also found on the sun visors.

#### Functional readiness of the airbag system

When the ignition is reel on, the warning lamp in the instrument cluster lights up briefly and thereby indicates the op-

erational readiness of the entire airbag system and the belt tensioner.

# Airbag system malfunctioning

- Warning lamp does not come on when the ignition is turned on.
- ▶ The warning lamp lights up continuously.



In case of a malfunction have airbag system checked immediately.

In case of a malfunction have airbag system checked immediately; otherwise, there is a risk that the system does not function as expected in case of a severe accident.

# Automatic deactivation of the frontseat passenger airbags

The system reads if the front passenger seat is occupied by measuring the human body's resistance.

Front, knee and side airbag on the front passenger's side are either activated or deactivated.

Leave feet in the footwell

Make sure that the front passenger keeps his or her feet in the footwell; otherwise, proper functioning of the front passenger airbag might not be assured. ◀



Child restraint fixing system in the front passenger seat

Before transporting a child on the front passenger seat, refer to the safety notes and instructions for children on the front passenger seat, see Children.

# Malfunction of the automatic deactivation system

When transporting older children and adults, the front-seat passenger airbags may be deactivated in certain sitting positions. In this case, the indicator lamp for the front-seat passenger airbags lights up.

In this case, change the sitting position so that the front-seat passenger airbags are activated and the indicator lamp goes out.

If it is not possible to activate the airbags, have the person sit in the rear.

To enable correct recognition of the occupied seat cushion

- Do not attach covers, cushions, ball mats or other items to the front passenger seat unless they are specifically recommended by your vehicle's manufacturer.
- Do not place any electronic devices on the passenger seat if a child restraint system is to be installed on it.
- Do not place objects under the seat that could press against the seat from below.
- ▷ No moisture in or on the seat.

# Indicator lamp for the front-seat passenger airbags



The indicator lamp for the front-seat passenger airbags indicates the operating state of the front-seat passenger airbags.

The lamp indicates whether the airbags are either activated or deactivated.



- The indicator lamp lights up when a child is properly seated in a child restraint fixing system or when the seat is empty. The airbags on the front passenger side are not activated.
- The indicator lamp does not light up when, e.g., a correctly seated person of sufficient size is detected on the seat. The airbags on the front passenger side are activated.

#### **Detected child seats**

The system generally detects children seated in a child seat, particularly in child seats required by NHTSA when the vehicle was manufactured.

After installing a child seat, make sure that the indicator lamp for the front-seat passenger airbags lights up. This indicates that the child seat has been detected and the front-seat passenger airbags are not activated.

# Strength of the driver's and front-seat passenger airbag

The explosive power that activates driver's/ front passenger's airbags very much depends on the positions of the driver's/front passenger's seat.

With a respective message appearing on Control Display calibrate the front seats to keep the accuracy of this function over the long-term.

#### Calibrating the front seats

A corresponding message appears on the Control Display.

- Move the respective seat all the way forward.
- 2. Move the respective seat forward again. It moves forward briefly.
- 3. Readjust the seat to the desired position.

The calibration procedure is completed when the message on the Control Display disappears.

If the message continues to be displayed, repeat the calibration.

If the message does not disappear after a repeat calibration, have the system checked as soon as possible.

Unobstructed area of movement
Ensure that the area of movement of the seats is unobstructed to avoid personal injury or damage to objects.

✓

# TIRE PRESSURE MONITOR TPM

#### The concept

The system monitors tire inflation pressure in the four mounted tires. The system warns you if there is a significant loss of pressure in one or more tires. For this purpose, sensors in the tire valves measure the tire inflation pressure.

#### Hints

Tire damage due to external factors
Sudden tire damage caused by external
circumstances cannot be recognized in advance.

With use of the system observe further information found under Tire inflation pressure, refer to page 174.

#### **Functional requirements**

The system must have been reset with the correct tire inflation pressure; otherwise, reliable signaling of tire pressure loss is not assured.

Reset the system after each adjustment of the tire inflation pressure and after every tire or wheel change.

Always use wheels with TPM electronics to ensure that the system will operate properly.

# Status display

The current status of the Tire Pressure Monitor TPM can be displayed on the Control Display, e.q., whether or not the TPM is active.

On the Control Display:

- 1. Wehicle info"
- 2. "Vehicle status"
- 3. (!) "Tire Pressure Monitor (TPM)"

The status is displayed.

#### Status control display

Tire and system status are indicated by the color of the tires and a text message on the Control Display.

#### All wheels green

System is active and will issue a warning relative to the tire inflation pressures stored during the last reset.

#### One wheel is yellow

A flat tire or major drop in inflation pressure in the indicated tire.

# All wheels are yellow

A flat tire or major drop in inflation pressure in several tires.

#### Wheels, gray

The system cannot detect a flat tire due to a malfunction.

#### **Status information**

The status control display additionally shows the current tire inflation pressures. It shows the actual values read; they may vary depending on driving style or weather conditions.

#### **Carry out reset**

Reset the system after each adjustment of the tire inflation pressure and after every tire or wheel change.

On the Control Display and on the vehicle:

- 2. "Vehicle status"
- 3. (!) "Perform reset"
- 4. Start the engine do not drive off.
- Reset the tire inflation pressure using "Perform reset".
- 6. Drive away.

The tires are shown in gray and the status is displayed.

After driving faster than 19 mph/30 km/h for a short period, the set tire inflation pressures are accepted as reference values. The resetting process is completed automatically while driving. After successful completion of the reset, the tires appear in green on the Control Display and "Tire Pressure Monitor (TPM) active" is displayed.

The progress of the reset is displayed.

You may interrupt this trip at any time. When you continue the reset resumes automatically.

#### Low tire pressure message



The yellow warning lamp lights up. A Check Control message is displayed.

- There is a flat tire or a major loss in tire inflation pressure.
- A reset of the system was not carried out after a wheel was changed. The system therefore issues a warning based on the tire pressures before the last reset.
- Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.
- 2. Check whether the vehicle is fitted with regular tires or run-flat tires.
  - Run-flat tires, refer to page 182, are labeled with a circular symbol containing the letters RSC marked on the tire's sidewall.



Do not continue driving without run-flat tires

Do not continue driving if the vehicle is not equipped with run-flat tires; continued driving may result in serious accidents. ◀

A low tire inflation pressure might turn on DSC Dynamic Stability Control.

#### Actions in the event of a flat tire

#### **Normal tires**

1. Identify the damaged tire.

Do this by checking the air pressure in all four tires.

The tire pressure gauge of the Mobility System, refer to page 183, can be used for this purpose.

If the tire inflation pressure in all four tires is correct, the Tire Pressure Monitor may not have been initialized. In this case, initialize the system.

If an identification is not possible, please contact the service center.

2. Fix the flat tire using the Mobility System, refer to page 183.

Use of tire sealant, e.g., the Mobility System, may damage the TPM wheel electronics. In this case, have the electronics checked at the next opportunity and have them replaced if needed.

#### **Run-flat tires**

#### **Maximum speed**

You may continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

#### Continued driving with a flat tire

If continuing to drive with a damaged tire:

- Avoid sudden braking and steering maneuvers.
- 2. Do not exceed a speed of 50 mph/80 km/h.
- Check the air pressure in all four tires at the next opportunity.

If the tire inflation pressure in all four tires is shown to be correct, it is possible that the Tire Pressure Monitor did not perform a reset. Then perform the reset.

Possible driving distance with complete loss of tire inflation pressure:

The possible driving distance after a loss of tire inflation pressure depends on cargo load, driving style and road conditions.

A vehicle with an average load has a possible driving range of approx. 50 miles/80 km.

A vehicle with a damaged tire reacts differently, e.g., it has reduced lane stability during braking, a longer braking distance and different self-steering properties. Adjust your driving style accordingly. Avoid abrupt steering maneuvers or driving over obstacles, e.g., curbs, potholes, etc.

Because the possible driving distance depends on how the vehicle is used during the trip, the actual distance may be shorter or longer depending on the driving speed, road conditions, external temperature, cargo load, etc.

Continued driving with a flat tire
Drive moderately and do not exceed a speed of 50 mph/80 km/h.

Your car handles differently when you lose tire inflation pressure, e.g., your lane stability is reduced when braking, braking distances are longer and the self-steering properties will change. ◀

Final tire failure

Vibrations or loud noises while driving can indicate the final failure of a tire. Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident. Do not continue driving and contact your service center.◀

# Required inflation pressure check message

A Check Control message is displayed in the following situations

- ▶ The system has detected a wheel change, but no reset was done.
- Inflation was not carried out according to specifications.
- The tire inflation pressure has fallen below the level of the last confirmation.

#### In this case:

Check the tire pressure and correct as needed. Carry out a reset of the system after a tire change.

#### System limits

The system does not function properly if a reset has not been carried out, e.g., a flat tire is reported though tire inflation pressures are correct.

The tire inflation pressure depends on the tire's temperature. Driving or exposure to the sun will increase the tire's temperature, thus increasing the tire inflation pressure. The tire inflation pressure is reduced when the tire temperature falls again. These circumstances may cause a warning when temperatures fall very sharply.

#### Malfunction



The yellow warning lamp flashes and then lights up continuously. A Check Control message is displayed. No flat tire or loss of tire pressure can be detected.

Display in the following situations:

- A wheel without TPM electronics, such as an emergency wheel, is mounted: have the service center check it if needed.
- Malfunction: have the system checked by your service center.
- ▶ TPM was unable to complete the reset. Reset the system again.
- Interference through systems or devices with the same radio frequency: after leaving the area of the interference, the system automatically becomes active again.

# **Declaration according to NHTSA/FMVSS** 138 Tire Pressure Monitoring System

Each tire, including the spare (if provided) should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the proper tire inflation pressure for those tires.) As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible. and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale. Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

#### FTM FLAT TIRE MONITOR

#### The concept

The system does not measure the actual inflation pressure in the tires.

It detects a tire inflation pressure loss by comparing the rotational speeds of the individual wheels while moving.

In the event of a tire inflation pressure loss, the diameter and therefore the rotational speed of the corresponding wheel changes. This will be detected and reported as a flat tire.

#### **Functional requirements**

The system must have been initialized when the tire inflation pressure was correct; otherwise, reliable flagging of a flat tire is not assured. Initialize the system after each correction of the tire inflation pressure and after every tire or wheel change.

#### Status display

The current status of the Flat Tire Monitor can be displayed on the Control Display, e.g., whether or not the FTM is active.

On the Control Display:

- Wehicle info"
- 2. "Vehicle status"
- 3. (!) "Flat Tire Monitor (FTM)"

The status is displayed.

#### Initialization

When initializing the once set inflation tire pressures serve as reference values in order to detect a flat tire. Initialization is started by confirming the inflation pressures.

Do not initialize the system when driving with snow chains.

On the Control Display:

- "Vehicle status"

- 3. (!) "Perform reset"
- 4. Start the engine do not drive off.
- 5. Start the initialization with "Perform reset".
- 6. Drive away.

The initialization is completed while driving, which can be interrupted at any time.

The initialization automatically continues when driving resumes.

#### Indication of a flat tire



The yellow warning lamp lights up. A Check Control message is displayed.

There is a flat tire or a major loss in tire inflation pressure.

- Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.
- 2. Check whether the vehicle is fitted with regular tires or run-flat tires.

Run-flat tires, refer to page 182, are labeled with a circular symbol containing the letters RSC marked on the tire's sidewall.



Do not continue driving without run-flat tires

Do not continue driving if the vehicle is not equipped with run-flat tires; continued driving may result in serious accidents. ◀

When a flat tire is indicated, DSC Dynamic Stability Control is switched on if needed.

# **System limits**

Sudden tire damage

Sudden serious tire damage caused by external circumstances cannot be recognized in advance.

A natural, even tire inflation pressure loss in all four tires will not be recognized. Therefore, check the tire inflation pressure regularly.

The system could be delayed or malfunction in the following situations:

- ▶ When the system has not been initialized.
- When driving on a snowy or slippery road surface.
- Sporty driving style: spinning traction wheels, high lateral acceleration (drifting).
- ▶ When driving with snow chains.

#### Actions in the event of a flat tire

#### **Normal tires**

1. Identify the damaged tire.

Do this by checking the air pressure in all four tires.

The tire pressure gauge of the Mobility System, refer to page 183, can be used for this purpose.

If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

If an identification is not possible, please contact the service center.

2. Fix the flat tire using the Mobility System, refer to page 183.

#### **Run-flat tires**

#### **Maximum speed**

You may continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

#### Continued driving with a flat tire

If continuing to drive with a damaged tire:

- Avoid sudden braking and steering maneuvers.
- 2. Do not exceed a speed of 50 mph/80 km/h.
- Check the air pressure in all four tires at the next opportunity.

If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

Possible driving distance with complete loss of tire inflation pressure:

The possible driving distance after a loss of tire inflation pressure depends on cargo load, driving style and road conditions.

A vehicle with an average load has a possible driving range of approx. 50 miles/80 km.

A vehicle with a damaged tire reacts differently, e.g., it has reduced lane stability during braking, a longer braking distance and different self-steering properties. Adjust your driving style accordingly. Avoid abrupt steering maneuvers or driving over obstacles, e.g., curbs, potholes, etc.

Because the possible driving distance depends on how the vehicle is used during the trip, the actual distance may be shorter or longer depending on the driving speed, road conditions, external temperature, cargo load, etc.

Continued driving with a flat tire
Drive moderately and do not exceed a speed of 50 mph/80 km/h.

Your car handles differently when you lose tire inflation pressure, e.g., your lane stability is reduced when braking, braking distances are longer and the self-steering properties will change. ◀

Final tire failure

Vibrations or loud noises while driving can indicate the final failure of a tire. Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident. Do not continue driving and contact your service center.

# **INTELLIGENT SAFETY**

# The concept

Intelligent Safety enables central operation of the driver assistance system.

The intelligent safety systems can hel prevent an imminent collision.

- Front-end collision warning with City Braking function, refer to page 105.
- Pedestrian warning with city braking function, refer to page 107

#### Hints

Personal responsibility
The system does not serve as a substitute for the driver's personal judgment of the traffic

situation.

Be aware of the traffic situation and the vehi-

cle's surroundings at all times, otherwise accidents are still possible despite all warnings.

Adapting your speed and driving style
The displays and warnings of the system
do not relieve the driver of the responsibility to
adapt his or her driving speed and style to the
traffic conditions.

Be alert

Due to system limitations, warnings may
be not issued at all, or may be issued late or improperly. Therefore, always be alert and ready
to intervene; otherwise, there is the risk of an
accident.

Tow-starting and towing
For towing the vehicle turn, switch off the
Intelligent Safety systems; otherwise malfunctions of the individual braking systems might

#### At a glance

#### **Button** in the vehicle





Intelligent Safety button

#### Switching on/off

Some Intelligent Safety systems are automatically active after every departure. Some Intelligent Safety systems activate according to the last setting.



Press button briefly:

- The menu for the intelligent safety system is displayed. The systems are individually switched off according to their respective settings.
- LED lights up orange or goes out respective to their individual settings.

Adjust as needed. Individual settings are stored for the profile currently in use.



Press button again:

- All Intelligent Safety systems are activated.



Hold down button:

- All Intelligent Safety systems are turned off.
- ▷ The LED goes out.

# FRONT-END COLLISION WARNING WITH CITY BRAK-ING FUNCTION

#### The concept

The ystem can help prevent accidents. If an accident cannot be prevented, the system will help reduce the collision speed.

The system sounds a warning before an imminent collision and actuates brakes independently if needed.

The automatic braking intervention is done with limited force and duration.

The system is controlled via a camera in the base of the mirror.

The front-end collision warning is available even if cruise control has been deactivated.

With the vehicle approaching another vehicle intentionally the collision warning is delayed avoiding false alarm.


#### **General information**

The system warns at two levels of an imminent danger of collision at speeds from approx.

3 mph/5 km/h. Time of warnings may vary with the current driving situation.

Appropriate braking kicks in at speeds of up to 35 mph/60 km/h.

# **Detection range**



It responds to objects if they are detected by the system.

#### Hints

Personal responsibility

The system does not serve as a substitute for the driver's personal judgment of the traffic situation.

Be aware of the traffic situation and the vehicle's surroundings at all times, otherwise accidents are still possible despite all warnings. ◀

Adapting your speed and driving style
The displays and warnings of the system
do not relieve the driver of the responsibility to
adapt his or her driving speed and style to the
traffic conditions.

Due to system limitations, warnings may be not issued at all, or may be issued late or improperly. Therefore, always be alert and ready to intervene; otherwise, there is the risk of an

Tow-starting and towing
For towing the vehicle turn, switch off the
Intelligent Safety systems; otherwise malfunctions of the individual braking systems might
lead to accidents.

# At a glance

accident.◀

Be alert

#### **Button in the vehicle**





Intelligent Safety button

#### Camera



The camera is found near the interior rearview mirror.

Keep the windshield in the area behind the interior rearriew mirror clean and clear.

#### Switching on/off

# Switching on automatically

The system is automatically active after every driving-off.

# Switching on/off manually



Press button briefly:

- The menu for the intelligent safety system is displayed. The systems are individually switched off according to their respective settings.
- ▷ LED lights up orange or goes out respective to their individual settings.

Adjust as needed. Individual settings are stored for the profile currently in use.



Press button again:

- All Intelligent Safety systems are activated.
- The LED lights up green.



Hold down button:

- All Intelligent Safety systems are turned off.
- The LED goes out.

#### Setting the warning time

The warning time can be set via the onboard monitor.

- 1. 
  Settings"
- 2. "Frontal Coll. Warning"
- 3. Activate the desired warning time on the Control Display.

The selected warning time is stored for the profile currently in use.

#### Warning with braking function

#### **Display**

If a collision with a recognized vehicle is imminent a warning symbol appears in the instrument cluster and in the Head-Up Display.

#### Symbol Measure



The vehicle lights up red: prewarning. Brake and increase distance.



The vehicle flashes red and an acoustic signal sounds: acute warning.

You are requested to intervene by braking or make an evasive maneuver.

#### **Prewarning**

This warning is issued, e.g., when there is the impending danger of a collision or the distance to the vehicle ahead is too small.

The driver must intervene actively when there is a prewarning.

# Acute warning with braking function

Warning of the imminent danger of a collision when the vehicle approaches another object at a relatively high differential speed.

The driver must intervene actively when there is an acute warning. If necessary, the driver is assisted by a minor automatic braking intervention in a possible risk of collision.

Acute warnings can also be triggered without previous prewarning.

# **Braking intervention**

The warning prompts the driver himself/herself to react. During a warning, the maximum braking force is used. Premise for the brake booster is sufficiently quick and sufficiently hard stepping on the brake pedal. The system can assist with some braking intervention if there is risk of a collision. At low speeds vehicles may thus come to a complete stop.

Manual transmission: During a braking intervention up to a complete stop, the engine may be shut down.

The braking intervention is executed only if DSC Dynamic Stability Control is switched on.

The braking intervention can be interrupted by stepping on the accelerator pedal or by actively moving the steering wheel.

Object detection can be restricted. Limitations of the detection range and functional restrictions are to be considered.

# System limits

#### **Detection range**

The system's detection potential is limited.

Thus a warning might not be issued or be issued late.

E. g. the following situations may not be detected:

- Slow moving vehicles when you approach them at high speed.
- Vehicles that suddenly swerve in front of you, or sharply decelerating vehicles.
- Vehicles with an unusual rear appearance.
- > Two-wheeled vehicles ahead of you.

#### **Functional limitations**

The system may not be fully functional in the following situations:

- In heavy fog, rain, sprayed water or snowfall.
- In tight curves.
- ▶ If the camera viewing field or the front windshield are dirty or covered.
- ▶ If the driving stability control systems are deactivated, e.g. DSC OFF.
- ▶ Up to 10 seconds after the start of the engine, via the Start/Stop knob.
- During calibration of the camera immediately after vehicle shipment.
- If there is constant blinding effects because of oncoming light, e. g., from the sun low in the sky.

# **Warning sensitivity**

The more sensitive the warning settings are, the more warnings are displayed. However, there may also be an excess of false warnings.

# PEDESTRIAN WARNING WITH CITY BRAKING FUNCTION

# The concept

The ystem can help prevent accidents with pedestrians.

The system issues a warning in the city driving speed area if there is imminent danger of a collision with pedestrians and includes a braking function.


A camera at the base of the rearview mirror controls the system.

#### General information

In daylight the system warns of possible collisions with pedestrians at speeds from about 6 mph/10 km/h to about 35 mph/60 km/h shortly before a collision the system supports you with a braking intervention.

Under those circumstances it reacts to people who are within the detection range of the system.

#### **Detection range**



The detection area in front of the vehicle is divided into two areas.

- Central area, arrow 1, directly in front of the vehicle.
- Expanded area, arrow 2, to the right and left

A collision is imminent if pedestrians are located within the central area. A warning is issued about pedestrians who are located within the extended area only if they are moving in the direction of the central area.

#### Hints

Personal responsibility
The system does not serve as a substitute for the driver's personal judgment of the traffic situation.

Be aware of the traffic situation and the vehicle's surroundings at all times, otherwise accidents are still possible despite all warnings. ◀

Adapting your speed and driving style
The displays and warnings of the system
do not relieve the driver of the responsibility to
adapt his or her driving speed and style to the
traffic conditions.

#### Be alert

Due to system limitations, warnings may be not issued at all, or may be issued late or improperly. Therefore, always be alert and ready to intervene; otherwise, there is the risk of an accident.

Tow-starting and towing

For towing the vehicle turn, switch off the Intelligent Safety systems; otherwise malfunctions of the individual braking systems might lead to accidents.

#### At a glance

#### **Button in the vehicle**





Intelligent Safety button

#### **Camera**



The camera is found near the interior rearview mirror.

Keep the windshield in the area behind the interior rearview mirror clean and clear.

#### Switching on/off

### Switching on automatically

The system is automatically active after every driving-off.

#### Switching on/off manually



Press button briefly:

- The menu for the intelligent safety system is displayed. The systems are individually switched off according to their respective settings.
- LED lights up orange or goes out respective to their individual settings.

Adjust as needed. Individual settings are stored for the profile currently in use.



Press button again:

- All Intelligent Safety systems are activated.
- The LED lights up green.



Hold down button:

- All Intelligent Safety systems are turned off.
- The LED goes out.

# Warning with braking function

# **Display**

If a collision with a person detected in this way is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.



The red symbol is displayed and a signal sounds.

Intervene immediately by braking or make an evasive maneuver.

# **Braking intervention**

The warning prompts the driver himself/herself to react. During a warning, the maximum braking force is used. Premise for the brake booster is sufficiently quick and sufficiently hard stepping on the brake pedal. The system can assist with some braking intervention if there is risk of a collision. At low speeds vehicles may thus come to a complete stop.

Manual transmission: During a braking intervention up to a complete stop, the engine may be shut down.

The braking intervention is executed only if DSC Dynamic Stability Control is switched on.

The braking intervention can be interrupted by stepping on the accelerator pedal or by actively moving the steering wheel.

Object detection can be restricted. Limitations of the detection range and functional restrictions are to be considered.

## System limits

## **Detection range**

The detection potential of the camera is limited

Thus a warning might not be issued or be issued late.

E. g. the following situations may not be detected:

- ▶ Partially covered pedestrians.
- Pedestrians that are not detected as such because of the viewing angle or contour.
- Pedestrians outside of the detection range.
- Pedestrians having a body size less than 32 in/80 cm.

#### **Functional limitations**

The system may not be fully functional or may not be available in the following situations:

- In heavy fog, rain, sprayed water or snowfall
- ▷ In tight curves.
- If the camera viewing field or the front windshield are dirty or covered.

- If the driving stability control systems are deactivated, e.g. DSC OFF.
- □ Up to 10 seconds after the start of the engine, via the Start/Stop knob.
- During calibration of the camera immediately after vehicle shipment.
- ▶ If there is constant blinding effects because of oncoming light, e. g., from the sun low in the sky.
- When it is dark outside.

# **BRAKE FORCE DISPLAY**

#### The concept



- During normal brake application, the brake lights light up.
- During heavy brake application, the flashers light up in addition.

# DRIVING STABILITY CONTROL SYSTEMS

# **VEHICLE FEATURES AND OP-TIONS**

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your car. e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# **ANTILOCK BRAKE SYSTEM ABS**

ABS prevents locking of the wheels during braking.

The vehicle contains its steering power even during full brake applications, thus increasing active safety.

ABS is operational every time you start the engine.

# **BRAKE ASSISTANT**

When you apply the brakes rapidly, this system automatically produces the greatest possible braking force boost. It reduces the braking distance to a minimum during emergency stop. This system utilizes all of the benefits provided by ABS.

Do not reduce the pressure on the brake pedal for the duration of the emergency stop.

# **DSC DYNAMIC STABILITY** CONTROL

#### The concept

DSC prevents traction loss in the power wheels when driving off and accelerating.

DSC also recognizes unstable vehicle conditions such as fishtailing or nose-diving. Within the physical limits DSC helps to keep the vehicle on a steady course by reducing engine speed and by applying brakes to the individual wheels.

Adjust your driving style to the situation An appropriate driving style is always the responsibility of the driver.

The laws of physics cannot be repealed, not even with DSC.

Therefore, do not reduce the additional safety margin by driving in a risky manner. ◀

# Indicator/warning lights



The indicator lamp flashes: DSC controls the drive and braking forces.

The indicator lamp lights up: DSC has failed.

#### **Deactivating DSC: DSC OFF**

When DSC is deactivated, driving stability is reduced during acceleration and when driving in curves.

To increase vehicle stability, activate DSC again as soon as possible.

# **Deactivating DSC**

Press and hold this button but not longer than approx. 10 seconds, until the indicator lamp for DSC OFF lights up in the instrument cluster and displays DSC OFF.

The DSC system is switched off.

# **Activating DSC**



Press button.

DSC OFF and the DSC OFF indicator

lamp go out.

#### **Indicator/warning lights**

When DSC is deactivated, DSC OFF is displayed in the instrument cluster.



The indicator lamp lights up: DSC is deactivated.

#### **Automatic activation**

When DSC is deactivated, automatic activation occurs in the following situations:

- The vehicle has a flat tire.
- When activating cruise control in TRACTION or DSC OFF mode.

# DTC DYNAMIC TRACTION CONTROL

#### The concept

The DTC system is a version of the DSC where forward momentum is optimized.

The system ensures maximum headway on special road conditions or loose road surfaces, e.g., unplowed snowy roads, but with somewhat limited driving stability.

Activating the Dynamic Traction Control DTC provides maximum traction. Driving stability is limited during acceleration and when driving in curves.

Therefore drive with appropriate caution.

You may find it useful to briefly activate DTC under the following special circumstances:

When driving in slush or on uncleared, snow-covered roads.

- When freeing vehicle from deep snow or driving off from loose grounds.
- > When driving with snow chains.

# Deactivating/activating DTC Dynamic Traction Control

#### Activating DTC



Press button.

TRACTION is displayed in the instrument cluster and the indicator lamp for DSC OFF lights up.

#### **Deactivating DTC**



Press button again.

TRACTION and the DSC OFF indicator lamp go out.

#### PERFORMANCE CONTROL

Performance Control enhances the agility of the vehicle.

To increase maneuverability, with a correspondingly sporty driving style, wheels are braked individually.

# DYNAMIC DAMPING CONTROL

# The concept

The tuning of the suspension can be changed with the system.

# **Programs**

The system offers several different programs. Select the programs via the Driving Dynamics Control, refer to page 113.

#### MID/GREEN

Balanced tuning of the shock absorbers for more comfort.

#### **SPORT**

Consistently sporty tuning of the shock absorbers for greater driving agility.

# DRIVING DYNAMICS CONTROL

#### The concept

The Driving Dynamics Control helps to finetune the vehicle's settings and features. Choose between three different programs. Driving Dynamics Control will activate the particular program.

#### Operating the programs

Driving Dynamics Control	Program
	MID
SPORT « · » GREEN	GREEN
	SPORT

#### **MID**

For balanced tuning.

With each starting operation, MID is activated using the Start/Stop button.

#### **GREEN**

GREEN, refer to page 162, provides consistent tuning to maximize range.

# **Activating GREEN**

Turn Driving Dynamics Control to the right until GREEN is displayed in the instrument cluster.

#### **Configuring GREEN**

#### **Via the Driving Dynamics Control**

- Activate GREEN.
- 2. "Configure GREEN"
- 3. Configure the program.

This configuration is retrieved when GREEN is activated.

#### Via onboard monitor:

- 1. "Settings"
- 2. "GREEN Mode"

#### Or

- 1. Ø "Settings"
- 2. "Driving mode"
- "Configure GREEN"

Configure the program.

This configuration is retrieved when GREEN is activated.

#### **SPORT**

Consistently sporty tuning of the engine control for greater driving agility.

With the appropriate equipment, the tuning of the suspension also changes and SPORT can be individually configured.

The configuration is stored for the profile currently in use.

#### **Activating SPORT**

Turn Driving Dynamics Control to the left until SPORT is displayed in the instrument cluster.

#### **Configuring SPORT**

Depending on your vehicle's optional features, when the display is activated on the Control Display, the SPORT driving mode can be configured for individual specifications.

Activating SPORT.

Select "Configure SPORT".

Configure the program.

SPORT can also be configured before it is activated:

- 1. 🕸 "Settings"
- "Driving mode"
- 3. "Configure SPORT"

This configuration is retrieved when SPORT is activated.

#### Configuring driving program

Settings can be made for the following driving programs in Driving mode:

- GREEN, refer to page 113.
- SPORT, refer to page 113.

#### **Displays**

#### **Program selection**



With Driving Dynamics Control turned on a list of programs is displayed and can be selected.

# Selected program



The instrument cluster displays the selected program.

# Display on the onboard monitor

Program changes can be displayed on the onboard monitor.

- 1. 🥨 "Settings"
- "Control display"
- "Driving mode info"

#### **DRIVE-OFF ASSISTANT**

This system supports driving off on inclines. The parking brake is not required.

- Hold the vehicle in place with the foot brake.
- Release the foot brake and drive off without delay.

After the foot brake is released, the vehicle is held in place for approx. 2 seconds.

For vehicles with respective equipment versions, the possible holding duration amounts to 2 minutes.

Driving off without delay

After releasing the foot brake, start driving without delay, since the drive-off assistant will not hold the vehicle in place for more than approx. 2 seconds and the vehicle will begin to roll back.

# **DRIVING COMFORT**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# CAMERA-BASED CRUISE CONTROL, ACC

### The concept

Use this system to select a desired speed that the vehicle will maintain automatically on clear roads.

To the extent possible, the system automatically adjusts the speed to a slower vehicle ahead of you.

A camera on the interior rear view mirror is used to detect vehicles driving ahead.

The distance that the vehicle maintains to the vehicle ahead of you can be varied.

For safety reasons, it depends on the speed.

To maintain a certain distance, the system automatically decelerates, applies the brakes lightly, or accelerates again if the vehicle ahead begins moving faster.

As soon as the road is clear, the vehicle accelerates to the desired speed.

The speed is also maintained downhill, but may not be maintained uphill if engine power is insufficient.

#### **General information**

The system is functional at speeds beginning at approx. 20 mph/30 km/h.

Depending on the set drive mode, refer to page 113, the features of the cruise control can change in certain areas.

#### Hints

Personal responsibility

Even an active system holds the driver responsible for his or her driving, particularly for staying in your lane, adjusting your speed, keeping your distance and for your driving style all in relation to traffic.

Technically the system has its limits, it cannot independently react to all traffic situations.

Monitor your driving, be on the alert, observe the vehicle surroundings and other traffic and react when needed, e.g. through braking, steering or make evasive maneuvers - risk of accident.

Unfavorable weather conditions
In the event of unfavorable weather and
light conditions, for instance if there is rain,
snowfall, slush, fog or glare, this may result in
poorer recognition of traffic situations as well
as short-term interruptions for vehicles that are
already detected. Drive attentively, and react to
the current traffic situation. Intervene actively
when necessary, e.g., by braking, steering or
making an evasive maneuver, otherwise, there
is the risk of an accident.

#### At a glance

### **Buttons on the steering wheel**

Press button	Function
FR	Cruise control on/off, interrupt, refer to page 116
SET	Store/maintain speed, refer to page 117
RES	Resume speed, refer to page 117
<b>/ā\</b>	Reduce distance, refer to page 117
<b>/</b> \$\	Increase distance, refer to page 117
+	Increase, maintain, and store speed, refer to page 117
_	Reduce, maintain, and store speed, refer to page 117

Buttons are arranged according to vehicle's series, optional features and country specifications.

#### Camera



The camera is found near the interior rearview mirror.

Keep the windshield in the area behind the interior rearview mirror clean and clear.

# Switching on/off and interrupting cruise control

#### Switching on



Press button on the steering wheel.



Display in the instrument cluster lights up.



Display in the instrument cluster lights up. The current speed is adopted as desired speed and displayed with symbol.

Cruise control can be used.

#### Switch off

Deactivated or interrupted system
With deactivated or interrupted system
use your brakes, steering and moves as usual
to avoid the chance of an accident.



Press button on the steering wheel.

- ▷ If active: press twice.
- ▷ If interrupted: press once.

The displays go out. The stored desired speed is deleted.

# Interrupting



Press button on the steering wheel.

The system is automatically interrupted if:

- ▶ The brakes are applied.
- The clutch pedal is depressed for a few seconds or released while a gear is not engaged.
- ▷ Selector lever position N is set.
- DTC Dynamic Traction Control is activated or DSC is deactivated.
- DSC is actively controlling stability.

- The detection range of the camera is impaired, e.g., by soiling, heavy precipitation or glare effects from the sun.
- The vehicle in front decelerates below a speed of approx. 20 mph/30 km/h.

# Maintaining, storing, and changing the speed

#### Hints

Adjusting the desired speed

Modify desired speed to road conditions
and be ready to brake at all times; otherwise,
there is the risk of an accident.

Differences in speed
Large differences in speed relative to
other vehicles cannot be compensated by the
system such as in the following situations:

- When fast approaching a slowly moving vehicle.
- When another vehicle suddenly swerves into the wrong lane. ◀

# Maintaining/storing the speed



Press button.

Or:

Press  $\boxplus$  or  $\sqsubseteq$  button in the interrupted state. When the system is switched on, the current speed is maintained and stored as the desired speed.



The speed is displayed on the symbol. When cruise control is maintained or stored, DSC Dynamic Stability Control

will be turned on if needed.

# Changing the speed

 $\boxplus$  or  $\boxminus$  button: press until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed when the road is clear.

 $\pm$  or  $\Box$  button: hold down to repeat the corresponding action.

#### **Distance**

∧ Select a distance

Adjust the distance according to the traffic and weather conditions; otherwise, there is the risk of an accident. Maintain the prescribed safety distance.

#### **Reduce distance**



Press button repeatedly until the desired distance is set.



The set distance is briefly displayed in the left part of the instrument cluster.

#### Increase distance



Press button repeatedly until the desired distance is set.



The set distance is briefly displayed in the left part of the instrument cluster.

# Calling up the desired speed and distance

#### While driving

Press button with the system interrupted. Desired speed and distance are then continued with these settings. The se-

lected distance is briefly displayed in the info display.

In the following cases, the stored speed value is deleted and cannot be called up again:

- When the system is switched off.
- When the ignition is switched off.

#### Changing between cruise control with/ without distance control

Traffic ahead
The cruise control does not react to traffic driving ahead of you, but instead maintains the stored speed. Take this factor into account – you yourself must react; otherwise, there is the risk of an accident.

To reel over to cruise control:



Press and hold this button, or



Press and hold this button.



The indicator lamp in the instrument cluster comes on and check-control message is displayed as soon as the reel

is made to cruise control.

To reel back to the camera-based cruise control, press one of the buttons.

# Displays in the instrument cluster

# **Desired speed**



In addition to the indicator lamp, the desired speed is displayed in the central information display.

- ▷ The indicator lights up green: the system is active.
- ▶ The indicator lights up orange: the system has been interrupted.
- No display: system is switched off.

#### **Brief status display**



Selected desired speed.

If --- appears briefly on the display for Check Control messages, it is possible that the system requirements are currently not ready for operations.

#### Distance to vehicle ahead of you

Selected distance from the vehicle driving ahead is briefly displayed in the left hand portion of the info display.

#### Distance display



Distance 1



Distance 2



Distance 3



Distance 4

This value is set after the system is switched on.

# **Indicator/warning lights**

Personal responsibility

The indicator and warning lights do not relieve the driver of the responsibility to adapt his or her desired driving speed and style to the traffic conditions.



The vehicle symbol lights up orange: A vehicle has been detected ahead of you.



The vehicle symbol flashes orange: The conditions are not adequate for the system to work.

The system was deactivated but applies the brakes until you actively resume control by

pressing on the brake pedal or accelerator pedal.

The vehicle symbol flashes red and an acoustic signal sounds:

You are requested to intervene by braking or make an evasive maneuver.



The system has been interrupted or distance control is temporarily suppressed because the accelerator pedal is being pressed: a vehicle was not detected.



Distance control is temporarily suppressed because the accelerator pedal is being pressed; a vehicle was de-

tected.

# Changing between cruise control with/ without distance control

Display in the instrument cluster:



Cruise Control without distance control.



Camera-based cruise control with distance control.

# Displays in the Head-up Display

The information from Active Cruise Control can also be displayed in the Head-up Display.

Adjusting the Head-up Display, refer to page **86**.

# **System limits**


# Speed range

The system is best used on well-constructed roads. The system is functional at speeds beginning at approx. 20 mph/30 km/h.

The max. speed that can be set is 85 mph/140 km/h.

Comply with the legal speed limit and safety distance in every situation when using the system.

#### **Detection range**



The detection lidacity of the system and the automatic braking lidacity are limited.

Two-wheeled vehicles for instance might not be detected.


Limited detection potential Because the camera detection system's potential is limited, you should be alert at all times so that you can intervene actively, if needed: otherwise, there is the risk of an accident 🐗

#### **Deceleration**

The system does not decelerate for:

- ▶ Pedestrians, cyclists or similar slow road users.
- ▶ Red traffic lights.
- Cross traffic.
- ▷ Oncoming traffic.
- Unlit vehicles or vehicles with defective lighting at night.

#### **Swerving vehicles**



A vehicle driving in front of you is not detected until it is completely within the same lane as your vehicle.

Swerving vehicles

If a vehicle driving ahead of you suddenly swerves into your lane, the system may not be able to automatically restore the selected distance. This also applies to major speed differences to vehicles driving ahead of you, e.g., when rapidly approaching a truck. When a vehicle driving ahead of you is reliably detected, the system requests that the driver intervene by braking and carrying out evasive maneuvers, if needed. You must react yourself; otherwise, there is the risk of an accident.

#### Cornering



If the desired speed is too high for a curve, the speed is reduced slightly, although curves cannot be anticipated in advance. Therefore, drive into a curve at an appropriate speed.

In tight curves the system offers only restricted detection where a vehicle ahead of you might be detected late or not at all.



When you approach a curve the system may briefly report vehicles in the next lane due to the bend of the curve. If the system decelerates you may compensate it by briefly accelerating. After releasing the gas pedal the system is reactivated and controls speed independently.

#### Malfunction

A Check Control message is displayed if the system fails or was automatically deactivated.

The system may not be fully functional in the following situations:

- ▶ When an object was not correctly detected.
- In heavy fog, rain, sprayed water or snowfall.
- In tight curves.
- ▶ If the camera viewing field or the front windshield are dirty or covered.
- ▶ When driving toward bright lights.
- □ Up to 20 seconds after the start of the engine, via the Start/Stop knob.
- During calibration of the camera immediately after vehicle shipment.

#### CRUISE CONTROL

#### The concept

The system is functional at speeds beginning at approx. 20 mph/30 km/h.

It maintains the speed that was set using the control elements on the steering wheel.

The system brakes on downhill gradients if engine braking is insufficient.

Unfavorable conditions
Do not use the system if unfavorable conditions make it impossible to drive at a constant speed, e.g.:

- On winding roads.
- ▷ In heavy traffic.
- On slippery roads, in fog, snow or rain, or on a loose road surface.

Otherwise, you could lose control of the vehicle and cause an accident. ◀

#### **General information**

The system is functional at speeds beginning at approx. 20 mph/30 km/h.

Depending on the set drive mode, refer to page 113, the features of the cruise control can change in certain areas.

#### **Controls**

#### Overview

Press button	Function
<b>්</b> ෆ	System on/off, interrupt
SET	Store speed
RES	Resume speed

Press button	Function
+	Increasing, maintaining or storing the speed
_	Reducing, maintaining or storing the speed

#### Switching on



Press button on the steering wheel.



The indicator lamp in the instrument cluster lights up.



The current speed is adopted as the desired speed and is displayed with the symbol in the instrument cluster.

Cruise control can be used.

#### Switch off

Deactivated or interrupted system
With deactivated or interrupted system
use your brakes, steering and moves as usual
to avoid the chance of an accident.



Press button.

- ▶ If active: press twice.
- If interrupted: press once.

The displays go out. The stored desired speed is deleted.

### Interrupting



When active, press the button.

The system is automatically interrupted if:

- ▶ The brakes are applied.
- The clutch pedal is depressed for a few seconds or released while a gear is not engaged.
- The gear engaged is too high for the current speed.

- Selector lever position N is set.
- DTC Dynamic Traction Control is activated or DSC is deactivated.
- DSC is actively controlling stability.

Maintaining, storing, and changing the speed

#### Hints

Adjusting the desired speed

Modify desired speed to road conditions
and be ready to brake at all times; otherwise,
there is the risk of an accident.

#### Maintaining/storing the speed



Press button.

Or

 $\boxplus$  or  $\boxminus$  button: press while the system is interrupted.

When the system is switched on, the current speed is maintained and stored as the desired speed.

This is displayed in the instrument cluster.

When cruise control is maintained or stored, DSC Dynamic Stability Control will be turned on if needed.

#### Changing the speed

 $\boxplus$  or  $\boxdot$  button: press repeatedly until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed when the road is clear.

The maximum speed that can be set depends on the vehicle.

#### Resuming the desired speed



Press button.

The stored speed is reached and maintained.

# Displays in the instrument cluster

# Indicator lamp



Depending on how the vehicle is equipped, the indicator lamp in the instrument cluster indicates whether the sys-

tem is switched on.

#### **Desired** speed



The desired speed is displayed together with the symbol.

- ➤ The indicator lights up green: the system is active.
- ▶ The indicator lights up orange: the system has been interrupted.
- ▷ No display: system is switched off.

# **Brief status display**



Selected desired speed.

If --- appears briefly on the display for Check Control messages, it is possible that the system requirements are currently not ready for operations.

# PDC PARK DISTANCE CONTROL

#### The concept

PDC supports you when parking. Slowly approaching an object behind or, with the appropriate equipment, also in front of your vehicle is signaled by:

- Signal tones.
- Visual display.

#### **General information**

Ultrasound sensors in the bumpers measure the distances from objects.

The maneuvering range, depending on obstacles and environmental conditions, is approx. 6 ft/2 m.

An acoustic warning is first given:

- ▶ By the front middle sensors and the two corner sensors at approx. 24 in/60 cm.
- By the rear middle sensors at approx. 5 ft/1.50 m.

#### Hints

Check the traffic situation as well PDC cannot serve as a substitute for the driver's personal judgment of the traffic situation. Check the traffic situation around the vehicle with your own eyes. Otherwise, an accident could result from road users or objects located outside of the PDC detection range.

Loud noises from outside and inside the vehicle may prevent you from hearing the PDC's signal tone. ◀



Avoid driving fast with PDC

Avoid approaching an object too fast.

Avoid driving off fast while PDC is not yet active.

For technical reasons, the system may otherwise be too late in issuing a warning.◀

#### At a glance

#### **Button** in the vehicle





**PDC Park Distance Control** 

#### Switching on/off

#### Switching on automatically

PDC switches on automatically in the following situations:

- ▶ If selector lever position R is engaged when the engine is running.
  - The rearview camera also switches on.
- ▷ If, with the appropriate equipment, obstacles are detected behind or in front of the vehicle by PDC and the speed is slower than approx. 2.5 mph/4 km/h.

You may turn off automatic activation:

- 1. 🐼 "Settings"
- 2. "Parking"
- 3. Select setting.

Settings are stored for the profile currently in use.

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on if needed.

#### Switching on/off manually



Press button.

- ▷ On: the LED lights up.
- Off: the LED goes out.

The rearview camera image is displayed when the reverse gear is engaged by pressing the button.

# Display

# Signal tones

When approaching an object, an intermittent sound indicates the position of the object. E. g. if an object is detected to the left rear of the vehicle, a signal tone sounds from the left rear speaker.

The shorter the distance to the object, the shorter the intervals.

If the distance to a detected object is less than approx. 10 in/25 cm, a continuous tone is sounded.

If objects are located both in front of and to the rear of the vehicle, an alternating continuous signal is sounded.

The signal tone is switched off, when selector lever position P is engaged on vehicles with Steptronic transmission.

#### Volume

The volume of the PDC signal tone can be adjusted similar to the sound and volume settings of the radio.

Settings are stored for the profile currently in use.

# Visual warning

The approach of the vehicle to an object can be shown on the Control Display. Objects that are farther away are already displayed on the Control Display before a signal sounds.

A display appears as soon as Park Distance Control (PDC) is activated.

The range of the sensors is represented in colors: red, green and yellow.

When the image of the rearview camera is displayed, the reel can be made to PDC:

Rear view camera"

#### System limits

#### Limits of ultrasonic measurement

Ultrasonic measuring might not function under the following circumstances:

- ▶ For small children and animals.
- ▶ For persons with certain clothing, e.g. coats.
- With external interference of the ultrasound, e.g. from passing vehicles or loud machines.
- When sensors are dirty, iced over, damaged or out of position.
- Under certain weather conditions such as high relative humidity, rain, snowfall, extreme heat or strong wind.
- With tow bars and trailer couplings of other vehicles.
- With thin or wedge-shaped objects.
- With moving objects.
- ▶ With elevated, protruding objects such as ledges or cargo.
- With objects with corners and sharp edges.
- ▶ With objects with a fine surface structure such as fences.
- ▶ For objects with porous surfaces.

Low objects already displayed, e.g., curbs, can move into the blind area of the sensors before or after a continuous tone sounds.

#### **False warnings**

PDC may issue a warning under the following conditions even though there is no obstacle within the detection range:

- ▷ In heavy rain.
- When sensors are very dirty or covered with ice.
- When sensors are covered in snow.
- ▷ On rough road surfaces.
- ▷ On uneven surfaces, such as speed bumps.
- In large buildings with right angles and smooth walls, e.g., in underground garages.
- In automatic car washes.
- ▷ Through heavy pollution.
- Due to other ultrasound sources, e.g., sweeping machines, high pressure steam cleaners or neon lights.

The malfunction is signaled by a continuous tone alternating between the front and rear speakers. As soon as the malfunction due to other ultrasound sources is no longer present, the system is again fully functional.

#### Malfunction

A Check Control message, refer to page 73, is displayed in the instrument cluster.



Red symbol is displayed, and the range of the sensors is dimmed on the Control Display.

PDC has failed. Have the system checked.

To ensure full functionality:

- Keep the sensors clean and free of ice.
- dimmedDo not put any stickers on sensors.
- When using high-pressure washers, do not spray the sensors for long periods and maintain a distance of at least 12 in/30 cm.

#### REARVIEW CAMERA

#### The concept

The rearview camera provides assistance in parking and maneuvering backwards. The area behind the vehicle is shown on the Control Display.

#### Note

Check the traffic situation as well
Check the traffic situation around the vehicle with your own eyes. Otherwise, an accident could result from road users or objects that are not lidtured by the camera.

#### At a glance

#### **Button in the vehicle**





Rearview camera

#### Camera



The camera lens is located in the handle of the tailgate. The image quality may be impaired by dirt.

Clean the camera lens, refer to page 217.

#### Switching on/off

#### Switching on automatically

With the engine running, engage lever in position P R.

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on if needed.

# Switching on/off manually



Press button.

- On: the LED lights up.
- ▷ Off: the LED goes out.

The PDC is shown on the Control Display.

The rearview camera image is displayed when the reverse gear is engaged by pressing the button.

# Switching the view via the onboard monitor

With PDC activated:

Ray "Rear view camera"

The rearview camera image is displayed.

# **Display on the Control Display**

#### **Functional requirement**

- The rearview camera is switched on.
- The tailgate is fully closed.

# **Activating the assistance functions**

More than one assistance function can be active at the same time.

Parking aid lines

"Parking aid lines"

Lanes and turning radius are indicated.


▷ Obstacle marking

<sup>P</sup>

✓ "Obstacle marking"


Spatially-shaped markings are displayed.

#### **Pathway lines**




- Can be faded into image of the rearview camera.
- Help you to estimate the space required when parking and maneuvering on level roads.
- Depend on the current steering angle and are continuously adjusted to the steering wheel movements.

# **Turning circle lines**



- Can be faded into image of the rearview camera.
- Show the course of the smallest possible turning radius on a level road.
- Only one turning radius line is displayed after the steering wheel is turned past a certain angle.

#### **Obstacle marking**




 Obstacle markings can be faded into the image of the rearview camera.


Their colored margins match the markings of the PDC. This simplifies estimation of the distance to the object shown.

# Parking using pathway and turning radius lines

 Position the vehicle so that the turning radius lines lead to within the limits of the parking space.



Turn the steering wheel to the point where the pathway line covers the corresponding turning radius line.



#### **Display settings**

#### **Brightness**

With the rearview camera switched on:

- 1. 🔅 Select the symbol.
- 2. Turn the controller until the desired setting is reached and press the controller.

#### **Contrast**

With the rearview camera switched on:

- 1. Select the symbol.
- 2. Turn the controller until the desired setting is reached and press the controller.

## **System limits**

# **Detection of objects**

Very low obstacles or high, protruding objects such as ledges may not be recognized by the system.


Assistance functions also take into account data of the PDC.

Follow instructions in the PDC chapter, refer to page 123.

The objects displayed on the Control Display under certain circumstances are closer than they appear. Therefore, do not estimate the distance from the objects on the display.

# **PARKING ASSISTANT**

# The concept



This system assists the driver in parking parallel to the road.

Ultrasound sensors measure parking spaces on both sides of the vehicle.

The parking assistant calculates the best possible parking line and takes control of steering during the parking procedure.

When parking, also take note of the visual and acoustic information issued by the PDC, the parking assistant and, where applicable, the rearview camera, and react accordingly.

A component of the parking assistant is the PDC Park Distance Control, refer to page 123.

#### Hints

Personal responsibility
Even an active system does not relieve the driver from personal responsibility while driving.

Technically the system has its limits, it cannot independently react to all traffic situations.

Monitor your driving, be on the alert, observe the vehicle surroundings and other traffic and react when needed - risk of accident. ◀

Changes to the parking space
Changes to the parking space after it was
measured are not taken into account by the
system.

Therefore, always be alert and ready to intervene; otherwise, there is the risk of an accident. ◀

Transporting cargo

Cargo that extends beyond the perimeter of the vehicle is not taken into account by the system during the parking procedure.

Therefore, always be alert and ready to intervene; otherwise, there is the risk of an accident. ◀

#### Curbs

The parking assistant may steer the vehicle over or onto curb if need be.

Therefore, always be alert and ready to intervene; otherwise, the wheels, tires, or the vehicle may become damaged. ◄

An engine that has been switched off by the Auto Start Stop function is restarted automatically when the parking assistant is activated.

#### Requirements

#### For measuring parking spaces

- Maximum speed while driving forward approx. 22 mph/35 km/h.
- Maximum distance to row of parked vehicles: 5 ft/1.5 m.

#### Suitable parking space

- □ Gaps behind an object that has a min. length of 5 ft/1.5 m.
- □ Gap between two objects with a minimum length of approx. 5 ft/1.5 m.
- Min. length of gap between two objects: your vehicle's length plus approx.
   3.3 ft/1.0 m.
- ⊳ Minimum depth: approx. 5 ft/1.5 m.

# Regarding the parking procedure

- Doors and tailgate closed.
- Parking brake released.
- When parking in parking spaces on the driver's side, the corresponding turn signal must be set.

#### At a glance

#### **Button** in the vehicle





Parking assistant

#### **Ultrasound sensors**



The ultrasound sensors for measuring parking spaces are located on the wheel housing.

To ensure full functionality:

- Keep the sensors clean and free of ice.
- When using high-pressure washers, do not spray the sensors for long periods and maintain a distance of at least 12 in/30 cm.
- ▷ Do not put stickers over sensors.

# Switching on/off

# Switching on with the button



Press button.

The LED lights up.

The current status of the parking space search is indicated on the Control Display.

Parking assistant is activated automatically.

#### Switching on with reverse gear

Shift into reverse.

The current status of the parking space search is indicated on the Control Display.

To activate: 🔊 "Parking Assistant"

#### Switch off

The system can be deactivated as follows:



Press button.

▷ Switch off the ignition.

# **Indicator on the Control Display**

### System activated/deactivated

Symbol	Meaning
P⊕	Gray: the system is not available. White: the system is available but not activated.
Pey	The system is activated.

#### System status



- Colored symbols, see arrows, on the side of the vehicle illustrated. Parking assistant is activated and search for parking space active.
- Control Display shows suitable parking spaces at the edge of the road next to the vehicle symbol. When the parking assistant

is active, suitable parking spaces are highlighted.

The parking procedure is active. Steering control has been taken over by system.

▶ Parking space search is always active whenever the vehicle is moving forward slow and straight, even if the system is deactivated. When the system is deactivated, the displays on the Control Display are shown in gray.

#### Parking using the parking assistant

Check the traffic situation as well

Louds noises outside and inside the vehicle can drown out the parking assistant's and PDC's signals.

Check the traffic situation around the vehicle with your own eyes; otherwise, there is a danger of an accident. ◀

- Switch on the parking assistant and activate it if needed.
  - The status of the parking space search is indicated on the display.
- Follow the instructions on the display.The best possible parking position will
  - come after gear change on the stationary vehicle wait for the automatic steering wheel move.
  - The end of the parking procedure is indicated on the display.
- Adjust the parking position yourself if needed.

# Interrupting manually

The parking assistant can be interrupted at any time:

- ▶ Parking Assistant"
- ▷ P/// Press

Press button.

#### Interrupting automatically

The system is interrupted automatically in the following situations:

- ▶ If the driver grasps the steering wheel or if he takes over steering.
- ▶ If a gear is selected that does not match the instruction on the display.
- ▶ If the vehicle speed exceeds approx. 6 mph/10 km/h.
- Possible on snow-covered or slippery road surfaces.
- ▶ If a maximum number of parking attempts or the time taken for parking is exceeded.
- ▶ If the Park Distance Control PDC displays clearances that are too small.
- When switching into other functions of the radio.

A Check Control message is displayed.

#### Resume

An interrupted parking procedure can be continued if needed.

To do this, follow the instructions on the display.

# System limits

# No parking assistance

The parking assistant does not offer assistance in the following situations:

In tight curves.

#### **Functional limitations**

The system may not be fully functional in the following situations:

- On bumpy road surfaces such as gravel roads.
- ▷ On slippery ground.
- With accumulations of leaves/snow in the parking space.
- ▶ With a mounted emergency wheel.

#### Limits of ultrasonic measurement

Ultrasonic measuring might not function under the following circumstances:

- For small children and animals.
- ▶ For persons with certain clothing, e.g. coats.
- With external interference of the ultrasound, e.g. from passing vehicles or loud machines.
- When sensors are dirty, iced over, damaged or out of position.
- Under certain weather conditions such as high relative humidity, rain, snowfall, extreme heat or strong wind.
- With tow bars and trailer couplings of other vehicles.
- With thin or wedge-shaped objects.
- With moving objects.
- With elevated, protruding objects such as ledges or cargo.
- ▶ With objects with corners and sharp edges.
- ▶ With objects with a fine surface structure such as fences.
- ▷ For objects with porous surfaces.

Low objects already displayed, e.g., curbs, can move into the blind area of the sensors before or after a continuous tone sounds.

The parking assistant may identify parking spaces that are not suitable for parking.

#### Malfunction

A Check Control message is displayed.

The parking assistant failed. Have the system checked.

# **CLIMATE CONTROL**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **AIR CONDITIONER**



- 1 Vent settings
- 2 Air flow
- 3 Temperature
- 4 Seat heating, right 50
- 5 Cooling function

- 6 Recirculated-air mode
- 7 Rear window defroster
- 8 Windshield defroster
- 9 Seat heating, left 50

#### Note

Sufficient ventilation

When remaining in the vehicle for an extended period of time, ensure sufficient external ventilation. Do not continuously use recirculated-air mode; otherwise the air quality in the interior continuously deteriorates and window condensation increases.

#### Climate control functions in detail

#### **Manual air distribution**



Turn the wheel to select the desired program or the desired intermediate setting.

- Upper body region.
- ▶ I Footwell.
- Windows, upper body region, and footwell.

# Defrosts windows and removes condensation

Direct the air distribution toward windows, increase the air flow and temperature, and, if needed, use the cooling function.

#### Air flow, manual



Turn the ring to set the desired air volume.

The higher the rate, the more effective the heating or cooling will be.

The air flow from the air conditioner may be reduced automatically to save battery power.

#### **Temperature**



Turn the ring to set the desired temperature.

# **Cooling function**

The car's interior can only be cooled with the engine running.

A/C Press button.

The air will be cooled and dehumidified and, depending on the temperature setting, warmed again.

Depending on the weather, the windshield may fog up briefly when the engine is started.

The air conditioner produces condensation water, refer to page 156, that will exit from below the car.

#### Recirculated-air mode

You may respond to unpleasant odors or pollutants in the immediate environment by temporarily suspending the supply of outside air. The system then recirculates the air currently within the vehicle.



Press button repeatedly to select an operating mode:

- ▶ LED off: outside air flows in continuously.
- LED on, recirculated-air mode: the supply of outside air into the vehicle is permanently blocked.

To prevent window condensation, recirculated air mode switches off automatically after a certain amount of time, depending on the external temperature.

If the windows fog over, switch off recirculatedair mode and increase the air flow, if needed.

Sufficient ventilation

When remaining in the vehicle for an extended period of time, ensure sufficient external ventilation. Do not continuously use recirculated-air mode; otherwise the air quality in the interior continuously deteriorates and window condensation increases.

#### Rear window defroster

Press button.

The rear window defroster switches off automatically after a certain period of time.

When Green mode, refer to page 162, is activated, the heater output is reduced.

#### Windshield defroster

Press button.

The front window defroster switches off automatically after a certain period of time.

# Switching the system on/off

#### Switch off



Turn wheel for air quantity to the left until the control switches off.

#### Switching on


Set any air volume.

#### Microfilter

In external and recirculated air mode the microfilter filters dust and pollen from the air.

This filter should be replaced during scheduled maintenance, refer to page 195, of your vehicle.

#### **AUTOMATIC CLIMATE CONTROL**



- 1 Temperature, left
- 2 Display
- 3 Air flow, AUTO intensity
- 4 AUTO program
- 5 Air distribution, manual
- 6 Display
- 7 Temperature, right
- 8 Seat heating, right 50

Sufficient ventilation

9 Maximum cooling

- 10 Cooling function
- 11 Automatic recirculated-air control/recirculated-air mode
- 12 Rear window defroster
- 13 Windshield defroster
- 14 Defrosts windows and removes condensation
- **15** Seat heating, left 50

#### Note

When remaining in the vehicle for an extended period of time, ensure sufficient external ventilation. Do not continuously use recirculated-air mode; otherwise the air quality in the interior continuously deteriorates and window condensation increases.

#### Climate control functions in detail

#### **Temperature**



Turn the ring to set the desired temperature.

The automatic climate control reaches this temperature as guickly as possible, if needed

by increasing the cooling or heating output, and then keeps it constant.

Do not rapidly switch between different temperature settings. The automatic climate control will not have sufficient time to adjust the set temperature.

#### Air flow, manual

To manually adjust air flow turn off AUTO program first.



Turn the ring to set the desired air volume.

Automatic climate control displays the selected amount of air flow.

The air flow of the automatic climate control may be reduced automatically to save battery power.

## **AUTO program**

AUTO Press button.

Air flow, air distribution

Air flow, air distribution and temperature are controlled automatically.

Depending on the selected temperature, AUTO intensity and outside influences, the air is directed to the windshield, side windows, upper body, and into the footwell.

The cooling function, refer to page 136, and the automatic recirculation control, refer to page 137, are automatically also switched on in the AUTO program.

To switch off the program: press the button again or manually adjust the air distribution.

#### Intensity of the AUTO program

With the AUTO program activated, the automatic intensity control can be changed.



Turn the ring to set the desired intensity.

The selected intensity is displayed on the automatic climate control.

#### Manual air distribution



Press button repeatedly to select a program:

- Upper body region.
- □ Upper body region and footwell.
- Footwell.
- ▶ Windows and footwell.
- ▶ Windows, upper body region, and footwell.
- ▶ Windows and upper body region.
- Windows.

#### **Maximum cooling**

Press button.

The system is set to the lowest temperature, optimum air flow and air circulation mode.

Air flows out of the vents to the upper body region. The vents need to be open for this.

The function is available with external temperatures beyond approx. 32  $^{\circ}F/0$   $^{\circ}C$  and with the engine running.

Adjust air flow with the program active.

# **Cooling function**

The car's interior can only be cooled with the engine running.

A/C Press button.

The air will be cooled and dehumidified and, depending on the temperature setting, warmed again.

Depending on the weather, the windshield may fog up briefly when the engine is started.

The cooling function is switched on automatically with the AUTO program.

When using the automatic climate control, condensation water, refer to page 156, develops that exits underneath the vehicle.

#### Automatic recirculated-air control/ recirculated-air mode

You may respond to unpleasant odors or pollutants in the immediate environment by temporarily suspending the supply of outside air. The system then recirculates the air currently within the vehicle.



Press button repeatedly to select an operating mode:

- ▶ LEDs off: outside air flows in continuously.
- Left LED on, automatic recirculated-air control: a sensor detects pollutants in the outside air and shuts off automatically.
- Right LED on, recirculated-air mode: the supply of outside air into the vehicle is permanently blocked.

To prevent window condensation, recirculated air mode switches off automatically after a certain amount of time, depending on the external temperature.

If windows are fogged over, switch off the recirculating mode and press the AUTO button.

Make sure that air can flow to the windshield.

Sufficient ventilation
When remaining in the vehicle for an extended period of time, ensure sufficient external ventilation. Do not continuously use recirculated-air mode; otherwise the air quality in the interior continuously deteriorates and window condensation increases.

#### Rear window defroster



Press button.

The rear window defroster switches off automatically after a certain period of time.

When Green mode, refer to page 162, is activated, the heater output is reduced.

#### Windshield defroster

Press button.

The front window defroster switches off automatically after a certain period of time.

# Defrosts windows and removes condensation

MAX V##/ Press button.

Ice and condensation are quickly removed from the windshield and the front side windows.

Adjust air flow with the program active. If the windows fog over, also switch on the cooling function or press the AUTO button.

# Switching the system on/off

#### Switch off



Turn wheel for air quantity to the left until the control switches off.

#### Switching on

Set any air volume.

#### Microfilter/activated-charcoal filter

In external and recirculated air mode the microfilter/activated charcoal filter filters dust, pollen, and gaseous pollutants out of the air.

This filter should be replaced during scheduled maintenance, refer to page 195, of your vehicle.

#### VENTILATION



- ▶ Turn knob for continuous opening and closing of the vents.
- Swivel the vents to alter the direction of the vent flow, arrow.

#### Adjusting the ventilation

- Ventilation for cooling:
   Direct vent in your direction when vehicle's interior is too hot.
- Draft-free ventilation:
   Adjust the vent to let the air flow past you.
- Indirect ventilation:
   If the vents are fully or partly closed, the air is directly routed into the car's interior.

# **PARKED-CAR VENTILATION**

# The concept

The parked-car ventilation ventilates the vehicle interior and lowers its temperature, if needed.

The system can be switched on and off at any external temperature, either directly or by using two preset reel-on times. It remains switched on for 30 minutes.

Open the vents to allow air to flow out.

#### Switching on/off directly

On the Control Display:

- 1. 🕸 "Settings"
- 2. "Climate"
- 3. "Activate comf. ventilation"

**%** The symbol on the automatic climate control flashes if the system is switched on.

### Preselecting the reel-on time

On the Control Display:

- 1. 🚱 "Settings"
- 2. "Climate"
- 3. "Timer 1:" or "Timer 2:"
- 4. Set the desired time.

#### Activating the reel-on time

On the Control Display:

- 1. 🐼 "Settings"
- 2. "Climate"
- 3. "Activate timer 1" or "Activate timer 2"

The symbol on the automatic climate control lights up when the reel-on time is activated.

 The symbol on the automatic climate control lights up when the reel-on time is activated.

 The symbol on the automatic climate control lights up when the reel-on time is activated.

 The symbol on the automatic climate control lights up when the reel-on time is activated.

 The symbol on the automatic climate control lights up when the reel-on time is activated.

 The symbol on the automatic climate control lights up when the reel-on time is activated.

 The symbol on the automatic climate control lights up when the reel-on time is activated.

 The symbol on the lights up when the reel-on time is activated.

 The symbol on the lights up when the reel-on time is activated.

 The symbol on the lights up when the reel-on time is activated.

 The symbol of the lights up when the reel-on time is activated.

 The symbol of the lights up when the reel-on time is activated.

 The symbol of the lights up when the reel-on time is activated.

 The symbol of the lights up when the lights u

The symbol on the automatic climate control flashes when the system has been switched on.

The system will only be switched on within the next 24 hours. After that, it needs to be reactivated.

# INTERIOR EQUIPMENT

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# UNIVERSAL INTEGRATED RE-MOTE CONTROL

#### The concept

The Universal Integrated Remote Control can operate up to 3 functions of remote-controlled systems such as garage door drives or lighting systems. The Universal Integrated Remote Control replaces up to 3 different hand-held transmitters. To operate the remote control, the buttons on the interior rearview mirror must be programmed with the desired functions. The hand-held transmitter for the particular system is required in order to program the remote control.

During programming

During programming and before activating a device using the universal garage door opener, ensure that there are no people, animals or objects in the area of the remote-controlled device; otherwise, there is a risk of injury or damage.

Also follow the safety instructions of the handheld transmitter. ◀

Before selling the vehicle, delete the stored functions for the sake of security.

#### Compatibility



If this symbol is printed on the packaging or in the instructions of the system to be controlled, the system is generally

compatible with the Universal Integrated Remote Control.

If you have any questions, please contact:

- Your service center.
- www.homelink.com on the Internet.

HomeLink is a registered trademark of Gentex Corporation.

#### At a glance



- 1 LED
- 2 Programmable keys
- 3 Hand-held transmitters of the system

### **Programming**

#### **General information**

- 1. Switch on the ignition.
- Initial setup:

Press and hold the left and right button on the interior rearview mirror simultaneously for approximately 20 seconds until the LED on the interior rearview mirror flashes. This erases all programming of the buttons on the interior rearview mirror.

- Hold the hand-held transmitter for the system to be controlled approx. 1 to 3 in/2.5 to 8 cm away from the buttons of the interior rearview mirror. The required distance depends on the manual transmitter.
- Simultaneously press and hold the button of the desired function on the hand-held transmitter and the button to be programmed on the interior rearview mirror. The LED on the interior rearview mirror will begin flashing slowly.
- 5. Release both buttons as soon as the LED flashes more rapidly. The LED flashing faster indicates that the button on the interior rearview mirror has been programmed. If the LED does not flash faster after at least 60 seconds, change the distance between the interior rearview mirror and the handheld transmitter and repeat the step. Several more attempts at different distances may be necessary. Wait at least 15 seconds between attempts.

Canada: if programming with the handheld transmitter was interrupted, hold down the interior rearview mirror button and repeatedly press and release the handheld transmitter button for 2 seconds.

6. To program other functions on other buttons, repeat steps 3 to 5.

The systems can be controlled using the interior rearview mirror buttons.

# Special feature of the alternating-code wireless system

If you are unable to operate the system after repeated programming, please check if the system to be controlled features an alternating-code system.

Read the system's operating manual, or press the programmed button on the interior rearview mirror longer. If the LED on the interior rearview mirror starts flashing rapidly and then stays lit constantly for 2 seconds, the system features an alternating-code system. Flashing and continuous illumination of the LED will repeat for approximately 20 seconds.

For systems with an alternating-code system, the Universal Integrated Remote Control and the system also have to be synchronized.

Please read the operating manual to find out how to synchronize the system.

Synchronizing is easier with the aid of a second person.

### To synchronize:

- 1. Park the vehicle within range of the remote-controlled system.
- Program the relevant button on the interior rearview mirror as described.
- Locate and press the synchronizing button on the system being programmed. You have approx. 30 seconds for the next step.
- Hold down the programmed button on the interior rearview mirror for approximately 3 seconds and then release it. If necessary, repeat this step up to three times in order to finish synchronization. Once synchronization is complete, the programmed function will be carried out.

# Reprogramming individual buttons

- 1. Switch on the ignition.
- 2. Press and hold the interior rearview mirror button to be programmed.
- As soon as the interior rearview mirror LED starts flashing slowly, hold the hand-held transmitter for the system to be controlled approx. 1 to 3 in/2.5 to 8 cm away from the buttons of the interior rearview mirror. The required distance depends on the manual transmitter.
- Likewise, press and hold the button of the desired function on the hand-held transmitter
- Release both buttons as soon as the interior rearview mirror LED flashes more rapidly.
   The LED flashing faster indicates that the

button on the interior rearview mirror has been programmed. The system can then be controlled by the button on the interior rearview mirror.

If the LED does not flash faster after at least 60 seconds, change the distance and repeat the step. Several more attempts at different distances may be necessary. Wait at least 15 seconds between attempts.

Canada: if programming with the handheld transmitter was interrupted, hold down the interior rearview mirror button and repeatedly press and release the handheld transmitter button for 2 seconds.

#### **Controls**

Before operation

Before operating a system using the universal garage door opener, ensure that there are no people, animals, or objects within the range of movement of the remote-controlled system; otherwise, there is a risk of injury or damage.

Also follow the safety instructions of the handheld transmitter. ◀

The system, such as the garage door, can be operated using the button on the interior rearview mirror while the engine is running or when the ignition is started. To do this, hold down the button within receiving range of the system until the function is activated. The interior rearview mirror LED stays lit while the wireless signal is being transmitted.

# **Deleting stored functions**

Press and hold the left and right button on the interior rearview mirror simultaneously for approximately 20 seconds until the LED flashes rapidly. All stored functions are deleted. The functions cannot be deleted individually.

#### **DIGITAL COMPASS**

#### Overview



- 1 Control button
- 2 Mirror display

#### **Mirror display**

The point of the compass is displayed in the mirror when driving straight.

#### Operating concept


Various functions can be called up by pressing the control button with a pointed object, such as the tip of a ballpoint pen or similar object. The following setting options are displayed in succession, depending on how long the control button is pressed:

- ▶ Pressed briefly: turns display on/off.
- → 3 to 6 seconds: compass zone setting.
- 9 to 12 seconds: left/right-hand steering setting.
- ▶ 12 to 15 seconds: language setting.

### Setting the compass zones

Sets the particular compass zones on the vehicle so that the compass operates correctly; refer to World map with compass zones.

#### World map with magnetic zones



#### **Procedure**

- Press and hold the control button for approx. 3 to 4 seconds. The number of the set compass zone appears in the mirror.
- To change the zone setting, press the control button quickly and repeatedly until the number of the compass zone that corresponds with your location appears in the mirror.

The set zone is stored automatically. The compass is ready for use again after approximately 10 seconds.

# Calibrating the digital compass

The digital compass must be calibrated in the event of the following:

- The wrong compass point is displayed.
- The point of the compass displayed does not change despite changing the direction of travel.
- ▷ Not all points of the compass are displayed.

#### **Procedure**

- Make sure that there are no large metallic objects or overhead power lines near the vehicle and that there is sufficient room to drive around in a circle.
- 2. Set the currently applicable compass zone.
- Press and hold the control button for approx. 6 to 7 seconds so that "C" appears on the display. Next, drive in a complete circle at least once at a speed of no more than 4 mph/7 km/h. If calibration is successful, the "C" is replaced by the points of the compass.

# Left/right-hand steering

The digital compass is already set for right or left-hand steering at the factory.

# Setting the language

Press and hold the control button for approx. 12 to 13 seconds. Briefly press the control button again to switch between English "E" and German "O". Settings are stored automatically after approximately 10 seconds.

#### **SUN VISOR**

#### Glare shield

Fold the sun visor down or up.

#### Vanity mirror

hind a cover. When the cover is opened, the mirror lighting switches on.

# A vanity mirror is located in the sun visor be-

# control with you when leaving the vehicle so that children cannot use the lighter and burn themselves.

Switch off the ignition and take the remote

Replace the cover after use Reinsert the lighter or socket cover after use, otherwise objects may get into the lighter 



Push in the lighter.

The lighter can be removed as soon as it pops back out.

# ASHTRAY/CIGARETTE **LIGHTER**

#### At a glance



The ashtray is located in one of the frontal cup holders, the cigarette lighter above it in the center console.

#### **Ashtray**

In order to empty the ashtray, remove the ashtray from the cupholder.

# Lighter

Danger of burns Only hold the hot lighter by its knob; otherwise, there is a danger of getting burned.

# **CONNECTING ELECTRICAL DE-**VICES

#### Hints

Do not connect charging devices to the 12 volt socket in the vehicle

Do not connect battery chargers to the factoryinstalled 12 volt sockets in the vehicle as this may damage the vehicle battery due to an in-

Replace the cover after use Reinsert the lighter or socket cover after use, otherwise objects may get into the lighter socket or fixture and cause a short circuit.

✓

Keep the airbag unfolding area clear Make sure that the devices and cable are located outside of the airbag's unfolding area: otherwise, its unfolding can be hampered or objects can be hurled through the interior when the airbag unfolds.◀

#### Sockets

Sockets can be used for the running electrical devices with the engine running or with the ignition switched on. The total load of all sockets must not exceed 140 watts at 12 volts.

Do not damage the socket by using unsuitable connectors.

#### In the center console



Remove the cover or cigarette lighter.

#### In the cargo area



The socket is located on the right side in the cargo area.

# **USB INTERFACE**

# The concept

Connection for USB devices with music files and for importing data, such as for Personal Profile settings.

#### Hints

Observe the following when connecting:

> Do not use force when plugging the connector into the USB interface.

- Do not connect devices such as fans or lights to the USB interface.
- Do not connect any USB hard drives or USB hubs.
- Do not use the USB interface for recharging external devices.

#### At a glance



The USB interface is located in the front of the center console.

# **CARGO AREA**

# Cargo cover

#### **General information**

When the tailgate is opened, the cargo cover is raised.


#### Note

Do not deposit heavy objects
Do not deposit heavy or hard objects on
the cargo cover. Otherwise, they may pose a
risk to occupants, such as during braking and
evasive maneuvers.

#### Removing

For storing bulky objects the cargo cover can be removed.

 Detach the left and right retaining straps at the tailgate. 2. Pull the cargo cover out of the brackets on the left and right.



#### Installation

- Slide the cover forward horizontally into the two side brackets until it audibly latches.
- 2. Attach the left and right retaining straps at the tailgate.

#### **Enlarging the trunk**

#### **General information**

The trunk can be enlarged by folding down the rear seat backrest.

The rear seat backrest is divided into two parts at a ratio of 60 to 40. The backrest of the left seat is connected to the backrest center section.

#### Hints

Danger of jamming
Before folding down

Before folding down the rear seat backrests, ensure that the area of movement of the backrests is clear. Ensure that no one is located in or reaches into the area of movement of the rear seat backrests. Otherwise, injury or damage may result.

Ensuring the stability of the child seat When installing child restraint systems, make sure that the child seat is securely fastened to the backrest of the seat. Angle and headrest of the backrest might need to be adjusted or possibly be removed. Make sure that all backrests are securely locked. Otherwise the

stability of the child seat can be affected, and there is an increased risk of injury because of unexpected movement of the seat backrest.

Using the middle safety belt
If the middle safety belt in the rear is
used, the larger side of the backrest must be
locked. Otherwise, the safety belt will not have
a restraining effect.

A

Push the headrests down, before the backrests are folded down

Before folding down the rear seat backrests, make sure that the corresponding headrest is pushed all the way down; otherwise, damage may result. ◀

#### Folding down rear seat backrest

The rear seat backrests can be folded down from the front or from the trunk.

Before the backrest is folded down, hook the corresponding safety belt into the safety belt on the side.



Pull the release upward and fold the backrest toward the front.

# Folding back the backrest

Ensure that the lock is securely engaged When you fold back the backrest make sure that it locks in place. When this happens the red warning field on the seat disappears. Otherwise transported cargo could shoot into the car's interior during braking or evasive maneuvers and endanger occupants.

Fold up the backrest and press it into the latch. Make sure that the safety belt is not pinched.

# Adjusting the backrest tilt

Do not install any child restraint systems
When the backrests are set at steeper position, do not install any child restraint systems
on the backrest; otherwise, their protective effect may be impaired.

To transport bulky items, the trunk can be expanded by setting the backrests at a steeper angle.

- 1. Released the back rest, and tilt it forward.
- 2. Fold the frame, arrow, up until it latches.



3. Fold back and latch the backrest.

# STORAGE COMPARTMENTS

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **HINTS**

No loose objects in the car's interior

Do not stow any objects in the car's interior without securing them; otherwise, they
may present a danger to occupants e.g., during
braking and evasive maneuvers.

■



Do not place anti-slip mats on the dashboard

Do not place anti-slip mats on the dashboard. The mat materials could damage the dashboard. ◀

# **OVERVIEW**

The following storage compartments are available in the vehicle interior:

- Storage compartment in front of the cupholders.
- Storage tray in the center console.
- ▷ Glove compartment on the front passenger side
- Storage compartment above the glove compartment.

- Storage compartment in the center armrest.
- ▷ Compartments in the doors.
- Pockets on the backrests of the front seats.

### **GLOVE COMPARTMENT**

#### Note



Close the glove compartment again immediately

Close the glove compartment immediately after use while driving; otherwise, injury may occur during accidents.

### Opening



Pull the handle.

The light in the glove compartment switches on.

#### Closing

Fold up the cover.

# STORAGE COMPARTMENT ABOVE THE GLOVE COMPARTMENT

#### Note



Immediately close the storage compartment

Close the storage compartment immediately after use while driving; otherwise, injury may occur during accidents. ◀

### **Opening**



Press the lower edge of the cover.

# Closing

Push the cover back into the original position.

# COMPARTMENTS IN THE DOORS

Do not stow any breakable objects
Do not store any breakable objects, e. g.
glass bottles, in the compartments, or there is
an increased risk of injury in the event of an accident.

# **CENTER ARMREST**

The center armrest contains a storage compartment.

#### **Opening**



Press button, arrow 1, and open center arm rest upward, arrow 2.

# Adjusting the height



Press button, arrow 1, and swing center arm rest upward or downward into the desired height, arrow 2.

# **CUPHOLDERS**

#### Hints



Shatter-proof containers and no hot drinks

Use light and shatter-proof containers and do not transport hot drinks. Otherwise, there is the increased danger of injury in an accident. ◀

Unsuitable containers

Do not forcefully push unsuitable containers into the cupholders. This may result in damage.

■

#### **Front**



In the center console.

#### Rear



On 3-door models: in front of the rear seats and in the and in the side armrests.




On 5-door models: in front of the rear seats.

# No heavy objects

Do not hang heavy objects from the hooks; otherwise, they may present a danger to passengers during braking and evasive maneuvers.

The clothes hooks are located above the side windows in the rear.

# STORAGE SPACE UNDER CARGO FLOOR PANEL



Located under the cargo floor panel on the right side is a trough for the onboard vehicle tool kit.

To remove the onboard vehicle tool kit, fold the right side of the cargo floor panel upward.

# **VARIABLE TRUNK FLOOR**

With the variable trunk floor, the trunk can be configured corresponding to transport requirements. To do this, remove the trunk floor, and insert it in the desired position.

Follow instructions on securing cargo, refer to page 157.

# **CLOTHES HOOKS**

Do not obstruct view
When suspending clothing from the hooks, ensure that it will not obstruct the driver's view.

#### Removing the cargo floor panel



On 5-door models: To change the position of the cargo floor panel, first fold up the rear part of the cargo floor panel.



Grasp the cargo floor panel in the rear and fold slightly upward. Next, pull it backward from the supports.

The cargo floor panel can be removed from the trunk above the tail lamps.

#### **Lower position**



- Larger objects can be transported.
- Space for smaller objects remains between the fixed and variable trunk floor.

#### Folded up position

The variable cargo floor panel may not be used as a partition net to separate the trunk and the vehicle interior.

- Only use the variable cargo floor in the folded-up position when the backrests are folded up and locked.
- ▷ Always secure cargo against shifting, using straps, belts and lashing eyes, e.g.

If you don't follow these precautions you can endanger vehicle's occupants and damage the cargo floor during braking. ◀



Fold up the cargo floor panel in the lower position and push it behind the locks on the left and right, arrow. You've reached the maximum cargo height.

# **Upper position**



- With the backrests folded down, a long, flat loading surface is produced.
- On 3-door models:
   Maximum load in this position:
   330 lbs/150 kg.

- On 5-door models:Maximum load in this position: 441 lbs/200 kg.
- Space for objects remains between the fixed and variable trunk floor.



# **DRIVE ME.**

**AT A GLANCE** 

**CONTROLS** 

**DRIVING TIPS** 

**MOBILITY** 

**REFERENCE** 

# THINGS TO REMEMBER WHEN DRIVING

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **BREAKING-IN PERIOD**

#### **General information**

Moving parts need time to adjust to one another (break-in time).

The following instructions will help accomplish a long vehicle life and good efficiency.

During break-in, do not use the Launch Control, refer to page 71.

### Engine, transmission, and axle drive

# Up to 1,200 miles/2,000 km

Do not exceed the maximum engine and road speed:

For gasoline engine 4,500 rpm and 100 mph/160 km/h.

Avoid full load or kickdown under all circumstances.

### From 1,200 miles/2,000 km

The engine and vehicle speed can gradually be increased.

#### **Tires**

Tire traction is not optimal due to manufacturing circumstances when tires are brand-new; they achieve their full traction potential after a break-in time.

Drive conservatively for the first 200 miles/300 km.

#### **Brake system**

Brakes require an initial break-in period of approx. 300 miles/500 km to achieve optimal performance between brake discs and brake pads. Drive moderately during this break-in period.

#### Clutch

The function of the clutch reaches its optimal level only after a distance driven of approx. 300 miles/500 km. During this break-in period, engage the clutch gently.

### Following part replacement

The same break-in procedures should be observed if any of the components above-mentioned have to be renewed in the course of the vehicle's operating life.

# **GENERAL DRIVING NOTES**

# Closing the tailgate

Drive with the tailgate closed
Only drive with the tailgate closed; otherwise, in the event of an accident or braking and evasive maneuvers, passengers and other traffic may be injured, and the vehicle may be damaged. In addition, exhaust fumes may enter the vehicle interior.

If driving with the tailgate open cannot be avoided:

- ▷ Close all windows and the glass sunroof.
- Greatly increase the air flow from the vents.
- Drive moderately.

#### Hot exhaust system



Hot exhaust system

High temperatures are generated in the exhaust system.

Do not remove the heat shields installed and never apply undercoating to them. Make sure that flammable materials, e. g. hay, leaves, grass, etc. do not come in contact with the hot exhaust system while driving, while in idle position mode, or when parked. Such contact could lead to a fire, resulting in an increased risk of serious personal injury as well as property damage.

Do not touch hot exhaust pipes; otherwise, there is a danger of getting burned. ◀

# Mobile communication devices in the vehicle



Mobile communication devices in the vehicle

It is not recommended to use mobile phones, such as mobile phones, in the vehicle interior without a direct connection to an external aerial. Otherwise, the vehicle's electronics and mobile communication devices can interfere with each other. In addition, there is no assurance that the radiation generated during transmission will be conducted away from the vehicle interior.

# Hydroplaning




Hydroplaning

When driving on wet or slushy roads, reduce your speed to prevent hydroplaning.

On wet or slushy roads, a wedge of water can form between the tires and road surface.

This phenomenon is referred to as hydroplaning. It is characterized by a partial or complete loss of contact between the tires and the road surface, ultimately undermining your ability to steer and brake the vehicle.

# **Driving through water**



Do not exceed the maximum water level and maximum speed; otherwise, the vehicle's engine, the electrical systems and the transmission may be damaged.◀

Drive through calm water only if it is not deeper than 9.8 inches/25 cm and at this height, no faster than walking speed, up to 3 mph/5 km/h.

#### **Braking safely**

Your vehicle is equipped with ABS as a standard feature.

Applying the brakes fully is the most effective way of braking in situations needed.

Steering is still responsive. You can still avoid any obstacles with a minimum of steering effort.

Pulsation of the brake pedal and sounds from the hydraulic circuits indicate that ABS is in its active mode.

# Objects in the area around the pedals



No objects in the area around the pedals Keep floor mats, carpets, and any other

objects out of the pedal area; otherwise, the function of the pedals could be impeded while driving and create the risk of an accident.

Do not place additional floor mats over existing mats or other objects.

Only use floor mats that have been approved for the vehicle and can be properly attached to floor.

Ensure that the floor mats are securely fastened again after they were removed for cleaning, e.q. ◀

#### **Driving in wet conditions**

When roads are wet or in heavy rain, press brake pedal ever so gently every few miles.

Ensure that this action does not endanger other traffic.

The heat generated in this process helps dry the brake discs and pads.

In this way braking efficiency will be available when you need it.

#### Hills

Avoid stressing the brakes
Avoid placing excessive stress on the
brake system. Light but consistent brake pressure can lead to high temperatures, brakes
wearing out and possibly even brake failure.

Do not drive in neutral
Do not drive in neutral or with the engine
stopped, as doing so disables engine braking.
In addition, steering and brake assist are unavailable with the engine stopped.

Drive long or steep downhill gradients in the gear that requires least braking efforts. Otherwise the brakes may overheat and reduce brake efficiency.

You can increase the engine's braking effect by shifting down, going all the way to first gear, if needed.

#### **Brake disc corrosion**

Corrosion on the brake discs and contamination on the brake pads are furthered by:

- ▶ Low mileage.
- Extended periods when the vehicle is not used at all.
- Infrequent use of the brakes.

Corrosion will built up when the maximum pressure applied to the brake pads during braking is not reached - thus discs don't get cleaned.

Corrosion buildup on the brake discs will cause a pulsating effect on the brakes in their response - generally that cannot be corrected.

### Condensation under the parked vehicle

When using the automatic climate control, condensation water develops collecting underneath the vehicle.

These traces of water under the vehicle are normal.

#### **Ground clearance**

Limited ground clearance

Observe the limited ground clearance of the vehicle, e. g. while entering underground parking garages or when driving over obstacles. Otherwise, damages to the vehicle may result.

■

# **LOADING**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **HINTS**

Overloading the vehicle
To avoid exceeding the approved capacity of the tires, never overload the vehicle.
Overloading can lead to overheating and increases the rate at which damage develops inside the tires. This could result in a sudden loss of tire inflation pressure.

No fluids in the cargo area

Make sure that fluids do not leak into the
cargo area; otherwise, the vehicle may be damaged.

Heavy and hard objects
Do not stow any heavy and hard objects
in the car's interior without securing them; otherwise, they may present a danger to occupants, e.g., during braking and evasive maneuvers.

# DETERMINING THE LOAD LIMIT


- Locate the following statement on your vehicle's placard:
  - The combined weight of occupants and cargo should never exceed XXX kg or YYY lbs. Otherwise, damage to the vehicle and unstable driving situations may result.




- Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Subtract the combined weight of the driver and passengers from XXX kilograms or YYY pounds.
- The resulting figure equals the available amount of cargo and luggage load capacity.
  - For example, if the YYY amount equals 1,000 lbs and there will be four 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 400 lbs: 1,000 lbs minus 600 lbs = 400 lbs.
- Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.

#### LOAD

#### On 3-door models



#### On 5-door models



The maximum load is the sum of the weight of the occupants and the cargo.

The greater the weight of the occupants, the less cargo that can be transported.

# **STOWING CARGO**

- Cover sharp edges and corners on the cargo.
- Heavy cargo: stow as far forward as possible, directly behind and at the bottom of the rear passenger seat backrests.
- Very heavy cargo: when the rear seat is not occupied, secure each of the outer safety belts in the opposite buckle.
- ▶ If necessary, fold down the rear backrests to stow cargo.
- Do not stack cargo above the top edge of the backrests.

### SECURING CARGO

### Lashing eyes in the cargo area



Without storage compartment package: to secure the cargo there are two lashing eyes, arrow 1, in the cargo area.

With storage compartment package: to secure the cargo there are six lashing eyes, arrows 1 and 2, in the cargo area.

# **Securing cargo**

Securing cargo
Stow and secure the cargo as described;
otherwise it may present a danger to the occupants, e.g., during braking and evasive maneuvers.

- Smaller and lighter items: secure with retaining straps or with draw straps.
- ▶ Larger and heavy objects: secure with cargo straps.

Attach the cargo straps, retaining straps or draw straps to the lashing eyes in the trunk.

# ROOF-MOUNTED LUGGAGE RACK

#### Note

Installation only possible with roof rack.

Roof racks are available as special accessories.

#### Securing

Follow the installation instructions of the roof rack.

#### Loading

Be sure that adequate clearance is maintained for tilting and opening the glass sunroof.

Because roof racks raise the vehicle's center of gravity when loaded, they have a major effect on vehicle handling and steering response.

Therefore, note the following when loading and driving:

- Do not exceed the approved roof/axle loads and the approved gross vehicle weight.
- ▷ Distribute the roof load uniformly.
- ▶ The roof load should not extend past the loading area.
- Always place the heaviest pieces on the bottom.
- ▷ Secure the roof luggage firmly, e.g., tie with ratchet straps.
- Do not let objects project into the opening path of the tailgate.
- Drive cautiously and avoid sudden acceleration and braking maneuvers. Take corners gently.

# **REAR LUGGAGE RACK**

#### General information

Installation only possible with rear luggage rack preparation.

Rear racks are available as special accessories.

#### Note

Follow the installation instructions of the rear luggage rack.

Drive cautiously and avoid sudden acceleration and braking maneuvers. Take corners gently.

#### Securing

#### COOPER/COOPER D/ONE/ONE D



#### COOPER S/COOPER SD



The anchorage points, arrow 1, and the socket, arrow 2, are located below the covers in the bumper.

Remove the covers before installing the rear luggage rack.

# Power consumption

Function of tail lights

Before driving off, check that the tail

lights of the rear luggage rack are functioning properly; otherwise, there is a risk of endangering other traffic. ◀

The rear luggage rack lights must not consume more than:

- ▶ Rear lights: 50 watts per side.
- > Brake lights: 84 watts in total.
- Rear fog lights: 42 watts in total.

> Backup lamp: 42 watts in total.

# **SAVING FUEL**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **GENERAL INFORMATION**

Fuel consumption depends on a number of different factors.

The implementation of certain measures, driving style and regular maintenance can influence fuel consumption and environmental impact.

# REMOVE UNNECESSARY CARGO

Additional weight increases fuel consumption.

# REMOVE ATTACHED PARTS FOLLOWING USE

Remove roof or rear luggage racks which are no longer required following use.

Attached parts on the vehicle impair the aerodynamics and increase the fuel consumption.

# CLOSE THE WINDOWS AND GLASS SUNROOF

Driving with the glass sunroof and windows open results in increased air resistance and raises fuel consumption.

### **TIRES**

#### **General information**

Tires can affect fuel consumption in various ways, e.g., tire size may influence fuel consumption.

# Check the tire inflation pressure regularly

Check and, if needed, correct the tire inflation pressure at least twice a month and before starting on a long trip.

Low tire inflation pressure increases rolling resistance and thus raises fuel consumption and tire wear.

# DRIVE AWAY WITHOUT DE-

Do not wait for the engine to warm-up while the vehicle remains stationary. Start driving right away, but at moderate engine speeds.

This is the fastest way for the cold engine to reach its operating temperature.

# LOOK WELL AHEAD WHEN DRIVING

Avoid unnecessary acceleration and braking.

By maintaining a suitable distance to the vehicle driving ahead of you.

Driving smoothly and proactively reduces fuel consumption.

### **AVOID HIGH ENGINE SPEEDS**

As a rule: driving at low engine speeds lowers fuel consumption and reduces wear.

Use 1st gear to get the vehicle moving. Starting with the 2nd gear, accelerate rapidly. When accelerating, shift up before reaching high engine speeds.

When you reach the desired speed, shift into the highest applicable gear and drive with the engine speed as low as possible and at a constant speed.

The gear shift indicator, refer to page 79, of your vehicle indicates the most fuel efficient gear.

# **USE COASTING CONDITIONS**

When approaching a red light, take your foot off the accelerator and let the vehicle coast to a halt.

For going downhill take your foot off the accelerator and let the vehicle roll.

The flow of fuel is interrupted while coasting.

# SWITCH OFF THE ENGINE DURING LONGER STOPS

Switch off the engine during longer stops, e.g., at traffic lights, railroad crossings or in traffic congestion.

# **Auto Start/Stop function**

The Auto Start/Stop function of your vehicle automatically switches off the engine during a stop.

If the engine is switched off and then restarted rather than leaving the engine running constantly, fuel consumption and emissions are reduced. Savings can begin within a few seconds of switching off the engine.

In addition, fuel consumption is also determined by other factors, such as driving style, road conditions, maintenance or environmental factors.

# SWITCH OFF ANY FUNCTIONS THAT ARE NOT CURRENTLY NEEDED

Functions such as seat heating and the rear window defroster require a lot of energy and consume additional fuel, especially in city and stop-and-go traffic.

Therefore, reel off these functions if they are not actually needed.

# HAVE MAINTENANCE CAR-RIED OUT

Have vehicles maintained regularly to achieve optimal vehicle efficiency and operating life. Have the maintenance carried out by your service center.

Please also note the MINI Maintenance System, refer to page 195.

# **GREEN MODE**

# The concept

The GREEN mode supports a driving style that saves on fuel consumption. For this purpose, the engine control and comfort features, e. g. the climate control output, are adjusted.

For Steptronic transmission:

The Coasting driving condition is enabled under certain conditions.

Under certain conditions the engine is automatically decoupled from the transmission in selector lever position D. The vehicle continues traveling with the engine idling to reduce fuel consumption. Selector lever position D remains engaged. An indicator provides information about the distance traveled in Coasting mode.

In addition, context-sensitive instructions are displayed to assist with an optimized fuel consumption driving style.

The achieved extended range is displayed in the instrument cluster.

#### At a glance

The system includes the following MINIMAL functions and displays:

- GREEN bonus range, refer to page 164.
- GREEN tips driving instruction, refer to page 164.
- ▷ GREEN climate control, refer to page 163.
- → MINIMALISM analyzer, refer to page 166.
- Coasting driving condition, refer to page 165.

# **Activating GREEN mode**



Turn Driving Dynamics Control to the right until GREEN mode is displayed in the instrument cluster.

# **Configuring GREEN mode**

# **Via the Driving Dynamics Control**

- 1. Activating GREEN mode.
- 2. "Configure GREEN"
- 3. Configure the program.

#### Via onboard monitor:

1. 🚱 "Settings"

2. "GREEN Mode"

#### Or

- Settings"
- "Driving mode"
- 3. "Configure GREEN"

Configure the program.

#### **GREEN tip**

▷ "Tip at:"

Set the GREEN mode speed at which a GREEN mode tip is to be displayed.

▶ "GREEN speed warning":Displays a reminder when the set GREEN mode speed is exceeded.

#### Coasting

Fuel-efficiency can be optimized by disengaging the engine and Coasting, refer to page 165, with the engine idling.

This function is only available in GREEN mode.

#### **GREEN climate control**

"GREEN climate control"

Climate control is set to be fuel-efficient.

By making a slight change to the set temperature, or adjusting the rate of heating or cooling of the car's interior fuel consumption can be economized.

The outputs of the seat heater and the exterior Additionally heat output to seats and exterior mirror is reduced.

Exterior mirror heat is available when outside temperatures are very low.

#### **GREEN** potential

The percentage of potential savings that can be achieved with the current configuration is displayed.

#### Display in the instrument cluster

#### **GREEN** bonus range



An adjusted driving style helps you extend your driving range.

This may be displayed as the bonus range in the instrument cluster.

The bonus range is shown in the range display.

The bonus range is automatically reset every time the vehicle is refueled.

- Green display: efficient driving style.
- Gray display: adjust driving style, e. g. by backing off the accelerator pedal.

#### **Driving style**



A bar display in the instrument cluster indicates your current driving efficiency.

Mark in the left area, arrow 1: display for energy recovered by

coasting or when braking.

Mark in the right area, arrow 2: display when accelerating.

Your driving style's efficiency is shown by the bar's color:

- Green display: efficient driving style as long as the mark moves within the green range.

The display switches to green as soon as all conditions for fuel-efficiency-optimized driving are met.

#### **GREEN tip driving instruction**



Instructions tell you to reel to a more fuel-efficient driving style when you back off the accelerator.

#### Note

The driving style display and GREEN mode tips in the instrument cluster appear when the GREEN mode display is activated.

Activating driving style and GREEN mode tips:

- 1. 🕸 "Settings"
- 2. "Instrument cluster"
- 3. "GREEN Info"

# **GREEN tip symbols**

An additional symbol and text instructions are displayed.

#### Symbol I





For efficient driving back off the accelerator or delay accelerating to allow time to assess road conditions.



Reduce speed to the selected GREEN speed.



Steptronic transmission: reel from S/M to D or avoid manual shift interventions.

#### Symbol Measure



Manual transmission: follow shifting instructions.



Manual transmission: engage neutral for engine stop.

#### **Indications on the Control Display**

#### MINIMALISM

Information on fuel consumption and technology can be displayed while driving.

- 2. "MINIMALISM"

#### **Displaying MINIMALISM info**

The current efficiency can be displayed.

/≧\ "MINIMALISM info"

The following systems are displayed:

- ▷ Energy recovery.
- Climate control output.
- ▶ Coasting.

# **Displaying GREEN mode tips**

i "GREEN Tips"

Driving instruction and an additional symbol are displayed.

Settings are stored for the profile currently in use.

# Coasting

# The concept

The system helps to conserve fuel.

To do this, under certain conditions the engine is automatically decoupled from the transmission when selector lever position D is set. The vehicle continues traveling with the engine idling to reduce fuel consumption. Selector lever position D remains engaged.

This driving condition is referred to as coasting. As soon as the brake or accelerator pedal is depressed, the engine is automatically coupled to the transmission again.

#### Hints

Coasting is a component of the GREEN driving mode, refer to page 162.

Coasting is automatically activated when GREEN mode is called via the Driving Dynamics Control, refer to page 113.

The function is available in a certain speed range.

A proactively driving style helps the driver to use the function as often as possible and supports the fuel-conserving effect of coasting.

#### Safety mode

The function is not available under one of the following conditions.

- DSC OFF or TRACTION activated.
- Driving in the dynamic limit range and on steep uphill or downhill grades.
- Battery charge status temporarily too low or vehicle electrical system drawing excessive current.
- Cruise control activated.

#### **Functional requirements**

In GREEN mode, this function is available in a speed range from approximately 30 mph, approx. 50 km/h to 100 mph, approx. 160 km/h, if the following conditions are met:

- Accelerator pedal and brake pedal are not operated.
- The selector lever is in selector lever position D
- Engine and transmission are at operating temperature.

#### **Display**

#### Display in the instrument cluster



The mark in the bar display below the tachometer is highlighted green and appears at the zero point. The tachometer approximately indicates idle speed.

#### **Indications on the Control Display**

The Coasting driving condition is displayed in MINIMALISM Info while this driving mode is active.

The distance traveled in the Coasting driving condition is indicated by a counter.



Color code green, arrow 1: distance traveled in the Coasting driving condition. Symbol, arrow 2: coasting driving condition.

#### **Displaying MINIMALISM info**

- 2. "MINIMALISM"
- /⊜\ "MINIMALISM info"

# Deactivating the system manually

The function can be deactivated in the Configure GREEN mode, refer to page 163, menu, e.g., to use the braking effect of the engine when traveling downhill.

Settings are saved for the profile currently being used.

#### **MINIMALISM driving style analysis**

#### The concept

In this situation the system helps develop an especially efficient driving style and to conserve fuel.

For this purpose, the driving style is analyzed. The assessment is done in various categories and is displayed on the Control Display.

Using this indication, the individual driving style can be oriented toward conserving fuel.

The last fifteen minutes of a trip are evaluated.

The range of the vehicle can be extended by an efficient driving style. This gain in range is displayed as a bonus range in the instrument cluster and on the Control Display.

### **Functional requirement**

The function is only available in GREEN mode.

### Calling up MINIMALISM Analyser

#### **Via the Driving Dynamics Control**

- 1. Activate GREEN mode.
- 2. "MINIMALISM"
- Select the symbol.

# **Display**

# **Display on the Control Display**



The display of the MINIMALISM Analyser consists of a fish, which is riding along in a glass of water on the roof of the MINI and a table of values that rates the driving style in various cat-

egories. The bonus range achieved by driving style that minimizes fuel consumption is displayed below the table of values.

The fish and the movements of the water in the glass symbolize the efficiency of the driving style. The more efficient the driving style, the less the water sloshes around in the glass and the better is the fish's mood, arrow 1.

The table of values includes asterisks, arrow 2. The more efficient the driving style, the more stars are included in the table and the faster the bonus range increases, arrow 3.

If by contrast the driving style is inefficient, the water oscillates, the mood of the fish is sullied and a reduced number of asterisks is displayed.

To assist with an efficient driving style, GREEN tips are displayed during driving.

Tips about the energy saving driving style, Conserving fuel, refer to page 161.



# MOVE ME.

**AT A GLANCE** 

**CONTROLS** 

**DRIVING TIPS** 

**MOBILITY** 

**REFERENCE** 

# REFUELING

# VEHICLE FEATURES AND OPTIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **GENERAL INFORMATION**

Observe the fuel recommendation, refer to page 172, prior to refueling.

Refuel promptly

Refuel no later than at a range of

30 miles/50 km or engine operation might fail
and damage might occur.

### **FUEL LID**

# **Opening**

1. Grasp the fuel filler flap at the rear edge and open it.



2. Turn the tank lid counterclockwise.



Place the tank lid in the bracket attached to the fuel filler flap.



# Closing

- 1. Fit the lid and turn it clockwise until you clearly hear a click.
- 2. Close the fuel filler flap.

Do not pinch the retaining strap
Do not pinch the retaining strap attached
to the lid; otherwise, the lid cannot be closed
properly and fuel vapors can escape.

Manually unlocking fuel filler flap
In the event of an electrical malfunction, e.g.



Remove the cover.

Pull the green knob with the fuel pump symbol, arrow. This releases the fuel filler flap.

# OBSERVE THE FOLLOWING WHEN REFUELING

The fuel tank is full when the filler nozzle clicks off the first time.

Do not overfill the fuel tank
Do not overfill the fuel tank; otherwise
fuel may eslide, causing harm to the environment and damaging the vehicle. ◄

Handling fuels
Observe safety regulations posted at the gas station. 

■

# **FUEL**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **FUEL RECOMMENDATION**

#### Note

General fuel quality

Even fuels that conform to the specifications can be of low quality. This may cause engine problems, for instance poor engine start-up behavior, poor handling and/or poor performance. Switch gas stations or use a brand name fuel with a higher octane rating.

#### Gasoline

For the best fuel efficiency, the gasoline should be sulfur-free or very low in sulfur content.

Fuels that are marked on the gas pump as containing metal must not be used.



Refuel only with unleaded gasoline without metallic additives.

Do not refuel with any leaded gasoline or gasoline with metallic additives, e. g. manganese or iron, as this can cause permanent damage to the catalytic converter and other components.

Fuels with a maximum ethanol content of 25 %, i. e. E10 or E25, may be used for refueling.

Ethanol should satisfy the following quality standards:

US: ASTM 4806-xx CAN: CGSB-3.511-xx

xx: comply with the current standard in each case.



Do not use a fuel with a higher percentage of ethanol

Do not use a fuel with a higher ethanol percentage than recommended or one with other types of alcohol, e.g. M5 to M100; otherwise this could damage the engine and fuel supply system. ◀

#### Recommended fuel grade

John Cooper Works:

Super Plus, 98 RON.

MINI recommends AKI 91.

# Minimum fuel grade

MINI recommends AKI 89.

Minimum fuel grade

Do not use any gasoline below the minimum fuel grade as this may impair engine performance.

If you use gasoline with this minimum AKI Rating, the engine may produce knocking sounds when starting at high outside temperatures. This has no effect on the engine life.

Fuel quality

The use of poor-quality fuels may result in harmful engine deposits or damage. Additionally, problems relating to drivability, starting and stalling, especially under certain environ-

mental conditions such as high ambient temperature and high altitude, may occur.

If drivability problems are encountered, we recommend switching to a high quality gasoline brand and a higher octane grade — AKI number — for a few tank fills. To avoid harmful engine deposits, it is highly recommended to purchase gasoline from Top Tier retailers.

Failure to comply with these recommendations may result in the need for unscheduled maintenance. ◀

# WHEELS AND TIRES

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### TIRE INFLATION PRESSURE

#### Safety information

The tire characteristics and tire inflation pressure influence the following:

- ▶ The service life of the tires.
- Road safety.
- Driving comfort.

# Checking the tire inflation pressure

Check the tire inflation pressure regularly Regularly check the tire inflation pressure, and correct it as needed: at least twice a month and before a long trip. If you fail to observe this precaution, you may be driving on tires with incorrect tire pressures, a condition that may not only compromise your vehicle's driving stability, but also lead to tire damage and the risk of an accident.

Tires have a natural, consistent loss of tire inflation pressure.

Tires heat up while driving, and the tire inflation pressure increases along with the tire's temperature. The tire inflation pressure specifications

relate to cold tires or tires with the ambient temperature.

Only check the tire inflation pressure when the tires are cold. This means after driving no more than 1.25 miles/2 km or when the vehicle has been parked for at least 2 hours.

The displays of inflation devices may underread by up to 1.45 psi/0.1 bar.

For Flat Tire Monitor: after correcting the tire inflation pressure, reinitialize the Flat Tire Monitor.

For Tire Pressure Monitor: after correcting the tire inflation pressure, reset the Tire Pressure Monitor.

- Reinitialize the Flat Tire Monitor.
- Reinitialize the Tire Pressure Monitor.

# Checking the inflation pressure of the emergency wheel



Located behind the bumper on the underside of the vehicle is an opening for checking the tire inflation pressure.

# **Pressure specifications**

The tire inflation pressure table, refer to page 175, contains all pressure specifications for the specified tire sizes at the ambient temperature. Pressure specifications apply to approved tire sizes and recommended tire brands. This information can be obtained from your service center.

To identify the correct tire inflation pressure, please note the following:

- Tire sizes of your vehicle.
- Maximum permitted driving speed.

# Tire inflation pressures up to 100 mph/ 160 km/h

For speeds of up to 100 mph/160 km/h and for optimum driving comfort, note the pressure values in the tire inflation pressure table, refer to page 175, and adjust as necessary.



These pressure values can also be found on the tire inflation pressure label on the driver's door pillar.

Maximum permissible speed
Do not exceed 100 mph/160 km/h; otherwise, tire damage and accidents may result. ◄

# Tire inflation pressure values up to 100 mph/160 km/h

#### On 3-door models: COOPER

#### Tire size

Pressure specifications in bar/PSI

Specifications in bar/PSI with cold tires



2.4 / 35

2.4 / 35

175/60 R 16 86 H M

+S XL RSC

175/65 R 15 84 H M

+S A/S Std

175/65 R 15 84 H M +S Std

13 300

175/65 R 15 84 H Std

Sto

195/55 R 16 87 H M

+S RSC

195/55 R 16 87 V M

+S A/S RSC

195/55 R 16 87 W

**RSC** 

205/45 R 17 88 V M

+S XL A/S RSC

205/45 R 17 88 V M

+S XL RSC

205/45 R 17 88 W XL

RSC

205/40 R 18 86 W XL

**RSC** 

Compact wheel

T 115/70 R 15 90 M

Speed up to a max. of 50 mph / 80 km/h

4.2 / 60

# On 3-door models: COOPER S

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires	††††	
195/55 R 16 87 H M +S RSC	2.4 / 35	2.4 / 35
195/55 R 16 87 V M +S A/S RSC		
195/55 R 16 87 W RSC		
175/60 R 16 86 H M +S XL RSC	2.6 / 38	2.4 / 35
205/45 R 17 88 V M +S XL A/S RSC		
205/45 R 17 88 V M +S XL RSC		
205/45 R 17 88 W XL RSC		
205/40 R 18 86 W XL		

# On 3-door models: JOHN COOPER WORKS

WORKS	
Tire size	Pressure specifications in bar/PSI
Specifications in bar/PSI with cold tires	ᡮ <b>┆</b> ᡮᡮ <b>҈</b>
185/50 R 17 86 H M +S XL RSC	2.9 /42 2.7 / 39
205/45 R 17 88 Y XL Std	
205/45 R 17 88 V M +S XL A/S RSC	
205/45 R 17 88 V M +S XL RSC	
205/40 R 18 86 W XL RSC	

# On 5-door models: COOPER

Tire size

Specifications in bar/PSI with cold tires	#####	/D 
175/65 R 15 84 H M +S A/S Std	2.5 / 36	2.3 / 33
175/65 R 15 84 H M +S Std		
175/65 R 15 84 H Std		
195/55 R 16 87 H M +S RSC		
195/55 R 16 87 V M +S A/S RSC		
195/55 R 16 87 W RSC		

Pressure specifications in bar/PSI

RSC

Tire size	Pressure specifications in bar/PSI	
205/45 R 17 88 V M +S XL A/S RSC 205/45 R 17 88 V M +S XL RSC 205/45 R 17 88 W XL RSC	2.5 / 36	2.4 / 35
175/60 R 16 86 H M +S XL RSC 205/40 R 18 86 W XL RSC	2.6 / 38	2.6 / 38
Compact wheel T 115/70 R 15 90 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60	

# Tire inflation pressures at max. speeds above 100 mph/160 km/h

Speeds above 100 mph/160 km/h
In order to drive at maximum speeds in
excess of 100 mph/160 km/h, please observe,
and, if necessary, adjust tire pressures for
speeds exceeding 100 mph/160 km/h from the
relevant table on the following pages. Otherwise tire damage and accidents could occur.

■

# Tire inflation pressure values over 100 mph/160 km/h

### On 3-door models: COOPER

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires	<b>水</b> * 水 * 。	
175/65 R 15 84 H M +S A/S Std	2.8 / 41	2.6 / 38
175/65 R 15 84 H M +S Std		
175/65 R 15 84 H Std		
175/60 R 16 86 H M +S XL RSC		
195/55 R 16 87 H M +S RSC		
195/55 R 16 87 V M +S A/S RSC		
195/55 R 16 87 W RSC		
205/45 R 17 88 V M +S XL A/S RSC		
205/45 R 17 88 V M +S XL RSC		
205/45 R 17 88 W XL RSC		
205/40 R 18 86 W XL RSC		
Compact wheel	Speed up to a max. of 50 mph / 80 km/h	
T 115/70 R 15 90 M	4.2 / 60	XIII/II

Tire size

# On 3-door models: JOHN COOPER WORKS

Pressure specifications in

1110 3120	bar/PSI	
Specifications in bar/PSI with cold tires	* * * * * ***	₽ _ <b>*</b> *
185/50 R 17 86 H M+S XL RSC 205/45 R 17 88 Y XL Std 205/45 R 17 88 V M +S XL A/S RSC 205/45 R 17 88 V M +S XL RSC	3.1 / 45	2.9  42
205/40 R 18 86 W XL RSC	3.4 / 49	3.2 / 46

# On 5-door models: COOPER

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires	* † * †	
175/65 R 15 84 H M +S A/S Std	2.8 / 41	2.6 / 38
175/65 R 15 84 H M +S Std		
175/65 R 15 84 H Std		
195/55 R 16 87 H M +S RSC		
195/55 R 16 87 V M +S A/S RSC		
195/55 R 16 87 W RSC		
205/45 R 17 88 V M +S XL A/S RSC		
205/45 R 17 88 V M +S XL RSC		
205/45 R 17 88 W XL RSC		
175/60 R 16 86 H M +S XL RSC	2.8 / 41	2.8 / 41
205/40 R 18 86 W XL RSC		
Compact wheel T 115/70 R 15 90 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60	

# **TIRE IDENTIFICATION MARKS**

# Tire size

205/45 R 17 84 V

205: nominal width in mm

45: aspect ratio in % R: radial tire code

17: rim diameter in inches

84: load rating, not for ZR tires

F: speed rating, before the R on ZR tires

# Speed letter

T = up to 118 mph, 190 km/h

H = up to 131 mph, 210 km/h

V = up to 150 mph, 240 km/h

W = up to 167 mph, 270 km/h

Y = up to 186 mph, 300 km/h

### **Tire Identification Number**

DOT code: DOT xxxx xxx 0115

xxxx: manufacturer code for the tire brand

xxx: tire size and tire design

0115: tire age

Tires with DOT codes meet the guidelines of the U.S. Department of Transportation.

### Tire age

DOT ... 0115: the tire was manufactured in the 1st week of 2015.

### Recommendation

Regardless of wear and tear, replace tires at least every 6 years.

# **Uniform Tire Quality Grading**

Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example: Treadwear 200; Traction AA; Temperature A

# **DOT Quality Grades**

Treadwear

Traction AA A B C
Temperature A B C

All passenger car tires must conform to Federal Safety Requirements in addition to these grades.

### **Treadwear**

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half, 1 g, times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

### **Traction**

The traction grades, from highest to lowest, are AA, A, B, and C.

Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

# **Temperature**

The temperature grades are A, the highest, B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades Band A represent higher levels of performance on the

laboratory test wheel than the minimum required by law.

Temperature grade for this tire
The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

If necessary, have the vehicle towed. ◀

### RSC - Run-flat tires

Run-flat tires, refer to page 182, are labeled with a circular symbol containing the letters RSC marked on the sidewall.

#### M+S

Winter and all-season tires with better cold weather performance than summer tires.

# **TIRE TREAD**

#### **Summer tires**

Do not drive with a tire tread depth of less than 0.12 in/3 mm.


There is an increased danger of hydroplaning if the tread depth is less than 0.12 in/3 mm.

### Winter tires

Do not drive with a tire tread depth of less than 0.16 in/4 mm.

Below a tread depth of 0.16 in/4 mm, tires are less suitable for winter operation.

### Minimum tread depth



Wear indicators are distributed around the tire's circumference and have the legally required minimum height of 0.063 in/1.6 mm.

They are marked on the side of the tire with TWI, Tread Wear Indicator.

# TIRE DAMAGE

### **General information**

Inspect your tires often for damage, foreign objects lodged in the tread, and tread wear.

#### Hints

Driving over rough or damaged road surfaces, as well as debris, curbs and other obstacles can cause serious damage to wheels, tires and suspension parts. This is more likely to occur with low-profile tires, which provide less cushioning between the wheel and the road. Be careful to avoid road hazards and reduce your speed, especially if your vehicle is equipped with low-profile tires.

Indications of tire damage or other vehicle defects:

- Unusual vibrations while driving.
- Unusual handling such as a strong tendency to pull to the left or right.

Damage can, e. g., be caused by driving over curbs, road damage, or similar things.

In case of tire damage

If there are indications of tire damage, reduce your speed immediately and have the rims and tires checked right away; otherwise, there is the increased risk of an accident.

Drive carefully to the nearest service center. If necessary, have the vehicle towed or transported there. Otherwise, tire damage can become life threatening for vehicle occupants and also other traffic.

Repair of tire damage

For safety reasons, the manufacturer of your vehicle recommends that you do not have damaged tires repaired; they should be replaced. Otherwise, damage can occur as a result.

# CHANGING WHEELS AND TIRES

# Mounting

Information on mounting tires
Have mounting and balancing performed only by a service center.

If work is not carried out properly, there is a danger of subsequent damage and related safety hazards. ◀

### Wheel and tire combination

Information on the correct wheel-tire combination and rim versions for your vehicle can be obtained from your service center.

Incorrect wheel and tire combinations impair the function of a variety of systems such as ABS or DSC.

To maintain good handling and vehicle response, use only tires with a single tread configuration from a single manufacturer.

Following tire damage, have the original wheel and tire combination remounted on the vehicle as soon as possible.

Approved wheels and tires

You should only use wheels and tires that have been approved by the vehicle manufacturer for your vehicle type; otherwise, e.g., despite having the same official size ratings, variations can lead to chassis contact and with it, the risk of severe accidents

The manufacturer of your vehicle cannot evaluate non-approved wheels and tires to determine if they are suited for use, and therefore cannot guarantee the operating safety of the vehicle. ◀

## **Recommended tire brands**



For each tire size, the manufacturer of your vehicle recommends certain tire brands. These can be identified by a star on the tire sidewall. With proper use, these tires meet the highest standards for safety and handling.

#### **New tires**

Tire traction is not optimal due to manufacturing circumstances when tires are brand-new; they achieve their full traction potential after a break-in time.

Drive conservatively for the first 200 miles/300 km.

### **Retreaded tires**

The manufacturer of your vehicle does not recommend the use of retreaded tires.

# lack

#### Retreaded tires

Possibly substantial variations in the design and age of the tire casing structures can limit service life and have a negative impact on road safety.

### Winter tires

Winter tires are recommended for operating on winter roads.

Although so-called all-season M+S tires provide better winter traction than summer tires, they do not provide the same level of performance as winter tires.

# **Maximum speed of winter tires**

If the maximum speed of the vehicle is higher than the permissible speed for the winter tires, then a respective symbol is displayed in your field of vision. You can obtain this sign from the tire specialist or from your service center.

Maximum speed for winter tires

Do not exceed the maximum speed for
the respective winter tires; otherwise, tire damage and accidents can occur.

✓

### **Run-flat tires**

If you are already using run-flat tires, for your own safety you should replace them only with the same kind. No spare tire is available in the case of a flat tire. Your service center will be glad to advise you.

# Rotating wheels between axles

Different wear patterns can occur on the front and rear axles depending on individual driving conditions.

The tires can be rotated between the axles to achieve even wear. Your service center will be glad to advise you.

After rotating, check the tire pressure and correct if needed.

### Storage

Store wheels and tires in a cool, dry place with as little exposure to light as possible.

Always protect tires against all contact with oil, grease and fuels.

Do not exceed the maximum tire inflation pressure indicated on the side wall of the tire.

# **RUN-FLAT TIRES**

### Label



RSC label on the tire sidewall.

The wheels are composed of tires that are selfsupporting to a limited degree.

The support of the sidewall allows the tire to remain drivable to a restricted degree in the event of a tire inflation pressure loss.

Continued driving with a damaged tire, refer to page 103.

Continued driving with a damaged tire, refer to page 100.

# **Changing run-flat tires**

For your own safety, only use run-flat tires. No spare tire is available in the case of a flat tire. Your service center will be glad to advise you.

# REPAIRING A FLAT TIRE

Safety measures in case of a breakdown Park the vehicle as far away as possible from passing traffic and on solid ground.

Switch on the hazard warning system.

Turn the steering wheel until the front wheels are in the straight-ahead position and engage the steering wheel lock.

Secure the vehicle against rolling away by setting the parking brake.

Have all vehicle occupants get out of the vehicle and ensure that they remain outside the immediate area in a safe place, such as behind a quardrail.

If necessary, set up a warning triangle at an appropriate distance.

Comply with all safety guidelines and regulations.◀

# **MOBILITY SYSTEM**

# The concept

With the Mobility System, minor tire damage can be sealed guickly to enable continued travel. To accomplish this, sealant is pumped into the tires, which seals the damage from the inside.

The compressor can be used to check the tire inflation pressure.

#### Hints

- Follow the instructions on using the Mobility System found on the compressor and sealant container.
- Use of the Mobility System may be ineffective if the tire puncture measures approx. 1/8 in/4 mm or more.
- Contact the nearest service center if the tire cannot be made drivable.

- If possible, do not remove foreign bodies that have penetrated the tire.
- ▶ Pull the speed limit sticker off the sealant container and apply it to the steering wheel.
- ▶ The use of a sealant can damage the TPM wheel electronics. In this case, have the electronics checked at the next opportunity and have them replaced if needed.


**Enclosed areas** 

Do not let the engine run in enclosed areas, since breathing in exhaust fumes may lead to loss of consciousness and death. The exhaust gases contain carbon monoxide, an odorless and colorless but highly toxic gas. ◀

### Storage

The Mobility System is located under the cargo floor panel.


### Sealant container



- Sealant container, arrow 1.
- Filling hose, arrow 2.

Observe use-by date on the sealant container.


### Compressor




- 1 On/off reel
- 2 Holder for bottle
- 3 Reduce inflation pressure
- 4 Inflation pressure dial
- 5 Compressor
- 6 Connector/cable for socket
- 7 Connection hose stowed in the bottom of the compressor

# Filling the tire with sealant

1. Shake the sealant container.




Take the connection hose completely out of the compressor housing. Do not kink the hose.




3. Attach the connection hose to the connector of the sealant container, ensuring that it engages audibly.



4. Slide the sealant container upright into the holder on the compressor housing, ensuring that it engages audibly.




5. Screw the connection hose onto the tire valve of the defective wheel.



With the compressor switched off, insert the plug into a power socket inside the vehicle.



7. With the ignition turned on or the engine running, switch on the compressor.



Let the compressor run for approx. 3 to 8 minutes to fill the tire with sealant and achieve a tire inflation pressure of approx. 2.5 bar.

While the tire is being filled with sealant, the tire inflation pressure may sporadically reach approx. 5 bar. Do not switch off the compressor at this point.



Switch off the compressor after 10 minutes

Do not allow the compressor to run longer than 10 minutes; otherwise, the device will overheat and may be damaged. ◀

If a tire inflation pressure of 2 bar is not reached:

- 1. Switch off the compressor.
- 2. Unscrew the filling hose from the wheel.
- Drive forward and back to distribute the sealant in the tire.
- Inflate the tire again using the compressor.
   If a tire inflation pressure of 2 bar cannot be reached, contact your service center.

# **Stowing the Mobility System**

- Remove the connection hose of the sealant container from the wheel.
- Remove the connection hose from the sealant container.
- Wrap the empty sealant container and connection hose in suitable material to avoid dirtying the cargo area.
- Stow the Mobility System back in the vehicle.


# Distributing the sealant

Immediately drive approx. 5 mls/10 km/h to ensure that the sealant is evenly distributed in the tire.

Do not exceed a speed of 50 mph/80 km/h. If possible, do not drive at speeds less than 12 mph/20 km/h.

### To correct the tire inflation pressure

- 1. Stop at a suitable location.
- 2. Screw the connection hose onto the tire valve stem.



Attach the connection hose directly to the compressor.



 Insert the connector into a power socket inside the vehicle.



- 5. Correct the tire inflation pressure to 2.5 bar.
  - Increase pressure: with the ignition turned on or the engine running, reel on the compressor.
  - ➤ To reduce the pressure: press the button on the compressor.

# Continuing the trip

Do not exceed the maximum permissible speed of 50 mph/80 km/h.

Reinitialize the Flat Tire Monitor, refer to page 102.

Reinitialize the Tire Pressure Monitor, refer to page 98.

Replace the defective tire and the sealant container of the Mobility System as soon as possible.

# **SNOW CHAINS**

### Fine-link snow chains

Only certain types of fine-link snow chains have been tested by the manufacturer of your vehicle, classified as road-safe and approved.

Information about the approved snow chains are available from the service center.

### Use

Use only in pairs on the front wheels, equipped with the tires of the following size:

- ▶ 175/65 R 15.
- ▶ 175/60 R 16.

John Cooper Works:

▶ 185/50 R 17

Follow the chain manufacturer's instructions.

Make sure that the snow chains are always sufficiently tight. Retighten as needed according to the chain manufacturer's instructions.

Do not initialize the Flat Tire Monitor after mounting snow chains, as doing so may result in incorrect readings.

Do not initialize the Tire Pressure Monitor after mounting snow chains, as doing so may result in incorrect readings.

When driving with snow chains, briefly activate Dynamic Traction Control if needed.

# Maximum speed with snow chains

Do not exceed a speed of 30 mph/50 km/h when using snow chains.

# **ENGINE COMPARTMENT**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# IMPORTANT FEATURES IN THE ENGINE COMPARTMENT



- Washer fluid reservoir
- 2 Vehicle identification number
- 3 Oil filler neck

- 4 Jump-starting, positive terminal
- 5 Jump-starting, negative terminal
- 6 Coolant reservoir

# HOOD

#### Hints

Working in the engine compartment

Never attempt to perform any service or repair operations on your vehicle without the necessary professional technical training.

If you are unfamiliar with the statutory guidelines, have any work on the vehicle performed only by a service center.

If work is not carried out properly, there is a danger of subsequent damage and related safety hazards. ◀



Never reach into the engine compartment

Never reach into spaces or gaps in the engine compartment; otherwise, there is a risk of injury, e.g., from rotating or hot parts. ◀

Fold down wiper arm

Before opening the hood, ensure that the wiper arms are against the windshield, or this may result in damage.

# Opening the hood

Pull lever, arrow 1.
 Hood is unlocked



After the lever is released, pull the lever again, arrow 2.

Hood can be opened.

# **Indicator/warning lights**

When the hood is opened, a Check Control message is displayed.

# Closing the hood

Hood open when driving
If you see any signs that the hood is not
completely closed while driving, pull over immediately and close it securely.

■

Danger of jamming

Make sure that the closing path of the hood is clear; otherwise, injuries may result.



Let the hood fall from approx. 16 in/40 cm, arrow.

The hood must audibly engage on both sides.

# **ENGINE OIL**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# **GENERAL INFORMATION**

The engine oil consumption is dependent on the driving style and driving conditions.

The engine oil consumption can increase in case of, for example:

- Sporty driving.
- Break-in the engine.
- ▷ Idling of the engine.
- Usage of non-approved engine oil grades.

Therefore, regularly check the engine oil level after refueling.

The vehicle is equipped with electronic oil measurement.

The electronic oil measurement has two measuring principles:

- Status display.
- Detailed measurement.

# ELECTRONIC OIL MEASURE-MENT

# Status display

# The concept

The engine oil level is monitored electronically while driving and shown on the Control Display.

If the engine oil level reaches the minimum level, a check control message is displayed.

### Requirements

A current measured value is available after approx. 30 minutes of driving. During a shorter trip, the status of the last, sufficiently long trip is displayed.

With frequent short-distance trips, perform a detailed measurement.

# Displaying the engine oil level

On the Control Display:

- 2. "Vehicle status"
- 3. "Engine oil level"

# **Engine oil level display messages**

Different messages appear on the display depending on the engine oil level. Pay attention to these messages.

If the engine oil level is too low within the next 125 miles/200 km, add engine oil, refer to page 191.

Add engine oil immediately: oth

Add engine oil immediately; otherwise, an insufficient amount of engine oil could result in engine damage. ◄

Take care not to add too much engine oil.

Too much engine oil
Have the vehicle checked immediately;
otherwise, surplus engine oil can lead to engine
damage.

#### **Detailed measurement**

### The concept

In the detailed measurement the engine oil level is checked and displayed via a scale.

If the engine oil level reaches the minimum level or an overfilling is detected, a check control message is displayed.

During the measurement, the idle speed is increased somewhat.

# Requirements

- ▷ Vehicle is on level road.
- Manual transmission: shift lever in neutral position, clutch and accelerator pedals not depressed.
- Steptronic transmission: selector lever in selector lever position N or P and accelerator pedal not depressed.
- Engine is running and is at operating temperature.

# Performing a detailed measurement

On the Control Display:

- Wehicle info"
- 2. "Vehicle status"
- Measure engine oil level
- 4. "Start measurement"

The engine oil level is checked and displayed via a scale.

Time: approx. 1 minute.

# **ADDING ENGINE OIL**

### **General information**

Switch off the ignition and safely park the vehicle before engine oil is added.

### Oil filler neck



Only replenish the maximum engine oil amount of 1 US quart/liter if the signal is displayed in the instrument cluster.

After refilling, perform a detailed measurement, refer to page 191.

Adding engine oil

Add oil within the next 125 miles/200 km;
otherwise, this may cause engine damage. ◀

Do not add too much engine oil
When too much engine oil is added, immediately have the vehicle checked, otherwise, this may cause engine damage.

Protect children

Keep oil, grease, etc., out of reach of children and observe the warnings on the containers to prevent health risks. ◄

# **ENGINE OIL TYPES TO ADD**

### Hints

No oil additives
Oil additives may lead to engine damage.

■

Viscosity grades for engine oils
When selecting an engine oil, ensure that
the engine oil belongs to one of the viscosity
grades SAE OW-40, SAE OW-30, SAE 5W-40, and
SAE 5W-30 or malfunctions or engine damage
may occur.

✓

The engine oil quality is critical for the life of the engine.

### Suitable engine oil types

You can add engine oils that meet the following oil rating standards:

Gasoline engine

BMW Longlife-01

BMW Longlife-01 FE

Further information regarding the oil specifications and viscosities of MINI engine oils can be inquired with the service center.

# Alternative engine oil types

If an engine oil suitable for continuous use is not available, up to 1 US quart/liter of an engine oil with the following oil rating can be added:

Gasoline engine

API SM or superior oil rating

# **ENGINE OIL CHANGE:**

The vehicle manufacturer recommends that you let the service center change the motor oil.

MINI recommends

MINI Original Engine Oil.

# COOLANT

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# **HINTS**

Danger of burns from hot engine
Do not open the cooling system while the
engine is hot; otherwise, esliding coolant may
cause burns.

✓

Suitable additives
Only use suitable additives; otherwise, engine damage may occur. The additives are harmful to your health.

■

Coolant consists of water and additives.

Not all commercially available additives are suitable for your vehicle. Ask your service center for suitable additives.


# **COOLANT LEVEL**

# Checking

There are yellow Min and Max marks in the coolant reservoir.

1. Let the engine cool.

Turn the coolant reservoir lid counterclockwise to unscrew and open it.



The coolant level is correct if it lies between the minimum and maximum marks in the filler neck.



# Adding

- 1. Let the engine cool.
- 2. Turn the coolant reservoir lid counterclockwise to unscrew and open it.



3. If the coolant is low, slowly add coolant up to the specified level; do not overfill.

- 4. Close cap.
- 5. Have the cause of the coolant loss eliminated as soon as possible.

# **DISPOSAL**



Comply with the relevant environmental protection regulations when disposing of coolant and coolant additives.

# **MAINTENANCE**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# MINI MAINTENANCE SYSTEM

The maintenance system indicates required maintenance measures, and thereby provides support in maintaining road safety and the operational reliability of the vehicle.

In some cases scopes and intervals may vary according to the country-specific version. Replacement work, spare parts, fuels and lubricants and wear materials are calculated separately. Additional information is available from the service center.

# CONDITION BASED SERVICE CBS

Sensors and special algorithms take into account the driving conditions of your vehicle. Based on this, Condition Based Service recognizes the maintenance requirements.

The system makes it possible to adapt the amount of maintenance corresponding to your user profile.

Detailed information on service requirements, refer to page 78, can be displayed on the Control Display.

#### For service data

Information on the required maintenance is continuously stored in the remote control. Your service center will read out this data and suggest the right array of service procedures for your vehicle.

Therefore, hand your service specialist the remote control that you used most recently.

### Storage periods

Storage periods during which the vehicle battery was disconnected are not taken into account.

If this occurs, have a service center update the time-dependent maintenance procedures, such as checking brake fluid and, if needed, changing the engine oil and the microfilter/activated-charcoal filter.

# SERVICE AND WARRANTY IN-FORMATION BOOKLET FOR US MODELS AND WARRANTY AND SERVICE GUIDE BOOK-LET FOR CANADIAN MODELS

Please consult your Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models for additional information on service requirements.

Maintenance and repair should be performed by your service center. Make sure to have regular maintenance procedures recorded in the vehicle's Service and Warranty Information Booklet for US models, and in the Warranty and Service Guide Booklet for Canadian models. These entries are proof of regular maintenance.

# SOCKET FOR OBD ONBOARD DIAGNOSIS

components, in particular the catalytic converter.

#### Note

Socket for Onboard Diagnosis
The socket for onboard diagnostics may
only be used by the service center or a workshop that operates in accordance with the
specifications of the vehicle manufacturer with
correspondingly trained personnel and other
authorized persons. Otherwise, use may result
in operating problems for the vehicle.

#### **Position**



There is an OBD socket on the driver's side for checking the primary components in the vehicle's emissions.

### **Emissions**



- The warning lamp lights up: Emissions are deteriorating. Have the vehicle checked as soon as possible.
- The warning lamp flashes under certain circumstances:

This indicates that there is excessive misfiring in the engine.

Reduce the vehicle speed and have the system checked immediately; otherwise, serious engine misfiring within a brief period can seriously damage emission control

# REPLACING COMPONENTS

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# **ONBOARD VEHICLE TOOL KIT**



The onboard vehicle tool kit is located in the trough under the cargo area floor.

The warning triangle is located in the tailgate trim.

# WIPER BLADE REPLACEMENT

### Hints



Do not fold down the wipers without wiper blades

Do not fold down the wipers if wiper blades have not been installed; this may damage the windshield. ◀




Folding down wipers before opening the hood


Before opening the hood, ensure that the wiper arms with the wiper blades are against the windshield to prevent damage. ◀

# Replacing the wiper blades

- 1. Fold up and hold the wiper arm firmly.
- 2. Open the wiper blade lock, arrow.




 Pull the wiper blade down first out of the holder on the wiper arm, arrow 1.
 Then pull the wiper blade free from the holder of the wiper arm, arrow 2.



- Insert and latch a new wiper blade in reverse order.
- 5. Fold down the wipers.

# Replace the rear wiper blade

- 1. Fold up and hold the wiper arm firmly.
- 2. Turn the wiper blade all the way back.



- Continue turning the wiper blade all the way so that it pops out of the holder.
- 4. Press the new wiper blade into the holder until you hear it snap into place.
- 5. Fold the wipers in.

# LAMP AND BULB REPLACE-MENT

### **General information**

Lights and bulbs make an essential contribution to vehicle safety.

The manufacturer of the vehicle recommends that you entrust corresponding procedures to the service center if you are unfamiliar those or if they have not been described here.

You can obtain a selection of replacement bulbs at the service center.

#### Hints

# **Lights and bulbs**

Danger of burns

Only change bulbs when they are cool; otherwise, there is a danger of getting burned. ◄

Working on the lighting system
When working on the lighting system,
you should always reel off the lights affected to
prevent short circuits.

To avoid possible injury or equipment damage when replacing bulbs, observe any instructions provided by the bulb manufacturer. ◄

Do not touch the bulbs

Do not touch the glass of new bulbs with
your bare hands, as even minute amounts of
contamination will burn into the bulb's surface
and reduce its service life.

Use a clean tissue, cloth or something similar, or hold the bulb by its base.  $\blacktriangleleft$ 

# **Light-emitting diodes (LEDs)**

Some items of equipment use light-emitting diodes installed behind a cover as a light source.

These light-emitting diodes, which are related to conventional lasers, are officially designated as Class 1 light-emitting diodes.

Do not remove the covers

Do not remove the covers, and never
stare into the unfiltered light for several hours;
otherwise, irritation of the retina could result.

# **Headlight glass**

Condensation can form on the inside of the external lights in cool or humid weather. When driving with the light switched on, the condensation evaporates after a short time. The headlight glass does not need to be changed.

If the headlights do not dim despite driving with the light switched on, increasing humidity forms, e. g. water droplets in the light, have the service center check this.

### Front lights, bulb replacement

### Overview

### Halogen headlights




- 1 Low beams/high beams
- 2 Turn signal

# **LED** headlights



- 1 Daytime running lights
- 2 Low beams/high beams
- 3 Turn signal

### **Bug light**



- Parking lights
- 2 Daytime running lights
- 3 Fog lights

# **LED** bug light



- 1 Parking lights
- 2 Fog lights

### LED low beams/LED high beams

Follow the general instructions on lights and bulbs, refer to page 198.


The lights feature LED technology. Contact your service center in the event of a malfunction.

# halogen low beams/halogen high beams


Follow the general instructions on lights and bulbs, refer to page 198.

#### Bulbs: H4

- 1. Open the hood, refer to page 189.
- 2. Turn the lid counterclockwise, arrow, and remove.



- Pull off the connector.
- 4. Unclip spring clip, arrow, and fold down.



- Remove the bulb from the headlight housing.
- 6. Insert the new bulb and install the cover in the reverse order.

### **Turn signal**

Follow the general instructions on lights and bulbs, refer to page 198.

**Bulbs: PW24W** 

### With white turn signal lights: PWY24W

- 1. Turn the steering wheel.
- Turn the lid counterclockwise, arrow 1, and remove.



3. Unscrew the inner lid counterclockwise, and remove it.



 Pull bulb holder out of the bulb housing; if needed, loosen it with small tilting movements if possible.



- 5. Pull the bulb out of the fixture.
- Insert the new bulb and install the cover in the reverse order.

### LED parking lights/LED fog lights

Follow the general instructions on lights and bulbs, refer to page 198.

The lights feature LED technology. Contact your service center in the event of a malfunction.

# Parking lights/fog lights/daytime running lights

Follow the general instructions on lights and bulbs, refer to page 198.

#### **Bulbs:**

- Parking lights for halogen headlights: W5W
   Parking lights for LED headlights: W5W NBV
- Daytime running light: PSX24W
- Fog lamp: H8
- 1. Turn the steering wheel.
- 2. Turn the lid counterclockwise, arrow 2, and remove.



- 3. Remove the corresponding connector.
- Remove bulb holder of the parking lamp, arrow 1, by turning it counterclockwise.

Pull the bulb out of the fixture.

 Remove the bulb holder of the daytime running lights, arrow 2, by pressing together the top and bottom latch mechanism.

For better accessibility, if needed, remove the bulb of the fog lamp beforehand.

 Turn the bulb holder of the fog lamp counterclockwise, arrow 3, and remove.




5. Insert the new bulbs and install the cover in the reverse order.

When installing the daytime running lights, audibly latch the bulb holder first at the bottom, then at the top.

# Tail lights, bulb replacement


### **Overview**

# Vehicles with a rear fog lamp




- 1 Side tail lights
- 2 Rear fog lamp
- 3 License plate lamp
- 4 Third brake lamp

### Vehicle with two rear fog lights




- Side tail lights
- 2 Rear fog lights
- 3 License plate lamp
- 4 Third brake lamp

### Side tail lights



- 1 Brake lights/tail lights
- 2 Turn signal
- 3 Reversing lights

### Side LED tail lights



- 1 Tail lights
- 2 Turn signal

- 3 Brake light
- 4 Reversing lights

### Side tail lights

Follow the general instructions on lights and bulbs, refer to page 198.

**Bulbs: P21W** 

- 1. Open the tailgate, refer to page 40.
- 2. Remove left or right cover.




Through the opening, loosen the plug connector, arrow 2 on the bulb holder.
 Press the latches together, arrows 1, and remove the bulb holder.



- 4. Remove the bulb holder from the opening.
- 5. Press the defective bulb gently into the socket, turn counterclockwise and remove.
  - Arrow 1: brake lights/tail lights
  - ▷ Arrow 2: turn signal

### ▷ Arrow 3: reversing light



Proceed in the reverse order to insert the new bulb and attach the bulb holder. Make sure that the bulb holder engages in all fasteners.

# Central brake lamp and license plate lamp

Follow the general instructions on lights and bulbs, refer to page 198.


The lights feature LED technology. Contact your service center in the event of a malfunction.

# Vehicles with a rear fog lamp

Follow the general instructions on lights and bulbs, refer to page 198.

Bulbs: W16W

 On vehicles with heat shield: Loosen 3 screws, arrow.



- 2. Push the heat shield forward and the bumper back in order to be able to reach the fog lamp.
- Turn the bulb socket counterclockwise and remove.

The wire is long enough to guide the socket down and through between any heat shield that may be installed and the bumper.



- 4. Replace defective bulb.
- To install the new bulb, proceed in reverse order of removal.


# Vehicle with two rear fog lights

Follow the general instructions on lights and bulbs, refer to page 198.

Bulbs: W16W

Left rear fog lamp:

 On vehicles with heat shield: Loosen 3 screws, arrow.



- 2. Push the heat shield forward and the bumper back in order to be able to reach the fog lamp.
- Turn the bulb socket counterclockwise and remove.

The wire is long enough to guide the socket down and through between any heat shield that may be installed and the bumper.




- 4. Replace defective bulb.
- To install the new bulb, proceed in reverse order of removal.

### Right fog lamp:

Turn the bulb socket counterclockwise and remove.

The wire is long enough to guide the socket down and through between any heat shield that may be installed and the bumper.



- 2. Replace defective bulb.
- To install the new bulb, proceed in reverse order of removal.

# Side turn signal, bulb replacement

Follow the general instructions on lights and bulbs, refer to page 198.

#### **Bulbs:**

> With orange lens: W5W

- With white lens: WY5W diadem
- Pull the turn signal housing at the top out of the catch, then unhook it at the bottom.



Turn the bulb socket counterclockwise and remove.



- 3. Replace the bulb.
- Proceed in the reverse order to insert the new bulb and install the turn signal housing.

First hook the turn signal housing to the bottom, then at the top press it into the latch.

# **CHANGING WHEELS**


#### Hints

When using run-flat tires or tire sealants, a tire does not need to be changed immediately in the event of pressure loss due to a flat tire.

Which is why no spare tire is available.

The tools for changing wheels are available as accessories from your service center.

# Jacking points for the vehicle jack



The jacking points for the vehicle jack are located at the positions shown.

# **Emergency wheel**

#### Hints



Safety measures in case of a breakdown or a wheel change

- Park the vehicle as far away as possible from passing traffic and on solid ground.
   Switch on the hazard warning system.
- ▷ Set the parking brake, and engage first gear or selector lever position P.
- Have all vehicle occupants get out of the vehicle and ensure that they remain outside the immediate area in a safe place, such as behind a guardrail.
- If necessary, set up a warning triangle or portable hazard warning lamp at an appropriate distance. Comply with all safety guidelines and regulations.
- Perform wheel change only on a flat, solid and slip-resistant surface. On soft or slippery ground, e.g., snow, ice, tiles, etc., the vehicle or vehicle jack can slip away to the side.
- Do not place wood blocks or similar items under the vehicle jack; otherwise, it cannot reach its carrying capacity because of the restricted height.
- ▷ If the vehicle is raised, do not lie under the vehicle and do not start the engine; otherwise, a fatal hazard exists. ◄




Use the vehicle jack only for changing wheels

Use the vehicle jack only for changing wheels. Do not attempt to use it to jack up a different type of vehicle or cargo of any kind; otherwise, this could cause material damage and personal injury.


### Removing the emergency wheel

The emergency wheel is housed in a well on the underbody of the vehicle. The screw connection of the emergency wheel is located in the trunk under the floor mat, on the floor of the storage compartment for the wheel changing set.


1. Loosen the nut from the wheel change set using the wheel wrench.



- 2. Remove the retaining plate.
- 3. Screw wheel lug wrench onto the thread and hold in place with one hand.



 Unlock the locking hexagon of the emergency wheel well using the hexagon attached to retaining plate.




- Lower the emergency wheel with the wheel wrench.
- 6. Unscrewing the wheel wrench
- Pull out the well with emergency wheel under the vehicle toward the rear.
- 8. Remove the spacer and emergency wheel from the well
- 9. Stow the well and spacer in the vehicle.

# Prepare wheel change

- 1. Follow the Safety instructions, refer to page 205.
- With the wheel chock from the wheel change set, also secure the vehicle against rolling away at the front wheel of the opposite side.
- 3. Loosen the wheel lug bolts a half turn.

# Jacking up the vehicle

 Place the vehicle jack at the jacking point closest to the wheel such that the vehicle jack foot is vertically beneath the vehicle jacking point with the entire surface on the ground.



- Insert the vehicle jack head in the rectangular recess of the jacking point for cranking it up.
- 3. Crank it up until the wheel in question lifts off of the ground.

# Wheel mounting

- Unscrew the wheel lug bolts and remove the wheel.
- Put the new wheel or emergency wheel on and screw in at least two bolts.
  - If original MINI light alloy wheels are not mounted, any accompanying lug bolts also have to be used.
- Screw in the remaining the lug bolts and tighten all bolts well in a crosswise pattern.
- 4. Lower the vehicle and remove the vehicle jack.

# After the wheel change

1. Tighten the lug bolts crosswise. The tightening torque is 101 lb ft/140 Nm.



Check for secure seating of the lug bolts

For safety reasons, have the secure seating of the lug bolts checked with a calibrated torque wrench; otherwise, a safety hazard results from incorrectly tightened lug bolts.

Stow the defective wheel in the trunk.

The defective wheel cannot be stored in the emergency wheel bracket because of its

- 3. Check tire inflation pressure at the next opportunity and correct as needed.
- 4. Reinitialize the Flat Tire Monitor, refer to page 102.
  - Reinitialize the Tire Pressure Monitor, refer to page 99.
- 5. Replace the damaged tires as soon as possible.

# **Driving with emergency wheel**



Watch the speed when driving with the emergency wheel

Drive conservatively and do not exceed a speed of 50 mph/80 km/h; otherwise, changed driving characteristics such as reduced lane stability while braking, extended braking distance and changed self-steering properties in the limit area.◀

Mount one emergency wheel only Only a single emergency wheel may be mounted. Reinstall wheels and tires of the original size as quickly as possible; otherwise, there is a safety risk.◀

# **VEHICLE BATTERY**

#### Maintenance

The battery is maintenance-free, i.e., the electrolyte will last for the life of the battery.

Your service center will be glad to advise you on questions regarding the battery.

# **Battery replacement**

Use approved vehicle batteries only Only use vehicle batteries that have been approved for your vehicle by the manufacturer: otherwise, the vehicle could be damaged and

systems or functions may not be fully available ◀

After a battery replacement, have the battery registered on the vehicle by your service center to ensure that all comfort features are fully available and that any Check Control messages are no longer displayed.

# Charging the battery

### **General information**

Make sure that the battery is always sufficiently charged to guarantee that the battery remains usable for its full service life.

The battery may need to be charged in the following cases:

- When making frequent short-distance drives.
- ▶ If the vehicle is not used for prolonged periods, longer than a month.
- Steptronic transmission: when parked for long periods of time in selector lever position D. R or N.

### Note



Do not connect charging devices to the 12 volt socket in the vehicle

Do not connect battery chargers to the factoryinstalled 12 volt sockets in the vehicle as this may damage the vehicle battery due to an increased power consumption. ◀

# Starting aid terminals

In the vehicle, only charge the battery via the starting aid terminals, refer to page 210, in the engine compartment with the engine off.

### **Power failure**

After a temporary power loss, some equipment needs to be reset.

Individual settings need to be reprogrammed:

▶ Time: update.

- Date: update.
- Navigation system: wait for the operability of the navigation.

# Disposing of old batteries



Have old batteries disposed of by your service center or bring them to a recycling center.

Maintain the battery in an upright position for transport and storage. Secure the battery so that it does not tip over during transport.

# **FUSES**

#### Note

Replacing fuses

Never attempt to repair a blown fuse and do not replace a defective fuse with a substitute of another color or amperage rating; this could lead to a circuit overload, ultimately resulting in a fire in the vehicle.

# **Replacing fuse**

The fuses are located in the passenger footwell under the dashboard.

1. To open, loosen screws, arrow 1.



- Fold down the fuse holder, arrow 2.
   Information on the fuse types and locations is found on a separate sheet.
- 3. Replace the fuse in question.
- The installation is done in reverse order from the removal.

# **BREAKDOWN ASSISTANCE**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

# HAZARD WARNING FLASH-ERS



The button is located above the Control Display.

# WARNING TRIANGLE



The warning triangle is located in the tailgate. To remove, loosen the brackets.

# **FIRST AID KIT**

The first aid kit is located in the cargo area. Some of the articles have a limited service life. Check the expiration dates of the contents regularly and replace any expired items promptly.

# **JUMP-STARTING**

### **General information**

If the battery is discharged, the engine can be started using the battery of another vehicle and two jumper cables. Only use jumper cables with fully insulated clamp handles.

#### Hints

Do not touch live parts

To avoid the risk of potentially fatal injury,
always avoid all contact with electrical components while the engine is running.

■

To prevent personal injury or damage to both vehicles, adhere strictly to the following procedure.

# **Preparation**

Bodywork contact between vehicles

Make sure that there is no contact between the bodywork of the two vehicles; otherwise, there is a danger of short circuits.

✓

- Check whether the battery of the other vehicle has a voltage of 12 volts. This information can be found on the battery.
- 2. Switch off the engine of the assisting vehicle.
- Switch off any electronic systems/power consumers in both vehicles.

# Starting aid terminals

Connecting order

Connect the jumper cables in the correct order to prevent risk of injury from arcing.

✓



The so-called starting aid terminal in the engine compartment acts as the battery's positive terminal.

Open the lid of the starting aid terminal.



The body ground acts as the negative terminal of the battery.

# Connecting the cables

- 1. Pull off the lid of the starting aid terminal.
- Attach one terminal clamp of the positive jumper cable to the positive terminal of the battery, or to the corresponding starting aid terminal of the vehicle providing assistance.
- Attach the terminal clamp on the other end of the cable to the positive terminal of the battery, or to the corresponding starting aid terminal of the vehicle to be started.
- Attach one terminal clamp of the negative jumper cable to the negative terminal of the battery, or to the corresponding engine or body ground of assisting vehicle.
- Attach the second terminal clamp to the negative terminal of the battery, or to the corresponding engine or body ground of the vehicle to be started.

# Starting the engine

Never use spray fluids to start the engine.

- Start the engine of the assisting vehicle and let it run for several minutes at an increased idle speed.
- 2. Start the engine of the vehicle that is to be started in the usual way.
  - If the first starting attempt is not successful, wait a few minutes before making another attempt in order to allow the discharged battery to recharge.

- 3. Let both engines run for several minutes.
- 4. Disconnect the jumper cables in the reverse order.

Check the battery and recharge if needed.

# TOW-STARTING AND TOWING

#### Note

Tow-starting and towing For towing the vehicle turn, switch off the Intelligent Safety systems; otherwise malfunctions of the individual braking systems might lead to accidents. ◀

Switching off Intelligent Safety systems, refer to page 103.

# Steptronic transmission: transporting vour vehicle

#### Note


Your vehicle must not be towed if the front wheels are touching the ground. Therefore, contact a service center in the event of a breakdown.



Tow the vehicle only with the front axle

Have the vehicle towed only with the front axle raised or transported on a loading platform: otherwise, damage may occur.

#### Tow truck



Have your vehicle transported with a tow truck with a so-called lift bar or on a flat bed.

Do not lift the vehicle

Do not lift the vehicle by the tow fitting or body and chassis parts; otherwise, damage may result.◀

Use tow fitting located in the front only for positioning the vehicle.

### **Manual transmission**

Observe before towing your vehicle Gearshift lever in neutral position.

# **Towing**

When the parking brake is blocked The parking brake cannot be released manually.

Do not tow the vehicle with the parking brake blocked, or the vehicle can be damaged.


Contact your service center. ◀

Follow the towing instructions Follow all towing instructions; otherwise, vehicle damage or accidents may occur. ◀

- Make sure that the ignition is switched on; otherwise, the low beams, tail lights, turn signals, and wipers may be unavailable.
- Do not tow the vehicle with the rear axle tilted, as the front wheels could turn.

- When the engine is stopped, there is no power assist. Consequently, more force needs to be applied when braking and steering.
- ► Larger steering wheel movements are required.
- The towing vehicle must not be lighter than the vehicle being towed; otherwise, it will not be possible to control the vehicle's response.

#### **Tow truck**



Have your vehicle transported with a tow truck with a so-called lift bar or on a flat bed.

Do not lift the vehicle

Do not lift the vehicle by the tow fitting or
body and chassis parts; otherwise, damage
may result.

■

# **Towing other vehicles**

#### Hints

Light towing vehicle
The towing vehicle must not be lighter
than the vehicle being towed; otherwise, it will
not be possible to control the vehicle's response.

Attaching the tow bar/tow rope correctly
Attach the tow bar or tow rope to the tow
fitting; connecting it to other vehicle parts may
cause damage.

- Switch on the hazard warning system, depending on local regulations.
- If the electrical system has failed, clearly identify the vehicle being towed by placing a sign or a warning triangle in the rear window.

#### Tow bar

The tow fittings used should be on the same side on both vehicles.

Should it prove impossible to avoid mounting the tow bar at an offset angle, please observe the following:

- Maneuvering capability is limited going around corners.
- The tow bar will generate lateral forces if it is secured with an offset.

### **Tow rope**

When starting to tow the vehicle, make sure that the tow rope is taut.


To avoid jerking and the associated stresses on the vehicle components when towing, always use nylon ropes or nylon straps.

Attaching the tow rope correctly

Only secure the tow rope on the tow fitting; otherwise, damage can occur when it is secured on other parts of the vehicle.

■

# **Tow fitting**



The screw-in tow fitting should always be carried in the vehicle. It can be screwed in at the front or rear of the MINI. It is located under the

cargo floor panel, next to the onboard vehicle tool kit, refer to page 197.



Tow fitting, information on use

- Use only the tow fitting provided with the vehicle and screw it all the way in.
- Use the tow fitting for towing on paved roads only.
- Avoid lateral loading of the tow fitting, e.g., do not lift the vehicle by the tow fitting.

Otherwise, damage to the tow fitting and the vehicle can occur. ◀

#### Screw thread for tow fitting



COOPER/COOPER D/ONE/ONE D



**COOPER S/COOPER SD** 



#### JOHN COOPER WORKS

Threaded holes for the tow fitting are located in the front and rear of the vehicle on the right side with respect to the direction of travel.

Push out the cover by pressing on the top edge.

#### **Tow-starting**

#### Steptronic transmission

Do not tow-start the vehicle.

Tow-starting the engine is not possible due to the Steptronic transmission.

Have the cause of the starting problems fixed.

#### **Manual transmission**

If possible, do not tow-start the vehicle but start the engine by jump-starting, refer to page 209. If the vehicle is equipped with a catalytic converter, only tow-start while the engine is cold.

- 1. Switch on the hazard warning system and comply with local regulations.
- 2. Ignition, refer to page 60, on.
- 3. Engage third gear.
- Have the vehicle tow-started with the clutch pedal pressed and slowly release the pedal. After the engine starts, immediately press on the clutch pedal again.
- Stop at a suitable location, remove the tow bar or rope, and switch off the hazard warning system.
- 6. Have the vehicle checked.

# **CARE**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **CAR WASHES**

#### **General information**

Regularly remove foreign objects such as leaves in the area below the windshield when the hood is raised.

Wash your vehicle frequently, particularly in winter. Intense soiling and road salt can damage the vehicle.

#### Hints

Steam jets or high-pressure washers
When using steam jets or high-pressure
washers, hold them a sufficient distance away
and use a maximum temperature of
140 °F/60 °C.

If the vehicle has a glass sunroof, ensure that a distance of at least 31.5 inches/80 cm is maintained. Holding them too close or using excessively high pressures or temperatures can cause damage or preliminary damage that may then lead to long-term damage.

Follow the user's manual for the high-pressure washer. ◀



Cleaning sensors/camera lenses with high-pressure washers

When using high-pressure washers, do not spray the sensors and camera lenses on the outside of the vehicle for long periods and maintain a distance of at least 12 in/30 cm. ◀

#### **Automatic car washes**

#### Hints

- Give preference to cloth car washes or those that use soft brushes in order to avoid paint damage.
- Make sure that the wheels and tires are not damaged by the transport mechanisms.
- Fold in the exterior mirrors; otherwise, they may be damaged, depending on the width of the vehicle.
- Unscrew the rod antenna.
- Deactivate the rain sensor, refer to page 66, to avoid unintentional wiper activation.
- In some cases, an unintentional alarm can be triggered by the interior motion sensor of the alarm system. Follow the instructions on avoiding an unintentional alarm, refer to page 44.

Guide rails in car washes

Avoid car washes with guide rails higher than 4 in/10 cm; otherwise, the vehicle body could be damaged.

■

#### Before driving into a car wash

In order to ensure that the vehicle can roll in a car wash, take the following steps:

Manual transmission:

- 1. Drive into the car wash.
- 2. Shift to neutral.

- 3. Switch the engine off.
- 4. Switch on the ignition.

Steptronic transmission:

- Drive into the car wash.
- 2. Engage selector lever position N.
- Press the Start/Stop button to reel off the engine.

In this way, the ignition remains switched on, and two Check-Control messages are displayed.

A signal sounds when you leave the vehicle while in selector lever position N.

The vehicle cannot be locked from the outside when in selector lever position N. A signal is sounded when an attempt is made to lock the vehicle.

To start the engine:

- 1. Depress the brake pedal.
- 2. Press the Start/Stop button.

#### **Headlights**

- Do not rub dry and do not use abrasive or acidic cleansers.
- Soak areas that have been dirtied e. g., from insects, with shampoo and wash off with water.
- Thaw ice with de-icing spray; do not use an ice scraper.

### After washing the vehicle

After washing the vehicle, apply the brakes briefly to dry them; otherwise, braking action can be reduced and corrosion of the brake discs can occur.

Completely remove all residues on the windows, to minimize loss of visibility due to smearing and to reduce wiper noises and wiper blade wear.

#### VEHICLE CARE

#### Car care products

MINI recommends using cleaning and care products from MINI, since these have been tested and approved.



Car care and cleaning products

Follow the instructions on the container.

When cleaning the interior, open the doors or windows.

Only use products intended for cleaning vehicles.

Cleansers can contain substances that are dangerous and harmful to your health. ◀

#### Vehicle paint

Regular care contributes to driving safety and value retention. Environmental influences in areas with elevated air pollution or natural contaminants, such as tree resin or pollen can affect the vehicle's paintwork. Tailor the frequency and extent of your car care to these influences.

Aggressive substances such as spilled fuel, oil, grease or bird droppings must be removed immediately to prevent the finish from being altered or discolored.

#### Leather care

Remove dust from the leather often, using a cloth or vacuum cleaner.

Otherwise, particles of dust and road grime chafe in pores and folds, and lead to increased wear and premature degradation of the leather surface.

To guard against discoloration, such as from clothing, provide leather care roughly every two months.

Clean light-colored leather more frequently because soiling on such surfaces is substantially more visible. Use leather care products; otherwise, dirt and grease will gradually break down the protective layer of the leather surface.

Suitable care products are available from the service center.

#### **Upholstery material care**

Vacuum regularly with a vacuum cleaner.

If upholstery is very dirty, e.g., with beverage stains, use a soft sponge or microfiber cloth with a suitable interior cleaner.

Clean the upholstery down to the seams using large sweeping motions. Avoid rubbing the material vigorously.

Damage from Velcro® fasteners

Open Velcro® fasteners on pants or other articles of clothing can damage the seat covers. Ensure that any Velcro® fasteners are closed. ◄

#### **Caring for special components**

#### **Light-alloy wheels**

When cleaning the vehicle, use only neutral wheel cleaners having a pH value from 5 to 9. Do not use abrasive cleaning agents or steam jets above 140 °F/60 °C. Follow the manufacturer's instructions.

Aggressive, acidic or alkaline cleaning agents can destroy the protective layer of adjacent components, such as the brake disk.

#### **Chrome surfaces**

Carefully clean components such as the radiator grille or door handles with an ample supply of water, possibly with shampoo added, particularly when they have been exposed to road salt.

#### **Rubber components**

Aside from water, treat only with rubber cleansers.

When cleaning rubber seals, do not use any silicon-containing car care products in order to avoid damage or noises.

#### Fine wood parts

Clean fine wood facing and fine wood components only with a moist rag. Then dry with a soft cloth.

#### **Plastic components**

#### These include:

- Imitation leather surfaces.
- Roofliner.
- Lamp lenses.
- Instrument cluster cover.
- Matt black spray-coated components.
- ▶ Painted parts in the interior.

Clean with a microfiber cloth.

Dampen cloth lightly with water.

Do not soak the roofliner.



No cleansers that contain alcohol or solvents

Do not use cleansers that contain alcohol or solvents, such as lacquer thinners, heavy-duty grease removers, fuel, or such; this could lead to surface damage. ◀

#### Safety belts

Dirty belt straps impede the reeling action and thus have a negative impact on safety.

lack

Chemical cleaning

Do not clean chemically; this can destroy the webbing. ◀

Use only a mild soapy solution, with the safety belts clipped into their buckles.

Do not allow the reels to retract the safety belts until they are dry.

#### **Carpets and floor mats**

No objects in the area around the pedals Keep floor mats, carpets, and any other objects out of the pedal area; otherwise, the function of the pedals could be impeded while driving and create the risk of an accident.

Do not place additional floor mats over existing mats or other objects.

Only use floor mats that have been approved for the vehicle and can be properly attached to floor.

Ensure that the floor mats are securely fastened again after they were removed for cleaning, e.g. ◀

Floor mats can be removed from the car's interior for cleaning.

If the floor carpets are very dirty, clean with a microfiber cloth and water or a textile cleaner. To prevent matting of the carpet, rub back and forth in the direction of travel only.

#### Sensor/camera lenses

To clean sensors and camera lenses, use a cloth moistened with a small amount of glass detergent.

#### **Displays/Screens/Projection lenses**

Cleaning displays and screens
Do not use any chemical or household
cleaning agents; otherwise, surfaces can be affected.

Keeping out moisture
Keep all fluids and moisture away from
the unit; otherwise, electrical components can
be damaged.

Avoid pressure
Avoid pressing too hard when cleaning
and do not use abrasive materials; otherwise,
damage can result. 

Clean with a clean, antistatic microfiber cloth.

For stubborn soiling on the projection lens of the Head-up Display, dampen the microfiber cloth with alcohol. Extending projection lens, refer to page 86.

#### Long-term

When the vehicle is shut down for longer than three months, special measures must be taken. Additional information is available from the service center.



FIND ME.

**AT A GLANCE** 

**CONTROLS** 

**DRIVING TIPS** 

**MOBILITY** 

**REFERENCE** 

# **TECHNICAL DATA**

# VEHICLE FEATURES AND OP-TIONS

This chapter describes all standard, countryspecific and optional features offered with the series. It also describes features that are not necessarily available in your car, e. g., due to the selected options or country versions. This also applies to safety-related functions and systems. The respectively applicable country provisions must be observed when using the respective features and systems.

#### **NOTE**

The technical data and specifications in this Owner's Manual are used as guidance values. The vehicle-specific data can deviate from this, for example, due to the selected special equipment, country version or country-specific measurement method. Detailed values can be

found in the approval documents, on information signs on the vehicle or can be obtained from the service center.

The information in the vehicle documents always has priority.

#### **DIMENSIONS**

The dimensions can vary depending on the model version, equipment or country-specific measurement method.

The specified heights do not take into account attached parts, for example, a roof antenna,

roof racks or spoiler. The heights can deviate, for example, due to the selected special equipment, tires, load and chassis version.

MINIT Jan		
MINI 3-door		
Width with mirrors	inches/mm	76.1/1,932
Width without mirrors	inches/mm	68.0/1,727
Height	inches/mm	55.7/1,414
Length		
Cooper	inches/mm	151.1/3,837
Cooper S	inches/mm inches/mm	151.1/3,837 151.9/3,858
<u> </u>	•	
Cooper S	inches/mm	151.9/3,858
Cooper S John Cooper Works	inches/mm	151.9/3,858 152.5/3,874

MINI 5-door		
Width with mirrors	inches/mm	76.1/1,932
Width without mirrors	inches/mm	68.0/1,727
Height	inches/mm	56.1/1,425
Length		
Cooper	inches/mm	157.4/3,998
Cooper S	inches/mm	158.0/4,013
Wheelbase	inches/mm	101.1/2,567
Smallest turning radius diam.	ft/m	36.2/11.02

### **WEIGHTS**

The values preceding the slash apply to vehicles with manual transmission; the values following

the slash apply to vehicles with Steptronic transmission.

MINI Cooper, 3-door		
Approved gross vehicle weight	lbs	3,565
	kg	1,617
Load	lbs	790/725
	kg	358/329
Approved front axle load	lbs	1,920/1,990
	kg	871/903
Approved rear axle load	lbs	1,725/1,685
	kg	782/764
Approved roof load capacity	lbs	132
	kg	60
Cargo area capacity	cu ft	8.7-34.0
	L	211-731

MINI Cooper, 5-door		
Approved gross vehicle weight	lbs	3,795
	kg	1,721
Load	lbs	885/820
	kg	401/372
Approved front axle load	lbs	1,995/2,065
	kg	905/937
Approved rear axle load	lbs	1,880/1,860
	kg	853/844
Approved roof load capacity	lbs	165
	kg	75
Cargo area capacity	cu ft	13.1–40.7
	L	278-941
MINI Cooper S, 3-door		
MINI Cooper S, 3-door Approved gross vehicle weight	lbs	3,620/3,650
	lbs kg	3,620/3,650 1,642/1,656
Approved gross vehicle weight	kg	1,642/1,656
Approved gross vehicle weight	kg Ibs	1,642/1,656 775/770
Approved gross vehicle weight  Load	kg Ibs kg	1,642/1,656 775/770 352/349
Approved gross vehicle weight  Load  Approved front axle load	kg Ibs kg Ibs	1,642/1,656 775/770 352/349 2,025/2,060
Approved gross vehicle weight  Load	kg Ibs kg Ibs kg	1,642/1,656 775/770 352/349 2,025/2,060 919/934
Approved gross vehicle weight  Load  Approved front axle load  Approved rear axle load	kg Ibs kg Ibs kg Ibs kg	1,642/1,656 775/770 352/349 2,025/2,060 919/934 1,690
Approved gross vehicle weight  Load  Approved front axle load	kg Ibs kg Ibs kg Ibs kg	1,642/1,656 775/770 352/349 2,025/2,060 919/934 1,690 767
Approved gross vehicle weight  Load  Approved front axle load  Approved rear axle load	kg Ibs kg Ibs kg Ibs kg Ibs kg Ibs	1,642/1,656 775/770 352/349 2,025/2,060 919/934 1,690 767
Approved gross vehicle weight  Load  Approved front axle load  Approved rear axle load  Approved roof load capacity	kg Ibs kg Ibs kg Ibs kg Ibs kg	1,642/1,656 775/770 352/349 2,025/2,060 919/934 1,690 767 132 60

Approved gross vehicle weight   lbs   3,860/3,900   kg   1,751/1,769    Load   lbs   885   kg   401    Approved front axle load   lbs   2,085/2,125   kg   946/964    Approved rear axle load   lbs   1,880   kg   853    Approved roof load capacity   lbs   165   kg   75    Cargo area capacity   cu ft   13.1–40.7   L   278–941
kg       1,751/1,769         Load       lbs       885         kg       401         Approved front axle load       lbs       2,085/2,125         kg       946/964         Approved rear axle load       lbs       1,880         kg       853         Approved roof load capacity       lbs       165         kg       75         Cargo area capacity       cu ft       13.1–40.7
Load       lbs       885         kg       401         Approved front axle load       lbs       2,085/2,125         kg       946/964         Approved rear axle load       lbs       1,880         kg       853         Approved roof load capacity       lbs       165         kg       75         Cargo area capacity       cu ft       13.1–40.7
kg       401         Approved front axle load       lbs       2,085/2,125         kg       946/964         Approved rear axle load       lbs       1,880         kg       853         Approved roof load capacity       lbs       165         kg       75         Cargo area capacity       cu ft       13.1–40.7
Approved front axle load       lbs       2,085/2,125         kg       946/964         Approved rear axle load       lbs       1,880         kg       853         Approved roof load capacity       lbs       165         kg       75         Cargo area capacity       cu ft       13.1–40.7
kg       946/964         Approved rear axle load       lbs       1,880         kg       853         Approved roof load capacity       lbs       165         kg       75         Cargo area capacity       cu ft       13.1-40.7
Approved rear axle load       lbs       1,880         kg       853         Approved roof load capacity       lbs       165         kg       75         Cargo area capacity       cu ft       13.1–40.7
kg 853  Approved roof load capacity lbs 165 kg 75  Cargo area capacity cu ft 13.1–40.7
Approved roof load capacity    lbs   165   kg   75     Cargo area capacity   cu ft   13.1–40.7
kg 75 Cargo area capacity cu ft 13.1–40.7
Cargo area capacity cu ft 13.1–40.7
en 30 en
L 278–941
MINI John Cooper Works, 3-door
Approved gross vehicle weight lbs 3,720/3,765
kg 1,687/1,708
Load lbs 775
kg 352
Approved front axle load lbs 2,065/2,105
kg 937/955
Approved rear axle load lbs 1,725
Approved real date load
kg 782
kg 782
kg 782 Approved roof load capacity lbs 132

# **CAPACITIES**

MINI		
Fuel tank, approx.		
Cooper, Cooper S, John Cooper Works	US gal/liters	11.6/44

# **APPENDIX**

Any updates to the Owner's Handbook for Vehicle are listed here.

Additional information on the description of the Head-up Display in the "Displays" chapter for John Cooper Works models:

# John Cooper Works: Sport displays in the Head-up Display

#### **General information**


The sport displays in the Head-up Display assist with a sporty driving style.

#### Switching on

- 1. 🕸 "Settings"
- 2. "Head-Up Display"
- 3. "Displayed information"
- 4. "Sport displays"

With navigation system: if the sport displays are switched on, no navigation content will be displayed on the Head-up Display.

#### **Display**



- Speed
- 2 Shift point indicator
- 3 Gear display

- 4 Current engine speed
- 5 Warning field, speed

#### Shift point indicator

#### The concept

Shift point indicator in the Head-up Display indicates the optimum shifting point. Thus, with a sporty driving style, the best possible vehicle acceleration is achieved.

#### **Functional requirements**

- Steptronic transmission:
   Manual mode M/S and if necessary the Dynamic Traction Control DTC are activated.
- ▶ Press the gas pedal all the way down.

#### **Switching on**

Shift point indicators are displayed in the Headup if the sport displays, refer to page 91, are switched on.

- 1. 🕸 "Settings"
- 2. "Head-Up Display"
- 3. "Displayed information"
- 4. "Sport displays"

#### **Display**

Successive gray illuminated fields indicate the upcoming upshift moment.

As soon as the red fields light up, shift up immediately.

When the permitted maximum speed is reached, all shift point indicators flash.

When the maximum speed is exceeded, the supply of fuel is interrupted in order to protect the engine.

# **EVERYTHING FROM A TO Z**

#### INDEX

#### Α

ABS, Antilock Brake System 111 ACC, Active Cruise Control 115 Acceleration Assistant, refer to Launch Control 71 Activated-charcoal filter 137 Active Cruise Control, ACC 115 Additives, oil 191 Adjustments, seats/head restraints 48 Adjustments, steering wheel 55 After washing vehicle 215 Airbags 95 Airbags, indicator/warning light 96 Air circulation, refer to Recirculated-air mode 133, 137 Air conditioner 132 Air, dehumidifying, refer to Cooling function 133, 136 Air distribution. manual 133, 136 Air flow, air conditioner 133 Air flow, automatic climate control 136 Air pressure, tires 174 Air vents, refer to Ventilation 138 Alarm system 43 Alarm triggering 43 Alarm, unintentional 44 All around the center console 16 All around the roofliner 17 All around the steering wheel 14 All-season tires, refer to Winter tires 182

Alternating-code hand-held transmitter 140 Alternative oil types 192 Antifreeze, washer fluid 67 Antilock Brake System, **ABS 111** Anti-slip control, refer to **DSC 111** Approved axle load 221 Approved engine oils, see Suitable engine oil types 192 Arrival time 82 Ash tray 143 Assistance when driving off 114 Assist system, refer to Intelligent Safety 103 **AUTO intensity 136** Automatic car wash 214 Automatic climate control 135 Automatic Curb Monitor 54 Automatic deactivation, frontseat passenger airbags 97 Automatic headlight control 91 Automatic locking 43 Automatic recirculated-air control 137 Automatic transmission with Steptronic 68 AUTO program, automatic climate control 136 AUTO program, intensity 136 Auto Start/Stop function 62 Average fuel consumption 82 Average speed 82 Axle loads, weights 221

#### B

Backrest curvature, refer to Lumbar support 49 Band-aids, refer to First aid kit 209 Bar for tow-starting/ towing 212 Battery replacement, vehicle battery 207 Battery, vehicle 207 Belts, safety belts 50 Beverage holder, cupholder 148 Bonus range, GREEN mode 164 Bottle holder, refer to Cupholder 148 Brake assistant 111 Brake discs, break-in 154 Brake pads, break-in 154 Braking, hints 155 Breakdown assistance 209 Break-in 154 Brightness of Control Display 85 Bug light 199 Bulb replacement 198 Bulb replacement, front 199 Bulb replacement, rear 201 Bulb replacement, side 204 Bulbs and lights 198 Button, RES 117 Button, Start/Stop 60 Bypassing, refer to Jumpstarting 209

#### C

California Proposition 65 Warning 8

Camagea based suries santual
Camera-based cruise control,
ACC 115
Camera lenses, care 217
Camera, rearview cam-
era 125
Can holder, refer to Cu-
pholder 148
Car battery 207
Car care products 215
Care, displays 217
Care, vehicle 215
Cargo area 144
Cargo area, adapting size 149
Cargo area, enlarging 145
Cargo area lid 40
Cargo area, storage compart-
ments 149
Cargo cover 144
Cargo, securing 158
Cargo straps, securing
cargo 158
Car key, refer to Remote con-
trol 34
Carpet, care 217
• •
Carwach 214
Car wash 214
Catalytic converter, refer to
Catalytic converter, refer to Hot exhaust system 155
Catalytic converter, refer to
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Serv-
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Serv- ice 195
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster,
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control Display 18
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control Display 18 Changes, technical, refer to
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control Display 18 Changes, technical, refer to Safety 7
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control Display 18 Changes, technical, refer to Safety 7 Changing parts 197
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control Display 18 Changes, technical, refer to Safety 7 Changing parts 197 Changing wheels 204
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control Display 18 Changes, technical, refer to Safety 7 Changing parts 197 Changing wheels 204 Changing wheels/tires 181
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control Display 18 Changes, technical, refer to Safety 7 Changing parts 197 Changing wheels 204
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control Display 18 Changes, technical, refer to Safety 7 Changing parts 197 Changing wheels 204 Changing wheels/tires 181 Chassis number, see vehicle
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control Display 18 Changes, technical, refer to Safety 7 Changing parts 197 Changing wheels 204 Changing wheels/tires 181 Chassis number, see vehicle identification number 9
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control Display 18 Changes, technical, refer to Safety 7 Changing parts 197 Changing wheels 204 Changing wheels/tires 181 Chassis number, see vehicle identification number 9 Check Control 73
Catalytic converter, refer to Hot exhaust system 155 CBS Condition Based Service 195 Center armrest 148 Center console 16 Central instrument cluster, LED ring 85 Central locking system 40 Central screen, refer to Control Display 18 Changes, technical, refer to Safety 7 Changing parts 197 Changing wheels 204 Changing wheels/tires 181 Chassis number, see vehicle identification number 9

Children, seating position 56
Children, transporting
safely 56
Child restraint fixing sys-
tem 56
Child restraint fixing system
LATCH 57
Child restraint fixing systems,
mounting 56
Child safety locks 59
Child seat, mounting 56
Child seats 56
Chrome parts, care 216
Chrono package, cockpit <mark>87</mark>
Cigarette lighter 143
Cleaning, displays 217
Climate control 132, 135
Clock 77
Closing/opening via door
lock 39
Closing/opening with remote
control 37
Clothes hooks 149
Coasting 165
Coasting with engine decou-
pled, coasting 165
Coasting with idling en-
gine 165
Combination reel, refer to
Turn signals 65
Combination reel, refer to
Wiper system 65
Comfort Access 41
Compartments in the
doors 148
Compass 141
Compressor 183
Computer, refer to On-board
computer 81
Condensation on win-
dows 137
Condensation under the vehi-
cle 156
Condition Based Service
CBS 195

Configuring driving program 114 Confirmation signal 43 Control Display 18 Control Display, settings 84 Controller 19 Control systems, driving stability 111 Convenient opening 38 Coolant 193 Cooling function 133, 136 Cooling, maximum 136 Cooling system 193 Cornering lamp 92 Corrosion on brake discs 156 Cosmetic mirror 143 Courtesy lamps during unlocking 37 Courtesy lamps with the vehicle locked 38 Cruise control 121 Cruise control, active 115 Cruising range 78 Cupholder 148 Current fuel consumption 78

### D

Damage, tires 180 Damping control, dynamic 112 Data. technical 220 Date 77 Daytime running lights 91 Defrosting, refer to defrosting the windows 133 Defrosting, refer to Windows, defrosting 137 Defrosting the windows 133 Dehumidifying, air 133, 136 Deleting personal data 25 Deletion of personal data 25 Destination distance 82 Digital clock 77 Digital compass 141 Dimensions 220

Dimmable exterior mirrors 54 Dimmable interior rearview	Dynamic Stability Control DSC 111	Engine start, refer to Starting the engine 61
mirror 55	Dynamic Traction Control	Engine stop 61
Direction indicator, refer to Turn signals 65	DTC 112	Engine temperature, display 82
Display, electronic, instrument cluster 73	E	Entering a car wash 214 Equipment, interior 139
Display, engine temperature 82	Electronic displays, instrument cluster 73	Error displays, see Check Control 73
Display lighting, refer to Instrument lighting 93	Electronic oil measure- ment 190	ESP Electronic Stability Pro- gram, refer to DSC 111
Displays 72	Electronic Stability Program	Exchanging wheels/tires 181
Displays, cleaning 217	ESP, refer to DSC 111	Exhaust system 155
Disposal, coolant 194 Disposal, vehicle battery 208	Emergency detection, remote control 35	Exterior mirror, automatic dimming feature 54
Distance control, refer to	Emergency release, fuel filler	Exterior mirrors 53
PDC 123	flap 170	External start 209
Distance to destination 82 Divided screen view, split	Emergency start function, engine start 35	External temperature dis- play 77
screen 24	Emergency wheel, compact	External temperature warn-
Door lock, refer to Remote	wheel, refer to Emergency	ing 77
control 34	wheel 205	Eyes for securing cargo 158
Drive mode, GREEN	Energy Control 78	-
mode 162	Engine, automatic Start/Stop	F
Drive-off assistant 114 Drive-off assistant, refer to	function 62 Engine, automatic switch-	Failure mossage see Check
DSC 111	off 62	Failure message, see Check Control 73
Driving Dynamics Control 113	Engine compartment 188	False alarm, refer to Uninten-
Driving Excitement, SPORT 83	Engine compartment, working	tional alarm 44
Driving instruction, GREEN mode 164	in 188 Engine coolant 193	Fan, refer to Air flow 133, 136 Favorites buttons, onboard
Driving instructions, break-	Engine idling when driving,	monitor 24
in 154	coasting 165	Filler neck for engine oil 191
Driving mode 113	Engine oil 190	Fine wood, care 216
Driving notes, general 154	Engine oil, adding 191	First aid kit 209
Driving stability control systems 111	Engine oil additives 191	
	Engine oil additives 191 Engine oil change 192	Fitting for towing, see tow fitting 212
	Engine oil change 192	
Driving style analysis 166 Driving tips 154		ting 212
Driving style analysis 166	Engine oil change 192 Engine oil filler neck 191	ting 212 Flat tire, changing wheels 204 Flat Tire Monitor FTM 102 Flat tire, repairing 183
Driving style analysis 166 Driving tips 154 DSC Dynamic Stability Control 111	Engine oil change 192 Engine oil filler neck 191 Engine oil types, alternative 192 Engine oil types, ap-	ting 212 Flat tire, changing wheels 204 Flat Tire Monitor FTM 102 Flat tire, repairing 183 Flat tire, Tire Pressure Monitor
Driving style analysis 166 Driving tips 154 DSC Dynamic Stability Control 111 DTC Dynamic Traction Con-	Engine oil change 192 Engine oil filler neck 191 Engine oil types, alternative 192 Engine oil types, approved 192	ting 212 Flat tire, changing wheels 204 Flat Tire Monitor FTM 102 Flat tire, repairing 183 Flat tire, Tire Pressure Monitor TPM 98
Driving style analysis 166 Driving tips 154 DSC Dynamic Stability Control 111 DTC Dynamic Traction Control 112	Engine oil change 192 Engine oil filler neck 191 Engine oil types, alternative 192 Engine oil types, approved 192 Engine start during malfunc-	ting 212 Flat tire, changing wheels 204 Flat Tire Monitor FTM 102 Flat tire, repairing 183 Flat tire, Tire Pressure Monitor TPM 98 Flat tire, warning
Driving style analysis 166 Driving tips 154 DSC Dynamic Stability Control 111 DTC Dynamic Traction Control 112 Dynamic Damping Con-	Engine oil change 192 Engine oil filler neck 191 Engine oil types, alternative 192 Engine oil types, approved 192 Engine start during malfunction 35	ting 212 Flat tire, changing wheels 204 Flat Tire Monitor FTM 102 Flat tire, repairing 183 Flat tire, Tire Pressure Monitor TPM 98 Flat tire, warning lamp 99, 102
Driving style analysis 166 Driving tips 154 DSC Dynamic Stability Control 111 DTC Dynamic Traction Control 112	Engine oil change 192 Engine oil filler neck 191 Engine oil types, alternative 192 Engine oil types, approved 192 Engine start during malfunc-	ting 212 Flat tire, changing wheels 204 Flat Tire Monitor FTM 102 Flat tire, repairing 183 Flat tire, Tire Pressure Monitor TPM 98 Flat tire, warning

Floor mats, care 217 Fogged up windows 133 Folding back rear seat backrests 145 Fold-out position, windshield wipers 67 Foot brake 155 Front airbags 95 Front-end collision warning with City Braking function 105 Front fog lights 93 front-seat passenger airbags, automatic deactivation 97 Front-seat passenger airbags, indicator lamp 97 FTM Flat Tire Monitor 102 **Fuel 172** Fuel consumption, current 78 Fuel consumption, refer to Average fuel consumption 82 Fuel filler flap 170 Fuel gauge 77 Fuel lid 170 Fuel quality 172 Fuel recommendation 172 Fuel, tank capacity 224 Fuse 208

#### G

Garage door opener, refer to Universal Integrated Remote Control 139 Gasoline 172 Gear change, Steptronic transmission 69 Gear shift indicator 79 General driving notes 154 Glare shield 143 Glass sunroof, refer to Panoramic glass sunroof 46 Glove compartment 147 GREEN mode 162

GREEN mode, bonus range 164 GREEN mode driving style analysis 166 **GREEN** mode indicator 162 GREEN - program, driving dynamics 113 GREEN tip 164 Gross vehicle weight, approved 221 Ground clearance 156

#### н

Halogen headlights 199 Handbrake, refer to parking brake 64 Hand-held transmitter, alternating code 140 Hazard warning flashers 209 Head airbags 95 Headlight control, automatic 91 Headlight courtesy delay feature 91 Headlight flasher 65 Headlight glass 198 Headlights, care 215 Head restraints 48 Head restraints, front 51 Head restraints, rear 52 Head-up Display 86 Head-up Display, standard view 87 Heavy cargo, stowing 158 High-beam Assistant 92 High beams 65 High beams/low beams, refer to High-beam Assistant 92 Hills 156 Hill start assistant, refer to Drive-off assistant 114 Hints 6 Holder for beverages 148 Homepage 6 Hood 188

Horn 14 Hot exhaust system 155 **HUD Head-up Display 86** Hydroplaning 155

Ice warning, see External temperature warning 77 Icy roads, see External temperature warning 77 Identification marks, tires 178 Identification number, see vehicle identification number 9 Ignition key, refer to Remote control 34 Ignition off 60 Ignition on 60 Illuminated ring, central instrument cluster 85 Indication of a flat tire 99. 102 Indicator lamp, see Check Control 73 Individual air distribution 133, 136 Individual settings, refer to Personal Profile 35 Inflation pressure, tires 174 Inflation pressure warning, tires 102 Info display, refer to On-Board computer 81 Initialize, Tire Pressure Monitor TPM 99 Initializing, Flat Tire Monitor FTM 102 Instrument cluster 72 Instrument cluster, electronic displays 73 Instrument lighting 93 Integrated key 34 Integrated Owner's Manual in the vehicle 30 Intelligent Safety 103

Intensity, AUTO program 136

Interior equipment 139	Lashing eyes, securing	Maintenance require-
Interior lights 93	cargo 158	ments 195
Interior lights during unlock-	LATCH child restraint sys-	Maintenance, service require
ing 37	tem 57	ments 78
Interior lights with the vehicle	Launch Control 71	Maintenance system,
locked 38	Leather, care 215	MINI 195
Interior motion sensor 44	LED bug light 199	Make-up mirror 143
Interior rearview mirror, auto-	LED headlights 199	Malfunction displays, see
matic dimming feature 55	LED ring, central instrument	Check Control 73
Interior rearview mirror, com-	cluster 85	Manual air distribu-
pass 141	LEDs, light-emitting di-	tion 133, 136
Interior rearview mirror, man-	odes 198	Manual air flow 133, 136
ually dimmable 54	Letters and numbers, enter-	Manual mode, transmis-
Internet site 6	ing 25	sion 69
Interval display, service re-	Light 90	Manual operation, door
quirements 78	Light-alloy wheels, care 216	lock 39
Interval mode 66	Light-emitting diodes,	Manual operation, exterior
mervar mode oo	LEDs 198	mirrors 54
J	Lighter 143	Manual operation, fuel filler
,	Lighting 90	flap 170
Jacking points for the vehicle	Lights and bulbs 198	Manual operation, Park Dis-
jack 205	Light switch 90	tance Control PDC 124
Joystick, Steptronic transmis-	Load 158	Manual operation, rearview
sion 69	Loading 157	camera 126
Jump-starting 209	Lock, door 39	Manual transmission 68
5 a p 5 tai ti 3 = 0 5	Locking/unlocking via door	Manufacturer of the MINI 7
K	lock 39	Marking on approved
	Locking/unlocking with re-	tires 181
Key/remote control 34	mote control 37	Marking, run-flat tires 182
Keyless Go, refer to Comfort	Locking, automatic 43	Master key, refer to Remote
Access 41	Locking, settings 42	control 34
Key Memory, refer to Personal	Lock, power window 46	Maximum cooling 136
Profile 35	Locks, doors, and windows 59	Maximum speed, display 79
Kickdown, Steptronic trans-	Low beams 90	Maximum speed, winter
mission 69	Low beams, automatic, refer	tires 182
Knee airbag 96	to High-beam Assistant 92	Measure, units of 85
3.1	Lower back support, mechani-	Medical kit 209
L	cal 49	Menu in instrument cluster 8
_	Luggage rack, refer to Roof-	Menus, refer to onboard mon
Lamp replacement 198	mounted luggage rack 158	itor operating concept 20
Lamp replacement, front 199	Lumbar support, mechani-	Messages, see Check Con-
Lamp replacement, rear 201	cal 49	trol 73
Lamp replacement, side 204		Microfilter 134, 137
Language on Control Display 85	M	MID - program, driving dy- namics 113
piuy 00	Maintenance 195	namics 113
	a	

MINI Connected, refer to	Office, i
Integrated Owner's Manual	Owne
MINI maintenance sys-	Oil 190
tem 195	Oil, add
MINIMALISM Analyser 166	Oil addi
MINIMALISM info 165	Oil char
Minimum tread, tires 180	Oil char
Mirrors 53	quiren
Mobile communication devi-	Oil filler
ces in the vehicle 155	Oil type
Mobility System 183	Oil type
Mode, GREEN Mode 162	Old bat
Modifications, technical, refe	r On-boa
to Safety 7	Onboar
Moisture in headlight 198	OBD 1
Monitor, refer to Control Dis-	Onboar
play 18	Onboar
Mounting of child restraint	conce
systems 56	Onboar
Multifunction steering wheel,	•
buttons 14	lock 3
Multimedia, refer to	Openin
Integrated Owner's Manual	contro
	Operati

#### N

Navigation, refer to Integrated Owner's Manual Neck restraints, front, refer to Head restraints 51 Neck restraints, rear, refer to Head restraints 52 New wheels and tires 181 Nylon rope for tow-starting/ towing 212

#### 0

OBD Onboard Diagnostics 196
Obstacle marking, rearview camera 127
Octane rating, refer to Recommended fuel grade 172
Odometer 77

refer to Integrated r's Manual ling 191 itives 191 nge 192 nge interval, service renents 78 neck 191 es, alternative 192 es, approved 192 teries, disposal 208 rd computer 81 d Diagnostics 96 d monitor 18 d monitor operating pt 18 d vehicle tool kit 197 g/closing via door g/closing with remote ing menus, onboard monitor 18 Optional equipment, standard equipment 6 Outside air, refer to Automatic recirculated-air control 137 Own safety 7

#### P

Paint, vehicle 215
Panoramic glass sunroof 46
Parallel parking assistant 127
Park Distance Control
PDC 123
Parked-car ventilation 138
Parked vehicle, condensation 156
Parking aid, refer to PDC 123
Parking assistant 127
Parking brake 64
Parking lights 90

Passenger side mirror, tilting downward 54 Pathway lines, rearview camera 126 PDC Park Distance Control 123 Pedestrian warning with city braking function 107 Performance Control 112 Personal Profile 35 Phone, refer to Integrated Owner's Manual Pinch protection system, glass sunroof 47 Pinch protection system, windows 45 Plastic, care 216 Power failure 207 Power windows 45 Pressure, tire air pressure 174 Pressure warning, tires 102 Profile, refer to Personal Pro-Protective function, glass sunroof 47 Protective function, windows 45 Push-and-turn switch, refer to Controller 19

#### R

Radiator fluid 193
Radio-operated key, refer to
Remote control 34
Radio ready state 60
Radio, refer to Integrated
Owner's Manual
Rain sensor 66
Rear fog lights 93
Rear lights 201
Rear luggage rack 159
Rearview camera 125
Rearview mirror 53
Rear window defroster 134, 137

Recirculated-air filter 137	5	Socket, OBD Onboard Diag-
Recirculated-air	6.6.1.1: 455	nostics 196
mode 133, 137	Safe braking 155	Spare fuse 208
Recommended fuel grade 172	Safety belt reminder for driv- er's seat and front passenger	Spare tire, refer to Emergency wheel 205
Recommended tire	seat 51	Specified engine oil types 192
brands 181	Safety belts 50	Speed, average 82
Refueling 170	Safety belts, care 216	Speed limit detection, com-
Remaining range 78	Safety reel, windows 46	puter 82
Remote control/key 34	Safety systems, airbags 95	Speed limiter, display 79
Remote control, blocking 35	Saving fuel 161	Speed Limit Information 79
Remote control, malfunc-	Screen, refer to Control Dis-	Speed warning 83
tion 38	play 18	Split screen 24
Remote control, replacing the	Screwdriver 197	Sport displays 83
battery 34	Screw thread for tow fit-	Sport instruments, cockpit 87
Remote control, univer-	ting 213	SPORT program, Dynamic
sal 139	Sealant 183	Driving Control 113
Replacement fuse 208	Seat belts, refer to Safety	Sport program, transmis-
Replacing parts 197	belts 50	sion 69
Replacing the battery, remote	Seat heating, front 50	Stability control systems 111
control 34	Seating position for chil-	Standard view, Head-up Dis-
Replacing wheels/tires 181	dren 56	play 87
Reporting safety defects 10	Seats 48	Start/stop, automatic func-
RES button 117	Selection list in instrument	tion 62
Reserve warning, refer to	cluster 81	Start/Stop button 60
Range 78	Selector lever, Steptronic	Start function during malfunc-
Reset, Tire Pressure Monitor	transmission 69	tion 35
TPM 99	Sensors, care 217	Starting the engine 61
Retaining straps, securing cargo 158	Service and warranty 8 Service requirements, Condi-	Status control display, tires 99 Status information, onboard
Retreaded tires 181	tion Based Service CBS 195	monitor 23
Roadside parking lights 90	Service requirements, dis-	Status of Owner's Manual 7
RON recommended fuel grade 172	play 78 Settings, locking/unlocking 42	Steering wheel, adjusting 55 Steptronic Sport transmission,
Roofliner 17	Settings, mirrors 53	
Roof load capacity 221	Settings on Control Display 84	see Steptronic transmis- sion 68
	Shift paddles on the steering	
Roof-mounted luggage rack 158	wheel 70	Steptronic transmission 68 Stopping the engine 61
Rope for tow-starting/	Side airbags 95	Storage compartments 147
towing 212	Signaling, horn 14	Storage, tires 182
RSC Run Flat System Compo-	Signals when unlocking 43	Storing the vehicle 217
nent, refer to Run-flat	Sitting safely 48	Suitable engine oils 192
tires 182	Size 220	Summer tires, tread 180
Rubber components,	Slide/tilt glass roof 46	Sun visor 143
care 216	Snow chains 186	Supplementary text mes-
Run-flat tires 182	Socket 143	sages 76

Switch for Dynamic Driv-	Tone, refer to Integrated Owner's Manual	Updates made after the editorial deadline 7
ing 113	Tools 197	
Switch-on times, parked-car ventilation 138		Upholstery care 216 USB interface 144
	Total vehicle weight 221	USB IIILEITACE 144
Switch, refer to Cockpit 14	Touchpad 21	V
Symbols 6	Tow fitting 212	V
Symbols in the status field 23	Towing 211	Vanita mirror 147
<b>T</b>	Tow-starting 211	Vanity mirror 143
Т	TPM Tire Pressure Monitor 98	Vehicle battery 207
To shame star 77	Traction control 112	Vehicle battery, replacing 207
Tachometer 77	TRACTION drive mode, driving	Vehicle, break-in 154
Tailgate 40	dynamics 112	Vehicle care 215
Tailgate via remote control 38 Tail lights 201	Transmission lock, releasing manually 70	Vehicle features and op- tions 6
Technical changes, refer to	Transmission, manual trans-	Vehicle identification num-
Safety 7	mission 68	ber 9
Technical data 220	Transmission, see Steptronic	Vehicle jack 205
Temperature, air condi-	transmission 68	Vehicle paint 215
tioner 133	Transporting children	Vehicle storage 217
Temperature, automatic cli-	safely 56	Vehicle wash 214
mate control 135	Tread, tires 180	Ventilation 138
Temperature display for exter-	Trip computer 82	Ventilation, refer to Parked-
nal temperature 77	Triple turn signal activa-	car ventilation 138
Temperature, engine 82	tion 65	VIN, see vehicle identification
Tempomat, see Camera-	Trip odometer 77	number 9
based cruise control 115	Turning circle lines, rearview	Voice activation system 27
Terminal, starting aid 210	camera 126	
Text messages, supplementary 76	Turn signal, front 199 Turn signal, side 204	W
Theft alarm system, refer to	Turn signals, operation 65	Warning and indicator lamps,
Alarm system 43	Turn signals, rear, bulb re-	see Check Control 73
Thigh support 49	placement 201	Warning displays, see Check
Tilt alarm sensor 44	p	Control 73
Time of arrival 82	U	Warning messages, see Check
Tire damage 180		Control 73
Tire identification marks 178	Unintentional alarm 44	Warning triangle 209
Tire inflation pressure 174	Units of measure 85	Warranty 7
Tire inflation pressure moni-	Universal remote control 139	Washer fluid 67
tor, refer to FTM 102	Unlock button, Steptronic	Washer nozzles, wind-
Tire Pressure Monitor TPM 98	transmission 69	shield 67
Tires, changing 181	Unlocking/locking via door	Washer system 65
Tire sealant 183	lock 39	Washing, vehicle 214
Tires, everything on wheels	Unlocking/locking with re-	Water on roads 155
and tires 174	mote control 37	Weights 221

Welcome lamps during un-

locking 37

Unlocking, settings 42

Tires, run-flat tires 182

Tire tread 180

Welcome lights 91 Wheels, changing 181 Wheels, everything on wheels and tires 174 Wheels, Flat Tire Monitor FTM 102 Wheels, Tire Pressure Monitor **TPM 98** Window defroster. rear 134, 137 Windows, powered 45 Windshield defroster 134, 137 Windshield washer fluid 67 Windshield washer nozzles 67 Windshield washer system 65 Windshield wiper 65 Windshield wipers, fold-out position 67 Winter storage, care 217 Winter tires, suitable tires 182 Winter tires, tread 180 Wiper blades, replacing 197 Wiper fluid 67 Wiper system 65 Wood, care 216 Word match concept, navigation 25

Wrench 197



# **DRIVE ME.**