# Pictorial index

Search by illustration

1	For safety and security	Make sure to read through them	
2	Instrument cluster	How to read the gauges and meters, the variety of warning lights and indicators, etc.	
3	Operation of each component	Opening and closing the doors and windows, adjustment before driving, etc.	
4	Driving	Operations and advices which are necessary for driving	
5	Lexus Display Audio system	Operating the Lexus Display Audio system	
6	Interior features	Usage of the interior features, etc.	
7	Maintenance and care	Caring for your vehicle and maintenance procedures	
8	When trouble arises	What to do in case of malfunction or emergency	
9	Vehicle specifications	Vehicle specifications, customizable features, etc.	
10	For owners	Reporting safety defects for U.S. owners, and seat belt and SRS airbag instructions for Canadian owners	
	Index	Search by symptom	
	Index	Search alphabetically	

## TABLE OF CONTENTS

For your information	8
Reading this manual	12
How to search	13
Pictorial index	14

## For safety and security

1-1.	For safe use

	Before driving	26
	For safety drive	28
	Seat belts	30
	SRS airbags	36
	Front passenger occupant classification system	47
	Safety information for children	53
	Child restraint systems	54
	Installing child restraints	58
	Exhaust gas precautions	68
1-2.	Theft deterrent system	
	Engine immobilizer system	69
	Alarm	71

2 Instrument cluster

## 2. Instrument cluster

Warning lights and	
indicators	76
Gauges and meters	81
Multi-information display	.86
Fuel consumption	
information	. 92

Theft prevention labels ......73

3	Operation of each
	component

3-1.	Key information
	Keys98
3-2.	Opening, closing and locking the doors and trunk
	Doors
	Trunk 109
	Smart access system with
	push-button start114
3-3.	Adjusting the seats
	Front seats120
	Rear seats121
	Driving position memory123
	Head restraints127
3-4.	Adjusting the steering wheel and mirrors
	Steering wheel130
	Inside rear view mirror132
	Outside rear view mirrors134
3-5.	Opening, closing the windows and moon roof
	Power windows137

Moon roof...... 140

# Driving

4-1.	Before driving
	Driving the vehicle146
	Cargo and luggage153
	Vehicle load limits156
	Trailer towing157
	Dinghy towing158
<b>4-2</b> .	Driving procedures
	Engine (ignition) switch159
	Automatic transmission164
	Turn signal lever170
	Parking brake172
4-3.	Operating the lights and wipers
	Headlight switch173
	Automatic High Beam176
	Fog light switch181
	Windshield wipers and washer
4-4.	Refueling
	Opening the fuel tank cap 188

4-5.	Using the driving support	
	systems	
	Cruise control192	
	Dynamic radar cruise	
	control196	
	LDA (Lane Departure Alert)208	
	Intuitive parking assist	2
	Rear view monitor system	2
	Driving mode select switch231	3
	Driving assist systems	
	PCS (Pre-Collision System)	4
	BSM	
	(Blind Spot Monitor)246 • The Blind Spot Monitor	5
	function	
	The Rear Cross Traffic     Alert function	6
4-6.	Driving tips	
	Winter driving tips254	7
		8

5	Lexus Display Audio system
---	----------------------------

5-1.	<b>Basic Operations</b>	
	Lexus Display Audio System	260
	Steering wheel audio switches	265
	USB/AUX ports	266
5-2.	Setup	
	Setup menu	267
	General settings	268
	Voice settings	271
	Display settings	272
5-3.	Using the audio system	
	Selecting the audio source	273
	Optimal use of the audio system	274
	Audio settings	
	Audio menu screen	
	operation	278
5-4.	Using the radio	
	Radio operation	281

5-5.	Playing an audio CD and MP3/WMA/AAC discs	
	CD player operation	287
5-6.	Using an external device	
	Listening to an iPod	293
	Listening USB memory device	296
	Using the AUX port	
5-7.	$ConnectingBluetooth^{\mathbb{R}}$	
	Steps for using Bluetooth <sup>®</sup> devices	301
	Registering a Bluetooth <sup>®</sup> device	303
	Selecting a Bluetooth <sup>®</sup> device	304
	Connecting a Bluetooth <sup>®</sup> audio player	305
	Connecting a Bluetooth <sup>®</sup> phone	306
	Displaying a Bluetooth <sup>®</sup> device details	307
	Detailed Bluetooth <sup>®</sup> settings	308

	Listening to $Bluetooth^{\mathbb{R}}$
	Audio309
5-9.	Bluetooth <sup>®</sup> Phone
	Using a Bluetooth ${}^{\mathbb{R}}$
	Phone
	Making a call313
	Receiving a call316
	Speaking on the phone
	Using a Bluetooth $^{ extsf{R}}$
	phone message
	Using the steering wheel
	switches
	Bluetooth <sup>®</sup> phone
	settings
5-10	. Phonebook
	Contact settings
	Messaging setting
5-11.	Bluetooth®
	What to do if
	(Troubleshooting)
	Bluetooth <sup>®</sup>
5-12	Other function
	"Information" screen337
	USB photo
	Weather information
	Voice command system

# 6 Interior features

6-1.	Using the air conditioning	
	system	1
	Automatic air conditioning system	
	Heated steering wheel/ seat heaters/ seat ventilators	2
6-2	Using the interior lights	2
0-2.	Interior lights list	3
	Interior lights	
	Personal lights	4
63	Using the storage features	
0-5.	List of storage features	_
	Glove box	5
	• Console box	
	• Cup holders/	6
	bottle holders	
	Trunk features	-7
6-4.	Using the other interior features	7
	Other interior features	8
	• Sun visors	
	Vanity mirrors	
	• Clock	9
	• Power outlet	
	• Armrest	
	• Rear sunshade	
	• Assist grips	
	• Coat hooks	
	Garage door opener	
	Compass	
	Safety Connect	

7	Maintenance and	d care
---	-----------------	--------

7-1.	Maintenance and care
	Cleaning and protecting the vehicle exterior
	Cleaning and protecting the vehicle interior
7-2.	Maintenance
	Maintenance requirements
	General maintenance
	Emission inspection and maintenance (I/M)
	programs
7-3.	Do-it-yourself maintenance
	Do-it-yourself service
	precautions
	Hood
	Positioning a floor jack400
	Engine compartment 401
	Tires
	Tire inflation pressure
	Wheels
	Air conditioning filter 425
	Electronic key battery427
	Checking and replacing
	fuses 429

	If your vehicle has to be stopped in an emergency447
8-2.	Steps to take in
	an emergency
	If your vehicle needs to be towed448
	If you think something is wrong
	Fuel pump shut off system 454
	If a warning light turns on or a warning buzzer sounds
	If a warning message is displayed461
	If you have a flat tire475
	If the engine will not start485
	If the shift lever cannot be shifted from P 487
	If the electronic key does not operate properly488
	If the vehicle battery is discharged490
	If your vehicle overheats 494
	If the vehicle becomes stuck

When trouble arises

Emergency flashers ...... 446

8-1. Essential information

## 7

# Vehicle specifications

9

# 9-1. Specifications Maintenance data (fuel, oil level, etc.) Fuel information 510 Tire information 513 9-2. Customization Customizable features 525 9-3. Items to initialize Items to initialize Items to initialize S34

Reporting safety defects for U.S. owners
Seat belt instructions for
Canadian owners
(in French)537
SRS airbag instructions for
Canadian owners
(in French)538

## Index

What to do if (Troubleshooting)548	
Alphabetical index	1
	2
	3
	4
	5
	6
	7
	8
	9
fer to the "Navigation System Owner's quipment listed below.	
<ul> <li>Intuitivo parking assist</li> </ul>	

For vehicles with a navigation system, refer to the "Navigation System Owner's Manual" for information regarding the equipment listed below.

- Navigation system
- Intuitive parking assist
- Audio/video system
- Rear view monitor system

# For your information

## Main Owner's Manual

Please note that this manual applies to all models and explains all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.

All specifications provided in this manual are current at the time of printing. However, because of the Lexus policy of continual product improvement, we reserve the right to make changes at any time without notice.

Depending on specifications, the vehicle shown in the illustrations may differ from your vehicle in terms of color and equipment.

## Noise from under vehicle after turning off the engine

Approximately five hours after the engine is turned off, you may hear sound coming from under the vehicle for several minutes. This is the sound of a fuel evaporation leakage check and, it does not indicate a malfunction.

## Accessories, spare parts and modification of your Lexus

A wide variety of non-genuine spare parts and accessories for Lexus vehicles are currently available in the market. You should know that Toyota does not warrant these products and is not responsible for their performance, repair, or replacement, or for any damage they may cause to, or adverse effect they may have on, your Lexus vehicle.

This vehicle should not be modified with non-genuine Lexus products. Modification with non-genuine Lexus products could affect its performance, safety or durability, and may even violate governmental regulations. In addition, damage or performance problems resulting from the modification may not be covered under warranty.

## Installation of a mobile two-way radio system

The installation of a mobile two-way radio system in your vehicle could affect electronic systems such as:

- Multiport fuel injection system/sequential multiport fuel injection system
- Dynamic radar cruise control system
- Cruise control system
- Anti-lock brake system
- Vehicle dynamics integrated management
- SRS airbag system
- Seat belt pretensioner system

Be sure to check with your Lexus dealer for precautionary measures or special instructions regarding installation of a mobile two-way radio system.

## Vehicle data recording

Your Lexus is equipped with several sophisticated computers that will record certain data, such as:

- Engine speed
- Accelerator status
- Brake status
- Vehicle speed
- Shift position

The recorded data varies according to the vehicle grade level and options with which it is equipped. Furthermore, these computers do not record conversations, sounds or pictures.

Data usage

Lexus may use the data recorded in these computers to diagnose malfunctions, conduct research and development, and improve quality.

Lexus will not disclose the recorded data to a third party except:

- With the consent of the vehicle owner or with the consent of the lessee if the vehicle is leased
- In response to an official request by the police, a court of law or a government agency
- For use by Lexus in a law suit.
- For research purposes where the data is not tied to a specific vehicle or vehicle owner
- Usage of data collected through Safety Connect / Lexus Enform (U.S. mainland only) If your Lexus has Safety Connect or Lexus Enform and if you have subscribed to those services, please refer to the Safety Connect / Lexus Enform Telematics Subscription Service Agreement for information on data collected and its usage.

## Event data recorder

This vehicle is equipped with an event data recorder (EDR). The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- · How various systems in your vehicle were operating;
- Whether or not the driver and passenger safety belts were buckled/fastened;
- How far (if at all) the driver was depressing the accelerator and/or brake pedal; and,
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

NOTE: EDR data are recorded by your vehicle only if a non-trivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data (e.g., name, gender, age, and crash location) are recorded. However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

- Disclosure of the EDR data
  - Lexus will not disclose the data recorded in an EDR to a third party except when:
  - An agreement from the vehicle's owner (or the lessee for a leased vehicle) is obtained
  - In response to an official request by the police, a court of law or a government agency
  - For use by Lexus in a law suit

However, if necessary, Lexus may:

- Use the data for research on vehicle safety performance
- Disclose the data to a third party for research purposes without disclosing information about the specific vehicle or vehicle owner

## Scrapping of your Lexus

The SRS airbag and seat belt pretensioner devices in your Lexus contain explosive chemicals. If the vehicle is scrapped with the airbags and seat belt pretensioners left as they are, this may cause an accident such as fire. Be sure to have the systems of the SRS airbag and seat belt pretensioner removed and disposed of by a qualified service shop or by your Lexus dealer before you scrap your vehicle.

## Perchlorate Material

Special handling may apply, See www.dtsc.ca.gov/hazardouswaste/perchlorate.

Your vehicle has components that may contain perchlorate. These components may include airbag, seat belt pretensioners, and wireless remote control batteries.

## **CAUTION**

#### General precautions while driving

Driving under the influence: Never drive your vehicle when under the influence of alcohol or drugs that have impaired your ability to operate your vehicle. Alcohol and certain drugs delay reaction time, impair judgment and reduce coordination, which could lead to an accident that could result in death or serious injury.

Defensive driving: Always drive defensively. Anticipate mistakes that other drivers or pedestrians might make and be ready to avoid accidents.

Driver distraction: Always give your full attention to driving. Anything that distracts the driver, such as adjusting controls, talking on a cellular phone or reading can result in a collision with resulting death or serious injury to you, your occupants or others.

#### General precaution regarding children's safety

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, the moon roof, or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

# Reading this manual


## **CAUTION:**


Explains something that, if not obeyed, could cause death or serious injury to people.

## NOTICE:


Explains something that, if not obeyed, could cause damage to or a malfunction in the vehicle or its equipment.

- **123**... Indicates operating or working procedures. Follow the steps in numerical order.
- Indicates the action (pushing, turning, etc.) used to operate switches and other devices.
- ☐> Indicates the outcome of an operation (e.g. a lid opens).
- Indicates the component or position being explained.
- Means "Do not", "Do not do this", or "Do not let this happen".






# How to search



## 14 Pictorial index

# **Pictorial index**

## Exterior



Windshield wipers	P. 254 P. 350
5 Fuel filler door Refueling method Fuel type/fuel tank capacity	P. 188
6 Tires. Tire size/inflation pressure Winter tires/tire chain. Checking/rotation/tire pressure warning system. Coping with flat tires.	P. 507 P. 254 P. 411
7 Hood	P. 399 P. 502 P. 494


## Light bulbs of the exterior lights for driving (Replacing method: P. 432, Watts: P. 509)

8 Headlights/parking lights/daytime running lights	P. 173
9 Fog lights*	P. 181
🔟 Turn signal lights	P.170
1 Tail lights	P.173
1 Stop lights	P.146
Icense plate lights	P.173
Back-up lights Shifting the shift lever to R	P. 164
(5) Side marker lights	P. 173

\*: If equipped

## 16 Pictorial index

#### Instrument panel




	Must in the	D 04
(4)	Multi-information display Display	
	When the warning messages are displayed	P. 461
5	Parking brake	
	Applying/releasing	
	Precautions against winter season	
(6)	Turn signal lever	
C	Headlight switch	
	Headlights/parking lights/tail lights/daytime running lights	P. 173
$\sim$	Fog lights <sup>*1</sup>	
(7)	Windshield wiper and washer switch.	
	Usage Adding washer fluid	P. 182 P 410
	Warning messages	
8	Emergency flasher switch	P. 446
9	Trunk opener	P. 109
(10)	Hood lock release lever	P. 399
(11)	Tilt and telescopic steering control switch *1	P. 130
Ŭ	Adjustment Driving position memory *1	
(12)	Tilt and telescopic steering lock release lever*1	
~	Adjustment	
(13)	Air conditioning system	
	Usage Rear window defogger	P. 346 P 350
(14)	Audio system <sup>*2</sup>	
(14)	Audio system	
	Hands-free system	
(15)	Trunk opener main switch	P. 110


\*<sup>2</sup>: For vehicles with a navigation system, refer to "Navigation System Owner's Manual".

## 18 Pictorial index

## Switches




19




\*<sup>2</sup>: For vehicles with a navigation system, refer to "Navigation System Owner's Manual".

## O Pictorial index



IS350/250\_U (OM53758U)


21



\*1: For vehicles with a navigation system, refer to "Navigation System Owner's Manual".
 \*2: If equipped
 \*3: Refer to "Navigation System Owner's Manual".

# 22 Pictorial index

### Interior



1 Inside rear view mirror	P. 132
2 Sun visors	P. 365
③ Vanity mirrors	P. 365
④ Interior light	P. 357
Personal lights *1	P. 357
5 Moon roof switches <sup>*2</sup>	P. 140
<b>(6) "SOS" button</b> <sup>*2</sup>	P. 378
⑦ Garage door opener switches	P. 370

\*1: The illustration shows the front, but they are also equipped in the rear. \*2: If equipped

24 Pictorial index

# For safety and security

1

1-1.	For safe use	
	Before driving	26
	For safety drive	28
	Seat belts	30
	SRS airbags	36
	Front passenger occupant classification system	47
	Safety information for children	53
	Child restraint systems	54
	Installing child restraints	58
	Exhaust gas precautions	68
1-2.	Theft deterrent system	
	Engine immobilizer system.	69
	Alarm	71
	Theft prevention labels	73

IS350/250\_U (OM53758U)


## 1-1. For safe use

# Before driving


## Floor mat

Use only floor mats designed specifically for vehicles of the same model and model year as your vehicle. Fix them securely in place onto the carpet.

1 Insert the retaining hooks (clips) into the floor mat eyelets.



- 2 Turn the upper knob of each retaining hook (clip) to secure the floor mats in place.
  - \*: Always align the riangle marks.



The shape of the retaining hooks (clips) may differ from that shown in the illustration.

1-1. For safe use

## **CAUTION**

Observe the following precautions.

Failure to do so may cause the driver's floor mat to slip, possibly interfering with the pedals while driving. An unexpectedly high speed may result or it may become difficult to stop the vehicle, leading to an accident, or leading to death or a serious injury.

When installing the driver's floor mat

- Do not use floor mats designed for other models or different model year vehicles, even if they are Lexus Genuine floor mats.
- Only use floor mats designed for the driver's seat.
- Always install the floor mat securely using the retaining hooks (clips) provided.
- Do not use two or more floor mats on top of each other.
- Do not place the floor mat bottom-side up or upside-down.

## Before driving

- Check that the floor mat is securely fixed in the correct place with all the provided retaining hooks (clips). Be especially careful to perform this check after cleaning the floor.
- With the engine stopped and the shift lever in P, fully depress each pedal to the floor to make sure it does not interfere with the floor mat.




IS350/250\_U (OM53758U)

## For safety drive

For safe driving, adjust the seat and mirror to an appropriate position before driving.

## Correct driving posture

- Adjust the angle of the seatback so that you are sitting straight up and so that you do not have to lean forward to steer. (→P. 120)
- 2 Adjust the seat so that you can depress the pedals fully and so that your arms bend slightly at the elbow when gripping the steering wheel. (→P.120)



- (3) Lock the head restraint in place with the center of the head restraint closest to the top of your ears. ( $\rightarrow$ P. 127)
- 4 Wear the seat belt correctly.  $(\rightarrow P. 30)$

## Correct use of the seat belts

Make sure that all occupants are wearing their seat belts before driving the vehicle.  $(\rightarrow P. 30)$ 

Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt. ( $\rightarrow$ P. 54)

## Adjusting the mirrors

Make sure that you can see backward clearly by adjusting the inside and outside rear view mirrors properly. ( $\rightarrow$ P. 132, 134)

## 

Observe the following precautions.

Failure to do so may result in death or serious injury.

- Do not adjust the position of the driver's seat while driving. Doing so could cause the driver to lose control of the vehicle.
- Do not place a cushion between the driver or passenger and the seatback. A cushion may prevent correct posture from being achieved, and reduce the effectiveness of the seat belt and head restraint.
- Do not place anything under the front seats. Objects placed under the front seats may become jammed in the seat tracks and stop the seat from locking in place. This may lead to an accident and the adjustment mechanism may also be damaged.
- When driving over long distances, take regular breaks before you start to feel tired. Also, if you feel tired or sleepy while driving, do not force yourself to continue driving and take a break immediately.

29

### 1-1. For safe use

# Seat belts


Make sure that all occupants are wearing their seat belts before driving the vehicle.

## Correct use of the seat belts

- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.
- Position the lap belt as low as possible over the hips.
- Adjust the position of the seatback. Sit up straight and well back in the seat.
- Do not twist the seat belt.

## Fastening and releasing the seat belt

- (1) To fasten the seat belt, push the plate into the buckle until a click sound is heard.
- (2) To release the seat belt, press the release button.





## 1-1. For safe use

## Adjusting the seat belt shoulder anchor height (front seats)

- Push the seat belt shoulder anchor down while pressing the release button.
- Push the seat belt shoulder anchor up.

Move the height adjuster up and down as needed until you hear a click.




# Seat belt pretensioners (front seats for all models and outboard rear seats of some models)

The pretensioners help the seat belts to quickly restrain the occupants by retracting the seat belts when the vehicle is subjected to certain types of severe frontal collision.

The front seat belt pretensioners also activate when the vehicle is subjected to certain types of severe side collision.


The pretensioners do not activate in the event of a minor frontal impact, a minor side impact, a rear impact or a vehicle rollover.



31

#### After the rear center seat belt has been used

Stow the buckle as shown.



#### Emergency locking retractor (ELR)

The retractor will lock the belt during a sudden stop or on impact. It may also lock if you lean forward too quickly. A slow, easy motion will allow the belt to extend so that you can move around fully.

#### Automatic locking retractor (ALR)

When a passenger's shoulder belt is completely extended and then retracted even slightly, the belt is locked in that position and cannot be extended. This feature is used to hold a child restraint system (CRS) firmly. To free the belt again, fully retract the belt and then pull the belt out once more. ( $\rightarrow$ P. 58)

#### Child seat belt usage

The seat belts of your vehicle were principally designed for persons of adult size.


- Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt. (→P. 54)
- When the child becomes large enough to properly wear the vehicle's seat belt, follow the instructions regarding seat belt usage. (→P. 30)

## Replacing the belt after the pretensioner has been activated

If the vehicle is involved in multiple collisions, the pretensioner will activate for the first collision, but will not activate for the second or subsequent collisions.

#### Seat belt extender

If your seat belts cannot be fastened securely because they are not long enough, a personalized seat belt extender is available from your Lexus dealer free of charge.



1-1. For safe use

## 

Observe the following precautions to reduce the risk of injury in the event of sudden braking, sudden swerving or an accident.


Failure to do so may cause death or serious injury.

- Wearing a seat belt
  - Ensure that all passengers wear a seat belt.
  - Always wear a seat belt properly.
  - Each seat belt should be used by one person only. Do not use a seat belt for more than one person at once, including children.
  - Lexus recommends that children be seated in the rear seat and always use a seat belt and/or an appropriate child restraint system.
  - To achieve a proper seating position, do not recline the seat more than necessary. The seat belt is most effective when the occupants are sitting up straight and well back in the seats.
  - Do not wear the shoulder belt under your arm.
  - Always wear your seat belt low and snug across your hips.
- Pregnant women

Obtain medical advice and wear the seat belt in the proper way.  $(\rightarrow P. 30)$ 

Women who are pregnant should position the lap belt as low as possible over the hips in the same manner as other occupants, extending the shoulder belt completely over the shoulder and avoiding belt contact with the rounding of the abdominal area.

If the seat belt is not worn properly, not only the pregnant woman, but also the fetus could suffer death or serious injury as a result of sudden braking or a collision.



33

## **CAUTION**

## People suffering illness

Obtain medical advice and wear the seat belt in the proper way.  $(\rightarrow P. 30)$ 

#### When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death. If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

#### Seat belt pretensioners

Do not place anything, such as a cushion, on the front passenger's seat. Doing so will
disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the seat belt pretensioner for the front passenger's seat may not activate in the event of a collision.

• If the pretensioner has activated, the SRS warning light will come on. In that case, the seat belt cannot be used again and must be replaced at your Lexus dealer.

#### Adjustable shoulder anchor

Always make sure the shoulder belt is positioned across the center of your shoulder. The belt should be kept away from your neck, but not falling off your shoulder. Failure to do so could reduce the amount of protection in an accident and cause death or serious injuries in the event of a sudden stop, sudden swerve or accident. ( $\rightarrow$ P. 31)

#### Seat belt damage and wear

- Do not damage the seat belts by allowing the belt, plate, or buckle to be jammed in the door.
- Inspect the seat belt system periodically. Check for cuts, fraying, and loose parts. Do
  not use a damaged seat belt until it is replaced. Damaged seat belts cannot protect an
  occupant from death or serious injury.
- Ensure that the belt and plate are locked and the belt is not twisted.
- If the seat belt does not function correctly, immediately contact your Lexus dealer.
- Replace the seat assembly, including the belts, if your vehicle has been involved in a serious accident, even if there is no obvious damage.
- Do not attempt to install, remove, modify, disassemble or dispose of the seat belts. Have any necessary repairs carried out by your Lexus dealer. Inappropriate handling may lead to incorrect operation.

#### 1-1. For safe use

## 

## Using a seat belt extender

- Do not wear the seat belt extender if you can fasten the seat belt without the extender.
- Do not use the seat belt extender when installing a child restraint system because the belt will not securely hold the child restraint system, increasing the risk of death or serious injury in the event of an accident.
- The personalized extender may not be safe on another vehicle, when used by another person, or at a different seating position other than the one originally intended.

## **NOTICE**

## When using a seat belt extender

When releasing the seat belt, press on the buckle release button on the extender, not on the seat belt. This helps prevent damage to the vehicle interior and the extender itself.


his helps prevent damage to the vehicle interior and the extender itself.

35

## 36 1-1. For safe use

# SRS airbags

The SRS airbags inflate when the vehicle is subjected to certain types of severe impacts that may cause significant injury to the occupants. They work together with the seat belts to help reduce the risk of death or serious injury.




## SRS front airbags

- SRS driver airbag/front passenger airbag Can help protect the head and chest of the driver and front passenger from impact with interior components
- SRS knee airbags
   Can help provide driver and front passenger protection

	1-1. For safe use	37	
SRS side and curtain shield airbags			
③ SRS front side airbags Can help protect the torso of the front seat occ	cupants		
SRS rear side airbags (if equipped) Can help protect the torso of occupants in the	rear outer seats		
<ul> <li>Generation (4) SRS curtain shield airbags</li> <li>Can help protect primarily the head of occupation</li> </ul>	ants in the outer seats		1
			7

38



Your vehicle is equipped with ADVANCED AIRBAGS designed based on the US motor vehicle safety standards (FMVSS208). The airbag sensor assembly (ECU) controls airbag deployment based on information obtained from the sensors etc. shown in the system components diagram above. This information includes crash severity and occupant information. As the airbags deploy, a chemical reaction in the inflators quickly fills the airbags with non-toxic gas to help restrain the motion of the occupants.

### 

#### SRS airbag precautions

Observe the following precautions regarding the SRS airbags. Failure to do so may cause death or serious injury.

- The driver and all passengers in the vehicle must wear their seat belts properly. The SRS airbags are supplemental devices to be used with the seat belts.
- The SRS driver airbag deploys with considerable force, and can cause death or serious injury especially if the driver is very close to the airbag. The National Highway Traffic Safety Administration (NHTSA) advises:

Since the risk zone for the driver's airbag is the first 2 - 3 in. (50 - 75 mm) of inflation, placing yourself 10 in. (250 mm) from your driver airbag provides you with a clear margin of safety. This distance is measured from the center of the steering wheel to your breastbone. If you sit less than 10 in. (250 mm) away now, you can change your driving position in several ways:

- Move your seat to the rear as far as you can while still reaching the pedals comfortably.
- Slightly recline the back of the seat.

Although vehicle designs vary, many drivers can achieve the 10 in. (250 mm) distance, even with the driver seat all the way forward, simply by reclining the back of the seat somewhat. If reclining the back of your seat makes it hard to see the road, raise yourself by using a firm, non-slippery cushion, or raise the seat if your vehicle has that feature.

• If your steering wheel is adjustable, tilt it downward. This points the airbag toward your chest instead of your head and neck.

The seat should be adjusted as recommended by NHTSA above, while still maintaining control of the foot pedals, steering wheel, and your view of the instrument panel controls.

39


### 

### SRS airbag precautions

• If the seat belt extender has been connected to the front seat belt buckles but the seat belt extender has not also been fastened to the latch plate of the seat belt, the SRS front airbags will judge that the driver and front passenger are wearing the seat belt even though the seat belt has not been connected. In this case, the SRS front airbags may not activate correctly in a collision, resulting in death or serious injury in the event of a collision. Be sure to wear the seat belt with the seat belt extender.



- The SRS front passenger airbag also deploys with considerable force, and can cause death or serious injury especially if the front passenger is very close to the airbag. The front passenger seat should be as far from the airbag as possible with the seatback adjusted, so the front passenger sits upright.
- Improperly seated and/or restrained infants and children can be killed or seriously injured by a deploying airbag. An infant or child who is too small to use a seat belt should be properly secured using a child restraint system. Lexus strongly recommends that all infants and children be placed in the rear seats of the vehicle and properly restrained. The rear seats are safer for infants and children than the front passenger seat. (→P. 54)
- Do not sit on the edge of the seat or lean against the dashboard.



41 1-1. For safe use **CAUTION** SRS airbag precautions • Do not allow a child to stand in front of the SRS front passenger airbag unit or sit on the knees of a front passenger. • Do not allow the front seat occupants to hold items on their knees. For safety and security • Do not lean against the door, the roof side rail or the front, side and rear pillars. • Do not allow anyone to kneel on the passenger seats toward the door or put their head or hands outside the vehicle. • Do not attach anything to or lean anything against areas such as the dashboard, steering wheel pad and lower portion of the instrument panel. These items can become projectiles when the SRS driver, front passenger and knee airbags deploy. Do not attach anything to areas such as a door, windshield glass, side door glass, front or rear pillar, roof side rail and assist grip.

### 

#### SRS airbag precautions

- Do not hang coat hangers or hard objects on the coat hooks. All of these items could become projectiles and may cause death or serious injury, should the SRS curtain shield airbags deploy.
- If a vinyl cover is put on the area where the SRS knee airbag will deploy, be sure to remove it.
- Do not use seat accessories which cover the parts where the SRS side airbags inflate as they may interfere with inflation of the airbags. Such accessories may prevent the side airbags from activating correctly, disable the system or cause the side airbags to inflate accidentally, resulting in death or serious injury.
- Do not strike or apply significant levels of force to the area of the SRS airbag components.
  - Doing so can cause the SRS airbags to malfunction.
- Do not touch any of the component parts immediately after the SRS airbags have deployed (inflated) as they may be hot.
- If breathing becomes difficult after the SRS airbags have deployed, open a door or window to allow fresh air in, or leave the vehicle if it is safe to do so. Wash off any residue as soon as possible to prevent skin irritation.
- If the areas where the SRS airbags are stored, such as the steering wheel pad and front and rear pillar garnishes are damaged or cracked, have them replaced by your Lexus dealer.
- Do not place anything, such as a cushion, on the front passenger's seat. Doing so will disperse the passenger's weight, which prevents the sensor from detecting the passenger's weight properly. As a result, the SRS front passenger airbag may not deploy in the event of a collision.

### 

#### Modification and disposal of SRS airbag system components

Do not dispose of your vehicle or perform any of the following modifications without consulting your Lexus dealer. The SRS airbags may malfunction or deploy (inflate) accidentally, causing death or serious injury.

- Installation, removal, disassembly and repair of the SRS airbags
- Repairs, modifications, removal or replacement of the steering wheel, instrument panel, dashboard, seats or seat upholstery, front, side and rear pillars or roof side rails
- Repairs or modifications of the front fender, front bumper, or side of the occupant compartment
- Installation of snow plows, winches, etc. to the front grille (bull bars or kangaroo bar etc.)
- Modifications to the vehicle's suspension system
- Installation of electronic devices such as mobile two-way radios and CD players
- Modifications to your vehicle for a person with a physical disability

#### ■ If the SRS airbags deploy (inflate)

- Bruising and slight abrasions may result from contact with a deploying (inflating) SRS airbag.
- A loud noise and white powder will be emitted.
- Parts of the airbag module (steering wheel hub, airbag cover and inflator) as well as the seats, parts of the front and rear pillars, and roof side rails may be hot for several minutes. The airbag itself may also be hot.
- The windshield may crack.
- For Safety Connect subscribers, if the SRS airbags deploy or in the event of a severe rear-end collision, the system is designed to send an emergency call to the response center, notifying them of the vehicle's location (without needing to push the "SOS" button) and an agent will attempt to speak with the occupants to ascertain the level of emergency and assistance required. If the occupants are unable to communicate, the agent automatically treats the call as an emergency and helps to dispatch the necessary emergency services. (→P. 378)

#### SRS airbag deployment conditions (SRS front airbags)

• The SRS front airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to an approximately 12 - 18 mph [20 - 30 km/h] frontal collision with a fixed wall that does not move or deform).


However, this threshold velocity will be considerably higher in the following situations:

- If the vehicle strikes an object, such as a parked vehicle or sign pole, which can move
  or deform on impact
- If the vehicle is involved in an underride collision, such as a collision in which the front of the vehicle "underrides", or goes under, the bed of a truck
- Depending on the type of collision, it is possible that only the seat belt pretensioners will
  activate.
- The SRS front airbags for the front passenger will not activate if there is no passenger sitting in the front passenger seat. However, the SRS front airbags for the front passenger may deploy if luggage is put in the seat, even if the seat is unoccupied. (→P. 47)
- SRS airbag deployment conditions (SRS side and curtain shield airbags)
  - The SRS side and curtain shield airbags will deploy in the event of an impact that exceeds the set threshold level (the level of force corresponding to the impact force produced by an approximately 3300 lb. [1500 kg] vehicle colliding with the vehicle cabin from a direction perpendicular to the vehicle orientation at an approximate speed of 12 18 mph [20 30 km/h]).
  - The SRS curtain shield airbags may also deploy in the event of a severe frontal collision.

### Conditions under which the SRS airbags may deploy (inflate), other than a collision

The SRS front airbags and SRS curtain shield airbags may also deploy if a serious impact occurs to the underside of your vehicle. Some examples are shown in the illustration.


- Hitting a curb, edge of pavement or hard surface
- Falling into or jumping over a deep hole
- Landing hard or falling



#### ■ Types of collisions that may not deploy the SRS airbags (SRS front airbags)

The SRS front airbags do not generally inflate if the vehicle is involved in a side or rear collision, if it rolls over, or if it is involved in a low-speed frontal collision. But, whenever a collision of any type causes sufficient forward deceleration of the vehicle, deployment of the SRS front airbags may occur.


- Collision from the side
  Collision from the rear
- Vehicle rollover



## Types of collisions that may not deploy the SRS airbags (SRS side and curtain shield airbags)


The SRS side and curtain shield airbags may not activate if the vehicle is subjected to a collision from the side at certain angles, or a collision to the side of the vehicle body other than the passenger compartment.

- Collision from the side to the vehicle body other than the passenger compartment
- Collision from the side at an angle




The SRS side airbags do not generally inflate if the vehicle is involved in a frontal or rear collision, if it rolls over, or if it is involved in a low-speed side collision.

- Collision from the front
- Collision from the rear
- Vehicle rollover



The SRS curtain shield airbags do not generally inflate if the vehicle is involved in a rear collision, if it rolls over, or if it is involved in a low-speed side or low-speed frontal collision.

- Collision from the rear
- Vehicle rollover




For safety and security


#### When to contact your Lexus dealer

In the following cases, the vehicle will require inspection and/or repair. Contact your Lexus dealer as soon as possible.


- Any of the SRS airbags have been inflated.
- The front of the vehicle is damaged or deformed, or was involved in an accident that was not severe enough to cause the SRS front airbags to inflate.



- A portion of a door or its surrounding area is damaged or deformed, or the vehicle was involved in an accident that was not severe enough to cause the SRS side and curtain shield airbags to inflate.
- The pad section of the steering wheel, dashboard near the front passenger airbag or lower portion of the instrument panel is scratched, cracked, or otherwise damaged.
- The surface of the seats with the side airbag is scratched, cracked, or otherwise damaged.
- The portion of the front pillars, rear pillars or roof side rail garnishes (padding) containing the curtain shield airbags inside is scratched, cracked, or otherwise damaged.




CLYTIAZTI2





### Front passenger occupant classification system

Your vehicle is equipped with a front passenger occupant classification system. This system detects the conditions of the front passenger seat and activates or deactivates the devices for the front passenger.



- 1 Seat belt reminder light
- SRS warning light
- ③ "AIR BAG OFF" indicator light
- ④ "AIR BAG ON" indicator light

For safety and security

# Condition and operation in the front passenger occupant classification system

Adult\*1

		,	
Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG ON"	
	SRS warning light	Off	
	Seat belt reminder light	$\operatorname{Off}^{*2}$ or flashing $^{*3}$	
Devices	Front passenger airbag		
	Side airbag on the front passenger seat		
	Curtain shield airbag in the front passenger side	Activated	
	Front passenger knee airbag		
	Front passenger's seat belt pretensioner		

### ■ Child\*<sup>4</sup>

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF" or "AIR BAG ON"*4	
	SRS warning light	Off	
	Seat belt reminder light	Off <sup>*2</sup> or flashing <sup>*3</sup>	
Devices	Front passenger airbag	Deactivated or activated <sup>*4</sup>	
	Side airbag on the front passenger seat	Activated	
	Curtain shield airbag in the front passenger side		
	Front passenger knee airbag	Deactivated or activated <sup>*4</sup>	
	Front passenger's seat belt pretensioner	Activated	

## Child restraint system with infant<sup>\*5</sup>

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF" *6	
	SRS warning light	Off	
	Seat belt reminder light	Off <sup>*2</sup> or flashing <sup>*3</sup>	
Devices	Front passenger airbag	Deactivated	
	Side airbag on the front passenger seat	- Activated	
	Curtain shield airbag in the front passenger side		
	Front passenger knee airbag	Deactivated	
	Front passenger's seat belt pretensioner	Activated	

### Unoccupied

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF"	
	SRS warning light	Off	
	Seat belt reminder light		
Devices	Front passenger airbag	Deactivated	
	Side airbag on the front passenger seat	- Activated	
	Curtain shield airbag in the front passenger side		
	Front passenger knee airbag	Deactivated	
	Front passenger's seat belt pretensioner	Activated	

49

### There is a malfunction in the system

Indicator/ warning light	"AIR BAG ON" and "AIR BAG OFF" indicator lights	"AIR BAG OFF"	
	SRS warning light	On	
	Seat belt reminder light		
Devices	Front passenger airbag	Deactivated	
	Side airbag on the front passenger seat	- Activated	
	Curtain shield airbag in the front passenger side		
	Front passenger knee airbag	Deactivated	
	Front passenger's seat belt pretensioner	Activated	

\*1: The system judges a person of adult size as an adult. When a smaller adult sits in the front passenger seat, the system may not recognize him/her as an adult depending on his/her physique and posture.

- $^{\star2}$ : In the event the front passenger is wearing a seat belt.
- \*<sup>3</sup>: In the event the front passenger does not wear a seat belt
- \*4: For some children, child in seat, child in booster seat or child in convertible seat, the system may not recognize him/her as a child. Factors which may affect this can be the physique or posture.
- \*<sup>5</sup>: Never install a rear-facing child restraint system on the front passenger seat. A forward-facing child restraint system should only be installed on the front passenger seat when it is unavoidable. (→P. 54)
- \*6: In case the indicator light is not illuminated, consult this manual on how to install the child restraint system properly. (→P. 58)

50

### 

### Front passenger occupant classification system precautions

Observe the following precautions regarding the front passenger occupant classification system.

Failure to do so may cause death or serious injury.

- Wear the seat belt properly.
- Make sure the front passenger's seat belt plate has not been left inserted into the buckle before someone sits in the front passenger seat.
- Make sure the "AIR BAG OFF" indicator light is not illuminated when using the seat belt extender for the front passenger seat. If the "AIR BAG OFF" indicator light is illuminated, disconnect the extender tongue from the seat belt buckle, and reconnect the seat belt. Reconnect the seat belt extender after making sure the "AIR BAG ON" indicator light is illuminated. If you use the seat belt extender while the "AIR BAG OFF" indicator light is illuminated, the SRS airbags for the front passenger may not activate, which could cause death or serious injury in the event of a collision.
- Do not apply a heavy load to the front passenger seat or equipment (e.g. seatback pocket).
- Do not put weight on the front passenger seat by putting your hands or feet on the front passenger seat seatback from the rear passenger seat.
- Do not let a rear passenger lift the front passenger seat with their feet or press on the seatback with their legs.
- Do not put objects under the front passenger seat.

IS350/250\_U (OM53758U)

### 

- Front passenger occupant classification system precautions
- Do not recline the front passenger seatback so far that it touches the rear seat. This may cause the "AIR BAG OFF" indicator light to be illuminated, which indicates that the SRS airbags for the front passenger will not deploy in the event of a severe accident. If the seatback touches the rear seat, return the seatback to a position where it does not touch the rear seat. Keep the front passenger seatback as upright as possible when the vehicle is moving. Reclining the seatback excessively may lessen the effectiveness of the seat belt system.
- If an adult sits in the front passenger seat, the "AIR BAG ON" indicator light is illuminated. If the "AIR BAG OFF" indicator is illuminated, ask the passenger to sit up straight, well back in the seat, feet on the floor, and with the seat belt worn correctly. If the "AIR BAG OFF" indicator still remains illuminated, either ask the passenger to move to the rear seat, or if that is not possible, move the front passenger seat fully rearward.
- When it is unavoidable to install a forward-facing child restraint system on the front passenger seat, install the child restraint system on the front passenger seat in the proper order. (→P. 58)
- Do not modify or remove the front seats.
- Do not kick the front passenger seat or subject it to severe impact. Otherwise, the SRS warning light may come on to indicate a malfunction of the front passenger occupant classification system. In this case, contact your Lexus dealer immediately.
- Child restraint systems installed on the rear seat should not contact the front seatbacks.
- Do not use a seat accessory, such as a cushion and seat cover, that covers the seat cushion surface.
- Do not modify or replace the upholstery of the front seat.
- Do not place anything between the console box and front passenger seat. Otherwise, the system may not detect the front passenger properly, leading to improper operation of the airbags.
- Adjust the front passenger seat so that the head restraint does not touch the ceiling. If the head restraint is left in contact with the ceiling, the system may not detect the front passenger properly, leading to improper operation of the airbags.

### Safety information for children

Observe the following precautions when children are in the vehicle. Use a child restraint system appropriate for the child, until the child becomes large enough to properly wear the vehicle's seat belt.

- It is recommended that children sit in the rear seats to avoid accidental contact with the shift lever, wiper switch etc.
- Use the rear door child-protector lock or the window lock switch to avoid children opening the door while driving or operating the power window accidentally.
- Do not let small children operate equipment which may catch or pinch body parts, such as the power window, hood, trunk, seats etc.

### **CAUTION**

Never leave children unattended in the vehicle, and never allow children to have or use the key.

Children may be able to start the vehicle or shift the vehicle into neutral. There is also a danger that children may injure themselves by playing with the windows, the moon roof or other features of the vehicle. In addition, heat build-up or extremely cold temperatures inside the vehicle can be fatal to children.

### **Child restraint systems**

A child restraint system for a small child or baby must itself be properly restrained on the seat with the lap portion of the lap/shoulder belt.

The laws of all 50 states of the U.S.A. and Canada now require the use of child restraint systems.

### Points to remember

Studies have shown that installing a child restraint on a rear seat is much safer than installing one on the front passenger seat.


- Choose a child restraint system that suits your vehicle and is appropriate to the age and size of the child.
- For installation details, follow the instructions provided with the child restraint system.

General installation instructions are provided in this manual.  $(\rightarrow P. 58)$ 

### Types of child restraints

Child restraint systems are classified into the following 3 types according to the age and size of the child:

Rear facing — Infant seat/convert Forward facing — Convertible seat





Booster seat



### Selecting an appropriate child restraint system

- Use a child restraint system appropriate for the child until the child becomes large enough to properly wear the vehicle's seat belt.
- If the child is too large for a child restraint system, sit the child on a rear seat and use the vehicle's seat belt. ( $\rightarrow$ P. 30)

### 

#### Child restraint precautions

- For effective protection in automobile accidents and sudden stops, a child must be properly restrained, using a seat belt or child restraint system depending on the age and size of the child. Holding a child in your arms is not a substitute for a child restraint system. In an accident, the child can be crushed against the windshield, or between you and the vehicle's interior. This may cause death or serious injury to the child in the event of a sudden stop, sudden swerve or an accident.
- Lexus strongly urges the use of a proper child restraint system that conforms to the size of the child, installed on the rear seat. According to accident statistics, the child is safer when properly restrained in the rear seat than in the front seat.
- Never install a rear-facing child restraint system on the front passenger seat even if the "AIR BAG OFF" indicator light is illuminated. In the event of an accident, the force of the rapid inflation of the front passenger airbag can cause death or serious injury to the child if the rear-facing child restraint system is installed on the front passenger seat.
- A forward-facing child restraint system may be installed on the front passenger seat only when it is unavoidable. A child restraint system that requires a top tether strap should not be used in the front passenger seat since there is no top tether strap anchor for the front passenger seat. Adjust the seatback as upright as possible and always move the seat as far back as possible even if the "AIR BAG OFF" indicator light is illuminated, because the front passenger airbag could inflate with considerable speed and force. Otherwise, the child may be killed or seriously injured.
- Do not use the seat belt extender when installing a child restraint system on the front or rear passenger seat. If installing a child restraint system with the seat belt extender connected to the seat belt, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of a sudden stop, sudden swerve or accident.
- Do not allow the child to lean his/her head or any part of his/her body against the door or the area of the seat, front, center and rear pillars or roof side rails from which the SRS side airbags or SRS curtain shield airbags deploy even if the child is seated in the child restraint system. It is dangerous if the SRS side airbags and curtain shield airbags inflate, and the impact could cause death or serious injury to the child.
- Make sure you have complied with all installation instructions provided by the child restraint manufacturer and that the system is properly secured. If it is not secured properly, it may cause death or serious injury to the child in the event of a sudden stop, sudden swerve or an accident.

### **CAUTION**

### When children are in the vehicle

Do not allow children to play with the seat belt. If the seat belt becomes twisted around a child's neck, it may lead to choking or other serious injuries that could result in death. If this occurs and the buckle cannot be unfastened, scissors should be used to cut the belt.

- When the child restraint system is not in use
  - Keep the child restraint system properly secured on the seat even if it is not in use. Do not store the child restraint system unsecured in the passenger compartment.
  - If it is necessary to detach the child restraint system, remove it from the vehicle or store it securely in the trunk. This will prevent it from injuring passengers in the event of a sudden stop, sudden swerve or accident.

57

### Installing child restraints

Follow the child restraint system manufacturer's instructions. Firmly secure child restraints to the seats using the LATCH anchors or a seat belt. Attach the top tether strap when installing a child restraint.

The lap/shoulder belt can be used if your child restraint system is not compatible with the LATCH (Lower Anchors and Tethers for Children) system.

Child restraint LATCH anchors


LATCH anchors are provided for the outboard rear seats, behind the anchor covers.

Seat belts equipped with a child restraint locking mechanism (ALR/ ELR belts except driver's seat belt)  $(\rightarrow P.32)$ 

Anchor brackets (for top tether strap) An anchor bracket is provided for each rear seat.







59

For safety and security

### Installation with LATCH system


1 Remove the head restraint if it interferes with your child restraint system.

▶ Type A

2 Latch the hooks of the lower straps onto the LATCH anchors. If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor.

For owners in Canada:

The symbol on a child restraint system indicates the presence of a lower connector system.




### ► Type B

2 Latch the buckles onto the LATCH anchors. If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor.

For owners in Canada:

The symbol on a child restraint system indicates the presence of a lower connector system.




# Installing child restraints using a seat belt (child restraint lock function belt)


### ■ Rear-facing—Infant seat/convertible seat

1 Place the child restraint system on the rear seat facing the rear of the vehicle.



- 2 Run the seat belt through the child restraint system and insert the plate into the buckle. Make sure that the belt is not twisted.
- 3 Fully extend the shoulder belt and allow it to retract to put it in lock mode. In lock mode, the belt cannot be extended.







4 While pushing the child restraint system down into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

> After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.


### Forward-facing—Convertible seat

- 1 Remove the head restraint if it interferes with your child restraint system.
- **2** Place the child restraint system on the seat facing the front of the vehicle.










- Fully extend the shoulder belt and allow it to retract to put it in lock mode. In lock mode, the belt cannot be extended.
- **5** While pushing the child restraint system into the rear seat, allow the shoulder belt to retract until the child restraint system is securely in place.

After the shoulder belt has retracted to a point where there is no slack in the belt, pull the belt to check that it cannot be extended.

 1.1. For safe use
 63



**6** If the child restraint has a top tether strap, the top tether strap should be latched onto the top tether strap anchor. ( $\rightarrow$ P. 65)

### Booster seat

- 1 Place the child restraint system on the seat facing the front of the vehicle.
- 2 Sit the child in the child restraint system. Fit the seat belt to the child restraint system according to the manufacturer's instructions and insert the plate into the buckle. Make sure that the belt is not twisted.


Check that the shoulder belt is correctly positioned over the child's shoulder and that the lap belt is as low as possible. ( $\rightarrow$ P. 30)





### Removing a child restraint installed with a seat belt

Push the buckle release button and fully retract the seat belt.




### Child restraint systems with a top tether strap

1 Remove the head restraint if it interferes with your child restraint system.

- 2 Secure the child restraint system using the seat belt or LATCH anchors.
- CUTIAZISS
- 3 Open the anchor bracket cover, latch the hook onto the anchor bracket and tighten the top tether strap.

Make sure the top tether strap is securely latched.



Laws and regulations pertaining to anchorages The LATCH system conforms to FMVSS225 or CMVSS210.2. Child restraint systems conforming to FMVSS213 or CMVSS213 specifications can be used.

This vehicle is designed to conform to the SAE J1819.

65

For safety and security

### 

#### When installing a booster seat

To prevent the belt from going into ALR lock mode, do not fully extend the shoulder belt. ALR mode causes the belt to tighten only. This could cause injury or discomfort to the child. ( $\rightarrow$ P. 32)

#### When installing a child restraint system

Follow the directions given in the child restraint system installation manual and fix the child restraint system securely in place.

If the child restraint system is not correctly fixed in place, the child or other passengers may be seriously injured or even killed in the event of a sudden braking or an accident.

- If the driver's seat interferes with the child restraint system and prevents it from being attached correctly, attach the child restraint system to the right-hand rear seat.
- Adjust the front passenger seat so that it does not interfere with the child restraint system.
- Only put a forward-facing child restraint system on the front seat when unavoidable. When installing a forward-facing child restraint system on the front passenger seat, move the seat as far back as possible even if the "AIR BAG OFF" indicator light is illuminated. Failure to do so may result in death or serious injury if the airbags deploy (inflate).





### 

### When installing a child restraint system

- When using the LATCH anchors for a child restraint system, move the seat as far back as possible, with the seatback close to the child restraint system.
- When a booster seat is installed, always ensure that the shoulder belt is positioned across the center of the child's shoulder. The belt should be kept away from the child's neck, but not so that it could fall off the child's shoulder. Failing to do so may result in death or serious injury in the event of sudden braking, sudden swerving or an accident.
- Ensure that the belt and plate are securely locked and the seat belt is not twisted.
- Shake the child restraint system left and right, and forward and backward to ensure that it has been securely installed.
- After securing a child restraint system, never adjust the seat.
- Follow all installation instructions provided by the child restraint system manufacturer.

#### Do not use a seat belt extender

If a seat belt extender is used when installing a child restraint system, the seat belt will not securely hold the child restraint system, which could cause death or serious injury to the child or other passengers in the event of a sudden braking, sudden swerving or an accident.

To correctly attach a child restraint system to the anchors

When using the LATCH anchors, be sure that there are no foreign objects around the anchors and that the seat belt is not caught behind the child restraint system. Make sure the child restraint system is securely attached, or it may cause death or serious injury to the child or other passengers in the event of a sudden braking, sudden swerve or an accident.

### Exhaust gas precautions

### Harmful substance to the human body is included in exhaust gases if inhaled.

### **CAUTION**

Exhaust gases include harmful carbon monoxide (CO), which is colorless and odorless. Observe the following precautions.

Failure to do so may cause exhaust gases enter the vehicle and may lead to an accident caused by light-headedness, or may lead to death or a serious health hazard.

### Important points while driving

• Keep the trunk lid closed.

• If you smell exhaust gases in the vehicle even when the trunk lid is closed, open the windows and have the vehicle inspected at your Lexus dealer as soon as possible.

#### When parking

- If the vehicle is in a poorly ventilated area or a closed area, such as a garage, stop the engine.
- Do not leave the vehicle with the engine on for a long time. If such a situation cannot be avoided, park the vehicle in an open space and ensure that exhaust fumes do not enter the vehicle interior.
- Do not leave the engine running in an area with snow build-up, or where it is snowing. If snowbanks build up around the vehicle while the engine is running, exhaust gases may collect and enter the vehicle.

### Exhaust pipe

The exhaust system needs to be checked periodically. If there is a hole or crack caused by corrosion, damage to a joint or abnormal exhaust noise, be sure to have the vehicle inspected and repaired by your Lexus dealer.

 1-1. For safe use	69	
		1
		-
		or sa
		fety a
		nd se
		For safety and security

### Engine immobilizer system

The vehicle's keys have built-in transponder chips that prevent the engine from starting if a key has not been previously registered in the vehicle's onboard computer.

Never leave the keys inside the vehicle when you leave the vehicle.

The indicator light flashes after the engine switch has been turned off to indicate that the system is operating.

The indicator light stops flashing after the engine switch has been turned to ACCESSORY or IGNITION ON mode to indicate that the system has been canceled.



System maintenance

The vehicle has a maintenance-free type engine immobilizer system.

- Conditions that may cause the system to malfunction
  - If the grip portion of the key is in contact with a metallic object
  - If the key is in close proximity to or touching a key registered to the security system (key with a built-in transponder chip) of another vehicle

### 69

For safety and security

#### Certifications for the engine immobilizer system

► For vehicles sold in the U.S.A.

FCC ID: NI4TMIMB-3

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

► For vehicles sold in Canada

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

### **NOTICE**

### To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

### Alarm

### The alarm


The alarm uses light and sound to give an alert when an intrusion is detected. The alarm is triggered in the following situations when the alarm is set:

- A locked door or trunk is unlocked or opened in any way other than using the entry function, wireless remote control or mechanical key. (The doors will lock again automatically.)
- The hood is opened.

### Setting the alarm system

Close the doors, trunk and hood, and lock all the doors. The system will be set automatically after 30 seconds.

The indicator light changes from being on to flashing when the system is set.



### Deactivating or stopping the alarm

Do one of the following to deactivate or stop the alarms:

- Unlock the doors or open the trunk.
- Turn the engine switch to ACCESSORY or IGNITION ON mode, or start the engine. (The alarm will be deactivated or stopped after a few seconds.)

#### System maintenance

The vehicle has a maintenance-free type alarm system.

#### Items to check before locking the vehicle

To prevent unexpected triggering of the alarm and vehicle theft, make sure of the following:

- Nobody is in the vehicle.
- The windows and moon roof are closed before the alarm is set.
- No valuables or other personal items are left in the vehicle.


#### Triggering of the alarm

The alarm may be triggered in the following situations: (Stopping the alarm deactivates the alarm system.)

 A person inside the vehicle opens a door, the trunk or hood, or unlocks the vehicle using a inside lock button.



● The battery is recharged or replaced when the vehicle is locked. (→P. 492)



#### Alarm-operated door lock

- In the following situations, the doors are locked automatically to prevent intruders:
- The doors are unlocked manually without the mechanical key and the alarm is triggered.
- While the alarm is operating, the doors are unlocked manually without the mechanical key.

#### **NOTICE**

#### To ensure the system operates correctly

Do not modify or remove the system. If modified or removed, the proper operation of the system cannot be guaranteed.

#### 1-2. Theft deterrent system

# Theft prevention labels (U.S.A.)

These labels are attached to the vehicle to reduce vehicle theft by facilitating the tracing and recovery of parts from stolen vehicles. Do not remove under penalty of law.



# Instrument cluster

2

#### 2. Instrument cluster Warning lights and indicators

indicators76
Gauges and meters
Multi-information display86
Fuel consumption
information92

IS350/250\_U (OM53758U)

# 76 2. Instrument cluster

# Warning lights and indicators

The warning lights and indicators on the instrument cluster and center panel inform the driver of the status of the vehicle's various systems.

For the purpose of explanation, the following illustrations display all warning lights and indicators illuminated.

Except F SPORT models



► F SPORT models



The units used on the meters and some indicators may differ depending on the target region.

2. Instrument cluster

ing light

(→P. 456)

#### Warning lights

Warning lights inform the driver of malfunctions in the indicated vehicle systems.


*
BRAKE
(U.S.A.)

(Canada)


\*1



Brake system warning light







\*1, 2

CS

(if equipped)

Automatic headlight leveling system warning light  $(\rightarrow P. 456)$ 

Pre-collision system warn-




(Canada)

Malfunction indicator lamp (→P. 455)

Charging system warning light (→P. 455)



Open door warning light (→P. 456)



(→P. 456)

Low fuel level warning light



SRS warning light (→P. 455)

(→P. 455)



Seat belt reminder light (→P. 456)



ABS warning light  $(\rightarrow P.455)$ 



ABS warning light  $(\rightarrow P. 455)$ 





Electric power steering system warning light (→P. 455)



Master warning light (→P. 456)



Tire pressure warning light (→P. 457)

2

Instrument cluster

#### 78 2. Instrument cluster

- \*1: These lights turn on when the engine switch is turned to IGNITION ON mode to indicate that a system check is being performed. They will turn off after the engine is on, or after a few seconds. There may be a malfunction in a system if the lights do not come on, or turn off. Have the vehicle inspected by your Lexus dealer.
- \*<sup>2</sup>: The light flashes to indicate a malfunction.

#### Indicators

The indicators inform the driver of the operating state of the vehicle's various systems.



Turn signal indicator (→P. 170)



Headlight indicator  $(\rightarrow P. 173)$ 



Tail light indicator (→P.173)



Headlight high beam indicator ( $\rightarrow$ P. 174)



(if equipped)

P M

(if equipped)

\*12

\*1,3

\*4,5

CS

VSC OFF indicator  $(\rightarrow P. 236)$ 

Slip indicator ( $\rightarrow$ P. 235)

(Lane


 $cator (\rightarrow P. 214)$ 

Alert) indicator ( $\rightarrow$ P. 208)

Intuitive parking assist indi-

LDA

Departure



Pre-collision system warning light (→P. 241)



AUTÓ

(if equipped)

Fog light indicator  $(\rightarrow P. 181)$ 

cator ( $\rightarrow$ P. 176)



Cruise control indicator (→P. 192, 196)



Dynamic radar cruise control indicator ( $\rightarrow$ P. 196)



Cruise control "SET" indicator  $(\rightarrow P. 192, 196)$ 



BSM (Blind Spot Monitor) outside rear view mirror indicators ( $\rightarrow$ P. 246)



Security indicator  $(\rightarrow P. 69, 71)$ 




Low outside temperature indicator ( $\rightarrow$ P. 81)



Eco Driving Indicator Light  $(\rightarrow P.90)$ 





- \*1: These lights turn on when the engine switch is turned to IGNITION ON mode to indicate that a system check is being performed. They will turn off after the engine is on, or after a few seconds. There may be a malfunction in a system if the lights do not come on, or turn off. Have the vehicle inspected by your Lexus dealer.
- \*<sup>2</sup>: The light flashes to indicate that the system is operating.
- \*<sup>3</sup>: The light comes on when the system is turned off. The light flashes faster than usual to indicate that the system is operating.
- \*4: In order to confirm operation, the BSM outside rear view mirror indicators illuminate in the following situations:
  - When the engine switch is turned to IGNITION ON mode while the BSM main switch is set to ON.
  - When the BSM main switch is set to ON while the engine switch is in IGNITION ON mode.

If the system is functioning correctly, the BSM outside rear view mirror indicators will turn off after a few seconds.

If the BSM outside rear view mirror indicators do not illuminate or do not turn off, there may be a malfunction in the system.

- If this occurs, have the vehicle inspected by your Lexus dealer.
- \*<sup>5</sup>: This light illuminates on the outside rear view mirrors.
- \*<sup>6</sup>: This light illuminates on the center panel.
- \*<sup>7</sup>: When the outside temperature is approximately 37°F (3°C) or lower, the indicator will flash for approximately 10 seconds, then stay on.
- \*8: Except F SPORT models
- \*<sup>9</sup>: F SPORT models

# 80 2. Instrument cluster

#### **A** CAUTION

#### If a safety system warning light does not come on

Should a safety system light such as the ABS and SRS warning light not come on when you start the engine, this could mean that these systems are not available to help protect you in an accident, which could result in death or serious injury. Have the vehicle inspected by your Lexus dealer immediately if this occurs.

81


Instrument cluster

# Gauges and meters


▶ Except F SPORT models



► F SPORT models (when the main meter is in the center position)



▶ F SPORT models (when the main meter is in the right-side position)



The units used on the meters may differ depending on the target region.

<ol> <li>Engine coolant temperature ga</li> </ol>	auge
---	------

- Displays the engine coolant temperature
- 2 Tachometer

Displays the engine speed in revolutions per minute

3 Outside temperature

Displays the outside temperature within the range of -40°F (-40°C) to 122°F (50°C). Low outside temperature indicator comes on when the ambient temperature is 37°F (3°C) or lower.

- 4 Shift position and gear position ( $\rightarrow$ P. 164)
- 5 Speedometer
- 6 Fuel gauge
- ⑦ Multi-information display

Presents the driver with a variety of vehicle data  $(\rightarrow P. 86)$ 

Displays warning messages in case of a malfunction ( $\rightarrow$ P. 461)

8 Odometer and trip meter display

Odometer:

Displays the total distance the vehicle has been driven  $\overline{\mathbf{T}}$ 

Trip meter:


Displays the distance the vehicle has been driven since the meter was last reset. Trip meters "A" and "B" can be used to record and display different distances independently.

#### 2. Instrument cluster

# Changing the display

Odometer/Trip meter

Switches between odometer and trip meter displays. When the trip meter is displayed, pressing and holding the button will reset the trip meter.



Main meter (F SPORT models)

Moves between center and rightside positions.



2

83


Instrument cluster

#### 84 2. Instrument cluster

#### Instrument panel light control

The brightness of the instrument panel lights can be adjusted.

- 1 Darker
- Brighter



#### The meters and display illuminate when

The engine switch is in IGNITION ON mode.

#### Instrument panel brightness adjustment

The instrument panel brightness levels when the tail lights are on and off can be adjusted individually. However, when the surroundings are bright (daytime, etc.), turning on the tail lights will not change the instrument panel brightness. At this time, any adjustments made to the instrument panel brightness levels will be applied to both settings at once.

#### Outside temperature display

In the following situations, the correct outside temperature may not be displayed, or the display may take longer than normal to change.

- When stopped, or driving at low speeds (less than 12 mph [20 km/h])
- When the outside temperature has changed suddenly (at the entrance/exit of a garage, tunnel, etc.)

#### Pop-up display

In some situations, such as when a switch operation is performed, a pop-up display, such as the operating methods of the headlight switch, will be temporarily displayed on the multi-information display or the odometer/trip meter screen (F SPORT models only). The pop-up display function can be set on/off. ( $\rightarrow$ P. 89)

#### Liquid crystal display

Small spots or light spots may appear on the display. This phenomenon is characteristic of liquid crystal displays, and there is no problem continuing to use the display.

#### Customization

The meter display can be customized on the multi-information display. ( $\rightarrow$ P. 86)

2. Instrument cluster

#### 


#### To prevent damage to the engine and its components

- Do not let the indicator needle of the tachometer enter the red zone, which indicates the maximum engine speed.
- The engine may be overheating if the engine coolant temperature gauge is in the red zone (H). In this case, immediately stop the vehicle in a safe place, and check the engine after it has cooled completely. (→P. 494)

#### 86 2. Instrument cluster

# **Multi-information display**

The multi-information display presents the driver with a variety of vehicle data.



Select to display various drive data.  $(\rightarrow P. 87)$ 



Navigation system-linked display (if equipped)

Select to display the following navigation system-linked information.

- Route guidance
- Compass display (north-up display/heading-up display)



Audio system-linked display

Select to enable selection of an audio source or track on the meter using the meter control switches.



Dynamic radar cruise control operation guide (if equipped)

Select to display operation procedures of the dynamic radar cruise control. (→P.196)

The tab will change to when the vehicle is in constant speed control mode. ( $\rightarrow$ P. 201)

If activated, the operational status of the LDA (Lane Departure Alert) system will also be displayed. ( $\rightarrow$ P. 210)



Warning message display

Select to display warning messages and measures to be taken if a malfunction is detected ( $\rightarrow$ P 461)




Settings display

Select to change the meter display settings.  $(\rightarrow P. 88)$ 

#### Operating the meter control switches

The multi-information display is operated using the meter control switches.

- 1 Select an item/change pages
- Enter/Set
- Except F SPORT models
- ③ Press: Displays the screen registered to ■



When no screen has been registered, the drive information screen will be displayed.

Press and hold: Registers the currently displayed screen to

When the confirmation screen is displayed, select yes to register the screen. If the selected screen cannot be registered, a registration failure message will be shown.

- F SPORT models
- ③ Move the main meter
- 4 Return to the previous screen

#### Drive Information

Current fuel consumption\*

Displays the current rate of fuel consumption

#### Average fuel economy (after reset/after start/after refuel)\*

Displays the average fuel economy since the function was reset, the engine was started, and the vehicle was refueled, respectively

#### Average vehicle speed (after reset/after start)\*

Displays the average vehicle speed since the function was reset and the engine was started, respectively

#### Elapsed time (after reset/after start)\*

Displays the elapsed time since the function was reset and the engine was started, respectively

87

2

Instrument cluster

#### Distance (driving range/after start)\*

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining and the distance driven after the engine was started respectively.

- This distance is computed based on your average fuel consumption. As a result, the actual distance that can be driven may differ from that displayed.
- When only a small amount of fuel is added to the tank, the display may not be updated.

When refueling, turn the engine switch off. If the vehicle is refueled without turning the engine switch off, the display may not be updated.

#### Eco Driving Indicator

→P. 90

Tire inflation pressure

→P. 412

Gear positions

→P. 168

\*: Displayed when the item is set in "Drive Info 1" or "Drive Info 2". Use these values as a reference.

#### Settings display

#### Language

Select to change the language on the display.

Units

Select to change the unit of measure for fuel consumption.

#### Maintenance system

Select to reset the maintenance data after the required maintenance is performed. ( $\rightarrow$ P. 391)

#### Eco Driving Indicator Light

Select to activate/deactivate the Eco Driving Indicator Light.

#### switch settings (except F SPORT models)

Displays a procedure to register a desired screen to I.

You can register 1 screen as a shortcut, which can be displayed by pressing  $I_{I}. (\rightarrow P. 87)$ 

#### Drive information 1/Drive information 2

Select to select up to 2 items that will be displayed on the "Drive Info 1" screen and "Drive Info 2" screen respectively. ( $\rightarrow$ P. 87)

#### Pop-up display

Select to set the following pop-up displays, which may appear in some situations, on/off.

- Route guidance display of the navigation system-linked system (if equipped)
- · Incoming call display of the hands-free phone system
- Windshield wiper switch operation display (if equipped)
- Headlight switch operation display (if equipped)
- Dynamic radar cruise control operation display (if equipped)
- Instrument panel brightness adjustment display
- Main meter switch operation display (F SPORT models)

#### Accent color (except F SPORT models)

Select to change the accent colors on the screen, such as the cursor color.

#### Needle (F SPORT models)

Select to change the needle color for the tachometer.

#### Speed indicator (F SPORT models)

Select to set the speed indicator on/ off.

When set to on, both sides of the displayed speed unit will turn yellow when the vehicle reaches a set speed.

Selectable speed range: 30 mph to 100 mph (50 km/h to 160 km/h)\*



The indicator will illuminate in yellow at an optionally set speed and red at the fixed high speed.

\*: Always observe the legal speed limit when driving on public roads.

#### Rev indicator (F SPORT models)

Select to set the rev indicator on/off.

When set to on, the tachometer will show a ring-shaped indicator in red when the engine reaches a set speed. Selectable engine speed range: 2000 rpm to 6600 rpm.



2

Instrument cluster

#### 2. Instrument cluster

#### Rev peak (F SPORT models)

Select to set the rev peak on/off.

When set to on and the engine speed reaches or exceeds 5000 rpm, an afterimage of the tachometer will be displayed at the highest engine speed for approximately 0.5 seconds.



#### Initialization

Select to reset the meter display settings.  $(\rightarrow P. 526)$ 

#### Eco Driving Indicator

- Eco Driving Indicator Light During Eco-friendly acceleration (Eco driving), the Eco Driving Indicator Light will turn on. When the acceleration exceeds the Zone of Eco driving, or when the vehicle is stopped, the light turns off.
- ② Eco Driving Indicator Zone Display Suggests the Zone of Eco driving with current Eco driving ratio based on acceleration.
- ③ Eco driving ratio based on acceleration If the acceleration exceeds the Zone of Eco driving, the right side of the Eco Driving Indicator Zone Display will illuminate.
- ④ Zone of Eco driving


Eco Driving Indicator will not operate under the following conditions:

- The shift lever is in any position other than D.
- A paddle shift switch is operated.
- Neither normal mode nor Eco drive mode is selected.  $(\rightarrow P. 231)$
- The vehicle speed is approximately 80 mph (130 km/h) or higher.

#### Suspension of the settings display

In the following situations, the settings display using the meter control switches will be suspended.

- When a warning message appears on the multi-information display
- When the vehicle begins to move



#### Tire inflation pressure

- It may take a few minutes to display the tire inflation pressure after the engine switch is turned to IGNITION ON mode. It may also take a few minutes to display the tire inflation pressure after inflation pressure has been adjusted.
- "---" may be displayed if the tire information cannot be determined due to unfavorable radio wave conditions.
- Tire inflation pressure changes with temperature. The displayed values may also be different from the values measured using a tire pressure gauge.

Liquid crystal display

 $\rightarrow P.84$ 

#### **CAUTION**

#### The information display at low temperatures

Allow the interior of the vehicle to warm up before using the liquid crystal information display. At extremely low temperatures, the information display monitor may respond slowly, and display changes may be delayed.

For example, there is a lag between the driver's shifting and the new gear number appearing on the display. This lag could cause the driver to downshift again, causing rapid and excessive engine braking and possibly an accident resulting in death or injury.

#### Cautions during setting up the display

As the engine needs to be running during setting up the display, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.

#### NOTICE

#### During setting up the display

To prevent battery discharge, ensure that the engine is running while setting up the display features.

#### 91

2

Instrument cluster

# 92 2. Instrument cluster

# Fuel consumption information

Fuel consumption information can be displayed on the navigation system screen or the Lexus Display Audio screen.

- Advigation system
   Cexus Display Addio controller
- Navigation system
- Lexus Display Audio system

#### 2. Instrument cluster

#### Trip information

Navigation system

Press the "MENU" button on the Remote Touch, then select "Info" on the "Menu" screen, and then select "Fuel Consumption".

If the "Past Record" screen is displayed, select "Trip Information".

- 1 Resetting the consumption data
- ② Fuel consumption in the past 15 minutes
- ③ Displays the average vehicle speed since the engine was started.
- (4) Displays the elapsed time since the engine was started.
- (5) Cruising range ( $\rightarrow$ P. 96)



CLY20AZE


#### **94** 2. Instrument cluster

Lexus Display Audio system

Press the "MENU" button on the Lexus Display Audio controller, then select "Info" on the "Menu" screen, and then select "Fuel Consumption".

If the "Trip Information" screen does not appear, move the controller to the right and select "Trip Information".

- Fuel consumption in the past 15 minutes
- ② Displays the average vehicle speed since the engine was started.
- 3 Displays the elapsed time since the engine was started.
- (4) Cruising range ( $\rightarrow$ P. 96)



Average fuel consumption for the past 15 minutes is divided by color into past averages and averages attained since the engine switch was last turned to IGNITION ON mode. Use the displayed average fuel consumption as a reference.

The image is an example only.

IS350/250\_U (OM53758U)

# Past record

Navigation system


Press the "MENU" button on the Remote Touch, then select "Info" on the "Menu" screen, and then select "Fuel Consumption".

- If the "Trip Information" screen is displayed, select "Past Record".
- (1) Resetting the past record data
- 2 Best recorded fuel consumption
- 3 Average fuel consumption
- 4 Previous fuel consumption record
- 5 Updating the average fuel consumption data
- Lexus Display Audio system

Press the "MENU" button on the Lexus Display Audio controller, then select "Info" on the "Menu" screen, and then select "Fuel Consumption".

If the "Past Record" screen does not appear, move the controller to the right and select "Past Record".

- 1 Previous fuel consumption record
- Average fuel consumption
- 3 Best recorded fuel consumption



The image is an example only.



Instrument cluster

2

#### Updating the past record data

► Navigation system

Update the average fuel consumption by selecting "Update" to measure the current fuel consumption again.

► Lexus Display Audio system

Update the average fuel consumption by moving the controller to the left and select "Update" to measure the current fuel consumption again.

#### Resetting the data

► Navigation system

The fuel consumption data can be deleted by selecting "Clear".

► Lexus Display Audio system

The fuel consumption data can be deleted by moving the controller to the left and select "Clear".

#### Cruising range

Displays the estimated maximum distance that can be driven with the quantity of fuel remaining.

This distance is computed based on your average fuel consumption.

As a result, the actual distance that can be driven may differ from that displayed.

# Operation of each component

- 5
$\sim$

3-1.	Key information	
	Keys	
3-2.	Opening, closing and lock the doors and trunk	ing
	Doors	103
	Trunk	109
	Smart access system with	
	push-button start	
3-3.	Adjusting the seats	
	Front seats	120
	Rear seats	
	Driving position memory	123
	Head restraints	127
3-4.	Adjusting the steering wheel and mirrors	
	Steering wheel	130
	Inside rear view mirror	132
	Outside rear view mirrors.	134
3-5.	Opening, closing the wind and moon roof	ows
	Power windows	137
	Moon roof	140

#### 3-1. Key information


# Keys

#### The keys

The following keys are provided with the vehicle.

- 1 Electronic keys
  - Operating the smart access system with push-button start (→P. 114)
     Operating the wireless remote con-
  - Operating the wireless remote control function
- (2) Mechanical keys
- 3 Key number plate
- (4) Card key (electronic key) (if equipped)


Operating the smart access system with push-button start ( $\rightarrow$ P. 114)



#### Wireless remote control

- (1) Locks the doors ( $\rightarrow$ P. 103)
- (2) Unlocks the doors ( $\rightarrow$ P. 103)
- ③ Opens the windows and moon roof\* (→P. 103)
- (4) Opens the trunk ( $\rightarrow$ P. 109)
- (5) Sounds the alarm ( $\rightarrow$ P. 99)

\*: This setting must be customized at your Lexus dealer.




3-1. Key information

#### Using the mechanical key

To take out the mechanical key, push the release button and take the key out.

The mechanical key can only be inserted in one direction, as the key only has grooves on one side. If the key cannot be inserted in a lock cylinder, turn it over and re-attempt to insert it.

After using the mechanical key, store it in the electronic key. Carry the mechanical key together with the electronic key. If the electronic key battery is depleted or the entry function does not operate properly, you will need the mechanical key.  $(\rightarrow P. 488)$ 



# Operation of each component


CLY32AZ014

#### Panic mode


When (() is pressed for longer than about one second, an alarm will sound intermittently and the vehicle lights will flash to deter any person from trying to break into or damage your vehicle.

To stop the alarm, press any button on the electronic key.

- Card key (if equipped)
  - The card key is not waterproof.
  - The mechanical key that is stored inside the card key should be used only if a problem arises, such as when the card key does not operate properly.
  - If it is difficult to take out the mechanical key, push down the lock release button using a pen tip etc. If it is still difficult to pull it out, use a coin etc.
  - To store the mechanical key in the card key, insert it while pressing the lock release button.



 If the battery cover is not installed and the battery falls out or if the battery was removed because the key got wet, reinstall the battery with the positive terminal facing the Lexus emblem.



#### When required to leave the vehicle's key with a parking attendant

Set the luggage security system ( $\rightarrow$ P. 110) on and lock the glove box ( $\rightarrow$ P. 359) as circumstances demand.

Remove the mechanical key for your own use and provide the attendant with the electronic key only.

#### If you lose your mechanical keys

New genuine mechanical keys can be made by your Lexus dealer using another mechanical key and the key number stamped on your key number plate. Keep the plate in a safe place such as your wallet, not in the vehicle.

#### When riding in an aircraft

When bringing an electronic key onto an aircraft, make sure you do not press any buttons on the electronic key while inside the aircraft cabin. If you are carrying an electronic key in your bag etc., ensure that the buttons are not likely to be pressed accidentally. Pressing a button may cause the electronic key to emit radio waves that could interfere with the operation of the aircraft.

#### Electronic key battery depletion

- The standard battery life is 1 to 2 years. (The card key battery life is about a year and a half.)
- If the battery becomes low, an alarm will sound in the cabin when the engine is stopped.  $(\rightarrow P. 472)$
- As the electronic key always receives radio waves, the battery will become depleted even if the electronic key is not used. The following symptoms indicate that the electronic key battery may be depleted. Replace the battery when necessary. (→P. 427)
  - The smart access system with push-button start or the wireless remote control does not operate.
  - The detection area becomes smaller.
  - The LED indicator on the key surface does not turn on.
- To avoid serious deterioration, do not leave the electronic key within 3 ft. (1 m) of the following electrical appliances that produce a magnetic field:
  - TVs
  - Personal computers
  - Cellular phones, cordless phones and battery chargers
  - Recharging cellular phones or cordless phones
  - Table lamps
    Induction co
    - Induction cookers

#### Replacing the battery

→P. 427

#### Confirmation of the registered key number

The number of keys already registered to the vehicle can be confirmed. Ask your Lexus dealer for details.

#### If a wrong key is used

The key cylinder rotates freely to isolate inside mechanism.

#### NOTICE

#### To prevent key damage

- Do not drop the keys, subject them to strong shocks or bend them.
- Do not expose the keys to high temperatures for long periods of time.
- Do not get the keys wet or wash them in an ultrasonic washer etc.
- Do not attach metallic or magnetic materials to the keys or place the keys close to such materials.
- Do not disassemble the keys.
- Do not attach a sticker or anything else to the surface of the electronic key.
- Do not place the keys near objects that produce magnetic fields, such as TVs, audio systems and induction cookers, or medical electrical equipment, such as low-frequency therapy equipment.
- Carrying the electronic key on your person

Carry the electronic key 3.9 in. (10 cm) or more away from electric appliances that are turned on. Radio waves emitted from electric appliances within 3.9 in. (10 cm) of the electronic key may interfere with the key, causing the key to not function properly.

#### In case of a smart access system with push-button start malfunction or other keyrelated problems

Take your vehicle with all the electronic keys provided with your vehicle, including the card key, to your Lexus dealer.

#### When an electronic key is lost

If the electronic key remains lost, the risk of vehicle theft increases significantly. Visit your Lexus dealer immediately with all remaining electronic keys and the card key that were provided with your vehicle.

#### Handling the card key

- Do not apply excess force when inserting the mechanical key into the card key. Doing so may damage the card key.
- If the battery or card key terminals get wet, the battery may corrode.
   If the key is dropped into water, or if drinking water etc. is spilled on the key, immediately remove the battery cover and wipe the battery and terminals. (To remove the battery cover, lightly grasp and pull it.) If the battery is corroded, have your Lexus dealer replace the battery.
- Do not crush the battery cover or use a screwdriver to remove the battery cover. Forcibly removing the battery cover may bend or damage the key.
- If the battery cover is frequently removed, the battery cover may become loose.
- When installing the battery, make sure to check the direction of the battery. Installing the battery in the wrong direction may cause the battery to deplete rapidly.
- The surface of the card key may be damaged, or its coating may peel off in the following situations:
  - The card key is carried together with hard objects, such as coins and keys.
  - The card key is scraped with a sharp object, such as the tip of a mechanical pencil.
  - The surface of the card key is wiped with thinner or benzene.

# Doors

#### Unlocking and locking the doors from the outside

#### Smart access system with push-button start

Carry the electronic key to enable this function.

(1) Grip the driver's door handle to unlock the door. Grip the passenger's door handle to unlock all the doors.\*

> Make sure to touch the sensor on the back of the handle.

The doors cannot be unlocked for 3 seconds after the doors are locked.

- \*: The door unlock settings can be changed. ( $\rightarrow$ P. 107)
- 2 Touch the lock sensor (indentation on the upper part of the door handle) to lock all the doors.


#### Wireless remote control

- 1 Locks all the doors
- 2 Unlocks all the doors

Pressing the button unlocks the driver's door. Pressing the button again within 5 seconds unlocks the other doors.

Press and hold to open the windows and moon roof.'

\*: This setting must be customized at your Lexus dealer.



0

a

CLY32AZ007

#### Operation signals

A buzzer sounds and the emergency flashers flash to indicate that the doors have been locked/unlocked. (Locked: once; Unlocked: twice)

A buzzer sounds to indicate that the windows and moon roof are operating.

Security feature

If a door is not opened within approximately 60 seconds after the vehicle is unlocked, the security feature automatically locks the vehicle again.

#### Welcome light illumination control

The front position, tail and license plate lights automatically turn on at night when the doors are unlocked using the entry function or wireless remote control if the light switch is in the "AUTO" position.

When the door cannot be locked by the lock sensor on the upper part of the door handle

If the door will not lock even when the topside sensor area is touched, try touching both the topside and underside sensor areas at the same time.



#### Door lock buzzer

If an attempt to lock the doors is made when a door is not fully closed, a buzzer sounds continuously for 5 seconds. Fully close the door to stop the buzzer, and lock the vehicle once more.

Setting the alarm

Locking the doors will set the alarm system.  $(\rightarrow P. 71)$ 

If the smart access system with push-button start or the wireless remote control does not operate properly


Use the mechanical key to lock and unlock the doors. ( $\rightarrow$ P. 488) Replace the key battery with a new one if it is depleted. ( $\rightarrow$ P. 427)

# Unlocking and locking the doors from the inside Door lock switches 1 Locks all the doors 2 Unlocks all the doors

#### Inside lock buttons

- (1) Locks the door
- Unlocks the door

The front doors can be opened by pulling the inside handle even if the lock buttons are in the lock position.



#### Locking the doors from the outside without a key

- 1 Move the inside lock button to the lock position.
- **2** Close the door.

The door cannot be locked if the engine switch is in ACCESSORY or IGNITION ON mode, or the electronic key is left inside the vehicle. However, the key may not be detected correctly and the door may be locked.

Operation of each component


# 106 3-2. Opening, closing and locking the doors and trunk

# Rear door child-protector lock

The door cannot be opened from inside the vehicle when the lock is set.

- 1 Unlock
- 2 Lock

These locks can be set to prevent children from opening the rear doors. Push down on each rear door switch to lock both rear doors.



#### Automatic door locking and unlocking systems

The following functions can be set or canceled:

For instructions on customizing, refer to P. 525.

Function	Operation
Speed linked door locking function	All doors are automatically locked when vehicle speed is approximately 12 mph (20 km/h) or higher.
Shift position linked door locking function	All doors are automatically locked when shifting the shift lever to position other than P.
Shift position linked door unlocking func- tion	All doors are automatically unlocked when shifting the shift lever to P.
Driver's door linked door unlocking func- tion	All doors are automatically unlocked when driver's door is opened.

#### Switching the door unlock function

It is possible to set which doors the entry function unlocks using the wireless remote control.

- **1** Turn the engine switch off.
- 2 When the indicator light on the key surface is not on, press and hold 2 , 4 or

((  $\mathbf{r}$  for approximately 5 seconds while pressing and holding

The setting changes each time an operation is performed, as shown below. (When changing the setting continuously, release the buttons, wait for at least 5 seconds, and repeat step **2**.)

	Multi-information display	Unlocking function	Веер
	1	Holding the driver's door handle unlocks only the driver's door.	Exterior: Beeps 3 times
		Holding a passenger's door han- dle unlocks all the doors.	Interior: Pings once
		Holding a door handle unlocks all the doors.	Exterior: Beeps twice Interior: Pings once

To prevent unintended triggering of the alarm, unlock the doors using the wireless remote control and open and close a door once after the settings have been changed. (If a door is not opened within 60 seconds after again and the alarm will automatically be set.)

In a case that the alarm is triggered, immediately stop the alarm. ( $\rightarrow$ P. 71)

#### Impact detection door lock release system

In the event that the vehicle is subject to a strong impact, all the doors are unlocked. Depending on the force of the impact or the type of accident, however, the system may not operate.

Using the mechanical key

The doors can also be locked and unlocked with the mechanical key.  $(\rightarrow P. 488)$ 

- Conditions affecting the operation of the smart access system with push-button start or wireless remote control
  - →P. 116

#### Customization

Settings (e.g. unlocking function using a key) can be changed. (Customizable features: →P. 525)

## **108** 3-2. Opening, closing and locking the doors and trunk

# CAUTION To prevent an accident Observe the following precautions while driving the vehicle. Failure to do so may result in a door opening and an occupant being thrown out of the vehicle, resulting in death or serious injury. Ensure that all doors are properly closed and locked. Do not pull the inside handle of the doors while driving. Be especially careful with the front doors, as the doors may be opened even if the inside lock buttons are in locked position. Set the rear door child-protector locks when children are seated in the rear seats.

# Trunk

The trunk can be opened using the trunk opener, entry function or wireless remote control.

## Opening the trunk from inside the vehicle

Press the opener switch.



## Opening the trunk from outside the vehicle


## Smart access system with push-button start

While carrying the electronic key, press the button on the trunk lid.

When all the doors are unlocked with the power door lock system, the trunk can be opened without carrying the electronic key.

# Wireless remote control

Press and hold the switch.



8 a

CLY32AZ019

109

## 110 3-2. Opening, closing and locking the doors and trunk

## When closing the trunk


Using the trunk grip, lower the trunk without applying force to the side and push the trunk down from the outside to close it.



## Luggage security system


To protect luggage stored in the trunk against theft, the luggage security system can be set to on.

1 Folding type rear seats only: Move the luggage security system levers to the lock position.



- **2** To disable the trunk opener, turn the main switch in the glove box off
  - (1) On
  - 2 Off

When the main switch is off, the trunk lid cannot be opened even with the wireless remote control or entry function.



## Trunk light


The trunk light turns on when the trunk is opened.

- Function to prevent the trunk being locked with the electronic key inside
  - When all doors are locked, closing the trunk lid with the electronic key left inside the trunk will sound an alarm.
    - In this case, the trunk lid can be opened pressing the trunk release button on the trunk lid.
  - If the spare electronic key is put in the trunk with all the doors locked, the key confinement prevention function is activated so the trunk can be opened. In order to prevent theft, take all electronic keys with you when leaving the vehicle.
  - If the electronic key is put in the trunk with all the doors locked, the key may not be detected depending on the location of the key and the surrounding radio wave conditions. In this case, the key confinement prevention function cannot be activated, causing the doors to lock when the trunk is closed. Make sure to check where the key is before closing the trunk.
  - The key confinement prevention function cannot be activated if any one of the doors is unlocked. In this case, open the trunk using the trunk opener.

#### Internal trunk release lever

The trunk lid can be opened by pulling the glowin-the-dark lever located on the inside of the trunk lid to the side.

The lever will continue to glow for some time after the trunk lid is closed.



Using the mechanical key

The trunk can be also opened using the mechanical key.  $(\rightarrow P. 488)$ 

If the smart access system with push-button start or the wireless remote control does not operate properly

Use the mechanical key to unlock the trunk.  $(\rightarrow P. 488)$ 

- Replace the key battery with a new one if it is depleted.  $(\rightarrow P. 427)$
- When leaving a key to the vehicle with a parking attendant →P. 100
- Customization

The trunk unlocking operation can be changed. (Customizable features:  $\rightarrow$  P. 525)

Operation of each component

## **112** 3-2. Opening, closing and locking the doors and trunk

## **CAUTION** Observe the following precautions. Failure to do so may result in death or serious injury. Before driving • Make sure that the trunk lid is fully closed. If the trunk lid is not fully closed, it may open unexpectedly while driving and hit near-by objects or luggage in the trunk may be thrown out, causing an accident. • Do not allow children to play in the trunk. If a child is accidentally locked in the trunk, they could suffer from heat exhaustion, suffocation or other injuries. • Do not allow a child to open or close the trunk lid. Doing so may cause the trunk lid to open unexpectedly, or cause the child's hands, head, or neck to be caught by the closing trunk lid. Important points while driving Never let anyone sit in the trunk. In the event of sudden braking or a collision, they are susceptible to death or serious injury.

## **A** CAUTION

#### Using the trunk

Observe the following precautions.

- Failure to do so may cause parts of the body to be caught, resulting in serious injury.
- Remove any heavy loads, such as snow and ice, from the trunk lid before opening it. Failure to do so may cause the trunk lid to suddenly shut again after it is opened.
- When opening or closing the trunk lid, thoroughly check to make sure the surrounding area is safe.
- If anyone is in the vicinity, make sure they are safe and let them know that the trunk is about to open or close.
- Use caution when opening or closing the trunk lid in windy weather as it may move abruptly in strong wind.
- The trunk lid may suddenly shut if it is not opened fully. It is more difficult to open or close the trunk lid on an incline than on a level surface, so beware of the trunk lid unexpectedly opening or closing by itself. Make sure that the trunk lid is fully open and secure before using the trunk.



- When closing the trunk lid, take extra care to prevent your fingers etc. from being caught.
- When closing the trunk lid, make sure to press it lightly on its outer surface. If the trunk handle is used to fully close the trunk lid, it may result in hands or arms being caught.



 Do not attach any accessories other than genuine Lexus parts to the trunk lid. Such additional weight on the trunk lid may cause the lid to suddenly shut again after it is opened.

## 113

Operation of each component

## 114 3-2. Opening, closing and locking the doors and trunk


## Smart access system with push-button start

The following operations can be performed simply by carrying the electronic key (including the card key) on your person, for example in your pocket. The driver should always carry the electronic key.

- Locks and unlocks the doors ( $\rightarrow$ P. 103)
- Opens the trunk ( $\rightarrow$ P. 109)
- Starts the engine  $(\rightarrow P. 159)$

## Antenna location

- ① Antennas outside the cabin
- ② Antennas inside the cabin
- ③ Antenna inside the trunk
- 4 Antenna outside the trunk




#### Effective range (areas within which the electronic key is detected)

When locking or unlocking the doors

The system can be operated when the electronic key is within about 2.3 ft. (0.7 m) of an outside door handle. (Only the doors detecting the key can be operated.)

## 🌑 When opening the trunk

The system can be operated when the electronic key is within about  $2.3 \,$  ft. (0.7 m) of the trunk release button.



When starting the engine or changing engine switch modes

The system can be operated when the electronic key is inside the vehicle.

## Battery-saving function

The battery-saving function will be activated in order to prevent the electronic key battery and the vehicle battery from being discharged while the vehicle is not in operation for a long time.

- In the following situations, the smart access system with push-button start may take some time to unlock the doors.
  - The electronic key has been left within approximately 6 ft. (2 m) of the outside of the vehicle for 10 minutes or longer.
  - The smart access system with push-button start has not been used for 5 days or longer.
- If the smart access system with push-button start has not been used for 14 days or longer, the doors cannot be unlocked at any door except the driver's door. In this case, hold the driver's door handle, or use the wireless remote control or mechanical key, to unlock the doors.

#### Electronic Key Battery-Saving Function

When battery-saving mode is set, battery depletion is minimized by stopping the electronic key from receiving radio waves.

Press at twice while pressing and holding

. Confirm that the electronic key indicator flashes 4 times.

While the battery-saving mode is set, the smart access system with push-button start cannot be used. To cancel the function, press any of the electronic key buttons.



3

## **116** 3-2. Opening, closing and locking the doors and trunk

#### Conditions affecting operation

The smart access system with push-button start uses weak radio waves. In the following situations, the communication between the electronic key and the vehicle may be affected, preventing the smart access system with push-button start, wireless remote control and engine immobilizer system from operating properly. (Ways of coping:  $\rightarrow$ P. 488)

- When the electronic key battery is depleted
- Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
- When carrying a portable radio, cellular phone, cordless phone or other wireless communication device
- When the electronic key is in contact with, or is covered by the following metallic objects
  - Cards to which aluminum foil is attached
  - · Cigarette boxes that have aluminum foil inside
  - Metallic wallets or bags
  - Coins
  - Hand warmers made of metal
  - Media such as CDs and DVDs
- When other wireless keys (that emit radio waves) are being used nearby
- When carrying the electronic key together with the following devices that emit radio waves
  - Another vehicle's electronic key or a wireless key that emits radio waves
  - Personal computers or personal digital assistants (PDAs)
  - Digital audio players
  - Portable game systems
- If window tint with a metallic content or metallic objects are attached to the rear window

#### Note for the entry function

- Even when the electronic key is within the effective range (detection areas), the system may not operate properly in the following cases:
  - The electronic key is too close to the window or outside door handle, near the ground, or in a high place when the doors are locked or unlocked.
  - The electronic key is near the ground or in a high place, or too close to the rear bumper center when the trunk is opened.
  - The electronic key is on the instrument panel, rear package tray or floor, or in the door pockets or glove box when the engine is started or engine switch modes are changed.
- Do not leave the electronic key on top of the instrument panel or near the door pockets when exiting the vehicle. Depending on the radio wave reception conditions, it may be detected by the antenna outside the cabin and the doors will become lockable from the outside, possibly trapping the electronic key inside the vehicle.
- As long as the electronic key is within the effective range, the doors may be locked or unlocked by anyone. However, only the doors detecting the electronic key can be used to unlock the vehicle.
- Even if the electronic key is not inside the vehicle, it may be possible to start the engine if the electronic key is near the window.
- The doors may unlock or lock if a large amount of water splashes on the door handle, such as in the rain or in a car wash, when the electronic key is within the effective range. (The doors will automatically be locked after approximately 30 seconds if the doors are not opened and closed.)
- If the wireless remote control is used to lock the doors when the electronic key is near the vehicle, there is a possibility that the door may not be unlocked by the entry function. (Use the wireless remote control to unlock the doors.)
- Touching the door lock or unlock sensor while wearing gloves may prevent lock or unlock operation.
- When the lock operation is performed using the lock sensor, recognition signals will be shown up to two consecutive times. After this, no recognition signals will be given.
- If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In this case, follow the following correction procedures to wash the vehicle:
  - Place the electronic key in a location 6 ft. (2 m) or more away from the vehicle. (Take care to ensure that the key is not stolen.)
  - Set the electronic key to battery-saving mode to disable the smart access system with push-button start. (→P. 115)
- If the electronic key is inside the vehicle and a door handle becomes wet during a car wash, a message may be shown on the multi-information display and a buzzer will sound outside the vehicle. To turn off the alarm, lock all the doors.
- The lock sensor may not work properly if it comes into contact with ice, snow, mud, etc. Clean the lock sensor and attempt to operate it again, or use the lock sensor on the lower part of the door handle.
- A sudden handle operation or a handle operation immediately after entering the effective range may prevent the doors from being unlocked. Touch the door unlock sensor and check that the doors are unlocked before pulling the door handle again.
- Unlocking the vehicle may take more time if another electronic key is within the effective range.

- When the vehicle is not driven for extended periods
  - To prevent theft of the vehicle, do not leave the electronic key within 6 ft. (2 m) of the vehicle.
  - The smart access system with push-button start can be deactivated in advance.  $(\rightarrow P. 525)$

#### To operate the system properly

• Make sure to carry the electronic key when operating the system. Do not get the electronic key too close to the vehicle when operating the system from the outside of the vehicle.

Depending on the position and holding condition of the electronic key, the key may not be detected correctly and the system may not operate properly. (The alarm may go off accidentally, or the door lock prevention function may not operate.)

 Do not leave the electronic key inside the luggage compartment. The key confinement prevention function may not operate, depending on the location of the key (close to a spare tire, the inside edge of the luggage compartment), conditions (inside a metal bag, close to metallic objects) and the radio waves in the surrounding area. (->P. 111)

#### If the smart access system with push-button start does not operate properly

- $\bullet$  Locking and unlocking the doors and opening the trunk: Use the mechanical key. (  $\rightarrow$  P. 488)
- Starting the engine:  $\rightarrow$  P. 489
- Customization

Settings (e. g. smart access system with push-button start) can be changed. (Customizable features:  $\rightarrow$ P. 525)

- If the smart access system with push-button start has been deactivated in a customized setting
  - Locking and unlocking the doors and opening the trunk: Use the wireless remote control or mechanical key. (→P. 103, 109, 488)
  - Starting the engine and changing engine switch modes:  $\rightarrow P.489$
  - Stopping the engine:  $\rightarrow$  P. 159

► For vehicles sold in the U.S.A.

FCC ID: HYQ23AAB FCC ID: HYQ14FBA FCC ID: HYQ14CBB FCC ID: NI4TMLF12-1

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

▶ For vehicles sold in Canada

NOTE:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

## A CAUTION


#### Caution regarding interference with electronic devices

- People with implanted pacemakers or cardiac defibrillators should keep away from the smart access system with push-button start antennas. (
   —P. 114)
- The radio waves may affect the operation of such devices. If necessary, the entry function can be disabled. Ask your Lexus dealer for details, such as the frequency of radio waves and timing of emitting the radio waves. Then, consult your doctor to see if you should disable the entry function.
- Users of any electrical medical device other than implanted pacemakers and implanted cardiac defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves. Radio waves could have unexpected effects on the operation of such medical
- devices.

Ask your Lexus dealer for details on disabling the entry function.

Operation of each component

## **120** 3-3. Adjusting the seats



## **CAUTION**

#### When adjusting the seat position

- Take care when adjusting the seat position to ensure that other passengers are not injured by the moving seat.
- Do not put your hands under the seat or near the moving parts to avoid injury. Fingers or hands may become jammed in the seat mechanism.
- Make sure to leave enough space around the feet so they do not get stuck.

## Seat adjustment

To reduce the risk of sliding under the lap belt during a collision, do not recline the seat more than necessary.

If the seat is too reclined, the lap belt may slide past the hips and apply restraint forces directly to the abdomen, or your neck may contact the shoulder belt, increasing the risk of death or serious injury in the event of an accident.


Adjustments should not be made while driving as the seat may unexpectedly move and cause the driver to lose control of the vehicle.

# Rear seats (folding type)<sup>\*</sup>

The rear seatbacks can be folded down.


## Folding down the rear seatbacks

1 Check that the luggage security system lever in the trunk is in the unlock position.



**2** Pull the seatback lock release lever and fold the seatback down.

To return the rear seatbacks to their original position, lift them up until they lock.




Luggage security system

→P. 110

Operation of each component

## **122** 3-3. Adjusting the seats



## Driving position memory

Your preferred driving position (the position of the driver's seat, steering wheel and outside rear view mirrors) can be memorized and recalled by pressing a button. It is also possible to set this function to activate automatically when the doors are unlocked.

Three different driving positions can be entered into memory.


## Entering a position to memory

- 1 Check that the shift lever is in P.
- **2** Turn the engine switch to IGNITION ON mode.
- 3 Adjust the driver's seat, steering wheel, and outside rear view mirrors to the desired positions.
- While pressing the "SET" button, or within 3 seconds after the "SET" button is pressed, press button "1", "2" or "3" until a buzzer sounds.

If the selected button has already been preset, the previously recorded position will be overwritten.

## Recalling the memorized position

- 1 Check that the shift lever is in P.
- **2** Turn the engine switch to IGNITION ON mode.
- **3** Press button "1", "2" or "3" to recall the desired position.



\*: If equipped

IS350/250\_U (OM53758U)

123


- When you want to stop the position recall operation part-way through Perform any of the following operations:
  - Press the "SET" button.
  - Press button "1", "2" or "3".

  - $\bullet$  Adjust the seat using the switches (only cancels seat position recall).
- The adjusted positions that can be memorized

The adjusted positions other than the position adjusted by lumbar support switch can be memorized.

## Power easy access system

The auto away/return function enables easy access by activating when the driver attempts to enter or exit the vehicle.



## Auto away function when exiting the vehicle

When all of the following actions have been performed, the steering wheel will move up and back to the point farthest away from the driver and the seat will move backward:

- The shift lever has been shifted to P.
- The engine switch has been turned off.
- The driver seat belt has been unfastened.

## Auto return function when entering the vehicle

When either of the following actions has been performed, the steering wheel will move toward the driver and seat will move forward:

- The engine switch has been turned to ACCESSORY mode.
- The driver's seat belt has been fastened.

## Linking driving position memory with door unlock operation

A desired driving position can be recalled linked with the unlocking of the door.

Setting procedure

Record your driving position to button "1", "2" or "3" before performing the following:

Carrying only the key (including the card key) to which you want to link the driving position, shift the shift lever to P and then close the driver's door.

If 2 or more keys are in the vehicle, the driving position cannot be linked properly.

- 1 Turn the engine switch to IGNITION ON mode and recall the position which you want to link.
- 2 While pressing the button to recall the position, press the driver's door lock switch (either lock or unlock) until the buzzer sounds.


The driving position is recalled when the driver's door is unlocked using the entry function or wireless remote control and the driver's door is opened.

## Cancelation procedure

Carry only the key for which you want to cancel the linked door unlock operation.

If 2 or more keys are in the vehicle, the driving position cannot be canceled properly.

- **1** Turn the engine switch to IGNITION ON mode.
- 2 While pressing the "SET" button, press the driver's door lock switch (either lock or unlock) until the buzzer sounds.



When driving position memory is linked with door unlock operation

If the driver's door is opened, the driver's seat will move toward the memorized position but stop slightly beforehand to allow easy access to the vehicle.

Turning the engine switch to ACCESSÓRY or IGNITION ON mode, or fastening the driver's seat belt moves the seat fully into the memorized position.

#### Operating the driving position memory after turning the engine switch off

Memorized seat positions can be activated up to 180 seconds after the driver's door is opened and another 60 seconds after it is closed again. Memorized steering wheel position can be activated by pressing the engine switch.

## Correct seat position

When the seat is in the most forward or most backward position, and the seat is being moved in those directions, the system may not correctly recognize the current position and the memorized position will not be correctly recalled.

#### The auto away function for exiting

If the seat is already close to the rearmost position, the auto away function may not operate when the driver exits the vehicle.

## When the driving position is recalled by a memory linked door unlock operation

- Since each memorized driving position is registered to a specific electronic key, the driving position recalled may be different depending on the carried key.
- When only doors other than the driver's door are unlocked by the smart access system
  with push-button start, the driving position will not be recalled. In this case, press a driving position memory button to recall the desired driving position.

#### Customization

The distance that the driver's seat moves backward during the auto away function can be changed. (Customizable features:  $\rightarrow$ P. 525)

## A CAUTION

#### Seat adjustment caution

Take care during seat adjustment so that the seat does not strike the rear passenger or squeeze your body against the steering wheel.

# Head restraints

Head restraints are provided for all seats.

## Front seats


Vertical adjustment

(1) Up

Pull the head restraints up.

2 Down


Push the head restraint down while pressing the lock release button.



Horizontal adjustment (if equipped)

The position of the head restraint can be adjusted forward in 4 stages.

If the head restraint is pulled forward from the foremost position, it will return to the rearmost position.



Operation of each component

127

## **128** 3-3. Adjusting the seats


## Rear seats

(1) Up

Pull the head restraints up.

Down


Push the head restraint down while pressing the lock release button.



## Removing the head restraints

Pull the head restraint up while pressing the lock release button.


If the head restraint touches the ceiling, making the removal difficult, change the seat height or angle.



## Installing the head restraints


▶ Front seats

Align the head restraint with the installation holes and push it down to the lock position. Press and hold the lock release button when lowering the head restraint.



## ▶ Rear seats


Align the head restraint with the installation holes and push it down to the lowest lock position while pressing the lock release button.



## 3-3. Adjusting the seats

## Adjusting the height of the head restraints

Make sure that the head restraints are adjusted so that the center of the head restraint is closest to the top of your ears.



## Adjusting the rear seat head restraint

Always raise the head restraint one level from the stowed position when using.

## **CAUTION**

## Head restraint precautions

Observe the following precautions regarding the head restraints. Failure to do so may result in death or serious injury.

- Use the head restraints designed for each respective seat.
- Adjust the head restraints to the correct position at all times.
- After adjusting the head restraints, push down on them and make sure they are locked in position.
- Do not drive with the head restraints removed.

129

## **130** 3-4. Adjusting the steering wheel and mirrors


# **Steering wheel**

## Adjustment procedure


Power type

Operating the switch moves the steering wheel in the following directions:

- (1) Up
- Down
- 3 Toward the driver
- 4 Away from the driver




- Manual type
- 1 Hold the steering wheel and push the lever down.



2 Adjust to the ideal position by moving the steering wheel horizontally and vertically.

After adjustment, pull the lever up to secure the steering wheel.



## Horn

To sound the horn, press on or close to the mark.



#### The steering wheel can be adjusted when (power type)

The engine switch is in ACCESSORY or IGNITION ON mode<sup>\*</sup>.

\*: If the driver's seat belt is fastened, the steering wheel can be adjusted regardless of engine switch mode.

## Automatic adjustment of the steering position (if equipped)

A desired steering position can be entered to memory and recalled automatically by the driving position memory system. ( $\rightarrow$ P. 123)

### Power easy access system (if equipped)

The steering wheel and driver's seat move in accordance with engine switch mode and the driver's seat belt condition. ( $\rightarrow$ P. 124)

## **CAUTION**

## Caution while driving

Do not adjust the steering wheel while driving.

Doing so may cause the driver to mishandle the vehicle and cause an accident, resulting in death or serious injury.

#### After adjusting the steering wheel (manual type)

Make sure that the steering wheel is securely locked.

Otherwise, the steering wheel may move suddenly, possibly causing an accident, and resulting in death or serious injury. Also, the horn may not sound if the steering wheel is not securely locked.

3

## **132** 3-4. Adjusting the steering wheel and mirrors

## Inside rear view mirror

The rear view mirror's position can be adjusted to enable sufficient confirmation of the rear view.

## Adjusting the height of rear view mirror

The height of the rear view mirror can be adjusted to suit your driving posture.

Adjust the height of the rear view mirror by moving it up and down.




## Anti-glare function

Responding to the level of brightness of the headlights of vehicles behind, the reflected light is automatically reduced.

Changing automatic anti-glare function mode

Type A

▶ Type B



## 1 ON

ON/OFF


2 OFF

When the automatic anti-glare function is in ON mode, the indicator illuminates. The function will set to ON mode each time the engine switch is turned to IGNITION ON mode.

Pressing the button turns the function to OFF mode. (The indicator also turns off.)

## ■ To prevent sensor error

To ensure that the sensors operate properly, do not touch or cover them.



## **CAUTION**

Do not adjust the position of the mirror while driving. Doing so may lead to mishandling of the vehicle and cause an accident, resulting in death or serious injury.

## **134** 3-4. Adjusting the steering wheel and mirrors

## Outside rear view mirrors

## Adjustment procedure

**1** To select a mirror to adjust, press the switch.


- 1 Left
- 2 Right


Pressing the same switch again will put the switch in neutral.

- **2** To adjust the mirror, press the switch.
  - (1) Up
  - 2 Right
  - 3 Down
  - (4) Left

## Folding the mirrors

Push the mirror back in the direction of the vehicle's rear.







#### Mirror angle can be adjusted when

The engine switch is in ACCESSORY or IGNITION ON mode.

#### Linked mirror function when reversing (if equipped)

- When either "L" or "R" of the mirror select switch is selected, the outside rear view mirrors will automatically angle downwards when the vehicle is reversing in order to give a better view of the ground. To disable this function, select neither "L" nor "R".
- If the mirror angle adjustment switch is operated while the linked mirror function is in operation, the angle and position of the mirrors can be remembered, and the mirrors will operate at the angle adjusted to the last time the linked mirror function was operated.

However, because the mirrors move based on the angle they are in when the linked mirror function is not operating, the mirror angle when the linked mirror function is operating will also be changed if the mirrors are adjusted while the function is not operating.

## When the mirrors are fogged up

The outside rear view mirrors can be cleared using the mirror defoggers. Turn on the rear window defogger to turn on the outside rear view mirror defoggers. ( $\rightarrow$ P. 350)

#### Automatic adjustment of the mirror angle (if equipped)

A desired mirror face angle can be entered to memory and recalled automatically by the driving position memory. ( $\rightarrow$ P. 123)

## Auto anti-glare function (if equipped)

When the anti-glare inside rear view mirror is set to automatic mode, the outside rear view mirrors will activate in conjunction with the anti-glare inside rear view mirror to reduce reflected light. ( $\rightarrow$ P. 132)

## **136** 3-4. Adjusting the steering wheel and mirrors

CAUTION
Important points while driving
Observe the following precautions while driving. Failure to do so may result in loss of control of the vehicle and cause an accident, result- ing in death or serious injury.
<ul> <li>Do not adjust the mirrors while driving.</li> </ul>
<ul> <li>Do not drive with the mirrors folded.</li> </ul>
• Both the driver and passenger side mirrors must be extended and properly adjusted before driving.
When the mirror defoggers are operating
Do not touch the rear view mirror surfaces, as they can become very hot and burn you.


## **Power windows**

## Opening and closing procedures

The power windows can be opened and closed using the switches.

Operating the switch moves the windows as follows:

- 1 Closing
- (2) One-touch closing<sup>\*</sup>
- 3 Opening
- 4 One-touch opening\*
  - \*: To stop the window partway, operate the switch in the opposite direction.




## Window lock switch

Press the switch to lock the passenger window switches.

The indicator will come on.

Use this switch to prevent children from accidentally opening or closing a passenger window.



Operation of each component

## The power windows can be operated when

The engine switch is in IGNITION ON mode.

## Operating the power windows after turning the engine off

The power windows can be operated for approximately 45 seconds after the engine switch is turned to ACCESSORY mode or turned off. They cannot, however, be operated once either front door is opened.

#### Jam protection function

If an object becomes caught between the window and the window frame, window travel is stopped and the window is opened slightly.

#### When the power window does not close normally

If the jam protection function is operating abnormally and a window cannot be closed, perform the following operations using the power window switch on the relevant door.

- After stopping the vehicle, the window can be closed by holding the power window switch in the one-touch closing position while the engine switch is turned to IGNITION ON mode.
- If the window still cannot be closed even by carrying out the operation as explained above, initialize the function by performing the following procedure.
- Hold the power window switch in the one-touch closing position. Continue holding the switch for a further 6 seconds after the window has closed.
- 2 Hold the power window switch in the one-touch opening position. Continue holding the switch for a further 2 seconds after the window has opened completely.
- Hold the power window switch in the one-touch closing position once again. Continue holding the switch for a further 2 seconds after the window has closed.

If you release the switch while the window is moving, start again from the beginning. If the window continues to close but then re-open slightly even after performing the above procedure correctly, have the vehicle inspected by your Lexus dealer.

## Door lock linked window operation

- The power windows can be opened and closed using the mechanical key. ( $\rightarrow$ P. 488)
- The power windows can be opened using the wireless remote control.<sup>\*</sup> (→P. 103)
   \*: These settings must be customized at your Lexus dealer.

#### When the battery is disconnected

The window lock switch is disabled. If necessary, press the window lock switch after reconnecting the battery.

#### Power windows open warning buzzer

The buzzer sounds and a message is shown on the multi-information display in the instrument cluster when the engine switch is turned off and the driver's door is opened with the power windows open.

#### Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable features: →P. 525)

## A CAUTION

Observe the following precautions. Failure to do so may result in death or serious injury.

#### Closing the windows

- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when a window is being operated.
- Do not allow children to operate the power windows. Closing a power window on someone can cause serious injury, and in some instances, even death.

#### Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the window fully closes.

## 3

Operation of each component

## 140 3-5. Opening, closing the windows and moon roof

## Moon roof\*

Use the overhead switches to open and close the moon roof and tilt it up and down.

## Opening and closing

1 Opens the moon roof\*

The moon roof stops slightly before the fully open position to reduce wind noise. Press the switch again to fully open the moon roof.

Closes the moon roof\*

\*: Lightly press either way of the moon roof switch to stop the moon roof partway.

## Tilting up and down

- 1 Tilts the moon roof up\*
- 2 Tilts the moon roof down\*
  - \*: Lightly press either way of the moon roof switch to stop the moon roof partway.





\*: If equipped

## The moon roof can be operated when

The engine switch is in IGNITION ON mode.

## Operating the moon roof after turning the engine off

The moon roof can be operated for approximately 45 seconds after the engine switch is turned to ACCESSORY mode or turned off. It cannot, however, be operated once either front door is opened.

#### Jam protection function

If an object is detected between the moon roof and the frame while the moon roof is closing or tilting down, travel is stopped and the moon roof opens slightly.

#### Sunshade

The sunshade can be opened and closed manually. However, the sunshade will open automatically when the moon roof is opened.

- Door lock linked moon roof operation
  - The moon roof can be opened and closed using the mechanical key.\* ( $\rightarrow$ P. 488)
  - The moon roof can be opened using the wireless remote control.<sup>\*</sup> ( $\rightarrow$ P. 103)
    - \*: These settings must be customized at your Lexus dealer.

- When the moon roof does not close normally Perform the following procedure:
  - If the moon roof closes but then re-opens slightly
  - **1** Stop the vehicle.
  - Press and hold the "CLOSE" switch.\*1
    - The moon roof will close, reopen and pause for approximately 10 seconds. \*<sup>2</sup> Then it will close again, tilt up and pause for approximately 1 second. Finally, it will tilt down, open and close.
  - 3 Check to make sure that the moon roof is completely closed and then release the switch.
  - If the moon roof tilts down but then tilts back up
  - **1** Stop the vehicle.
  - 2 Press and hold the "UP" switch<sup>\*1</sup> until the moon roof moves into the tilt up position and stops.
  - Release the "UP" switch once and then press and hold the "UP" switch again.\*1 The moon roof will pause for approximately 10 seconds in the tilt up position.\*2 Then it will adjust slightly and pause for approximately 1 second. Finally, it will tilt down, open and close.
  - [4] Check to make sure that the moon roof is completely closed and then release the switch.
  - $^{*1}$ : If the switch is released at the incorrect time, the procedure will have to be performed again from the beginning.
  - \*<sup>2</sup>: If the switch is released after the above mentioned 10 second pause, automatic operation will be disabled. In that case, press and hold the "CLOSE" or "UP" switch, and the moon roof will tilt up and pause for approximately 1 second. Then it will tilt down, open and close. Check to make sure that the moon roof is completely closed and then release the switch.

If the moon roof does not fully close even after performing the above procedure correctly, have the vehicle inspected by your Lexus dealer.

## Moon roof open warning buzzer

The buzzer sounds and a message is shown on the multi-information display in the instrument cluster when the engine switch is turned off and the driver's door is opened with the moon roof open.

Customization

Settings (e.g. linked door lock operation) can be changed. (Customizable features: →P. 525)

## 

Observe the following precautions.

Failure to do so may cause death or serious injury.

#### Opening the moon roof

- Do not allow any passengers to put their hands or heads outside the vehicle while it is moving.
- Do not sit on top of the moon roof.

## Closing the moon roof

- Check to make sure that all passengers do not have any part of their body in a position where it could be caught when the moon roof is being operated.
- Do not allow children to operate the moon roof.
- Closing the moon roof on someone can cause death or serious injury.

## Jam protection function

- Never use any part of your body to intentionally activate the jam protection function.
- The jam protection function may not work if something gets caught just before the moon roof fully closes.

IS350/250\_U (OM53758U)

## Driving

4

4-1.	Before driving
	Driving the vehicle146
	Cargo and luggage153
	Vehicle load limits156
	Trailer towing157
	Dinghy towing158
4-2.	Driving procedures
	Engine (ignition) switch
	Automatic transmission164
	Turn signal lever170
	Parking brake172
4-3.	Operating the lights and wipers
	Headlight switch173
	Automatic High Beam176
	Fog light switch181
	Windshield wipers and washer182
4-4.	Refueling
	Opening the fuel tank cap188

4-5.	Using the driving support systems
	Cruise control 192
	Dynamic radar cruise control
	(Lane Departure Alert)208
	Intuitive parking assist
	Rear view monitor system221
	Driving mode select switch
	Driving assist systems234 PCS
	(Pre-Collision System)
	BSM (Blind Spot Monitor) 246
	• The Blind Spot Monitor function249
	The Rear Cross Traffic     Alert function
4-6.	Driving tips
	Winter driving tips254

## 145

## Driving the vehicle

The following procedures should be observed to ensure safe driving:

#### Starting the engine

 $\rightarrow$ P.159

#### Driving

- 1 With the brake pedal depressed, shift the shift lever to D. ( $\rightarrow$ P. 164)
- **2** Release the parking brake.  $(\rightarrow P. 172)$
- **3** Gradually release the brake pedal and gently depress the accelerator pedal to accelerate the vehicle.

### Stopping

- 1 With the shift lever in D, depress the brake pedal.
- 2 If necessary, set the parking brake.

If the vehicle is to be stopped for an extended period of time, shift the shift lever to P or N. ( $\rightarrow$ P. 164)

#### Parking the vehicle

- 1 With the shift lever in D, depress the brake pedal.
- **2** Set the parking brake.  $(\rightarrow P. 172)$
- **3** Shift the shift lever to P.  $(\rightarrow P. 164)$

\_\_\_\_ If parking on a hill, block the wheels as needed.

- **4** Press the engine switch to stop the engine.
- **5** Lock the door, making sure that you have the electronic key on your person.

#### Starting off on a steep uphill

- 1 Make sure that the parking brake is set and shift the shift lever to D.
- 2 Gently depress the accelerator pedal.
- **3** Release the parking brake.

#### When starting off on an uphill

The hill-start assist control will activate. ( $\rightarrow$ P. 234)

#### Driving in the rain

- Drive carefully when it is raining, because visibility will be reduced, the windows may become fogged-up, and the road will be slippery.
- Drive carefully when it starts to rain, because the road surface will be especially slippery.
- Refrain from high speeds when driving on an expressway in the rain, because there may be a layer of water between the tires and the road surface, preventing the steering and brakes from operating properly.

#### Engine speed while driving

In the following conditions, the engine speed may become high while driving. This is due to automatic up-shifting control or down-shifting implementation to meet driving conditions. It does not indicate sudden acceleration.

- The vehicle is judged to be driving uphill or downhill
- When the accelerator pedal is released
- When the brake pedal is depressed while sport mode is selected

#### Breaking in your new Lexus

To extend the life of the vehicle, observing the following precautions is recommended:

- For the first 186 miles (300 km):
- Avoid sudden stops.
- For the first 621 miles (1000 km):
  - Do not drive at extremely high speeds.
  - Avoid sudden acceleration.
  - Do not drive continuously in low gears.
  - Do not drive at a constant speed for extended periods.

#### Drum-in-disc type parking brake system

Your vehicle has a drum-in-disc type parking brake system. This type of brake system needs bedding-down of the brake shoes periodically or whenever the parking brake shoes and/or drum are replaced. Have your Lexus dealer perform the bedding down operation.

#### Operating your vehicle in a foreign country

Comply with the relevant vehicle registration laws and confirm the availability of the correct fuel. ( $\rightarrow$ P. 510)

147

#### 

Observe the following precautions.

Failure to do so may result in death or serious injury.

#### When starting the vehicle

Always keep your foot on the brake pedal while stopped with the engine running. This prevents the vehicle from creeping.

#### When driving the vehicle

 Do not drive if you are unfamiliar with the location of the brake and accelerator pedals to avoid depressing the wrong pedal.

- Accidentally depressing the accelerator pedal instead of the brake pedal will
  result in sudden acceleration that may lead to an accident.
- When backing up, you may twist your body around, leading to a difficulty in operating the pedals. Make sure to operate the pedals properly.
- Make sure to keep a correct driving posture even when moving the vehicle only slightly. This allows you to depress the brake and accelerator pedals properly.
- Depress the brake pedal using your right foot. Depressing the brake pedal using your left foot may delay response in an emergency, resulting in an accident.
- Do not drive the vehicle over or stop the vehicle near flammable materials.

The exhaust system and exhaust gases can be extremely hot. These hot parts may cause a fire if there is any flammable material nearby.

• During normal driving, do not turn off the engine. Turning the engine off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.

However, in the event of an emergency, such as if it becomes impossible to stop the vehicle in the normal way:  $\to\!P\!.\,447$ 


• Use engine braking (downshift) to maintain a safe speed when driving down a steep hill.

Using the brakes continuously may cause the brakes to overheat and lose effectiveness. ( $\rightarrow$ P. 164)

• Do not adjust the positions of the steering wheel, the seat, or the inside or outside rear view mirrors while driving.

Doing so may result in a loss of vehicle control.

- Always check that all passengers' arms, heads or other parts of their body are not outside the vehicle.
- Do not drive in excess of the speed limit. Even if the legal speed limit permits it, do not drive over 85 mph (140 km/h) unless your vehicle has high-speed capability tires. Driving over 85 mph (140 km/h) may result in tire failure, loss of control and possible injury. Be sure to consult a tire dealer to determine whether the tires on your vehicle are high-speed capability tires or not before driving at such speeds.



149

#### 

Observe the following precautions.

Failure to do so may result in death or serious injury.

- When the vehicle is stopped
  - Do not race the engine.
     If the shift lever is any position other than P or N, the vehicle may accelerate suddenly and unexpectedly, causing an accident.
  - In order to prevent accidents due to the vehicle rolling away, always keep depressing the brake pedal while the engine is running, and apply the parking brake as necessary.
  - If the vehicle is stopped on an incline, in order to prevent accidents caused by the vehicle rolling forward or backward, always depress the brake pedal and securely apply the parking brake as needed.
  - Avoid revving or racing the engine. Running the engine at high speed while the vehicle is stopped may cause the exhaust system to overheat, which could result in a fire if combustible material is nearby.
- When the vehicle is parked
  - Do not leave glasses, cigarette lighters, spray cans, or soft drink cans in the vehicle when it is in the sun.
    - Doing so may result in the following:
    - Gas may leak from a cigarette lighter or spray can, and may lead to a fire.
    - The temperature inside the vehicle may cause the plastic lenses and plastic material of glasses to deform or crack.
    - Soft drink cans may fracture, causing the contents to spray over the interior of the vehicle, and may also cause a short circuit in the vehicle's electrical components.
  - Do not leave cigarette lighters in the vehicle. If a cigarette lighter is in a place such as the glove box or on the floor, it may be lit accidentally when luggage is loaded or the seat is adjusted, causing a fire.
  - Do not attach adhesive discs to the windshield or windows. Do not place containers such as air fresheners on the instrument panel or dashboard. Adhesive discs or containers may act as lenses, causing a fire in the vehicle.
  - Do not leave a door or window open if the curved glass is coated with a metallized film such as a silver-colored one. Reflected sunlight may cause the glass to act as a lens, causing a fire.
  - Always apply the parking brake, shift the shift lever to P, stop the engine and lock the vehicle.

Do not leave the vehicle unattended while the engine is running.

- Do not touch the exhaust pipes while the engine is running or immediately after turning the engine off.
  - Doing so may cause burns.

#### **CAUTION** Observe the following precautions. Failure to do so may result in death or serious injury. When taking a nap in the vehicle Always turn the engine off. Otherwise, if you accidentally move the shift lever or depress the accelerator pedal, this could cause an accident or fire due to engine overheating. Additionally, if the vehicle is parked in a poorly ventilated area, exhaust gases may collect and enter the vehicle, leading to death or a serious health hazard. When braking • When the brakes are wet, drive more cautiously. Braking distance increases when the brakes are wet, and this may cause one side of the vehicle to brake differently than the other side. Also, the parking brake may not securely hold the vehicle. • If the power brake assist function does not operate, do not follow other vehicles closely and avoid hills or sharp turns that require braking. In this case, braking is still possible, but the brake pedal should be depressed more firmly than usual. Also, the braking distance will increase. Have your brakes fixed immediately. Do not pump the brake pedal if the engine stalls. Each push on the brake pedal uses up the reserve for the power-assisted brakes. • The brake system consists of 2 individual hydraulic systems; if one of the systems fails, the other will still operate. In this case, the brake pedal should be depressed more firmly than usual and the braking distance will increase. Have your brakes fixed immediately. If the vehicle becomes stuck

Do not spin the wheels excessively when any of the tires is up in the air, or the vehicle is stuck in sand, mud, etc. This may damage the driveline components or propel the vehicle forward or backward, causing an accident.

151

Driving

#### **NOTICE**

#### When driving the vehicle

- Do not depress the accelerator and brake pedals at the same time during driving, as this may restrain driving torque.
- Do not use the accelerator pedal or depress the accelerator and brake pedals at the same time to hold the vehicle on a hill.

#### When parking the vehicle

Always shift the shift lever to P. Failure to do so may cause the vehicle to move or the vehicle may accelerate suddenly if the accelerator pedal is accidentally depressed.

#### Avoiding damage to vehicle parts

- Do not turn the steering wheel fully in either direction and hold it there for an extended period of time.
- Doing so may damage the power steering motor.
- When driving over bumps in the road, drive as slowly as possible to avoid damaging the wheels, underside of the vehicle, etc.

#### If you get a flat tire while driving

A flat or damaged tire may cause the following situations. Hold the steering wheel firmly and gradually depress the brake pedal to slow down the vehicle.

- It may be difficult to control your vehicle.
- The vehicle will make abnormal sounds or vibrations.
- The vehicle will lean abnormally.
- Information on what to do in case of a flat tire ( $\rightarrow$ P. 475)

#### When encountering flooded roads

Do not drive on a road that has flooded after heavy rain etc. Doing so may cause the following serious damage to the vehicle:

- Engine stalling
- Short in electrical components
- Engine damage caused by water immersion

In the event that you drive on a flooded road and the vehicle is flooded, be sure to have your Lexus dealer check the following:

- Brake function
- Changes in quantity and quality of oil and fluid used for the engine, transmission, transfer (AWD models), differential, etc.
- Lubricant condition for the propeller shaft, bearings and suspension joints (where possible), and the function of all joints, bearings, etc.

Driving

## Cargo and luggage

Take notice of the following information about storage precautions, cargo capacity and load:

#### Capacity and distribution

Cargo capacity depends on the total weight of the occupants.

(Cargo capacity) = (Total load capacity) – (Total weight of occupants)

#### Steps for Determining Correct Load Limit –

- (1) Locate the statement "The combined weight of occupants and cargo should never exceed XXX kg or XXX lbs." on your vehicle's placard.
- (2) Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- (3) Subtract the combined weight of the driver and passengers from XXX kg or XXX lbs.
- (4) The resulting figure equals the available amount of cargo and luggage load capacity.


For example, if the "XXX" amount equals 1400 lbs. and there will be five 150 lb passengers in your vehicle, the amount of available cargo and luggage load capacity is 650 lbs.  $(1400 - 750 (5 \times 150) = 650 \text{ lbs.})$ 

- (5) Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.
- (6) If your vehicle will be towing a trailer, load from your trailer will be transferred to your vehicle. Consult this manual to determine how this reduces the available cargo and luggage load capacity of your vehicle. (→P. 156)

Lexus does not recommend towing a trailer with your vehicle. Your vehicle is not designed for trailer towing.

#### Calculation formula for your vehicle

- 1 Cargo capacity
- (2) Total load capacity (vehicle capacity weight) ( $\rightarrow$  P. 500)



When 2 people with the combined weight of A lb. (kg) are riding in your vehicle, which has a total load capacity (vehicle capacity weight) of B lb. (kg), the available amount of cargo and luggage load capacity will be C lb. (kg) as follows:

 $B^{*2}$  lb. (kg) -  $A^{*1}$  lb. (kg) =  $C^{*3}$  lb. (kg)

- \*1: A =Weight of people
- \*<sup>2</sup>: B =Total load capacity


\*<sup>3</sup>: C = Available cargo and luggage load

In this condition, if 3 more passengers with the combined weight of D lb. (kg) get on, the available cargo and luggage load will be reduced E lb. (kg) as follows: C lb. (kg) - D<sup>\*4</sup> lb. (kg) = E<sup>\*5</sup> lb. (kg)

\*<sup>4</sup>: D =Additional weight of people

\*<sup>5</sup>: E =Available cargo and luggage load

As shown in the example above, if the number of occupants increases, the cargo and luggage load will be reduced by an amount that equals the increased weight due to the additional occupants. In other words, if an increase in the number of occupants causes an excess of the total load capacity (combined weight of occupants plus cargo and luggage load), you must reduce the cargo and luggage on your vehicle.



155

## Vehicle load limits

Vehicle load limits include total load capacity, seating capacity, towing capacity and cargo capacity.

• Total load capacity (vehicle capacity weight):  $(\rightarrow P. 500)$ 

Total load capacity means the combined weight of occupants, cargo and luggage.

Seating capacity: 5 occupants (Front 2, Rear 3)

Seating capacity means the maximum number of occupants whose estimated average weight is 150 lb. (68 kg) per person.

Towing capacity

Lexus does not recommend towing a trailer with your vehicle.

Cargo capacity

Cargo capacity may increase or decrease depending on the weight and the number of occupants.

#### Total load capacity and seating capacity

These details are also described on the tire and loading information label. ( $\rightarrow$ P. 420)

#### A CAUTION

#### Overloading the vehicle

Do not overload the vehicle.

It may not only cause damage to the tires, but also degrade steering and braking ability, resulting in an accident.

## **Trailer towing**


Lexus does not recommend towing a trailer with your vehicle. Lexus also does not recommend the installation of a tow hitch or the use of a tow hitch carrier for a wheelchair, scooter, bicycle, etc. Your vehicle is not designed for trailer towing or for the use of tow hitch mounted carriers.



4 Driving

## **Dinghy towing**

Your vehicle is not designed to be dinghy towed (with 4 wheels on the ground) behind a motor home.



## **NOTICE**

#### To avoid serious damage to your vehicle

Do not tow your vehicle with the four wheels on the ground.

## Engine (ignition) switch

Performing the following operations when carrying the electronic key on your person starts the engine or changes engine switch modes.


#### Starting the engine

- 1 Check that the parking brake is set.
- 2 Check that the shift lever is in P.
- **3** Firmly depress the brake pedal.

and a message will be displayed on the multi-information display. If it is not displayed, the engine cannot be started.

4 Press the engine switch.

The engine will crank until it starts or for up to 30 seconds, whichever is less. Continue depressing the brake pedal until the engine is completely started. The engine can be started from any engine switch mode.



Stopping the engine

- **1** Stop the vehicle.
- 2 Shift the shift lever to P.
- **3** Set the parking brake.  $(\rightarrow P. 172)$
- **4** Press the engine switch.
- **5** Release the brake pedal and check that the display on the meters is off.

#### **160** 4-2. Driving procedures

#### Changing engine switch modes

Modes can be changed by pressing the engine switch with brake pedal released. (The mode changes each time the switch is pressed.)

1 Off\*

The emergency flashers can be used. The multi-information display will not be displayed.


2 ACCESSORY mode

Some electrical components such as the audio system can be used. "ACCESSORY" will be displayed on the meters.

(3) IGNITION ON mode

All electrical components can be used. "IGNITION ON" will be displayed on the meters.

\*: If the shift lever is in a position other than P when turning off the engine, the engine switch will be turned to ACCES-SORY mode, not to off.



#### When stopping the engine with the shift lever in a position other than P

If the engine is stopped with the shift lever in a position other than P, the engine switch will not be turned off but instead be turned to ACCESSORY mode. Perform the following procedure to turn the switch off:

- 1 Check that the parking brake is set.
- 2 Shift the shift lever to P.
- 3 Check that "Turn Power OFF" is displayed on the multi-information display and then press the engine switch once.
- (4) Check that "Turn Power OFF" on the multi-information display is off.

#### Auto power off function

If the vehicle is left in ACCESSORY mode for more than 20 minutes or IGNITION ON mode (the engine is not running) for more than an hour with the shift lever in P, the engine switch will automatically turn off. However, this function cannot entirely prevent battery discharge. Do not leave the vehicle with the engine switch in ACCESSORY or IGNI-TION ON mode for long periods of time when the engine is not running.

Electronic key battery depletion

→P. 101

Conditions affecting operation

 $\rightarrow P.116$ 

Notes for the entry function

→P. 117

#### If the engine does not start

- Check that the shift lever is securely set in P. The engine may not start if the shift lever is displaced out of P.
- The engine immobilizer system may not have been deactivated. (→P. 69) Contact your Lexus dealer.

#### Steering lock

After turning the engine switch off and opening and closing the doors, the steering wheel will be locked due to the steering lock function. Operating the engine switch again automatically cancels the steering lock.

#### When the steering lock cannot be released

"Steering Lock active" will be displayed on the multi-information display.

Check that the shift lever is in P. Press the engine switch while turning the steering wheel left and right.

#### Steering lock motor overheating prevention

To prevent the steering lock motor from overheating, operation of the motor may be suspended if the engine is turned on and off repeatedly in a short period of time. In this case, refrain from operating the engine switch. After about 10 seconds, the steering lock motor will resume functioning.



Driving

When "Check Access System with Elec. Key" is displayed on the multi-information display

The system may be malfunctioning. Have the vehicle inspected by your Lexus dealer immediately.

#### If the electronic key battery is depleted

→P. 427

#### Operation of the engine switch

- When operating the engine switch, one short, firm press is enough. If the switch is
  pressed improperly, the engine may not start or the engine switch mode may not
  change. It is not necessary to press and hold the switch.
- If attempting to restart the engine immediately after turning the engine switch off, the engine may not start in some cases. After turning the engine switch off, please wait a few seconds before restarting the engine.
- If the smart access system with push-button start has been deactivated by a customized setting

→P. 488

#### **CAUTION**

#### When starting the engine

Always start the engine while sitting in the driver's seat. Do not depress the accelerator pedal while starting the engine under any circumstances.

Doing so may cause an accident resulting in death or serious injury.

#### Caution while driving

If engine failure occurs while the vehicle is moving, do not lock or open the doors until the vehicle reaches a safe and complete stop. Activation of the steering lock in this circumstance may lead to an accident, resulting in death or serious injury.

#### Stopping the engine in an emergency

If you want to stop the engine in an emergency while driving the vehicle, press and hold the engine switch for more than 2 seconds, or press it briefly 3 times or more in succession. ( $\rightarrow$ P. 447)

However, do not touch the engine switch while driving except in an emergency. Turning the engine off while driving will not cause loss of steering or braking control, but the power assist to these systems will be lost. This will make it more difficult to steer and brake, so you should pull over and stop the vehicle as soon as it is safe to do so.

4-2. Driving procedures

#### 

#### To prevent battery discharge

- Do not leave the engine switch in ACCESSORY or IGNITION ON mode for long periods of time without the engine running.
- If "ACCESSORY" or "IGNITION ON" is displayed on the meters while the engine is not running, the engine switch is not off. Exit the vehicle after turning the engine switch off.
- Do not stop the engine when the shift lever is in a position other than P. If the engine is stopped in another shift lever position, the engine switch will not be turned off but instead be turned to ACCESSORY mode. If the vehicle is left in ACCESSORY mode, battery discharge may occur.

#### When starting the engine

- Do not race a cold engine.
- If the engine becomes difficult to start or stalls frequently, have your vehicle checked by your Lexus dealer immediately.

#### Symptoms indicating a malfunction with the engine switch

If the engine switch seems to be operating somewhat differently than usual, such as the switch sticking slightly, there may be a malfunction. Contact your Lexus dealer immediately.


Driving

#### 163

## **164** 4-2. Driving procedures

# Automatic transmission

Shifting the shift lever



While the engine switch is in IGNITION ON mode, move the shift lever with the brake pedal depressed.

When shifting the shift lever between  $\mathsf{P}$  and  $\mathsf{D}$ , make sure that the vehicle is completely stopped.

#### 4-2. Driving procedures

### Shift position purpose

Shift position	Objective or function
Р	Parking the vehicle/starting the engine
R	Reversing
Ν	Neutral
D	Normal driving *1
М	M mode driving $^{*2}$ ( $\rightarrow$ P. 167)

\*1: To improve fuel efficiency and reduce noise, shift the shift lever to D for normal driving.

 $^{\star2}\!\!:$  Any gear range can be fixed when driving in M mode.

#### Selecting the driving mode

#### Sport mode/Eco drive mode

→P. 231

#### Snow mode

Snow mode can be selected to suit the conditions when driving on slippery road surfaces, such as snow.

#### Press the switch.

Press the switch again to return to normal mode.



165

#### **166** 4-2. Driving procedures

#### Selecting shift ranges in the D position

To drive using temporary shift range selection, operate the "-" paddle shift switch. The shift range can then be selected by operating the "-" and "+" paddle shift switches. Changing the shift range allows restriction of the highest gear, preventing unnecessary upshifting and enabling the level of engine braking force to be selected.


- 1 Upshifting
- 2 Downshifting

8-speed models: The selected shift range, from D1 to D8, will be displayed in the meter.

6-speed models: The selected shift range, from D1 to D6, will be displayed in the meter.

To return to normal D position driving, the "+" paddle shift switch must be held down for a period of time.

#### Shift ranges and their functions



Meter display	Function
D2 - D8 (8-speed models)	A gear in the range between 1 and the selected gear is auto- matically chosen depending on vehicle speed and driving
D2 - D6 (6-speed models)	conditions
D1	1st gear is set

A lower shift range will provide greater engine braking forces than a higher shift range.

#### Selecting gears in the M position


To enter M mode, shift the shift lever to M. Gears can then be selected by operating the shift lever or paddle shift switches, allowing you to drive in the gear of your choice.

- 1 Upshifting
- Downshifting

The gear changes once every time the shift lever or paddle shift switch is operated.

8-speed models: The selected gear, from M1 to M8, will be fixed and displayed in the meter.

6-speed models: The selected gear, from M1 to M6, will be fixed and displayed in the meter.



4 Driving

When in the M position, the gear will not change unless the shift lever or paddle shift switches are operated.

However, even when in the M position, the gears will be automatically changed in the following situation:

- When vehicle speed drops (downshift only).
- When the automatic transmission fluid or engine coolant temperature is low.
- When automatic transmission fluid temperature is high.
- When the needle of the tachometer is in the red zone (the range which exceeds the allowable revs of the engine).

In the following situations, the gear will not shift even if the shift lever or paddle shift switches are operated.

- "1st Gear not available due to slippery road surface" is displayed on the multi information display.
- The vehicle speed is low (upshift only).

When the "-" paddle shift switch is operated with the shift lever in the D position A shift range will be automatically selected. The highest gear of the first shift range will be one gear lower than the gear in use during normal D position driving.

#### Automatic deactivation of shift range selection in the D position

Shift range selection in the D position will be deactivated in the following situations:

- When the vehicle comes to a stop
- If the accelerator pedal is depressed for more than a certain period of time
- When the shift lever is shifted to a position other than D

#### To protect the automatic transmission

"Transmission Fluid High Temperature" is displayed on the multi-information display and a function is adopted that automatically selects a higher shift range when the fluid temperature is high. Have the vehicle inspected by your Lexus dealer.

#### Downshifting restriction warning buzzer

To help ensure safety and driving performance, downshifting operation may sometimes be restricted. In some circumstances, downshifting may not be possible even when the shift lever or paddle shift switch is operated. (A buzzer will sound twice.)

#### Snow mode automatic deactivation

Snow mode is automatically deactivated if the engine switch is turned off after driving in snow mode.

#### Multi-information display

When the shift lever is shifted to the M position, the current gear position is displayed on the multi-information display.



#### When driving with cruise control or dynamic radar cruise control activated

Even when performing the following actions with the intent of enabling engine braking, engine braking will not activate because cruise control or dynamic radar cruise control will not be canceled.

- 8-speed models: While driving in the D position, downshifting to 7, 6, 5 or 4. (→P. 192, 196)
- 6-speed models: While driving in the D position, downshifting to 5 or 4. ( $\rightarrow$ P. 192, 196)
- When switching the driving mode to sport mode while driving in D position.  $(\rightarrow P. 231)$

■ If the shift lever cannot be shifted from P

→P. 487

#### AI-SHIFT

The AI-SHIFT automatically selects the suitable gear according to driver performance and driving conditions.

The AI-SHIFT automatically operates when the shift lever is in D. (Shifting the shift lever to the M position cancels the function.)

## 

#### When driving on slippery road surfaces

Be careful of downshifting and sudden acceleration, as this could result in the vehicle skidding to the side or spinning.

## **170** 4-2. Driving procedures

## Turn signal lever


#### **Operating instructions**

The lever will return to its original position after operation.

- 1 Right turn
- Lane change to the right (move the lever partway and release it)
- The right hand signals will flash 3 times.(3) Lane change to the left (move the lever partway and release it)

The left hand signals will flash 3 times.

(4) Left turn



If the turn signals do not stop flashing after turning left or right, or if you want to stop them flashing

Operate the lever in the opposite direction to either position (2) or (3). If you move the lever to either position (1) or (4), the selected turn signals will flash.

- Turn signals can be operated when The engine switch is in IGNITION ON mode.
- If the indicator flashes faster than usual
  - Check that a light bulb in the front or rear turn signal lights has not burned out.
- If the turn signals stop flashing before a lane change has been performed Operate the lever again.
- Customization

The number of times the turn signals flash during a lane change can be changed. (Customizable feature  $\to\!P\!.\,525)$ 

IS350/250\_U (OM53758U)

## **172** 4-2. Driving procedures

## Parking brake

#### **Operating instructions**

To set the parking brake, fully depress the parking brake pedal with your left foot while depressing the brake pedal with your right foot.

(Depressing the pedal again releases the parking brake.)



■ Parking brake engaged warning buzzer →P. 464

■ Usage in winter time →P. 255

**NOTICE** 

#### Before driving

Fully release the parking brake. Driving the vehicle with the parking brake set will lead to brake components overheating, which may affect braking performance and increase brake wear.

## Headlight switch


The headlights can be operated manually or automatically.

#### **Operating instructions**

Turning the end of the lever turns on the lights as follows:

- ∃DOE The side marker, parking, tail, license plate and instrument panel lights turn on.
- ② ≣○ The headlights and all lights listed above turn on.
- (3) AUTO The headlights, daytime running lights and all the lights listed above turn on and off automatically.
   (When the engine switch is in IGNITION ON mode.)

O The daytime running lights (Canada) turn on.



Driving

## **174** 4-3. Operating the lights and wipers


#### Turning on the high beam headlights

 With the headlights on, push the lever away from you to turn on the high beams.

Pull the lever toward you to the center position to turn the high beams off.

2 Pull the lever toward you and release it to flash the high beams once.

You can flash the high beams with the headlights on or off.




#### Daytime running light system

- To make your vehicle more visible to other drivers, the parking lights turn on automatically (at an increased intensity) whenever the engine is started and the parking brake is released. Daytime running lights are not designed for use at night.
- Compared to turning on the headlights, the daytime running light system offers greater durability and consumes less electricity, so it can help improve fuel economy.

#### Headlight control sensor

The sensor may not function properly if an object is placed on the sensor, or anything that blocks the sensor is affixed to the windshield. Doing so interferes with the sensor detecting the level of ambient light and may cause the automatic headlight system to malfunction.



#### Automatic light off system

When the light switch is in AUTO, ⇒D ∈ or ≣D : The headlights and tail lights turn off 30 seconds after the engine switch is turned to ACCESSORY mode or turned off and a door is opened and all of the doors and trunk are closed. (The lights turn off immediately if **n** on the key is pressed twice after all the doors are closed.)

To turn the lights on again, turn the engine switch to IGNITION ON mode, or turn the

light switch off once and then back to  $\operatorname{SD}$  or  $\operatorname{SD}$ .

If any of the doors or trunk lid is left open, the lights automatically turn off after 20 minutes.

#### Automatic headlight leveling system

The level of the headlights is automatically adjusted according to the number of passengers and the loading condition of the vehicle to ensure that the headlights do not interfere with other road users.

#### Light reminder buzzer

A buzzer sounds when the engine switch is turned off or turned to ACCESSORY mode and the driver's door is opened while the lights are turned on.

Operation guide display (vehicles with rain-sensing windshield wipers only)

When the headlight switch is operated to and from the "AUTO" position, the current status is displayed on the meters for a few seconds to show that AUTO mode is activated/ deactivated. ( $\rightarrow$ P. 89)

Customization

Settings (e.g. light sensor sensitivity) can be changed. (Customizable features:  $\rightarrow$  P. 525)

#### ▲ NOTICE

#### To prevent battery discharge

Do not leave the lights on longer than necessary when the engine is not running.

Driving

## **176** 4-3. Operating the lights and wipers

## Automatic High Beam<sup>\*</sup>


The Automatic High Beam uses an in-vehicle camera sensor to assess the brightness of streetlights, the lights of oncoming and preceding vehicles, etc., and automatically turns the high beam on or off as necessary.

#### Activating the Automatic High Beam system


1 Push the lever away from you with


the headlight switch in the AUTO or

**≣D** position.



The Automatic High Beam indicator will come on when the headlights are turned on automatically to indicate that the system is active.





\*: If equipped

#### High beam automatic turning on or off conditions

When all of the following conditions are met, the high beam will be automatically turned on (after approximately 1 second):

- Vehicle speed is above approximately 21 mph (34 km/h).
- The area ahead of the vehicle is dark.
- There are no oncoming or preceding vehicles with headlights or tail lights turned on.
- There are few streetlights on the road ahead.

If any of the following conditions are met, the high beam will be automatically turned off:

- Vehicle speed drops below approximately 17 mph (27 km/h).
- The area ahead of the vehicle is not dark.
- Oncoming or preceding vehicles have headlights or tail lights turned on.
- There are many streetlights on the road ahead.

#### Turning the high beam on/off manually

#### Switching to low beam

Pull the lever to the original position.

The Automatic High Beam indicator will turn off.


Push the lever away from you to activate the Automatic High Beam system again.

#### Switching to high beam

Press the Automatic High Beam switch.

The Automatic High Beam indicator will turn off and the high beam indicator will turn on.

Press the switch to activate the Automatic High Beam system again.



Driving

## The Automatic High Beam can be operated when

The engine switch is in IGNITION ON mode.

#### Camera sensor detection information

- High beam may not be automatically turned off in the following situations:
  - When oncoming vehicles suddenly appear from a curve
  - When the vehicle is cut in front of by another vehicle
  - When oncoming or preceding vehicles are hidden from sight due to repeated curves, road dividers or roadside trees
- High beam may be turned off if an oncoming vehicle that is using fog lights without using the headlights is detected.
- House lights, street lights, red traffic signals, and illuminated billboards or signs may cause the high beam to turn off.
- The following factors may affect the amount of time taken to turn high beam on or off:
  - The brightness of headlights, fog lights, and tail lights of oncoming and preceding vehicles
  - The movement and direction of oncoming and preceding vehicles
  - When an oncoming or preceding vehicle only has operational lights on one side
  - When an oncoming or preceding vehicle is a two-wheeled vehicle
  - The condition of the road (gradient, curve, condition of the road surface etc.)
  - The number of passengers and amount of luggage
- High beam may be turned on or off when unexpected by the driver.
- Small vehicles, such as bicycles, may not be detected.
- In the situations below, the system may not be able to correctly detect the surrounding brightness levels, and may flash or expose nearby pedestrians to the high beam. Therefore, you should consider turning the high beams on or off manually rather than relying on the Automatic High Beam system.
  - In bad weather (rain, snow, fog, sandstorms etc.)
  - The windshield is obscured by fog, mist, ice, dirt etc.
  - The windshield is cracked or damaged.
  - The camera sensor is deformed or dirty.
  - · Surrounding brightness levels are equal to those of headlights, tail lights or fog lights.
  - Vehicles ahead have headlights or tail lights that are either switched off, dirty, changing color, or have improperly adjusted aim.
  - When driving through an area of intermittently changing brightness and darkness.
  - When frequently and repeatedly driving ascending/descending roads, or roads with rough, bumpy or uneven surfaces (such as stone-paved roads, gravel tracks etc.).
  - When frequently and repeatedly taking curves or driving on a winding road.
  - There is a highly reflective object ahead of the vehicle, such as a sign or a mirror.
  - The vehicle's headlights are damaged or dirty.
  - The vehicle is listing or titling, due to a flat tire, a trailer being towed etc.
  - The driver believes that the high beam may be causing problems or distress to other drivers or pedestrians nearby.

#### Temporarily lowering sensor sensitivity

- The sensitivity of the sensor can be temporarily lowered.
- **1** Turn the engine switch off while the following conditions are met.
  - The headlight switch is in AUTO or ≣○.
  - The headlight switch lever is in high beam position.
  - Automatic High Beam switch is on.
- **1** Turn the engine switch to IGNITION ON mode.
- 3 Within 5 seconds after 2, repeat pulling the headlight switch lever to the original position then pushing it to the high beam position quickly 9 times, then leave the lever in high beam position.

Automatic High Beam (headlights) may turn on even the vehicle is stopped.


#### 

#### Limitations of the Automatic High Beam

Do not rely on the Automatic High Beam. Always drive safely, taking care to observe your surroundings and turning high beam on or off manually if necessary.

Driving

#### 4-3. Operating the lights and wipers




180

# Fog light switch

The fog lights secure excellent visibility in difficult driving conditions, such as in rain and fog.

- 1 OFF (U.S.A.) or O (Canada) Turns the fog lights off
- ② ≢() Turns the fog lights on



- Fog lights can be used when
  - The headlights are on in low beam.
- **Operation guide display (vehicles with rain-sensing windshield wipers only)** When the fog light switch is operated, the current status is displayed on the meters for a few seconds. ( $\rightarrow$ P. 89)

\*: If equipped

IS350/250\_U (OM53758U)


# **182** 4-3. Operating the lights and wipers

# Windshield wipers and washer

### Operating the wiper lever

Operate the lever as follows to operate the wipers. The lever will return to its original position after operation.

- ▶ Intermittent windshield wipers with interval adjuster
- ▲OFF (U.S.A.) or o (Canada) Up 2 levels
- ② △ Up1level
- ③ ▼ (U.S.A.) or ▽ (Canada) Down1level
- ④ ¥HI (U.S.A.) or ∑ (Canada) Down 2 levels




Operation Status before operation	<b>₹</b> OFF or o		▼ or マ	≚HI or ⊠	
Off	Temporary operation	Temporary operation	Intermittent operation	High speed operation	
Intermittent operation	Off	Off	Low speed operation	High speed operation	
Low speed operation	Off	Intermittent operation	High speed operation	High speed operation	
High speed operation	Off	Low speed operation	No change	No change	

#### 4-3. Operating the lights and wipers


Wiper intervals can be adjusted when intermittent operation is selected.

- 5 Increases the intermittent windshield wiper frequency
- 6 Decreases the intermittent windshield wiper frequency




⑦ Washer/wiper dual operation

The wipers will automatically operate a couple of times after the washer squirts. Vehicles with headlight cleaners: When the headlights are on and the lever is pulled and held, the headlight cleaners will operate once. After this, the headlight cleaners will operate every 5th time the lever is pulled.



# **184** 4-3. Operating the lights and wipers

- ► Rain-sensing windshield wipers
- ① **조**OFF (U.S.A.) or o (Canada) Up 2 levels
- ② △ Up1level
- ③ ▼ (U.S.A.) or ▼ (Canada) Down1level
- ④ **≚** HI (U.S.A.) or <u></u>∠ (Canada) Down 2 levels
- 5 AUTO mode on/off switch



With AUTO mode selected, the wipers will operate automatically when the sensor detects falling rain. The system automatically adjusts wiper timing in accordance with rain volume and vehicle speed.


The AUTO mode indicator will turn on when AUTO mode is selected.

Operation Status before operation		The second seco		▼ or マ	¥HI or ⊠
Off		Temporary operation	Temporary operation	Low speed operation	High speed operation
Low speed operation		Off	Off	High speed operation	High speed operation
High speed operation		Off	Low speed operation	No change	No change
AUTO mode	Intermittent operation	Off	Temporary operation*	Low speed operation	High speed operation
	Continuously		No change		

\*: After temporary operation, the mode will return to AUTO mode.


When AUTO mode is selected, the sensor sensitivity can be adjusted by turning the switch ring.

- 6 Increases the sensitivity
- $\bigcirc$  Decreases the sensitivity



(8) Washer/wiper dual operation

The wipers will automatically operate a couple of times after the washer squirts. Vehicles with headlight cleaners: When the headlights are on and the lever is pulled and held, the headlight cleaners will operate once. After this, the headlight cleaners will operate every 5th time the lever is pulled.




4 Driving

# Switching between the intermittent windshield wipers and rain-sensing windshield wipers (vehicles with rain-sensing windshield wipers)

The wipers can be used as intermittent windshield wipers, which operate regardless of vehicle speed or amount of raindrops. The intermittent windshield wiper operation can be switched when the vehicle is stopped and the wiper is off. The wiper operation cannot be switched during AUTO mode or while the intermittent windshield wipers are operating.

Press and hold  $\underset{AUTO}{\bigcirc}$  until the AUTO mode indicator stops flashing.

If AUTO is pressed and held until the AUTO mode indicator stops flashing again, it will return to its previous state. The wiper can be switched when the vehicle is stopped and the wipers are off.



The windshield wiper and washer can be operated when The engine switch is in IGNITION ON mode.

#### Dripping prevention wiper sweep

After performing a washing and wiping operation several times, the wipers operate one more time after a short delay to prevent dripping.

However, the last sweep will not happen if the vehicle is traveling above 106 mph (170 km/h).

Effects of vehicle speed on wiper operation (vehicles with rain-sensing windshield wipers)

Vehicle speed affects the following even when the wipers are not in AUTO mode.

- Intermittent wiper interval
- Wiper operation when the washer is being used (delay until drip prevention wiper sweep occurs)

With low speed windshield wiper operation selected, wiper operation will be switched from low speed to intermittent wiper operation only when the vehicle is stationary.

#### Raindrop sensor (vehicles with rain-sensing windshield wipers)

• The raindrop sensor judges the amount of raindrops.

An optical sensor is adopted. It may not operate properly when sunlight from the rising or setting of the sun intermittently strikes the windshield, or if bugs etc. are present on the windshield.



- If the wiper is turned to AUTO mode while the engine switch is in IGNITION ON mode, the wipers will operate once to show that AUTO mode is activated.
- If the temperature of the raindrop sensor is 185°F (85°C) or higher, or -22°F (-30°C) or lower, automatic operation may not occur. In this case, operate the wipers in any mode other than AUTO mode.
- When the windshield wipers are in temporary operation (vehicles with rain-sensing windshield wipers)

AUTO mode cannot be activated even if AUTO is pressed.

### If no windshield washer fluid sprays

Check that the washer nozzles are not blocked if there is washer fluid in the windshield washer fluid reservoir.

Operation guide display (vehicles with rain-sensing windshield wipers only)

When the windshield wiper switch is operated to activate AUTO mode or when the rainsensing level is adjusted, the current status is displayed on the meters for a few seconds.  $(\rightarrow P. 89)$ 

### **CAUTION**

#### Caution regarding the use of windshield wipers in AUTO mode

The windshield wipers may operate unexpectedly if the sensor is touched or the windshield is subject to vibration in AUTO mode. Take care that your fingers or anything else do not become caught in the windshield wipers.

Caution regarding the use of washer fluid

When it is cold, do not use the washer fluid until the windshield becomes warm. The fluid may freeze on the windshield and cause low visibility. This may lead to an accident, resulting in death or serious injury.

#### **NOTICE**

When the windshield is dry

Do not use the wipers, as they may damage the windshield.

#### When there is no washer fluid spray from the nozzle

Damage to the washer fluid pump may be caused if the lever is pulled toward you and held continually.

When a nozzle becomes blocked

In this case, contact your Lexus dealer.

Do not try to clear it with a pin or other object. The nozzle will be damaged.

# **188** 4-4. Refueling

# Opening the fuel tank cap

Perform the following steps to open the fuel tank cap:

#### Before refueling the vehicle

- Close all the doors and windows, and turn the engine switch off.
- Confirm the type of fuel.

#### Fuel types

Use unleaded gasoline (Octane rating 91 [Research Octane Number 96] or higher)

#### 

#### When refueling the vehicle

Observe the following precautions while refueling the vehicle. Failure to do so may result in death or serious injury.

• After exiting the vehicle and before opening the fuel door, touch an unpainted metal surface to discharge any static electricity. It is important to discharge static electricity before refueling because sparks resulting from static electricity can cause fuel vapors to ignite while refueling.

Always hold the grips on the fuel tank cap and turn it slowly to remove it.
 A whooshing sound may be heard when the fuel tank cap is loosened. Wait until the sound cannot be heard before fully removing the cap. In hot weather, pressurized fuel may spray out the filler neck and cause injury.

- Do not allow anyone that has not discharged static electricity from their body to come close to an open fuel tank.
- Do not inhale vaporized fuel. Fuel contains substances that are harmful if inhaled.
- Do not smoke while refueling the vehicle. Doing so may cause the fuel to ignite and cause a fire.
- Do not return to the vehicle or touch any person or object that is statically charged. This may cause static electricity to build up, resulting in a possible ignition hazard.

#### When refueling

Observe the following precautions to prevent fuel overflowing from the fuel tank:

- Securely insert the fuel nozzle into the fuel filler neck.
- Stop filling the tank after the fuel nozzle automatically clicks off.
- Do not top off the fuel tank.

4-4. Refueling

189

# **NOTICE**

#### Refueling


Do not spill fuel during refueling. Doing so may damage the vehicle, such as causing the emission control system to operate abnormally or damaging fuel system components or the vehicle's painted sur-face.

# Opening the fuel tank cap

1 With the doors unlocked, press the center of the rear edge of the fuel filler door.


Push until you hear a click and take your hand away to slightly open the fuel filler door. Then open the door fully by hand.

**2** Turn the fuel tank cap slowly to remove it and put it into the holder on the fuel filler door.



#### ■ If the fuel filler door cannot be opened

Remove the cover inside the trunk and pull the lever to open the fuel filler door if the fuel filler door cannot be opened by pressing the rear edge of the fuel filler door.




CLY44AZ008

4-4. Refueling

### Closing the fuel tank cap

- 1 After refueling, turn the fuel tank cap until you hear a click. Once the cap is released, it will turn slightly in the opposite direction.
- 2 Close the fuel filler door, and press the center of the rear edge of the fuel filler door until you hear a click.

When you lock the doors, the fuel filler door will also lock.





Driving

#### Fuel filler door lock condition

The fuel filler door may not be locked even when the vehicle's doors are locked in the following situations:

- When operating the door lock button inside the vehicle
- When the automatic door locking system is operated ( $\rightarrow$ P. 527)
- When the fuel filler door is closed after the vehicle's doors are locked

### A CAUTION

#### When replacing the fuel tank cap

Do not use anything but a genuine Lexus fuel tank cap designed for your vehicle. Doing so may cause a fire or other incident which may result in death or serious injury.

IS350/250\_U (OM53758U)

191


# **192** 4-5. Using the driving support systems

# Cruise control

### Summary of functions

Use the cruise control to maintain a set speed without depressing the accelerator pedal.

- 1 Indicators
- 2 Cruise control switch




### Setting the vehicle speed

1 Press the "ON/OFF" button to activate the cruise control.

Cruise control indicator will come on. Press the button again to deactivate the cruise control.

2 Accelerate or decelerate the vehicle to the desired speed, and push the lever down to set the speed.

"SET" indicator will come on. The vehicle speed at the moment the lever is released becomes the set speed.



\*: If equipped

#### Adjusting the set speed

To change the set speed, operate the lever until the desired set speed is obtained.

- 1 Increases the speed
- Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction. Large adjustment: Hold the lever in the desired direction.



The set speed will be increased or decreased as follows:

Fine adjustment: By approximately 1 mph (1.6 km/h) each time the lever is operated. Large adjustment: The set speed can be increased or decreased continually until the lever is released.


#### Canceling and resuming the constant speed control

 Pulling the lever toward you cancels the constant speed control.

The speed setting is also canceled when the brakes are applied.

2 Pushing the lever up resumes the constant speed control.

Resuming is available when the vehicle speed is more than approximately 25 mph (40 km/h).



- Cruise control can be set when
  - The shift lever is in D.
  - Range 4 or higher of D has been selected by using the paddle shift.
  - Vehicle speed is above approximately 25 mph (40 km/h).
- Accelerating after setting the vehicle speed
  - The vehicle can be accelerated normally. After acceleration, the set speed resumes.
  - Even without canceling the cruise control, the set speed can be increased by first accelerating the vehicle to the desired speed and then pushing the lever down to set the new speed.


#### Automatic cruise control cancelation

- Cruise control will stop maintaining the vehicle speed in any of the following situations.
- Actual vehicle speed falls more than approximately 10 mph (16 km/h) below the preset vehicle speed.
  - At this time, the memorized set speed is not retained.
- Actual vehicle speed is below approximately 25 mph (40 km/h).
- VSC is activated.
- TRAC is activated for a period of time.
- When the VSC or TRAC system is turned off by pressing the VSC OFF switch.

#### If the warning message for the cruise control is shown on the multi-information display

Press the "ON/OFF" button once to deactivate the system, and then press the button again to reactivate the system.

If the cruise control speed cannot be set or if the cruise control cancels immediately after being activated, there may be a malfunction in the cruise control system. Have the vehicle inspected by your Lexus dealer. 4-5. Using the driving support systems



Driving

IS350/250\_U (OM53758U)


# **196** 4-5. Using the driving support systems

# Dynamic radar cruise control\*

### Summary of functions

Dynamic radar cruise control supplements conventional cruise control with a vehicle-to-vehicle distance control. In vehicle-to-vehicle distance control mode, the vehicle automatically accelerates or decelerates in order to maintain a set following distance from vehicles ahead.

- ① Vehicle-to-vehicle distance button
- Display
- ③ Set speed
- (4) Indicators
- 5 Cruise control switch



\*: If equipped

# Setting the vehicle speed (vehicle-to-vehicle distance control mode) 1 Press the "ON/OFF" button to activate the cruise control. Dynamic radar cruise control indicator will come on. Press the button again to deactivate the cruise control. Rada ready **2** Accelerate or decelerate the vehicle to the desired speed, and push the lever down to set the speed. "SET" indicator will be displayed. The vehicle speed at the moment the lever is released becomes the set speed. SET

Driving

CLY45AZ

197

IS350/250\_U (OM53758U)

#### Adjusting the set speed

To change the set speed, operate the lever until the desired set speed is displayed.

- 1 Increases the speed
- 2 Decreases the speed

Fine adjustment: Momentarily move the lever in the desired direction.

Large adjustment: Hold the lever in the desired direction.



In the vehicle-to-vehicle distance control mode, the set speed will be increased or decreased as follows:

When the set speed is shown in "MPH"

Fine adjustment: By approximately 1 mph (1.6 km/h) each time the lever is operated

Large adjustment: By approximately 5 mph (8 km/h) for each 0.75 seconds the lever is held

• When the set speed is shown in "km/h"

Fine adjustment: By approximately 0.6 mph (1 km/h) each time the lever is operated

Large adjustment: By approximately 3.1 mph (5 km/h) for each 0.75 seconds the lever is held

In the constant speed control mode ( $\rightarrow$ P. 201), the set speed will be increased or decreased as follows:

Fine adjustment: By approximately 1 mph (1.6 km/h) each time the lever is operated Large adjustment: The set speed can be increased or decreased continually until the lever is released.


IS350/250\_U (OM53758U)

#### Changing the vehicle-to-vehicle distance

Pressing the button changes the vehicle-to-vehicle distance as follows:

- 1 Long
- Medium
- 3 Short

The vehicle-to-vehicle distance is set automatically to long mode when the engine switch is turned to IGNITION ON mode.



If a vehicle is running ahead of you, the preceding vehicle mark will also be displayed.

#### Vehicle-to-vehicle distance settings

Select a distance from the table below. Note that the distances shown correspond to a vehicle speed of 50 mph (80 km/h). Vehicle-to-vehicle distance increases/decreases in accordance with vehicle speed.

Distance options	Vehicle-to-vehicle distance		
Long	Approximately 160 ft. (50 m)		
Medium	Approximately 130 ft. (40 m)		
Short	Approximately 100 ft. (30 m)		

Driving


#### Canceling and resuming the speed control

 Pulling the lever toward you cancels the cruise control.

The speed setting is also canceled when the brakes are applied.

2 Pushing the lever up resumes the cruise control and returns vehicle speed to the set speed.

Resuming is available when the vehicle speed is more than approximately 25 mph (40 km/h).




### 199

# **200** 4-5. Using the driving support systems

#### Driving in vehicle-to-vehicle distance control mode

This mode employs a radar sensor to detect the presence of vehicles up to approximately 400 ft. (120 m) ahead, determines the current vehicle-to-vehicle following distance, and operates to maintain a suitable following distance from the vehicle ahead.

Note that vehicle-to-vehicle distance will close in when traveling on long downhill slopes.



(1) Example of constant speed cruising When there are no vehicles ahead

> The vehicle travels at the speed set by the driver. The desired vehicle-to-vehicle distance can also be set by operating the vehicle-to-vehicle distance control.

(2) Example of deceleration cruising

When the vehicle ahead is driving slower than the set speed

When a vehicle is detected running ahead of you, the system automatically decelerates your vehicle. When a greater reduction in vehicle speed is necessary, the system applies the brakes. A warning tone warns you when the system cannot decelerate sufficiently to prevent your vehicle from closing in on the vehicle ahead.

③ Example of follow-up cruising

When following a vehicle driving slower than the set speed

The system continues follow-up cruising while adjusting for changes in the speed of the vehicle ahead in order to maintain the vehicle-to-vehicle distance set by the driver.

4 Example of acceleration

When there are no longer any vehicles ahead driving slower than the set speed

The system accelerates until the set speed is reached. The system then returns to constant speed cruising.

### Approach warning

When your vehicle is too close to a vehicle ahead, and sufficient automatic deceleration via the cruise control is not possible, the display will flash and the buzzer will sound to alert the driver. An example of this would be if another driver cuts in front of you while you are following a vehicle. Apply the brakes to ensure an appropriate vehicle-to-vehicle distance.

#### Warnings may not occur when

In the following instances, there is a possibility that the warnings will not occur:

- When the speed of the vehicle ahead matches or exceeds your vehicle speed
- When the vehicle ahead is traveling at an extremely slow speed
- Immediately after the cruise control speed was set
- At the instant the accelerator is applied

#### Selecting conventional constant speed control mode

When constant speed control mode is selected, your vehicle will maintain a set speed without controlling the vehicle-to-vehicle distance. Select this mode only when vehicle-to-vehicle distance control mode does not function correctly due to dirt etc.

1 Press the "ON/OFF" button to activate the cruise control.

Press the button again to deactivate the cruise control.

2 Switch to constant speed control mode.

(Push the lever forward and hold for approximately one second.)

Constant speed control mode indicator will come on.

When in constant speed control mode, to return to vehicle-to-vehicle distance control mode, push the lever forward again and hold for approximately 1 second.

After the desired speed has been set, it is not possible to return to vehicle-to-vehicle distance control mode.

If the engine switch is turned off and then turned to IGNITION ON mode again, the vehicle will automatically return to vehicle-to-vehicle distance control mode.

Adjusting the speed setting:  $\rightarrow$  P. 193

Canceling and resuming the speed setting:  $\rightarrow$  P. 193



- Dynamic radar cruise control can be set when
  - The shift lever is in D.
  - Range 4 or higher of D has been selected by using the paddle shift.
  - Vehicle speed is above approximately 30 mph (50 km/h).
- Accelerating after setting the vehicle speed

The vehicle can accelerate normally. After acceleration, the set speed resumes. However, during vehicle-to-vehicle distance control mode, the vehicle speed may decrease below the set speed in order to maintain the distance to the vehicle ahead.

Automatic cancelation of vehicle-to-vehicle distance control

Vehicle-to-vehicle distance control driving is automatically canceled in the following situations:

- Actual vehicle speed falls below approximately 25 mph (40 km/h).
- VSC is activated.
- TRAC is activated for a period of time.
- When the VSC or TRAC system is turned off by pressing the VSC OFF switch.
- The sensor cannot operate correctly because it is covered in some way.
- The windshield wipers are operating at high speed (when the wipers are in AUTO mode or the high speed wiper operation).
- When snow mode is set.
- Pre-collision braking is activated.

If vehicle-to-vehicle distance control driving is automatically canceled for any other reason, there may be a malfunction in the system. Contact your Lexus dealer.

- Automatic cancelation of constant speed control
  - The cruise control will stop maintaining the vehicle speed in the following situations:
  - Actual vehicle speed is more than approximately 10 mph (16 km/h) below the set vehicle speed.

At this time, the memorized set speed is not retained.


- Vehicle speed falls below approximately 25 mph (40 km/h).
- VSC is activated.
- TRAC is activated for a period of time.
- When the VSC or TRAC system is turned off by pressing the VSC OFF switch.
- Pre-collision braking is activated.

#### Radar sensor and grille cover

Always keep the sensor and grille cover clean to ensure that the vehicle-to-vehicle distance control operates properly. (Some obstructions, such as snow, ice and plastic objects, cannot be detected by the obstruction sensor.)

Dynamic radar cruise control is canceled if an obstruction is detected.

- $\textcircled{1} \quad \mathsf{Grille} \ \mathsf{cover}$
- Radar sensor



#### Operation guide display

When the dynamic radar cruise control switch is operated, a guidance display is shown on the meters for a few seconds as to how to operate the dynamic radar cruise control switch or distance switch. ( $\rightarrow$ P. 89)

#### Warning messages and buzzers for dynamic radar cruise control

Warning messages and buzzers are used to indicate a system malfunction or to inform the driver of the need for caution while driving. ( $\rightarrow$ P. 465)



#### Certification

► For vehicles sold in the U.S.A.

FCC ID: BABFT0041A

CAUTION: Radio Frequency Radiation Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body (excluding extremities: hands, wrists, feet and ankles).

Co-location: This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

▶ For vehicles sold in Canada

IC: 2024B-FT0041A

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

#### **A** CAUTION Before using dynamic radar cruise control Do not overly rely on vehicle-to-vehicle distance control. Be aware of the set speed. If automatic deceleration/acceleration is not appropriate, adjust the vehicle speed, as well as the distance between your vehicle and vehicles ahead by applying the brakes etc. Cautions regarding the driving assist systems Observe the following precautions. Failure to do so may cause an accident resulting in death or serious injury. • Assisting the driver to measure following distance The dynamic radar cruise control is only intended to help the driver in determining the following distance between the driver's own vehicle and a designated vehicle traveling ahead. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for driver to pay close attention to the vehicle's surroundings. Assisting the driver to judge proper following distance The dynamic radar cruise control determines whether the following distance between the driver's own vehicle and a designated vehicle traveling ahead is appropriate or not. It is not capable of making any other type of judgement. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of danger in any given situation. • Assisting the driver to operate the vehicle The dynamic radar cruise control has no capability to prevent or avoid a collision with a vehicle traveling ahead. Therefore, if there is ever any danger, the driver must take immediate and direct control of the vehicle and act appropriately in order to ensure the safety of all involved. To avoid inadvertent cruise control activation

Switch the cruise control off using the "ON/OFF" button when not in use.

# **206** 4-5. Using the driving support systems

### CAUTION Situations unsuitable for dynamic radar cruise control Do not use dynamic radar cruise control in any of the following situations. Doing so may result in inappropriate speed control and could cause an accident resulting in death or serious injury. In heavy traffic • On roads with sharp bends • On winding roads • On slippery roads, such as those covered with rain, ice or snow • On steep downhills, or where there are sudden changes between sharp up and down gradients Vehicle speed may exceed the set speed when driving down a steep hill. • At entrances to expressways • When weather conditions are bad enough that they may prevent the sensors from functioning correctly (fog, snow, sandstorm, heavy rain, etc.) • When an approach warning buzzer is heard often During emergency towing When the sensor may not be correctly detecting the vehicle ahead Apply the brakes as necessary when any of the following types of vehicles are in front of you. As the sensor may not be able to correctly detect these types of vehicles, the approach warning ( $\rightarrow$ P. 201) will not be activated, and a fatal or serious accident may result. • Vehicles that cut in suddenly • Vehicles traveling at low speeds Vehicles that are not moving • Vehicles with small rear ends (trailers with no load on board etc.) Motorcycles traveling in the same lane Conditions under which the vehicle-to-vehicle distance control may not function correctly Apply the brakes as necessary in the following conditions as the radar sensor may not be able to correctly detect vehicles ahead, and a fatal or serious accident may result: • When water or snow thrown up by the surrounding vehicles hinders the functioning of the sensor • When your vehicle is pointing upwards (caused by a heavy load in the trunk etc.) When the road curves or when the lanes are narrow • When steering wheel operation or your position in the lane is unstable When the vehicle ahead of you decelerates suddenly

# 

#### Handling the radar sensor

Observe the following to ensure the cruise control system can function effectively.

Otherwise, the system may not function correctly and could result in an accident.

• Keep the sensor and grille cover clean at all times.

Clean the sensor and grille cover with a soft cloth so you do not mark or damage them.

- Do not subject the sensor or surrounding area to a strong impact. If the sensor moves even slightly off position, the system may malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by a Lexus dealer.
- Do not disassemble the sensor.
- Do not attach accessories or stickers to the sensor, grille cover or surrounding area.
- Do not modify or paint the sensor and grille cover.
- Do not replace them with non-genuine parts.

# **208** 4-5. Using the driving support systems

# LDA (Lane Departure Alert)\*

### Summary of function

While driving on a road that has lane markers, this system recognizes the lane markers using a camera as a sensor to alert the driver when the vehicle deviates from its lane.

If the system judges that the vehicle has deviated from its lane, it alerts the driver using a buzzer and indications on the multi-information display.

Camera sensor



\*: If equipped

### Turning the LDA system on

Press the LDA switch to activate the system.


- The LDA indicator and lane lines will come on.
- Press the switch again to turn the LDA system off.

The LDA system will remain on or off even if the engine switch is turned to IGNITION ON mode.

### Operating conditions

- When the vehicle speed is approximately 32 mph (50 km/h) or more
- When the lane width is more than approximately 8.2 ft. (2.5 m)
- When driving on a straight road or through a curve with a radius of more than approximately 328 ft. (100 m)

n



#### IS350/250\_U (OM53758U)

209

4

# **210** 4-5. Using the driving support systems

#### Indication on the multi-information display

When the inside of both lane lines turn white:

Indicates that both right and left lane markers are recognized.

If the vehicle deviates from the lane, the lane line on the side the vehicle has deviated from will flash in yellow. ( $\rightarrow$ P. 462)


When the inside of either lane line turns white:

Indicates that the lane marker on the white-marked side is recognized.

If the vehicle deviates from the side of a lane with recognized lane markers, the lane line will flash in yellow. ( $\rightarrow$ P. 462)

When the inside of both lane lines are black:

Indicates that no lane markers are recognized or the LDA system is temporarily canceled.



CLY45AZ021



IS350/250\_U (OM53758U)

#### Temporary cancelation of the LDA system functions

If any of the following occurs, the LDA system functions will be temporarily canceled. The functions will resume after the necessary operating conditions have returned.

- The turn signal lever is operated.
- The vehicle speed deviates from the operating range of the LDA system functions.
- When the lane lines cannot be recognized while driving.
- When the lane departure warning sounds.

The lane departure warning function will not operate again for a several seconds after it has been activated, even if the vehicle leaves the lane again.

#### The lane departure warning

Depending on the audio system sound level or air conditioning fan noise while the audio system or air conditioning system is in use, it may be difficult to hear the warning sound.

#### After the vehicle has been parked in the sun

The LDA system may not be available and a warning message ( $\rightarrow$ P. 465) will be displayed for a while after driving has started. When the temperature in the cabin decreases and the temperature around the camera sensor ( $\rightarrow$ P. 196) becomes suitable for its operation, the functions will begin to operate.

#### If there are lane markers on only one side of the vehicle

The lane departure warning will not operate for the side on which lane markers could not be recognized.

#### Conditions in which the function may not operate correctly

In the following situations, the camera sensor may be unable to recognize lane markers causing the lane departure warning function to operate incorrectly. However, this does not indicate a malfunction.

- When driving through an area with no lane markers, such as a tollbooth, a crossing or before a ticket checkpoint
- When driving on a sharp curve
- When lane markers are extremely narrow or extremely wide
- When the vehicle leans to one side an unusual amount due to a heavy load or improper tire inflation pressure
- When the following distance between your vehicle and the vehicle ahead is extremely short
- When the lane markers are yellow (These may be more difficult for the system to recognize compared to white markers.)
- When the lane markers are broken, Botts' dots (raised pavement markers) or stones
- When the lane markers are on a curb etc.
- When lane markers are obscured or partially obscured by sand, dirt, etc.
- When there are shadows on the road running parallel with lane markers, or if a shadow covers the lane markers
- When driving on a particularly bright road surface, such as concrete
- When driving on a road surface that is bright due to reflected light
- When driving in a location where the light level changes rapidly, such as the entrance to
  or exit from a tunnel
- When sunlight or the headlights of oncoming vehicles are shining directly into the camera lens

- When driving on roads that are branching or merging
- When driving on a road surface that is wet due to rain, previous rainfall, standing water, etc.
- When the vehicle experiences strong up-and-down motion such as when driving on an extremely rough road or on a seam in the pavement
- When headlight brightness at nighttime is reduced due to dirt on the lenses, or when the headlights are misaligned
- When driving on winding roads or roads that are uneven
- When driving on rough or unpaved roads
- When changing the tires
  - Depending on the tires used, sufficient performance may not be maintainable.
- Warning messages for the LDA system

Warning messages are used to indicate a system malfunction or to inform the driver of the need for caution while driving. ( $\rightarrow$ P. 465)

### **CAUTION**

#### Before using the LDA system

Do not rely solely on the LDA system. The LDA system does not drive the vehicle automatically, nor does it reduce the amount of care you need to take. As such, the driver must always assume full responsibility for understanding his/her surroundings, for operating the steering wheel to correct the driving line, and for driving safely.

Inappropriate or negligent driving could lead to an accident.

- To avoid operating the LDA by mistake
  - Switch the LDA system off using the LDA switch when not in use.
- Situations unsuitable for LDA system


Do not use the LDA system in any of the following situations.

Otherwise, the system may not function correctly and could result in an accident.

- When driving with tire chains, a spare tire, or similar equipment
- When there are objects or structures along the roadside that might be misinterpreted as lane markers (such as guardrails, a curb, reflector posts, etc.)
- When driving on snowy roads
- When pavement lane markers are difficult to see due to rain, snow, fog, sand dust, etc.
- When there are visible lines on the pavement from road repairs, or if the remains of old lane markers are still visible on the road
- When driving on a road with lane closures due to maintenance, or when driving in a temporary lane

IS350/250\_U (OM53758U)

4-5. Using the driving support systems



213

#### 214 4-5. Using the driving support systems

# Intuitive parking assist

The distance from your vehicle to nearby obstacles when parallel parking or maneuvering into a garage is measured by the sensors and communicated via the multi-information display, Lexus Display Audio screen (if equipped) and a buzzer. Always check the surrounding area when using this system.


Types of sensors



- (1) Front center sensors
- 2 Front corner sensors
- Intuitive parking assist switch

Turns the intuitive parking assist on/ off

When on, the indicator light comes on to inform the driver that the system is operational.



4 Rear center sensors

\*: If equipped

### Display

When the sensors detect an obstacle, a graphic is shown on the multi-information display and Lexus Display Audio screen (if equipped) depending on the position and distance to the obstacle.

### Multi-information display

- ① Front corner sensor detection
- Front center sensor detection
- ③ Rear corner sensor detection
- ④ Rear center sensor detection



### Lexus Display Audio screen (if equipped)

A graphic is automatically displayed when an obstacle is detected. The screen can be set so that the graphic is not displayed. ( $\rightarrow$ P. 218)

sounds.



# Sensor detection display, obstacle distance

# Multi-information display and Lexus Display Audio screen (if equipped)

Sensors that detect an obstacle will illuminate continuously or blink.

	Approximate distance to obstacle		
Display	Front corner sensor/ front center sensor	Rear corner sensor/ rear center sensor	
(continuous)	Front center sensor only: 3.3 ft. (100 cm) to 1.6 ft. (50 cm)	Rear center sensor only: 4.9 ft. (150 cm) to 2.0 ft. (60 cm)	
(continuous)	1.6 ft. (50 cm) to 1.3 ft. (40 cm)	2.0 ft. (60 cm) to 1.5 ft. (45 cm)	
(continuous)	1.3 ft. (40 cm) to 1.0 ft. (30 cm)	Rear corner sensor: 1.5 ft. (45 cm) to 1.0 ft. (30 cm) Rear center sensor: 1.5 ft. (45 cm) to 1.1 ft. (35 cm)	
(blinking <sup>*1</sup> or continuous <sup>*2</sup> )	Less than 1.0 ft. (30 cm)	Rear corner sensor: Less than 1.0 ft. (30 cm) Rear center sensor: Less than 1.1 ft. (35 cm)	

\*1: Multi-information display

\*<sup>2</sup>: Lexus Display Audio screen

## Buzzer operation and distance to an obstacle

A buzzer sounds when the sensors are operating.


- The buzzer beeps faster as the vehicle approaches an obstacle. When the vehicle comes within the following distance of the obstacle, the buzzer sounds continuously:
  - Front center sensors: Approximately 1.0 ft. (30 cm)
  - Corner sensors: Approximately 1.0 ft. (30 cm)
  - Rear center sensors: Approximately 1.1 ft. (35 cm)
- When 2 or more obstacles are detected simultaneously, the buzzer system responds to the nearest obstacle. If one or both come within the above distances, the beep will repeat a long tone, followed by fast beeps.

# Detection range of the sensors

- (1) Approximately 3.3 ft. (100 cm)
- (2) Approximately 4.9 ft. (150 cm)
- 3 Approximately 1.6 ft. (50 cm)
- 4 Approximately 2.0 ft. (60 cm)

The diagram shows the detection range of the sensors. Note that the sensors cannot detect obstacles that are extremely close to the vehicle.

The range of the sensors may change depending on the shape of the object etc.



IS350/250\_U (OM53758U)

# Setting up intuitive parking assist

You can change the warning beep volume and Lexus Display Audio screen operating conditions.

- **1** Press the "MENU" button on the Lexus Display Audio controller. ( $\rightarrow$ P. 262)
- 2 Select "SETUP" on the "Menu" screen.
- **3** Select "Vehicle" on the "Setup" screen.
- 4 Select "LEXUS Park Assist" on the "Vehicle Settings" screen.
- **5** Select the desired button.
  - 1 The alert volume can be adjusted.
  - On or off can be selected for intuitive parking assist display.
  - Front or rear center sensors display and tone indication can be set.

Alert Volume	(1)	
Display	2	On
Front Sonar Distance	10	
Rear Sonar Distance		

#### The intuitive parking assist can be operated when

- Front center sensors:
  - The engine switch is in IGNITION ON mode.
  - The shift lever is in a position other than P or R.
  - The vehicle speed is less than about 6 mph (10 km/h).
- Front corner sensors:
  - The engine switch is in IGNITION ON mode.
  - The shift lever is in a position other than P.
  - The vehicle speed is less than about 6 mph (10 km/h). (At any speed when the shift lever is in R)
- Rear corner and rear center sensors:
  - The engine switch is in IGNITION ON mode.
  - The shift lever is in R.

#### Sensor detection information

- The sensor's detection areas are limited to the areas around the vehicle's front corner and rear bumpers.
- Certain vehicle conditions and the surrounding environment may affect the ability of the sensor to correctly detect obstacles. Particular instances where this may occur are listed below.
  - There is dirt, snow or ice on the sensor. (Wiping the sensors will resolve this problem.)
  - The sensor is frozen. (Thawing the area will resolve this problem.) In especially cold weather, if a sensor is frozen the screen may show an abnormal display, or obstacles may not be detected.

  - The sensor is covered in any way. The vehicle is leaning considerably to one side.
  - On an extremely bumpy road, on an incline, on gravel, or on grass.
  - The vicinity of the vehicle is noisy due to vehicle horns, motorcycle engines, air brakes of large vehicles, or other loud noises producing ultrasonic waves.
  - There is another vehicle equipped with parking assist sensors in the vicinity.
  - The sensor is coated with a sheet of spray or heavy rain.
  - The vehicle is equipped with a fender pole or wireless antenna.
  - Towing eyelets are installed.
  - The bumper or sensor receives a strong impact.
  - The vehicle is approaching a tall or curved curb.
  - In harsh sunlight or intense cold weather.
  - The area directly under the bumpers is not detected.
  - If obstacles draw too close to the sensor.
  - A non-genuine Lexus suspension (lowered suspension etc.) is installed.
  - People may not be detected if they are wearing certain types of clothing

In addition to the examples above, there are instances in which, because of their shape, signs and other objects may be judged by the sensor to be closer than they are.

- The shape of the obstacle may prevent the sensor from detecting it. Pay particular attention to the following obstacles:
  - Wires, fences, ropes, etc.
  - Cotton, snow and other materials that absorb sound waves
  - Sharply-angled objects
  - Low obstacles
  - Tall obstacles with upper sections projecting outwards in the direction of your vehicle
- The following situations may occur during use.
  - Depending on the shape of the obstacle and other factors, the detection distance may shorten, or detection may be impossible.
  - Obstacles may not be detected if they are too close to the sensor.
  - There will be a short delay between obstacle detection and display. Even at slow speeds, there is a possibility that the obstacle will come within the sensor's detection areas before the display is shown and the warning beep sounds.
  - Thin posts or objects lower than the sensor may not be detected when approached, even if they have been detected once.
  - It might be difficult to hear beeps due to the volume of the audio system or air flow noise of the air conditioning system.

Driving

## If a message is displayed on the multi-information display

→P. 463

# Certification

▶ For vehicles sold in the U.S.A.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions; (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

▶ For vehicles sold in Canada

This ISM device complies with Canadian ICES-001.

Cet appareil ISM est conforme a la norme NMB-001 du Canada.

# **CAUTION**

#### When using the intuitive parking assist

Observe the following precautions.

Failing to do so may result in the vehicle being unable to be driven safely and possibly cause an accident.

- Do not use the sensor at speeds in excess of 6 mph (10 km/h).
- The sensors' detection areas and reaction times are limited. When moving forward or reversing, check the areas surrounding the vehicle (especially the sides of the vehicle) for safety, and drive slowly, using the brake to control the vehicle's speed.
- Do not install accessories within the sensors' detection areas.

🔨 NOTICE

#### When using intuitive parking assist

In the following situations, the system may not function correctly due to a sensor malfunction etc. Have the vehicle checked by your Lexus dealer.

- The intuitive parking assist operation display flashes, and a beep sounds when no obstacles are detected.
- If the area around a sensor collides with something, or is subjected to strong impact.
- If the bumper or grille collides with something.
- If the display shows continuously without beeping, except when the buzzer mute switch has been turned on.
- If a display error occurs, first check the sensor.
   If the error occurs even when there is no ice, snow or mud on the sensor, it is likely that the sensor is malfunctioning.

#### Notes when washing the vehicle

Do not apply intensive bursts of water or steam to the sensor area.

Doing so may result in the sensor malfunctioning.


# Rear view monitor system

The rear view monitor system assists the driver by displaying guide lines and an image of the view behind the vehicle while backing up, for example while parking.

The screen illustrations used in this text are intended as examples, and may differ from the image that is actually displayed on the screen.

The rear view image is displayed when the shift position is in R and the engine switch is in IGNITION ON mode.

The rear view monitor system will be deactivated when the shift lever is in any position other than R.




#### \*: If equipped

## Using the rear view monitor system

## Screen description

The rear view monitor system screen will be displayed if the shift lever is shifted to R while the engine switch is in IGNITION ON mode.



1 Vehicle width guide lines

The line indicates a guide path when the vehicle is being backed straight up. The displayed width is wider than the actual vehicle width.

2 Vehicle center guide lines

These lines indicate the estimated vehicle center on the ground.

③ Distance guide line

The line shows points approximately 1.5 ft. (0.5 m) (red) from the center of the edge of the bumper.

4 Distance guide line

The line shows distance behind the vehicle, a point approximately 3 ft. (1 m) (blue) from the edge of the bumper.


## Rear view monitor system precautions

# Area displayed on screen

The rear view monitor system displays an image of the view from the bumper of the rear area of the vehicle.

To adjust the image on the rear view monitor system screen.  $(\rightarrow P. 272)$ 

- The area displayed on the screen may vary according to vehicle orientation conditions.
- Objects which are close to either corner of the bumper or under the bumper cannot be seen on the screen.
- The camera uses a special lens. The distance of the image that appears on the screen differs from the actual distance.
- Items which are located higher than the camera may not be displayed by the monitor.



223

#### Rear view monitor system camera

The camera for the rear view monitor system is located above the license plate.



#### • Using the camera

If the camera lens becomes dirty, it cannot transmit a clear image. If water droplets, snow or mud adhere to the lens, rinse it with water and wipe with a soft cloth. If the lens is extremely dirty, wash it with a mild cleanser and rinse.

# Differences between the screen and the actual road

The distance guide lines and the vehicle width guide lines may not actually be parallel with the dividing lines of the parking space, even when they appear to be so. Be sure to check visually.

The distances between the vehicle width guide lines and the left and right dividing lines of the parking space may not be equal, even when they appear to be so. Be sure to check visually.

The distance guide lines give a distance guide for flat road surfaces. In any of the following situations, there is a margin of error between the fixed guide lines on the screen and the actual distance/course on the road.

#### IS350/250\_U (OM53758U)

The distance guide lines will appear to be closer to the vehicle than the actual distance. Because of this, objects will appear to be farther away than they actually are. In the




• When the ground behind the vehicle slopes down sharply

• When the ground behind the vehicle slopes up sharply

The distance guide lines will appear to be further from the vehicle than the actual distance. Because of this, objects will appear to be closer than they actually are. In the same way, there will be a margin of error between the guidelines and the actual distance/course on the road.

same way, there will be a margin of error between the guidelines and the actual distance/course on the




225

45AZ099

• When any part of the vehicle sags

When any part of the vehicle sags due to the number of passengers or the distribution of the load, there is a margin of error between the fixed guide lines on the screen and the actual distance/course on the road.




# When approaching three-dimensional objects

The distance guide lines are displayed according to flat surfaced objects (such as the road). It is not possible to determine the position of three-dimensional objects (such as vehicles) using the distance guide lines. When approaching a three-dimensional object that extends outward (such as the flatbed of a truck), be careful of the following.

Distance guidelines


Visually check the surroundings and the area behind the vehicle. On the screen, it appears that a truck is parked at point (2). However, in reality if you back up to point (1), you will hit the truck. On the screen, it appears that (1) is closest and (3) is furthest away. However, in reality, the distance to (1) and (3) is the same, and (2) is farther than (1) and (3).



# Vehicle width guide lines

Visually check the surroundings and the area behind the vehicle. In the case shown below, the truck appears to be outside of the vehicle width guide lines and the vehicle does not look as if it hits the truck. However, the rear body of the truck may actually cross over the vehicle width guide lines. In reality if you back up as guided by the vehicle width guide lines, the vehicle may hit the truck.

Vehicle width guide lines



# Things you should know

# If you notice any symptoms

If you notice any of the following symptoms, refer to the likely cause and the solution, and re-check.

If the symptom is not resolved by the solution, have the vehicle inspected by your Lexus dealer.

Likely cause	Solution			
The image is difficult to see				
<ul> <li>The vehicle is in a dark area</li> <li>The temperature around the lens is either high or low</li> <li>The outside temperature is low</li> <li>There are water droplets on the camera</li> <li>It is raining or humid</li> <li>Foreign matter (mud etc.) is adhering to the camera</li> <li>There are scratches on the camera</li> <li>Sunlight or headlights are shining directly into the camera</li> <li>The vehicle is under fluorescent lights, sodium lights, mercury lights etc.</li> </ul>	If this happens due to these causes, it does not indicate a malfunction. Back up while visually checking the vehi- cle's surroundings. (Use the monitor again once conditions have been improved.) To adjust the image on the rear view mon- itor system screen. (→P. 272)			
The image is blurry				
Dirt or foreign matter (such as water droplets, snow, mud etc.) is adhering to the camera.	Rinse the camera lens with water and wipe it clean with a soft cloth. Wash with a mild soap if the dirt is stub- born.			
The image is out of alignment				
The camera or surrounding area has received a strong impact.	Have the vehicle inspected by your Lexus dealer.			
The fixed guide lines are very far out of alignment				
<ul> <li>The vehicle is tilted (there is a heavy load on the vehicle, tire pressure is low due to a tire puncture, etc.)</li> <li>The vehicle is used on an incline.</li> </ul>	If this happens due to these causes, it does not indicate a malfunction. Back up while visually checking the vehicle's sur- roundings.			
The camera position is out of alignment.	Have the vehicle inspected by your Lexus dealer.			

# 

#### When using the rear view monitor system

The rear view monitor system is a supplemental device intended to assist the driver when backing up. When backing up, be sure to check visually behind and all around the vehicle before proceeding.

Observe the following precautions to avoid an accident that could result in death or serious injuries.

- Never depend on the rear view monitor system entirely when backing up. The image and the position of the guide lines displayed on the screen may differ from the actual state.
  - Use caution, just as you would when backing up any vehicle.
- Be sure to back up slowly, depressing the brake pedal to control vehicle speed.
- The instructions given are only guidelines. When and how much to turn the steering wheel will vary according to traffic conditions, road surface conditions, vehicle condition, etc. when parking. It is necessary to be fully aware of this before using the rear view monitor system.
- When parking, be sure to check that the parking space will accommodate your vehicle before maneuvering into it.
- Do not use the rear view monitor system in the following cases:
  - On icy or slick road surfaces, or in snow
  - When using tire chains or the compact spare tire
  - When the trunk lid is not closed completely
  - On roads that are not flat or straight, such as curves or slopes.

 In low temperatures, the screen may darken or the image may become faint. The image could distort when the vehicle is moving, or you may become unable to see the image on the screen. Be sure to check direct visually and with the mirrors all around the vehicle before proceeding.

- If the tire sizes are changed, the position of the fixed guide lines displayed on the screen may change.
- The camera uses a special lens. The distances between objects and pedestrians that appear in the image displayed on the screen will differ from the actual distances.
   (->P. 224)

Driving

# NOTICE


#### How to use the camera

- The rear view monitor system may not operate properly in the following cases.
  - If the back of the vehicle is hit, the position and mounting angle of the camera may change.
  - As the camera has a water proof construction, do not detach, disassemble or modify it. This may cause incorrect operation.
  - Do not strongly rub the camera lens. If the camera lens is scratched, it cannot transmit a clear image.
  - Do not allow organic solvent, car wax, window cleaner or glass coat to adhere to the camera. If this happens, wipe it off as soon as possible.
  - If the temperature changes rapidly, such as when hot water is poured on the vehicle in cold weather, the system may not operate normally.
  - When washing the vehicle, do not apply intensive bursts of water to the camera or camera area. Doing so may result in the camera malfunctioning.
  - When the camera is used under fluorescent lights, sodium light or mercury light etc., the lights and the illuminated areas may appear to flicker.
- Do not expose the camera to strong impact as this could cause a malfunction. If this happens, have the vehicle inspected by your Lexus dealer as soon as possible.

# Driving mode select switch

The driving modes can be selected to suit driving condition.

Vehicles without Adaptive Variable Suspension System



For normal driving.

Press the switch to change the driving mode to normal mode when selected to Eco drive mode or sport mode.

2 Eco drive mode

Use Eco drive mode to help achieve low fuel consumption during trips that involve frequent accelerating.

When not in Eco drive mode and the driving mode select switch is turned to the left, the Eco drive mode indicator comes on.

③ Sport mode

Assists acceleration response by controlling the transmission and steering. Suitable for when precise handling is desirable, for example when driving on mountain roads.

When not in sport mode and the driving mode select switch is turned to the right, the "SPORT" indicator comes on.

231

- Except F SPORT F SPORT models models ECCO ECCO MORE SORT S SORT S SORT S SORT S
- Vehicles with Adaptive Variable Suspension System

## Normal mode

For normal driving.

Press the switch to change the driving mode to normal mode when selected to Eco drive mode or sport mode.

2 Eco drive mode

Use Eco drive mode to help achieve low fuel consumption during trips that involve frequent accelerating.

When not in Eco drive mode and the driving mode select switch is turned to the left, the Eco drive mode indicator comes on.

- 3 Sport mode
  - SPORT S mode

Assists acceleration response by controlling the transmission and the engine. Suitable for when powerful acceleration is desirable.

When not in SPORT S mode and the driving mode select switch is turned to the right, the "SPORT S" indicator comes on.

SPORT S+ mode

Helps to ensure steering performance and driving stability by simultaneously controlling the steering and suspension in addition to the transmission. Suitable for sporty driving.

When in SPORT S mode and the driving mode select switch is turned to the right, the "SPORT S+" indicator comes on.

# Operation of the air conditioning system in Eco drive mode

Eco drive mode controls the heating/cooling operations and fan speed of the air conditioning system to enhance fuel efficiency ( $\rightarrow$ P. 346). To improve air conditioning performance, adjust the fan speed or turn off Eco drive mode.

#### Sport mode automatic deactivation

Sport mode is automatically deactivated if the engine switch is turned off after driving in sport mode.

IS350/250\_U (OM53758U)

# Driving assist systems

To help enhance driving safety and performance, the following systems operate automatically in response to various driving situations. Be aware, however, that these systems are supplementary and should not be relied upon too heavily when operating the vehicle.

#### ABS (Anti-lock Brake System)

Helps to prevent wheel lock when the brakes are applied suddenly, or if the brakes are applied while driving on a slippery road surface

## Brake assist

Generates an increased level of braking force after the brake pedal is depressed when the system detects a panic stop situation

## VSC (Vehicle Stability Control)

Helps the driver to control skidding when swerving suddenly or turning on slippery road surfaces

# Enhanced VSC (Enhanced Vehicle Stability Control)

Provides cooperative control of the ABS, TRAC, VSC and EPS. Helps to maintain directional stability when swerving on slippery road surfaces by controlling steering performance.

# TRAC (Traction Control)

Helps to maintain drive power and prevent the drive wheels from spinning when starting the vehicle or accelerating on slippery roads

#### Hill-start assist control

Prevents the vehicle from rolling backward when starting on an incline or slippery slope

# VGRS (Variable Gear Ratio Steering) (if equipped)

Adjusts the front wheel turning angle in accordance with the vehicle speed and steering wheel movement EPS (Electric Power Steering)

Employs an electric motor to reduce the amount of effort needed to turn the steering wheel

Adaptive Variable Suspension system (if equipped)

By independently controlling the damping force of the shock absorbers for each of the 4 wheels according to the road and driving conditions, this system combines riding comfort with superior steering stability, and helps good vehicle posture. ( $\rightarrow$ P. 232)

# VDIM (Vehicle Dynamics Integrated Management)


Provides integrated control of the ABS, brake assist, TRAC, VSC, hill-start assist control, EPS and VGRS (if equipped) systems

Helps to maintain vehicle stability when swerving on slippery road surfaces by controlling the brakes, engine output, steering assist, and if equipped with VGRS, steering ratio

- PCS (Pre-Collision System) (if equipped)
  - $\rightarrow$ P. 240
- BSM (Blind Spot Monitor) (if equipped)
  - →P. 246

# When the TRAC/VSC systems are operating

The slip indicator light will flash while the TRAC/VSC systems are operating.



Driving

# Disabling the TRAC/VSC systems

If the vehicle gets stuck in fresh snow or mud, the TRAC and VSC systems may reduce power from the engine to the wheels. Pressing VSC OFF switch to turn the system off may make it easier for you to rock the vehicle in order to free it.

# ■ Turning off the TRAC system only

To turn the TRAC system off, quickly press and release the switch.

The "TRAC OFF" will be shown on the multi-information display. Press the switch again to turn the system back on.




# Turning off both TRAC/VSC systems

To turn the TRAC and VSC systems off, press and hold the switch for more than 3 seconds while the vehicle is stopped.

The VSC OFF indicator light will come on and the "TRAC OFF" will be shown on the multi-information display.

Press the switch again to turn the systems back on.



\*: On vehicles with pre-collision system, pre-collision brake assist and pre-collision braking will also be disabled. The pre-collision system warning light will come on and the message will be shown on the multi-information display. (→P. 240)

#### VGRS is disabled when

VGRS may stop operating in the following situations.

In this event, the steering wheel may move from its straight forward position, but it will return when the system restarts.

- When the steering wheel is operated for an extended period of time while the vehicle is stopped or is moving very slowly
- When the steering wheel has been held fully to the left or right

The center position of the steering wheel may change when VGRS is disabled. However, the position will return to normal after VGRS is reactivated.

#### When the battery is disconnected

The steering wheel may move from its straight forward position, but this will be corrected automatically when driving.

- Sounds and vibrations caused by the ABS, brake assist, VSC, TRAC, hill-start assist control and VGRS systems
  - A sound may be heard from the engine compartment when the brake pedal is depressed repeatedly, when the engine is started or just after the vehicle begins to move. This sound does not indicate that a malfunction has occurred in any of these systems.
  - Any of the following conditions may occur when the above systems are operating. None of these indicates that a malfunction has occurred.
    - Vibrations may be felt through the vehicle body and steering.
    - A motor sound may be heard after the vehicle comes to a stop.
    - The brake pedal may pulsate slightly after the ABS is activated.
    - The brake pedal may move down slightly after the ABS is activated.

#### EPS and VGRS operation sound

When the steering wheel is operated, a motor sound may be heard. This does not indicate a malfunction.

#### Reactivation of the TRAC/VSC systems

Even after the TRAC/VSC systems have been turned off, turning the engine off and then on again will automatically reactivate the TRAC/VSC systems.

#### Reactivation of the TRAC system linked to vehicle speed

When only the TRAC system is turned off, the TRAC system will turn on when vehicle speed increases. However, when both TRAC/VSC systems are turned off, the systems will not turn on even when vehicle speed increases.

## Reduced effectiveness of the EPS system

The effectiveness of the EPS system is reduced to prevent the system from overheating when there is frequent steering input over an extended period of time. The steering wheel may feel heavy as a result. Should this occur, refrain from excessive steering input or stop the vehicle and turn the engine off. The EPS system should return to normal within 10 minutes.

## Operating conditions of hill-start assist control

When the following four conditions are met, the hill-start assist control will operate:

- The shift lever is in a position other than P or N (when starting off forward/backward on an upward incline).
- The vehicle is stopped.
- The accelerator pedal is not depressed.
- The parking brake is not engaged.

#### Automatic system cancelation of hill-start assist control

The hill-start assist control will turn off in any of the following situations:

- The shift lever is moved to P or N.
- The accelerator pedal is depressed.
- The parking brake is engaged.
- Approximately 2 seconds elapse after the brake pedal is released.

# CAUTION The ABS does not operate effectively when • The limits of tire gripping performance have been exceeded (such as excessively worn tires on a snow covered road). The vehicle hydroplanes while driving at high speed on wet or slick roads. Stopping distance when the ABS is operating may exceed that of normal conditions The ABS is not designed to shorten the vehicle's stopping distance. Always maintain a safe distance from the vehicle in front of you, especially in the following situations: • When driving on dirt, gravel or snow-covered roads When driving with tire chains • When driving over bumps in the road When driving over roads with potholes or uneven surfaces TRAC may not operate effectively when Directional control and power may not be achievable while driving on slippery road surfaces, even if the TRAC system is operating. Drive the vehicle carefully in conditions where stability and power may be lost. Hill- start assist control does not operate effectively when • Do not overly rely on hill-start assist control. Hill-start assist control may not operate effectively on steep inclines and roads covered with ice. • Unlike the parking brake, hill-start assist control is not intended to hold the vehicle stationary for an extended period of time. Do not attempt to use hill-start assist control to hold the vehicle on an incline, as doing so may lead to an accident. When the VSC is activated The slip indicator light flashes. Always drive carefully. Reckless driving may cause an accident. Exercise particular care when the indicator light flashes. When the TRAC/VSC systems are turned off Be especially careful and drive at a speed appropriate to the road conditions. As these are the systems to ensure vehicle stability and driving force, do not turn the TRAC/ VSC systems off unless necessary. Replacing tires Make sure that all tires are of the specified size, brand, tread pattern and total load capacity. In addition, make sure that the tires are inflated to the recommended tire inflation pressure level. The ABS, TRAC and VSC systems will not function correctly if different tires are installed on the vehicle.

Contact your Lexus dealer for further information when replacing tires or wheels.

#### Handling of tires and the suspension

Using tires with any kind of problem or modifying the suspension will affect the driving assist systems, and may cause a system to malfunction.

## 239

Driving


# PCS (Pre-Collision System)\*

When the radar sensor detects the possibility of a frontal collision, brakes are automatically engaged to lessen impact as well as vehicle damage.

The pre-collision system can be turned on and off as necessary by operating the switch. ( $\rightarrow$ P. 241)

# Pre-collision warning

When a high possibility of a frontal collision is detected, the pre-collision system warning light flashes, a buzzer sounds and a message is shown on the multi-information display to urge the driver to take evasive action.



#### Pre-collision brake assist

When there is a high possibility of a frontal collision, the system applies greater braking force in relation to how strongly the brake pedal is depressed. The system may not warn the driver using a warning light, warning display and buzzer when the system detects and judges braking operations.

# Pre-collision braking

When there is a high possibility of a frontal collision, the system warns the driver using a warning light, warning display and buzzer. If the system determines that a collision is unavoidable, the brakes are automatically applied to reduce the collision speed.

#### Suspension control (vehicles with Adaptive Variable Suspension System)


When the system determines that there is a high possibility of a frontal collision, the operation of Adaptive Variable Suspension System ( $\rightarrow$ P. 235) optimally controls the damping force of the shock absorber.

\*: If equipped

# Disabling pre-collision system

- 1 Enabled
- Disabled


The pre-collision system warning light comes on when pre-collision system is disabled.



# 4 Driving

# Radar sensor

The radar sensor detects vehicles or other obstacles on or near the road ahead and determines whether a collision is imminent based on the position, speed, and heading of the obstacles.



#### The pre-collision system is operational when

The PCS OFF switch is not pressed and the following conditions are met:

- Pre-collision warning:
  - Vehicle speed is greater than about 10 mph (15 km/h).
  - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 10 mph (15 km/h).
- Pre-collision brake assist:
  - The VSC OFF switch is not pressed.
  - Vehicle speed is greater than about 19 mph (30 km/h).
  - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 19 mph (30 km/h).
  - The brake pedal is depressed.
- Pre-collision braking:
  - The VSC OFF switch is not pressed.
  - Vehicle speed is greater than about 10 mph (15 km/h).
  - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 10 mph (15 km/h).
- Suspension control (vehicles with Adaptive Variable Suspension System):
  - Vehicle speed is greater than about 4 mph (5 km/h).
  - The speed at which your vehicle is approaching the obstacle or the vehicle running ahead of you is greater than about 19 mph (30 km/h).

## Conditions that may trigger the system even if there is no danger of a collision

- When there is an object by the roadside at the entrance to a curve
- When passing an oncoming vehicle on a curve
- When driving over a narrow iron bridge
- When there is a metal object on the road surface
- When driving on an uneven road surface
- When passing an oncoming vehicle on a left-turn
- When your vehicle rapidly closes on the vehicle in front
- When a grade separation/interchange, sign, billboard, or other structure appears to be directly in the vehicle's line of travel
- When there is a metal plate in the road in front of the vehicle on a downhill slope
- When climbing a steep hill causes an overhead billboard or other metallic structure to appear directly in the vehicle's line of travel
- When driving under an overpass
- When an extreme change in vehicle height occurs
- When passing through certain toll gates
- When passing through a tunnel
- When the radar sensor moves off position due to its surrounding area being subjected to a strong impact

When the system is activated in the situations described above, there is also a possibility that the brakes will be applied with a force greater than normal.

#### Obstacles not detected

The sensor cannot detect plastic obstacles such as traffic cones. There may also be occasions when the sensor cannot detect pedestrians, animals, bicycles, motorcycles, trees, or snowdrifts.

#### Situations in which the pre-collision system does not function properly

The system may not function effectively in situations such as the following:

- On roads with sharp bends or uneven surfaces
- If a vehicle suddenly moves in front of your vehicle, such as at an intersection
- If a vehicle suddenly cuts in front of your vehicle, such as when overtaking
- In inclement weather such as heavy rain, fog, snow or sand storms
- If the vehicle is skidding when VSC is not operating
- When an extreme change in vehicle height occurs
- When only part of your vehicle's front end collides with, or contacts, a vehicle or object in a frontal collision
- When the radar sensor moves off position due to its surrounding area being subjected to a strong impact

## Automatic cancelation of the pre-collision system

When a malfunction occurs due to sensor contamination, etc. that results in the sensors being unable to detect obstacles, the pre-collision system will be automatically disabled. In this case, the system will not activate even if there is a collision possibility.

# When there is a malfunction in the system

The pre-collision system warning light will flash and warning messages will be displayed. ( $\rightarrow$ P. 456, 465)

4 Driving

## Certification

► For vehicles sold in the U.S.A.

FCC ID: BABFT0041A

CAUTION: Radio Frequency Radiation Exposure

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment.

This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body (excluding extremities: hands, wrists, feet and ankles).

Co-location: This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

▶ For vehicles sold in Canada

IC: 2024B-FT0041A

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

## **CAUTION** Limitations of the pre-collision system Do not overly rely on the pre-collision system. Always drive safely, taking care to observe your surroundings and checking for any obstacles or other road hazards. Failure to do so may cause an accident resulting in death or serious injury. Handling the radar sensor Observe the following to ensure the pre-collision system can function effectively. Otherwise, the system may not function correctly and could result in an accident. Keep the sensor and grille cover clean at all times. Clean the sensor and grille cover with a soft cloth so you do not mark or damage them. Do not subject the sensor or surrounding area to a strong impact. If the sensor moves even slightly off position, the system may malfunction. If the sensor or surrounding area is subject to a strong impact, always have the area inspected and adjusted by your Lexus dealer. Do not disassemble the sensor. • Do not attach accessories or stickers to the sensor, grille cover or surrounding area. • Do not modify or paint the sensor and grille cover. Do not replace them with non-genuine parts. Cautions regarding the assist contents of the system By means of alarms and brake control, the pre-collision system is intended to assist the driver in avoiding collisions through the process of LOOK-JUDGE-ACT. There are limits to the degree of assistance the system can provide, so please keep in mind the following important points. • Assisting the driver in watching the road The pre-collision system is only able to detect obstacles directly in front of the vehicle, and only within a limited range. It is not a mechanism that allows careless or inattentive driving, and it is not a system that can assist the driver in low-visibility conditions. It is still necessary for the driver to pay close attention to the vehicle's surroundings. Assisting the driver in making correct judgment When attempting to estimate the possibility of a collision, the only data available to the pre-collision system is that from obstacles it has detected directly in front of the vehicle. Therefore, it is absolutely necessary for the driver to remain vigilant and to determine whether or not there is a possibility of collision in any given situation. • Assisting the driver in taking action The pre-collision system's braking assist feature is designed to help reduce the severity of a collision, and so only acts when the system has judged that a collision is unavoidable. This system by itself is not capable of automatically avoiding a collision or bringing the vehicle to a stop safely. For this reason, when encountering a dangerous situation the driver must take direct and immediate action in order to ensure the safety of all involved.

Driving

# BSM (Blind Spot Monitor)

# Summary of the Blind Spot Monitor


The Blind Spot Monitor is a system that has 2 functions;

The Blind Spot Monitor function

Assists the driver in making the decision when changing lanes

• The Rear Cross Traffic Alert function Assists the driver when backing up

These functions use same sensors.



## 1 BSM main switch

Pressing the switch turns the system on or off. When the switch is set to on, the switch's indicator illuminates and the buzzer sounds. Common switch for Blind Spot Monitor function and Rear Cross Traffic Alert function.

2 Outside rear view mirror indicators

#### Blind Spot Monitor function:

When a vehicle is detected in the blind spot, the outside rear view mirror indicator comes on while the turn signal lever is not operated and the outside rear view mirror indicator flashes while the turn signal lever is operated.

#### Rear Cross Traffic Alert function:

When a vehicle approaching from the right or left rear of the vehicle is detected, the outside rear view mirror indicators flash.

③ Rear Cross Traffic Alert buzzer (Rear Cross Traffic Alert function only)

When a vehicle approaching from the right or left rear of the vehicle is detected, a buzzer sounds from behind the rear seat.

\*: If equipped

#### The outside rear view mirror indicators visibility

When under strong sunlight, the outside rear view mirror indicator may be difficult to see.

#### Rear Cross Traffic Alert buzzer hearing

Rear Cross Traffic Alert function may be difficult to hear over loud noises such as high audio volume.

#### When there is a malfunction in the Blind Spot Monitor

If a system malfunction is detected due to any of the following reasons, warning messages will be displayed: (  $\to\!P\!.\,465)$ 

- There is a malfunction with the sensors
- The sensors have become dirty
- The outside temperature is extremely high or low
- The sensor voltage has become abnormal

#### Certification for the Blind Spot Monitor

► For vehicles sold in the U.S.A.

#### FCC ID: OAYSRR2A

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Warning

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


## ▶ For vehicles sold in Canada

Applicable law : Canada 310

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Frequency bands : 24.05 - 24.25GHz

Output power : less than 20 milliwatts



# The Blind Spot Monitor function

The Blind Spot Monitor function uses radar sensors to detect vehicles that are traveling in an adjacent lane in the area that is not reflected in the outside rear view mirror (the blind spot), and advises the driver of the vehicles existence via the outside rear view mirror indicator.

# The Blind Spot Monitor function detection areas


The areas that vehicles can be detected in are outlined below.

The range of the detection area extends to:

(1) Approximately 11.5 ft. (3.5 m) from the side of the vehicle

The first 1.6 ft. (0.5 m) from the side of the vehicle is not in the detection area

- 2 Approximately 9.8 ft. (3 m) from the rear bumper
- ③ Approximately 3.3 ft. (1 m) forward of the rear bumper



# **CAUTION**

#### Cautions regarding the use of the system

The driver is solely responsible for safe driving. Always drive safely, taking care to observe your surroundings.

The Blind Spot Monitor function is a supplementary function which alerts the driver that a vehicle is present in the blind spot. Do not overly rely on the Blind Spot Monitor function. The function cannot judge if it is safe to change lanes, therefore over reliance could cause an accident resulting in death or serious injury.

According to conditions, the system may not function correctly. Therefore the driver's own visual confirmation of safety is necessary.


- The Blind Spot Monitor function is operational when
  - The BSM main switch is set to on
  - Vehicle speed is greater than approximately 10 mph (16 km/h).
- The Blind Spot Monitor function will detect a vehicle when
  - A vehicle in an adjacent lane overtakes your vehicle.
  - Another vehicle enters the detection area when it changes lanes.
- Conditions under which the Blind Spot Monitor function will not detect a vehicle The Blind Spot Monitor function is not designed to detect the following types of vehicles and/or objects:
  - Small motorcycles, bicycles, pedestrians etc.\*
  - Vehicles traveling in the opposite direction
  - Guardrails, walls, signs, parked vehicles and similar stationary objects<sup>\*</sup>
  - Following vehicles that are in the same lane\*
  - Vehicles driving 2 lanes across from your vehicle\*
  - \*: Depending on conditions, detection of a vehicle and/or object may occur.

#### Conditions under which the Blind Spot Monitor function may not function correctly

- The Blind Spot Monitor function may not detect vehicles correctly in the following conditions:
  - During bad weather such as heavy rain, fog, snow etc.
  - When ice or mud etc. is attached to the rear bumper
  - When driving on a road surface that is wet due to rain, standing water etc.
  - When there is a significant difference in speed between your vehicle and the vehicle that enters the detection area
  - When a vehicle is in the detection area from a stop and remains in the detection area as your vehicle accelerates
  - When driving up or down consecutive steep inclines, such as hills, a dip in the road etc.
  - · When multiple vehicles approach with only a small gap between each vehicle
  - When vehicle lanes are wide, and the vehicle in the next lane is too far away from your vehicle
  - When the vehicle that enters the detection area is traveling at about the same speed as your vehicle
  - When there is a significant difference in height between your vehicle and the vehicle that enters the detection area
  - Directly after the BSM main switch is set to on
- Instances of the Blind Spot Monitor function unnecessarily detecting a vehicle and/or object may increase under the following conditions:
  - When there is only a short distance between your vehicle and a guardrail, wall etc.
  - · When there is only a short distance between your vehicle and a following vehicle
  - When vehicle lanes are narrow and a vehicle driving 2 lanes across from your vehicle enters the detection area
  - When items such as a bicycle carrier are installed on the rear of the vehicle

# The Rear Cross Traffic Alert function

The Rear Cross Traffic Alert functions when your vehicle is in reverse. It can detect other vehicles approaching from the right or left rear of the vehicle. It uses radar sensors to alert the driver of the other vehicle's existence through flashing the outside rear view mirror indicators and sounding a buzzer.




According to conditions, the system may not function correctly. Therefore the driver's own visual confirmation of safety is necessary.

# 251

# **252** 4-5. Using the driving support systems

#### The Rear Cross Traffic Alert function detection areas

The areas that vehicles can be detected in are outlined below.



To give the driver a more consistent time to react, the buzzer can alert for faster vehicles from farther away.

Example:

Approaching vehicle	Speed	1 Approximate alert distance
Fast	18 mph (28 km/h)	65 ft. (20 m)
Slow	5 mph (8 km/h)	18 ft. (5.5 m)

#### The Rear Cross Traffic Alert function is operational when


- The BSM main switch is set to on.
- The shift lever is in R.
- Vehicle speed is less than approximately 5 mph (8 km/h).
- Approaching vehicle speed is between approximately 5 mph (8 km/h) and 18 mph (28 km/h).

4-5. Using the driving support systems

- Conditions under which the Rear Cross Traffic Alert function will not detect a vehicle The Rear Cross Traffic Alert function is not designed to detect the following types of vehicles and/or objects.
  - Small motorcycles, bicycles, pedestrians etc.\*
  - Vehicles approaching from directly behind
  - Guardrails, walls, signs, parked vehicles and similar stationary objects<sup>\*</sup>
  - Vehicles moving away from your vehicle
  - Vehicles approaching from the parking spaces next to your vehicle\*
  - Vehicles backing up in the parking space next to your vehicle
  - \*: Depending on conditions, detection of a vehicle and/or object may occur.
- Conditions under which the Rear Cross Traffic Alert function may not function correctly

The Rear Cross Traffic Alert function may not detect vehicles correctly in the following conditions:

- During bad weather such as heavy rain, fog, snow etc.
- When ice or mud etc. is attached to the rear bumper
- When multiple vehicles approach continuously
- Shallow angle parking
- When a vehicle is approaching at high speed
- When parking on a steep incline, such as hills, a dip in the road etc.
- Directly after the BSM main switch is set to on
- Directly after the engine is started with the BSM main switch on
- Vehicles that the sensors cannot detect because of obstacles



4 Driving

# Winter driving tips

Carry out the necessary preparations and inspections before driving the vehicle in winter. Always drive the vehicle in a manner appropriate to the prevailing weather conditions.

#### Preparation for winter

- Use fluids that are appropriate to the prevailing outside temperatures.
  - Engine oil
  - Engine coolant
  - Washer fluid
- Have a service technician inspect the condition of the battery.
- Have the vehicle fitted with four snow tires or purchase a set of tire chains for the rear tires.\*

Ensure that all tires are the specified size and brand, and that chains match the size of the tires.

\*: Tire chains cannot be mounted on the 18-inch tires.

#### Before driving the vehicle

Perform the following according to the driving conditions:

- Do not try to forcibly open a window or move a wiper that is frozen. Pour warm water over the frozen area to melt the ice. Wipe away the water immediately to prevent it from freezing.
- To ensure proper operation of the climate control system fan, remove any snow that has accumulated on the air inlet vents in front of the windshield.
- Check for and remove any excess ice or snow that may have accumulated on the exterior lights, vehicle's roof, chassis, around the tires or on the brakes.
- Remove any snow or mud from the bottom of your shoes before getting in the vehicle.

#### When driving the vehicle

Accelerate the vehicle slowly, keep a safe distance between you and the vehicle ahead, and drive at a reduced speed suitable to road conditions.

#### When parking the vehicle


Park the vehicle and move the shift lever to P without setting the parking brake. The parking brake may freeze up, preventing it from being released. If necessary, block the wheels to prevent inadvertent sliding or creeping.

#### Selecting tire chains

► Except vehicles with 18-inch tires

Use the correct tire chain size when mounting the tire chains. Chain size is regulated for each tire size.

- 1) Side chain (0.12 in. [3 mm] in diameter)
- (2) Cross chain (0.16 in. [4 mm] in diameter)



Vehicles with 18-inch tires

Tire chains cannot be mounted.

Snow tires should be used instead.

#### Regulations on the use of tire chains

Regulations regarding the use of tire chains vary depending on location and type of road. Always check local regulations before installing chains.

#### Tire chain installation

- Observe the following precautions when installing and removing chains:
- Install and remove tire chains in a safe location.
- Install tire chains on the rear tires. Do not install tire chains on the front tires.
- Install tire chains on rear tires as tightly as possible. Retighten chains after driving 1/4 —1/2 mile (0.5 — 1.0 km).
- Install tire chains following the instructions provided with the tire chains.

#### 

#### Driving with snow tires

Observe the following precautions to reduce the risk of accidents.

- Failure to do so may result in a loss of vehicle control and cause death or serious injury.
- Use tires of the specified size.
- Maintain the recommended level of air pressure.
- Do not drive in excess of 75 mph (120 km/h), regardless of the type of snow tires being used.
- Use snow tires on all, not just some wheels.

#### Driving with tire chains (except vehicles with 18-inch tires)

Observe the following precautions to reduce the risk of accidents. Failure to do so may result in the vehicle being unable to be driven safely, and may cause death or serious injury.

- Do not drive in excess of the speed limit specified for the tire chains being used, or 30 mph (50 km/h), whichever is lower.
- Avoid driving on bumpy road surfaces or over potholes.
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.
- Slow down sufficiently before entering a curve to ensure that vehicle control is maintained.
- Do not use LDA (Lane Departure Alert) system.

#### **NOTICE**

#### Repairing or replacing snow tires

Request repairs or replacement of snow tires from Lexus dealers or legitimate tire retailers.

This is because the removal and attachment of snow tires affects the operation of the tire pressure warning valves and transmitters.

#### Fitting tire chains (except vehicles with 18-inch tires)

The tire pressure warning valves and transmitters may not function correctly when tire chains are fitted.

4-6. Driving tips **257** 



# 258

# 5-1. Basic Operations

	Lexus Display Audio	
	System	260
	Steering wheel audio	
	switches	265
	USB/AUX ports	266
5-2.	Setup	
	Setup menu	267
	General settings	268
	Voice settings	271
	Display settings	272
5-3.	Using the audio system	
	Selecting the audio source	273
	Optimal use of the audio	
	system	274
	Audio settings	275
	Audio menu screen	
	operation	278
5-4.	Using the radio	
	Radio operation	281
5-5.	Playing an audio CD and MP3/WMA/AAC discs	
	CD player operation	287

# Lexus Display Audio system

5-6.	Using an external device	
	Listening to an iPod	293
	Listening USB memory device	296
	Using the AUX port	.300
5-7.	$ConnectingBluetooth^{\mathbb{R}}$	
	Steps for using Bluetooth <sup>®</sup> devices	301
	Registering a Bluetooth <sup>®</sup> device	. 303
	Selecting a Bluetooth <sup>®</sup> device	.304
	Connecting a Bluetooth <sup>®</sup> audio player	.305
	Connecting a Bluetooth <sup>®</sup> phone	.306
	Displaying a Bluetooth <sup>®</sup> device details	307
	Detailed Bluetooth <sup>®</sup> settings	.308
5-8.	Bluetooth <sup>®</sup> Audio	
	Listening to Bluetooth <sup>®</sup> Audio	.309

5	
$\mathcal{I}$	

5-9.	Bluetooth <sup>®</sup> Phone	
	Using a Bluetooth <sup>®</sup> Phone	311
	Making a call	313
	Receiving a call	316
	Speaking on the phone	317
	Using a Bluetooth $^{\mathbb{R}}$	
	phone message	319
	Using the steering wheel switches	321
	Bluetooth <sup>®</sup> phone settings	322
5-10	Phonebook	
	Contact settings	324
	Messaging setting	327
5-11.	Bluetooth®	
	What to do if (Troubleshooting) Bluetooth <sup>®</sup>	
5-12.	Other function	
	"Information" screen	337
	USB photo	338
	Weather information	340


# 

# 260 5-1. Basic Operations

# Lexus Display Audio System<sup>\*</sup>

Use the following buttons to start listening to the audio system.

#### **Display Audio operation buttons**



- 1 Eject a disc.
- ② Seek up or down for a radio station, or to access a desired track or file.
- ③ Except radio and A/V mode: Pause or resume playing a track. Radio and A/V mode: Turn mute on/off
- (4) Select a radio station band, track or file.
- 5 Disc slot
- 6 Display the media top screen.
- Display the radio top screen.
- 8 Press to turn the audio system on/off, and turn to adjust the volume.

# "Menu" screen

To display the "Menu" screen, press the 🚾 button on the controller unit.



Button	Function	
"Radio"	Display the radio top screen ( $\rightarrow$ P. 281)	
"Media"	Display the media top screen ( $\rightarrow$ P. 287, 293, 296, 300)	
"Climate"	Automatic air conditioning system ( $\rightarrow$ P. 346)	
"Phone"	Display the phone top screen ( $\rightarrow$ P. 311)	
"Info"	Display the "Information" screen ( $\rightarrow$ P. 337)	
"Setup"	Setup menu (→P. 267)	
"Display"	Display settings ( $\rightarrow$ P. 272)	

Lexus Display Audio system

#### Lexus Display Audio controller

By using the Lexus Display Audio controller, you can control the audio system, hands-free system, etc.

- 1 Display the "Source" screen or audio top screen ( $\rightarrow$ P. 273)
- ② Display the "Menu" screen  $(\rightarrow P. 261)$
- ③ Display the previous screen
- 4 Turn or move the controller to select a function and number.

Move the controller to display the left or right side of screen.

Push the controller to enter the selected function and number.

# Using the Lexus Display Audio controller

- 1) Select: Turn or move the controller.
- (2) Enter: Push the controller.

#### Basic screen operation

When a list is displayed, use the appropriate button to scroll through the list.

- 1 Indicator turns on when you can select the list by turning the controller.
- (2) Indicator turns on when you can return to the previous screen by pressing the 📄 button.
- ③ Indicator turns on when you can move the controller left to view additional screen text.



④ Indicator turns on when you can move the controller right to view additional screen text.



#### Inputting letters and numbers

#### Input mode

Letters and numbers are inputted via the screen.

- Turn the controller to select the desired character and press the controller to input the character.
- When this indicator is shown, you can change input fields by moving the controller forward.
- 3 When this indicator is shown, you can change character types by moving the controller to the right and then selecting the desired character type.



- ④ Select to erase characters one by one. Select and hold to erase all characters.
- 5 Select to complete data input.

#### Input field mode

When in the input field you can move the cursor to the desired position.

- 1 Turn the controller to move the cursor left or right.
- When this indicator is shown, you can move the cursor to the right input field by moving the controller to the right.
- 3 When this indicator is shown, you can move the cursor to the left input field by moving the controller to the left.
- New Contact
- When this indicator is shown, you can change to input mode by moving the controller backward.

263

#### When using the screen

- Under extremely cold conditions, the Lexus Display Audio controller may react slowly.
- If the screen is cold, the display may be dark, or the system may seem to be operating slightly slower than normal.
- The screen may seem dark and hard to see when viewed through sunglasses. Change your angle of viewing, adjust the display on the "Display" screen (→P. 272) or remove your sunglasses.
- Using cellular phones

Interference may be heard through the audio system's speakers if a cellular phone is being used inside or close to the vehicle while the audio system is operating.

#### 

#### Using the Lexus Display Audio controller

Be careful when touching the Lexus Display Audio controller in extreme temperatures as it may become very hot or cold due to the temperature inside the vehicle.

- Laser product
- USE OF CONTROL OR ADJUSTMENT OR PERFORMANCE OF PROCE-DURES OTHER THAN THOSE SPECIFIED HEREIN MAY RESULT IN HAZARD-OUS RADIATION EXPOSURE.
- THE USE OF OPTICAL INSTRUMENTS WITH THIS PRODUCT WILL INCREASE EYE HAZARD.

#### 🔨 NOTICE

#### To prevent Lexus Display Audio controller malfunction

- Do not allow the Lexus Display Audio controller to come into contact with food, liquid, stickers or lit cigarettes as doing so may cause it to change color, emit a strange odor or stop functioning.
- Do not subject the Lexus Display Audio controller to excessive pressure or strong impact as the controller may bend or break off.
- To prevent battery discharge

Do not leave the audio system on longer than necessary when the engine is off.

To avoid damaging the audio system

Take care not to spill drinks or other fluids on the audio system.

# Steering wheel audio switches

Some audio features can be controlled using the switches on the steering wheel.

Operation may differ depending on the type of audio system or navigation system. For details, refer to the manual provided with the audio system or navigation system.

#### Operating the audio system using the steering wheel switches

- 1 Volume switch
  - Increases/decreases volume
  - Press and hold: Continuously increases/decreases volume
- 2 Radio mode:
  - Press: Select a radio station
  - Press and hold: Seek up/down

CD, MP3/WMA/AAC disc,

Bluetooth<sup>®</sup>, iPod or USB mode:

- Press: Select a track/file/video
- Press and hold: Fast up/down tracks/files/videos (MP3/WMA/AAC disc, iPod or USB)


3 "MODE" switch

- Turns the power on, selects audio source
- Press and hold this switch to mute or pause the current operation. To cancel the mute or pause, press and hold.

## 

#### To reduce the risk of an accident

Exercise care when operating the audio switches on the steering wheel.



265

# 266 5-1. Basic Operations

# **USB/AUX** ports


Connect an iPod, USB memory device or portable audio player to the USB/ AUX port as indicated below. Select "iPod", "USB", "AUX" or "A/V" on the audio source selection screen and the device can be operated via Display Audio system.

#### Connecting using the USB/AUX port

#### 🔳 iPod

Open the cover and connect an iPod using an iPod cable.

Turn on the power of the iPod if it is not turned on.



#### USB memory

Open the cover and connect the USB memory device.

Turn on the power of the USB memory device if it is not turned on.

#### Portable audio player

Open the cover and connect the portable audio player.

Turn on the power of the portable audio player if it is not turned on.

#### iPod video and A/V

To operate the video functions such as iPod video or A/V, a 4-pole AUX cable is necessary. However, depending on the cable specifications, the video function may not work properly. For more information consult your Lexus dealer.

#### A CAUTION

#### While driving

Do not connect a device or operate the device controls.

5-2. Setup

267

# Setup menu

The Display Audio system can be adjusted to the desired settings.

#### Display "Setup" screen

"Setup" screen:  $\longrightarrow$  "Setup"

- Change the settings for operation sounds, screen animation, etc.
   (→P. 268)
- ② Adjust the settings for voice guidance volume and voice recognition prompts. (→P. 271)
- ③ Change the settings for registering, removing, connecting and disconnecting Bluetooth<sup>®</sup> devices. (→P. 302)
- Setup 1 General 2 Voice 3 Bluetooth 4 Audio 5 Whicle 6 Phone CLYWAZ242
- 4 Change the settings for FM radio, iPod, etc.  $(\rightarrow P. 275)$
- (5) Change the settings for vehicle customization. ( $\rightarrow$ P. 525)
- (6) Change the settings for phone sound, phonebook, etc. ( $\rightarrow$ P. 322)

5

# 268 5-2. Setup

# **General settings**

Settings are available for adjusting the operation sounds, screen animation, etc.


#### Screen for general settings "General Settings" screen: $\blacksquare \rightarrow$ "Setup" $\rightarrow$ "General" 1 Change language. The selectable languages may differ al Setting depending on the model or region. 2 Set the beep sound on/off. English Off 3 Change the button color. (4) Change the startup image and screen off image. ( $\rightarrow$ P. 269) On Personal Data 5 Set the animation effect on/off. e Update 6 Delete personal data ( $\rightarrow$ P. 270) Datah ⑦ Update program versions. For details, contact your Lexus dealer. CIYAVA7

For details, contact your Lexus dealer. 9 Display the open source license.

8 Update gracenote database versions.

#### Customizing images

- Go to "Customize Images": → "Setup" → "General" → "Customize Images"
- **2** Select "Set Images" and then select the desired image.
  - 1 Set as startup image.
  - 2 Set as screen off image.
  - 3 Set as startup image and screen off image.



#### Adding an image

- 1 Connect a USB memory device. ( $\rightarrow$ P. 266)
- 2 Select "Copy from USB" on the "Customize Images" screen and then select the desired image.
- 3 Move the controller to the left and then select "Copy". Up to 10 images can be downloaded.

#### Deleting images

Select "Delete Images" on the "Customize Images" screen and then select the desired images.

#### USB memory

When saving the images to a USB memory device, name the folder that the images are saved to "Image".

Compatible device formats

- The following device format can be used:
  - The image's file format must be JPEG
  - USB communication format: USB2.0 FS (480 Mbps)
  - File system format: FAT16/32 (Windows)
  - Correspondence class: Mass storage class
- JPEG file compatibility

Compatible image size: Maximum 5MB

#### 270 5-2. Setup

#### NOTICE A

If the console box lid cannot be fully closed

 $\rightarrow P.299$ 

To prevent damage to the USB memory device or its terminals  $\rightarrow$  P. 299

#### **Deleting personal data**

- $\blacksquare \rightarrow$  "Setup"  $\rightarrow$  "General"  $\rightarrow$  "Delete Personal Data" 1
- 2 Select "Delete".

Check carefully beforehand, as data cannot be retrieved once deleted.

The following personal data will be deleted or changed to its default settings.

- Phonebook data
- Call history data
- Favorite data
- Bluetooth<sup>®</sup> devices data
  Phone sound settings
- Detailed Bluetooth<sup>®</sup> settings
- Audio/video setting
- Preset switch data
- Last used radio station
- · Customized image data
- FM info setting
- iPod tagging information
- Software update history
- Software update detail information
- Phone display setting
  Contact/call history setting
- Messaging setting
- Traffic information map
- Weather information
- Phonebook data for voice recognition
- Music data for voice recognition

271

# Voice settings

This screen is used for guidance for voice command systems setting.

Go to "Voice Settings":  $\longrightarrow$  "Setup"  $\rightarrow$  "Voice"

- 1 Adjust the voice guidance volume setting.
- 2) Set the voice recognition prompts on/off.



Return to the default settings Move the controller to the left and select "Default".

# **272** 5-2. Setup


# Display settings

Settings are available for adjusting the contrast and brightness of the screen. The display can also be turned off.

#### Screen for display settings

Go to "Display":  $\longrightarrow$  "Display"

- 1 Turn off screen.
- Adjust screen quality.
- 3 Adjust screen quality of the rear view monitor camera.
- (4) Change to day mode.



#### Screen off

This setting turns the screen off. To turn it on, press any button such as 🧮 or

If a screen off image has been set, the set image will be displayed.

#### Day mode

When the headlights are turned on, the screen dims.

However, the screen can be switched to day mode by selecting "Day Mode".

The screen will stay in day mode when the headlights are turned on until "Day Mode" is selected again.

#### Adjusting the screen quality

- Select "General" or "Camera" on the "Display" screen or select "Display" on each audio menu screen. (→P. 278)
- **2** Adjust the display as desired by turning the controller clockwise (+) or counterclockwise (-).

To select "Contrast", "Brightness", "Color" or "Tone", move the controller to the left. (when "Display" is selected, "Color" and "Tone" are available.)

#### Changing the sample image (when "General" is selected)

Move the controller to the right and select the desired sample image.

# Selecting the audio source

Switching between audio sources such as radio and CD are explained in this section.

#### Changing audio source

1 Press the 📻 button to display the "Source" screen.

If the "Source" screen is not displayed, press the 📻 button again.

Select the desired audio source. The audio source can be selected by pressing the "RADIO" or "MEDIA" button.

#### Using the steering wheel switches to change audio sources

Press the "MODE" switch when the audio system is turned on. The audio source changes each time the "MODE" switch is pressed.

#### Rearranging the list

The listing order of the source list can be rearranged.

- 1 Move the controller to the left while on the "Source" screen.
- 2 Select "Audio Source Select".
- 3 Select an item you wish to move and then select where to move the item to.

# **274** 5-3. Using the audio system

# Optimal use of the audio system

On the "Sound Settings" screen, sound quality (Treble/Mid/Bass), volume balance and DSP settings can be adjusted.

How to adjust the sound settings and sound quality

- **1** Display audio menu screen. ( $\rightarrow$ P. 278)
- **2** Select "Sound Settings".

To change between the sound setting screen and DSP setting screen, move the controller to the right then select the desired screen.

"Sound"

(1)(2)(3) Adjust the treble, mid or bass.

- 4 Adjust the front/rear audio balance.
- (5) Adjust the left/right audio balance.

#### Sound Settings AM 1 Treble 2 Mid 3 Bass 4 Fade 5 Balance L R CLYRWAZ244

#### ▶ "DSP"

- Set the automatic sound levelizer (ASL) on/off
- ② Set the surround function on/off



The sound quality level is adjusted individually

The treble, mid and bass levels can be adjusted for each audio mode separately.

About Automatic Sound Levelizer (ASL)

ASL automatically adjusts the volume and tone quality according to the vehicle speed.

#### 5-3. Using the audio system

dio Setting

# Audio settings

#### Screen for audio settings

Go to "Audio Settings":  $\boxed{}$   $\rightarrow$  "Setup"  $\rightarrow$  "Audio"

- (1) Change radio settings ( $\rightarrow$ P. 275)
- (2) Change iPod settings ( $\rightarrow$ P. 276)
- (3) Change A/V settings ( $\rightarrow$ P. 276)
- (4) Change the cover art settings  $(\rightarrow P. 277)$
- (5) Change USB settings ( $\rightarrow$ P. 277)



To change radio settings, select "Radio Settings" on the "Audio Settings" screen or radio menu screen. ( $\rightarrow$ P. 278)

- Set the displaying RBDS text message on/off
- 2 Change the number of radio presets



Lexus Display Audio system

275

CLYAVAZ03

#### Changing iPod settings

To change iPod settings, select "iPod Settings" on the "Audio Settings" screen or iPod menu screen. ( $\rightarrow$ P. 278)

d Setting

Art Settings

- Change the screen size (video mode)
- ② Change the cover art settings (→P. 277)
- ③ Adjust the screen quality (video mode) (→P. 272)
- (4) Change video sound input port

#### Changing A/V settings

To change A/V settings, select "External Video Settings" on the "Audio Settings" screen or A/V menu screen. ( $\rightarrow$ P. 278)

- 1 Change the screen size
- 2 Change the video signal
- ③ Adjust the screen quality (video mode) (→P. 272)



Normal

US8

CLYAVAZ032

#### Changing the cover art settings

To change the cover art settings, select "Cover Art Settings" on the "Audio Settings" screen, CD or MP3/WMA/AAC disc menu screen. ( $\rightarrow$ P. 278)

- Select to set the cover art display of the DISC mode on/off.
- Select to set the cover art display of the USB mode on/off.
- 3 Change the priority of the Gracenote database of the USB mode.
- (4) Select to set the cover art display of the iPod mode on/off.
- 5 Change the priority of the Gracenote database of the iPod mode.

## Changing USB settings

To change USB settings, select "USB Settings" on the "Audio Settings" screen or USB menu screen. ( $\rightarrow$ P. 278)

(1) Change the cover art settings  $(\rightarrow P. 277)$ 



Lexus Display Audio system



# **278** 5-3. Using the audio system

# Audio menu screen operation

You can change the settings and control functions for each audio source.


#### Audio menu screen

To display the audio menu screen, move the controller to the left while on an audio top screen.

- ► AM, FM radio or XM Satellite Radio
  - Scan for receivable stations (AM, FM radio)
- 2 Seek a station of the nearest frequency (stops when a station is found) (AM, FM radio)
- 3 Memorize the information in the music under broadcasting (when the "HD" indicator on the selected station is appears) (FM radio)
- 4 Change the channel of HD radio (when the "HD" indicator on the selected station is appears) (FM radio)



- 5 Seek a station of the traffic announcement (FM radio)
- 6 Select to set the station list shows of HD radio on/off (AM, FM radio)
- (7) Change radio settings ( $\rightarrow$ P. 275)
- (8) Change sound settings ( $\rightarrow$ P. 274)



# **280** 5-3. Using the audio system

# Repeat play

Mode	Action	Target audio source
с Ф	File/track repeat	All media
≌⊄⊅	Folder repeat	MP3/WMA/AAC disc, USB
049	Album repeat	USB, Bluetooth <sup>®</sup>

# Random/shuffle playback

Mode	Action	Target audio source
X	Random/shuffle play of the disc/ folder/album	All media
Random play of all folders		MP3/WMA/AAC disc, USB
o≭	Random/shuffle play of all albums	iPod, USB, Bluetooth <sup>®</sup>

# **Radio operation**

Select "AM", "FM" or "SAT" on the audio source selection screen to begin listening to the radio.

#### Radio top screen

Pressing the "RADIO" button displays the radio top screen from any screen of the selected source.

Menu screen

 $\rightarrow$  P. 278

#### Selecting a station (AM or FM radio)

Tune in to the desired station using one of the following methods.

Seek tuning

Press and hold then release "<" or ">".

The radio will begin seeking up or down for a station of the nearest frequency and will stop when a station is found.

Manual tuning

Turn the "TUNE/SCROLL" knob.

Preset stations

Select the desired preset station by pressing "<" or ">" or controller.

- Station list
- 1 Move the controller to the right and selecting "Station List".
- **2** AM radio: Selecting a desired station.

FM radio: Selecting a desired type of station and selecting a desired station.

To refreshing the station list, select "Refresh". Select "Source" on the refresh screen, can be change to the other audio source while refreshing.

#### Selecting a channel (XM Satellite Radio)

Select in to the desired channel using one of the following methods.

Turning up/down the channel

Press and hold "<" or ">" or turn the "TUNE/SCROLL" knob.

Preset channels

Select the desired preset channel by pressing "<" or ">" or controller.

- Channel list
- Move the controller to the right and selecting "Select a SAT Category".
- 2 Selecting a desired category of channel and selecting a desired channel.

#### Setting presets

- **1** Search for desired stations or channel.
- 2 Select and hold one of the preset until you hear a beep.

#### Display the text message

Display the song information

Move the controller to the right and selecting "Text".

Display the Additional information (AM, FM radio)

Move the controller to the right and selecting "Additional Information".

#### Selecting an HD radio channel

When "HD Radio" is set to on, available stations with HD radio channels are marked with "HD".

- 1 Select a station marked with "HD".
- **2** Turn the "TUNE/SCROLL" knob to select an HD radio channel.

HD channels can also be selected by selecting "Multicast" on the menu screen. (  $\rightarrow$  P. 278)

# HD Radio™ Technology

HD Radio<sup>™</sup> Technology is the digital evolution of analog AM/FM radio. Your radio product has a special receiver which allows it to receive digital broadcasts (where available) in addition to the analog broadcasts it already receives.

Digital broadcasts have better sound quality than analog broadcasts as digital broadcasts provide free, crystal clear audio with no static or distortion. For more information, and a guide to available radio stations and programming, refer to www.hdradio.com.

# Radio

HD Radio Technology manufactured under license from iBiquity Digital Corporation. U.S. and Foreign Patents. HD Radio<sup>™</sup> and the HD, HD Radio, and "Arc" logos are proprietary trademarks of iBiguity Digital Corp.

#### ■ HD Radio<sup>™</sup> Technology troubleshooting guide

Experience	Cause	Action
Mismatch of time align- ment- a user may hear a short period of program- ming replayed or an echo, stutter or skip.	The radio stations analog and digital volume are not properly aligned or the sta- tion is in ballgame mode.	None, radio broadcast issue. A user can contact the radio station.
Sound fades, blending in and out.	Radio is shifting between analog and digital audio.	Reception issue, may clear-up as the vehicle continues to be driven. Set "HD Radio" to off, can force radio in an analog audio.
Audio mute condition when an HD2/HD3 multi- cast channel had been playing.	The radio does not have access to digital signals at the moment.	This is normal behavior, wait until the digital signal returns. If out of the cover- age area, seek a new sta- tion.
Audio mute delay when selecting an HD2/HD3 multicast channel preset.	The digital multicast con- tent is not available until HD Radio™ broadcast can be decoded and make the audio available. This takes up to 7 seconds.	This is normal behavior, wait for the audio to become available.

# Lexus Display Audio system

# **284** 5-4. Using the radio

Experience	Cause	Action
Text information does not match the present song audio.	Data service issue at the radio broadcaster.	Broadcaster should be notified. Complete the form: www.ibiquity.com/ automotive/ report_radio_station_ experiences.
No text information shown for the present selected frequency.	Data service issue by the radio broadcaster.	Broadcaster should be notified. Complete the form: www.ibiquity.com/ automotive/ report_radio_station_ experiences.

#### Reception sensitivity

- Maintaining perfect radio reception at all times is difficult due to the continually changing position of the antenna, differences in signal strength and surrounding objects, such as trains, transmitters, etc.
- The radio antenna is mounted inside the rear window. To maintain clear radio reception, do not attach metallic window tinting or other metallic objects to the antenna wire mounted inside the rear window.

#### XM Radio Services – Descriptions

Radio and Entertainment

XM offers more than 170 satellite radio channels of commercial-free music and premier sports, news, talk, and entertainment. XM is broadcast via satellites to millions of listeners across the continental United States. XM subscribers listen to XM on satellite radio receivers for the car, home, and portable use. More information about XM is available online at <u>www.siriusxm.com</u> (U.S.A.) or <u>www.xmradio.ca</u> (Canada).

#### Satellite tuner

The tuner supports only Audio Services (Music and Talk) and the accompanying Text Information of XM Satellite Radio.

#### XM Radio Services — Subscription Instructions

For XM Services requiring a subscription (such as XM Radio), the following paragraph shall be included.

Required XM Radio monthly subscriptions sold separately after trial period. Subscription fee is consumer only. All fees and programming subject to change. Subscriptions are subject to the Customer Agreement available at <u>www.siriusxm.com.</u> (U.S.A.) or www.xmradio.ca (Canada) XM service only available in the 48 contiguous United States and 10 Canadian provinces. © 2011 Sirius XM Radio Inc. Sirius, XM and all related marks and logos are trademarks of Sirius XM Radio Inc. All other marks, channel names and logos are the property of their respective owners.

For more information, program schedules, and to subscribe or extend subscription after complimentary trial period; more information is available at:

- ▶ U.S.A. Customers:
  - Visit www.siriusxm.com or call 1-877-515-3987
- ► Canadian Customers:

Visit www.xmradio.ca or call 1-877-438-9677

Radio ID

You will need the radio ID when activating XM service or reporting a problem. If "Ch000" is selected using the "TUNE•SCROLL" knob, the ID code, which is 8 alphanumeric characters, will be displayed. If another channel is selected, the ID code will no longer be displayed. The channel (000) alternates between displaying the radio ID and the specific radio code.

#### XM Radio Services – Legal Disclaimers and Warnings

• Fees and Taxes – Subscription fee, taxes, one time activation fee, and other fees may apply. Subscription fee is consumer only. All fees and programming subject to change. Subscriptions subject to Customer Agreement available at <u>www.siriusxm.com.</u> (U.S.A.) or www.xmradio.ca (Canada) XM service only available in the 48 contiguous United States and Canada.

Explicit Language Notice - Channels with frequent explicit language are indicated with an "XL" preceding the channel name. Channel blocking is available for XM Satellite Radio receivers by notifying XM at;

- ▶ U.S.A. Customers:
- Visit www.siriusxm.com or calling 1-877-515-3987
- ► Canadian Customers:
  - Visit www.xmradio.ca or calling 1-877-438-9677

It is prohibited to copy, decompile, disassemble, reverse engineer, hack, manipulate, or otherwise make available any technology or software incorporated in receivers compatible with the XM Satellite Radio System or that support the XM website, the Online Service or any of its content. Furthermore, the  $AMBE^{\mathbb{R}}$  voice compression software included in this product is protected by intellectual property rights including patent rights, copyrights, and trade secrets of Digital Voice Systems, Inc.

Note: this applies to XM receivers only and not XM Ready devices.

#### ■ If the satellite radio does not operate normally

If a problem occurs with the XM tuner, a message will appear on the screen. Refer to the table below to identify the problem, and take the suggested corrective action.

SAT Check Antenna	The XM antenna is not connected. Check whether the XM antenna cable is attached securely.
5/11 Check / Intenna	There is a short-circuit in the antenna or the surrounding antenna cable. See a Lexus certified dealer.
SAT Ch Unautho-	You have not subscribed to XM Satellite Radio. The radio is being updated with the latest encryption code. Contact XM Satellite Radio for subscription information. When a con- tract is canceled, you can choose "ChOOO" and all free-to- air channels.
rized	The premium channel you selected is not authorized. Wait for about 2 seconds until the radio returns to the previous channel or "ChOO1". If it does not change automatically, select another channel. To listen to the premium channel, contact XM Satellite Radio.
SAT No Signal	The XM signal is too weak at the current location. Wait until your vehicle reaches a location with a stronger signal.
SAT Loading	The unit is acquiring audio or program information. Wait until the unit has received the information.
SAT Channel Off Air	The channel you selected is not broadcasting any program- ming. Select another channel.
	There is no song/program title or artist name/feature asso- ciated with the channel at that time. No action is required.
SAT Chan Unavail- able	The channel you selected is no longer available. Wait for about 2 seconds until the radio returns to the previous channel or "Ch001". If it does not change automatically, select another channel.

Contact the XM Listener Care Center at 1-877-515-3987 (U.S.A.) or 1-877-438-9677 (Canada).

# **CD** player operation

Insert a disc, press the "MEDIA" button or select "DISC" on the "Source" screen with a disc inserted to begin listening to a CD.

#### CD top screen

Pressing the "MEDIA" button displays the CD top screen from any screen of the selected source.

Menu screen

→P. 278

Selecting a track/file

Press the "<" or ">" button or turn the "TUNE/SCROLL" knob to select the desired track/file number.

To fast-forward or rewind, press and hold the "<" or ">" button.

Selecting the track by the list (CD)

Move the controller to the right and then select the desired track.

- Selecting a folder (MP3/WMA/AAC disc)
- 1 Move the controller to the right and then select "Folders".
- 2 Select the desired folder. Then select a file to begin using the selected folder.

#### Selecting a file by the selected folder (MP3/WMA/AAC disc)

- 1 Move the controller to the right and then select "Files".
- **2** Select the desired file.

### Error messages

If an error message is displayed, refer to the following table and take the appropriate measures. If the problem is not rectified, take the vehicle to your Lexus dealer.

Message	Cause	Correction procedures
"Check disc"	<ul> <li>The disc is dirty or damaged.</li> <li>The disc is inserted upside down.</li> <li>The disc is not playable with the player.</li> </ul>	<ul> <li>Clean the disc.</li> <li>Insert the disc correctly.</li> <li>Confirm the disc is playable with the player.</li> </ul>
"DISC Error"	There is a malfunction within the system.	Eject the disc.
"No music files found."	No playable data is included on the disc.	Eject the disc.

### Discs that can be used

Discs with the marks shown below can be used.

Playback may not be possible depending on recording format or disc features, or due to scratches, dirt or deterioration.



CDs with copy-protection features may not play correctly.

### CD player protection feature

To protect the internal components, playback is automatically stopped when a problem is detected.

### ■ If a disc is left inside the CD player or in the ejected position for extended periods

Disc may be damaged and may not play properly.

### Lens cleaners

Do not use lens cleaners. Doing so may damage the CD player.

### MP3, WMA and AAC files

MP3 (MPEG Audio LAYER3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size by using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format.

This format compresses audio data to a size smaller than that of the MP3 format.

AAC is short for Advanced Audio Coding and refers to an audio compression technology standard used with MPEG2 and MPEG4.

MP3, WMA and AAC file and media/formats compatibility are limited.

288

- MP3 file compatibility
  - Compatible standards
  - MP3 (MPEG1 LAYER3, MPEG2 LSF LAYER3) Compatible sampling frequencies MPEG1 LAYER3: 32, 44.1, 48 (kHz)
  - MPEG2 LSF LAYER3: 16, 22.05, 24 (kHz) Compatible bit rates (compatible with VBR) MPEG1LAYER3: 32-320 (kbps) MPEG2 LSF LAYER3: 8-160 (kbps)
- Compatible channel modes: stereo, joint stereo, dual channel and monaural WMA file compatibility
  - Compatible standards
  - WMA Ver. 7, 8, 9 (only compatible with Window Media Audio Standard) Compatible sampling frequencies
  - 32, 441, 48 (kHz)
  - Compatible bit rates (only compatible with 2-channel playback) Ver. 7, 8: CBR 48-192 (kbps) Ver. 9: CBR 48-320 (kbps)
- AAC file compatibility
  - Compatible standards MPEG4/AAC-LC

  - Compatible sampling frequencies 11.025/12/16/22.05/24/32/44.1/48 (kHz)
  - Compatible bit rates 16-320 (kbps)
  - Compatible channel modes: 1 ch and 2 ch
- Compatible media

Media that can be used for MP3, WMA and AAC playback are CD-Rs and CD-RWs. Playback in some instances may not be possible if the CD-R or CD-RW is not finalized. Playback may not be possible or the audio may jump if the disc is scratched or marked with fingerprints.

- Compatible disc formats
  - The following disc formats can be used.
  - Disc formats: CD-ROM Mode 1 and Mode 2
  - CD-ROM XA Mode 2, Form 1 and Form 2 ISO9660 Level 1, Level 2, (Romeo, Joliet) File formats:
    - UDF (2.01 or lower)

MP3, WMA and AAC files written in any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows.

- Maximum directory hierarchy: 8 levels (including the root)
- Maximum length of folder names/file names: 32 characters
- Maximum number of folders: 192 (including the root)
- Maximum number of files per disc: 255

289

### File names

The only files that can be recognized as MP3/WMA/AAC and played are those with the extension .mp3, .wma or .m4a.

• Discs containing multi-session recordings

As the audio system is compatible with multi session discs, it is possible to play discs that contain MP3, WMA and AAC files. However, only the first session can be played.

ID3, WMA and AAC tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

AAC tags can be added to AAC files, making it possible to record the track title and artist name in the same way as with ID3 tags.

MP3, WMA and AAC playback

When a disc containing MP3, WMA or AAC files is inserted, all files on the disc are first checked. Once the file check is finished, the first MP3, WMA or AAC file is played. To make the file check finish more quickly, we recommend you do not write any files to the disc other than MP3, WMA or AAC files or create any unnecessary folders.

Discs that contain a mixture of music data and MP3, WMA or AAC format data cannot be played.

Extensions

If the file extensions .mp3, .wma and .m4a are used for files other than MP3, WMA and AAC files, they may be mistakenly recognized and played as MP3, WMA and AAC files. This may result in large amounts of interference and damage to the speakers.

- Playback
  - To play MP3 files with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
  - CD-R or CD-RW playback may not be possible in some instances, depending on the characteristics of the disc.
  - There is a wide variety of freeware and other encoding software for MP3, WMA and AAC files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
  - cases, playback may not be possible at all.
    When files other than MP3, WMA or AAC files are recorded on a disc, it may take more time to recognize the disc and in some cases, playback may not be possible at all.
  - Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S.A. and other countries.

### ■ The Gracenote<sup>®</sup> media database

 Gracenote, the Gracenote logo and logotype, "Powered by Gracenote", MusicID, Playlist Plus and MediaVOCS are either registered trademarks or trademarks of Gracenote, Inc. in the United States



### Gracenote<sup>®</sup> End User License Agreement - Music

This application or device contains software from Gracenote. Inc. of Emeryville, California ("Gracenote"). The software from Gracenote (the "Gracenote Software") enables this application to perform disc and/or file identification and obtain music-related information, including name, artist, track, and title information ("Gracenote Data") from online servers or embedded databases (collectively, "Gracenote Servers") and to perform other functions. You may use Gracenote Data only by means of the intended End-User functions of this application or device.

This application or device may contain content belonging to Gracenote's providers. If so, all of the restrictions set forth herein with respect to Gracenote Data shall also apply to such content and such content providers shall be entitled to all of the benefits and protections set forth herein that are available to Gracenote.

You agree that you will use Gracenote Data, the Gracenote Software, and Gracenote Servers for your own personal non-commercial use only. You agree not to assign, copy, transfer or transmit the Gracenote Software or any Gracenote Data to any third party. YOU AGREE NOT TO USE OR EXPLOIT GRACENOTE DATA. THE GRACENOTE SOFTWARE, OR GRACENOTE SERVERS, EXCEPT AS EXPRESSLY PERMITTED HEREIN.

You agree that your non-exclusive license to use the Gracenote Data, the Gracenote Software, and Gracenote Servers will terminate if you violate these restrictions. If your license terminates, you agree to cease any and all use of the Gracenote Data, the Gracenote Software, and Gracenote Servers. Gracenote reserves all rights in Gracenote Data, the Gracenote Software, and the Gracenote Servers. Gracenote reserves all rights. Under no circumstances will Gracenote become liable for any payment to you for any information that you provide. You agree that Gracenote. Inc. may enforce its rights under this Agreement against you directly in its own name.


The Gracenote service uses a unique identifier to track queries for statistical purposes. The purpose of a randomly assigned numeric identifier is to allow the Gracenote service to count queries without knowing anything about who you are. For more information, see the web page for the Gracenote Privacy Policy for the Gracenote service.

The Gracenote Software and each item of Gracenote Data are licensed to you "AS IS." Gracenote makes no representations or warranties, express or implied, regarding the accuracy of any Gracenote Data from the Gracenote Servers. Gracenote reserves the right to delete data from the Gracenote Servers or to change data categories for any cause that Gracenote deems sufficient. No warranty is made that the Gracenote Software or Gracenote Servers are error-free or that functioning of Gracenote Software or Gracenote Servers will be uninterrupted. Gracenote is not obligated to provide you with new enhanced or additional data types or categories that Gracenote may provide in the future and is free to discontinue its services at any time.

GRACENOTE DISCLAIMS ALL WARRANTIES EXPRESS OR IMPLIED. INCLUDING. BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY. FITNESS FOR A PARTICULAR PURPOSE. TITLE. AND NON-INFRINGEMENT. GRACENOTE DOES NOT WARRANT THE RESULTS THAT WILL BE OBTAINED BY YOUR USE OF THE GRACENOTE SOFTWARE OR ANY GRACENOTE SERVER. IN NO CASE WILL GRACENOTE BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES OR FOR ANY LOST PROFITS OR LOST REVENUES.

© 2012 Gracenote, Inc. All rights reserved.

### 292 5-5. Playing an audio CD and MP3/WMA/AAC discs



IS350/250\_U (OM53758U)

# Listening to an iPod

Connecting an iPod enables you to enjoy music from the vehicle speakers. Press the "MEDIA" button or select "iPod" on the audio source selection screen.

### Connecting an iPod

→P. 266

### iPod top screen

Pressing the "MEDIA" button displays the iPod top screen from any screen of the selected source.

Menu screen

→P. 278

Selecting a song

Press the "<" or ">" button or turn the "TUNE/SCROLL" knob to select the desired song number.

To fast-forward or rewind, press and hold the "<" or ">" button.

### Selecting a play mode

1 Move the controller to the right and then select "Browse".

2 Select the desired play mode, and then select a song to begin using the selected play mode.

### Displaying the now playing list

Move the controller to the right and then select "Now Playing List".

### About iPod



- "Made for iPod" and "Made for iPhone" mean that an electronic accessory has been designed to connect specifically to an iPod, or iPhone, respectively, and has been certified by the developer to meet Apple performance standards.
- Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod or iPhone may affect wireless performance.
- iPhone, iPod, iPod classic, iPod nano and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

### iPod cover art

- Depending on the iPod and songs in the iPod, iPod cover art may be displayed.
- This function can be changed to on/off.  $(\rightarrow P. 277)$
- It may take time to display iPod cover art, and the iPod may not be operated while the cover art display is in process.

### iPod functions

- When an iPod is connected and the audio source is changed to iPod mode, the iPod will resume play from the same point in which it was last used.
- Depending on the iPod that is connected to the system, certain functions may not be available. If a function is unavailable due to a malfunction (as opposed to a system specification), disconnecting the device and reconnecting it may resolve the problem.
- Depending on the iPod, while connected to the system, the iPod cannot be operated with its own controls. It is necessary to use the controls of the vehicle's audio system instead.
- When the battery level of an iPod is very low, the iPod may not operate. If so, charge the iPod before use.
- Compatible models ( $\rightarrow$ P. 295)

### iPod problems

To resolve most problems encountered when using your iPod, disconnect your iPod from the vehicle iPod connection and reset it. For instructions on how to reset your iPod, refer to your iPod Owner's Manual.

### Error messages

Message	Cause/Correction procedures	
"Connection error."	This indicates a problem in the iPod or its connection.	
"There are no songs available for playback."	This indicates that there is no music data in the iPod.	
"No items available."	This indicates that songs are not found in a selected playlist.	
"Please check the iPod firm- ware version."	This indicates that the software version is not compatible. Please check the compatible models. ( $\rightarrow$ P. 295)	
"iPod authorization failed."	This indicates that the display audio system failed to authorize the iPod. Please check your iPod.	

5-6. Using an external device

### Compatible models

The following iPod  $^{(\!R\!)}$ , iPod nano $^{(\!R\!)}$ , iPod classic $^{(\!R\!)}$ , iPod touch  $^{(\!R\!)}$  and iPhone  $^{(\!R\!)}$  devices can be used with this system.

- Made for
  - iPod touch (5th generation)
  - iPod touch (4th generation)
  - iPod touch (3rd generation)
  - iPod touch (2nd generation) iPod touch (1st generation)

  - iPod classic
  - iPod with video
  - iPod nano (7th generation)
  - iPod nano (6th generation)
  - iPod nano (5th generation)
  - iPod nano (4th generation)
  - iPod nano (3rd generation)
  - iPod nano (2nd generation) iPod nano (1st generation)
  - iPhone 5
  - iPhone 4S •
  - iPhone 4
  - iPhone 3GS
  - iPhone 3G
  - iPhone

Depending on differences between models or software versions etc., some models might be incompatible with this system.

### To use the video mode

To operate the video functions such as iPod video, a 4-pole AUX cable is necessary. However, depending on the cable specifications, the video function may not work properly. For more information consult your Lexus dealer.

### NOTICE

### If the console box lid cannot be fully closed

Depending on the size and shape of the iPod that is connected to the system, the auxiliary box lid may not close fully. In this case, do not forcibly close the lid as this may damage the iPod or the terminals, etc.

### To prevent damage to the iPod or its terminals

- Do not leave the iPod in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the iPod.
- Do not push down on or apply unnecessary pressure to the iPod while it is connected.
- Do not insert foreign objects into the port.

# **296** 5-6. Using an external device

# Listening USB memory device

Connecting a USB memory device enables you to enjoy music from the vehicle speakers.

Select "USB1" or "USB2" on the audio source selection screen.

### Connecting a USB memory device

→P. 266

### USB top screen

Pressing the "MEDIA" button displays the USB top screen from any screen of the selected source.

Menu screen

→P. 278

Selecting a file

Press the "<" or ">" button or turn the "TUNE/SCROLL" knob to select the desired file number.

To fast-forward or rewind, press and hold the "<" or ">" button.

### Selecting a play mode

1 Move the controller to the right and select "Browse".

2 Select the desired play mode, then select a file to begin the selected play mode.

### Displaying the now playing list

Move the controller to the right and select "Now Playing List".

### USB memory functions

- Depending on the USB memory device that is connected to the system, the device itself may not be operable and certain functions may not be available. If the device is inoperable or a function is unavailable due to a malfunction (as opposed to a system specification), disconnecting the device and reconnecting it may resolve the problem.
- If the USB memory device still does not begin operation after being disconnected and reconnected, format the device.
- Error messages for USB memory

Message	Cause/Correction procedures
"Connection error."	This indicates a problem with the USB memory device or its connection.
"There are no files available for playback."	This indicates that no MP3/WMA/AAC files are included on the USB memory device.

### ■ USB memory

Compatible devices

- USB memory devices that can be used for MP3, WMA and AAC playback.
- Compatible device formats

The following device format can be used:

- USB communication format: USB2.0 FS (480 Mbps)
- File system format: FAT16/32 (Windows)

Correspondence class: Mass storage class MP3, WMA and AAC files written to a device with any format other than those listed above may not play correctly, and their file names and folder names may not be displayed correctly.

Items related to standards and limitations are as follows:

- Maximum directory hierarchy: 8 levels •
- Maximum number of folders in a device: 3000 (including the root) Maximum number of files in a device: 9999 •
- •
- Maximum number of files per folder: 255

Lexus Display Audio system

IS350/250\_U (OM53758U)

MP3, WMA and AAC files

MP3 (MPEG Audio LAYER 3) is a standard audio compression format.

Files can be compressed to approximately 1/10 of their original size using MP3 compression.

WMA (Windows Media Audio) is a Microsoft audio compression format. This format compresses audio data to a size smaller than that of the MP3 format.

AAC is short for Advanced Audio Coding and refers to an audio compression technology standard used with MPEG2 and MPEG4.

MP3, WMA and AAC file and media/formats compatibility are limited.

- MP3 file compatibility
  - Compatible standards
  - MP3 (MPEG1 AUDIO LAYERIII, MPEG2 AUDIO LAYERIII) Compatible sampling frequencies
  - MPEG1 AUDIO LAYERIII: 32, 44.1, 48 (kHz) MPEG2 AUDIO LAYERIII: 16, 22.05, 24 (kHz)
  - Compatible bit rates (compatible with VBR) MPEG1 AUDIO LAYERIII: 32-320 (kbps) MPEG2 AUDIO LAYERIII: 8-160 (kbps)
  - Compatible channel modes: stereo, joint stereo, dual channel and monaural
- WMA file compatibility
  - Compatible standards
  - WMA Ver. 7, 8, 9 (only compatible with Window Media Audio Standard)
  - Compatible sampling frequencies
  - 32, 44.1, 48 (kHz)
  - Compatible bit rates (only compatible with 2-channel playback) Ver. 7, 8: CBR 48-192 (kbps) Ver. 9: CBR 48-320 (kbps)
- AAC file compatibility
  - Compatible standards MPEG4/AAC-LC
  - Compatible sampling frequencies
  - 11.025/12/16/22.05/24/32/44.1/48 (kHz)
  - Compatible bit rates
  - 16-320 (kbps)
  - Compatible channel modes: 1 ch and 2 ch
- File names

The only files that can be recognized as MP3/WMA/AAC and played are those with the extension .mp3, wma or .m4a.

ID3, WMA and AAC tags

ID3 tags can be added to MP3 files, making it possible to record the track title, artist name, etc.

The system is compatible with ID3 Ver. 1.0, 1.1, and Ver. 2.2, 2.3 ID3 tags. (The number of characters is based on ID3 Ver. 1.0 and 1.1.)

WMA tags can be added to WMA files, making it possible to record the track title and artist name in the same way as with ID3 tags.

AAC tags can be added to AAC files, making it possible to record the track title and artist name in the same way as with ID3 tags.

### MP3, WMA and AAC playback

- When a device containing MP3, WMA or AAC files is connected, all files in the USB memory device are checked. Once the file check is finished, the first MP3, WMA or AAC file is played. To make the file check finish more quickly, we recommend that you do not include any files other than MP3, WMA or AAC files or create any unnecessary folders.
- When a USB memory device is connected and the audio source is changed to USB memory mode, the USB memory device will start playing the first file in the first folder. If the same device is removed and reconnected (and the contents have not been changed), the USB memory device will resume play from the same point in which it was last used.
- Extensions

If the file extensions .mp3, .wma and .m4a are used for files other than MP3, WMA and AAC files, they will be skipped (not played).

- Playback
  - To play MP3 files with steady sound quality, we recommend a fixed bit rate of at least 128 kbps and a sampling frequency of 44.1 kHz.
  - There is a wide variety of freeware and other encoding software for MP3, WMA and AAC files on the market, and depending on the status of the encoding and the file format, poor sound quality or noise at the start of playback may result. In some cases, playback may not be possible at all.
  - Microsoft, Windows, and Windows Media are the registered trademarks of Microsoft Corporation in the U.S.A. and other countries.

### 🕂 NOTICE

### If the console box lid cannot be fully closed

Depending on the size and shape of the USB memory device that is connected to the system, the auxiliary box lid may not close fully. In this case, do not forcibly close the lid as this may damage the USB memory device or the terminals, etc.

### To prevent damage to the USB memory device or its terminals

- Do not leave the USB memory device in the vehicle. The temperature inside the vehicle may become high, resulting in damage to the USB memory device.
- Do not push down on or apply unnecessary pressure to the USB memory device while it is connected.
- Do not insert foreign objects into the port.

Lexus Display Audio system

# **300** 5-6. Using an external device

# Using the AUX port

To use the AUX port, connect a portable player, press the "MEDIA" button or select "AUX" or "A/V" on the "Source" screen.

### Connecting a portable player

→P. 266

### Top screen

Pressing the "MEDIA" button displays the top screen from any screen of the selected source.

Menu screen

→P. 278

### Operating portable players connected to the audio system

Volume can be adjusted using the vehicle's audio controls. All other adjustments must be made on the portable player itself.

### When using a portable player connected to the power outlet

Noise may occur during playback. Use the power source of the portable player.

### To use the A/V function

To operate the video functions such as A/V, a 4-pole AUX cable is necessary. However, depending on the cable specifications, the video function may not work properly. For more information consult your Lexus dealer.

### NOTICE

### If the console box lid cannot be fully closed

Depending on the size and shape of the portable player that is connected to the system, the auxiliary box lid may not close fully. In this case, do not forcibly close the lid as this may damage the portable audio player or the terminals, etc.


# Steps for using Bluetooth<sup>®</sup> devices

The following can be performed using Bluetooth<sup>®</sup> wireless communication:

- A portable audio player can be operated and listened to via the Display Audio system
- Hands-free phone calls can be made via a cellular phone

In order to use wireless communication, register and connect a Bluetooth<sup>®</sup> device by performing the following procedures.

### Device registration/connection flow



# **302** 5-7. Connecting Bluetooth<sup>®</sup>

### "Bluetooth\* Setup" screen

Go to "Bluetooth" Setup":  $\longrightarrow$  "Setup"  $\rightarrow$  "Bluetooth"

\*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

- When displaying "Bluetooth<sup>\*</sup> Setup" screen from the "Bluetooth<sup>\*</sup> Audio" screen
  - 1 Display the "Bluetooth" Audio" screen. ( $\rightarrow$ P. 273)
  - 2 Move the controller to the left and select "Connect".

■ When displaying "Bluetooth<sup>\*</sup> Setup" screen from the phone top screen

- 1 Display the phone top screen. ( $\rightarrow$ P. 311)
- 2 Move the controller to the left and select "Connect Phone".
- \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

5-7. Connecting Bluetooth®

# Registering a Bluetooth<sup>®</sup> device

Bluetooth<sup>®</sup> compatible phones (HFP) and portable audio players (AVP) can be registered simultaneously. You can register up to 5 Bluetooth<sup>®</sup> devices.

# How to register a Bluetooth<sup>®</sup> device

- $\blacksquare$  Turn the Bluetooth<sup>®</sup> connection setting of your device set to on.
- **2** Go to "Bluetooth<sup>\*</sup> Setup":  $\longrightarrow$  "Setup"  $\rightarrow$  "Bluetooth<sup>\*</sup>"
- 3 Move the controller to the left and then select "Add Device"
- When this screen is displayed, input the passcode displayed on the screen into your Bluetooth<sup>®</sup> device. For operation of the Bluetooth<sup>®</sup> device, see the manual that comes with your Bluetooth<sup>®</sup> device.
- **5** Register the Bluetooth<sup>®</sup> device using your Bluetooth<sup>®</sup> device.

A PIN code are not required for SSP (Secure Simple Pairing) compatible Bluetooth<sup>®</sup> devices. Depending on the device, you may need to select Yes to register, or No to cancel on the device.



Lexus Display Audio system

303

- If an error message is displayed, follow the guidance on the screen to try again.
- $\star$ : Bluetooth is a registered trademark of Bluetooth SIG, Inc.

# Removing a Bluetooth<sup>®</sup> device

- **1** Go to "Bluetooth<sup>\*</sup> Setup":  $\longrightarrow$  "Setup"  $\rightarrow$  "Bluetooth<sup>\*</sup>"
- 2 Move the controller to the left and then select "Remove Device".
- 3 Select the device to remove.
  - \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

# **304** 5-7. Connecting Bluetooth<sup>®</sup>

# Selecting a Bluetooth<sup>®</sup> device

If multiple Bluetooth<sup>®</sup> devices are registered, follow the procedure below to select the Bluetooth<sup>®</sup> device to be used. You may only use one device at a time.

# How to select a Bluetooth<sup>®</sup> device

**1** Go to "Bluetooth" Setup":  $\longrightarrow$  "Setup"  $\rightarrow$  "Bluetooth"

**2** Select the device to connect.

3 Select "Connect All", "Connect as a Phone" or "Connect as an Audio Player".

If the desired Bluetooth  $^{\textcircled{R}}$  device is not displayed, register the device. (  $\rightarrow P.$  303)

\*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

IS350/250\_U (OM53758U)

# Connecting a Bluetooth<sup>®</sup> audio player

There are 2 portable audio player connection settings available: connecting from the vehicle and connecting from the portable player.

### Connecting method is set to "Vehicle"

When the portable audio player is in standby for a connection, it will be automatically connected whenever the "ENGINE START STOP" switch is in either ACCESSORY or IGNITION ON mode.

# Connecting method is set to "Device"

Operate the portable player and connect it to the Bluetooth  $^{\ensuremath{\mathbb{R}}}$  audio system.

**1** Go to "Bluetooth<sup>\*</sup> Setup":  $\longrightarrow$  "Setup"  $\rightarrow$  "Bluetooth<sup>\*</sup>"

2 Select the device to connect.

**3** Select "Connect All" or "Connect as an Audio player".

If the desired Bluetooth  $^{\textcircled{R}}$  device is not displayed, register the device. (  $\rightarrow$  P. 303)

\*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

### **306** 5-7. Connecting Bluetooth<sup>®</sup>

# Connecting a Bluetooth<sup>®</sup> phone

There are two connecting methods available: automatic and manual.

### Auto connection

When you register a phone, auto connection will be activated. Always set it to this mode and leave the Bluetooth  $^{\textcircled{R}}$  phone in a place where a connection can be established.

When the engine switch is turned to ACCESSORY or IGNITION ON mode, the system will search for a nearby cellular phone you have registered.

Next, the system automatically connects with the most recent phone that was connected. The connected result is displayed.

### Manual connection

When auto connection has failed or "Bluetooth<sup>\*</sup> Power" is turned off, you must connect the Bluetooth<sup>®</sup> device manually.

**1** Go to "Bluetooth<sup>\*</sup> Setup":  $\longrightarrow$  "Setup"  $\rightarrow$  "Bluetooth<sup>\*</sup>"

**2** Select the device to connect.

**3** Select "Connect All", "Connect as a Phone" or "Connect as an Audio player".

If the desired Bluetooth<sup>®</sup> device is not displayed, register the device.  $(\rightarrow P. 303)$ 

\*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

### Reconnecting a Bluetooth<sup>®</sup> phone

If the system cannot connect due to poor signal strength with the "ENGINE START STOP" switch in ACCESSORY or IGNITION ON mode, the system will automatically attempt to reconnect.

If the phone is turned off, the system will not attempt to reconnect. In this case, the connection must be made manually, or the phone must be reselected.

- Connecting a phone while Bluetooth<sup>®</sup> audio is playing
  - $\bullet$  Bluetooth  $^{\textcircled{R}}$  audio will stop temporarily.
  - It may take time to connect.

5-7. Connecting Bluetooth<sup>®</sup>

### Displaying a Bluetooth<sup>®</sup> device details You can confirm and change the registered device details. Bluetooth<sup>®</sup> device registration status **1** Go to "Bluetooth<sup>\*</sup> Setup": $\overline{}$ $\rightarrow$ "Setup" $\rightarrow$ "Bluetooth<sup>\*</sup>" 2 Select the desired device and then select "Device Info". (1) Change the name of the device (2) Change the connection method BT01 "Vehicle": Connect the audio system dio Player Fr Witch to the portable audio player. "Device": Connect the portable \*\*\*\*\* audio player to the audio system 00123456789 3 Device address OPP. PBAP. A2DP. AVRCP. MAR (4) Device telephone number CLYANAZ247 Depending on the model of phone, the number may not be displayed. (5) Compatibility profile of the device \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

### Restoring the default settings

Move the controller to the left and select "Default" on the "Device Information" screen.

Lexus Display Audio system

307

# **308** 5-7. Connecting Bluetooth<sup>®</sup>

# Detailed Bluetooth<sup>®</sup> settings

You can confirm and change the detailed Bluetooth<sup>®</sup> settings.

How to check and change detailed  $\mathsf{Bluetooth}^{\mathbb{R}}$  settings

**1** Go to "Bluetooth" Setup":  $\longrightarrow$  "Setup"  $\rightarrow$  "Bluetooth"

- 2 Move the controller to the left and then select "System Settings".
  - 1 Select to set the Bluetooth<sup>®</sup> function on/off.
  - 2 Change the name of the device.
  - 3 Change the PIN-code.

You can change the PIN-code that is used to register your Bluetooth<sup>®</sup> devices in the system.

- 4 Device address
- (5) Select to set the display of the telephone status on/off

You can set the system to show the status confirmation display when connecting a telephone.



- 6 Select to set the display of the audio player status on/off You can set the system to show the status confirmation display when connecting an audio player.
- ⑦ Compatibility profile of the system
  - \*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

### Restoring the default settings

Move the controller to the left and select "Default" on the "System Settings" screen.

# Listening to Bluetooth<sup>®</sup> Audio

The Bluetooth  $^{\textcircled{R}}$  audio system enables the user to enjoy music played on a portable player from the vehicle speakers via wireless communication.

When a Bluetooth  $^{\ensuremath{\mathbb{R}}}$  device cannot be connected, check the connection status on the "Bluetooth<sup>\*</sup> Audio" screen. If the device is not connected, either register or reconnect the device. ( $\rightarrow$ P. 304, 305)

\*: Bluetooth is a registered trademark of Bluetooth SIG, Inc.

### Status display

You can check indicators, such as, signal strength and battery charge on the screen.

- 1 Connection status
- Battery charge

Depending on the type of portable audio player used, some titles may not be displayed.



309

Indicators	Conditions		
Connection status	Good <> Not connected		
Battery charge	Full <> Empty		

Lexus Display Audio system

# Bluetooth<sup>®</sup> audio top screen

Pressing the "MEDIA" button displays the Bluetooth  $^{\textcircled{R}}$  audio top screen from any screen of the selected source.

### Menu screen

→P. 278

Selecting a song

Press the "<" or ">" button or turn the "TUNE/SCROLL" knob to select the desired song number.

To fast-forward or reverse, press and hold the "<" or ">" button.

### Selecting a play mode

1 Move the controller to the right and then select "Browse".

2 Select the desired play mode, and then select a song to begin using the selected play mode.

### Displaying the now playing list

Move the controller to the right and then select "Now Playing List".

# Using a Bluetooth<sup>®</sup> Phone

The hands-free system is a function that allows you to use your cellular phone without touching it.

This system supports Bluetooth<sup>®</sup>. Bluetooth<sup>®</sup> is a wireless data system that allows the cellular phone to wirelessly connect to the hands-free system and make/receive calls.

Before making a phone call, check the connection status, battery charge, call area and signal strength. ( $\rightarrow$ P. 312)

If a Bluetooth<sup>®</sup> device cannot be connected, check the connection status. If the device is not connected, either register or reconnect it. ( $\rightarrow$ P. 304, 306)

### Phone top screen

To display the screen shown below, press the 🕾 switch on the steering wheel or select "Phone" on the "Menu" screen.

- 1 Phone name
- 2 Bluetooth<sup>®</sup> connection status  $(\rightarrow P. 312)$
- (3) Display the call history screen  $(\rightarrow P. 315)$
- ④ Display the favorites screen
   (→P. 315)
- (5) Display the contacts screen  $(\rightarrow P. 313)$
- 6 Display the dial pad screen ( $\rightarrow$ P. 313)
- $\bigcirc$  Display the message inbox screen ( $\rightarrow$ P. 319)



311

# **312** 5-9. Bluetooth<sup>®</sup> Phone

Telephone switch (→P. 321)

### Microphone

The vehicle's built-in microphone is used when talking on the phone.

The person you are speaking to can be heard from the front speakers.



# Status display

You can check indicators such as signal strength and battery charge on any screen.

- 1 Connection status
- 2 Signal strength
- ③ Battery charge



Indicators	Conditions		
Connection status	Good	>	Poor *
Battery charge	Full	>	Empty D
Signal strength	Excellent	>	Poor

5-9. Bluetooth<sup>®</sup> Phone

# Making a call

Once a Bluetooth  $^{\textcircled{R}}$  phone is registered, you can make a call using the following procedure:

### Dialing

- **1** Go to "Dial Pad":  $\longrightarrow$  "Phone"  $\rightarrow$  "Dial Pad"
- **2** Input a phone number.  $(\rightarrow P. 263)$
- $\fbox{3}$  Press the C switch on the steering wheel or select  $\fbox{a}$

### Dialing from the phonebook

You can dial a number from the phonebook data imported from your cellular phone. The system has one phonebook for each registered telephone. Up to 2500 contacts may be stored in each phonebook. ( $\rightarrow$ P. 314)

- **1** Go to "Contacts":  $\overline{}$   $\rightarrow$  "Phone"  $\rightarrow$  "Contacts"
- **2** Choose the desired contact to call from the list.
- 3 Choose the number and then press the 🕾 switch on the steering wheel or press the controller.

### **314** 5-9. Bluetooth<sup>®</sup> Phone

### When the phonebook is empty


You can transfer the phone numbers in a Bluetooth<sup>®</sup> phone to the system. Operation methods differ between PBAP (Phone Book Access Profile) compatible and PBAP incompatible Bluetooth<sup>®</sup> phones. If the cellular phone does not support either PBAP or OPP (Object Push Profile) service, you cannot transfer contacts.

1 Press the 🕾 switch on the steering wheel.

If the phonebook is empty, a message will be displayed.

- $\blacktriangleright$  For a PBAP compatible Bluetooth <sup>®</sup> phone and "Automatic Transfer" is off
- To transfer new contacts from a cellular phone, select "Always" and then enable "Automatic Transfer".
   (→P. 324)

Select "Once" if you want to transfer new contacts from a cellular phone.



- ▶ For a PBAP incompatible and OPP compatible Bluetooth<sup>®</sup> phone
- 2 Select "Transfer" and operate your cellular phone to transfer new contacts from a cellular phone.

Select "Add" if you want to add a new contact manually.



IS350/250\_U (OM53758U)

5-9. Bluetooth<sup>®</sup> Phone

### **Dialing from favorites**

You can make a call using numbers registered in the favorites.

- **1** Go to "Favorites":  $\longrightarrow$  "Phone"  $\rightarrow$  "Favorites"
- **2** Choose the desired contact to call from the list.
- 3 Choose the number and then press the 🕾 switch on the steering wheel or press the controller.

### Dialing from history

You can make a call using the call history.

- **1** Go to "Call History":  $\blacksquare \rightarrow$  "Phone"  $\rightarrow$  "Call History"
- 2 Select the desired entry from the list.
- 3 Press the 🕾 switch on the steering wheel or select 🕋

### Call history list

- If you make a call to or receive a call from a number registered in the phonebook, the name is displayed in the call history.
- If you make multiple calls to the same number, only the last call made is displayed in the call history.

### International calls

Depending on the mobile phone in use, you may not be able to make international calls. Calling by using the latest call history entry

- 1 Press the 🕾 switch on the steering wheel to display the phone top screen.
- **2** Press the C switch on the steering wheel to display the "Call History" screen.
- $\fbox{3}$  Press the C switch on the steering wheel to select the latest call history entry.

Lexus Display Audio system

# **316** 5-9. Bluetooth<sup>®</sup> Phone

# **Receiving a call**

When a call is received, the following screen is displayed together with a sound.




### International calls

Depending on the cellular phone in use, received international calls may not be displayed correctly.

# Speaking on the phone

The following screen is displayed when speaking on the phone.



### To adjust the call volume

Select "Transmit Volume". To restore default volume, move the controller to the left on the "Transmit Volume" screen and then select "Default".

### To adjust in call volume

Move the controller to the left and then select "In-call Volume". You can also adjust the volume using the steering switches or volume knob.

### To prevent the other party from hearing your voice

Select "Mute".

### Inputting tones

When using phone services such as an answering service or a bank, you can store phone numbers and code numbers in the contacts using "p" or "w" symbols (eg. 056133 w 0123p#1).

- Contact including a phone number only
- Move the controller to the left and then select "0-9".
- **2** Input the number.
- Phone number containing a "p" symbol

When the "p" symbol is dialed in an outgoing call, there will be a pause for 2 seconds before the following digits are dialed automatically.

# Lexus Display Audio system

317

### **318** 5-9. Bluetooth<sup>®</sup> Phone

Phone number containing a "w" symbol

When the "w" symbol is dialed in an outgoing call, you need to go to the "Release Tones" screen to dial the following digits. Move the controller to the left and then select "Release Tones".

### To transfer a call

Select "Handset Mode" to change from a hands-free call to a cellular phone call or vice versa.

### To hang up

Press the 🕾 switch on the steering wheel or select 🕋

### Call waiting


When a call is interrupted by a third party while talking, an incoming call message will be displayed.

To talk with the other party:

Press the  $\mathfrak{S}$  switch on the steering wheel or select  $\overline{\mathfrak{S}}$ .

To refuse the call:

Press the  $\bigcirc$  switch on the steering wheel or select  $\bigcirc$ .



Every time you press the C switch on the steering wheel or select C during call waiting, you will be switched to the other party.

### Transferring calls

- It is not possible to transfer from hands-free to the cellular phone while driving.
- If you transfer from the cellular phone to hands-free, the hands-free screen will be displayed, and you can operate the system using the screen.
- Transfer method and operation may vary according to the cellular phone used.
- For operation of the cellular phone in use, see the phone's manual.

### Call waiting operation

Call waiting operation may differ depending on your phone company and cellular phone.

5-9. Bluetooth<sup>®</sup> Phone

# Using a Bluetooth<sup>®</sup> phone message

Once a MAP-profile compatible Bluetooth phone is registered, you can check the E-mail/SMS/MMS and reply to a message using the following procedures:

### Checking messages

- **1** Go to message screen:  $\longrightarrow$  "Phone"  $\rightarrow$  "Messages"
- **2** Select a message.

Moving the controller to the left while on the message screen displays the setting screen. ( $\rightarrow$ P. 327)

Move the controller to the right while on the message screen and then select an account to display a message list for the selected account.

### Message screen

Selecting "Next" or "Previous" displays the next or previous message. If a message is too long, select "Read More" to display the full text.

Option menu

Move the controller to the left while on the message screen.

- Select a prepared message and send a return message.
- 2 Call a sender.

If more than one phone number is registered for a sender, a phone number selection screen will be displayed.



- 3 Call a phone number written in a message.
- ④ Select "Play" to have a message read out loud. Select "Stop" to stop this function.
- (5) Select "Mark Unread" to mark mail that has been read as unread. Select "Mark Read" to mark mail that has not been read as read.

319

### Replying to a message

- 1 Move the controller to the left while on the message screen.
- 2 Select "Quick Message" to display the "Quick Message" screen.
- **3** Select the desired message and then select "Send".

### Editing a quick message

- 1 Move the controller to the left while on the message screen.
- 2 Select "Quick Message" and then the desired message. Move the controller to the left while the desired message is displayed.
- **3** Select "Edit".

To return to the default message after editing, select "Default".

### Receiving a message popup function

This function is available when the "E-mail Notification Popup" or "SMS/MMS Notification Popup" are set to on. ( $\rightarrow$ P. 327)

 "Incoming E-mail Display" or "Incoming SMS/MMS Display" are set to "Drop-Down"

When E-mail/ SMS/MMS are received, the incoming message is displayed on the upper side of the screen with a sound.

 "Incoming E-mail Display" or "Incoming SMS/MMS Display" are set to "Full Screen"

When E-mail/ SMS/MMS are received, the incoming message screen is displayed with a sound and it can be operated on the screen.

- 1 Check the message.
- 2 Refuse to check the message.
- 3 Call to receive the message sender's phone number.



# Using the steering wheel switches

The steering wheel switches can be used to operate a connected cellular phone.

### Operating a telephone using the steering wheel switches

1 Volume switch

During an incoming call: Adjusts the ring tone volume

During speaking on the phone: Adjusts in call volume

The voice guidance volume cannot be adjusted using this button.

- Off hook switch
  - Start call
  - Receiving
  - Phone top screen display
- 3 On hook switch
  - End call
  - Refuse call
- (4) Talk switch

Press: Turns the voice command system on

Press and hold: Turns the voice command system off



# **322** 5-9. Bluetooth<sup>®</sup> Phone

# Bluetooth<sup>®</sup> phone settings

You can adjust the hands-free system to your desired settings.

### "Phone/Message Settings" screen

Go to "Phone/Message Settings":  $\longrightarrow$  "Setup"  $\rightarrow$  "Phone"

- Register and connect a Bluetooth<sup>®</sup> device. (→P. 302)
- ② Adjust the call volume and message readout volume. (→P. 322)
- ③ Change the contact/call history settings. (→P. 324)
- (4) Change messaging settings. ( $\rightarrow$ P. 327)
- (5) Change phone display settings. ( $\rightarrow$ P. 323)

### Sound settings

Go to "Sound Settings":  $\blacksquare \rightarrow$  "Setup"  $\rightarrow$  "Phone"  $\rightarrow$  "Sound Settings"

- 1 Change the ring tone type
- Adjust the ring tone volume
- 3 Adjust the message readout volume
- ④ Change the incoming SMS/MMS tone type
- 5 Adjust the incoming SMS/MMS tone volume
- 6 Change the incoming email tone type
- Adjust the incoming email tone volume
- 8 Adjust in call tone volume



ssage Setting

CLYAVAZI

IS350/250\_U (OM53758U)

# Phone display settings

Go to "Phone Display Settings":  $\blacksquare \rightarrow$  "Setup"  $\rightarrow$  "Phone"  $\rightarrow$  "Phone Display Settings"

- ① Change the incoming call display
- ② Set the phonebook/history transfer status notification display on/off




### To return to the default volume settings

Move the controller to the left and then select "Default".

# Contact settings

Individual phonebooks can be registered for a maximum of 5 phones in total. The data for 2500 contacts (up to 4 numbers per contact) can be registered in each phonebook.



Input the name, phone number and phone number type to add a new contact.

 Edit a contact (PBAP incompatible Bluetooth phones, or compatible phones with "Automatic Transfer" off)

Select the desired contact to edit.

1 Delete contacts (→P. 326) (PBAP incompatible Bluetooth phones, or compatible phones with "Automatic Transfer" off)

Return to the default settings

Move the controller to the left and select "Default".

## Transferring a phone number


You can transfer the phone numbers in your Bluetooth<sup>®</sup> phone to display audio system. Operation methods differ between PBAP compatible and PBAP incompatible Bluetooth<sup>®</sup> phones. If your cellular phone does not support either PBAP or OPP services, you cannot transfer contacts.

Go to "Transfer Contacts":  $\longrightarrow$  "Setup"  $\rightarrow$  "Phone"  $\rightarrow$  "Contact/Call History Settings"  $\rightarrow$  "Update Contacts from Phone"

▶ For PBAP compatible Bluetooth<sup>®</sup> phones when "Automatic Transfer" is set to on

Start the update automatically.

- ► For PBAP compatible Bluetooth<sup>®</sup> phones when "Automatic Transfer" is set to off and PBAP incompatible Bluetooth<sup>®</sup> phones
- Select to transfer the contact from the connected cellular phone and replace the current one.
- 2 Select to transfer the desired contact data from the connected cellular phone to add to the current one.



## **Registering favorites**

You can register the desired contact from the phonebook. Up to 15 contacts per phone can be registered.

- Go to "Add Favorite": → "Setup" → "Phone" → "Contact/Call History Settings" → "Add Favorite"
- **2** Choose the contact to register.

## **Removing favorites**

- Go to "Remove Favorite": → "Setup" → "Phone" → "Contact/Call History Settings" → "Remove Favorite"
- **2** Select the desired contacts.

You can select all contacts by selecting "Select All"

3 Move the controller to the left and select "Remove".

## Deleting the contacts data

- Go to "Delete Contact": → "Setup" → "Phone" → "Contact/Call History Settings" → "Delete Contacts"
- **2** Select the desired contacts.

You can select all contacts by selecting "Select All".

3 Move the controller to the left and select "Delete".

## Phonebook data

Phonebook data is managed separately for every registered phone. When another phone is connected, you cannot read the registered data.

When transferring contacts

Transfer contacts while the engine is running. If the cellular phone is OPP or PBAP compatible, you may need to input "1234" on the cellular phone for OBEX certification.

When you have selected "Replace contacts" or "Add contact" to transfer contacts

If the cellular phone does not support OPP service, you cannot use these functions. You can transfer the phonebook data only by operating your phone.

Transferring contacts while Bluetooth<sup>®</sup> audio is playing

 $\mathsf{Bluetooth}^{(\!\!\!\!\ensuremath{\mathbb{R}})}$  audio will disconnect. It will reconnect automatically when data transfer finishes. It may not reconnect depending on the phone which is connected.

# Messaging setting

Go to "Messaging Settings":  $\blacksquare \rightarrow$  "Setup"  $\rightarrow$  "Phone"  $\rightarrow$  "Messaging Settings"

- (1) Set the message forwarding from cellular phones on/off
- Set the automatic message read out function on/off
- ③ Set the new SMS/MMS notification display on/off
- ④ Set the new email notification display on/off
- 5 Set the add vehicle signature function on/off
- 6 Set the cellular phone's message read and unread status update function on/off.
- ⑦ Change the incoming SMS/MMS display.
- (8) Change the incoming email display.
- 9 Change the account name to "Service name" (names from the connected device) or "Fixed name" (pre-defined names).

## Restoring the default settings

Move the controller to the left then select "Default" on the "Messaging Settings" screen.

Lexus Display Audio system



12200

# What to do if... (Troubleshooting)

If there is a problem with the hands-free system or a Bluetooth<sup>®</sup> device, first check the table below.

▶ When using the hands-free system with a Bluetooth<sup>®</sup> device

The hands-free system or Bluetooth<sup>®</sup> device does not work.

The connected device may not be a compatible  $\mathsf{Bluetooth}^{\mathbb{R}}$  cellular phone.

→ For a list of specific devices which operation has been confirmed on this system, check with your Lexus dealer or the following website: http://www.lexus.com/MobileLink

The Bluetooth version of the connected cellular phone may be older than the specified version.

→ Use a cellular phone with Bluetooth version 2.0 or higher (recommended: Ver. 3.0 with EDR or higher). (→P. 334)

5-11. Bluetooth  $^{ extsf{R}}$ 

ŀ	A cellular phone cannot be registered.
	An incorrect passcode was entered on the cellular phone. → Enter the correct passcode on the cellular phone.
	he registration operation has not been completed on the cellular phone side. → Complete the registration operation on the cellular phone (approve registration on the phone).
	Dld registration information remains on either this system or the cellular phone. → Delete the existing registration information from both this system and the cellu- lar phone, then register the cellular phone you wish to connect to this system. (→P.303)
ŀ	A Bluetooth <sup>®</sup> connection cannot be made.
1	Another Bluetooth <sup>®</sup> device is already connected. $\rightarrow$ Manually connect the cellular phone you wish to use to this system. ( $\rightarrow$ P. 306)
E	Bluetooth <sup>®</sup> function is not enabled on the cellular phone. $\rightarrow$ Enable the Bluetooth <sup>®</sup> function on the cellular phone.
"	Check your telephone." message is displayed.
E	Bluetooth <sup>®</sup> function is not enabled on the cellular phone. $\rightarrow$ Enable the Bluetooth <sup>®</sup> function on the cellular phone.
	Dld registration information remains on either this system or the cellular phone. → Delete the existing registration information from both this system and the cellu- lar phone, then register the cellular phone you wish to connect to this system. (→P. 303)

A call cannot be made/received.

Your vehicle is in a "No Service" area. → Move to where "No Service" no longer appears on the display.

Lexus Display Audio system

## **330** 5-11. Bluetooth<sup>®</sup>

When using the phonebook

Phonebook data cannot be transferred manually/automatically.

The profile version of the connected cellular phone may not be compatible with transferring phonebook data.

→ For a list of specific devices which operation has been confirmed on this system, check with your Lexus dealer or the following website: http://www.lexus.com/MobileLink

Automatic phonebook transfer function on this system is set to off.  $\rightarrow$  Set automatic phonebook transfer function on this system to on. ( $\rightarrow$ P. 324)

Passcode has not been entered on the cellular phone.

ightarrow Enter the passcode on the cellular phone if requested (default passcode: 1234).

Transfer operation on the cellular phone has not completed.

→ Complete transfer operation on the cellular phone (approve transfer operation on the phone).

Phonebook data cannot be edited.

Automatic phonebook transfer function on this system is set to on.  $\rightarrow$  Set automatic phonebook transfer function on this system to off. ( $\rightarrow$ P. 324)

▶ When using the Bluetooth<sup>®</sup> message function

Messages cannot be viewed.

Message transfer is not enabled on the cellular phone.

→ Enable message transfer on the cellular phone (approve message transfer on the phone).

Automatic transfer function on this system is set to off.  $\rightarrow$  Set automatic transfer function on this system to on. ( $\rightarrow$ P. 327)

New message notifications are not displayed.

Notification of SMS/MMS/E-mail reception on this system is set to off.  $\rightarrow$  Set notification of SMS/MMS/E-mail reception on this system to on. ( $\rightarrow$ P. 327)

Automatic message transfer function is not enabled on the cellular phone.  $\rightarrow$  Enable automatic transfer function on the cellular phone.

## ► In other situations

Even though all conceivable measures have been taken, the symptom status does not change.
The cellular phone is not close enough to this system. $\rightarrow$ Bring the cellular phone closer to this system.
Radio interference has occurred. $\rightarrow$ Turn off Wi-Fi devices or other devices that may emit radio waves.
<ul> <li>The cellular phone is the most likely cause of the symptom.</li> <li>→ Turn the cellular phone off, remove and reinstall the battery pack, and then restart the cellular phone.</li> <li>→ Enable the cellular phone's Bluetooth<sup>®</sup> connection.</li> <li>→ Disable the Wi-Fi connection of the cellular phone.</li> <li>→ Stop the cellular phone's security software and close all applications.</li> <li>→ Before using an application installed on the cellular phone, carefully check its source and how its operation might affect this system.</li> </ul>

# Bluetooth®

## ■ When using the Bluetooth<sup>®</sup> audio system

- In the following situations, the system may not function.
  - If the portable audio player is turned off
  - If the portable audio player is not connected
  - If the portable audio player's battery is low
- There may be a delay if a cellular phone connection is made during Bluetooth<sup>®</sup> audio play.
- Depending on the type of portable audio player that is connected to the system, operation may differ slightly and certain functions may not be available.

## When using the hands-free system

- The audio system is muted when making a call.
- If both parties speak at the same time, it may be difficult to hear.
- If the received call volume is overly loud, an echo may be heard.
   If the Bluetooth<sup>®</sup> phone is too close to the system, quality of the sound may deteriorate and connection status may deteriorate.
- In the following situations, it may be difficult to hear the other party:
  - · When driving on unpaved roads
  - When driving at high speeds
  - If a window is open
  - If the air conditioning is blowing directly on the microphone
  - If there is interference from the network of the cellular phone
- Conditions under which the system will not operate
  - If using a cellular phone that does not support Bluetooth<sup>®</sup>
  - If the cellular phone is turned off
  - If you are outside of cellular phone service coverage
  - If the cellular phone is not connected
  - If the cellular phone's battery is low
  - When outgoing calls are controlled, due to heavy traffic on telephone lines, etc.
  - When the cellular phone itself cannot be used
  - When transferring phonebook data from the cellular phone

## ■ Bluetooth<sup>®</sup> antenna

The antenna is built into the display.

If the portable audio player is behind the seat or in the glove box or console box, or is touching or covered by metal objects, the connection status may deteriorate. If the cellular phone is behind the seat or in the console box, or touching or covered by metal objects, the connection status may deteriorate.

## Battery charge/signal status

- This display may not correspond exactly with the portable audio player or cellular phone itself.
- This system does not have a charging function.
- $\bullet$  The portable audio player or cellular phone battery will be depleted quickly when the device is connected to Bluetooth  $^{\textcircled{R}}.$

## When using the Bluetooth<sup>®</sup> audio and hands-free system at the same time

The following problems may occur.

- $\bullet$  The Bluetooth  $^{\textcircled{R}}$  audio connection may be interrupted.
- Noise may be heard during Bluetooth<sup>®</sup> audio playback.

## About the contact in this system

The following data is stored for every registered cellular phone. When another phone is connecting, you cannot read the registered data.

- Contact data
- Call history
- Favorite
- Message

When removing a Bluetooth  ${}^{\textcircled{R}}$  phone from the system, the above-mentioned data is also deleted.

## About Bluetooth<sup>®</sup>

 $\mathsf{Bluetooth}^{\circledast}$  is a registered trademark of  $\mathsf{Bluetooth}\,\mathsf{SIG},\mathsf{Inc}.$ 

The Bluetooth<sup>®</sup> word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by PIONEER Corporation is under license. Other trademarks and trade names are those of their respective owners.



## Compatible models

The Bluetooth  $^{\textcircled{R}}$  audio system supports portable audio players with the following specifications

- Bluetooth<sup>®</sup> specifications:
  - Ver. 2.0 or higher (Recommended: Ver. 3.0 +EDR or higher)
- Profiles:
  - A2DP (Advanced Audio Distribution Profile) Ver. 1.0, or higher (Recommended: Ver. 1.2 or higher)
  - This is a profile to transmit stereo audio or high quality sound to the audio system.
  - AVRCP (Audio/Video Remote Control Profile) Ver. 1.0 or higher (Recommended: Ver. 1.4 or higher)
  - This is a profile to allow remote control the A/V equipment.

However, please note that some functions may be limited depending on the type of portable audio player connected.

The hands-free system supports cellular phones with the following specifications.

- Bluetooth<sup>®</sup> specification:
  - Ver. 2.0 or higher (Recommended: Ver. 3.0 +EDR or higher)
- Profiles:
  - HFP (Hands Free Profile) Ver. 1.0 or higher (Recommended: Ver. 1.6 or higher) This is a profile to allow hands-free phone calls using a cellular phone or head set. It has outgoing and incoming call functions.
  - OPP (Object Push Profile) Ver. 11 or higher (Recommended: Ver. 1.1) This is a profile to transfer phonebook data. When a Bluetooth<sup>®</sup> compatible cellular phone has both PBAP and OPP. OPP cannot be used.
  - PBAP (Phone Book Access Profile) Ver. 1.0 or higher (Recommended: Ver. 1.1) This is a profile to transfer phonebook data.
  - MAP (Message Access Profile) Ver.1.0 or higher This is a profile to using phone message.

If the cellular phone does not support HFP, you cannot register it with the hands-free system. OPP, PBAP or MAP services must be selected individually.

5-11. Bluetooth®

Certification

NOTE: FCC ID:AJDK066 IC ID:775E-K066

This device complies with Part 15 of FCC Rules and Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of this device.

Le présent appareil est conforme aux la partie 15 des règles de la FCC et CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

CAUTION:

Radio Frequency Radiation Exposure

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines in Supplement C to OET65 and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment should be installed and operated keeping the radiator at least 20cm or more away from person's body (excluding extremities: hands, wrists, feet and ankles).

Cet équipement est conforme aux limites d'exposition aux rayonnements énoncées pour un environnement non contrôlé et respecte les règles les radioélectriques (RF) de la FCC lignes directrices d'exposition dans le Supplément C à OET65 et d'exposition aux fréquences radioélectriques (RF) CNR-102 de l'IC. Cet équipement doit être installé et utilisé en gardant une distance de 20 cm ou plus entre le dispositif rayonnant et le corps (à l'exception des extrémités : mains, poignets, pieds et chevilles).

Co-location:

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

## Reconnecting the portable audio player

If the portable audio player is disconnected due to poor reception when the engine switch is in ACCESSORY or IGNITION ON mode, the system automatically reconnects the portable audio player.

If you have switched off the portable audio player yourself, follow the instructions below to reconnect:

- Select the portable audio player again
- Enter the portable audio player

## When you sell your car

Be sure to delete your personal data. ( $\rightarrow$ P. 270)

# A CAUTION

## While driving

Do not operate the portable audio player, cellular phone or connect a device to the  $\mathsf{Bluetooth}^{\mathbb{R}}$  system.

## Caution regarding interference with electronic devices

- Your audio unit is fitted with Bluetooth<sup>®</sup> antennas. People with implanted pacemakers or cardiac defibrillators should maintain a reasonable distance between themselves and the Bluetooth<sup>®</sup> antennas. The radio waves may affect the operation of such devices.
- Before using Bluetooth<sup>®</sup> devices, users of any electrical medical device other than implanted pacemakers and implanted cardiac defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves. Radio waves could have unexpected effects on the operation of such medical devices.

## ▲ NOTICE

#### When leaving the vehicle

Do not leave your portable audio player or cellular phone in the vehicle. The inside of the vehicle may become hot, causing damage to the portable audio player or cellular phone.

USB1 Photo USB2 Photo

Traffic Incidents

337

CLYAVA ZOZ

# "Information" screen

## Display "Information" screen

Go to "Information":  $\blacksquare \rightarrow$  "Info"

- 1 Display the fuel consumption.  $(\rightarrow P. 92)$
- ② Display the "USB Photo" screen.
   (→P.338)
- (3) Display the weather information. ( $\rightarrow$ P. 340)
- 4 Display the traffic information map.

# Traffic information map

Go to "Traffic Map":  $\blacksquare \rightarrow$  "Info"  $\rightarrow$  "Traffic Incidents"

- 1 Current position of your car
- 2 Traffic information line

The line color means the following:

Red: Heavy congestion

Yellow: Moderate traffic

Green: Freely flowing traffic



Lexus Display Audio system

# **338** 5-12. Other function

# **USB** photo

Connecting a USB memory device enables you to enjoy photo on the Lexus Display Audio display.

## USB photo screen

Go to "USB Photo":  $\longrightarrow$  "Info"  $\rightarrow$  "USB1 Photo" or "USB2 Photo"

## Connecting a USB memory device

→P. 266

## Menu screen

Move the controller to the left to display the menu screen.

- (1) Change the full screen mode.
- Select to set the slide show display on/off.
- Start the slide show at a selected folder.
- ③ Change the play speed.
- (4) Change the play mode.



## Selecting a folder and a file

- 1 Move the controller to the right and select "Browse".
- 2 Select the desired folder, and then select a desired file to begin using the selected folder.

5-12. Other function

USB memory functions

→P. 297

# ■ USB memory

- Compatible devices USB memory device that can be used for JPEG display.
- Compatible device formats
  - The following device format can be used:
  - USB communication format: USB2.0 FS (480 Mbps)
  - File system format: FAT16/32 (Windows)
  - Correspondence class: Mass storage class
- JPEG file compatibility
  - Compatible image size: Maximum 10MB
  - Compatible pixel size: Maximum 10,000,000 pixels

#### NOTICE $\Lambda$

## If the console box lid cannot be fully closed

→P. 299

To prevent damage to the USB memory device or its terminals

 $\rightarrow P.299$ 

# Lexus Display Audio system

# **340** 5-12. Other function

# Weather information

Weather information for the selected city is displayed.

## How to check the weather information

- **1** Go to "Weather":  $\longrightarrow$  "Info"  $\rightarrow$  "Weather"
- **2** Select the desired city/location.
- 1 Current location of your car
- Select of the recently checked location list

Select the desired location on the recently checked location list.

- 3 Select of the National City list. Select the region on the region list and then select the city on the National City list.
- 4 Select of the local location list


Select the location on the local location list.

- **3** Select the time
- 1 Display the current weather information.
- Display the 3 days weather information.

You can display detail of a week, move the controller right and then select the desired week.

 $\bigcirc$  Display the 6/12 hour weather information.





CLYAVAZ203

# Voice command system

The voice command system enables the audio and hands-free systems to be operated using voice commands.

Operations of the voice command system can be performed by selecting the menu corresponding to each function on the right part of the screen. Even if any menu is selected, commands displayed on all menus can be operated.

## Using the voice command system

- **1** Press the talk switch.
  - To cancel the voice command system, press and hold the talk switch.
- **2** After a beep sounds, say the desired command.

On the list screen, you can select the desired command.

## Menu screen

To display the menu screen, move the controller to the left.


- (1) Offer examples of commands and operation methods
- 2 Adjust the settings for voice guidance volume and voice recognition prompts. ("Hints" screen)  $(\rightarrow P. 271)$
- 3 Start over voice recognition (except "Hints" screen)
- 4 Cancel voice recognition


# ■ Microphone

→P. 312

When using the microphone

- It is unnecessary to speak directly into the microphone when giving a command.
- Wait for the confirmation beep before speaking a command.





Lexus Display Audio system

- Voice commands may not be recognized if:
  - Spoken too quickly.
  - Spoken at a low or high volume.
  - The roof or windows are open.
  - Passengers are talking while voice commands are spoken.
  - The air conditioning speed is set high.
  - The air conditioning vents are turned towards the microphone.
- In the following conditions, the system may not recognize the command properly and using voice commands may not be possible:
  - The command is incorrect or unclear. Note that certain words, accents or speech patterns may be difficult for the system to recognize.There is excessive background noise, such as wind noise.

### When searching for a track

- A USB memory or iPod must be connected to enable track searching and playback.  $(\rightarrow P. 266)$
- When a USB memory or iPod is connected, recognition data is created so tracks can be searched using voice commands.
- Recognition data is updated under the following conditions:
  - When the USB memory or iPod data has changed.
  - When the voice recognition language is changed.  $(\rightarrow P. 268)$
- While the recognition data is being created or being updated, a track search cannot be performed using a voice command.

## ■ The Gracenote<sup>®</sup> media database

→P. 291

## Casual speech recognization

Due to natural language speech recognition technology, this system enables recognition of a command when spoken naturally. However, the system cannot recognize every variation of each command.

In some situations, it is possible to omit the command for the procedure and directly state the desired operation.

This function is available in English, Spanish and French.

# Expression examples for each function

Command	Expression examples
"Call <name> <type>"</type></name>	Get me <robert brown="">. I need to call <robert brown=""> at <work> right away.</work></robert></robert>
"Dial <number>"</number>	Please dial the number <3334445555>. Ring <3334445555>.
"Play Artist <name>"</name>	Play the artist <xxxxx>. I'd like to hear the band <xxxxx>.*</xxxxx></xxxxx>
"Play Album <name>"</name>	Play album <xxxxx>. Music from album <xxxxx>.*</xxxxx></xxxxx>

\*: Say the desired artist name or album name in the place of the "<".

# Command list

Some recognizable voice commands and their actions are shown below as examples.

► Basic

Command	Action
"Help"	Prompts voice guidance to offer examples of com- mands or operation methods
"Go Back"	Returns to the previous screen
"Go to <tab>"</tab>	Displays the command list of the selected tab

# 344 5-12. Other function

# ▶ Phone

Command Action	
"Redial"	Places a call to the phone number of the latest outgo- ing call
"Call Back"	Places a call to the phone number of latest incoming call
"Show Recent Calls"	Displays the call history screen
"Dial <phone number="">"</phone>	Places a call to the said phone number
"Call <contacts> <phone- types&gt;"</phone- </contacts>	Place a call to the said phone type of the contact from the phone book

# Audio

Command	Action
"Play Playlist <playlists>"</playlists>	Plays tracks from the selected playlist
"Play Artist <artist>"</artist>	Plays tracks from the selected artist
"Play Song <songs>"</songs>	Plays the selected track
"Play Album <albums>"</albums>	Plays tracks from the selected album
"Turn Music On/Off"	Turns the audio system on/off
Audio source name	Selects audio source

## ► Info

Command	Action
"Show Forecast"	Displays weather information
"Show Traffic"	Displays traffic information

# IS350/250\_U (OM53758U)

# Interior features

6

# 6-1. Using the air conditioning system

## 6-2. Using the interior lights

Interior I	ights list	356
• Interi	or lights	
-		0.5.7

## 6-3. Using the storage features

List of storage features	358
• Glove box	359
• Console box	359
• Cup holders/	
bottle holders	360
Trunk features	362

# 6-4. Using the other interior features Other interior features Sun visors Sun visors 365 Vanity mirrors 365 Clock 365 Power outlet 366 Armrest 367 Rear sunshade 369 Coat hooks 370 Compass 378

# 345

IS350/250\_U (OM53758U)

# Automatic air conditioning system

Air outlets and fan speed are automatically adjusted according to the temperature setting.


Vehicles with a Lexus Display Audio system: Press the "MENU" button on the Lexus Display Audio controller, then select "Climate" to display the air conditioning operation screen.

For details on the Lexus Display Audio controller, refer to "Lexus Display Audio controller" on P. 262.

Vehicles with a navigation system: Press the "MENU" button on the Remote Touch, then select "Climate" to display the air conditioning control screen.

For details on the Remote Touch, refer to the "Navigation System Owner's Manual".


Air conditioning controls



## Adjusting the temperature setting

To adjust the temperature setting, touch and slide your finger up or down on the sensor.

The temperature setting can also be adjusted by touching on the sensor. When the temperature setting is changed, a buzzer sounds.



## Fan speed setting

Press et la speed.

Press	8	to decrease the fan speed.
-------	---	----------------------------

Change the airflow mode

To change the airflow, press

The air outlets used are switched each time the button is pressed.


- Other functions
  - Switching between outside air and recirculated air modes  $(\rightarrow P. 349)$
  - Defogging the windshield  $(\rightarrow P. 350)$
  - Defogging the rear window and outside rear view mirrors ( $\rightarrow$ P. 350)

## Air conditioning control screen

- With a Lexus Display Audio
  - Adjust the left-hand side temperature setting.
  - 2 Adjust the fan speed setting
  - (3) Select to set auto mode on/off, fan off and displaying the option control screen ( $\rightarrow$ P. 348)
  - (4) Select the air flow mode
- 5 Adjust the right-hand side temperature setting
- 1 Move the Lexus Display Audio controller left/right to select the desired item (1) to (5).
- 2 When (1), (2) or (5) is selected:

Move the controller forward/backward or turn it left/right for adjusting. When (3) or (4) is selected:

Move the controller forward/backward or turn it left/right to select a screen button, then press the controller.



Interior features

# 348 6-1. Using the air conditioning system

- ▶ With a navigation system
  - 1 Adjust the left-hand side temperature setting
  - 2 Adjust the fan speed setting
  - ③ Select the air flow mode
  - Adjust the right-hand side temperature setting
  - (5) Display the option control screen
     (→P. 348)
  - 6 Turn the fan off
  - ⑦ Select to set auto mode on/off



To adjust or select settings, move the Remote Touch knob to select the screen button, and then press the Remote Touch knob to enter the selected function.

## Option control screen

The functions can be switched on and off.

- (1) Cooling and dehumidification function
- ② Adjusting the temperature for driver and passenger seats separately ("DUAL" mode) (→P. 349)
- ③ Removing pollen from the air (Micro dust and pollen filter) (→P. 349)

		n	Optic
		A/C	
	2	DUAL	
	3	÷4	1
CU	an an tao an	0 2000 N	AVA

## Using automatic mode

- 1 Press \_\_\_\_\_, or select "AUTO" on the air conditioning control screen.
- **2** Adjust the temperature setting.
- **3** To stop the operation, press **even** or select "OFF" on the air conditioning control screen.
- If the system is operated manually in automatic mode

If the fan speed setting or air flow modes are operated, the automatic mode indicator goes off. However, automatic mode for functions other than that operated are maintained.

 Adjusting the temperature for driver and passenger seats separately ("DUAL" mode)

To turn on the "DUAL" mode, perform any of the following procedures:

- Press DLIAL .
- Select "DUAL" on the option control screen.
- Adjust the passenger's side temperature setting.

The indicator comes on when the "DUAL" mode is on.

While in "DUAL" mode, the temperature of the rear air outlets is set at the righthand side temperature setting.

## Other functions

## Switching between outside air and recirculated air modes

Press **to change to recirculated air mode**.

Press to change to outside air mode.

The indicator above the selected button comes on.

## Micro dust and pollen filter

Pollen is removed from the air and the air flows to the upper part of the body.

Select Select on the option control screen.

When the micro dust and pollen filter is on, is displayed on the air conditioning control screen.

In order to prevent the windshield from fogging up when the outside air is cold, the dehumidification function may operate.

The pollens are filtered out even if the micro dust and pollen filter is turned off.

6

Interior features

## Defogging the windshield

Defoggers are used to defog the windshield and front side windows.

Press 📟

Set the outside/recirculated air mode button to outside air mode if the recirculated air mode is used. (It may switch automatically.)

To defog the windshield and the side windows early, turn the air flow and temperature up.

To return to the previous mode, press early again when the windshield is defogged.

## Defogging the rear window and outside rear view mirrors

Defoggers are used to defog the rear window, and to remove raindrops, dew and frost from the outside rear view mirrors.

Press @@

The defoggers will automatically turn off after a period of time.


## Windshield wiper de-icer (if equipped)

This feature is used to prevent ice from building up on the windshield and wiper blades.

Turns on/off.

The indicator comes on when the windshield wiper de-icer is on.


The windshield de-icer will automatically turn off after a period of time.



## Air outlets

## Location of air outlets


The air outlets and air volume changes according to the selected airflow mode.



Adjusting the position of and opening and closing the air outlets

## Front

▶ Rear



① Direct air flow to the left or right, up or down

To close the vent, move the knob to the most outside position. (rear outlets only)

2 Turn the knob to open or close the vent

 Registering air conditioning settings to electronic keys (vehicles with driving position memory)

- Unlocking the vehicle using an electronic key and turning the engine switch to IGNI-TION ON mode will recall that key's registered air conditioning settings.
- When the engine switch is turned off, the current air conditioning settings will automatically be registered to the electronic key that was used to unlock the vehicle.
- The system may not operate correctly if more than one electronic key is in the vicinity or if the smart access system with push-button start is used to unlock a passenger door.
- The doors that can recall the air conditioning setting\* when unlocked using the smart access system with push-button start can be changed. For details, contact your Lexus dealer.
- \*: The doors that can recall the driving position memory are changed at the same time.

6

Interior features

## Using automatic mode

Fan speed is adjusted automatically according to the temperature setting and the ambient conditions.

Therefore, the fan may stop for a while until warm or cool air is ready to flow immediately after **rest** is pressed or "AUTO" is selected.

## Using the voice command system (vehicles with a navigation system)

Air conditioning system can be operated using voice commands. For details, refer to the "Navigation System Owner's Manual".

#### Fogging up of the windows

The windows will easily fog up when the humidity in the vehicle is high. Turning ("A/C") on will dehumidify the air from the outlets and defog the windshield effectively.

- If you turn ("A/C") off, the windows may fog up more easily.
- The windows may fog up if the recirculated air mode is used.

## Outside/recirculated air mode

- When driving on dusty roads such as tunnels or in heavy traffic, set the outside/recirculated air mode button to the recirculated air mode. This is effective in preventing outside air from entering the vehicle interior. During cooling operation, setting the recirculated air mode will also cool the vehicle interior effectively.
- Outside/recirculated air mode may automatically switch depending on the temperature setting or the inside temperature.
- When the outside temperature exceeds 75°F (24°C) and the air conditioning system is on
  - In order to reduce the air conditioning power consumption, the air conditioning system may switch to recirculated air mode automatically. This may also reduce fuel consumption.
  - Recirculated air mode is selected as a default mode when the engine switch is turned to IGNITION ON mode.
  - It is possible to switch to outside air mode at any time by pressing

## Operation of the air conditioning system in Eco drive mode

In Eco drive mode, the air conditioning system is controlled as follows to prioritize fuel efficiency:

- Engine speed and compressor operation controlled to restrict heating/cooling capacity
- Fan speed restricted when automatic mode is selected

To improve air conditioning performance, perform the following operations:

- Adjust the fan speed
- Turn off Eco drive mode

■ When the outside temperature falls to nearly 32°F(0°C)

The dehumidification function may not operate even when **even** is pressed or "A/C" is selected.

- Air conditioning odors
  - During use, various odors from inside and outside the vehicle may enter into and accumulate in the air conditioning system. This may then cause odor to be emitted from the vents.
  - To reduce potential odors from occurring:
    - It is recommended that the air conditioning system be set to outside air mode prior to turning the vehicle off.
      The start timing of the blower may be delayed for a short period of time immediately.
    - The start timing of the blower may be delayed for a short period of time immediately after the air conditioning system is started in automatic mode.

## Air conditioning filter

→P. 425

## Customization

Settings (e.g. A/C Auto switch operation) can be changed. (Customizable features  $\rightarrow$  P. 531)

## 

## To prevent the windshield from fogging up

- Do not use <u>even</u> during cool air operation in extremely humid weather. The difference between the temperature of the outside air and that of the windshield can cause the outer surface of the windshield to fog up, blocking your vision.
- Do not place anything on the instrument panel which may cover the air outlets. Otherwise, air flow may be obstructed, preventing the windshield defoggers from defogging.



### To prevent burns

- Do not touch the rear view mirror surfaces when the outside rear view mirror defoggers are on.
- Do not touch the glass at lower part of the windshield or to the side of the front pillars when the windshield wiper de-icer is on.

## **NOTICE**

## To prevent battery discharge

Do not leave the air conditioning system on longer than necessary when the engine is stopped.

6

Interior features

# Heated steering wheel<sup>\*</sup>/seat heaters<sup>\*</sup>/seat ventilators<sup>\*</sup>

Heated steering wheel and seat heaters heat the side grips of the steering wheel and seats, respectively. Seat ventilators maintain good airflow by blowing air from the seats.

## A CAUTION

- Care should be taken to prevent injury if anyone in the following categories comes in contact with the steering wheel or seats when the heater is on:
  - Babies, small children, the elderly, the sick and the physically challenged
  - Persons with sensitive skin
  - Persons who are fatigued
  - Persons who have taken alcohol or drugs that induce sleep (sleeping drugs, cold remedies, etc.)
- Observe the following precautions to prevent the minor burns or overheating
  - Do not cover the seat with a blanket or cushion when using the seat heater.
  - Do not use seat heater more than necessary.

# 

- Do not put heavy objects that have an uneven surface on the seat and do not stick sharp objects (needles, nails, etc.) into the seat.
- To prevent battery discharge, do not use the functions when the engine is off.

## Heated steering wheel

Turn the heated steering wheel on/off

The indicator light comes on when the heated steering wheel is operating.



\*: If equipped


IS350/250\_U (OM53758U)

- The heated steering wheel can be used when the engine switch is in IGNITION ON mode.
- The heated steering wheel will automatically turn off after about 30 minutes.

## Seat heaters

Each time the switch is pressed, the intensity of the seat heater changes and the level indicator lights (amber) light as follows:

Hi (3 segments lit)  $\rightarrow$  Mid (2 segments lit)  $\rightarrow$  Lo (1 segment lit)  $\rightarrow$  Off



- The seat heaters can be used when the engine switch is in IGNITION ON mode.
- Seat heater timer control: The seat heater automatically switches from Hi→Mid→Lo. The switching timing differs depending on the temperature inside the cabin etc. when the seat heater was operated.
- The seat heater timer control can be turned on and off by pressing the seat heater switches for the driver side and front passenger side at the same time until a buzzer sounds. The buzzer will beep once when the seat heater timer control is turned on and twice when it is turned off.

## Seat ventilators

Each time the switch is pressed, the intensity of the seat ventilator changes and the level indicator lights (green) light as follows:

Hi (3 segments lit)  $\rightarrow$  Mid (2 segments lit)  $\rightarrow$  Lo (1 segment lit)  $\rightarrow$  Off




The seat ventilators can be used when the engine switch is in IGNITION ON mode.

6

Interior features

# **356** 6-2. Using the interior lights


# Interior lights list



6-2. Using the interior lights

# Interior lights

- 1 Turns the light on/off
- 2 Turns the door position on/off




## Personal lights

Turns the light on/off

▶ Front

▶ Rear



- Illuminated entry system: The lights automatically turn on/off according to engine switch mode, the presence of the electronic key, whether the doors are locked/ unlocked, and whether the doors are opened/closed.
- If the interior lights remain on when the door is not fully closed and the interior light main switch is in the door position, the lights will go off automatically after 20 minutes.
- Setting (e.g. the time elapsed before lights turn off) can be changed. (Customizable features: →P. 525)

## 

To prevent battery discharge, do not leave the lights on longer than necessary when the engine is off.

6

# **358** 6-3. Using the storage features

List of storage features

# 3 2 (4 (3) CLY63AZ001 (→P. 359) 1 Glove box 3 Cup holders (if equipped) (→P. 360) 2 Bottle holders (→P. 360) (→P. 359) 4 Console box **CAUTION** • Do not leave glasses, lighters or spray cans in the storage spaces, as this may cause the following when cabin temperature becomes high:


- Glasses may be deformed by heat or cracked if they come into contact with other stored items.
- Lighters or spray cans may explode. If they come into contact with other stored items, the lighter may catch fire or the spray can may release gas, causing a fire hazard.
- When driving or when the storage compartments are not in use, keep the lids closed. In the event of sudden braking or sudden swerving, an accident may occur due to an occupant being struck by an open lid or the items stored inside.

IS350/250\_U (OM53758U)

## 6-3. Using the storage features


# Glove box

- 1 Open (press the button)
- 2 Unlock with the mechanical key
- 3 Lock with the mechanical key



359


- The glove box light turns on when the engine switch is in ACCESSORY or IGNITION ON mode.
- The trunk opener main switch is located in the glove box.  $(\rightarrow P. 110)$
- The insert inside the glove box can be removed.



# Console box

Push the knob.

Lift by hand to fully open the console box.



6

Interior features


## **360** 6-3. Using the storage features

## Cup holders/bottle holders

- Cup holders
- ▶ Front




► Rear (if equipped)




To open, pull down the armrest and press the button and release the rear cup holder on the armrest.

### Bottle holders



- When storing a bottle, close the cap.
- The bottle may not be stored depending on its size or shape.
- The rubber mats at the bottom of the front cup holders can be removed.

6-3. Using the storage features



361

IS350/250\_U (OM53758U)


## **362** 6-3. Using the storage features

# **Trunk** features

## Cargo hooks

Raise the hooks when needed.

The cargo hooks are provided for securing loose items.




# **CAUTION**

To avoid injury, always return the cargo hooks to their stowed positions when not in use.


## First-aid kit storage belt

- 1 Loosen the belt
- 2 Tighten the belt



### 6-3. Using the storage features


## Luggage mat




## **364** 6-3. Using the storage features

## Warning reflector storage belt

- 1 Loosen the belt
- 2 Tighten the belt




To prevent damage to the warning reflector storage belt when it is not in use, fold the belt (as shown in (1)) and secure it with the clip ((2)).



# Other interior features

## Sun visors

- (1) To set the visor in the forward position, flip it down.
- 2 To set the visor in the side position, flip down, unhook, and swing it to the side.



## Vanity mirrors

Slide the cover to open.


The light turns on when the cover is opened.



## Clock

The clock can be adjusted.

- (1) Pressing and holding will move the clock hands backward.
- 2 Pressing and holding will move the clock hands forward.



6

Interior features


IS350/250\_U (OM53758U)

## **366** 6-4. Using the other interior features

## Power outlet

The power outlet can be used for 12 V accessories that run on less than 10 A.

Open the lid.



- The power outlet can be used when the engine switch is in ACCESSORY or IGNI-TION ON mode.
- To fully close the console box with the cable routed to outside the console box, insert the cable into the holder.




## 🔨 NOTICE

- To avoid the damaging the power outlet, close the power outlet lid when the power outlet is not in use. Foreign objects or liquids that enter the power outlet may cause a short circuit.
- To prevent blown fuse, do not use an accessory that uses more than 12 V 10 A.
- To prevent battery discharge, do not use the power outlet longer than necessary when the engine is off.

## Armrest (if equipped)

Fold down the armrest for use.




NOTICE

To prevent damage to the armrest, do not apply too much load on the armrest.

## Rear sunshade (if equipped)

The rear sunshade can be raised and lowered.

Raise/lower



• The rear sunshade can be used when the engine switch is in IGNITION ON mode.

• The rear sunshade can be operated for approximately 1 minute even after the engine switch is turned to ACCESSORY mode or turned off.

 Reverse operation feature: To ensure adequate rear visibility, the rear sunshade automatically lowers when the shift lever is shifted to R.

However, the rear sunshade is raised again if any of the following occurs:

- The button is pressed again.\*
- The shift lever is shifted into P.

• The shift lever is shifted out of R, and the vehicle reaches a speed of 9 mph (15 km/h). If the engine is off when the rear sunshade has been lowered due to the reverse operation feature, it will not be raised even when the engine is turned on again and the vehicle reaches a speed of 9 mph (15 km/h). To raise the sunshade again, press the button.

\*: Occasionally, the reverse function may not be carried out after the switch has been pressed. Repeat the above operation to operate the function.

## **CAUTION**

When the rear sunshade is being operated, do not place fingers or other objects in the fastener section or in the opening. They may get caught, causing injury.

#### 🕂 NOTICE

- To prevent battery discharge, do not operate the rear sunshade when the engine is off.
- To ensure normal operation of the rear sunshade, observe the following precautions:
  - Do not place excessive load on the motor or other components of the rear sunshade.
  - Do not place objects where they may hinder opening and closing operations.
  - Do not attach items to the rear sunshade.
  - Keep the opening clean and clear of obstructions.
  - Do not operate the rear sunshade continuously for long periods of time.

## Assist grips

An assist grip installed on the ceiling can be used to support your body while sitting on the seat.



## **CAUTION**

Do not use the assist grip when getting in or out the vehicle or rising from your seat.

### 🕂 NOTICE

To prevent damage to the assist grip, do not put a heavy load on the assist grip.

### Coat hooks

The coat hooks are provided with the rear assist grips.



6

## **CAUTION**

Do not hang coat hangers or other hard or sharp objects on the hook. If the SRS curtain shield airbags deploy, these items may become projectiles, causing death or serious injury.

## Garage door opener


The garage door opener can be programmed to operate garage doors, gates, entry doors, door locks, home lighting systems, security systems, and other devices.

The garage door opener (HomeLink  $^{\textcircled{R}}$  Universal Transceiver) is manufactured under license from HomeLink  $^{\textcircled{R}}.$ 

## Programming the HomeLink®

The HomeLink<sup>®</sup> compatible transceiver in your vehicle has 3 buttons which can be programmed to operate 3 different devices. Refer to the programming method below appropriate for the device.

- 1 Indicator light
- 2 Buttons



## Before programming HomeLink<sup>®</sup>

- During programming, it is possible that garage doors, gates, or other devices may operate. For this reason, make sure that people and objects are clear of the garage door or other devices to prevent injury or other potential harm.
- It is recommended that a new battery be placed in the remote control transmitter for more accurate programming.
- Garage door openers manufactured after 1995 may be equipped with rolling code protection. If this is the case, you will need a stepladder or other sturdy, safe device to reach the "Learn" or "Smart" button on the garage door opener motor.

IS350/250\_U (OM53758U)

## Programming HomeLink<sup>®</sup>


Point the remote control transmitter for the device 1 to 3 in. (25 to 75 mm) from the HomeLink® buttons.

Keep the HomeLink<sup>®</sup> indicator light in view while programming.

## ▶ For U.S.A. owner's


**2** Press and hold the HomeLink<sup>®</sup> button you want to program and the handheld transmitter button simultaneously. When the HomeLink® indicator light changes from a slow to a rapid flash, you can release both buttons.





Programming has completed when the indicator light changes to a rapid flash.

- Programming an entry gate (for U.S.A. owners)/Programming a device in the Canadian market
- 2 With one hand, press and hold the HomeLink<sup>®</sup> button you want to program. With your other hand, press and release the remote control transmitter every 2 seconds and repeat this cycle until the HomeLink<sup>®</sup> indicator light starts to flash rapidly. Then, release the buttons.
- **3** Test the HomeLink<sup>®</sup> operation by pressing the newly programmed button and observing the indicator light:
  - If the indicator light is solid/ continuous, programming has been completed and your device should activate when the HomeLink<sup>®</sup> button is pressed and released.



• If the indicator light blinks rapidly for 2 seconds and then turns into a solid/continuous light, proceed with the following instructions 4 for programming a rolling code system.

Interior features


## **372** 6-4. Using the other interior features


Programming a rolling code system

4 Locate the "Learn" or "Smart" button on the garage door opener motor in the garage.

> This button can usually be found where the hanging antenna wire is attached to the unit. The name and color of the button may vary by manufacturer. Please refer to the operator's manual supplied with the garage door opener motor for details.


 Fress and release the "Learn" or "Smart" button.
 Perform 6 within 30 seconds after performing 5.





Press and hold the programmed HomeLink<sup>®</sup> button (located inside the vehicle) for 2 seconds and release it. Repeat this sequence (press/hold/release) up to 3 times to complete programming.

> If the garage door opener motor activates when the HomeLink<sup>®</sup> button is pressed, the garage door opener motor recognizes the HomeLink<sup>®</sup> signal.



Repeat the steps above to program another device for any of the remaining HomeLink<sup>®</sup> buttons.

# Reprogramming a single HomeLink<sup>®</sup> button


When the following procedure is performed, buttons which already have devices registered to them can be overwritten:

- $\blacksquare$  With one hand, press and hold the desired HomeLink<sup>®</sup> button.
- 2 When the HomeLink<sup>®</sup> indicator starts flashing, continue to hold the HomeLink<sup>®</sup> button and perform "Programming HomeLink<sup>®</sup>" from 1 (it takes 20 seconds for the HomeLink<sup>®</sup> indicator to start flashing).

## Erasing the entire HomeLink<sup>®</sup> memory (all three programs)

Press and hold the 2 outside buttons for 10 seconds until the indicator light flashes.

If you sell your vehicle, be sure to erase the programs stored in the HomeLink  $^{\textcircled{R}}$  memory.



### ■ Programs stored in the HomeLink<sup>®</sup> memory

- The registered codes are not erased even if the 12-volt battery cable is disconnected.
- If learning failed when registering a different code to a HomeLink<sup>®</sup> button that already has a code registered to it, the already registered code is not erased.

#### Certification for the garage door opener

▶ For vehicles sold in the U.S.A.

FCC ID: NZLWZLHL4

FCC ID: NZLOBIHL4

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### ► For vehicles sold in Canada

NOTE:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

NOTE:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

#### When support is necessary

Visit on the web at <u>www.homelink.com</u> or call 1-800-355-3515.

## **374** 6-4. Using the other interior features

# CAUTION When programming a garage door or other remote control device The garage door or other device may operate, so ensure people and objects are out of danger to prevent potential harm. Conforming to federal safety standards Do not use the HomeLink<sup>®</sup> compatible transceiver with any garage door opener or device that lacks safety stop and reverse features as required by federal safety standards. This includes any garage door that cannot detect an interfering object. A door or device without these features increases the risk of death or serious injury. When operating or programming HomeLink<sup>®</sup> Never allow a child to operate or play with the HomeLink<sup>®</sup> buttons.


IS350/250\_U (OM53758U)

# Compass\*

The compass on the inside rear view mirror indicates the direction in which the vehicle is heading.

## Operation

To turn the compass on or off, push the switch.



## **Displays and directions**

Display	Direction
N	North
NE	Northeast
E	East
SE	Southeast
S	South
SW	Southwest
W	West
NW	Northwest

Interior features


\*: If equipped

375

IS350/250\_U (OM53758U)

## **376** 6-4. Using the other interior features


## Calibrating the compass



The direction display deviates from the true direction determined by the earth's magnetic field. The amount of deviation varies according to the geographic position of the vehicle.

If you cross over a map boundary shown in illustration, the compass will deviate. To obtain higher precision or perfect calibration, refer to the following.

- Deviation calibration
- 1 Stop the vehicle in a place where it is safe to drive in a circle.
- 2 Press the switch until a number (1 to 15) appears on the compass display.




**3** Press the switch and referring to the map above, select the number of the zone where you are.

If the direction is displayed several seconds after adjustment, the calibration is complete.

## Circling calibration

When "C" appears on the display, drive the vehicle at 5 mph (8 km/h) or less in a circle until a direction is displayed.

If there is not enough space to drive in a circle, drive around the block until the direction is displayed.



#### Conditions unfavorable to correct operation

- The compass may not show the correct direction in the following conditions:
- The vehicle is stopped immediately after turning.
- The vehicle is on an inclined surface.
- The vehicle is in a place where the earth's magnetic field is subject to interference by artificial magnetic fields (underground car park/parking lot, under a steel tower, between buildings, roof car park/parking lot, near an intersection, near a large vehicle, etc.).
- The vehicle has become magnetized. (There is a magnet or metal object near the inside rear view mirror.)
- The battery has been disconnected.
- A door is open.

### A CAUTION

While driving the vehicle

Do not adjust the display. Adjust the display only when the vehicle is stopped.

When doing the circling calibration

Secure a wide space, and watch out for people and vehicles in the neighborhood. Do not violate any local traffic rules while performing circling calibration.

## NOTICE

#### To avoid compass malfunctions

Do not place magnets or any metal objects near the inside rear view mirror. Doing this may cause the compass sensor to malfunction.

#### To ensure normal operation of the compass

- Do not perform circling calibration of the compass in a place where the earth's magnetic field is subject to interference by artificial magnetic fields.
- During calibration, do not operate electric systems (moon roof, power windows, etc.) as they may interfere with the calibration.

Interior features

# Safety Connect<sup>\*</sup>


Safety Connect is a subscription-based telematics service that uses Global Positioning System (GPS) data and embedded cellular technology to provide safety and security features to subscribers. Safety Connect is supported by Lexus' designated response center, which operates 24 hours per day, 7 days per week.

Safety Connect service is available by subscription on select, telematics hardware-equipped vehicles.

By using the Safety Connect service, you are agreeing to be bound by the Telematics Subscription Service Agreement and its Terms and Conditions, as in effect and amended from time to time, a current copy of which is available at Lexus.com. All use of the Safety Connect service is subject to such thenapplicable Terms and Conditions.

### System components

- 1 "SOS" button
- LED light indicators
- 3 Microphone



### Services

Subscribers have the following Safety Connect services available:

- Automatic Collision Notification\*
  - Helps drivers receive necessary response from emergency service providers. ( $\rightarrow$ P. 380)
  - \*: U.S. Patent No. 7,508,298 B2
- Stolen Vehicle Location Helps drivers in the event of vehicle theft. (→P. 381)
- Emergency Assistance Button ("SOS")
   Connects drivers to response-center support. (→P. 381)
- Enhanced Roadside Assistance
   Provides drivers various on-road assistance. (→P. 381)

### Subscription

After you have signed the Telematics Subscription Service Agreement and are enrolled, you can begin receiving services.

A variety of subscription terms is available for purchase. Contact your Lexus dealer, call 1-800-25-LEXUS (1-800-255-3987) or push the "SOS" button in your vehicle for further subscription details.

### Safety Connect Services Information

- Phone calls using the vehicles Bluetooth<sup>®</sup> technology will not be possible during Safety Connect.
- Safety Connect is available beginning Fall 2009 on select Lexus models. Contact with the Safety Connect response center is dependent upon the telematics device being in operative condition, cellular connection availability, and GPS satellite signal reception, which can limit the ability to reach the response center or receive emergency service support. Enrollment and Telematics Subscription Service Agreement required. A variety of subscription terms is available; charges vary by subscription term selected.
- Automatic Collision Notification, Emergency Assistance and Stolen Vehicle Location will function in the United States, including Hawaii and Alaska, and in Canada, and Enhanced Roadside Assistance will function in the United States (except Hawaii) and in Canada. No Safety Connect services will function outside of the United States in countries other than Canada.
- Safety Connect services are not subject to section 255 of the Telecommunications Act and the device is not TTY compatible.

#### Languages

The Safety Connect response center will offer support in multiple languages. The Safety Connect system will offer voice prompts in English and Spanish. Please indicate your language of choice when enrolling.

When contacting the response center

You may be unable to contact the response center if the network is busy.

## Safety Connect LED light Indicators

When the engine switch is turned to IGNITION ON mode, the red indicator light comes on for 2 seconds then turns off. Afterward, the green indicator light comes on, indicating that the service is active.

The following indicator light patterns indicate specific system usage conditions:

- Green indicator light on = Active service
- Green indicator light flashing = Safety Connect call in process
- Red indicator light (except at vehicle start-up) = System malfunction (contact your Lexus dealer)
- No indicator light (off) = Safety Connect service not active

### Safety Connect services

### Automatic Collision Notification

In case of either airbag deployment or severe rear-end collision, the system is designed to automatically call the response center. The responding agent receives the vehicle's location and attempts to speak with the vehicle occupants to assess the level of emergency. If the occupants are unable to communicate, the agent automatically treats the call as an emergency, contacts the nearest emergency services provider to describe the situation, and requests that assistance be sent to the location.

### Stolen Vehicle Location

If your vehicle is stolen, Safety Connect can work with local authorities to assist them in locating and recovering the vehicle. After filing a police report, call the Safety Connect response center at 1-800-25-LEXUS (1-800-255-3987) and follow the prompts for Safety Connect to initiate this service.

In addition to assisting law enforcement with recovery of a stolen vehicle, Safety-Connect-equipped vehicle location data may, under certain circumstances, be shared with third parties to locate your vehicle. Further information is available at Lexus.com.

## Emergency Assistance Button ("SOS")

In the event of an emergency on the road, push the "SOS" button to reach the Safety Connect response center. The answering agent will determine your vehicle's location, assess the emergency, and dispatch the necessary assistance required.

If you accidentally press the "SOS" button, tell the response-center agent that you are not experiencing an emergency.

### Enhanced Roadside Assistance

Enhanced Roadside Assistance adds GPS data to the already included warranty-based Lexus roadside service.

Subscribers can press the "SOS" button to reach a Safety Connect responsecenter agent, who can help with a wide range of needs, such as: towing, flat tire, fuel delivery, etc. For a description of the Roadside Assistance services and their limitations, please see the Safety Connect Terms and Conditions, which are available at Lexus.com.

### Safety information for Safety Connect

Important! Read this information before using Safety Connect.

### Exposure to radio frequency signals

The Safety Connect system installed in your vehicle is a low-power radio transmitter and receiver. It receives and also sends out radio frequency (RF) signals.

In August 1996, the Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for mobile wireless phones. Those guidelines are consistent with the safety standards previously set by the following U.S. and international standards bodies.

- ANSI (American National Standards Institute) C95.1 [1992]
- NCRP (National Council on Radiation Protection and Measurement) Report 86 [1986]
- ICNIRP (International Commission on Non-Ionizing Radiation Protection) [1996]

Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. Over 120 scientists, engineers, and physicians from universities, and government health agencies and industries reviewed the available body of research to develop the ANSI Standard (C95.1).

The design of Safety Connect complies with the FCC guidelines in addition to those standards.

### Certification for Lexus Enform with Safety Connect

FCC ID: O9EGTM1 FCC ID: O6Y-CDMRF101 FCC ID: N7NGTM2

NOTE:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

# Maintenance and care

7

7-1.	Maintenance and care
	Cleaning and protecting the vehicle exterior
	Cleaning and protecting the vehicle interior
7-2.	Maintenance
	Maintenance requirements
	General maintenance
	Emission inspection and maintenance (I/M) programs
7-3.	Do-it-yourself maintenance
	Do-it-yourself service
	precautions
	Hood
	Positioning a floor jack
	Engine compartment 401
	Tires
	Tire inflation pressure
	Wheels 423
	Air conditioning filter
	Electronic key battery427
	Checking and replacing
	fuses
	Light bulbs432

IS350/250\_U (OM53758U)

## Cleaning and protecting the vehicle exterior

Perform the following to protect the vehicle and maintain it in prime condition:

- Working from top to bottom, liberally apply water to the vehicle body, wheel wells and underside of the vehicle to remove any dirt and dust.
- Wash the vehicle body using a sponge or soft cloth, such as a chamois.
- For hard-to-remove marks, use car wash soap and rinse thoroughly with water.
- Wipe away any water.
- Wax the vehicle when the waterproof coating deteriorates.

If water does not bead on a clean surface, apply wax when the vehicle body is cool.

#### Automatic car washes

- Fold the mirrors before washing the vehicle. Start washing from the front of the vehicle. Make sure to extend the mirrors before driving.
- Brushes used in automatic car washes may scratch the vehicle surface and harm your vehicle's paint.

#### High pressure car washes

- Do not allow the nozzles of the car wash to come within close proximity of the windows.
- Before using the car wash, check that the fuel filler door on your vehicle is closed properly.

#### When using a car wash

If the door handle becomes wet while the electronic key is within the effective range, the door may lock and unlock repeatedly. In that case, follow the following correction procedures to wash the vehicle:

- Place the key in a position 6 ft. (2 m) or more separate from the vehicle while the vehicle is being washed. (Take care to ensure that the key is not stolen.)
- Set the electronic key to battery-saving mode to disable the smart access system with push-button start. (→P. 115)

#### Aluminum wheels

- Remove any dirt immediately by using a neutral detergent. Do not use hard brushes or abrasive cleaners. Do not use strong or harsh chemical cleaners. Use the same mild detergent and wax as used on the paint.
- Do not use detergent on the wheels when they are hot, for example after driving a long distance in hot weather.
- Wash detergent from the wheels immediately after use.

### Bumpers

Do not scrub with abrasive cleaners.

- The following precautions can extend the effectiveness of the water-repellent coating.
  - Remove any dirt, etc. from the front side windows regularly.
  - Do not allow dirt and dust to accumulate on the windows for a long period. Clean the windows with a soft, damp cloth as soon as possible.
    - Do not use wax or glass cleaners that contain abrasives when cleaning the windows.
  - Do not use any metallic objects to remove condensation build up.
- When the water-repellent performance has become insufficient, the coating can be repaired. Contact your Lexus dealer.

### 


#### When washing the vehicle

Do not apply water to the inside of the engine compartment. Doing so may cause the electrical components etc. to catch fire.

#### When cleaning the windshield (vehicles with rain-sensing windshield wipers)

Set the wipers to the intermittent windshield wipers. ( $\rightarrow$ P. 185)

If AUTO mode is selected, the wipers may operate unexpectedly in the following situations, and may result in hands being caught or other serious injuries and cause damage to the wiper blades.



- When the upper part of the windshield where the raindrop sensor is located is touched by hand
- When a wet rag or similar is held close to the raindrop sensor
- If something bumps against the windshield
- If you directly touch the raindrop sensor body or if something bumps into the raindrop sensor
- Precautions regarding the exhaust pipe

Exhaust gases cause the exhaust pipe to become quite hot.

When washing the vehicle, be careful not to touch the pipe until it has cooled sufficiently, as touching hot exhaust pipe can cause burns.

Precaution regarding the rear bumper with Blind Spot Monitor (if equipped) If the paint of the rear bumper is chipped or scratched, the system may malfunction. If this occurs, consult your Lexus dealer.

IS350/250\_U (OM53758U)

#### 386 7-1. Maintenance and care

### 🔨 NOTICE

To prevent paint deterioration and corrosion on the body and components (aluminum wheels etc.)

- Wash the vehicle immediately in the following cases:
  - · After driving near the sea coast
  - After driving on salted roads •
  - If coal tar or tree sap is present on the paint surface
  - If dead insects, insect droppings or bird droppings are present on the paint surface · After driving in an area contaminated with soot, oily smoke, mine dust, iron pow-
  - der or chemical substances If the vehicle becomes heavily soiled with dust or mud
- If liquids such as benzene and gasoline are spilled on the paint surface • If the paint is chipped or scratched, have it repaired immediately.
- To prevent the wheels from corroding, remove any dirt and store in a place with low humidity when storing the wheels.
- Cleaning the exterior lights
  - Wash carefully. Do not use organic substances or scrub with a hard brush. This may damage the surfaces of the lights.
  - Do not apply wax to the surfaces of the lights. Wax may cause damage to the lenses.

When using an automatic car wash (vehicles with rain-sensing windshield wipers)

Set the wipers to the intermittent windshield wipers.  $(\rightarrow P. 185)$ If AUTO mode is selected, the wipers may operate and the wiper blades may be damaged.

## Cleaning and protecting the vehicle interior

The following procedures will help protect your vehicle's interior and keep it in top condition:

### Protecting the vehicle interior

Remove dirt and dust using a vacuum cleaner. Wipe dirty surfaces with a cloth dampened with lukewarm water.

### Cleaning the leather areas

- Remove dirt and dust using a vacuum cleaner.
- Wipe off any excess dirt and dust with a soft cloth dampened with diluted detergent.

Use a diluted water solution of approximately 5% neutral wool detergent.

- Wring out any excess water from the cloth and thoroughly wipe off all remaining traces of detergent.
- Wipe the surface with a dry, soft cloth to remove any remaining moisture. Allow the leather to dry in a shaded and ventilated area.

### Cleaning the synthetic leather areas

- Remove loose dirt using a vacuum cleaner.
- Apply a mild soap solution to the synthetic leather using a sponge or soft cloth.
- Allow the solution to soak in for a few minutes. Remove the dirt and wipe off the solution with a clean, damp cloth.

#### Caring for leather areas

Lexus recommends cleaning the interior of the vehicle at least twice a year to maintain the quality of the vehicle's interior.

#### Shampooing the carpets

There are several commercial foaming-type cleaners available. Use a sponge or brush to apply the foam. Rub in overlapping circles. Do not use water. Wipe dirty surfaces and let them dry. Excellent results are obtained by keeping the carpet as dry as possible.

Seat belts

Clean with mild soap and lukewarm water using a cloth or sponge. Also check the belts periodically for excessive wear, fraying or cuts.

When cleaning the carpeted portions of the glove box, console box, etc.

If a strong adhesive tape is used, there is a possibility that the surface of the carpet could be damaged.

## **A** CAUTION

#### Water in the vehicle

- Do not splash or spill liquid in the vehicle.
- Doing so may cause electrical components etc. to malfunction or catch fire.
- Do not get any of the SRS components or wiring in the vehicle interior wet.  $(\rightarrow P. 38)$

Àn electrical malfunction may cause the airbags to deploy or not function properly, resulting in death or serious injury.

Cleaning the interior (especially instrument panel)

Do not use polish wax or polish cleaner. The instrument panel may reflect off the windshield, obstructing the driver's view and leading to an accident, resulting in death or serious injury.

7-1. Maintenance and care

### ▲ NOTICE Cleaning detergents • Do not use the following types of detergent, as they may discolor the vehicle interior or cause streaks or damage to painted surfaces: • Non-seat portions: Organic substances such as benzene or gasoline, alkaline or acidic solutions, dye, and bleach Seats: Alkaline or acidic solutions, such as thinner, benzene, and alcohol • Do not use polish wax or polish cleaner. The instrument panel's or other interior part's painted surface may be damaged. Preventing damage to leather surfaces Observe the following precautions to avoid damage to and deterioration of leather surfaces: Remove any dust or dirt from leather surfaces immediately. • Do not expose the vehicle to direct sunlight for extended periods of time. Park the vehicle in the shade, especially during summer. • Do not place items made of vinyl, plastic, or containing wax on the upholstery, as they may stick to the leather surface if the vehicle interior heats up significantly. Water on the floor Do not wash the vehicle floor with water. Vehicle systems such as the audio system may be damaged if water comes into contact with electrical components such as the audio system above or under the floor of the vehicle. Water may also cause the body to rust. When cleaning the inside of the windshield (vehicles with LDA [Lane Departure Alert]) Be careful not to touch the camera sensor ( $\rightarrow$ P. 208). If the camera is accidentally scratched or hit, LDA may not operate properly or may cause a malfunction. Cleaning the inside of the rear window • Do not use glass cleaner to clean the rear window, as this may cause damage to the rear window defogger heater wires or antenna. Use a cloth dampened with lukewarm water to gently wipe the window clean. Wipe the window in strokes running parallel to the heater wires or antenna.

• Be careful not to scratch or damage the heater wires or antenna.

Maintenance and care

## **390** 7-2. Maintenance

## Maintenance requirements

To ensure safe and economical driving, day-to-day care and regular maintenance are essential. It is the owner's responsibility to perform regular checks. Lexus recommends the following maintenance:

### General maintenance

General maintenance should be performed on a daily basis. This can be done by yourself or by a Lexus dealer.

#### Scheduled maintenance

Scheduled maintenance should be performed at specified intervals according to the maintenance schedule.

For details about maintenance items and schedules, refer to the "Warranty and Service Guide", "Owner's Manual Supplement" or "Scheduled Maintenance".

#### Do-it-yourself maintenance

You can perform some maintenance procedures by yourself.

Please be aware that do-it-yourself maintenance may affect warranty coverage.

The use of Lexus repair manuals is recommended.

For details about warranty coverage, refer to the separate "Owner's Guide", "Warranty and Service Guide", "Owner's Manual Supplement" or "Warranty Booklet".

#### Repair and replacement

It is recommended that genuine Lexus parts be used for repairs to ensure performance of each system. If non-Lexus parts are used in replacement or if a repair shop other than a Lexus dealer performs repairs, confirm the warranty coverage.

#### Reset the maintenance data (U.S.A. only)

After the required maintenance is performed according to the maintenance schedule, please reset the maintenance data.

To reset the data, follow the procedure described below:

- I While the engine is running, switch the multi-information display to the "Settings" screen. (→P. 81)
- 2 Select "Maintenance System" on the "Settings" screen.
- **3** Select "Yes" on the "Maintenance System" screen.

A message will be displayed when the reset procedure has been completed.



#### Allow inspection and repairs to be performed by a Lexus dealer

- Lexus technicians are well-trained specialists and are kept up to date with the latest service information. They are well informed about the operations of all systems on your vehicle.
- Keep a copy of the repair order. It proves that the maintenance that has been performed is under warranty coverage. If any problem should arise while your vehicle is under warranty, your Lexus dealer will promptly take care of it.

## **CAUTION**

#### If your vehicle is not properly maintained

Improper maintenance could result in serious damage to the vehicle and possible death or serious injury.

- Handling of the battery
  - Engine exhaust, some of its constituents, and a wide variety of automobile components contain or emit chemicals known to the State of California to cause cancer and birth defects and other reproductive harm. Work in a well ventilated area.
  - Oils, fuels and fluids contained in vehicles as well as waste produced by component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Avoid exposure and wash any affected area immediately.
  - Battery posts, terminals and related accessories contain lead and lead compounds which are known to cause brain damage. Wash your hands after handling. (→P. 408)

# **General maintenance**

Listed below are the general maintenance items that should be performed at the intervals specified in the "Warranty and Service Guide" or "Owner's Manual Supplement". It is recommended that any problem you notice should be brought to the attention of your Lexus dealer or qualified service shop for advice.

## Engine compartment

ltems	Check points	
Battery	Check the connections.	(→P. 408)
Brake fluid	Is the brake fluid at the correct level?	(→P. 407)
Engine coolant	Is the engine coolant at the correct level?	(→P. 405)
Engine oil	Is the engine oil at the correct level?	(→P. 402)
Exhaust system	There should not be any fumes or strange sounds.	
Radiator/condenser	The radiator and condenser should be fr eign objects.	ree from for- $(\rightarrow P. 406)$
Washer fluid	Is there sufficient washer fluid?	(→P. 410)

Maintenance and care

## **394** 7-2. Maintenance

#### Vehicle interior Items Check points The accelerator pedal should move smoothly (with-Accelerator pedal out uneven pedal effort or catching). When parked on a slope and the shift lever is in P, is Automatic transmission "Park" mechanism the vehicle securely stopped? Does the brake pedal move smoothly? • Does the brake pedal have appropriate clearance Brake pedal from the floor? $(\rightarrow P.506)$ Does the brake pedal have the correct amount of (→P. 506) free play? The vehicle should not pull to one side when the brakes are applied. The brakes should work effectively. Brakes • The brake pedal should not feel spongy. • The brake pedal should not get too close to the floor when the brakes are applied. • Do the head restraints move smoothly and lock Head restraints securely? Indicators/buzzers • Do the indicators and buzzers function properly? Lights Do all the lights come on? • Moves smoothly? Parking brake • When parked on a slope and the parking brake is on, is the vehicle securely stopped? • Do the seat belts operate smoothly? Seat belts • The seat belts should not be damaged. Seats • Do the seat controls operate properly? Does the steering wheel rotate smoothly? • Does the steering wheel have the correct amount of Steering wheel free play? There should not be any strange sounds coming from the steering wheel.

#### IS350/250\_U (OM53758U)

7-2. Maintenance

395

ltems	Check points
Doors/trunk	Do the doors/trunk operate smoothly?
Engine hood	Does the engine hood lock system work properly?
Fluid leaks	<ul> <li>There should not be any signs of fluid leakage after the vehicle has been parked.</li> </ul>
Tires	<ul> <li>Is the tire inflation pressure correct?</li> <li>The tires should not be damaged or excessively worn.</li> <li>Have the tires been rotated according to the maintenance schedule?</li> <li>The wheel nuts should not be loose.</li> </ul>
Windshield wipers	<ul> <li>The wiper blades should not show any signs of cracking, splitting, wear, contamination or deformation.</li> <li>The wiper blades should clear the windshield without streaking or skipping.</li> </ul>

## **CAUTION**

## If the engine is running

Turn the engine off and ensure that there is adequate ventilation before performing maintenance checks.

# Emission inspection and maintenance (I/M) programs

Some states have vehicle emission inspection programs which include OBD (On Board Diagnostics) checks. The OBD system monitors the operation of the emission control system.

#### If the malfunction indicator lamp comes on

The OBD system determines that a problem exists somewhere in the emission control system. Your vehicle may not pass the I/M test and may need to be repaired. Contact your Lexus dealer to service the vehicle.

# Your vehicle may not pass the I/M test in the following situations:

• When the battery is disconnected or discharged

Readiness codes that are set during ordinary driving are erased. Also, depending on your driving habits, the readiness codes may not be completely set.

• When the fuel tank cap is loose

The malfunction indicator lamp comes on indicating a temporary malfunction and your vehicle may not pass the I/M test.

# When the malfunction indicator lamp still remains on after several driving trips

The error code in the OBD system will not be cleared unless the vehicle is driven 40 or more times.

#### If your vehicle does not pass the I/M test

Contact your Lexus dealer to prepare the vehicle for re-testing.

# Do-it-yourself service precautions

If you perform maintenance by yourself, be sure to follow the correct procedure as given in these sections.

ltems	Parts and tools
Battery condition $(\rightarrow P. 408)$	Warm water     Baking soda     Grease
	Conventional wrench (for terminal clamp bolts)
Brake fluid level (→P. 407)	SAE J1703 or FMVSS No.116 DOT 3 brake fluid
	• Rag or paper towel
	<ul> <li>Funnel (used only for adding brake fluid)</li> </ul>
Engine coolant level (→P. 405)	<ul> <li>"Toyota Super Long Life Coolant" or a similar high quality ethylene glycol-based non-silicate, non-amine, non-nitrite and non-borate coolant with long-life hybrid organic acid technology</li> </ul>
	For the U.S.A.: "Toyota Super Long Life Coolant" is pre-mixed with 50% coolant and 50% deionized water.
	For Canada: "Toyota Super Long Life Coolant" is pre-mixed with 55% coolant and 45% deionized water.
	<ul> <li>Funnel (used only for adding coolant)</li> </ul>
Engine oil level (→P. 402)	<ul> <li>"Toyota Genuine Motor Oil" or equivalent</li> </ul>
	• Rag or paper towel
	<ul> <li>Funnel (used only for adding engine oil)</li> </ul>
Fuses (→P. 429)	<ul> <li>Fuse with same amperage rating as original</li> </ul>
Light bulbs (→P. 432)	Bulb with same number and wattage rating as original
	Phillips-head screwdriver     Flathead screwdriver
	• Wrench
Radiator and con- denser (→P. 406)	
Tire inflation pressure ( $\rightarrow$ P. 420)	Tire pressure gauge     Compressed air source
Washer fluid (→P. 410)	Water or washer fluid containing antifreeze (for winter use)
	<ul> <li>Funnel (used only for adding water or washer fluid)</li> </ul>

Maintenance and care

# 397

### 

The engine compartment contains many mechanisms and fluids that may move suddenly, become hot, or become electrically energized. To avoid death or serious injury, observe the following precautions.

- When working on the engine compartment
  - Keep hands, clothing and tools away from the moving fan and engine drive belt.
  - Be careful not to touch the engine, radiator, exhaust manifold, etc. right after driving as they may be hot. Oil and other fluids may also be hot.
  - Do not leave anything that may burn easily, such as paper and rags, in the engine compartment.
  - Do not smoke, cause sparks or expose an open flame to fuel or the battery. Fuel and battery fumes are flammable.
  - Be extremely cautious when working on the battery. It contains poisonous and corrosive sulfuric acid.
- When working near the electric cooling fans or radiator grille

Be sure the engine switch is off.

With the engine switch in IGNITION ON mode, the electric cooling fans may automatically start to run if the air conditioning is on and/or the coolant temperature is high. ( $\rightarrow$ P. 406)

Safety glasses

Wear safety glasses to prevent flying or falling material, fluid spray, etc. from getting in your eyes.

# \Lambda NOTICE


#### If you remove the air cleaner filter

Driving with the air cleaner filter removed may cause excessive engine wear due to dirt in the air.


# Hood

Release the lock from the inside of the vehicle to open the hood.

1 Pull the hood lock release lever. The hood will pop up slightly.



2 Pull up the auxiliary catch lever and lift the hood.



# 

#### Pre-driving check

Check that the hood is fully closed and locked. If the hood is not locked properly, it may open while the vehicle is in motion and cause

an accident, which may result in death or serious injury.

Maintenance and care


IS350/250\_U (OM53758U)

# Positioning a floor jack

When using a floor jack, follow the instructions in the manual provided with the jack and perform the operation safely.


When raising your vehicle with a floor jack, position the jack correctly. Improper placement may damage your vehicle or cause injury.






- 1 2WD models
- 2 AWD models








Maintenance and care

# Engine oil

With the engine at operating temperature and turned off, check the oil level on the dipstick.

#### Checking the engine oil


- 1 Park the vehicle on level ground. After warming up the engine and turning it off, wait more than 5 minutes for the oil to drain back into the bottom of the engine.
- 2 Holding a rag under the end, pull the dipstick out.



- **3** Wipe the dipstick clean.
- 4 Reinsert the dipstick fully.
- **5** Holding a rag under the end, pull the dipstick out and check the oil level.
  - 1 Low
  - Normal
  - 3 Excessive


The shape of the dipstick may differ depending on the type of vehicle or engine.

**6** Wipe the dipstick and reinsert it fully.



# Adding engine oil

If the oil level is below or near the low level mark, add engine oil of the same type as that already in the engine.



Make sure to check the oil type and prepare the items needed before adding oil.

Engine oil selection	→P. 503
Oil quantity (Low $\rightarrow$ Full)	1.6 qt. (1.5 L, 1.3 Imp. qt.)
ltems	Clean funnel

1 Remove the oil filler cap by turning it counterclockwise.

**2** Add engine oil slowly, checking the dipstick.

**3** Install the oil filler cap by turning it clockwise.

#### Engine oil consumption

A certain amount of engine oil will be consumed while driving. In the following situations, oil consumption may increase, and engine oil may need to be refilled in between oil maintenance intervals.

- When the engine is new, for example directly after purchasing the vehicle or after replacing the engine
- If low quality oil or oil of an inappropriate viscosity is used
- When driving at high engine speeds or with a heavy load, or when driving while accelerating or decelerating frequently
- When leaving the engine idling for a long time, or when driving frequently through heavy traffic

IS350/250\_U (OM53758U)

### **CAUTION**

#### Used engine oil

• Used engine oil contains potentially harmful contaminants which may cause skin disorders such as inflammation and skin cancer, so care should be taken to avoid prolonged and repeated contact. To remove used engine oil from your skin, wash thoroughly with soap and water.

• Dispose of used oil and filters only in a safe and acceptable manner. Do not dispose of used oil and filters in household trash, in sewers or onto the ground. Call your Lexus dealer, service station or auto parts store for information concerning recycling or disposal.

• Do not leave used engine oil within the reach of children.

### 🕂 NOTICE


- To prevent serious engine damage
- Check the oil level on a regular basis.
- When replacing the engine oil
  - Be careful not to spill engine oil on the vehicle components.
  - Avoid overfilling, or the engine could be damaged.
  - Check the oil level on the dipstick every time you refill the vehicle.
  - Be sure the engine oil filler cap is properly tightened.

# Engine coolant

The coolant level is satisfactory if it is between the "FULL" and "LOW" lines on the reservoir when the engine is cold.

- (1) Reservoir cap
- 2 "FULL" line
- 3 "LOW" line

If the level is on or below the "LOW" line, add coolant up to the "FULL" line.  $(\rightarrow P. 494)$ 



#### Coolant selection

Only use "Toyota Super Long Life Coolant" or a similar high quality ethylene glycol based non-silicate, non-amine, non-nitrite, and non-borate coolant with long-life hybrid organic acid technology.

U.S.A.:

"Toyota Super Long Life Coolant" is a mixture of 50% coolant and 50% deionized water. (Minimum temperature: -31°F [-35°C])

Canada:

"Toyota Super Long Life Coolant" is a mixture of 55% coolant and 45% deionized water. (Minimum temperature: -44°F [-42°C])

For more details about engine coolant, contact your Lexus dealer.

#### If the coolant level drops within a short time of replenishing

Visually check the radiator, hoses, engine coolant reservoir cap, drain cock and water pump.

If you cannot find a leak, have your Lexus dealer test the cap and check for leaks in the cooling system.

# 

#### When the engine is hot

Do not remove the engine coolant reservoir cap or radiator cap. ( $\rightarrow$ P. 496) The cooling system may be under pressure and may spray hot coolant if the cap is removed, causing serious injuries, such as burns.

# **NOTICE**

#### When adding coolant

Coolant is neither plain water nor straight antifreeze. The correct mixture of water and antifreeze must be used to provide proper lubrication, corrosion protection and cooling. Be sure to read the antifreeze or coolant label.

If you spill coolant

Be sure to wash it off with water to prevent it from damaging parts or paint.

#### Radiator and condenser

Check the radiator and condenser and clear away any foreign objects.

If either of the above parts is extremely dirty or you are not sure of their condition, have your vehicle inspected by your Lexus dealer.

#### **A** CAUTION

#### When the engine is hot

Do not touch the radiator or condenser as they may be hot and cause serious injuries, such as burns.

# Brake fluid

# Checking fluid level

The brake fluid level should be between the "MAX" and "MIN" lines on the tank.



#### Adding fluid

Make sure to check the fluid type and prepare the necessary items.

Fluid type	SAE J1703 or FMVSS No.116 DOT 3 brake fluid
ltems	Clean funnel

#### Brake fluid can absorb moisture from the air

Excess moisture in the brake fluid can cause a dangerous loss of braking efficiency. Use only newly opened brake fluid.

# **CAUTION**

#### When filling the reservoir

Take care as brake fluid can harm your hands and eyes and damage painted surfaces. If fluid gets on your hands or in your eyes, flush the affected area with clean water immediately.

If you still experience discomfort, see a doctor.

# 

#### If the fluid level is low or high

It is normal for the brake fluid level to go down slightly as the brake pads wear out or when the fluid level in the accumulator is high.

If the reservoir needs frequent refilling, there may be a serious problem.


# Battery

Check the battery as follows.

#### Battery exterior

Make sure that the battery terminals are not corroded and that there are no loose connections, cracks, or loose clamps.

- 1 Terminals
- 2 Hold-down clamp



#### Before recharging

When recharging, the battery produces hydrogen gas which is flammable and explosive. Therefore, observe the following before recharging:

- If recharging with the battery installed on the vehicle, be sure to disconnect the ground cable.
- Make sure the power switch on the charger is off when connecting and disconnecting the charger cables to the battery.

#### After recharging/reconnecting the battery

The engine may not start. Follow the procedure below to initialize the system.

- 1 Shift the shift lever to P.
- 2 Open and close any of the doors.
- **3** Restart the engine.
  - Unlocking the doors using the smart access system with push-button start may not be
    possible immediately after reconnecting the battery. If this happens, use the wireless
    remote control or the mechanical key to lock/unlock the doors.
  - Start the engine with the engine switch in ACCESSORY mode. The engine may not start with the engine switch turned off. However, the engine will operate normally from the second attempt.
  - The engine switch mode is recorded by the vehicle. If the battery is disconnected and reconnected, the vehicle will return the engine switch mode to the status it was in before the battery was disconnected. Make sure to turn off the engine before disconnecting the battery. Take extra care when connecting the battery if the engine switch mode prior to the battery being disconnected is unknown.
- If the system will not start even after multiple attempts, contact your Lexus dealer.

# **A** CAUTION Chemicals in the battery Batteries contain poisonous and corrosive sulfuric acid and may produce hydrogen gas which is flammable and explosive. To reduce the risk of death or serious injury, take the following precautions while working on or near the battery: • Do not cause sparks by touching the battery terminals with tools. • Do not smoke or light a match near the battery. • Avoid contact with eyes, skin and clothes. • Never inhale or swallow electrolyte. • Wear protective safety glasses when working near the battery. • Keep children away from the battery. Where to safely charge the battery Always charge the battery in an open area. Do not charge the battery in a garage or closed room where there is insufficient ventilation. How to recharge the battery Only perform a slow charge (5 A or less). The battery may explode if charged at a auicker rate. Emergency measures regarding electrolyte • If electrolyte gets in your eyes Flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If possible, continue to apply water with a sponge or cloth while traveling to the nearest medical facility. If electrolyte gets on your skin Wash the affected area thoroughly. If you feel pain or burning, get medical attention immediately. • If electrolyte gets on your clothes It can soak through clothing on to your skin. Immediately take off the clothing and follow the procedure above if necessary. • If you accidentally swallow electrolyte Maintenance and care Drink a large quantity of water or milk. Get emergency medical attention immediately. ▲ NOTICE When recharging the battery


Never recharge the battery while the engine is running. Also, be sure all accessories are turned off.

409

IS350/250\_U (OM53758U)

# Washer fluid

If any washer does not work or the warning message appears on the multiinformation display, the washer tank may be empty. Add washer fluid.



# **CAUTION**

#### When adding washer fluid

Do not add washer fluid when the engine is hot or running as washer fluid contains alcohol and may catch fire if spilled on the engine etc.

# <u>∧</u> NOTICE

#### Do not use any fluid other than washer fluid

Do not use soapy water or engine antifreeze instead of washer fluid. Doing so may cause streaking on the vehicle's painted surfaces.

Diluting washer fluid

Dilute washer fluid with water as necessary.

Refer to the freezing temperatures listed on the label of the washer fluid bottle.

 $\bigcirc$ 

2

3

# Tires

Replace or rotate tires in accordance with maintenance schedules and treadwear.

### **Checking tires**

- 1 New tread
- Treadwear indicator
- 3 Worn tread

The location of treadwear indicators is shown by the "TWI" or " $\Delta$ " marks, etc., molded on the sidewall of each tire. Check spare tire condition and pressure if not rotated.

# Tire rotation

▶ Vehicles with front and rear tires of the same size

Rotate the tires in the order shown.

To equalize tire wear and extend tire life, Lexus recommends that tire rotation is carried out at the same interval as tire inspection.

Do not fail to initialize the tire pressure warning system after tire rotation.

- Front
- ▶ Vehicles with front and rear tires of differing sizes

Tires cannot be rotated.



7

#### Tire pressure warning system

Your vehicle is equipped with a tire pressure warning system that uses tire pressure warning valves and transmitters to detect low tire inflation pressure before serious problems arise.

- If the tire pressure drops below a predetermined level, the driver is warned by a screen display and a warning light. (→P. 467)
- The tire pressure detected by the tire pressure warning system can be displayed on the multi-information display.



#### Installing tire pressure warning valves and transmitters

When replacing tires or wheels, tire pressure warning valves and transmitters must also be installed.

When new tire pressure warning valves and transmitters are installed, new ID codes must be registered in the tire pressure warning computer and the tire pressure warning system must be initialized. Have tire pressure warning valve and transmitter ID codes registered by your Lexus dealer. ( $\rightarrow$ P. 414)

Initializing the tire pressure warning system

- The tire pressure warning system must be initialized in the following circumstances:
  - When rotating the tires.

When the tire pressure warning system is initialized, the current tire inflation pressure is set as the benchmark pressure.

#### How to initialize the tire pressure warning system

- 1 Park the vehicle in a safe place and turn the engine switch off.
- Initialization cannot be performed while the vehicle is moving. Adjust the tire inflation pressure to the specified cold tire inflation pressure
  - level. (→P. 507) Make sure to adjust the tire pressure to the specified cold tire inflation pressure

level. The tire pressure warning system will operate based on this pressure level.

- **3** Turn the engine switch to IGNITION ON mode.
- Press and hold the tire pressure warning reset switch until the tire pressure warning light blinks slowly 3 times.



**5** Wait for a few minutes with the engine switch in IGNITION ON mode and then turn the engine switch off.



#### Registering ID codes

The tire pressure warning valve and transmitter is equipped with a unique ID code. When replacing a tire pressure warning valve and transmitter, it is necessary to register the ID code. Have the ID code registered by your Lexus dealer.

#### When to replace your vehicle's tires

Tires should be replaced if:

- You have tire damage such as cuts, splits, cracks deep enough to expose the fabric, and bulges indicating internal damage
- A tire goes flat repeatedly or cannot be properly repaired due to the size or location of a cut or other damage
- If you are not sure, consult your Lexus dealer.

#### Replacing tires and wheels

If the ID code of the tire pressure warning valve and transmitter is not registered, the tire pressure warning system will not work properly. After driving for about 20 minutes, the tire pressure warning light blinks for 1 minute and stays on to indicate a system malfunction.

#### Tire life

Any tire over 6 years old must be checked by a qualified technician even if it has seldom or never been used or damage is not obvious.

#### Routine tire inflation pressure checks

The tire pressure warning system does not replace routine tire inflation pressure checks. Make sure to check tire inflation pressure as part of your routine of daily vehicle checks.

#### When rotating the tires

Make sure that the engine switch is off. If the tires are rotated while the engine switch is in IGNITION ON mode, the tire position information will not be updated. If this accidentally occurs, either turn the engine switch to off and then to IGNITION ON mode, or initialize the system after checking that the tire pressure is properly adjusted.

#### Low profile tires (except 16-inch tires)


Generally, low profile tires will wear more rapidly and tire grip performance will be reduced on snowy and/or icy roads when compared to standard tires. Be sure to use snow tires or tire chains\* on snowy and/or icy roads and drive carefully at a speed appropriate for road and weather conditions.

 $\star$ : Tire chains cannot be mounted on the 18-inch tires. Snow tires should be used instead.

#### Maximum load of tire

Check that the maximum load of the replacement tire is greater than 1/2 of the Gross Axle Weight Ratings (GAWR) of either the front axle or the rear axle, whichever is greater.

For the GAWR, see the Certification Label. For the maximum load of the tire, see the load limit at maximum cold tire inflation pressure mentioned on the sidewall of the tire. ( $\rightarrow$ P. 513)



#### Tire types

Summer tires

Summer tires are high-speed performance tires best suited to highway driving under dry conditions. Since summer tires do not have the same traction performance as snow tires, summer tires are inadequate for driving on snow-covered or icy roads. For driving on snow-covered roads or icy roads, the use of snow tires is recommended. When installing snow tires, be sure to replace all four tires.

All season tires

All season tires are designed to provide better traction in snow and to be adequate for driving in most winter conditions as well as for use year-round. All season tires, however, do not have adequate traction performance compared with snow tires in heavy or loose snow. Also, all season tires fall short in acceleration and handling performance compared with summer tires in highway driving.

Snow tires

For driving on snow-covered roads or icy roads, we recommend using snow tires. If you need snow tires, select tires of the same size, construction and load capacity as the originally installed tires. Since your vehicle has radial tires as original equipment, make sure your snow tires also have radial construction. Do not install studded tires without first checking local regulations for possible restrictions. Snow tires should be installed on all wheels. ( $\rightarrow$ P. 254)

IS350/250\_U (OM53758U)

- If the tread on snow tires wears down below 0.16 in. (4 mm) The effectiveness of the tires as snow tires is lost.
- Situations in which the tire pressure warning system may not operate properly
  - In the following cases, the tire pressure warning system may not operate properly.
    - If non-genuine Lexus wheels are used.
    - A tire has been replaced with a tire that is not an OE (Original Equipment) tire.
    - A tire has been replaced with a tire that is not of the specified size.
    - Tire chains etc. are equipped.
    - Lock nuts are equipped.
    - An auxiliary-supported run-flat tire is equipped.
    - If a window tint that affects the radio wave signals is installed.
    - If there is a lot of snow or ice on the vehicle, particularly around the wheels or wheel housings.
    - If the tire inflation pressure is extremely higher than the specified level.
    - If tires not equipped with tire pressure warning valves and transmitters are used.
      If the ID code on the tire pressure warning valves and transmitters is not registered in the tire pressure warning computer.
  - Performance may be affected in the following situations.
    - Near a TV tower, electric power plant, gas station, radio station, large display, airport or other facility that generates strong radio waves or electrical noise
    - <sup>1</sup> When carrying a portable radio, cellular phone, cordless phone or other wireless communication device

If tire position information is not correctly displayed due to the radio wave conditions, the display may be corrected by driving and changing the radio wave conditions.

- When the vehicle is parked, the time taken for the warning to start or go off could be extended.
- When tire inflation pressure declines rapidly for example when a tire has burst, the warning may not function.
- The initialization operation
  - Make sure to carry out initialization after adjusting the tire inflation pressure. Also, make sure the tires are cold before carrying out initialization or tire inflation pressure adjustment.
  - If you have accidentally turned the engine switch off during initialization, it is not necessary to press the reset switch again as initialization will restart automatically when the engine switch has been turned to IGNITION ON mode for the next time.
  - If you accidentally press the reset switch when initialization is not necessary, adjust the tire inflation pressure to the specified level when the tires are cold, and conduct initialization again.

IS350/250\_U (OM53758U)

#### When initialization of the tire pressure warning system has failed

Initialization can be completed in a few minutes. However, in the following cases, the settings have not been recorded and the system will not operate properly. If repeated attempts to record tire inflation pressure settings are unsuccessful, have the vehicle inspected by your Lexus dealer.

- When operating the tire pressure warning reset switch, the tire pressure warning light does not blink 3 times.
- After carrying out the initialization procedure, the tire pressure warning light blinks for 1 minute then stays on after driving for 20 minutes.

#### Tire pressure warning system certification

MODEL/FCC IDs:

Transmitter: PAXPMVC010 Initiator: HYQ22AAA

► For vehicles sold in the U.S.A.

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC WARNING:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

► Transmitter (for vehicles sold in Canada)

NOTE:

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

▶ Initiator (for vehicles sold in Canada)

NOTE:

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

# 

#### When inspecting or replacing tires

Observe the following precautions to prevent accidents. Failure to do so may cause damage to parts of the drivetrain as well as dangerous han-

dling characteristics, which may lead to an accident resulting in death or serious injury.
Do not mix tires of different makes, models or tread patterns.

- Also, do not mix tires of remarkably different treadwear.
- Do not use tire sizes other than those recommended by Lexus.
- Do not mix differently constructed tires (radial, bias-belted or bias-ply tires).
- Do not mix summer, all season and snow tires.
- Do not use tires that have been used on another vehicle.
  - Do not use tires if you do not know how they were used previously.
- Do not tow if your vehicle has a compact spare tire installed.

#### When initializing the tire pressure warning system

Do not operate the tire pressure warning reset switch without first adjusting the tire inflation pressure to the specified level. Otherwise, the tire pressure warning light may not come on even if the tire inflation pressure is low, or it may come on when the tire inflation pressure is actually normal.

Caution regarding interference with electronic devices

 People with implanted pacemakers or cardiac defibrillators should not come within 17.7 in. (450 mm) of the tire pressure warning system initiators. The radio waves may affect the operation of such devices.



 Users of any electrical medical device other than implanted pacemakers and implanted cardiac defibrillators should consult the manufacturer of the device for information about its operation under the influence of radio waves. Radio waves could have unexpected effects on the operation of such medical

devices.

# 

- Repairing or replacing tires, wheels, tire pressure warning valves, transmitters and tire valve caps
  - When removing or fitting the wheels, tires or the tire pressure warning valves and transmitters, contact your Lexus dealer as the tire pressure warning valves and transmitters may be damaged if not handled correctly.
  - Make sure to install the tire valve caps. If the tire valve caps are not installed, water could enter the tire pressure warning valves and the tire pressure warning valves could be bound.
  - When replacing tire valve caps, do not use tire valve caps other than those specified. The cap may become stuck.

#### To avoid damage to the tire pressure warning valves and transmitters

When a tire is repaired with liquid sealants, the tire pressure warning valve and transmitter may not operate properly. If a liquid sealant is used, contact your Lexus dealer or other qualified service shop as soon as possible. Make sure to replace the tire pressure warning valve and transmitter when replacing the tire. ( $\rightarrow$ P. 412)

#### Driving on rough roads

Take particular care when driving on roads with loose surfaces or potholes. These conditions may cause losses in tire inflation pressure, reducing the cushioning ability of the tires. In addition, driving on rough roads may cause damage to the tires themselves, as well as the vehicle's wheels and body.

#### Low profile tires (except 16-inch tires)

Low profile tires may cause greater damage than usual to the tire wheel when sustaining impact from the road surface. Therefore, pay attention to the following:

- Be sure to use proper tire inflation pressure. If tires are under-inflated, they may be damaged more severely.
- Avoid potholes, uneven pavement, curbs and other road hazards. Failure to do so may lead to severe tire and wheel damage.


#### If tire inflation pressure of each tire becomes low while driving

Do not continue driving, or your tires and/or wheels may be ruined.

# Tire inflation pressure


# Tire inflation pressure

The recommended cold tire inflation pressure and tire size are displayed on the tire and loading information label.  $(\rightarrow P. 507)$ 



#### Inspection and adjustment procedure

- 1 Tire valve
- Tire pressure gauge



421

- **1** Remove the tire valve cap.
- **2** Press the tip of the tire pressure gauge onto the tire valve.
- **3** Read the pressure using the gauge gradations.
- 4 If the tire inflation pressure is not at the recommended level, adjust the pressure.

If you add too much air, press the center of the valve to deflate.

- **5** After completing the tire inflation pressure measurement and adjustment, apply soapy water to the valve and check for leakage.
- 6 Put the tire valve cap back on.

#### Tire inflation pressure check interval

You should check tire inflation pressure every two weeks, or at least once a month. Do not forget to check the spare.

#### Effects of incorrect tire inflation pressure

Driving with incorrect tire inflation pressure may result in the following:

- Reduced fuel efficiency
- Reduced driving comfort and tire life
- Reduced safety
- Damage to the drivetrain
- If a tire needs frequent inflating, have it checked by your Lexus dealer.

#### Instructions for checking tire inflation pressure

When checking tire inflation pressure, observe the following:

- Check only when the tires are cold. If your vehicle has been parked for at least 3 hours or has not been driven for more than 1 mile or 1.5 km, you will get an accurate cold tire inflation pressure reading.
- Always use a tire pressure gauge. The appearance of the tire can be misleading. In addition, tire inflation pressure that is even just a few pounds off can affect ride quality and handling.
- Do not reduce tire inflation pressure after driving. It is normal for tire inflation pressure to be higher after driving.
- Never exceed the vehicle capacity weight.
   Passengers and luggage weight should be placed so that the vehicle is balanced.

### 

#### Proper inflation is critical to save tire performance

Keep your tires properly inflated. Otherwise, the following conditions may occur and result in an accident causing death or serious injury:

- Excessive wear
- Uneven wear
- Poor handling
- Possibility of blowouts resulting from overheated tires
- Poor sealing of the tire bead
- Wheel deformation and/or tire separation
- A greater possibility of tire damage from road hazards

### \Lambda NOTICE

#### When inspecting and adjusting tire inflation pressure

Be sure to put the tire valve caps back on.

Without the valve caps, dirt or moisture could get into the valve and cause air leakage, which could result in an accident. If the caps are lost, replace them as soon as possible.

# Wheels

If a wheel is bent, cracked or heavily corroded, it should be replaced. Otherwise, the tire may separate from the wheel or cause a loss of handling control.

### Wheel selection

When replacing wheels, care should be taken to ensure that they are equivalent to those removed in load capacity, diameter, rim width and inset<sup>\*</sup>.

Replacement wheels are available at your Lexus dealer.

\*: Conventionally referred to as "offset".

- Lexus does not recommend using the following:
- Wheels of different sizes or types
- Used wheels
- Bent wheels that have been straightened

### Aluminum wheel precautions

- Use only Lexus wheel nuts and wrenches designed for use with your aluminum wheels.
- When rotating, repairing or changing your tires, check that the wheel nuts are still tight after driving 1000 miles (1600 km).
- Be careful not to damage the aluminum wheels when using tire chains.
- Use only Lexus genuine balance weights or equivalent and a plastic or rubber hammer when balancing your wheels.

#### When replacing wheels

The wheels of your vehicle are equipped with tire pressure warning valves and transmitters that allow the tire pressure warning system to provide advance warning in the event of a loss in tire inflation pressure. Whenever wheels are replaced, tire pressure warning valves and transmitters must be installed. ( $\rightarrow$ P. 412)

# 

#### When replacing wheels

- Do not use wheels that are a different size from those recommended in the Owner's Manual, as this may result in a loss of handling control.
- Never use an inner tube in a leaking wheel which is designed for a tubeless tire. Doing so may result in an accident, causing death or serious injury.

# 🕂 NOTICE

#### Replacing tire pressure warning valves and transmitters

- Because tire repair or replacement may affect the tire pressure warning valves and transmitters, make sure to have tires serviced by your Lexus dealer or other qualified service shop. In addition, make sure to purchase your tire pressure warning valves and transmitters at your Lexus dealer.
- Ensure that only genuine Lexus wheels are used on your vehicle. Tire pressure warning valves and transmitters may not work properly with non-genuine wheels.


# Air conditioning filter


The air conditioning filter must be changed regularly to maintain air conditioning efficiency.

### **Removal** method

- **1** Turn the engine switch off.
- 2 Open the glove box. Lift up the side with the stay, disconnect the stay tabs and remove the partition by pulling horizontally.
- 3 Press the tabs and remove the filter cover.

4 Press the tabs and remove the filter case.








**5** Remove the air conditioning filter from the filter case and replace it with a new one.

The " $\uparrow UP$ " marks shown on the filter and the filter case should be pointing up.



#### Checking interval

Inspect and replace the air conditioning filter according to the maintenance schedule. In dusty areas or areas with heavy traffic flow, early replacement may be required. (For scheduled maintenance information, please refer to the "Owner's Manual Supplement" or "Scheduled Maintenance".)

#### ■ If air flow from the vents decreases dramatically

The filter may be clogged. Check the filter and replace if necessary.

### 🔨 NOTICE

#### When using the air conditioning system

Make sure that a filter is always installed. Using the air conditioning system without a filter may cause damage to the system.

IS350/250\_U (OM53758U)

# Electronic key battery


Replace the battery with a new one if it is depleted.

# You will need the following items:

- Flathead screwdriver
- Small flathead screwdriver
- Lithium battery CR2032

# Replacing the battery


**1** Take out the mechanical key.



## **2** Remove the cover.

To prevent damage to the key, wrap the tip of the screwdriver with tape.

Remove the depleted battery.
 Insert a new battery with the "+" terminal facing up.



Maintenance and care

IS350/250\_U (OM53758U)

427

#### Use a CR2032 lithium battery

- Batteries can be purchased at your Lexus dealer, local electrical appliance shops or camera stores.
- Replace only with the same or equivalent type recommended by the manufacturer.
- Dispose of used batteries according to local laws.
- When the card key battery needs to be replaced (if equipped)

The battery for the card key is available only at Lexus dealers. Your Lexus dealer can replace the battery for you.

- If the electronic key battery is depleted
  - The following symptoms may occur:
  - The smart access system with push-button start and wireless remote control will not function properly.
  - The operational range will be reduced.

#### A CAUTION

#### Removed battery and other parts

These parts are small and if swallowed by a child, they can cause choking. Keep away from children. Failure to do so could result in death or serious injury.

#### **NOTICE**

#### For normal operation after replacing the battery


Observe the following precautions to prevent accidents:

- Always work with dry hands. Moisture may cause the battery to rust.
- Do not touch or move any other component inside the remote control.
- Do not bend either of the battery terminals.

# Checking and replacing fuses

If any of the electrical components do not operate, a fuse may have blown. If this happens, check and replace the fuses as necessary.

- **1** Turn the engine switch off.
- 2 Open the Fuse box cover.
- ▶ Engine compartment (type A fuse box) Push the tab in and lift the lid off.





► Engine compartment (type B fuse box)

Push the tab in and lift the lid off.

► Driver's side instrument panel

Remove the lid.






Maintenance and care

429

**3** Remove the fuse with the pullout tool.

Only type A fuses can be removed using the pullout tool.



- 4 Check if the fuse is blown.
  - 1 Normal fuse
  - 2 Blown fuse


Type A and B:

Replace the blown fuse with a new fuse of an appropriate amperage rating. The amperage rating can be found on the fuse box lid.

Type C and D: Contact your Lexus dealer.


▶ Type A

► Type B



► Type C

▶ Type D



#### After a fuse is replaced

- If the lights do not turn on even after the fuse has been replaced, a bulb may need replacement. (→P. 432)
- If the replaced fuse blows again, have the vehicle inspected by your Lexus dealer.
- If there is an overload in a circuit
  - The fuses are designed to blow, protecting the wiring harness from damage.

#### When replacing light bulbs

Lexus recommends that you use genuine Lexus products designed for this vehicle. Because certain bulbs are connected to circuits designed to prevent overload, non-genuine parts or parts not designed for this vehicle may be unusable.

# **CAUTION**

#### To prevent system breakdowns and vehicle fire

Observe the following precautions.

Failure to do so may cause damage to the vehicle, and possibly a fire or injury.

- Never use a fuse of a higher amperage rating than that indicated, or use any other object in place of a fuse.
- Always use a genuine Lexus fuse or equivalent.
   Never replace a fuse with a wire, even as a temporary fix.
- Do not modify the fuses or fuse boxes.

### \land NOTICE

#### Before replacing fuses

Have the cause of electrical overload determined and repaired by your Lexus dealer as soon as possible.

# **432** 7-3. Do-it-yourself maintenance

# **Light bulbs**

You may replace the following bulbs by yourself. The difficulty level of replacement varies depending on the bulb. If necessary bulb replacement seems difficult to perform, contact your Lexus dealer.

For more information about replacing other light bulbs, contact your Lexus dealer.

Preparing for light bulb replacement

Check the wattage of the light bulb to be replaced. ( $\rightarrow$ P. 509)

#### **Bulb locations**

- Front
- ▶ Vehicles with discharge headlights




- $\bigcirc$  Front turn signal light
- Fog light (if equipped)

- Vehicles with LED headlights

1 Fog light (if equipped)

(2) Front turn signal light

Rear



# 434 7-3. Do-it-yourself maintenance

#### Replacing light bulbs

# Fog lights (if equipped)

1 Remove the 2 fender liner screws under the fog light and pull back the fender liner.




**2** Unplug the connector while pressing the lock release.

**3** Turn the bulb base counterclock-wise.



- 4 Set the new light bulb.
  - Hold the bulb base at an angle of about 45 degrees as shown in the illustration and insert it so that the 3 tabs on the light bulb are aligned with the mounting.
  - Turn the light bulb clockwise to install it.



#### 7-3. Do-it-yourself maintenance

# Set the connector. After installing the connector, shake the bulb base gently to check that it is not loose, turn the fog lights on once and visually confirm that no light is leaking through the mounting. Reinstall the fender liner with the 2 screws.

Maintenance and care

# 436 7-3. Do-it-yourself maintenance

#### Front turn signal lights (vehicles with discharge headlights)

**1** To ensure enough space to perform work, turn the steering wheel to rotate the front wheel away from the bulb to be replaced.

Remove the 2 fender liner clips.

Turn the steering wheel to the left when replacing the right side light bulb, and turn the steering wheel to the right when replacing the left side light bulb.


To take out the lower clip, turn the head of the clip to unlock it, then remove it by pulling.

2 Unfasten the clamp, and pull back the fender liner.

When unfastening the clamp, wrap the tip of the screwdriver with tape to protect the vehicle from damage.

**3** Turn the bulb base counterclock-wise.





#### 7-3. Do-it-yourself maintenance


 Install a new light bulb then install the bulb base to the light unit by inserting it and turning the bulb base clockwise.

**4** Remove the light bulb.

After installing the light bulb, turn on the front turn signal light to visually check that there is no light leaking from the bulb base.

6 Reinstall the fender liner, fasten the clamp and install the 2 clips.

Install the lower clip by inserting it with the clip groove held vertically straight.



Maintenance and care

# 438 7-3. Do-it-yourself maintenance

#### Front turn signal lights (vehicles with LED headlights)


2)7

- **1** For the left side only: Pinch the clip to remove the washer fluid filler opening.
- **2** Turn the bulb base counterclockwise.

**3** Remove the light bulb.

Install a new light bulb then install the bulb base to the light unit by inserting it and turning the bulb base clockwise.

> After installing the light bulb, turn on the front turn signal light to visually check that there is no light leaking from the bulb base.



CIY72A7

CLY72AZ0

**5** After replacing the left side bulb, install the washer fluid filler opening to its original position.

#### 7-3. Do-it-yourself maintenance

#### Rear turn signal lights

1 Open the trunk, and remove the 2 covers and 2 screws.

> When removing the cover, wrap the tip of the screwdriver with tape to protect the vehicle from damage.


**2** Push and pull the light unit toward the rear of the vehicle as shown in the illustration to remove it.

> Apply protective tape to the peripheral of the light unit installation surface on the vehicle body, such as the rear bumper, to protect the vehicle from damage.


> Pushing on the portion A in the illustration toward the rear of the vehicle will make disengagement of the tabs easier.

**3** Turn the bulb base counterclockwise.

**4** Remove the light bulb.







439

Maintenance and care

# 440 7-3. Do-it-yourself maintenance


**5** Install a new light bulb then install the bulb base to the light unit by inserting it and turning the bulb base clockwise.

> After installing the light bulb, turn on the rear turn signal light to visually check that there is no light leaking from the bulb base.

6 Align the tabs and push the light unit toward the front of the vehicle to install it.

> Remove the protective tape applied to the peripheral of the light unit installation surface on the vehicle body.

**7** Install the 2 screws and 2 covers.



#### 7-3. Do-it-yourself maintenance

#### Back-up light

- Open the trunk, remove the 3 clips on the side which the bulb is to be replaced and pull back the trunk lid cover.
- **2** Turn the bulb base counterclockwise.

3 Remove the light bulb. Pull out the connector carefully, ensuring that excessive pulling load is


not applied to the wire harness.

4 Install a new light bulb then install the bulb base to the light unit by inserting it and turning the bulb base clockwise.

> After installing the light bulb, turn on the back-up light to visually check that there is no light leaking from the bulb base.

**5** Reinstall the trunk lid cover with the 3 clips.

To install the clips, simply push them in.



441

CLY72AZ0

CLY72AZC

7

Maintenance and care

#### Replacing the following bulbs

If any of the lights listed below has burnt out, have it replaced by your Lexus dealer.

- Headlights
- Parking lights and daytime running lights
- Side marker lights
- Side turn signal lights
- Outer foot lights
- Stop/tail lights
- Tail lights
- High mounted stoplight
- License plate lights

#### Discharge headlights (if equipped)

If voltage to the discharge bulbs is insufficient, the bulbs may not come on, or may go out temporarily. The discharge bulbs will come on when normal power is restored.

#### LED Lights

The lights other than the discharge headlights (if equipped), fog lights (if equipped), front turn signal lights, rear turn signal lights, back-up light and outer foot lights each consist of a number of LEDs. If any of the LEDs burn out, take your vehicle to your Lexus dealer to have the light replaced.

#### Condensation build-up on the inside of the lens

Temporary condensation build-up on the inside of the headlight lens does not indicate a malfunction. Contact your Lexus dealer for more information in the following situations:


- Large drops of water have built up on the inside of the lens.
- Water has built up inside the headlight.

#### When replacing the front turn signal lights (vehicles with LED headlights)

When the washer fluid filler opening is removed with a large amount of washer fluid contained in the washer tank, washer fluid may spill onto the vehicle and cleaning may be required.

#### When replacing light bulbs

→P. 431



# When trouble arises

8

8-1.	<b>Essential information</b>	
	Emergency flashers	446
	lf your vehicle has	
	to be stopped in	
	an emergency	44/
8-2.	Steps to take in	
	an emergency	
	If your vehicle needs	4 4 0
	to be towed	448
	If you think something	150
	is wrong	
	Fuel pump shut off system	454
	If a warning light turns on or a warning buzzer sounds4	455
	If a warning message is displayed	.461
	If you have a flat tire	
	If the engine will not start4	
	If the shift lever cannot	
	be shifted from P	487
	If the electronic key does not operate properly	188
	If the vehicle battery is discharged	490
	If your vehicle overheats	
	If the vehicle becomes	
	stuck	497


# 446 8-1. Essential information

# **Emergency flashers**

The emergency flashers are used to warn other drivers when the vehicle has to be stopped in the road due to a breakdown, etc.

Press the switch.

All the turn signals will flash. To turn them off, press the switch once again.



#### Emergency flashers

If the emergency flashers are used for a long time while the engine is not operating, the battery may discharge.

447

# If your vehicle has to be stopped in an emergency

Only in an emergency, such as if it becomes impossible to stop the vehicle in the normal way, stop the vehicle using the following procedure:

1 Steadily step on the brake pedal with both feet and firmly depress it.

Do not pump the brake pedal repeatedly as this will increase the effort required to slow the vehicle.

- 2 Shift the shift lever to N.
- ▶ If the shift lever is shifted to N
- 3 After slowing down, stop the vehicle in a safe place by the road.
- **4** Stop the engine.
- If the shift lever cannot be shifted to N
- 3 Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.
- **4** To stop the engine, press and hold the engine switch for 2 consecutive seconds or more, or press it briefly 3 times or more in succession.



**5** Stop the vehicle in a safe place by the road.

#### 

#### If the engine has to be turned off while driving

Power assist for the brakes and steering wheel will be lost, making the brake pedal harder to depress and the steering wheel heavier to turn. Decelerate as much as possible before turning off the engine.

# If your vehicle needs to be towed

If towing is necessary, we recommend having your vehicle towed by your Lexus dealer or a commercial towing service, using a lift-type truck or flat bed truck.

Use a safety chain system for all towing, and abide by all state/provincial and local laws.

#### Before towing

The following may indicate a problem with your transmission. Contact your Lexus dealer before towing.

- The engine is running but the vehicle will not move.
- The vehicle makes an abnormal sound.

#### Emergency towing

If a tow truck is not available in an emergency, your vehicle may be temporarily towed using a cable or chain secured to the emergency towing eyelet. This should only be attempted on hard surfaced roads for short distances at low speeds.

A driver must be in the vehicle to steer and operate the brakes. The vehicle's wheels, drive train, axles, steering and brakes must be in good condition.




#### Installing towing eyelet

- 1 Take out the towing eyelet  $(\rightarrow P. 476)$
- **2** Remove the eyelet cover using a flathead screwdriver.


To protect the bodywork, place a rag between the screwdriver and the vehicle body as shown in the illustration.


3 Insert the towing eyelet into the hole and tighten partially by hand.

**4** Tighten down the towing eyelet securely using a wheel nut wrench.



449





Ŭ

#### Towing with a sling-type truck

Do not tow with a sling-type truck to prevent body damage.




# Towing with a wheel-lift type truck

▶ From the front

▶ From the rear (2WD models)






Use a towing dolly under the rear wheels.

Turn the engine switch to ACCES-SORY mode so that the steering wheel is unlocked.

▶ From the rear (AWD models)



Use a towing dolly under the front wheels.

#### Using a flat bed truck

If your Lexus is transported by a flat bed truck, it should be tied down at the locations shown in the illustration.

If you use chains or cables to tie down your vehicle, the angles shaded in black must be 45°.

Do not overly tighten the tie downs or the vehicle may be damaged.

#### Before emergency towing

- 1 Release the parking brake.
- 2 Shift the shift lever to N.
- **3** Turn the engine switch to ACCESSORY (engine off) or IGNITION ON (engine running) mode.

#### A CAUTION

Observe the following precautions. Failure to do so may result in death or serious injury.

- Caution while towing
  - Use extreme caution when towing the vehicle. Avoid sudden starts or erratic driving maneuvers which place excessive stress on the emergency towing eyelets and the cables or chains. Always be cautious of the surroundings and other vehicles while towing.
  - If the engine is not running, the power assist for the brakes and steering will not function, making steering and braking more difficult.

#### Installing towing eyelets to the vehicle

Make sure that towing eyelets are installed securely.

If not securely installed, towing eyelets may come loose during towing.

451

TYR2A7TR

#### **NOTICE**

To prevent causing serious damage to the transmission and transfer (AWD models) when towing using a wheel-lift type truck

2WD models:

Never tow this vehicle from the front with the rear wheels on the ground. AWD models:

Never tow this vehicle with any of the wheels in contact with the ground.

- To prevent damage to the vehicle when towing using a wheel-lift type truck 2WD models:
  - Do not tow the vehicle from the rear with the engine switch off. The steering lock mechanism is not strong enough to hold the front wheels straight.
  - When raising the vehicle from the rear, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed from the rear.

#### AWD models:

When raising the vehicle, ensure adequate ground clearance for towing at the opposite end of the raised vehicle. Without adequate clearance, the vehicle could be damaged while being towed.

To prevent body damage when towing with a sling-type truck

Do not tow with a sling-type truck, either from the front or rear.

To prevent damage to the vehicle

Do not use the rear tie down hooks when your vehicle is towed.

# If you think something is wrong

If you notice any of the following symptoms, your vehicle probably needs adjustment or repair. Contact your Lexus dealer as soon as possible.

#### Visible symptoms

- Fluid leaks under the vehicle. (Water dripping from the air conditioning after use is normal.)
- Flat-looking tires or uneven tire wear
- Engine coolant temperature gauge needle continually points higher than normal.

#### Audible symptoms

- Changes in exhaust sound
- Excessive tire squeal when cornering
- Strange noises related to the suspension system
- Pinging or other noises related to the engine

#### Operational symptoms

- Engine missing, stumbling or running roughly
- Appreciable loss of power
- Vehicle pulls heavily to one side when braking
- Vehicle pulls heavily to one side when driving on a level road
- Loss of brake effectiveness, spongy feeling, pedal almost touches the floor

8

# Fuel pump shut off system

To minimize the risk of fuel leakage when the engine stalls or when an airbag inflates upon collision, the fuel pump shut off system stops the supply of fuel to the engine.

Follow the procedure below to restart the engine after the system is activated.

- 1 Turn the engine switch to ACCESSORY mode or turn it off.
- **2** Restart the engine.

**NOTICE** 

#### Before starting the engine

Inspect the ground under the vehicle. If you find that fuel has leaked onto the ground, the fuel system has been damaged and is in need of repair. Do not restart the engine.

# If a warning light turns on or a warning buzzer sounds

Calmly perform the following actions if any of the warning lights comes on or flashes. If a light comes on or flashes, but then goes off, this does not necessarily indicate a malfunction in the system. However, if this continues to occur, have the vehicle inspected by your Lexus dealer.

#### Warning light and warning buzzer list

Warning light	Warning light/Details/Actions
BRAKE (US.A.) (Canada)	Brake system warning light (warning buzzer) <sup>*1</sup> Indicates that: • The brake fluid level is low; or • The brake system is malfunctioning → Immediately stop the vehicle in a safe place and contact your Lexus dealer. Continuing to drive the vehicle may be dangerous.
<b>=</b>	Charging system warning light Indicates a malfunction in the vehicle's charging system → Immediately stop the vehicle in a safe place and contact your Lexus dealer.
(CHECK (US.A.)	Malfunction indicator lamp         Indicates a malfunction in:         • The electronic engine control system;         • The electronic throttle control system; or         • The electronic automatic transmission control system         → Have the vehicle inspected by your Lexus dealer immediately.
*	<ul> <li>SRS warning light <ul> <li>Indicates a malfunction in:</li> <li>The SRS airbag system;</li> <li>The front passenger occupant classification system; or</li> <li>The seat belt pretensioner system</li> </ul> </li> <li>→ Have the vehicle inspected by your Lexus dealer immediately.</li> </ul>
ABS (U.S.A.) (Canada)	<ul> <li>ABS warning light Indicates a malfunction in:</li> <li>The ABS; or</li> <li>The brake assist system</li> <li>→ Have the vehicle inspected by your Lexus dealer immediately.</li> </ul>
<b>.</b>	Electric power steering system warning light Indicates a malfunction in the EPS (Electric Power Steering) sys- tem → Have the vehicle inspected by your Lexus dealer immediately.

When trouble arises

8

Warning light	Warning light/Details/Actions
PCS (Flashes) (If equipped)	<ul> <li>Pre-collision system warning light <ul> <li>Indicates a malfunction in the PCS (Pre-Collision System)</li> <li>The warning light will operate as follows, even when the system is not malfunctioning:</li> <li>The light will flash quickly when the system is operating.</li> <li>(→P. 240)</li> </ul> </li> <li>The light will turn on when the pre-collision system is disabled.</li> <li>(→P. 241)</li> <li>The light will turn on when the VSC (Vehicle Stability Control) system is disabled. (→P. 236)</li> <li>The light will flash when the system cannot temporarily be used. (→P. 469)</li> <li>→Have the vehicle inspected by your Lexus dealer immediately.</li> </ul>
	<ul> <li>Slip indicator</li> <li>Indicates a malfunction in:</li> <li>The VSC (Vehicle Stability Control) system;</li> <li>The TRAC (Traction Control) system; or</li> <li>The hill-start assist control system</li> <li>The light will flash when the VSC or the TRAC system is operating.</li> <li>→ Have the vehicle inspected by your Lexus dealer immediately.</li> </ul>
NIL.	Automatic headlight leveling system warning light Indicates a malfunction in the automatic headlight leveling system → Have the vehicle inspected by your Lexus dealer immediately.
	Open door warning light (warning buzzer) <sup>*2</sup> Indicates that a door or the trunk is not fully closed → Check that all the doors and the trunk are closed.
	Low fuel level warning light Indicates that remaining fuel is approximately 2.6 gal. (10 L, 2.2 Imp. gal.) or less → Refuel the vehicle.
*	Seat belt reminder light (warning buzzer) <sup>*3</sup> Warns the driver and/or front passenger to fasten their seat belts → Fasten the seat belt. If the front passenger's seat is occupied, the front passenger's seat belt also needs to be fastened to make the warning light (warning buzzer) turn off.
	Master warning light A buzzer sounds and the warning light comes on and flashes to indicate that the master warning system has detected a malfunc- tion. → P. 461

Warning light	Warning light/Details/Actions
(!)	<ul> <li>Tire pressure warning light When the light comes on: Low tire inflation pressure such as <ul> <li>Natural causes (→P. 458)</li> <li>Flat tire (→P. 475)</li> </ul> </li> <li>→ Adjust the tire inflation pressure to the specified level. The light will turn off after a few minutes. In case the light does not turn off even if the tire inflation pressure is adjusted, have the system checked by your Lexus dealer. When the light comes on after blinking for 1 minute: Malfunction in the tire pressure warning system → Have the system checked by your Lexus dealer.</li></ul>

\*1: Parking brake engaged warning buzzer:

→P. 464

\*<sup>2</sup>: Open door warning buzzer:

→P. 463

\*<sup>3</sup>: Driver's seat belt buzzer:

The driver's seat belt buzzer sounds to alert the driver that his or her seat belt is not fastened. Once the engine switch is turned to IGNITION ON mode, the buzzer sounds for 6 seconds. If the vehicle reaches a speed of 12 mph (20 km/h), the buzzer sounds once. If the seat belt is still unfastened after 24 seconds, the buzzer will sound intermittently for 10 seconds. Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 20 more seconds.

Front passenger's seat belt buzzer:

The front passenger's seat belt buzzer sounds to alert the front passenger that his or her seat belt is not fastened. The buzzer sounds once if the vehicle reaches a speed of 12 mph (20 km/h). If the seat belt is still unfastened after 24 seconds, the buzzer will sound intermittently for 10 seconds. Then, if the seat belt is still unfastened, the buzzer will sound in a different tone for 20 more seconds.

8

8-2. Steps to take in an emergency

#### IS350/250\_U (OM53758U)

#### SRS warning light

This warning light system monitors the airbag sensor assembly, front impact sensors, side impact sensors (front door), side impact sensors (front), side impact sensors (rear), driver's seat position sensor, driver's seat belt buckle switch, front passenger occupant classification system, "AIR BAG ON" indicator light, "AIR BAG OFF" indicator light, front passenger's seat belt buckle switch, seat belt pretensioner assemblies, airbags, interconnecting wiring and power sources. ( $\rightarrow$ P. 38)

#### Front passenger detection sensor, seat belt reminder and warning buzzer

If luggage is placed on the front passenger seat, the front passenger detection sensor may cause the warning light to flash and the warning buzzer to sound even if a passenger is not sitting in the seat.

#### If the malfunction indicator lamp comes on while driving

First check the following:

- Is the fuel tank empty?
  - If it is, fill the fuel tank immediately.
- Is the fuel tank cap loose? If it is, tighten it securely.

init is, lighternit securely.

The light will go off after several driving trips.

If the light does not go off even after several trips, contact your Lexus dealer as soon as possible.

#### Electric power steering system warning light (warning buzzer)

When the battery charge becomes insufficient of the voltage temporarily drops, the electric power steering system warning light may come on and the warning buzzer may sound.

#### When the tire pressure warning light comes on

Check the tire inflation pressure and adjust to the appropriate level. Pushing the tire pressure warning reset switch will not turn off the tire pressure warning light.

#### The tire pressure warning light may come on due to natural causes

The tire pressure warning light may come on due to natural causes such as natural air leaks and tire inflation pressure changes caused by temperature. In this case, adjusting the tire inflation pressure will turn off the warning light (after a few minutes).

#### When a tire is replaced with the spare tire

The compact spare tire is not equipped with a tire pressure warning valve and transmitter. If a tire goes flat, the tire pressure warning light will not turn off even though the flat tire has been replaced with the spare tire.

■ Conditions that the tire pressure warning system may not function properly →P. 416


#### If the tire pressure warning light frequently comes on after blinking for 1 minute

If the tire pressure warning light frequently comes on after blinking for 1 minute when the engine switch is turned to IGNITION ON mode, have it checked by your Lexus dealer.

#### Warning buzzer

In some cases, the buzzer may not be heard due to being in a noisy location or audio sound.

#### 459



When trouble arises

#### 

#### Maintenance of the tires

Each tire, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label (tire and load information label). (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label [tire and load information label], you should determine the proper tire inflation pressure for those tires.)

As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS-tire pressure warning system) that illuminates a low tire pressure telltale (tire pressure warning light) when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale (tire pressure warning light) illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS (tire pressure warning system) is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale (tire pressure warning light).

Your vehicle has also been equipped with a TPMS (tire pressure warning system) malfunction indicator to indicate when the system is not operating properly. The TPMS (tire pressure warning system) malfunction indicator is combined with the low tire pressure telltale (tire pressure warning light). When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended.

TPMS (tire pressure warning system) malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS (tire pressure warning system) from functioning properly. Always check the TPMS (tire pressure warning system) malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS (tire pressure warning system) to continue to function properly.

#### 

#### Precaution when installing a different tire

When differently constructed tires or tires of different makers, models or tread patterns are installed, the tire pressure warning system may not operate properly.

# If a warning message is displayed

If a warning is shown on the multi-information display, stay calm and perform the following actions:

- Except F SPORT models
- ► F SPORT models (when the main meter is in the center position)

461



 F SPORT models (when the main meter is in the right-side position)





1 Master warning light

The master warning light also comes on or flashes in order to indicate that a message is currently being displayed on the multi-information display.

2 Multi-information display

If any of the warning lights come on again after the following actions have been performed, contact your Lexus dealer.

# Warning message and warning buzzer list

Warning message	Details/Actions
BRAKE ! PCS (Flashes) (If equipped)	<ul> <li>Indicates that:</li> <li>There is a high possibility of a frontal collision; or</li> <li>The pre-collision braking function is operating A buzzer also sounds.</li> <li>→ Slow the vehicle by applying the brakes.</li> </ul>
The Engine Has Stopped. Please Put Shift Lever into "P". (Flashes)	Indicates that the engine was stopped with the shift lever not in P A buzzer also sounds. → Shift the shift lever to P.
The Engine Has Stopped. Please Stop Your Car in a Safe Place. (Flashes)	Indicates that the engine was stopped while driving A buzzer also sounds. → Stop the vehicle in a safe place such as the shoulder of a road.
(If equipped)	Indicates that your vehicle is nearing the vehicle ahead (in vehicle-to-vehicle distance mode) A buzzer also sounds. → Slow the vehicle by applying the brakes.
(lf equipped)	Alerts the driver that the vehicle has deviated from the lane (while the LDA [Lane Departure Alert] system is operating) The lane line on the side the vehicle has deviated from flashes in yellow. The warning buzzer sounds continuously. → Check around the vehicle and back to inside of the lane lines.
Brake Malfunction BRAKE (US.A.) (Canada)	<ul> <li>Indicates that:</li> <li>The brake fluid level is low; or</li> <li>The brake system is malfunctioning A buzzer also sounds.</li> <li>→ Immediately stop the vehicle in a safe place and contact your Lexus dealer. Continuing to drive the vehicle may be dangerous.</li> </ul>

IS350/250\_U (OM53758U)

		_
Warning message	Details/Actions	
	Indicates that one or more of the doors is not fully closed The system also indicates which doors are not fully closed. If the vehicle reaches a speed of 3 mph (5 km/h), flashes and a buzzer sounds to indicate that the door(s) are not yet fully closed. → Make sure that all the doors are closed.	
	Indicates that the hood is not fully closed If the vehicle reaches a speed of 3 mph (5 km/h), flashes and a buzzer sounds to indicate that the hood is not yet fully closed. → Close the hood.	
	Indicates that the trunk is not fully closed If the vehicle reaches a speed of 3 mph (5 km/h), flashes and a buzzer sounds to indicate that the trunk is not yet fully closed. → Close the trunk.	
Check Park Sonar System	Indicates a malfunction in the intuitive parking assist-sen- sor The assist-sensors flash. A buzzer also sounds. → <b>Have the vehicle inspected by your Lexus dealer</b> .	
Clean Park Sonar	Indicates that an intuitive parking assist sensor is dirty or covered with ice A buzzer also sounds. → Clean the sensor.	8
EPS Failure. Steering Wheel Harder to Turn. Voltage Abnormality. Steering Wheel Harder to Turn. Check Power Steering System	Indicates a malfunction in the EPS (Electric Power Steer- ing) system A buzzer also sounds. → <b>Have the vehicle inspected by your Lexus dealer</b> .	When trouble arises

Warning message	Details/Actions
Release Parking Brake       BRAKE (U.S.A.)     (Canada)       (Canada)     (Flashes)	Indicates that the vehicle is being driven at 3 mph (5 km/ h) or more with the parking brake still engaged. A buzzer also sounds. → <b>Release the parking brake</b> .
1st Gear not available due to slippery road surface	Indicates that the shift lever was used to attempt to shift to the first gear position in M mode on a slippery road surface The gear position will not shift from the second gear. A buzzer also sounds. →Drive the vehicle in the second or a higher gear position.
Check SRS Airbag System	<ul> <li>Indicates a malfunction in:</li> <li>The SRS airbag system;</li> <li>The front passenger occupant classification system; or</li> <li>The seat belt pretensioner system <ul> <li>A buzzer also sounds.</li> </ul> </li> <li>→ Have the vehicle inspected by your Lexus dealer.</li> </ul>
Check ABS ABS (U.S.A.) (Canada)	<ul> <li>Indicates a malfunction in:</li> <li>The ABS; or</li> <li>The brake assist system A buzzer also sounds.</li> <li>→ Have the vehicle inspected by your Lexus dealer.</li> </ul>
Engine Coolant High Temperature	Indicates that the engine coolant temperature is too high A buzzer also sounds. → P. 494
Clean Radar Sensor	Indicates that the radar sensor is dirty or covered with ice A buzzer also sounds. → <b>Clean the sensor.</b>
Cruise Control not available	Indicates that the dynamic radar cruise control system is unable to judge vehicle-to-vehicle distance A buzzer also sounds. → Turn off snow mode. If the windshield wipers are on, turn them off or set them to a mode other than AUTO or high speed wiper operation.

464

Warning message	Details/Actions	]	
LDA not available (If equipped)	Indicates that the LDA (Lane Departure Alert) system is suspended (The camera sensor temperature is higher than the operation temperature range) A buzzer also sounds. → Restart the LDA after driving for a while.		
BSM not available (If equipped)	Indicates that a Blind Spot Monitor sensor or the surrounding area on the bumper is dirty or covered with ice A buzzer also sounds. → Clean the sensor and its surrounding area on the bumper.		
Check Cruise Control System	<ul> <li>Indicates a malfunction in:</li> <li>The cruise control system; or</li> <li>The dynamic radar cruise control system (if equipped) Press the "ON/OFF" button once to deactivate the system, and then press the button again to reactivate the system. A buzzer also sounds.</li> <li>→ Have the vehicle inspected by your Lexus dealer.</li> </ul>		
Check LDA System (If equipped)	Indicates a malfunction in the LDA (Lane Departure Alert) system A buzzer also sounds. → Have the vehicle inspected by your Lexus dealer.		
Check PCS System PCS (Flashes) (If equipped)	Indicates a malfunction in the PCS (Pre-Collision Sys- tem) A buzzer also sounds. → Have the vehicle inspected by your Lexus dealer.		8
Check BSM System	Indicates a malfunction in the BSM (Blind Spot Monitor) system A buzzer also sounds. → Have the vehicle inspected by your Lexus dealer.		When trouble arises
Engine Oil Pressure Low	Indicates abnormal engine oil pressure A buzzer also sounds. →Immediately stop the vehicle in a safe place and contact your Lexus dealer.		ses

# **466** 8-2.

# 8-2. Steps to take in an emergency

Warning message	Details/Actions
Transmission Fluid High Temperature	Indicates that the automatic transmission fluid tempera- ture is too high A buzzer also sounds. → Have the vehicle inspected by your Lexus dealer.
Check AWD System	Indicates a malfunction in the AWD system A buzzer also sounds. → Have the vehicle inspected by your Lexus dealer.
Check VGRS System	Indicates a malfunction in the VGRS (Variable Gear Ratio Steering) system A buzzer also sounds. → Have the vehicle inspected by your Lexus dealer.
Engine Stopped, Steering Wheel Harder to Turn.	Indicates that the engine was stopped while driving A buzzer also sounds. → Operate the steering wheel with more force than usual.
Turn Light Off	Indicates that the engine switch is turned off or turned to ACCESSORY mode and the driver's door is opened while the lights are turned on A buzzer also sounds. → Turn the lights off.
Moon Roof opened	Indicates that the moon roof is not fully closed (with the engine switch off, and the driver's door open) A buzzer also sounds. → Close the moon roof.
Window opened (Flashes)	Indicates that the windows are not fully closed (with the engine switch off, and the driver's door open) A buzzer also sounds. → Close all the windows.

· · · ·		
Warning message	Details/Actions	
Window / Moon Roof opened	Indicates that the windows and the moon roof are not fully closed (with the engine switch off, and the driver's door open) A buzzer also sounds. → Close all the windows and the moon roof.	
Brake Override	Indicates a malfunction in the brake override system	
System	A buzzer also sounds.	
Failure.	→ Have the vehicle inspected by your Lexus dealer.	
Engine Oil Level Low	Indicates that engine oil level is low A buzzer also sounds. → <b>Check the level of engine oil, and add if necessary</b> .	
Check	<ul> <li>Indicates a malfunction in:</li> <li>The automatic headlight leveling system; or</li> <li>The Automatic High Beam system (if equipped)</li> <li>The LED headlight system (if equipped)</li></ul>	
Headlight System	A buzzer also sounds. <li>→ Have the vehicle inspected by your Lexus dealer.</li>	
Both Accelerator	Indicates that the accelerator and brake pedal are being	
and Brake Pedals	depressed simultaneously	
Are Depressed.	→ <b>Release the accelerator or brake pedal</b> .	
Tire Pressure [psi]	Indicates that the tire inflation pressure is low	
36 26	→ Check the tire inflation pressure, and adjust to the	
36 36 36	appropriate level.	

467

Warning message	Details/Actions
Tire Pressure [psi]   (!)	<ul> <li>Indicates a malfunction in the tire pressure warning system</li> <li>→ Stop the vehicle in a safe place and turn the engine switch off then on again.</li> <li>If the tire pressure warning indicator flashes for 1 minute then illuminates, there is a malfunction in the system. Have the vehicle inspected at your Lexus dealer.</li> </ul>
Tire Pressure [psi]  	Indicates that the tire position information cannot be rec- ognized → Drive for a short while and check if the display updates. If the radio wave conditions improve, the display may return to normal. If the tire pressure is still not displayed after driving for several minutes, stop the vehicle in a safe place, turn the engine switch off then on again, and start driving. If the tire pressure is still not displayed even after repeating this process several times, have the vehi- cle inspected at your Lexus dealer.
Washer Fluid Low	Indicates that the washer fluid level is low $\rightarrow$ Add washer fluid.
Fuel Low	Indicates that remaining fuel is approximately 2.6 gal. (10 L, 2.2 lmp. gal.) or less → <b>Refuel the vehicle.</b>
TRAC OFF	Indicates that the TRAC (Traction Control) system has been deactivated → Turn the TRAC on. (→P. 236)
Maintenance required soon (U.S.A. only)	Indicates that all maintenance according to the driven distance on the maintenance schedule <sup>*</sup> should be per- formed soon. Comes on approximately 4500 miles (7200 km) after the maintenance data has been reset. → If necessary, perform maintenance.

468

Warning message	Details/Actions
Maintenance required (U.S.A. only)	Indicates that all maintenance is required to correspond to the driven distance on the maintenance schedule <sup>*</sup> . Comes on approximately 5000 miles (8000 km) after the maintenance data has been reset. (The indicator will not work properly unless the mainte- nance data has been reset.) → Perform the necessary maintenance. Please reset the maintenance data after the maintenance is per- formed (→P. 391)
Turn on the high beam	Indicates that the Automatic High Beam switch is
to activate	pressed while the headlights are in low beam.
AHB System	→ Turn the high beam on and press the Automatic
(If equipped)	High Beam switch again.
VSC System Switched Off.	Indicates that, since the VSC (Vehicle Stability Control)
Pre-Collision Brake System	system was turned off, the pre-collision brake system
Disengaged.	operation is stopped
PCS	→ Turn the VSC on. (→P. 236)
PCS temporarily	Indicates that the PCS (Pre-Collision System) is not cur-
not available	rently functional because the grille cover or the sensor is
PCS	dirty
(Flashes)	→ Check the grille cover and the sensor and clean
(If equipped)	them if they are dirty.
Operation of Electrical Items Restricted.	Indicates that operation of large electricity consuming systems such as the air conditioning system are sus- pended → Stop using unnecessary electric components to reduce electricity consumption. Wait a while until the electric power supply is restored.
LDA System is Unavailable	Indicates that the LDA (Lane Departure Alert) system
Below Approx.	cannot be used because the vehicle speed is lower than
32 MPH.	approximately 32 mph (50 km/h)
(If equipped)	→ Drive the vehicle at 32 mph (50 km/h) or higher.

\*: Refer to the separate "Scheduled Maintenance" or "Owner's Manual Supplement" for the maintenance interval applicable to your vehicle.

469

#### Warning messages

The warning message illustrations used are intended as examples, and may differ from the image that is actually displayed on the multi-information display.

■ Warning message in radar cruise mode (if equipped)

In the following situations, the warning message may not be displayed even if vehicle-to-vehicle distance decreases:

- When your vehicle and the vehicle ahead are traveling at the same speed or the vehicle ahead is traveling more quickly than your vehicle
- When the vehicle ahead is traveling at a very low speed
- Immediately after cruise control speed is set
- At the instant the accelerator pedal is depressed
- The LDA (Lane Departure Alert) lane departure warning function

In the following situations, the warning message will not be displayed even if a lane line is crossed.

- When the vehicle speed deviates from the operating range of the LDA system functions
- When the lane lines cannot be recognized
- Reset the maintenance data (U.S.A. only)

Make sure to reset the oil change system.  $(\rightarrow P. 391)$ 

- Conditions that the tire pressure warning system may not function properly →P. 416
- Warning buzzer
  - →P. 458

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Con- tinuous		Shift to P position when parked (Flashes)	The driver's door was opened when the shift lever was not in P and the engine switch was not turned off. → Shift the shift lever to P.
Con- tinuous	Con- tinuous	Shift to P position when parked Key not detected (Displayed alternately) (Flashes)	The driver's door was opened and closed while the electronic key was not in the vehicle, the shift lever was not in P and the engine switch was not turned off. → Shift the shift lever to P. → Bring the electronic key back into the vehicle.
Once		Key not detected	The electronic key is not detected when an attempt is made to start the engine. → Start the engine with the elec- tronic key present.
Once	Con- tinuous	Turn Power Off Key not detected (Displayed alternately)	An attempt was made to exit the vehicle with the electronic key and lock the doors without first turning the engine switch off when the shift lever was in P. → Turn the engine switch off and lock the doors again.
Once	3 times	Key not detected	The electronic key was carried out- side the vehicle and a door other than the driver's door was opened and closed while the engine switch was in a mode other than off. $\rightarrow$ Bring the electronic key back into the vehicle. The driver's door was opened and closed while the electronic key was not in the vehicle, the shift lever was in P and the engine switch was not turned off. $\rightarrow$ Turn the engine switch off. $\rightarrow$ Bring the electronic key back into the vehicle.

471


When trouble arises

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
9 times		Key not detected	An attempt was made to drive when the electronic key was not inside the vehicle. → Confirm that the electronic key is inside the vehicle.
_	Con- tinuous	Key detected in vehicle (Flashes)	An attempt was made to lock the doors using the smart access system with push-button start while the electronic key was still inside the vehicle. → Retrieve the electronic key from the vehicle and lock the doors again.
Once	Con- tinuous	Key detected in vehicle (Flashes)	An attempt was made to lock either front door by opening a door and putting the inside lock button into the lock position, then closing the door with the electronic key still inside the vehicle. → Retrieve the electronic key from the vehicle and lock the doors again.
Once	_	Key Battery Low	The electronic key has a low battery. → Replace the electronic key bat- tery. (→P. 427)
Once		Steering Lock active	The steering lock could not be released within 3 seconds of the engine switch being pressed. → Press the engine switch while depressing the brake pedal and moving the steering wheel left and right.
Once		Check Access System with Elec. Key	Indicates a malfunction in the smart access system with push-button start → Have the vehicle inspected by your Lexus dealer.

Interior buzzer	Exterior buzzer	Warning message	Details/Actions
Once		Depress brake pedal, touch engine switch with key (Flashes)	<ul> <li>When the doors were unlocked with the mechanical key and then the engine switch was pressed, the electronic key could not be detected in the vehicle.</li> <li>The electronic key could not be detected in the vehicle even after the engine switch was pressed two consecutive times.</li> <li>→ Touch the electronic key to the engine switch while depressing the brake pedal.</li> </ul>
Once		Depress brake pedal and push engine switch to start	During an engine starting proce- dure in the event that the electronic key was not functioning properly (→P. 489), the engine switch was touched with the electronic key. → Press the engine switch within 10 seconds of the buzzer sound- ing.
		Depress brake pedal and push engine switch to start	<ul> <li>Indicates that:</li> <li>With the engine switch off, the doors were unlocked and then the driver's door was opened and closed</li> <li>The engine switch was turned to ACCESSORY mode without starting the engine</li> <li>The shift lever was shifted to P or N from another shift position with the engine switch in IGNITION ON mode.</li> <li>→ Press the engine switch while depressing the brake pedal.</li> </ul>
Once		Shift to P position when parked	The engine switch has been turned off with the shift lever in a position other than P or N. → <b>Shift the shift lever to P</b> .
Once		Turn Power Off	After the engine switch has been turned off with the shift lever in a position other than P, the shift lever has been shifted to P. → Turn the engine switch off.

473

When trouble arises



\*: The engine may not be restarted depending on the vehicle condition.

■ Warning messages
 →P. 470
 ■ Warning buzzer

→P. 458

.

# If you have a flat tire

Remove the flat tire and replace it with the spare tire provided.

For details about tires:  $\rightarrow$  P. 411

# **CAUTION**

If you have a flat tire


Do not continue driving with a flat tire. Driving even a short distance with a flat tire can damage the tire and the wheel beyond repair, which could result in an accident.


### Before jacking up the vehicle

- Stop the vehicle on a hard, flat surface.
- Set the parking brake.
- Shift the shift lever to P.
- Stop the engine.
- Turn on the emergency flashers. ( $\rightarrow$ P. 446)

When trouble arises

475





### 477

# 


#### Using the tire jack

Observe the following precautions.

- Improper use of the tire jack may cause the vehicle to suddenly fall off the jack, leading to death or serious injury.
- Do not use the tire jack for any purpose other than replacing tires or installing and removing tire chains.
- Only use the tire jack that comes with this vehicle for replacing a flat tire. Do not use it on other vehicles, and do not use other tire jacks for replacing tires on this vehicle.
- Put the jack properly in its jack point.
- Do not put any part of your body under the vehicle while it is supported by the jack.
- Do not start the engine or drive the vehicle while the vehicle is supported by the jack.
- Do not raise the vehicle while someone is inside.
- When raising the vehicle, do not put an object on or under the jack.
- Do not raise the vehicle to a height greater than that required to replace the tire.
- Use a jack stand if it is necessary to get under the vehicle.
- When lowering the vehicle, make sure that there is no-one near the vehicle. If there are people nearby, warn them vocally before lowering.


## Taking out the jack and jack handle

- **1** Remove the luggage mat.
- **2** Take out the jack handle from the reverse side of the luggage mat. Remove the spacer.




## **3** Take out the jack.

- 1 For tightening
- 2 For loosening



#### Taking out the spare tire


- **1** Remove the luggage mat.
- **2** Remove the spacer and tool tray.



479

**3** Loosen the center fastener that secures the spare tire.

If the center fastener cannot be turned by hand, use the wheel nut wrench that is stored in the trunk. (To secure the tire, tighten the center fastener by hand. Do not use the wrench or other tools.)



# 

#### When storing the spare tire

Be careful not to catch fingers or other body parts between the spare tire and the body of the vehicle.

8


### Replacing a flat tire

1 Chock the tires.



	Flat tire	Wheel chock positions
Front	Left-hand side	Behind the rear right-hand side tire
TIOIR	Right-hand side	Behind the rear left-hand side tire
Rear	Left-hand side	In front of the front right-hand side tire
Redi	Right-hand side	In front of the front left-hand side tire

2 Slightly loosen the wheel nuts (one turn).



**3** Turn the tire jack portion "A" by hand until the notch of the jack is in contact with the jack point.


The jack point guides are located under the rocker panel. They indicate the jack point positions.



**4** Raise the vehicle until the tire is slightly raised off the ground.

**5** Remove all the wheel nuts and the tire.

When resting the tire on the ground, place the tire so that the wheel design faces up to avoid scratching the wheel surface.



481



### **CAUTION**

#### Replacing a flat tire

 Do not touch the disc wheels or the area around the brakes immediately after the vehicle has been driven.

After the vehicle has been driven the disc wheels and the area around the brakes will be extremely hot. Touching these areas with hands, feet or other body parts while changing a tire, etc. may result in burns.


- Failure to follow these precautions could cause the wheel nuts to loosen and the tire to fall off, resulting in death or serious injury.
  - Never use oil or grease on the wheel bolts or wheel nuts.
  - Oil and grease may cause the wheel nuts to be excessively tightened, leading to bolt or disc wheel damage. In addition, the oil or grease can cause the wheel nuts to loosen and the wheel may fall off, causing a serious accident. Remove any oil or grease from the wheel bolts or wheel nuts.
  - Have the wheel nuts tightened with a torque wrench to 76 ft•lbf (103 N•m, 10.5 kgf•m) as soon as possible after changing wheels.
  - Do not attach a heavily damaged wheel ornament, as it may fly off the wheel while the vehicle is moving.
  - When installing a tire, only use wheel nuts that have been specifically designed for that wheel.
  - If there are any cracks or deformations in the bolt screws, nut threads or bolt holes of the wheel, have the vehicle inspected by your Lexus dealer.

8

#### Installing the spare tire

1 Remove any dirt or foreign matter from the wheel contact surface.

If foreign matter is on the wheel contact surface, the wheel nuts may loosen while the vehicle is in motion, causing the tire to come off.




Tapered portion

Disc wheel


**2** Install the spare tire and loosely tighten each wheel nut by hand by approximately the same amount.


When replacing an aluminum wheel with a steel wheel, tighten the wheel nuts until the tapered portion comes into loose contact with the disc wheel seat.



**4** Firmly tighten each wheel nut two or three times in the order shown in the illustration.

**Tightening torque:** 76 ft•lbf (103 N•m, 10.5 kgf•m)





**5** Stow the flat tire, tire jack and all tools.

#### The compact spare tire

• The compact spare tire is identified by the label "TEMPORARY USE ONLY" on the tire sidewall.

Use the compact spare tire temporarily, and only in an emergency.

• Make sure to check the tire inflation pressure of the compact spare tire. ( $\rightarrow$  P. 507)

#### When using the compact spare tire

As the compact spare tire is not equipped with a tire pressure warning valve and transmitter, low inflation pressure of the spare tire will not be indicated by the tire pressure warning system. Also, if you replace the compact spare tire after the tire pressure warning light comes on, the light remains on.

#### When the compact spare tire is equipped

The vehicle becomes lower when driving with the compact spare tire compared to when driving with standard tires.

If you have a flat rear tire on a road covered with snow or ice (vehicles with front and rear tires of the same size)

Install the compact spare tire on one of the front wheels of the vehicle. Perform the following steps and fit tire chains to the rear tires:

- Replace a front tire with the compact spare tire.
- 2 Replace the flat rear tire with the tire removed from the front of the vehicle.
- **3** Fit tire chains to the rear tires.

483

#### **CAUTION**

#### When using the compact spare tire

- Remember that the compact spare tire provided is specifically designed for use with your vehicle. Do not use your compact spare tire on another vehicle.
- Do not use more than one compact spare tires simultaneously.
- Replace the compact spare tire with a standard tire as soon as possible.
- Avoid sudden acceleration, abrupt steering, sudden braking and shifting operations that cause sudden engine braking.

#### When the compact spare tire is attached

The vehicle speed may not be correctly detected, and the following systems may not operate correctly:

- ABS & Brake assist
- VSC
- TRAC
- Cruise control (if equipped)
- Dynamic radar cruise control
- (if equipped)
- PCS (if equipped)EPS

- Adaptive Variable Suspension System (if equipped)
- LDA (Lane Departure Alert) (if equipped)
- VGRS (if equipped)
- Rear view monitor system
- (if equipped)
- Intuitive parking assist (if equipped)Navigation system (if equipped)

Also, not only can the following system not be utilized fully, but it may even negatively affect the drive-train components:

- AWD system
- Speed limit when using the compact spare tire

Do not drive at speeds in excess of 50 mph (80 km/h) when a compact spare tire is installed on the vehicle.

The compact spare tire is not designed for driving at high speeds. Failure to observe this precaution may lead to an accident causing death or serious injury.

#### After using the tools and jack

Before driving, make sure all the tools and jack are securely in place in their storage location to reduce the possibility of personal injury during a collision or sudden braking.

#### **NOTICE**

#### Driving with tire chains and the compact spare tire

Do not fit tire chains to the compact spare tire.

Tire chains may damage the vehicle body and adversely affect driving performance.

When replacing the tires

When removing or fitting the wheels, tires or the tire pressure warning valve and transmitter, contact your Lexus dealer as the tire pressure warning valve and transmitter may be damaged if not handled correctly.

# If the engine will not start

If the engine will not start even though correct starting procedures are being followed ( $\rightarrow$ P. 159), consider each of the following points:

The engine will not start even though the starter motor operates normally.

One of the following may be the cause of the problem:

- There may not be sufficient fuel in the vehicle's tank. Refuel the vehicle.
- The engine may be flooded. Try to restart the engine again following correct starting procedures.  $(\rightarrow P. 159)$
- There may be a malfunction in the engine immobilizer system.  $(\rightarrow P. 69)$

# The starter motor turns over slowly, the interior lights and headlights are dim, or the horn does not sound or sounds at a low volume.

One of the following may be the cause of the problem:

- The battery terminal connections may be loose or corroded.
- The battery may be discharged. ( $\rightarrow$ P. 490)

#### The starter motor does not turn over

The engine starting system may be malfunctioning due to an electrical problem such as electronic key battery depletion or a blown fuse. However, an interim measure is available to start the engine.  $(\rightarrow P. 486)$ 

# The starter motor does not turn over, the interior lights and headlights do not turn on, or the horn does not sound.

One of the following may be the cause of the problem:

- One or both of the battery terminals may be disconnected.
- The battery may be discharged.  $(\rightarrow P. 490)$
- There may be a malfunction in the steering lock system.

Contact your Lexus dealer if the problem cannot be repaired, or if repair procedures are unknown.

### **Emergency start function**

When the engine does not start, the following steps can be used as an interim measure to start the engine if the engine switch is functioning normally:

- **1** Set the parking brake.
- 2 Shift the shift lever to P.
- **3** Turn the engine switch to ACCESSORY mode.
- **4** Press and hold the engine switch for about 15 seconds while depressing the brake pedal firmly.

Even if the engine can be started using the above steps, the system may be malfunctioning. Have the vehicle inspected by your Lexus dealer.

# If the shift lever cannot be shifted from P


If the shift lever cannot be shifted with your foot on the brake pedal, there may be a problem with the shift lock system (a system to prevent accidental operation of the shift lever). Have the vehicle inspected by your Lexus dealer immediately.

The following steps may be used as an emergency measure to ensure that the shift lever can be shifted:

- **1** Set the parking brake.
- **2** Turn the engine switch to ACCESSORY mode.
- 3 Depress the brake pedal.
- **4** Pry the cover up with a flathead screwdriver or equivalent tool.

To prevent damage to the cover, cover the tip of the screwdriver with a rag.

Fress the shift lock override button.
 The shift lever can be shifted while the button is pressed.



8

# If the electronic key does not operate properly

If communication between the electronic key and vehicle is interrupted ( $\rightarrow$ P. 116) or the electronic key cannot be used because the battery is depleted, the smart access system with push-button start and wireless remote control cannot be used. In such cases, the doors and trunk can be opened and the engine can be started by following the procedure below.

Locking and unlocking the doors, unlocking the trunk and key linked functions

Doors


Use the mechanical key ( $\rightarrow$ P. 99) in order to perform the following operations:


- 1 Locks all the doors
- ② Closes the windows and moon roof (turn and hold)\*
- 3 Unlocks the door

Turning the key rearward unlocks the driver's door. Turning the key once again within 5 seconds unlocks the other doors.

- (4) Opens the windows and moon roof (turn and hold)\*
  - \*: This setting must be customized at your Lexus dealer.
- Trunk

Turn the mechanical key clockwise to open.






#### Starting the engine

- 1 Ensure that the shift lever is in P and depress the brake pedal.
- **2** Touch the Lexus emblem side of the electronic key to the engine switch.

When the electronic key is detected, a buzzer sounds and the engine switch will turn to IGNITION ON mode.

When the smart access system with push-button start is deactivated in customization setting, the engine switch will turn to ACCESSORY mode.



3 Firmly depress the brake pedal and check that is shown on the multi-

information display.

4 Press the engine switch.

In the event that the engine still cannot be started, contact your Lexus dealer.

#### Stopping the engine

Shift the shift lever to P and press the engine switch as you normally do when stopping the engine.

Replacing the key battery

As the above procedure is a temporary measure, it is recommended that the electronic key battery be replaced immediately when the battery is depleted. ( $\rightarrow$ P. 427)

#### Changing engine switch modes

Release the brake pedal and press the engine switch in step 3 above. The engine does not start and modes will be changed each time the switch is pressed. ( $\rightarrow$ P. 160)

#### When the electronic key does not work properly

- Make sure that the smart access system with push-button start has not been deactivated in the customization setting. If it is off, turn the function on. (Customizable features →P. 525)
- Check if battery-saving mode is set. If it is set, cancel the function.  $(\rightarrow P. 115)$

8

#### 489

# If the vehicle battery is discharged


The following procedures may be used to start the engine if the vehicle's battery is discharged.

You can also call your Lexus dealer or a qualified repair shop.

If you have a set of jumper (or booster) cables and a second vehicle with a 12-volt battery, you can jump start your vehicle by following the steps below.


- 1 Open the hood ( $\rightarrow$ P. 399)
- **2** Remove the engine cover.
- ▶ IS250

Raise the front of the engine cover to detach it from the clips and then pull the cover to detach it from the brackets on the rear bar.



### ▶ IS350

Raise the rear of the engine cover to remove the rear clip, and then raise the front of the engine cover to remove the two front clips.



- 3 Connect the jumper cables according to the following procedure:

- Connect a positive jumper cable clamp to the positive (+) battery terminal on your vehicle.
- 2 Connect the clamp on the other end of the positive cable to the positive (+) battery terminal on the second vehicle.
- 3 Connect a negative cable clamp to the negative (-) battery terminal on the second vehicle.
- ④ Connect the clamp at the other end of the negative cable to a solid, stationary, unpainted metallic point away from the battery and any moving parts, as shown in the illustration.
- 4 Start the engine of the second vehicle. Increase the engine speed slightly and maintain at that level for approximately 5 minutes to recharge the battery of your vehicle.
- **5** Open and close any of the doors of your vehicle with the engine switch off.
- 6 Maintain the engine speed of the second vehicle and start the engine of your vehicle by turning the engine switch to IGNITION ON mode.
- Once the vehicle's engine has started, remove the jumper cables in the exact reverse order from which they were connected.

Once the engine starts, have the vehicle inspected at your Lexus dealer as soon as possible.

8

491

# Starting the engine when the battery is discharged

The engine cannot be started by push-starting.

#### To prevent battery discharge

- Turn off the headlights and the audio system while the engine is off.
- Turn off any unnecessary electrical components when the vehicle is running at a low speed for an extended period, such as in heavy traffic.


#### Charging the battery

The electricity stored in the battery will discharge gradually even when the vehicle is not in use, due to natural discharge and the draining effects of certain electrical appliances. If the vehicle is left for a long time, the battery may discharge, and the engine may be unable to start. (The battery recharges automatically during driving.)

#### When recharging or replacing the battery

- Make sure that the key is not inside the vehicle when recharging or replacing the battery. The key may be locked in the vehicle if the alarm is activated. (→P. 72)
- In some cases, it may not be possible to unlock the doors using the smart access system with push-button start when the battery is discharged. Use the wireless remote control or the mechanical key to lock or unlock the doors.
- The engine may not start on the first attempt after the battery has recharged but will start normally after the second attempt. This is not a malfunction.
- The engine switch mode is memorized by the vehicle. When the battery is reconnected, the system will return to the mode it was in before the battery was discharged. Before disconnecting the battery, turn the engine switch off.
  - If you are unsure what mode the engine switch was in before the battery discharged, be especially careful when reconnecting the battery.

## 493



### **NOTICE**

#### When handling jumper cables

When connecting the jumper cables, ensure that they do not become entangled in the cooling fans or engine drive belt.

# If your vehicle overheats

The following may indicate that your vehicle is overheating.

- The needle of the engine coolant temperature gauge (→P. 81) enters the red zone or a loss of engine power is experienced. (For example, the vehicle speed does not increase.)
- Steam comes out from under the hood.

#### **Correction procedures**


- 1 Stop the vehicle in a safe place and turn off the air conditioning system, and then stop the engine.
- **2** If you see steam:

Carefully lift the hood after the steam subsides.


If you do not see steam: Carefully lift the hood.

- 3 After the engine has cooled down sufficiently, inspect the hoses and radiator core (radiator) for any leaks.
  - 1 Radiator
  - Cooling fans

If a large amount of coolant leaks, immediately contact your Lexus dealer.



- **4** The coolant level is satisfactory if it is between the "FULL" and "LOW" lines on the reservoir.
  - 1 Reservoir
  - 2 "FULL"
  - 3 "LOW"
- Add coolant if necessary.
   Water can be used in an emergency if coolant is unavailable.



495



**6** Start the engine and turn the air conditioning system on to check that the radiator cooling fan operates and to check for coolant leaks from the radiator or hoses.

The fan operates when the air conditioning system is turned on immediately after a cold start. Confirm that the fan is operating by checking the fan sound and air flow. If it is difficult to check these, turn the air conditioning system on and off repeatedly. (The fan may not operate in freezing temperatures.)

**7** If the fan is not operating:

Stop the engine immediately and contact your Lexus dealer.

If the fan is operating:

Have the vehicle inspected at the nearest Lexus dealer.

### 


#### When inspecting under the hood of your vehicle

Observe the following precautions.

Failure to do so may result in serious injury such as burns.

- If steam is seen coming from under the hood, do not open the hood until the steam has subsided. The engine compartment may be very hot.
- Keep hands and clothing (especially a tie, a scarf or a muffler) away from the fans and belts. Failure to do so may cause the hands or clothing to be caught, resulting in serious injury.
- While the engine and radiator are hot, do not loosen or remove the coolant reservoir cap or radiator cap. (The radiator cap is located under the engine cover.)

High temperature steam or coolant could spray out.



### \land NOTICE

#### When adding engine coolant

Add coolant slowly after the engine has cooled down sufficiently. Adding cool coolant to a hot engine too quickly can cause damage to the engine.

To prevent damage to the cooling system

Observe the following precautions:

- Avoid contaminating the coolant with foreign matter (such as sand or dust etc.).
- Do not use commercially available coolant additives.


# If the vehicle becomes stuck

Carry out the following procedures if the tires spin or the vehicle becomes stuck in mud, dirt or snow:

- 1 Stop the engine. Set the parking brake and shift the shift lever to P.
- **2** Remove the mud, snow or sand from around the rear wheels.
- 3 Place wood, stones or some other material under the rear wheels to help provide traction.
- **4** Restart the engine.
- **5** Shift the shift lever to D or R and release the parking brake. Then, while exercising caution, depress the accelerator pedal.

#### When it is difficult to free the vehicle

Press to turn off TRAC.



497

### **CAUTION**

#### When attempting to free a stuck vehicle

If you choose to push the vehicle back and forth to free it, make sure the surrounding area is clear to avoid striking other vehicles, objects or people. The vehicle may also lunge forward or lunge back suddenly as it becomes free. Use extreme caution.

#### When shifting the shift lever

Be careful not to shift the shift lever with the accelerator pedal depressed. This may lead to unexpected rapid acceleration of the vehicle that may cause an accident resulting in death or serious injury.

#### NOTICE

#### To avoid damaging the transmission and other components

- Avoid spinning the rear wheels and depressing the accelerator pedal more than necessary.
- If the vehicle remains stuck even after these procedures are performed, the vehicle may require towing to be freed.

# 

# Vehicle specifications

9-1.	Specifications	
	Maintenance data (fuel, oil level, etc.)	500
	Fuel information	510
	Tire information	513
9-2.	Customization	
	Customizable features	.525
9-3.	ltems to initialize	
	Items to initialize	.534

# 500 9-1. Specifications

# Maintenance data (fuel, oil level, etc.)

# Dimensions and weight

Overall length		183.7 in. (4665 mm)
Overall width		71.3 in. (1810 mm)
Overall height <sup>*1</sup>		56.3 in. (1430 mm)
Wheelbase		110.2 in. (2800 mm)
+1	Front	60.4 in. (1535 mm)
Tread <sup>*1</sup> Rear		61.0 in. (1550 mm) 60.6 in. (1540 mm)* <sup>2</sup>
Vehicle capacity weight (Occupants + lug- gage)		825 lb. (375 kg)

\*<sup>1</sup>: Unladen vehicle

\*<sup>2</sup>: Vehicles with 255/35R18 tires

# Vehicle identification

### Vehicle identification number

The vehicle identification number (VIN) is the legal identifier for your vehicle. This is the primary identification number for your Lexus. It is used in registering the ownership of your vehicle.

This number is stamped on the top left of the instrument panel and in the engine compartment.




This number is also on the Certification Label.



#### Engine number

The engine number is stamped on the engine block as shown.



9

Vehicle specifications

# 502 9-1. Specifications

# Engine

	IS250	IS350
Model	2.5 L 6-cylinder (4GR-FSE) engine	3.5 L 6-cylinder (2GR-FSE) engine
Туре	6-cylinder V type, 4-cycle, gasoline	
Bore and stroke	$3.27 \times 3.03$ in. (83.0 × 77.0 mm)	$3.70 \times 3.27$ in. (94.0 × 83.0 mm)
Displacement	152.5 cu. in. (2500 cm <sup>3</sup> )	210.9 cu. in. (3456 cm <sup>3</sup> )
Valve clearance (engine cold)	Automatic adjustment	
Drive belt tension	Automatic adjustment	

# Fuel

Fuel type	Unleaded gasoline only
Octane Rating	91 (Research Octane Number 96) or higher
Fuel tank capacity (Reference)	17.5 gal. (66.3 L, 14.6 lmp. gal.)

### Lubrication system

# Oil capacity (Drain and refill [Reference\*])

	2WD	AWD
With filter	6.6 qt. (6.2 L, 5.5 Imp. qt.)	6.8 qt. (6.4 L, 5.6 lmp. qt.)
Without filter	6.2 qt. (5.9 L, 5.2 Imp. qt.)	6.3 qt. (6.0 L, 5.3 lmp. qt.)

\*: The engine oil capacity is a reference quantity to be used when changing the engine oil. Warm up and turn off the engine, wait more than 5 minutes, and check the oil level on the dipstick.

#### Engine oil selection

"Toyota Genuine Motor Oil" is used in your Lexus vehicle. Use Lexus approved "Toyota Genuine Motor Oil" or equivalent to satisfy the following grade and viscosity.

Oil grade: ILSAC GF-5 multigrade engine oil

Recommended viscosity: SAE OW-20

SAE OW-20 is the best choice for good fuel economy and good starting in cold weather.

If SAE OW-20 is not available, SAE 5W-20 oil may be used. However, it must be replaced with SAE OW-20 at the next oil change.

Outside temperature

Oil viscosity (OW-20 is explained here as an example):

- The OW in OW-20 indicates the characteristic of the oil which allows cold startability. Oils with a lower value before the W allow for easier starting of the engine in cold weather.
- The 20 in OW-20 indicates the viscosity characteristic of the oil when the oil is at high temperature. An oil with a higher viscosity (one with a higher value) may be better suited if the vehicle is operated at high speeds, or under extreme load conditions.

How to read oil container label:

The International Lubricant Specification Advisory Committee (ILSAC) Certification Mark is added to some oil containers to help you select the oil you should use.



9

Vehicle specifications

503

#### **504** 9-1. Specifications

# Cooling system

	IS250	IS350
Capacity	11.1 qt. (10.5 L, 9.2 lmp. qt.)	9.8 qt. (9.3 L, 8.2 lmp. qt.)
Coolant type	Use either of the following: • "Toyota Super Long Life Co • Similar high-quality ethyle non-amine, non-nitrite, and life hybrid organic acid tech Do not use plain water alone.	ene glycol-based non-silicate, I non-borate coolant with long-

#### Ignition system

Spark plug

Make	DENSO FK20HBR11
Gap	0.043 in. (1.1 mm)

#### <u>∧</u>NOTICE

#### Iridium-tipped spark plugs

Use only iridium-tipped spark plugs. Do not adjust the spark plug gap.

#### Electrical system

Battery	
(20°C):	12.6 — 12.8 V Fully charged 12.2 — 12.4 V Half charged 11.8 — 12.0 V Discharged (Check the voltage 20 minutes after the engine and all lights are turned off.)
Charging rates	5 A max.

505

#### Automatic transmission

		IS250	IS350
Fluid capacity*	2WD	7.9 qt. (7.5 L, 6.6 lmp. qt.)	10.0 qt. (9.5 L, 8.4 lmp. qt.)
	AWD	9.9 qt. (9.4 L, 8.3 lmp. qt.)	10.6 qt. (10.0 L, 8.8 lmp. qt.)
Fluid type		Toyota Genuine ATF WS	

\*: The fluid capacity is a reference quantity.

If replacement is necessary, contact your Lexus dealer.

#### **NOTICE**

#### Automatic transmission fluid type

Using transmission fluid other than "Toyota Genuine ATF WS" may cause deterioration in shift quality, locking up of your transmission accompanied by vibration, and ultimately damage the transmission of your vehicle.

#### Front differential (AWD models)

Oil capacity	0.74 qt. (0.70 L, 0.61 lmp. qt.)
Oil type and viscosity	Hypoid gear oil API GL-5 Above 0°F (-18°C): SAE90 Below 0°F (-18°C): SAE80W or SAE80W-90

#### **Rear differential**

Oil capacity	IS250	1.20 qt. (1.15 L, 1.01 lmp. qt.)
	IS350	1.42 qt. (1.35 L, 1.19 lmp. qt.)
Oil type and viscosity		Toyota Genuine Differential gear oil LT 75W-85 GL-5 or equivalent

Your Lexus vehicle is filled with "Toyota Genuine Differential Gear Oil" at the factory. Use Lexus approved "Toyota Genuine Differential Gear Oil" or an equivalent of matching quality to satisfy the above specification. Please contact your Lexus dealer for further details.

Vehicle specifications

#### 506 9-1. Specifications

#### Brakes

Pedal clearance <sup>*1</sup>	2WD	4.2 in. (107 mm) Min.
	AWD	4.7 in. (118 mm) Min.
Pedal free play		0.04 - 0.08 in. (1.0 - 2.0 mm)
Brake pad wear limit		0.04 in. (1.0 mm)
Parking brake lining wear limit		0.04 in. (1.0 mm)
Parking brake pedal travel <sup>*2</sup>		7—10 clicks
Fluid type		SAE J1703 or FMVSS No. 116 DOT 3

\*1: Minimum pedal clearance when depressed with a force of 112.4 lbf (500 N, 51.0 kgf) while the engine is running.

 $^{\star2}\!:$  Parking brake pedal travel when depressed with a force of 67.4 lbf (300 N, 30.6 kgf)

#### Steering

Free play

Less than 1.2 in. (30 mm)

9-1. Specifications

507

#### Tires and wheels

#### ▶ Type A

Tire size	205/55R16 91W, T125/70D17 98M (spare)
Tire inflation pressure (Recommended cold tire inflation pressure)	Front tire 36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) Rear tire 36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) Spare tire 60 psi (420 kPa, 4.2 kgf/cm <sup>2</sup> or bar)
Wheel size	$16 \times 7$ J, $17 \times 4T$ (spare)
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

# ▶ Туре В

Tire size	225/45R17 91W, T125/70D17 98M (spare)
Tire inflation pressure (Recommended cold tire inflation pressure)	Front tire 36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) Rear tire 36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) Spare tire 60 psi (420 kPa, 4.2 kgf/cm <sup>2</sup> or bar)
Wheel size	17 × 7 1/2J, 17 × 4T (spare)
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

#### ► Type C

Tire size	225/45R17 91V, T125/70D17 98M (spare)	
Tire inflation pressure (Recommended cold tire inflation pressure)	Front tire 36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) Rear tire 36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) Spare tire 60 psi (420 kPa, 4.2 kgf/cm <sup>2</sup> or bar)	
Wheel size	$17\times71/2$ J, $17\times4T$ (spare)	
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)	

9

#### 508 9-1. Specifications

#### ► Type D

	-
Tire size	225/40R18 88Y, 255/35R18 90Y, T125/70D17 98M (spare)
Tire inflation pressure (Recommended cold tire inflation pressure)	Front tire 36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) Rear tire 36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) Spare tire 60 psi (420 kPa, 4.2 kgf/cm <sup>2</sup> or bar)
Wheel size	18 × 8J (225/40R18), 18 × 81/2J (255/35R18), 17 × 4T (spare)
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

#### ▶ Type E

Tire size	225/40R18 88W, 255/35R18 90W, T125/70D17 98M (spare)
Tire inflation pressure (Recommended cold tire inflation pressure)	Front tire 36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) Rear tire 36 psi (250 kPa, 2.5 kgf/cm <sup>2</sup> or bar) Spare tire 60 psi (420 kPa, 4.2 kgf/cm <sup>2</sup> or bar)
Wheel size	18 × 8J (225/40R18), 18 × 8 1/2J (255/35R18), 17 × 4T (spare)
Wheel nut torque	76 ft•lbf (103 N•m, 10.5 kgf•m)

ight bulbs <sup>*1</sup>						
	Light bulbs	Bulb No.	W	Туре		
	Discharge headlights <sup>*2</sup>		35	А		
	Fog lights <sup>*2</sup>		19	В		
Exterior	Front turn signal lights	7444NA	28/8	С		
LXIENDI	Rear turn signal lights		21	С		
	Back-up lights	921	16	D		
	Outer foot lights		5	D		
	Door courtesy lights	168	5	D		
	Vanity lights		8	D		
Interior	Interior light		8	D		
	Personal lights		8	D		
	Footwell lights	194	3.8	D		
	Trunk light		5	D		

Li

Γ

A: D4S discharge bulbs

B: H16 halogen bulbs

C: Wedge base bulbs (amber)

D: Wedge base bulbs (clear)

\*1: Light bulbs not listed in this table are LED bulbs.

\*<sup>2</sup>: If equipped

9-1. Specifications

#### **Fuel information**

You must only use unleaded gasoline in your vehicle.

▶ IS250

Select premium unleaded gasoline with an octane rating of 91 (Research Octane Number 96) or higher required for optimum engine performance. If 91 octane cannot be obtained, you may use unleaded gasoline with an octane rating as low as 87 (Research Octane Number 91). Use of unleaded gasoline with an octane rating lower than 91 may result in engine knocking. Persistent knocking can lead to engine damage and should be corrected by refueling with higher octane unleaded gasoline.

▶ IS350

Select premium unleaded gasoline with an octane rating of 91 (Research Octane Number 96) or higher required for optimum engine performance. If 91 octane cannot be obtained, you may use unleaded gasoline with an octane rating as low as 87 (Research Octane Number 91). Use of unleaded gasoline with an octane rating lower than 91 may result in engine knocking and significantly reduced performance. Persistent knocking can lead to engine damage and should be corrected by refueling with higher octane unleaded gasoline.

At minimum, the gasoline you use should meet the specifications of ASTM D4814 in the U.S.A. and CGSB3.5-M93 in Canada.

#### Fuel tank opening for unleaded gasoline

To help prevent incorrect fueling, your vehicle has a fuel tank opening that only accommodates the special nozzle on unleaded fuel pumps.

Gasoline quality

In very few cases, driveability problems may be caused by the brand of gasoline you are using. If driveability problems persist, try changing the brand of gasoline. If this does not correct the problem, consult your Lexus dealer.

- Gasoline quality standards
  - Automotive manufacturers in the U.S.A., Europe and Japan have developed a specification for fuel quality called the World-Wide Fuel Charter (WWFC), which is expected to be applied worldwide.
  - The WWFC consists of four categories that are based on required emission levels. In the U.S., category 4 has been adopted.
  - The WWFC improves air quality by lowering emissions in vehicle fleets, and improves customer satisfaction through better performance.

#### Recommendation of the use of gasoline containing detergent additives

- Lexus recommends the use of gasoline that contains detergent additives to avoid the build-up of engine deposits.
- All gasoline sold in the U.S.A. contains minimum detergent additives to clean and/or keep clean intake systems, per EPA's lowest additives concentration program.
- Lexus strongly recommends the use of Top Tier Detergent Gasoline. For more information on Top Tier Detergent Gasoline and a list of marketers, please go to the official website www.toptiergas.com.

#### Recommendation of the use of cleaner burning gasoline


Cleaner burning gasoline, including reformulated gasoline that contains oxygenates such as ethanol or MTBE (Methyl Tertiary Butyl Ether) is available in many areas.

Lexus recommends the use of cleaner burning gasoline and appropriately blended reformulated gasoline. These types of gasoline provide excellent vehicle performance, reduce vehicle emissions and improve air quality.

#### Non-recommendation of the use of blended gasoline

• Use only gasoline containing up to 15% ethanol.

DO NOT use any flex-fuel or gasoline that could contain more than 15% ethanol, including from any pump labeled E30, E50, E85 (which are only some examples of fuel containing more than 15% ethanol).



- If you use gasohol in your vehicle, be sure that it has an octane rating no lower than 87.
- Lexus does not recommend the use of gasoline containing methanol.
- Non-recommendation of the use of gasoline containing MMT

Some gasoline contains an octane enhancing additive called MMT (Methylcyclopentadienyl Manganese Tricarbonyl).

Lexus does not recommend the use of gasoline that contains MMT. If fuel containing MMT is used, your emission control system may be adversely affected.

The malfunction indicator lamp on the instrument cluster may come on. If this happens, contact your Lexus dealer for service.

#### If your engine knocks

- Consult your Lexus dealer.
- You may occasionally notice light knocking for a short time while accelerating or driving uphill. This is normal and there is no need for concern.

#### ▲ NOTICE

#### Notice on fuel quality

- Do not use improper fuels. If improper fuels are used, the engine will be damaged.
- Do not use leaded gasoline. Leaded gasoline can cause damage to your vehicle's three-way catalytic converters causing the emission control system to malfunction.
- Do not use gasohol other than the type previously stated. Other gasohol may cause fuel system damage or vehicle performance problems.
- Using unleaded gasoline with an octane number or rating lower than the level previously stated will cause persistent heavy knocking. At worst, this will lead to engine damage.

#### Fuel-related poor driveability

If poor driveability is encountered after using a different type of fuel (poor hot starting, vaporization, engine knocking, etc.), discontinue the use of that type of fuel.


#### When refueling with gasohol

Take care not to spill gasohol. It can damage your vehicle's paint.

513

# <section-header>

► Compact spare tire



•

Vehicle specifications


1 Tire size	(→P. 516)
2 TUBELESS or TUBE TYPE	
<ul><li>A tubeless tire does not have a tube and air is directly put into the has a tube inside the tire and the tube maintains the air pressure.</li><li>3 Radial tires or bias-ply tires</li></ul>	
A radial tire has "RADIAL" on the sidewall. A tire not marked "F tire.	RADIAL" is a bias-ply
④ Summer tires or all season tires	(→P. 415)
An all season tire has "M+S" on the sidewall. A tire not marked tire.	d "M+S" is a summer
5 Maximum cold tire inflation pressure	(→P. 520)
This means the pressure to which a tire may be inflated. 6 Load limit at maximum cold tire inflation pressure	(→P. 520)
$\bigcirc$ Tire ply composition and materials	
Plies are layers of rubber-coated parallel cords. Cords are the st plies in a tire.	trands which form the
⑧ Uniform tire quality grading	
For details, see "Uniform Tire Quality Grading" that follows. ODT and Tire Identification Number (TIN)	(→P. 515)
<ul> <li>Dest and me identification (unit)</li> <li>Location of treadwear indicators</li> </ul>	(→P. 411)
<ul> <li>"TEMPORARY USE ONLY"</li> </ul>	
A compact spare tire is identified by the phrase "TEMPORARY	USE ONLY" molded

A compact spare tire is identified by the phrase "TEMPORARY USE ONLY" molded on its sidewall. This tire is designed for temporary emergency use only.

9-1. Specifications

#### Typical DOT and Tire Identification Number (TIN)

- 1 DOT symbol\*
- (2) Tire Identification Number (TIN)
- ③ Tire manufacturer's identification mark
- 4 Tire size code
- 5 Manufacturer's optional tire type code (3 or 4 letters)
- 6 Manufacturing week
- ⑦ Manufacturing year



Safety Standards.

 $\star$ : The DOT symbol certifies that the tire conforms to applicable Federal Motor Vehicle

9

#### 516 9-1. Specifications

#### Tire size

#### ■ Typical tire size information


The illustration indicates typical tire size.

- Tire use (P = Passenger car, T = Temporary use)
- ② Section width (millimeters)
- (3) Aspect ratio(tire height to section width)
- (4) Tire construction code (R = Radial, D = Diagonal)
- 5 Wheel diameter (inches)
- 6 Load index (2 digits or 3 digits)
- Speed symbol (alphabet with one letter)

#### Tire dimensions

- 1 Section width
- Tire height
- 3 Wheel diameter






#### 9-1. Specifications

517

#### Tire section names

- 1 Bead
- Sidewall
- 3 Shoulder
- (4) Tread
- 5 Belt
- 6 Inner liner
- 7 Reinforcing rubber
- 8 Carcass
- 9 Rim lines
- 10 Bead wires
- (1) Chafer



#### Uniform Tire Quality Grading

This information has been prepared in accordance with regulations issued by the National Highway Traffic Safety Administration of the U.S. Department of Transportation.

It provides the purchasers and/or prospective purchasers of Lexus vehicles with information on uniform tire quality grading.

Your Lexus dealer will help answer any questions you may have as you read this information.

#### DOT quality grades

All passenger vehicle tires must conform to Federal Safety Requirements in addition to these grades. Quality grades can be found where applicable on the tire sidewall between tread shoulder and maximum section width.

For example: Treadwear 200 Traction AA Temperature A

Treadwear

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course.

For example, a tire graded 150 would wear one and a half (1 - 1/2) times as well on the government course as a tire graded 100.

The relative performance of tires depends upon the actual conditions of their use. Performance may differ significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

#### Traction AA, A, B, C

The traction grades, from highest to lowest, are AA, A, B and C, and they represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete.

A tire marked C may have poor traction performance.

Warning: The traction grade assigned to this tire is based on braking (straight ahead) traction tests and does not include cornering (turning) traction.

519

#### Temperature A, B, C

The temperature grades are A (the highest), B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

- Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to sudden tire failure.
- Grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109.
- Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.
- Warning: The temperature grades of a tire assume that it is properly inflated and not overloaded.
- Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

9

#### **520** 9-1. Specifications

# Glossary of tire terminology

Tire related term	Meaning
Cold tire inflation pressure	Tire pressure when the vehicle has been parked for three hours or more, or has not been driven more than 1 mile or 1.5 km under that condition
Maximum inflation pres- sure	The maximum cold inflated pressure to which a tire may be inflated, shown on the sidewall of the tire
Recommended inflation pressure	Cold tire inflation pressure recommended by a manu- facturer
Accessory weight	The combined weight (in excess of those standard items which may be replaced) of automatic transmission, power steering, power brakes, power windows, power seats, radio and heater, to the extent that these items are available as factory-installed equipment (whether installed or not)
Curb weight	The weight of a motor vehicle with standard equipment, including the maximum capacity of fuel, oil and coolant, and if so equipped, air conditioning and additional weight optional engine
Maximum loaded vehicle weight	The sum of: (a) Curb weight (b) Accessory weight (c) Vehicle capacity weight (d) Production options weight
Normal occupant weight	150 lb. (68 kg) times the number of occupants specified in the second column of Table 1 <sup>*</sup> that follows
Occupant distribution	Distribution of occupants in a vehicle as specified in the third column of Table 1 <sup>*</sup> below
Production options weight	The combined weight of installed regular production options weighing over 5 lb. (2.3 kg) in excess of the standard items which they replace, not previously con- sidered in curb weight or accessory weight, including heavy duty brakes, ride levelers, roof rack, heavy duty battery, and special trim
Rim	A metal support for a tire or a tire and tube assembly upon which the tire beads are seated

9-1. Specifications

521

Tire related term	Meaning
Rim diameter (Wheel diameter)	Nominal diameter of the bead seat
Rim size designation	Rim diameter and width
Rim type designation	The industry manufacturer's designation for a rim by style or code
Rim width	Nominal distance between rim flanges
Vehicle capacity weight (Total load capacity)	The rated cargo and luggage load plus 150 lb. (68 kg) times the vehicle's designated seating capacity
Vehicle maximum load on the tire	The load on an individual tire that is determined by dis- tributing to each axle its share of the maximum loaded vehicle weight, and dividing by two
Vehicle normal load on the tire	The load on an individual tire that is determined by dis- tributing to each axle its share of curb weight, accessory weight, and normal occupant weight (distributed in accordance with Table 1 <sup>*</sup> below), and dividing by two
Weather side	The surface area of the rim not covered by the inflated tire
Bead	The part of the tire that is made of steel wires, wrapped or reinforced by ply cords and that is shaped to fit the rim
Bead separation	A breakdown of the bond between components in the bead
Bias ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at alternate angles substantially less than 90 degrees to the centerline of the tread
Carcass	The tire structure, except tread and sidewall rubber which, when inflated, bears the load
Chunking	The breaking away of pieces of the tread or sidewall
Cord	The strands forming the plies in the tire
Cord separation	The parting of cords from adjacent rubber compounds
Cracking	Any parting within the tread, sidewall, or innerliner of the tire extending to cord material

#### **522** 9-1. Specifications

Tire related term	Meaning
СТ	A pneumatic tire with an inverted flange tire and rim system in which the rim is designed with rim flanges pointed radially inward and the tire is designed to fit on the underside of the rim in a manner that encloses the rim flanges inside the air cavity of the tire
Extra load tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire
Groove	The space between two adjacent tread ribs
Innerliner	The layer(s) forming the inside surface of a tubeless tire that contains the inflating medium within the tire
Innerliner separation	The parting of the innerliner from cord material in the carcass
Intended outboard sidewall	<ul> <li>(a) The sidewall that contains a whitewall, bears white lettering, or bears manufacturer, brand, and/or model name molding that is higher or deeper than the same molding on the other sidewall of the tire, or</li> <li>(b) The outward facing sidewall of an asymmetrical tire that has a particular side that must always face outward when mounted on a vehicle</li> </ul>
Light truck (LT) tire	A tire designated by its manufacturer as primarily intended for use on lightweight trucks or multipurpose passenger vehicles
Load rating	The maximum load that a tire is rated to carry for a given inflation pressure
Maximum load rating	The load rating for a tire at the maximum permissible inflation pressure for that tire
Maximum permissible infla- tion pressure	The maximum cold inflation pressure to which a tire may be inflated
Measuring rim	The rim on which a tire is fitted for physical dimension requirements
Open splice	Any parting at any junction of tread, sidewall, or inner- liner that extends to cord material
Outer diameter	The overall diameter of an inflated new tire

9-1. Specifications

523

Tire related term	Meaning
Overall width	The linear distance between the exteriors of the side- walls of an inflated tire, including elevations due to label- ing, decorations, or protective bands or ribs
Passenger car tire	A tire intended for use on passenger cars, multipurpose passenger vehicles, and trucks, that have a gross vehicle weight rating (GVWR) of 10,000 lb. or less.
Ply	A layer of rubber-coated parallel cords
Ply separation	A parting of rubber compound between adjacent plies
Pneumatic tire	A mechanical device made of rubber, chemicals, fabric and steel or other materials, that, when mounted on an automotive wheel, provides the traction and contains the gas or fluid that sustains the load
Radial ply tire	A pneumatic tire in which the ply cords that extend to the beads are laid at substantially 90 degrees to the centerline of the tread
Reinforced tire	A tire designed to operate at higher loads and at higher inflation pressures than the corresponding standard tire
Section width	The linear distance between the exteriors of the side- walls of an inflated tire, excluding elevations due to labeling, decoration, or protective bands
Sidewall	That portion of a tire between the tread and bead
Sidewall separation	The parting of the rubber compound from the cord material in the sidewall
Snow tire	A tire that attains a traction index equal to or greater than 110, compared to the ASTM E-1136 Standard Ref- erence Test Tire, when using the snow traction test as described in ASTM F-1805-00, Standard Test Method for Single Wheel Driving Traction in a Straight Line on Snow-and Ice-Covered Surfaces, and which is marked with an Alpine Symbol (
Test rim	The rim on which a tire is fitted for testing, and may be any rim listed as appropriate for use with that tire

#### **524** 9-1. Specifications

Tire related term	Meaning
Tread	That portion of a tire that comes into contact with the road
Tread rib	A tread section running circumferentially around a tire
Tread separation	Pulling away of the tread from the tire carcass
Treadwear indicators (TWI)	The projections within the principal grooves designed to give a visual indication of the degrees of wear of the tread
Wheel-holding fixture	The fixture used to hold the wheel and tire assembly securely during testing

\*: Table 1— Occupant loading and distribution for vehicle normal load for various designated seating capacities

Designated seating capac- ity, Number of occupants	Vehicle normal load, Num- ber of occupants	Occupant distribution in a normally loaded vehicle
2 through 4	2	2 in front
5 through 10	3	2 in front, 1 in second seat
11 through 15	5	2 in front, 1 in second seat, 1 in third seat, 1 in fourth seat
16 through 20	7	2 in front, 2 in second seat, 2 in third seat, 1 in fourth seat

525

#### **Customizable features**

Your vehicle includes a variety of electronic features that can be personalized to your preferences. The settings of these features can be changed by using the meter control switches, the Remote Touch or Lexus Display Audio controller or at your Lexus dealer.

#### Customizing vehicle features

- Changing by using the Remote Touch or Lexus Display Audio controller
- Vehicles with a Remote Touch
- 1 Press the "MENU" button on the Remote Touch.
- **2** Select "Setup" on the "Menu" screen and select "Vehicle".

Various setting can be changed. Refer to the list of settings that can be changed for details.

- ▶ Vehicles with a Lexus Display Audio controller
- 1 Press the "MENU" button on the Lexus Display Audio controller.
- 2 Select "Setup" on the "Menu" screen and select "Vehicle".

Various setting can be changed. Refer to the list of settings that can be changed for details.

Changing by using the meter control switches

→P. 87

9

#### Customizable features

Some function settings are changed simultaneously with other functions being customized. Contact your Lexus dealer for further details.

- Settings that can be changed using the Remote Touch or Lexus Display Audio controller
- ② Settings that can be changed using the meter control switches
- 3 Settings that can be changed by your Lexus dealer

Definition of symbols: O = Available, - = Not available

■ Gauges, meters and multi-information display (→P. 76, 81, 86)

Function <sup>*1</sup>	Default setting	Customized setting	1	2	3
Language	English	French	0	0	_
Language	Liigiisii	Spanish			
		km (km/L)		0	
Units <sup>*2</sup>	miles (MPG US)	km (L/100 km)	_		_
		miles (MPG Impe- rial)			
Maintenance system initial- ization	OFF	ON	_	0	_
Eco Driving Indicator Light	ON (Self-lighting)	OFF	_	0	-
switch settings *3	Drive information 1	Desired status screen <sup>*4</sup>	-	0	-
Drive information 1	Current fuel econ- omy	*5	_	0	
	Average fuel econ- omy (after reset)				
	Distance (range)	*5			
Drive information 2	Average speed (after reset)	^0	-	0	-
Pop-up display	ON	OFF	-	0	-
Accent color <sup>*3</sup>	Blue	Red	0	0	-
Needle <sup>*6</sup>	Blue	Red		0	
Ineedie		White	-		
Speed indicator <sup>*6</sup>	OFF	30 to 100 mph (50 to 160 km/h)	-	0	_

9-2. Customization

527

Function <sup>*1</sup>	Default setting	Customized setting	1	2	3
REV indicator <sup>*6</sup>	5000 rpm	2000 to 6600 rpm	_	0	_
		OFF			
REV peak <sup>*6</sup>	ON	OFF	-	0	_

\*1: For details about each function:  $\rightarrow$  P.88

\*<sup>2</sup>: The default setting varies according to country.

\*<sup>3</sup>: Except F SPORT models

\*4: Some status screens cannot be registered (indicated on multi-information display).

\*5: 2 of the following items: current fuel consumption, average fuel economy (after reset), average fuel economy (after refuel), average fuel economy (after start), average vehicle speed (after reset), average vehicle speed (after start), distance (driving range), distance (after start), elapsed time (after reset), elapsed time (after start), blank.

#### \*6: F SPORT models

#### ■ Door lock (→P. 103, 109, 488)

Function	Default setting	Customized setting	1	2	3
Unlocking using a mechani- cal key	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step	_	_	0
		Off			
Automatic door lock	Shifting the shift lever to position other than P	Vehicle speed is approximately 12 mph (20 km/h) or higher	0		0
	Shifting the shift	Off			
Automatic door unlock	lever to P	Driver's door is opened	0	-	0
Locking/unlocking of the trunk when all doors are locked/unlocked	On	Off	_	_	0

•

#### 528 9-2. Customization

# ■ Smart access system with push-button start and wireless remote control (→P.103,109)

Function	Default setting	Customized setting	1	2	3
Operation buzzer volume	5	Off	0		0
	5	1 to 7		_	U
Operation signal (Emer- gency flashers)	On	Off	0	_	0
Time elapsed before auto- matic door lock function is	60 seconds	Off	0	_	
activated if door is not		30 seconds			0
opened after being unlocked		120 seconds			
Open door warning buzzer	On	Off	_	-	0

#### ■ Smart access system with push-button start (→P. 103, 109, 114)

Function	Default setting	Customized setting	1	2	3
Smart access system with push-button start	On	Off	_	_	0
Smart door unlocking	Driver's door	All the doors	0	_	0
Number of consecutive door lock operations	2 times	As many as desired	_	_	0

#### ■ Wireless remote control (→P. 98, 103, 109)

Function	Default setting	Customized setting	1	2	3
Wireless remote control	On	Off	_	_	0
Unlocking operation	Driver's door unlocked in one step, all doors unlocked in two steps	All doors unlocked in one step	0	_	0
		One short press			
	Press and hold	Push twice			
Trunk unlocking operation	(short)	Press and hold (long)	-	_	0
		Off			
Alarm (panic mode)	On	Off	-	-	0

#### ■ Driving position memory<sup>\*</sup> ( $\rightarrow$ P. 123)

Function	Default setting	Customized setting	1	2	3
Driver's seat movement		Off	0	_	0
when exiting the vehicle		Partial	)		Ŭ
Selecting the door linking driving position memory with door unlock operation	Driver's door	All doors	_	_	0

\*: If equipped

■ Power windows (→P. 137)

Function	Default setting	Customized setting	1	2	3
Mechanical key linked oper- ation	Off	On	_	_	0
Wireless remote control linked operation	Off	On (Open only)	_	_	0

#### ■ Moon roof\* (→P. 140)

Function	Default setting	Customized setting	1	2	3
Mechanical key linked oper- ation	Off	On	_	_	0
Linked operation of compo- nents when mechanical key is used (open only)	Slide only	Tilt only	_	_	0
Wireless remote control linked operation	Off	On (Open only)	_	_	0
Linked operation of compo- nents when wireless remote control is used	Slide only	Tilt only	_	_	0

\*: If equipped

#### 530 9-2. Customization

#### ■ Turn signal lever ( $\rightarrow$ P. 170)

Function	Default setting	Customized setting	1	2	3
The number of times the turn signal lights flash auto- matically when the turn sig- nal lever is moved to the first position during a lane change <sup>+1</sup>	3	5 7 Off*2 Off*3	_	_	0

\*1: After flashing the turn signal lights when turning left or right while this function is off and the turn signal lever is moved to the first position in the direction of the flashing light, the turn signal lights can be selected to be flashing or off.

\*2: The turn signal lights keep flashing if the turn signal lever is moved to the first position in the direction of flashing light.

\*<sup>3</sup>: The turn signal lights will be off if the turn signal lever is moved to the first position in the direction of flashing light.

#### Automatic light control system ( $\rightarrow$ P. 173)

Function	Default setting	Customized setting	1	2	3
Light sensor sensitivity	Standard	-2 to 2	0	-	0
Time elapsed before head-		Off			
lights automatically turn off	30 seconds	60 seconds	0	-	0
after doors are closed		90 seconds	-		
Welcome light illumination control	On	Off	_	_	0

9-2. Customization

531

#### ■ Lights (→P. 173)

Function	Default setting	Customized setting	1	2	3
Daytime running light sys- tem*	On	Off	0	_	0

# \*: U.S.A. only

# Intuitive parking assist $^{*1}(\rightarrow P. 214)$

Function	Default setting	Customized setting	1	2	3
Detection distance of the front center sensor	Far	Near	0	_	0
Detection distance of the rear center sensor	Far	Near	0	_	0
Buzzer volume	3	1 to 5	0	-	0
Display setting <sup>*2</sup>	All sensors dis- played	Display off	0	-	0

\*1: If equipped

\*<sup>2</sup>: When intuitive parking assist is operating.

#### Automatic air conditioning system ( $\rightarrow$ P. 346)

Function	Default setting	Customized setting	1	2	3
A/C Auto switch operation	On	Off	0	Ι	0

#### 532 9-2. Customization

#### Illumination ( $\rightarrow$ P. 356)

Function	Default setting	Customized setting	1	2	3
		Off			
Time elapsed before the interior lights turn off	15 seconds	7.5 seconds	0	-	0
		30 seconds			
Operation after the engine switch is turned off	On	Off	_	_	0
Operation when the doors are unlocked	On	Off	_	_	0
Operation when you approach the vehicle with the electronic key on your person	On	Off	_	_	0
Inside door handle lights	On	Off	-	-	0
		Off			
Time elapsed before the outer foot lights turn off	15 seconds	7.5 seconds	0	-	0
		30 seconds			
Operation of the outer foot lights when you approach the vehicle with the elec- tronic key on your person	On	Off	_	_	0
Operation of the outer foot lights when the doors are unlocked with the power door lock switch	On	Off	_	_	0

#### ■ Seat belt reminder (→P. 456)

Function	Default setting	Customized setting	1	2	3
Vehicle speed linked seat belt reminder buzzer	On	Off	_	_	0

#### Vehicle customization

- When the smart access system with push-button start is off, the entry unlock function cannot be customized.
- When the doors remain closed after unlocking the doors and the timer activated automatic door lock function activates, signals will be generated in accordance with the operation buzzer volume and operational signal (Emergency flashers) function settings.
- When customizing using the Remote Touch or Lexus Display Audio controller

Stop the vehicle in a safe place, apply the parking brake, and shift the shift lever to P. Also, to prevent battery discharge, leave the engine running while customizing the features.

#### 

#### During customization

As the engine needs to be running during customization, ensure that the vehicle is parked in a place with adequate ventilation. In a closed area such as a garage, exhaust gases including harmful carbon monoxide (CO) may collect and enter the vehicle. This may lead to death or a serious health hazard.

#### 

#### During customization

To prevent battery discharge, ensure that the engine is running while customizing features.

#### **534** 9-3. Items to initialize

# Items to initialize

The following items must be initialized for normal system operation after such cases as the battery being reconnected, or maintenance being performed on the vehicle:

ltem	When to initialize	Reference
Maintenance data	<ul> <li>After the maintenance is per- formed</li> </ul>	P. 391
Tire pressure warning system	<ul> <li>When rotating the tires</li> <li>When changing the tire inflation pressure by changing traveling speed or load weight, etc.</li> </ul>	P. 413

#### For owners

10

# 535

Reporting safety defects for U.S. owners	536
Seat belt instructions for Canadian owners (in French)	. 537
SRS airbag instructions for Canadian owners (in French)	538

#### Reporting safety defects for U.S. owners

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying the Lexus Division of Toyota Motor Sales, U.S.A., Inc. (Toll-free: 1-800-25-LEXUS).

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Lexus Division of Toyota Motor Sales, U.S.A., Inc.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to *http://www.safercar.gov*; or write to: Administrator, NHTSA, 1200 New Jersey Ave, S.E., Washington, DC 20590. You can also obtain other information about motor vehicle safety from *http://www.safercar.gov.* 

# Seat belt instructions for Canadian owners (in French)

# The following is a French explanation of seat belt instructions extracted from the seat belt section in this manual.

See the seat belt section for more detailed seat belt instructions in English.

#### Utilisation correcte des ceintures de sécurité

- Déroulez la sangle diagonale de telle sorte qu'elle passe bien sur l'épaule, sans pour autant être en contact avec le cou ou glisser de l'épaule.
- Placez la sangle abdominale le plus bas possible sur les hanches.
- Réglez la position du dossier de siège. Asseyez-vous le dos le plus droit possible et calez-vous bien dans le siège.
- Ne vrillez pas la ceinture de sécurité.

#### Entretien et soin

#### Ceintures de sécurité

Nettoyez avec un chiffon ou une éponge humectée d'eau savonneuse tiède. Vérifiez régulièrement que les ceintures ne sont pas effilochées, entaillées ou exagérément usées.

#### **ATTENTION**

#### Détérioration et usure des ceintures de sécurité

Inspectez les ceintures de sécurité périodiquement. Contrôlez qu'elles ne sont pas entaillées, effilochées et que leurs ancrages ne sont pas desserrés. N'utilisez pas une ceinture de sécurité défectueuse avant qu'elle ne soit remplacée. Une ceinture de sécurité défectueuse n'apporte aucune garantie de protection de l'occupant en cas d'accident.


For owners



# SRS airbag instructions for Canadian owners (in French)

# The following is a French explanation of SRS airbag instructions extracted from the SRS airbag section in this manual.

See the SRS airbag section for more detailed SRS airbag instructions in English.



#### Airbags SRS frontaux

- 1 L'airbag SRS conducteur/l'airbag du passager avant Participent à la protection de la tête et du thorax du conducteur et du passager avant contre les chocs contre les éléments de l'habitacle
- Les airbags SRS de genoux
   Participent à la protection du conducteur et du passager avant

#### 538

#### • Airbags SRS latéraux et rideaux


# 3 Airbags SRS latéraux avant

Peuvent aider à protéger le torse des passagers avant

Airbags SRS latéraux arrière (sur modèles équipés)

Participent à la protection du haut du corps des occupants assis aux places arrière extérieures

 Airbags SRS rideaux
 Participent principalement à la protection de la tête des occupants assis aux places extérieures



- 8 Capteurs d'impact latéral (avant)
- (17) Contacteur de boucle de ceinture de sécurité du siège passager avant
- (18) Capteurs d'impact avant

Votre véhicule est équipé d'AIRBAGS INTELLIGENTS conçus selon les normes de sécurité américaines applicables aux véhicules à moteur (FMVSS208). Le boîtier électronique (ECU) des airbags régule le déploiement de ces derniers sur la base des informations qu'il reçoit des capteurs, etc., indiqués ci-dessus dans le schéma illustrant les composants du système. Parmi ces informations figurent la gravité du choc et l'occupation du véhicule par les passagers. Le déploiement rapide des airbags est obtenu au moyen d'une réaction chimique dans les dispositifs pyrotechniques, qui produit un gaz inoffensif permettant d'amortir le mouvement des occupants.

#### **ATTENTION**

#### Précautions avec les airbags SRS

Respectez les précautions suivantes avec les airbags SRS.

Autrement, des blessures graves, voire mortelles, pourraient s'ensuivre.

 Le conducteur et les passagers du véhicule doivent porter correctement leur ceinture de sécurité.

Les airbags SRS sont des dispositifs supplémentaires à utiliser avec les ceintures de sécurité.

 L'airbag SRS conducteur se déploie avec une violence considérable, qui peut être très dangereuse, voire mortelle, si le conducteur se trouve très près de l'airbag. L'autorité fédérale chargée de la sécurité routière aux États-Unis (NHTSA) conseille:

Sachant que la zone de danger pour l'airbag conducteur se trouve dans les premiers 2 à 3 in. (50 - 75 mm) de déploiement, vous placer à 10 in. (250 mm) de votre airbag conducteur vous garantit une marge de sécurité suffisante. Cette distance est à mesurer entre l'axe du volant et le sternum. Si vous êtes assis à moins de 10 in. (250 mm), vous pouvez changer votre position de conduite de plusieurs façons:

- Reculez votre siège le plus possible, de manière à pouvoir encore atteindre confortablement les pédales.
- Inclinez légèrement le dossier du siège.

Bien que les véhicules puissent être différents les uns des autres, la plupart des conducteurs peuvent s'asseoir à une distance de 10 in. (250 mm), même avec le siège conducteur complètement avancé, simplement en inclinant un peu le dossier de siège. Si vous avez des difficultés à voir la route après avoir incliné votre siège, utilisez un coussin ferme et antidérapant pour vous rehausser ou, si votre véhicule est équipé du réglage en hauteur du siège, remontez-le.

 Si votre volant est réglable, inclinez-le vers le bas. Cela a pour effet d'orienter l'airbag en direction de votre poitrine plutôt que de votre tête et de votre cou.

Réglez votre siège selon ces recommandations de la NHTSA, tout en conservant le contrôle des pédales, du volant et la vue des commandes du tableau de bord.

#### Précautions avec les airbags SRS

Si vous attachez une rallonge de ceinture de sécurité aux boucles de ceinture de sécurité avant, mais pas au pêne de la ceinture de sécurité, les airbags SRS frontaux détectent que le conducteur et le passager avant ont attaché leur ceinture de sécurité, alors même que ce n'est pas le cas. Dans ce cas, il se peut que les airbags SRS frontaux ne se déploient pas correctement en cas d'accident et vous risquez d'être tué ou grièvement blessé. Veillez à porter la ceinture de sécurité.



- L'airbag SRS passager avant se déploie également avec une violence considérable, qui peut être très dangereuse, voire mortelle, si le passager avant se trouve très près de l'airbag. Éloignez le siège du passager avant au maximum de l'airbag et réglez le dossier de siège de façon à être assis bien droit dans le siège.
- Les nourrissons et les enfants qui ne sont pas correctement assis et/ou protégés peuvent être grièvement blessés ou tués par le déploiement d'un airbag. Installez dans un siège de sécurité enfant les enfants trop jeunes pour pouvoir utiliser la ceinture de sécurité. Lexus recommande vivement d'installer tous les nourrissons et enfants aux sièges arrière du véhicule et de prévoir pour eux des systèmes de retenue adaptés. Les sièges arrière sont plus sûrs pour les nourrissons et les enfants que le siège du passager avant.
- N'installez jamais un siège de sécurité enfant type dos à la route sur le siège du passager avant, même si le témoin indicateur "AIR BAG OFF" est allumé. En cas d'accident, par la violence et la vitesse de son déploiement, l'airbag du passager avant peut blesser grièvement, voire tuer l'enfant si vous l'avez installé à la place du passager avant dans un siège de sécurité enfant type dos à la route.




For owners

#### 

#### Précautions avec les airbags SRS

 Ne rien fixer aux portes, à la vitre du parebrise, aux vitres latérales, aux montants avant et arrière, au rail latéral de toit et à la poignée d'assistance.



- Ne suspendez aucun cintre ni objet dur aux crochets à vêtements. En cas de déploiement des airbags SRS rideaux, tous ces objets pourraient se transformer en projectiles et causer des blessures graves, voire mortelles.
- Si un cache en vinyle recouvre la partie où l'airbag SRS de genoux se déploie, veillez à l'enlever.
- N'utilisez aucun accessoire de siège venant recouvrir les zones de déploiement des airbags SRS latéraux, car il risquerait d'en gêner le déploiement. De tels accessoires peuvent empêcher les airbags latéraux de fonctionner correctement, désactiver le dispositif ou entraîner le déploiement accidentel des airbags latéraux, ce qui pourrait entraîner la mort ou des blessures graves.
- Évitez de faire subir des chocs ou des pressions excessives aux zones renfermant les composants des airbags SRS.

En effet, cela pourrait entraîner un fonctionnement anormal des airbags SRS.

- Ne touchez aucun composant du système immédiatement après le déploiement (gonflage) des airbags SRS, car ils peuvent être chauds.
- Si vous avez des difficultés à respirer après le déploiement des airbags SRS, ouvrez une porte ou une vitre pour faire entrer de l'air frais, ou bien descendez du véhicule si cela ne présente pas de danger. Essuyez tout résidu dès que possible afin d'éviter d'éventuelles irritations de la peau.
- Si les parties renfermant les airbags SRS, telles que la garniture du moyeu de volant et les garnitures de montants avant et arrière, apparaissent abîmées ou craquelées, faites-les remplacer par votre concessionnaire Lexus.
- Ne placez rien sur le siège du passager avant, comme un coussin par exemple. Cela a pour conséquence de répartir le poids du passager sur toute la surface du siège, ce qui empêche le capteur de détecter correctement le poids du passager. En conséquence, l'airbag SRS passager avant risque de ne pas se déployer en cas de choc.


#### **ATTENTION**

#### Modification et mise au rebut des éléments du système d'airbags SRS

Consultez impérativement votre concessionnaire Lexus si vous avez besoin d'intervenir sur votre véhicule, de vous en séparer ou de procéder à l'une des modifications suivantes. Les airbags SRS risquent de ne pas fonctionner correctement ou de se déployer (se gonfler) accidentellement, provoquant ainsi des blessures graves, voire mortelles.

- Installation, dépose, démontage et réparation des airbags SRS
- Réparations, modifications, démontage ou remplacement du volant, du tableau de bord, de la planche de bord, des sièges ou de leur garniture, des montants avant, latéraux et arrière ou des rails latéraux de toit
- Réparations ou modifications des ailes avant, du pare-chocs avant ou des flancs de l'habitacle
- Installation de chasse-neige, de treuils, etc., sur la calandre (pare-buffle ou pare-kangourou, etc.)
- Modifications du système de suspension du véhicule
- Installation d'appareils électroniques, tels qu'une radio émetteur/récepteur ou un lecteur CD
- Aménagements du véhicule visant à permettre sa conduite par une personne atteinte d'un handicap physique

IS350/250\_U (OM53758U)



vv hat to do if	
(Troubleshooting)	548
Alphabetical index	552

For vehicles with a navigation system, refer to the "Navigation System Owner's Manual" for information regarding the equipment listed below.


- Navigation systemAudio/video system
- Intuitive parking assist Rear view monitor system

#### 548 What to do if... (Troubleshooting)


### What to do if... (Troubleshooting)

If you have a problem, check the following before contacting your Lexus dealer.

The doors cannot be locked, unlocked, opened or closed



- If you lose your mechanical keys, new genuine mechanical keys can be made by your Lexus dealer. (→P. 100)
- If you lose your electronic keys, the risk of vehicle theft increases significantly. Contact your Lexus dealer immediately. (→P. 102)



- Is the electronic key battery weak or depleted?  $(\rightarrow P. 427)$
- Is the engine switch in IGNITION ON mode?
   When locking the doors, turn the engine switch off. (→P. 160)
- Is the electronic key left inside the vehicle? When locking the doors, make sure that you have the electronic key on your person.
- The function may not operate properly due to the condition of the radio wave. (→P. 116)



The rear door cannot be opened

• Is the child-protector lock set?

The rear door cannot be opened from inside the vehicle when the lock is set. Open the rear door from outside and then unlock the child-protector lock.  $(\rightarrow P. 106)$ 

#### ) The trunk lid is closed with the electronic key left inside

 The function to prevent the electronic key from being left inside the trunk will operate and you can open the trunk as usual. Take the key out from the trunk. (→P. 111)

#### If you think something is wrong



The engine does not start

- Did you press the engine switch while firmly depressing the brake pedal? (→P. 159)
- Is the shift lever in P? ( $\rightarrow$ P. 161)
- Is the electronic key anywhere detectable inside the vehicle?  $(\rightarrow P. 114)$
- Is the steering wheel unlocked?  $(\rightarrow P. 161)$
- Is the electronic key battery weak or depleted?
   In this case, the engine can be started in a temporary way. (→P. 489)
- Is the battery discharged? ( $\rightarrow$ P. 490)

# The shift lever cannot be shifted from P even if you depress the brake pedal

• Is the engine switch in IGNITION ON mode?

If you cannot release the shift lever by depressing the brake pedal with the engine switch in IGNITION ON mode. ( $\rightarrow$ P. 487)



#### The steering wheel cannot be turned after the engine is stopped

• It is locked automatically to prevent theft of the vehicle. ( $\rightarrow$ P. 161)



- The windows do not open or close by operating the power window switches
- Is the window lock switch pressed? The power window except for the one at the driver's seat cannot be operated if the window lock switch is pressed. (→P. 137)



#### The engine switch is turned off automatically

 The auto power off function will be operated if the vehicle is left in ACCES-SORY or IGNITION ON mode (the engine is not running) for a period of time. (→P. 161)

#### 550 What to do if... (Troubleshooting)

#### A warning buzzer sounds during driving

- The seat belt reminder light is flashing
  - Are the driver and the front passenger wearing the seat belts? ( $\rightarrow$ P. 456)
- The parking brake indicator is on
  - Is the parking brake released? ( $\rightarrow$ P. 172)

Depending on the situation, other types of warning buzzer may also sound. (  ${\rightarrow}\text{P}.455,461$  )

#### $_{\lambda})$ An alarm is activated and the horn sounds

● Did anyone inside the vehicle open a door during setting the alarm? The sensor detects it and the alarm sounds. (→P. 71)

To stop the alarm, turn the engine switch to IGNITION ON mode or start the engine.

### A warning buzzer sounds when leaving the vehicle

● Is the electronic key left inside the vehicle or the moon roof opened? Check the message on the multi-information display. (→P. 461)



#### A warning light turns on or a warning message is displayed

• When a warning light turns on or a warning message is displayed, refer to P. 455, 461.

#### When a problem has occurred




( ) If you have a flat tire

• Stop the vehicle in a safe place and replace the flat tire with the spare tire. (→P. 475)



The vehicle becomes stuck

• Try the procedure for when the vehicle becomes stuck in mud, dirt, or snow. (→P. 497)



## **Alphabetical index**

#### Α A/C ..... 346 Air conditioning filter..... ..425 Automatic air conditioning ...346 system ..... ABS (Anti-lock Brake System)...... 234 Adaptive Variable Air conditioning filter......425 Automatic air conditioning ..346 system .....

Airbags	36
Airbag operating conditions	44
Airbag precautions	
for your child	39
Correct driving posture	28
Curtain shield airbag	
operating conditions	44
Curtain shield airbag	
precautions	41
Front passenger occupant	
classification system	47
General airbag precautions	39
Locations of airbags	36
Modification and disposal	
of airbags	43
Side airbag operating	
conditions	44
Side airbag precautions	39
Side and curtain shield airbags	
operating conditions	44
Side and curtain shield	
airbags precautions	39
SRS airbags	36
SRS warning light	.455

	•	

Alarm	71
Anchor brackets	58
Antennas (smart access system	
with push-button start)	114
Anti-lock Brake System (ABS)	234
Function	234
Warning light	455
Approach warning (dynamic	
radar cruise control)	201
Armrest	367
Assist grip	369
Audio input	266
Audio system	260
Audio input	266
AUX port/USB port	266
Bluetooth <sup>®</sup> audio	309
CD player	287
iPod	293
MP3/WMA/AAC disc	287
Optimal use	274
Portable music player	300
Radio	281
Steering wheel audio switch	265
USB memory	296

### Automatic headlight leveling

system	174
Warning light	456
Automatic High Beam	176
Automatic light control	
system	173
Automatic transmission	164
If the shift lever	
cannot be shifted from P	487
M mode	167
Paddle shift switches	166
AUX port	266
Average fuel economy	
Average vehicle speed	87

В
Back-up lights
Replacing light bulbs
Wattage509
Battery408
Battery checking408
If the vehicle battery
is discharged490
Preparing and checking before
winter254
Warning light
Bluetooth®
Audio system309
Hands-free system
(for cellular phone)
Bottle holders
Brake
Fluid407
Parking brake172
Warning light
Brake assist
Break-in tips147
Brightness control
Instrument panel light control84
BSM (Blind Spot Monitor)

С	
Care	l, 387
Aluminum wheels	384
Exterior	384
Interior	387
Seat belts	388
Cargo capacity	156
Cargo hooks	362
CD player	287
Chains	255
Child restraint system	54
Booster seats, definition	55
Booster seats, installation	64
Convertible seats, definition	55
Convertible seats, installation	61
Front passenger occupant	
classification system	47
Infant seats, definition	55
Infant seats, installation	61
Installing CRS	
with LATCH anchors	59
Installing CRS with seat belts	61
Installing CRS	
with top tether strap	65

Child safety
Airbag precautions
Battery precautions
Child restraint system54
How your child should wear
the seat belt
Installing child restraints58
Moon roof precautions143
Power window lock switch137
Power window precautions 139
Rear door child-protectors106
Removed electronic
key battery precautions428
Seat belt extender
precautions35
Seat belt precautions57
Seat heater precautions354
Trunk precautions112
Child-protectors

#### Aluminum wheels..... .384 ..384 Exterior ..... Interior..... .387 Cruise control Dynamic radar cruise control ......196 Curtain shield airbags......37

555

D	
Daytime running light system	174
Defogger	
Front windshield	.350
Outside rear view mirrors	.350
Rear window	.350
Differential	
Front differential	.505
Rear differential	.505
Dimension	.500
Dinghy towing	158
Display	
Drive information	87
Dynamic radar cruise control	196
LDA (Lane Departure Alert)	209
Multi-information display	86
Warning message	461
Distance	88
Do-it-yourself maintenance	397
Door courtesy lights	
Location	.356
Wattage	.509

Doors	103
Automatic door locking	
and unlocking system	106
Door glasses	137
Door lock	105
Open door warning buzzer	104
Open door warning light	456
Outside rear view mirrors	134
Rear door child-protector	106
Drive information	87
Drive info 1/Drive info 2	88
Driver's seat position memory	123
Driving	146
Break-in tips	147
Correct driving posture	
Driving mode select switch	231
Procedures	146
Winter drive tips	254
Dynamic radar cruise control	196

E	
E-mail	319
Eco drive mode	231
Eco Driving Indicator	90
Eco Driving Indicator Light	88
EDR (Event data recorder)	10
Elapsed time	87
Electric Power Steering (EPS) 2	235
Function2	235
Warning light4	55
Electronic key	98
Battery-saving function	. 115
If the electronic key does not	
operate properly4	-88
Replacing the battery4	127

#### Emergency, in case of

If the electronic key	
does not operate properly4	88
If the engine will not start	185
If the shift lever	
cannot be shifted from P	187
If the vehicle battery is	
dischargedZ	190
If the warning buzzer	
sounds	155
If the warning light turns on	155
If the warning message	
is displayed	461
If you have a flat tire	175
If you think something	
is wrong	153
If your vehicle becomes	
stuck	197
If your vehicle has to be	
stopped in an emergency	447
If your vehicle needs	
to be towed	148
If your vehicle overheats4	194

Emergency flashers	146
Engine5	502
Accessory mode	160
Compartment	401
Engine switch	159
Hood	399
How to start the engine	159
Identification number	501
If the engine will not start4	185
Ignition switch (engine switch)	159
Overheating	194
Engine coolant4	105
Capacity5	504
CheckingZ	105
Preparing and checking	
before winter2	254
Engine coolant temperature	
gauge	81
Engine immobilizer system	.69
Engine oil2	102
Capacity5	502
Checking	102
Preparing and checking	
before winter2	254
Engine switch	159
Enhanced VSC	234
EPS	
(Electronic Power Steering)2	235
Function	235
Warning light	155
Event data recorder (EDR)	10

F	
First-aid kit storage belt	362
Flat tire	475
Floor mats	26
Fluid	
Automatic transmission	505
Brake	506
Washer	410
Fog lights	181
Replacing light bulbs	434
Switch	181
Wattage	509
Footwell light	356
Wattage	509
Front passenger occupant	
classification system	47
Front personal lights	357
Wattage	509
Front seats	120
Adjustment	120
Cleaning	387
Correct driving posture	
Driving position memory	123
Head restraints	127
Power easy access system	124
Seat heaters	355
Seat position memory	123
Seat ventilators	355

IS350/250\_U (OM53758U)

Front turn signal lights	170
Replacing light bulbs43	36,438
Turn signal lever	
Wattage	509
Fuel	
Capacity	502
Fuel gauge	
Fuel pump shut off system	454
Information	
Refueling	
Туре18	38, 502
Warning light	456
Fuel consumption	
Average fuel economy	
Current fuel consumption	
Fuel filler door	
If the fuel filler door	
cannot be opened	
Refueling	
Fuel gauge	81
Fuel pump shut off system	454
Fuses	429

#### G

Garage door opener	
Gauges	81
Gear positions	168
Glove box	359
Glove box light	

### Н

Hands-free system	
(for cellular phone)	311
HD Radio <sup>®</sup> system	281
Head restraints	127
Headlights	173
Discharge headlights	
precautions	443
Light switch	173
Replacing light bulbs	442
Wattage	509
Headlights cleaner	182
Heaters	
Air conditioning system	346
Heated steering wheel	354
Outside rear view mirrors	350
Seat heaters	355
Hill-start assist control	234
Hood	399
Open	
Hooks	
Cargo hooks	362
Coat hooks	369
Retaining hooks (floor mat)	
Horn	

#### Alphabetical index

l	
I/M test	396
Identification	
Engine	501
Vehicle	501
Ignition switch (engine switch)	159
Illuminated entry system	357
Immobilizer system	69
Indicators	78
Initialization	
Maintenance	
Moon roof	142
Multi-information display	
Power windows	138
Tire pressure	
warning system	412
Initiators (tire pressure	
warning system)	418
Inside door handle lights	356
Inside rear view mirror	132
Instrument panel light control	84
Interior lights	357
Wattage	509
Intuitive parking assist	214

#### Jack

Jack	
Positioning a floor jack	.400
Vehicle-equipped jack	476
Jack handle	476
Jam protection function	
Moon roof	141
Power windows	138

J

#### K Keyless entry

ice yiess entry
Smart access system
with push-button start103, 109
Wireless remote control103, 109
Keys
Battery-saving function
Electronic key98
Engine switch159
If the electronic key
does not operate properly 488
Key number plate98
Keyless entry98
Mechanical key99
Replacing the battery427
Warning buzzer104
Wireless remote control
Knee airbags

IS350/250\_U (OM53758U)

L
Lane Departure Alert (LDA)
Language
(multi-information display)88
LATCH anchors
LDA (Lane Departure Alert)
Lever
Auxiliary catch lever
Hood lock release lever
Internal trunk release lever111
Shift lever164
Tilt and telescopic steering
lock release lever130
Turn signal lever
Wiper lever182
Lexus Display Audio system
Lexus Display Audio controller 262
Lexus Enform*
License plate lights173
Light switch
Replacing light bulbs

#### Light bulbs

Replacing	434
Wattage	509
Lights	
Fog light switch	181
Headlight switch	173
Illuminated entry system	
Interior light	
Interior lights list	356
Personal lights	
Replacing light bulbs	434
Trunk light	111
Turn signal lever	
Vanity lights	365
Wattage	509
Lock steering column	161
Low profile tire	
Luggage security system	110

\*: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

Maintenance	
Do-it-yourself maintenance	397
General maintenance	393
Maintenance data	500
Maintenance requirements	390
Maintenance system	88
Malfunction indicator lamp	455
Master warning light	456
Meter	
Changing the display	83
Indicators	78
Instrument panel light control	84
Meters	81
Multi-information display	86
Warning lights	77
Micro dust and pollen filter	349
Mirrors	
Inside rear view mirror	132
Outside rear view mirror	
defoggers	350
Outside rear view mirrors	134
Vanity mirrors	365

Μ

#### MMS (Multimedia messaging

· 55	
service)	
Moon roof	140
Door lock linked	
moon roof operation	141
Jam protection function	141
Operation	140
MP3 disc	287
Multi-information display	86
Audio system-linked	86
Drive information	87
Dynamic radar cruise control	196
LDA (Lane Departure Alert)	209
Navigation system-linked	86
Settings	88
Switching the display	
Warning message	

### Ν

Navigation system*	
Needle	38
Noise from under vehicle	8

0	
Odometer	81
Oil	
Engine oil	502
Front differential oil	
Rear differential oil	
Opener	
Hood	
Trunk	
Outer foot lights	
Location	
Replacing light bulbs	
Wattage	
Outside rear view mirrors	
Adjusting and folding	
Blind spot monitor	
Linked mirror function	
when reversing	
Mirror position memory	
Outside rear view	
mirror defoggers	
Outside temperature	
Overheating, Engine	
5, 5	

Р	
Paddle shift switches	166
Parking assist sensors	
(intuitive parking assist)	214
Parking brake	172
Parking lights	173
Light switch	173
Replacing light bulbs	442
PCS (Pre-Collision System)	240
Function	240
PCS OFF switch	241
Warning light	456
Personal lights	357
Wattage	509
Pop-up display	
Power easy access system	124
Power outlet	366
Power steering (Electric power	
steering system)	235
steering system) Warning light	
	455
Warning light	455
Warning light Power windows	455 <b>137</b>
Warning light <b>Power windows</b> Door lock linked	455 <b>137</b> 139
Warning light Power windows Door lock linked window operation	455 <b>137</b> 139 138
Warning light Power windows Door lock linked window operation Jam protection function	455 <b>137</b> 139 138 137
Warning light Power windows Door lock linked window operation Jam protection function Operation	455 137 139 138 137 137
Warning light Power windows Door lock linked window operation Jam protection function Operation Window lock switch	455 137 139 138 137 137 240
Warning light Power windows Door lock linked window operation Jam protection function Operation Window lock switch Pre-Collision System (PCS)	455 137 138 138 137 137 

\*: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

#### Alphabetical index

#### R Radar cruise control (dynamic radar cruise control).....196 Fold down the seatback ...... 121 Rear turn signal lights ......170 Replacing light bulbs......439 Rear view mirror

Rear view monitor system	221
Rear window defoggers	50
Refueling18	88
Capacity5	02
Fuel types5	02
If the fuel filler door	
cannot be opened14	90
Opening the fuel tank cap19	90
Remote Touch*	
Replacing	
Electronic key battery4	27
Fuses4	29
Light bulbs4	32
Tires4	75
Reporting safety defects	
for U.S. owners	36
Reset the maintenance data3	391
Rev indicator	88
Rev peak	88

S	
Safety Connect	78
Seat belt reminder light45	56
Seat belts3	30
Adjusting the seat belt	31
Automatic Locking Retractor3	32
Child restraint system	
installation	61
Cleaning and maintaining	
the seat belt38	88
Emergency Locking	
Retractor	32
How to wear your seat belt3	30
How your child should wear	
the seat belt3	32
Pregnant women, proper	
seat belt use	33
Reminder light and buzzer	56
Seat belt extender	32
Seat belt pretensioners	31
SRS warning light45	55
Seat heaters35	55
Seat position memory12	23
Seat ventilators	55
Seating capacity15	56

Seats, Front120
Adjustment120
Adjustment precautions120
Child seats/child restraint
system installation58
Cleaning
Driving position memory123
Head restraints
Power easy access system
Properly sitting in the seat
Seat heaters
Seat position memory
Seat ventilators
Seats, Rear
Seats, Kear
Fold down the seatback121
Luggage security system
Sensor
Automatic headlight system
Inside rear view mirror133
Intuitive parking assist214
Radar sensor
Rain-sensing windshield
wipers
Service reminder indicators

\*: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

### 565

Shift lever	
Automatic transmission	
If the shift lever	
cannot be shifted from P487	
Shift lock system	
Shift position and gear position81	
Side airbags	
Side marker lights173	
Light switch173	
Replacing light bulbs442	
Side mirrors134	
Adjusting and folding134	
Blind Spot Monitor246	
Linked mirror function	
when reversing135	
Mirror position memory123	
Side turn signal lights170	
Replacing light bulbs442	
Turn signal lever170	
Slip indicator	
Smart access system	
with push-button start 114	
Antenna location114	
Entry functions103, 109	
Starting the engine159	

SMS (Short message service)	
Snow mode	165
Snow tires	256
Spare tire	475
Inflation pressure	507
Storage location	476
Spark plug	504
Specifications	500
Speedometer	
Speed indicator	
Steering lock	161
Column lock release	161
Steering wheel	130
Adjustment	130
Audio switches	265
Heated steering wheel	354
Power easy access system	124
Steering wheel	
position memory	123
Stop lights	
Replacing light bulbs	442
Storage feature	358
Stuck	
If the vehicle becomes stuck	497
Sun visors	365

-	Ł	-	
Э	О		

Sun shade	
Rear	7
Roof14	1
switch settings88	3
Switches	
Audio remote control	
switches265	)
BSM (Blind spot monitor)	
switch265	)
Cruise control switch	)
Door lock switches105	
Driving mode select switch	1
Driving position memory	
switches123	3
Dynamic radar cruise	
control switch196	)
Emergency flashers switch	)
Engine switch159	)
Fog light switch18	1
Garage door opener	
switches	)
Heated steering wheel	
switch	ŀ
Ignition switch159	)
Intuitive parking assist214	ł
LDA (Lane Departure Alert)	
switch	)
Light switches173	3
Meter control switches	

Moon root switches	140
Outside rear view mirror	
switches	134
Paddle shift switches	166
PCS OFF switch	
Power door lock switch	105
Power window switches	137
Rear sunshade switch	
Rear window and outside	
rear view mirror defoggers	
switch	350
Seat heater switches	355
Seat ventilator switches	355
Snow mode switch	165
Steering wheel switch	
"SOS" button	378
Talk switch	
Telephone switches	
Tilt and telescopic	
steering control switch	130
Tire pressure warning reset	
switch	413
Trunk opener switch	109
Trunk opener main switch	110
Vehicle-to-vehicle distance	
button	199
VSC OFF switch	236
Window lock switch	137
Windshield wipers	
and washer switch	

Т	
Tachometer8	1
Tail lights173	3
Light switch173	3
Replacing light bulbs442	2
Talk switch*32	1
Telephone switches <sup>*</sup> 32	1
Theft deterrent system	
Alarm7	1
Engine immobilizer system69	)
Luggage security system110	)
Theft prevention labels73	3
Tire inflation pressure	)
Maintenance data507	7
Tire inflation pressure display	
function412	2
Warning light457	7
Tire information	3
Glossary520	)
Size	
Tire identification number	5
Uniform Tire Quality	
Grading518	3

Tire pressure warning system	412
Function	412
Initializing	412
Installing tire pressure warning	
valves and transmitters	412
Registering ID codes	414
Tire pressure warning reset	
switch	413
Warning light	457
Tires	411
Chains	255
Checking	411
If you have a flat tire	475
Inflation pressure	507
Information	513
Replacing	475
Rotating tires	411
Size	507
Snow tires	256
Spare tire	475
Tire inflation pressure display	
function	412
Tire pressure warning system	412
Warning light	457

5	6	9

Tools	
Top tether strap65	
Total load capacity156	
Towing	
Dinghy towing158	
Emergency towing	
Towing eyelet449	
Trailer towing157	
TRAC (Traction Control)	
Transmission164	
Automatic transmission	
Driving mode select switch231	
If the shift lever cannot be	
shifted from P487	
M mode167	
Paddle shift switches166	
Trip meters81	

Trunk	109
Internal trunk release lever	111
Luggage security system	110
Smart access system	
with push-button start	109
Trunk features	
Trunk handle	110
Trunk light	111
Trunk opener main switch	110
Trunk opener switch	109
Wireless remote control	
Trunk light	
Wattage	509
Turn signal lights	170
Replacing light	
bulbs 436, 438, 43	39, 442
Turn signal lever	
Wattage	

\*: For vehicles with a navigation system, refer to the "Navigation System Owner's Manual".

V

#### Vanity lights

Vanity lights	
Vanity lights	365
Wattage	509
Vanity mirrors	365
Variable Gear Ratio Steering	
(VGRS)	234
VDIM (Vehicle Dynamics	
Integrated Management)	235
Vehicle data recordings	9
Vehicle Dynamics Integrated	
Management (VDIM)	235
Vehicle identification number	501
Vehicle Stability Control	
(VSC)	234
Ventilators (seat ventilators)	355
VGRS (Variable Gear Ratio	
Steering)	234
Voice command system	341
VSC	
(Vehicle Stability Control)	234

### W

Warning buzzers	
Brake system	455
Downshifting	168
Key reminder	472
Open door	456
Open moon roof	466
Open hood	463
Open trunk	463
Open window	466
Seat belt reminder	456
Warning lights	77
ABS	455
Automatic headlight leveling	
system	456
Brake system	455
Charging system	455
Electric power steering	455
Low fuel level	456
Malfunction indicator lamp	455
Master warning light	456
Open door	456
Pre-collision system	456
Seat belt reminder light	456
Slip indicator	456
SRS	455
Tire pressure	457
Warning messages	461
Warning reflector storage belt	

Washer 182
Checking
Preparing and checking
before winter254
Switch
Washing and waxing
Weight
Cargo capacity156
Load limits156
Weight
Wheels
Replacing wheels423
Size
Window glasses137
Window lock switch137
Windows137
Power windows137
Rear window defogger350
Windshield wiper de-icer350
Windshield wipers
Intermittent windshield
wipers with interval adjuster 182
Rain-sensing windshield
wipers
Winter driving tips254
Wireless remote control98
Battery-Saving Function115
Locking/Unlocking103, 109
Replacing the battery
WMA disc

#### X XM<sup>®</sup> Satellite Radio......281

IS350/250\_U (OM53758U)

571

