

TECHNOLOGY  
REFERENCE  
GUIDE



*CR-Z*

[owners.honda.com](http://owners.honda.com)

31S2TQ30  
00X31-SZT-Q300

2014 Honda CR-Z Technology Reference Guide  
©2013 American Honda Motor Co., Inc. — All Rights Reserved

Printed in Japan



2014

# TECHNOLOGY REFERENCE GUIDE

This Technology Reference Guide is designed to help you get acquainted with your 2014 Honda CR-Z and provide basic instructions on some of its technology and convenience features.

This guide is not intended to be a substitute for the Owner's Manual. For more detailed information on vehicle controls and operation, please refer to the respective sections in the Owner's Manual or Navigation Manual.

As with the Owner's Manual, this guide covers all trims of the CR-Z. Therefore, you may find descriptions of equipment and features that are not on your particular vehicle.



|  |    |
|--|----|
| Instrument Panel Indicators .....            | 2  |
| Multi-Information Display (MID) .....        | 4  |
| Auto Door Locks .....                        | 6  |
| Fuel Fill Door .....                         | 7  |
| Eco Assist™ .....                            | 8  |
| 3-Mode Drive System .....                    | 12 |
| Plus Sport System .....                      | 13 |
| Tire Pressure Monitoring System (TPMS) ..... | 14 |
| Paddle Shifting* .....                       | 15 |
| Rearview Camera* .....                       | 16 |
| Multi-View Rear Camera* .....                | 17 |

|                                       |    |
|---------------------------------------|----|
| Voice Recognition* .....              | 18 |
| Navigation* .....                     | 22 |
| Bluetooth® HandsFreeLink® (HFL) ..... | 25 |
| SMS Text Messaging* .....             | 31 |
| iPod® or USB Flash Drive .....        | 32 |
| Bluetooth® Audio* .....               | 33 |
| Pandora®* .....                       | 34 |
| Honda Owners .....                    | 35 |
| Safety Reminder .....                 | 35 |
| Fuel Recommendation .....             | 36 |

\*if equipped













## INSTRUMENT PANEL INDICATORS

Briefly appear with each engine start. Red and amber indicators are most critical. Blue and green indicators are used for general information. See your Owner's Manual for more information.







### Malfunction Indicators

If an indicator remains on, there may be a problem; see a dealer

|  |  |
|--|--|
|  Charging system                       |  Anti-Lock Brake System (ABS)                                   |
|  Low brake fluid, Brake system         |  IMA System   |
|  Low oil pressure                      |  Malfunction lamp (check engine light)                          |
|  Supplemental Restraint System (SRS) |  Vehicle Stability Assist® (VSA)                              |
|  Electric Power Steering (EPS)       |  Tire Pressure Monitoring System (TPMS) (blinks and stays on) |
|  Low engine temperature (stays on)   |  Transmission (blinks)  |














### Condition Indicators

Action is needed by driver

|  |  |
|--|--|
|  Parking brake on: <b>Release</b>              |  Seat belt reminder: <b>Fasten seat belt(s)</b> |
|  Door/Hatch open: <b>Close door(s) / hatch</b> |  Low fuel: <b>Refill</b>                        |

|   |   |
|---|---|
|  Low tire pressure: <b>Add air</b> |  High temperature indicator: <b>Pull over for engine cooling</b>   |
|  Message indicator: <b>See MID</b> |  Immobilizer (blinks): <b>Use other vehicle key and see dealer</b> |

### On/Off Indicators

|  |  |
|--|--|
|  SIDE AIRBAG <b>OFF</b>                            |  NORMAL mode <b>on</b>               |
|  PASSENGER AIRBAG <b>OFF</b> (center audio panel) |  ECON mode <b>on</b>                |
|  VSA <b>OFF</b>                                   |  Plus Sport System <b>on</b>        |
|  Auto Idle Stop <b>on</b> (blinking)              |  Fog lights <b>on</b> (if equipped) |
|  CRUISE MAIN <b>on</b>                            |  Exterior lights <b>on</b>          |
|  CRUISE CONTROL <b>on</b>                         |  Turn signals/hazards <b>on</b>     |
|  SPORT mode <b>on</b>                             |  High beams <b>on</b>               |


## MULTI-INFORMATION DISPLAY (MID)

Consists of several displays that provide you with useful information.

### Accessing the Multi-Information Display



When you start the engine, the MID shows the main display.




To toggle between the MID displays:

- Press either Info button (▲/▼) for the main displays.
- Press SEL/RESET for the sub-displays.



### MID Main Displays



\*if a call is active

## AUTO DOOR LOCKS

Program how and when the vehicle doors automatically lock and unlock.

### Default Lock/Unlock Setting



#### Default Lock Setting

All doors and the hatch are preset to lock when your vehicle reaches about 10 mph.

#### Default Unlock Setting

Only the driver's door and hatch are preset to unlock when you shift into Park (P)\*.

*\*When you turn the ignition to LOCK (0) for manual transmission vehicles*

### Modifying the Auto Door Unlock Setting

Press either Info (▲/▼) button on the steering wheel to toggle to the Customize Settings display on the MID, then press SEL/RESET to activate the menu. See your Owner's Manual for all programmable options.

1. Select CHG SETTING.



2. Select DOOR SETUP.




3. Select AUTO DOOR UNLOCK.



4. Select one of the options.



5. Select one of the options.



6. Select EXIT to save the setting and exit the menu.



**Note:** The driver's and passenger's doors can be opened by pulling the inner front door handle, regardless of the setting.

## FUEL FILL DOOR

Easy-to-open fuel door keeps your fuel cap covered.

### Opening and Closing the Fuel Fill Door

To open, push and release the fuel door in the area shown until you hear a click and it pops open.



To close, push the fuel door flush with the body.



## ECO ASSIST™

Provides various ways to monitor your fuel efficiency and driving style.

### Activating the ECON Mode

1. Press ECON.



3. Check the MID.



2. The ECON mode indicator comes on.




4. Press either INFO (▲/▼) button and toggle to the Ecological Drive Display.













**Note:** When turned on, performance of the vehicle's engine, transmission, cruise control, and air conditioning system are adjusted to maximize fuel efficiency.

### Driver Feedback



#### Real-time Fuel Efficiency Coach

| Driving Style   | Eco Drive Bar (on the MID)  | Ambient Meter Background Color Changes  | Fuel Efficiency  |     |
|---|---|---|--|-----|
| Smooth, steady acceleration<br><b>maximizes fuel efficiency</b> |    |    | <br>High |     |
| Smooth, steady deceleration<br><b>maximizes fuel efficiency</b> |    |   |  |     |
| Moderate acceleration   |  |  |  |     |
| Moderate deceleration   |  |   |  |     |
| Rapid acceleration<br><b>lowers fuel efficiency</b>             |  |  |  | Low |
| Rapid deceleration<br><b>lowers fuel efficiency</b>             |  |   |  |     |

#### Goals:

- Keep the Eco Drive bar near the center.
- Keep the Ambient Meter at **GREEN**.
- Develop a driving style that maximizes fuel efficiency.

*NORMAL/ECON mode shown*



## Eco Assist Scoring

Monitors the fuel efficiency of your driving style in real time and converts results into leaves, which are displayed in a series of five “plant” icons on the MID.

Once you start your vehicle, make sure the MID shows the Ecological Drive Display on the display to view your Eco Assist score in real time.



As you drive, you earn leaves if you drive in a fuel-efficient manner, or lose them if you drive inefficiently.




When you turn the ignition off, your drive cycle and lifetime score are displayed on the MID.



### Eco Score


Each time you reach a new stage, a Stage Up Recognition icon briefly appears on the MID. When you reach the highest ranking, a trophy icon briefly appears.



## Auto Idle Stop

Shuts the engine off at a stop to maximize fuel efficiency. Idle stop occurrence and duration varies depending on the selected drive mode, ambient conditions, and IMA battery condition. See your Owner's Manual for more information.

### How It Works



### AUTOMATIC TRANSMISSION

While driving, the engine is on.

At a stop with the brake pedal pressed, the engine turns off.

When you take your foot off the brake pedal, the engine turns back on.

**Note:** Auto Idle Stop only functions if you come to a stop while driving with the transmission in the D or N position.

### MANUAL TRANSMISSION

While driving, the engine is on.

At a stop with the brake pedal pressed and the transmission in neutral, the engine turns off.

When you take your foot off the brake pedal and fully depress the clutch, the engine turns back on.

## IMA Gauge

Shows when the IMA motor is assisting the engine or charging the battery.



**Note:** IMA assist may not operate in extreme temperatures, or if the battery is low on charge.

## 3-MODE DRIVE SYSTEM

Select one of three different modes of driving styles.



### Driving Modes

When a mode is selected, a message briefly appears on the MID and the mode indicator turns on.





#### Sport Mode

- Enhanced steering, handling, and performance response.
- Reduced fuel efficiency.
- Ambient meter turns red.



#### Normal Mode

- Achieves the best balance of driving performance and fuel efficiency.
- This is the default mode at engine start.
- Ambient meter changes from blue to green.



#### Econ Mode

- Fuel efficiency is prioritized over engine response and climate control.
- Ambient meter changes from blue to green.



## PLUS SPORT SYSTEM

Helps the vehicle briefly accelerate by increasing power and electric motor assist when you depress the gas pedal. Works in any driving mode.

### How It Works

When the vehicle speed is over 20 mph and the IMA battery charge level shows at least four segments, the Plus Sport System indicator appears. The system is now ready for activation.



### Activating the System

- When the Plus Sport System indicator is on, press the S+ button.
- S+ begins to blink. Depress the gas pedal to activate the system.
- S+ blinks, READY disappears, and the ambient meter turns red when the system is in operation.
- To cancel the system during operation, release the gas pedal or press the S+ button again.





## TIRE PRESSURE MONITORING SYSTEM (TPMS)

Monitors the vehicle's tire pressures.

### How It Works



When the tire pressure drops significantly below recommended levels, the low tire pressure indicator comes on and CHECK TIRE PRESSURE appears on the MID.

If there is a problem with the system, CHECK TPMS SYSTEM appears on the MID. See a dealer.

### What to Do

1. Visually inspect the tires for damage.
2. Use a tire air pressure gauge to check which tire(s) have low pressure.
3. Inflate the tire(s), if necessary, to the recommended pressures listed on the label on the driver's doorjamb.




## PADDLE SHIFTING


While in the D position, 7-Speed Manual Shift Mode allows you to manually shift your vehicle's speeds up or down. Useful for engine braking or when driving in hilly terrain or cornering. Available on vehicles with automatic transmission.

### Paddle Modes

Pull (-) to shift down.




Pull (+) to shift up.




#### NORMAL or ECON Mode

- Pull (+) or (-) to temporarily switch from automatic to manual shift mode.
- The speed number is displayed on the shift indicator display.
- When the vehicle's speed is constant, the mode returns to automatic.




#### SPORT Mode

- Pull (+) or (-) to switch to manual shift mode.
- The M indicator and speed number are displayed on the shift indicator display.
- Pull (+) or (-) to change transmission speeds.
- Pull and hold (+) to cancel this mode.



#### L (Low) Mode

- Pull and hold (+) and (-) at the same time until L is displayed on the shift indicator display.
- Use this mode to get higher torque when climbing steep hills.
- Pull and hold again to cancel this mode.



## REARVIEW CAMERA

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up. *Available on vehicles without navigation.*

### How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the rearview mirror; along with helpful parking guidelines.
- The display turns off when you shift out of Reverse.
- Press and hold the power button for 3 seconds to turn the guidelines off. Repeat to turn back on.




## MULTI-VIEW REAR CAMERA

For added convenience, the area behind your vehicle is displayed to help you navigate while backing up. *Available on vehicles with navigation.*

### How It Works

- When you shift into Reverse (R), a real-time image of the area behind your vehicle is shown in the navigation display.
- The rearview display turns off when you shift out of Reverse.



### Parking Guidelines

- Yellow parking guidelines also appear to help you judge distance. They can be turned on or off.
- Press and hold CANCEL until the guidelines turn on or off. They remain off until you turn them on again.




### Switching Views

There are three rearview modes: wide, normal, and top down.

- Select the corresponding icon to change views.
- Press ZOOM (▲/▼) to adjust the screen brightness.



## VOICE RECOGNITION

To keep your eyes on the road and hands on the wheel, use the  Talk button to say voice commands to operate certain vehicle features.

### Key Functions by Voice Command

The voice control system uses the steering wheel buttons and the ceiling microphone.

**To reduce the potential for driver distraction, certain manual and touchscreen functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.**



**Pick-Up button:** Answer an incoming call, or go directly to the Phone screen.




**Talk button:** Say navigation, HFL, audio, and climate control commands.



**Hang-Up button:** End a call or decline a call.




**Back button:** Cancel a command or return to the previous screen.



### NAVIGATION p.22



### BLUETOOTH® HANDSFREELINK® p.27






### AUDIO p.21



### CLIMATE p.21



### Voice Command Tips

- Press and release the  Talk button, wait for a beep, then say a command.
- All available voice commands are highlighted in blue when you press the  Talk button.
- For a list of available commands, press and release the  Talk button and say "Help" at any time. For a full list of commands, say "Display information" and "Voice info," or see your Navigation Manual.
- Speak in a clear, natural voice, and reduce all background noise.
- Adjust the dashboard and side vents away from the microphone in the ceiling.
- Close the windows.
- The system also uses a touchscreen display. You can select options or icons by touching them on the screen. This is limited while the vehicle is moving.

## Commonly Used Voice Commands


Here are some examples of commonly used voice commands. Try some of these to familiarize yourself with the voice command system.

Press and release the  Talk button before you say a command.

### General Commands

(Accepted on most screens to change displays)

- Display map
- Display menu
- Display information
- Display audio
- What time is it?
- Next/previous (to change pages)
- Left/right (to change tabs)
- Up/down (to scroll lists up to three pages)



### Find Place Commands

(Accepted on Map screen)

- Find nearest:
  - ATM
  - gas station
  - Mexican restaurant
  - Honda dealer
  - airport
  - hospital
  - bank
  - post office



### Navigation Commands

(Accepted on Map screen)


- How long/far to the destination?
- Display destination map
- Display entire route




### Display Commands

(Accepted on Map screen)

- Display/Hide:
  - ATM
  - gas station
  - restaurant
  - post office
- Display north up/heading up
- Zoom in/out
- Go home
- Display current location



Press and release the  Talk button before you say a command.

### Audio Commands

(Accepted on most screens)

- Radio on
- Radio # FM/AM
- Radio preset 1/2/3/4/5/6
- DISC/USB/iPod play
- DISC/USB/iPod skip forward/back
- Auxiliary (AUX) play




### Phone Commands

(Accepted on Phone screen)

- Dial
- Speed Dial 1 (or 2)
- Redial
- Phonebook
- Phone setup

(Accepted on any screen)

- Dial by number
- Dial by voice tag



### Climate Control Commands

(Accepted on most screens)

- Air conditioner on/off
- Rear defrost on/off
- Climate control recirculate/fresh air
- Fan speed up/down
- Temperature # degrees (# = 57-87)
- Temperature max hot/cold



### Help Commands

(Accepted on most screens)

- Help (list of available commands for current screen)
- Voice info - from INFO screen (list of all available commands by category)






## NAVIGATION

### Entering a Destination Using Voice Commands

Set a destination using a street address. For other destination options, see your Navigation Manual.

Press and release the  Talk button before you say a command.

1. Say "Display menu." Say "Address."
2. Say "Street," then say the street name on the next screen. Do not include the direction (N, S, E, W) or type (St, Ave, Blvd, etc.).
3. A list of street names appears. Say the number next to the street you want to select.
4. Say the entire street address number. For example, "1-2-3-4." If necessary, say "OK" to proceed.
5. If the street address is in more than one city, a list of city names appears. Say the number next to the city you want to select.
6. The system displays the "Calculate route to" screen. Say "Set as destination" to set the route.



**Note:** It is recommended that you enter your destination before driving or when the vehicle is stopped.




Real-time navigation system uses GPS and a map database to show your current location and help guide you to a desired destination. Available on vehicles with navigation.

### Using the "Find Nearest" Command


Find a nearby point of interest, such as a gas station, movie theater, restaurant, etc.

Press and release the  Talk button before you say a command.

1. From the map screen, say "Find nearest ATM."
2. A list of the nearest ATMs in your area is displayed by shortest distance to destination.
3. Say the number next to the destination you want to select.
4. The system displays the "Calculate route to" screen. Say "Set as destination" to set the route.




### Map Screen Legend







## FM Traffic

Provides continuously updated information, including traffic speed, incidents, and construction in major metro areas. Works in cities where a clear FM traffic signal is available.

Press and release the  Talk button before you say a command.

### Displaying Traffic Information

Say "Display traffic" to view highway flow data.



**Heavy traffic**

**Moderate traffic**

**Note:** Traffic flow and incident icons are only displayed on map scales of 5 miles or less.

#### Traffic Icons:



Incident



Road closed



Construction




Weather


### Traffic Rerouting

When a destination is already set, you can create a detour to avoid traffic incidents or congestion.


1. Say "Display traffic list" to view a list of incidents on your route.




3. Say "Avoid," and the incident list returns.



2. Say the number of the incident you want to avoid. When the incident appears, say "Traffic detail."



4. Say "Reroute" to set the new route.



## BLUETOOTH® HANDSFREELINK® (HFL) (without navigation)

Make and receive phone calls through your vehicle's audio system. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if this feature is compatible with your phone.

### How to Use HFL



**HFL Talk button:** Give HFL commands or answer incoming calls.

**HFL Back button:** End a call, go back to the previous command, or cancel an operation.




### Pairing Your Phone

You can pair your phone only when your vehicle is stopped.

Press and release the HFL Talk button before you say a command.

1. Enable discovery mode on your phone.
2. If no phone has been paired before, the system gives you instructions. If you are pairing an additional phone, say "Phone setup," then say "Pair."
3. HFL gives you a four-digit code that also appears on the MID.
4. Search for HandsFreeLink from your phone, and enter the code when prompted. Connect to HFL.
5. HFL asks you to name the phone. For example, say "Mary's phone." The phone is now added.






## Making a Call

Press and release the HFL Talk button before you say a command.

1. Say "Call" or "Dial" and the phone number.
2. Say "Call" or "Dial" to continue.
3. The call is connected and heard through the vehicle's speakers.



## HFL Phonebook

Store up to 50 names and their phone numbers, which can be used as speed dials.


Press and release the HFL Talk button before you say a command.

1. Say "Phonebook."
2. Say "Store."
3. Say the name of the contact, and then the phone number.
4. To call a contact once an entry is stored, say "Call Mike."



## Receiving a Call

A notification is heard and the incoming phone number appears on the MID.



Press the HFL Talk button to accept the call.



Press the HFL Back button to end or decline the call.



## BLUETOOTH® HANDSFREELINK® (HFL) (with navigation)

Make and receive phone calls through your vehicle's audio system. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if this feature is compatible with your phone.

**To reduce the potential for driver distraction, certain manual and touch screen functions may be inoperable or grayed out while the vehicle is moving. Voice commands are always available.**

## How to Use HFL



**Pick-Up button:** Answer an incoming call, or go directly to the Phone screen.




**Talk button:** Give navigation, HFL, audio, or climate control commands.



**Hang-Up button:** End a call or decline a call.



**Back button:** Cancel a command and return to the previous screen.



Use these buttons to navigate through the HFL menus.

**Joystick/ENTER button:** Move up, down, left, or right to scroll options, and press to make a selection.



**PHONE button:** Go directly to the Phone screen.


**CANCEL button:** Press to cancel an operation or return to the previous screen.

## Pairing Your Phone


Use this pairing method when no phone has ever been paired to the system. You can pair your compatible phone only when the vehicle is stopped.

Press and release the  Talk button before you say a command.

1. Press PHONE to go to the Phone screen. A prompt appears. Say "Yes."
2. Make sure your phone is in discovery mode. Say "OK."




3. HFL searches for your phone. Say the number next to the phone when it appears on the list.



*If your phone does not appear:*  
Say "Find another phone," and search for HandsFreeLink from your phone. Connect to HFL.


4. HFL gives you a four-digit code. Enter it on your phone when prompted. The phone is now paired.




Use this pairing method when a phone has already been paired to the system, or when you want to pair an additional phone.

Press and release the  Talk button before you say a command.

1. Press PHONE to go to the Phone screen. If a prompt appears asking to connect to a phone, say "No."
2. Say "Phone setup."




3. Say "Bluetooth setup add select a phone."
4. Say "Search."




5. Make sure your phone is in discovery mode. Say "OK."

6. HFL searches for your phone. Say the number next to the phone when it appears on the list.




*If your phone does not appear:*  
Say "Find Another Phone," and search for HandsFreeLink from your phone. Connect to HFL.

7. HFL gives you a four-digit code. Enter it on your phone when prompted. The phone is now paired.




## Dialing a Number

Enter a 10-digit phone number to call.

Press and release the  Talk button before you say a command.


1. Press PHONE to go to the Phone screen.
2. Say "Dial."
3. Say the entire phone number. For example, "3-1-0-5-5-1-2-3-4."
4. Say "Dial" to begin the call.




**Note:** You can also say "Dial by number," followed by the phone number and "Dial" from any screen.

## Using the Phonebook

When your phone is paired, its entire phonebook is automatically imported to the system. This feature is inoperable when the vehicle is moving.

Press and release the  Talk button before you say a command.

1. Press PHONE to go to the Phone screen.
2. Say "Phonebook."
3. Scroll through the list to find the name and number you want.
4. Say "Call" to begin the call.




## Using Speed Dial

Store up to 15 numbers for quick calling. See your Navigation Manual for instructions on storing voice tags.

Press and release the  Talk button before you say a command.


1. Press PHONE to go to the Phone screen.
2. Say “Speed Dial 1” (or “Speed Dial 2”) and the number next to the entry. For example, “One.”
3. Say “Call” to begin the call.




**Note:** If an entry has a stored voice tag, you can say “Dial by voice tag,” followed by the voice tag name and “Dial” from any screen.


## Receiving a Call

A notification is heard and the following screen appears:



Press the  (Pick-Up) button to answer the call.



Press the  (Hang-Up) button to end or decline the call.




## SMS TEXT MESSAGING

Receive and send text messages from your paired and linked compatible phone. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to see if this feature is compatible with your phone. Standard message rates apply. This feature is limited while the vehicle is moving. Available on vehicles with navigation.


## Receiving Text Messages

Press and release the  Talk button before you say a command.


1. A notification appears on the navigation screen.
2. Say “Read” to open the message. It is displayed, and the system reads it aloud.




## Replying to Text Messages

Press and release the  Talk button before you say a command.


1. With the message open, say “Reply.”
2. Say the number next to one of the six available reply messages.
3. Say “Send” to send the message.



## Calling the Sender

Press and release the  Talk button before you say a command.

1. With the message open, say “Call.”
2. HFL begins dialing the number.




## iPod® OR USB FLASH DRIVE

Play audio files from your compatible iPod or USB flash drive through your vehicle's audio system.

### Connecting Devices and Playing Audio

1. Pull out the USB adapter cable from the front console.
2. Press AUX or CD/AUX until iPod or USB mode appears. Audio begins to play.
3. Press (⏮) (⏭) or (+) (-) to change tracks.



Connect the USB adapter cable to your iPod cable or flash drive.



**Note:** Connect your device only when your vehicle is stopped.

*Model with navigation shown  
iPod is a trademark of Apple, Inc.*

## BLUETOOTH® AUDIO

Play stored or streaming audio files from your compatible phone through your vehicle's audio system. Visit [handsfreelink.honda.com](http://handsfreelink.honda.com) to check if this feature is compatible with your phone. Available on vehicles with navigation.

### Playing Bluetooth Audio

1. Make sure your phone is on and paired to Bluetooth® HandsFreeLink® (see [page 28](#)).
2. Press CD/AUX until Bluetooth Audio mode appears.
3. From your phone, open the desired audio player or app and begin playing. Sound is redirected to the audio system.
4. Press (⏮) (⏭) or (+) (-) to change tracks.



3. From your phone, open the desired audio player or app and begin playing. Sound is redirected to the audio system.

Make sure the volume on your phone is properly adjusted.

#### Notes:


- You may need to enable additional settings on your phone for playback.
- Remote audio controls and the play/pause function may not be supported on all phones.
- Operate your phone only when your vehicle is stopped.

## PANDORA®

Play and operate Pandora from your iPhone® through your vehicle's audio system. Standard data rates apply. Available on vehicles with navigation.

### Playing Pandora

1. Pull out the USB adapter cable from the front console. Connect the USB adapter cable to your iPhone cable.
3. From the audio screen, select items such as Station List, Like/Dislike, and Pause/Resume.\*



2. Open Pandora from your phone. Press CD/AUX until Pandora mode appears and streaming begins.



4. Press (⏮) or (+) to change tracks.




#### Notes:

- If Pandora is not selected from your phone, iPod music is played.
- Press the Home button on your iPhone to switch from Pandora to iPod. To play Pandora again, you must reopen the app from your phone.
- If you cannot operate Pandora through the audio system, it may be streaming through Bluetooth® Audio. Make sure Pandora mode on your audio system is selected. If Pandora still does not operate, you may have to reconnect the cable.
- A pop-up may appear on your phone requesting you to allow access for Pandora to be launched.
- Connect your phone only when your vehicle is stopped.

\*Menu functions not available on all phones  
iPhone is a trademark of Apple, Inc.

## HONDA OWNERS

Visit [owners.honda.com](http://owners.honda.com) and register to explore features and technologies specific to your vehicle, obtain and update maintenance and service records, manage your financial services account, and access other useful information. For added convenience, Honda Owners can also be accessed on a mobile device.



## SAFETY REMINDER

Your vehicle is equipped with airbags. Airbags do not replace seat belts; they add to the protection offered by seat belts. Airbags can help protect you in some types of collisions, but they do not provide protection in all collisions.

Always make sure you and your passenger wear seat belts.

Never carry an infant in a rear-facing child seat in this vehicle; a deploying airbag could seriously injure or kill them.

Further, the National Highway Traffic Safety Administration (NHTSA) and Transport Canada both recommend that all children age 12 and under be properly restrained in a back seat. Since this vehicle does not have a back seat, we strongly recommend that you do not carry a child aged 12 or under in this vehicle.

Honda further recommends that you do not carry any child who is not large enough or mature enough to ride in the front passenger seat for the following reasons:

- An inflating front or side airbag can injure or kill a child sitting in the front passenger seat.
- A child in the passenger seat is more likely to interfere with the driver's ability to safely control the vehicle.

## FUEL RECOMMENDATION

Use of unleaded gasoline of 87 octane or higher is recommended.

- Honda recommends TOP TIER Detergent Gasoline where available.
- Do NOT use gasoline containing more than 15% ethanol.
- Do NOT use gasoline containing methanol.
- Do NOT use gasoline containing MMT.
- See your Owner's Manual for more information.

Some gasoline in North America contains MMT, a manganese-based fuel additive. Prolonged and consistent use of gasoline containing MMT can deteriorate your vehicle's performance, fuel economy, and the emission control system. Always use MMT-free gasoline if available. Failures caused by use of gasoline containing MMT may not be covered under your new vehicle warranty.

TOP TIER Detergent Gasoline (recommended) never contains MMT and has detergent additives to keep your engine clean. For further information on fuel and lubricants for your car and information on gasoline that does not contain MMT, contact your dealer or visit [owners.honda.com](http://owners.honda.com).